

HITACHI

Color LCD Television

Model Name

32LD9800TA
37LD9800TA

USER'S MANUAL

用戶手冊

用戶手冊

РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ



This is the image of the model 32LD9800TA.
Desktop stand is optional for 37LD9800TA.



READ THE INSTRUCTIONS INSIDE CAREFULLY.
KEEP THIS USER'S MANUAL FOR FUTURE REFERENCE
For future reference, record the serial number of your television.
SERIAL NO. _____

This serial number is located on the rear of the television.

USER'S MANUAL

Thank you for purchasing the HITACHI LCD Television.
Please read this user's manual carefully before
operating this product.
To ensure proper operation, please read and follow ALL
the instructions, especially the "IMPORTANT SAFETY
INSTRUCTIONS" and "SAFETY PRECAUTIONS".
Please keep this user's manual for future reference.

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	1
INTRODUCTION	2
About This Manual	2
Trademark Credits	2
About Software	2
SAFETY PRECAUTIONS	3
About the Symbols	3
Cleaning and Maintenance	6
ABOUT LCD PANEL	7
Common Phenomena of LCD Panel	7
FEATURES	8
SUPPLIED ACCESSORIES	8
OPTION	8
COMPONENT NAMES	9
Main Unit	9
Remote Control	10
PREPARATION	11
Remote Control Batteries Installation	11
Handling the Remote Control	11
Caution When Moving the Main Unit	11
Safety Precaution on Main Unit Installation	12
Anti-Tumble Measures	12
CONNECTION	13
Terminal Positions	13
Connecting Procedure	13
BASIC OPERATION	18
Power On/Off	18
First Time Setup	19
Volume UP/DOWN	19
Mute	19
Input Switching to TV/AV1~4, and HDMI	20
Input Signal Screen Display	20

MENU OPERATION	21
How to use the On-Screen Display (OSD) system	21
Language Menu	21
Setup Menu (TV mode)	22
Setup Menu (AV mode)	24
Function Menu	25
Picture Menu	26
Audio Menu	29
Timer Menu	30
FUNCTION	31
Power Swivel	31
About Teletext	32
Size Switching	33
Picture Freezing	35
Audio Switching	36
Power Save Mode	37
DVD Player / STB Selection	38
TROUBLESHOOTING	39
When Following Messages Appear on the Screen	39
Symptom and Check List	39
PRODUCT SPECIFICATIONS	41
Signal Input	42
Recommended Signal List	42

IMPORTANT SAFETY INSTRUCTIONS

- Read this instruction thoroughly.
- Retain this instruction for future reference.
- Heed all warnings and cautions to prevent possible danger.
- Follow all instructions. Improper handling could cause personal injury and/or serious damage to the unit that may shorten its service time.
- Do not block any ventilation openings.
- Install the product in accordance with the manufacture's instructions.
- Before calling for the technical support or service technician, read "TROUBLESHOOTING" (39, 40) to determine the symptoms when problems occur during installation or operation of the product.
- If serious problems happen (such as smoke or an abnormal odor from the unit), turn off the Main Power, unplug the Power Cord, and then, contact your local dealer immediately.

INTRODUCTION

Thank you for purchasing the HITACHI LCD Television. We hope that you will enjoy the great performance with this product.

This LCD television has been designed to meet the international standards. However, it could cause personal injuries and property damage if improperly handled. In order to prevent potential danger and obtain maximum benefit from your set, please observe the following instructions when installing, operating, and cleaning the product.

Keep this manual for future reference, and record the serial number of your set in the space provided on the front cover page of this manual.

ENGLISH

About This Manual

- The information in this manual is subject to change without notice.
- This manual has been created with extra care. In case that you have any comments or questions regarding this manual, please contact your local dealer or our Customer Service Center.
- Before operating this set, please fully understand the prerequisite such as specifications or constraints of the hardware and software. We are not responsible and have no liability for any loss, damage or injury as a result of misuse.
- Reproduction, copying, use, modification, and/or transmission in whole or in part of this manual are prohibited without any prior written permission.
- All other products and company names used in this manual are trademarks or registered trademarks of their respective owners.

Trademark Credits

- VGA is a trademark of International Business Machines Corporation.
- Licensed by BBE Sound, Inc. under USP5510752 and 5736897.
BBE and BBE symbol are registered trademarks of BBE Sound, Inc.
Manufactured under license from BBE Sound, Inc.
- WOW, SRS and (●) symbol are trademarks of SRS Labs, Inc.
WOW technology is incorporated under license from SRS Labs, Inc.
- HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

Even if no special notation has been made of company or product trademarks, these trademarks have been fully respected.

About Software



You may not alter, decompile, disassemble, decrypt, or otherwise reverse-engineer the Software installed in this product, which are prohibited by law.




SAFETY PRECAUTIONS






For your safety, please read the following precautions carefully before using this product. Improper use would cause serious personal injuries and/or damage to your property or this product.

About the Symbols













The following are the symbols used in this manual and affixed on the unit itself. Please fully understand the meanings of the symbols before reading the instructions in this section.

 WARNING	Never ignore the instruction. There are risks of serious injuries or possible death to the user.
 CAUTION	Do not ignore the instruction. There are possibilities of personal injuries and/or property damage.

Other Symbols	
	The triangle with illustration is intended to alert the users that there are possibilities of fire, explosion, or high temperatures if the product is handled improperly. Each illustration within the triangle specifies the contents in detail. (The figure on the left is an example.)
	The circle with diagonal line and illustration indicates a prohibited action (the symbol to the left indicates that disassembly is prohibited).
	This symbol indicates a compulsory action. The contents will be clearly indicated in an illustration or nearby (the symbol to the left indicates that the power plug should be disconnected from the power outlet).

 WARNING	
There is a risk of fire, electric shock, or serious injury.	
<p>■ Unplug the power cord immediately when serious problems occur.</p> <p>Serious problems such as</p> <ul style="list-style-type: none"> • Smoke, abnormal odor or noise comes out from the product. • No picture, no sound or distorted picture on the display. • Foreign objects (such as water, metals etc.) get inside the unit. <p>Do not continue using the product under these abnormal conditions. Turn off the Main Power, unplug the Power Cord, and contact your dealer immediately.</p> <p>For your safety, never try to repair the product by yourself.</p>	 Disconnect the plug from the power outlet.
<p>■ Do not insert liquids or any foreign objects (such as metals or flammable items) inside the unit.</p> <ul style="list-style-type: none"> • In case it happens, turn off the main power, unplug the Power Cord, and contact your dealer immediately. • Use special caution when younger children are around the unit. 	
<p>■ Do not remove cover, or modify the product.</p> <ul style="list-style-type: none"> • High-voltage components are installed inside of the unit. Removing covers can expose you to high voltage, electrical shock, and other dangerous conditions. • Contact your local dealer to perform servicing such as inspection, adjustment, or repair work. 	  Do not disassemble

SAFETY PRECAUTIONS (continued)

 WARNING	
There is a risk of fire, electric shock, or serious injury.	
■ Install the unit at a proper area where it does not expose anyone to any danger. <ul style="list-style-type: none"> If you hit against the edge of the unit, you may be injured. 	
■ Do not place any objects on top of the unit. <p>Objects such as</p> <ul style="list-style-type: none"> Liquid containers (vase, fish tank, flowerpot, cosmetics or liquid medicine). If water or any liquid spill onto the unit, it may cause short-circuit and result in fire or electrical shock. In case that it happens, turn off the Main Power, unplug the Power Cord, and contact your dealer immediately. Do not place anything heavy on top of the unit. Do not climb on or hang from the unit. Do not let your pets get on top of the unit 	
■ Do not expose this unit to rain or moisture. <ul style="list-style-type: none"> Never use this unit in the bathroom or shower room. Beware when you use this product outside, especially in rainy, or snowy weather, and at the beach or waterfront. When the product gets wet, it could cause fire or electrical shock. 	 
■ Unplug this unit during lightning storm. <ul style="list-style-type: none"> To reduce the risk of electrical shock, do not touch the product when starts lightning. 	  <p>Disconnect the plug from the power outlet.</p>
■ Do not do anything that may damage the Power Cord. <ul style="list-style-type: none"> Do not damage, modify, twist, forcibly bend, heat, or pull excessively the Power Cord. Do not place heavy objects (including the unit itself) on top of the Power Cord. If the Power Cord is damaged, contact your dealer for repairs or exchange. 	
■ Use only with designated power supply voltage. <ul style="list-style-type: none"> To prevent the risk of fire and electrical shock, operate this product only with the power supply voltage indicated on the unit. 	
■ Beware not to drop or have any impact on the unit. <ul style="list-style-type: none"> Take extra care while moving the unit. There is no protection glass on the surface of the LCD panel. Thus, do not press the panel surface with your fingers or hands. Or do not hit anything against the monitor. These actions would damage the LCD cells or the panel surface and could cause the failure or personal injuries. In case that you drop the unit or the cabinet is damaged, turn off the Main Power, unplug the Power Cord and contact your local dealer immediately. Continuing use of the product with above conditions may cause fire or electrical shock. 	
■ Clean dust or metals on or around the blade of the power plug regularly. <ul style="list-style-type: none"> Continuing use of the product with above condition may cause fire or electrical shock. Always unplug the Power Cord first, and clean the blades with a dry cloth. 	
■ Do not place the unit on an unstable surface. <p>Unstable places such as</p> <ul style="list-style-type: none"> Tilted surface or shaky rack, table, stand or trolley. If the unit falls down, it could cause personal injury. 	

SAFETY PRECAUTIONS (continued)

CAUTION

■ **Do not place the unit at a dusty place.**

It could cause malfunction.



■ **Do not cover or block any ventilation holes on the product.**

The unit would overheat, and it could cause fire or damage the product which may shorten its service life.

- Install the product in accordance with the instructions in this manual.
- Do not place the unit with ventilation side down.
- Do not install the unit on the carpet or bedclothes.
- Do not cover the unit with table cloth etc.



■ **Be sure to ground the earth cable correctly.**

- Especially when you use Power Cord adapter, be sure to connect the earth cable to the ground terminal. Incorrect connection would cause fire or electrical shock.
- For your safety, always make sure to unplug the Power Cord before connect or disconnect the earth cable .



Supply connect the ground wire.

■ **Follow the Anti-tumble measures in this manual.**

- If the unit tumbles over, there is a risk of personal injury and possible death. Also, it would damage the product seriously.



■ **Do not install the unit near the medical devices.**

- To prevent malfunction of the medical devices, do not use this product and medical devices in the same room.



■ **Do not place a CRT-based television near the speakers of the LCD.**

- It could cause the partial discoloration or blurring of the image on the CRT-based television. Please install it away from the speakers of the unit.



■ **Disconnect all of the external connection cables and detach the anti-tumble measures before moving the unit.**

- It may cause fire, electrical shock, or personal injuries.



■ **Connect the power plug securely.**

- Improper connection will cause overheating and may result in fire.
- Do not touch the blades of the plug while connecting it to the wall socket. It could cause electrical shock.
- If the plug is not fitted for the wall socket, contact your dealer for replacement.



■ **Do not handle the Power Cord with wet hands.**

- It could result in electrical shock.



■ **Do not pull the cord when you unplug the Power Cord.**

- It may damage the cord and could result in fire or electrical shock.
- Hold the plug when disconnecting it.



■ **Unplug the Power Cord when you do not intend to use the product for long periods of time.**



■ **Handle the batteries properly.**

- Improper or incorrect use of the batteries may cause corrosion or battery leakage, which could cause fire, personal injury or damage to the property.
- Use only the types of the batteries which are indicated in this manual.
- Do not install new batteries with used ones.
- Install the batteries correctly by following the polarity (+ and -) indications on the battery compartment.
- Do not dispose of the used batteries as domestic waste. Dispose of them in accordance with the local regulations.



SAFETY PRECAUTIONS (continued)

ENGLISH

PRECAUTIONS

■ **Do not install the unit at areas where it will be subjected to high temperatures.**

It could damage the cabinet or parts of the product.

- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Keep the unit out of direct sunlight. It could increase the temperature of the unit and cause malfunction.



■ **Viewing Advice**

- The lighting of the environment in which the product is used should be appropriate. Too bright / dark environments are not good for your eyes.
- Take time to relax your eyes occasionally.
- When you use this product, view from a distance equal to 3 to 7 times the height of the screen. This is the best viewing distance in order to protect your eyes against eyestrain.
- Adjust the volume to an appropriate level, especially during the night.

■ **When transporting this product:**

- When the product needs to be transported due to moving or repair, use the carton box and buffer material that came with this product.
- Do not transport this product on its side. It could damage the panel glass or degrade the phosphors of the panel.



■ **Keep radios away from the unit while in use.**

This unit is designed to meet the international EMI standards due to prevent radio interference. However, the unit may generate noise in the radio.

- If the noise is heard on the radio, please try the following actions.
 - Adjust the direction of the radio antenna in order not to receive the interference from the unit.
 - Keep the radio away from the unit.
 - Use coaxial cable for the antenna.



■ **About infrared communication devices:**

- The infrared communication devices such as cordless microphones or cordless headphones may not operate properly around the unit. It is because of communication failure. Please note that this is not malfunction.

■ **When you dispose of this product at the end of its life, follow the regulations in your residential area.**

- For more information, contact the local authority or the dealer where you purchased the product.

Cleaning and Maintenance

Please make sure to unplug the power cord before cleaning the unit.

■ **How to clean the LCD panel of the unit.**

- Wipe the panel with a lint-free and dry cloth in order to prevent damage to the panel surface.
- Do not use a chemical cloth or cleaner. Depending on the ingredients, it may cause discoloration and damage the panel surface.
- Do not wipe with a hard cloth or rub hard. It may hurt the panel surface.
- In case of the greasy dirt such as fingerprint, wipe with a lint-free cloth moistened by a diluted neutral detergent solution, and then wipe with a soft and dry cloth.
- Do not use a spray cleaner. It could cause malfunction.

■ **How to clean the cabinet of the unit.**

- The following may cause crack, deformation, and paint peeling.
 - Do not wipe the cabinet with benzene, thinner, and other chemical products.
 - Do not spray volatile solutions such as insecticide over the cabinet.
 - Do not leave the cabinet in prolonged contact with plastic or rubber materials.
- Do not use a chemical cloth, cleaner or wax. Depending on the ingredients, it may cause crack and deformation.
- Use a lint-free cloth to clean the cabinet and control panel of the unit. In case of the heavy dirt, wipe with a soft cloth moistened by a diluted neutral detergent solution, and then wipe with a soft and dry cloth.
- Never use the following detergents. It could cause crack, discoloration, and scratch.
 - Acid/ alkaline detergent, alcoholic detergent, abrasive cleaner, powder soap, OA cleaner, car wax, glass cleaner, etc.

ABOUT LCD PANEL

Common phenomena of LCD Panel

The following are the common phenomena when operating LCD Panel due to its structural reason. Please note that they are not malfunctions.

- **Defective Spots on Panel**

The LCD panel is manufactured with high-precision technology. However, there might be some spots that are not emitted, brighter than the others, or in different colors, etc.

- **Surface on Panel**

The LCD panel displays images by blinking the fluorescent lamps internally. This could raise the temperature of the display surface.

In addition, do not impact strongly on the surface of the panel because LCD panel is made with fine processing glass.

- **Residual image**

When a still image or menu is displayed on the screen for a short time (about a minute) and then switches to another image, it may leave an “after-image” on the screen.

The residual image will disappear on its own.

- **The Usage under the Low Temperature Environment**

Because of the structural characteristics of the LCD panel, the response speed of the LCD panel becomes slower when the ambient temperature around the monitor becomes too low. In some cases, it may cause the residual image.

The residual image will disappear on its own as the temperature goes up and back to normal.

FEATURES


Enjoy not only beautiful and high-quality pictures on the display, but also various kinds of useful and convenient functions in your daily life!

- Large-screen and high-definition LCD display.
- Improved Digital signal processor.
- High quality sound with deeper, richer and dynamic bass tones.
- Accept more digital input devices with 2 HDMI terminals.
- Great diversity of connecting terminals to cover wide range of audio-visual equipments.
- Easy-to-use On-Screen Display system operating with Remote control.
- Low power consumption with Power Saving feature.

SUPPLIED ACCESSORIES

Check the supplied accessories before installation.
In case of missing or damaged, please contact the dealer immediately.


User's Manual




Remote Control



AA size battery
X2



Power Cord
(BS Type)*



*The type of power plug provided may be different from this drawing for some countries.

OPTION


Ask your local dealer for further details.

Desktop Stand : SD9G4237 (for 37LD9800TA)

COMPONENT NAMES


Main Unit

Front Panel




Rear Panel

32LD9800TA




37LD9800TA



- ① Side Input Terminal
- ② Control Panel (see below for details)
- ③ Handgrips
- ④ Power Cord Socket
- ⑤ Terminal Board (External Device Connection)


Please refer to 13~17 for the detailed information for the connections.

Control Panel



COMPONENT NAMES (Continued)

Remote Control



- ① **Sub Power**
- ② **Function Select (TV/DVD/STB)**
Press this button to select function mode indicating LED lamp.
Normally, select "TV".
- ③ **Input Select/DVD Control**
Press this button to change input mode.
RGB input is not available.
In addition, you can use these buttons while operating the selected brand of DVD player.
- ④ **Menu**
- ⑤ **Cursor**
- ⑥ **OK**
- ⑦ **Sound Mode**
Sound mode can be changed each time pressed in the following sequence. Movie→Music→Speech→Favorite
- ⑧ **CHI/II**
This is exclusively for TV audio A2/NICAM mode.
- ⑨ **Volume Up/Down**
- ⑩ **Program Select [Page Select]**
Press these buttons to select a TV program directly. For 2 or 3 digits channel selection, press button in advance.
Refer to **[22]** for details.
- ⑪ **Freeze [Hold]**
Press this button to change the picture to freeze mode. Press it again to return to normal picture. (Also, it holds the page in teletext mode.)
- ⑫ **[Color (Red, Green, Yellow, Blue)]**
- ⑬ **[Index]**
- ⑭ **Time [Cancel]**
Press this button to display the time when receiving a TV program.
The time is not displayed if the signal received does not have any time information.
- ⑮ **TV/Text [TV ↔ Text]**
This switches between the TV mode and the Teletext mode.
- ⑯ **Zoom [Text ↔ TV+Text]**
Press this button to change picture size.
- ⑰ **Recall**
Press this button to show the input signal status.
- ⑱ **Return**
You can use this to return to the previous menu.
- ⑲ **Picture Mode**
Picture mode can be changed each time pressed in the following sequence. Dynamic→Natural→Cinema
- ⑳ **Channel Up/Down [Page Select]**
- ㉑ **Mute**
- ㉒ **Not Available**
- ㉓ **[Reveal]**
- ㉔ **[Subtitle]**
- ㉕ **Not Available**
- ㉖ **Swivel** (Desktop stand is optional for 37LD9800TA)
This function is to rotate TV. Select the degree of rotation with cursor key.

NOTE

Some buttons are only for Teletext mode, and other buttons have different functions in Teletext mode from the use of TV mode. Those buttons are indicated by []. Refer to "About Teletext" on **[32]**.


PREPARATION

Remote Control Batteries Installation

This remote control operates on 2 “AA” batteries.


1. Open the battery compartment cover.

- Slide open the battery compartment cover on the backside of the remote control in the direction of an arrow.




2. Install the batteries.

- Install 2 “AA” batteries (included) making sure the polarities match the indication inside the compartment.




3. Close the battery compartment cover.

- To close the battery compartment cover, slide the cover in the direction of an arrow till it clicks shut.



Handling the Remote Control

Use the remote control within about 5m from front of the unit's remote-control sensor and within 30 degrees on both sides.



⚠ CAUTION

It could cause corrosion or battery leakage and may result in physical injury and/or property damage including fire.

- Never mix used and new batteries in the device.
- Replace all the batteries in a device at the same time.
- Remove the batteries if the remote control is not going to be used for an extended period of time.

To avoid possible failure, read the following instructions and handle the remote control properly.


- Do not drop or cause impact to the remote control.
- Do not spill water or any liquid on the remote control.
- Do not place the remote control on a wet object.
- Do not place the remote control under the direct sunlight or near sources of excessive heat.

Caution When Moving the Main Unit

As this product is heavy, whenever it is moved, two people are required to transport it safely.


When transferring the unit, hold the unit by using the handgrips at the backside of the panel. (See the figures below for details.)

32LD9800TA:



Handgrips

37LD9800TA:



Handgrips

PREPARATION (continued)

Safety Precaution on Main Unit Installation

Read **SAFETY PRECAUTIONS** (3 to 6) carefully besides this page.

*When installing the unit, use the optional Desktop Stand (SD9G4237). Please refer to the user's manual of the stand. The Desktop Stand (Option) has been used for the illustration in this manual.

When installing the main unit, be sure to use the specified mount units in order to obtain maximum performance and maintain the safety.

We assume no responsibility or liability for personal injuries or property damages caused by use of other mount units or improper installation.

As for the installation instruction, please read each user's manual of the mount units: for Desktop Setup, Wall Mounting, and Ceiling Mounting.

In case of using Wall or Ceiling Mounting unit, by contacting your local dealer, ask the specified installation specialist to set up. Never attempt to install it by yourself. It could cause injuries or damages.


Please leave the adequate space around this unit in order to avoid increasing the internal temperature and keep safety while using swivel function. Make sure not to block any ventilation holes. Do not install the unit in the small space such as inside the rack, closet or the box. Leave more than 10cm of clearance from each side of unit and 30cm from the top of unit to wall.

Without Swivel function: Leave at least 10cm of clearance behind rear monitor.

With Swivel function: Leave the adequate space to obtain the maximum performance of Swivel Function.

(32LD9800TA:25cm/ 37LD9800TA:27cm)

Refer to 31 for Swivel Function.




Anti-Tumble Measures

Install in a stable place and implement safety measure against overturning.

Securing to a wall or pillar

Using a commercially available cord, chain, and clamp, secure the set to a wall or pillar.



Securing to ceiling


Using a commercially available cord, chain, and clamp, secure the set to a ceiling.

NOTE

- For more information regarding the mounting of the unit, please contact your dealer.
- Loosen a cord or chain enough while operating power swivel to avoid physical injury.
- Please install the unit at a proper area where it does not expose anyone to the danger of hitting themselves (for example their hands, head or face, etc) against the edge of the unit and cause personal injury.

CONNECTION

Terminal Positions



Rear

- ① Power Cord Socket
- ② Aerial Socket
- ③ AV1
- ④ AV2
- ⑤ AV3
- ⑥ Monitor Out and Sub Woofer
- ⑦ HDMI Analog Audio Input (See 15)
- ⑧ Service Use only
- ⑨ Power Swivel Terminal (See 31)
- ⑩ Service Use only
- ⑪ HDMI1 and HDMI2

Side

- ⑫ AV4
- ⑬ Headphone Terminal

Connecting Procedure

This unit is ready for various kinds of connections. Make a connection in the following steps. Be sure to turn off the Main Power first when connecting external equipments.

1. Connect Power Cord to the rear panel.
2. Connect Aerial Lead.
3. Connect your external equipments to the unit if any.
4. Connect the Power Plug to the Wall Socket.

1. Connecting Power Cord to the Rear Panel


Connect Power Cord to the unit.

*Make sure not to connect the Power Plug to the Wall Socket until all connections are completed.

2. Connecting Aerial Lead.

There are two ways to connect Aerial Lead.

- ① **When you do not have any other external equipment:**
Connect the Aerial Lead directly into the Socket at rear panel.
- ② **When you have one or more external devices to connect:**
 1. Use RF cable to connect between each equipment and Antenna.
 2. Connect the Aerial Lead to an equipment 'In' Socket marked
 3. Connect the RF cable from the equipment 'Out' to the other equipment 'In.'
 4. Then, connect from the equipment 'Out' to "ANT" on the LCD screen Socket on marked .



[Example: Connecting Antenna through STB and VCR]

Precautions when connecting the aerial

- Please use a coaxial cable which is free from interference to connect the aerial. Avoid using a parallel flat feeder wire as interference may occur, causing reception to be unstable and stripe noise to appear on the screen.
- Avoid using indoor aerial as this may be affected by interference. Please use CATV net or outdoor aerial.
- For safety, install an external aerial conforming to AS1417.1 (applicable for Australia only)
- If noise appears in the picture of VHF-Low band channel, please use a double-shielded cable (not provided) for RF LEADS to reduce the noise.


CONNECTION (continued)

Connecting Procedure (continued)

3. Connecting to External Equipment


• Terminals on Rear

AV1 and AV2 can be connected to the equipment with either Component or Composite output. Depending on whether the Y/VIDEO input of your selected equipment is Y signal or Video signal, it automatically regards as Component or Composite. When using as Composite, do not insert the jacks into P_B or P_R.



💡 If your external device has a Component terminal, COMPONENT connection is recommended for higher quality picture.

AV3 can be connected to the equipment with an S-Video output and Composite output.




💡 If your external device has a S-video terminal, S-VIDEO connection is recommended for higher quality picture.

NOTE

- If both S-video and video input terminals of AV3 are connected at the same time, S-video will have its priority.

Monitor Out can be used to display same image as main unit on another monitor.


When this output terminal is connected to an external monitor with a 7 Ohm terminal, the same image from composite(AV1~4), S-Video(AV3,4), or RF signal can be displayed to the external monitor.



NOTE

- Video and audio output are not available from component or HDMI input.

Sub Woofer terminal can bring the deep bass sound from the external speaker.




CONNECTION (continued)

Connecting Procedure (continued)

HDMI 1•2 terminals can be connected to the devices with HDMI output.

If the external device has DVI output, this can be available with HDMI-DVI cable. In case of using the HDMI-DVI cable, connect analog audio signal to **HDMI Analog Audio Input** terminal.



Information

HDMI (High Definition Multimedia Interface) is next-generation multimedia I/O interface. Only one cable is used to transmit all video/audio/control signals, which creates easy connection.

Moreover, those digital signals can produce high quality data without any degradation.

You are provided with two HDMI terminals, one of the most remarkable features.

If your external device has a HDMI terminal, HDMI connection is recommended for higher quality picture and sound.

NOTE


• HDMI analog audio input terminal

This terminal can be used in one of the following cases only.

- ① The DVI output of an external device is connected to the HDMI1 terminal using the HDMI-DVI cable.
- ② The DVI output of an external device is connected to the HDMI2 terminal using the HDMI-DVI cable.

Make sure that the video and audio terminals are connected to the same external device.

About the output format of an external device, refer to "Recommended Signal List" on [42](#).




CONNECTION (continued)

Connecting Procedure (continued)

• Terminals on Side

Since the following terminals are located on the side, it is very convenient to connect an extra device on a temporary basis after completing the connections on the rear panel.

AV4 can be connected to the equipment with S-Video output and composite output.




💡 If your external device has S-video terminal, S-VIDEO connection is recommended for higher quality picture.

NOTE

- If both S-video and video input terminals of AV4 are connected at the same time, S-video will have its priority.

Headphone The detail settings can be adjusted from Audio Menu on page [29](#).




💡 The audio from the speaker will be muted when connecting the headphone to this terminal.

CONNECTION (continued)

Connecting Procedure (continued)

4. Connecting the plug into the wall socket

Connect the Power Cord after completing all other connections.
(The type of plug is different from this drawing for some countries.)




CAUTION

- Use only the Power Cord provided.
- Do not use a power supply voltage other than that indicated (AC110-240V, 50/60Hz). It may cause fire or electric shock.
- For the LCD television, a three-core power cord with a ground terminal is used for efficiency protection. Always be sure to connect the Power Cord to a three-pronged grounded outlet and make sure that the cord is properly grounded. If you use a power source converter plug, use an outlet with a ground terminal and screw down the ground line.
- Ensure that both ends of power cord are easily accessible.
- If you have to change the power cord, please use the certified power cord that meets your region's safety standard.

Information

• How to secure the cables.


After connecting all of the cables to the terminals, secure them with the band.
When you secure the cables, please be careful not to tighten too much.



With long band


How to fasten the band:

• To tighten



Pull the band in the direction of the arrow.

• To loosen



Loosen the band by pushing the knob in the direction of the arrow.



BASIC OPERATION

Power On/Off

Now, turn On the main power to the unit. Make sure that the Power Cord has plugged into the wall socket.


• To turn On the power of the unit:

1. Press the **Main Power switch** on the unit.
 - The Indicating Lamp will illuminates in **Red** (Standby mode).
2. Press **Sub Power** button either on the control panel or on the remote control.
 - The color of the Indicating Lamp turns into **Green**, and the image will display on the screen.



• To turn Off the power of the unit:

1. Press **Sub Power button** either on the control panel or on the remote control.
 - The image disappears from the screen and the Indicating Lamp turns into **Red** (Standby mode).
2. Press **Main Power switch** to completely turn Off the power of the unit.



The Indicating Lamp Status Check

Indicating Lamp Status	Power Status	Power Switch Status
Off	Off	Main power → Off
Red	Standby mode	Main power → On Sub Power button → Off
Green	On	Main power → On Sub power button → On
Orange	Power Save mode*	Main power → On Sub Power button → On

*About Power Save mode, see “Power Save Mode” and “When Following Messages Appear on the Screen” on [37](#) and [39](#) for details.

NOTE

- If the image does not appear on the screen at all, or have any problem, see TROUBLESHOOTING on [39](#), [40](#). It may help you to solve the problems.
- You can turn ON the power only by pressing the **Sub Power** button during the Standby mode.
- Do not switch the power On/Off repeatedly in a short period of time. It could cause malfunction.
- To avoid sudden surges of electricity when the power comes back on, turn Off the main power of the unit before you leave if there is a power cut during use of the unit.

BASIC OPERATION (continued)



First Time Setup

When you turn ON the TV for the first time, your TV automatically leads to the settings of “Language” and “Auto Tuning.”

1. The first screen appeared will ask you to choose the language of your TV’s display.
2. Select the language you preferred from the list and press **OK** button.
3. Once selecting the language, “Auto Tuning” screen appears to start scanning channels.


NOTE

If you want to change the setting after completing this first time setup, press **MENU** button and set up individually. Refer to **21** **22**.



Volume UP/DOWN

1. To increase the sound volume, press **+** button on the remote control, or **Volume Up** button on the control panel.
 - The Volume Indicator value on the screen will shift right.
2. To decrease the sound volume, press **-** button on the remote control or **Volume Down** button on the control panel.
 - The Volume Indicator value on the screen will shift left.





Mute

1. To mute the sound, press **Mute** button on the remote control.
 - The sound of the unit is temporarily turned Off.
 - The color of the Volume Indicator will turn into **magenta** while muting the volume.
2. To turn the sound back, press **Mute** button again, or Volume Up button on either remote control or the control panel.
 - The color of the Volume Indicator will turn back to **green**.

NOTE

- You can decrease the volume by pressing **-** button while the sound is muted.



BASIC OPERATION (continued)

Input Switching to TV/AV1~4, and HDMI


By pressing Input Select button, you can switch the input.

- To watch actual broadcast, press Input Select button on the control panel, the numeric buttons or Channel Up/Down button on the remote control.
- To display the image outputting from the external equipments connected to each terminal (TV, AV1~4, HDMI 1, 2), select corresponding mode.

1. Press **Input Select** buttons on the remote control.



2. The Input modes can be also switched by using **Input Select** button on the control panel.

Each time this button is pressed, the screen displays corresponding mode by following order.



3. To directly go back to TV mode, pressing channel Up/Down buttons on either remote control or the control panel.


Also, you can use the numeric buttons on the remote control.



Input Signal Screen Display

The input signal status can be displayed on the screen by pressing the **RECALL** button of the remote control.

- The display will go out in approximately 6 seconds.











MENU OPERATION

How to use the On-Screen Display (OSD) system


With the On-Screen Display system, you can access the various kinds of the features and functions in this product.

• Basic Operation


1. Press  button on the remote control or **Menu** button on the control panel of the unit. The **Main Menu** is displayed on the screen as shown on the right.
2. To select the item, press  button.
The selected item will be highlighted in Green.
3. Press  button to set your selection.
The selected menu page will be displayed on the screen.
4. Use  button to choose the item on the MENU page.
Press  button to set your selection.
5. Use  button to adjust the item values or choose options.
Press  button to set your selection.
6. To exit from the menu, press  button.

NOTE

- The OSD menu screen will be closed automatically when no operation has been made for about one minute.
- If the item in menu is shown in gray, it means that it cannot be selected or adjusted.



<Main Menu>



Menu button







Menu button

Language Menu

Select the language from the list so that you can display the OSD menu in the selected language.

How to set Language


1. Enter the "Language" menu from the Main Menu.
2. Select the appropriate language with  button from the list.
The selected item will be highlighted in Green.
3. Press  button to set your selection.
The black dot is marked inside of the circle when the selection is fixed.
4. Press  button to exit from the entire OSD menu.



MENU OPERATION (continued)

Setup Menu (TV mode)

With this menu, you can access various kinds of features relating to TV channel settings.



ENGLISH




Selected Items			Setup hint
Auto Tuning	Mode	Position	Select the way to display the channels on the screen between "--", "---", "-" and AV00 by using button. "--" is for 2 digits channel selection, "---" is for 3 digits channel selection, and "-" is for 1 digit channel selection. The position numbers are displayed on the upper right corner of screen. (1~199, AV00)
		Direct	The channel number 1~99 are displayed as C* *, and the channel number 101~199 are displayed as S* *.
	Search		Tune the local channels automatically. Press button to start searching.
Manual Tuning	Position		Press channel up (+) down (-) buttons to input position number (1~199, AV00) or channel number (C* * or S* *).
	Frequency		When Auto Tuning Mode is set to [position], search the frequency by using button.
			When Auto Tuning Mode is set to [Direct], this function is not available (grayed out).
	Name		1. Move the cursor to the first digit and select the letters with button. 2. Move to the next digit with button. 3. Press button again when you finish inputting all the letters. • The selectable letters are as follows: "0"~"9", "A"~"Z", "+", " " (blank), "-" (displayed as blank), and "." (period).
	Sound System	Auto	Select the sound system from 5 different modes.
		M	
		BG	
		I	
		DK	

Information

- Use AV00 when connecting equipment such as a VCR via an RF (aerial type) cable.

MENU OPERATION (continued)


Setup Menu (TV mode) (continued)

Selected Items			Setup hint
Manual Tuning	Color System	Auto	Select color system from 5 different modes.
		PAL	
		SECAM	
		NTSC 4.43	
		NTSC 3.58	
	Skip	Off	It allows you to skip unregistered channels automatically when you use channel up (+) down (-) buttons to select channels. This function will automatically skip unavailable channels when set to on.
		On	
	NR	Off	The noise on the screen or interference could be reduced, especially at the area of weak electric field.
On			
Fine Tuning	-56~+56		► : Increase the frequency data for the main tuner. ◄ : Decrease the frequency data for the main tuner.
Sort			You can change the order of channels as follows. 1. Move the cursor to the channel row you want to change order and then, press  button. 2. The color of the letters on the designated line will be turned into green bracket and with []. 3. Move the designated row by using  button. 4. Press  button to fix the position. • This function is not available (grayed out) when the Auto Tuning Mode is set to [Direct].
Teletext Language			Select Teletext Language from 5 different categories (West Europe, East Europe, Russian, Arabic and Farsi) according to the area. Example: West Europe : Asian countries where the Teletext is broadcasting in English such as Singapore, Australia, and Malaysia. East Europe : Poland, Sweden, Hungary Russian : Russia Arabic : Arab countries Farsi : Iran
Auto Off	Off		When no airwave has been received and no operation has been made for 10 minutes in TV mode, it turns to standby mode automatically.
	On		

MENU OPERATION (continued)

Setup Menu (AV mode)

With this menu, you can select or adjust the condition of the input signals from each terminal.



ENGLISH


Selected Items				Setup hint
System	System 1			Do not change the original setting. (System1: Europe/Asia, System2:South America) • Composite and S-video input only.
	System 2			
Color System	AV1~AV4	System 1	Auto	Select the color system depending on the input signal. • Generally, select [Auto] to receive all signals for both System 1 and System 2. • In case that the input signal has too much noise, the signal level is too low, or the operation is unstable in [Auto], select the system according to the color system of the input signal. • Composite and S-video input only.
			PAL	
			SECAM	
			NTSC 4.43	
			NTSC 3.58	
		System 2	PAL60	
			Auto	
			NTSC-M	
			PAL-M	
			PAL-N	

MENU OPERATION (continued)

Function Menu

This menu provides various ways to protect your panel, reduce power consumption, and set up utilizing the useful functions, such as Freeze Mode.


Function	
Black Side Panel	Off
Video Power Save	Off
Freeze Mode	Split
Default Zoom	Panoramic
Picture Size	1
Reset	Reset
⬇ Select ⬅ Set ⏹ Return	

Selected Items		Setup hint
Black Side Panel	Off	This can change the color of sidebars showing up in normal mode. (Off:gray, On:black) It is recommended to set Off to reduce image retention. This cannot be stored. (The default setting is off.)
	On	
Video Power Save	Off	During AV input, this helps to reduce power consumption when there is no video signal. In case of selecting AV input terminal which does not have signal input, it changes the power status to power save mode in AV1/AV2 and standby mode in other AV input. (See 37 in details.)
	On	
Freeze Mode	Single	This is the useful function to watch the program in a still picture. (See 35 in details.) • Single: full-sized image • Split: half-sized images (One is still, while the other is active.)
	Split	
Default Zoom	Panoramic1	You can set the display size for TV input screen appearing first when turning the main power On.
	Panoramic2	
	4:3	
	Full	
Picture Size	1	In case that the image from TV signal (especially CATV) has a blackened gap in either or both side during Panoramic mode, select [2] so that it can make up for the gap. This is not available when displaying "Cinema" size. This is not available except RF, composite, and component (576i,480i) input. (gray out)
	2	
Reset		Each item on this menu screen can be restored to the original factory settings by pressing  button.

MENU OPERATION (continued)

Picture Menu

In this menu, you can make specific adjustments for the picture based on your preference.
By pressing ▼ button at the bottom of each menu page, the next Picture menu page will appear on the screen.



Selected Items		Setup hint
Picture Mode	Dynamic	You can make the best selection from 3 modes depending on the lighting condition and intended use. Dynamic: Suitable for the brighter conditions. Natural : Suitable for the normal lighting condition. Cinema : Suitable for watching movie.
	Natural	
	Cinema	
Contrast*	-31~+31 (+32~+40)	This adjusts the contrast to meet the lighting environment by using ◀▶ button. • The maximum value can be extended to [+40] by pressing and holding ▶ button at [+31], which changes the color between those numbers from green to magenta. This is the special feature prepared for the dark scene. At the normal condition, it is recommended to set the value less than [+31].
Brightness*	-31~+31	With this function, black is adjusted to change the overall brightness by using ◀▶ button.
Color*	-31~+31	It can adjust color density based on your preference by using ◀▶ button.
Sharpness*	-15~+15	Preferred sharpness can be adjusted by pressing ◀ button for Softer image or ▶ button for Sharper image.
Tint*	-31~+31	Pressing ◀ button enhances red and weakens green, while pressing ▶ button weakens red and enhances green. The setup hint is adjusting for the realistic skin color.
Color Temperature*	Cool	You can select from 3 settings (default) depending on the color condition with ◀▶ button.
	Normal	
	Warm	
Contrast Mode*	Dynamic	It allows you to choose from 3 modes. Dynamic: Sharpen the gradation to improve the contrast feeling. Normal: Reproduce as faithful gradation as possible. Low: Weaken the gradation to reduce the contrast feeling.
	Normal	
	Low	
Back Light	-20~+20	Adjust the brightness of the Back Light for the maximum visibility.
Reset		Each item on this menu screen can be restored to the original factory settings by pressing OK button.

MENU OPERATION (continued)

Picture Menu (continued)

Selected Items		Setup hint
3D Color Management*	Off	On : It automatically adjusts the suitable tint, color density, and brightness on images. Off : Set it off if the image does not look natural.
	On	
Black Enhancement*	Off	Adjusts the black level compensation.
	Low	
	Middle	
	High	
DNR*	Off	This is a noise reduction system for picture signal.
	Low	
	Middle	
	High	
MPEG NR*	Off	This is a noise reduction system for MPEG picture signal. (ex. against mosquito noise and block noise.)
	Low	
	High	
Film Mode*	Off	On: Automatically identify if it is the movie film and faithfully reproduces the original film images. Off: Set to Off if the image does not look natural.
	On	
3D Comb Filter*	Off	This is available only when receiving NTSC/PAL composite signal. This reduces the dot and color blurring in minute scales so that it can reproduce purer color. This is not available for NTSC4.43, PAL60, PAL-N, and PAL-M system.
	Low	
	Middle	
	High	
Reset		Each item on this menu screen can be restored to the original factory settings by pressing (OK) button.

MENU OPERATION (continued)

Picture Menu (continued)

ENGLISH

Selected Items			Setup hint
Color Temp. Adjust*	On	Amplitude	On: When you want to set specific adjustments in each of the 3 Color Temperature modes. You can adjust on the amplitude and cut off. The settings reflect on the Color Temperature. Amplitude: subdue the following colors on the brighter parts. (-63 ~ 0) Cut off : subdue the following colors on the darker parts. (-31 ~ +31)
		Red**	
		Green**	
		Blue**	
		Cut off	
		Red**	
		Green**	
		Blue**	
	Off		Off: Remains as default setting.

Information


The items indicated by “*” can be stored for each of inputs and picture modes (Dynamic/Natural/Cinema). You can enjoy different setting depending on the selected input such as VCR in AV1.

In addition, the item indicated by “**” can be stored for each of color temperature modes.

MENU OPERATION (continued)

Audio Menu

With this menu, you can adjust and customize the audio condition as you like.
You can move on to the next menu screen by pressing ▼ button at the bottom.



Selected Items		Setup hint
Audio Mode	Movie	You can select the most suitable sound condition from 4 alternatives according to the contents. If you want to adjust each item value based on your preference, select "Favorite".
	Music	
	Speech	
	Favorite	
Treble*	-15~+15	Adjust the Treble.
Bass*	-15~+15	Adjust the Bass.
Balance	-10~+10	Adjust the balance of the sound from right and left speakers.
SRS*	Off	This system gives you the dynamic 3D sound.
	On	
TruBass*	Off	TruBass gives you the enhanced bass sound. Select it depending on your preference.
	Low	
	High	
BBE*	Off	BBE High Definition Sound restores clarity and presence for better speech intelligibility and musical realism. Select it depending on your preference.
	Low	
	High	
Perfect Volume	Off	It will automatically adjust the volume to its average level each time you change the channel.
	On	
Internal Speaker	Off	This needs to be switched to Off when you want to take audio from external equipment.
	On	It is normally set to On when you operate the set using the built in speakers.
Headphone Volume	0~63	It allows you to adjust the volume of the headphone. The sound from the speaker will automatically set to MUTE when the headphone is connected to the terminal.
Reset		Reset all the set values on this Menu Page to the original factory settings.


Information


The items indicated by "*" can be stored for each of Audio Mode.

MENU OPERATION (continued)

Timer Menu


This allows the unit to turn Off (Standby mode) or On at set time automatically, which you may find useful.





Selected Items		Setup hint
Off Timer	--Min.	This function automatically sets the power to Standby mode when the selected time period has elapsed.
	30Min.	
	60Min.	
	90Min.	
	120Min.	
On Timer	--:--	<p>This function automatically sets the power from standby mode to On when the specified time period has elapsed. After the “On Timer” is set, the indicating lamp will start blinking.</p> <p>Input the desired time within the range of 00:01 to 11:59 by using  button on the remote control.</p>

FUNCTION

Power Swivel

With the optional Desktop stand (included for 32LD9800TA, optional for 37LD9800TA), you can adjust the angle of the panel side to side by pressing  button on the remote control.


1. Press  button on the remote control.
The Swivel Display (as shown in the figure on the right) will appear on the screen.
2. Adjust the angle of the panel with  button while Swivel Display is on the screen.
The unit will be able to rotate ± 30 degrees to each side.

CAUTION

- When you use the Power Swivel function, make sure that the Power Cord, cord or chain connected to the wall is loose enough to operate the Swivel function securely.
- Do not put hands or face near the unit while operating the Swivel. It could cause personal injury. Beware especially when small children are around the unit.




SWIVEL button



The Swivel Display

NOTE

- If the stand cable is not connected to the unit, the message "Not Available" will appear on the screen.
- The Swivel Display will automatically disappear when no operation has been made for about 6 seconds.




CAUTION

- Do not push the panel with your hands while operating the Swivel. It could damage the panel and/or stand.
- Do not allow children to play or hang on the TV. These actions may tip it over, causing personal injury.
- Do not swing the unit back and forth.
- Do not place any fragile objects around the unit. The unit would hit the object(s) during the Swivel operation and could cause the breakage of the objects and/or the stand.
- To operate the Swivel function correctly, place the unit on the stable surface.
- When you use the unit as wall-mounting, disconnect the stand cable from the unit before installation.


Information

About Swivel terminal connection

- To connect the Desktop stand to the unit
Connect the designated stand cable to the Swivel terminal on the rear side of the unit.



- To disconnect the stand from the unit.
Before detach the stand from the unit, make sure to disconnect the stand cable from the Swivel terminal on the rear side of the unit.



CAUTION

- When you install the Desktop stand, follow the Instructions of the Manual included with the stand.
- Turn Off the Main Power of the unit when connecting or disconnecting the stand cable to the unit.


FUNCTION (continued)

About Teletext

• What is “Teletext”

Teletext is the written information services provided by each TV channel. Most TV channels provide information via Teletext such as:

- TV program schedule
- Weather forecasts
- Sports results
- Newsflash



• How to operate the Teletext

You can display the Teletext simply by pressing the remote control buttons.

NOTE

Select Teletext language from Setup Menu shown on **23**.

Operation	Press
To activate Teletext mode. To exit from the Teletext mode.	[TV⇌Text]
To move to the next or previous page.	[Page Select]
To jump to the indicated page.	[Page Select]
To split the screen into two and watch both Teletext information and actual broadcast at the same time. Press again to watch Teletext on a single screen.	[Text⇌TV+Text]
To display Index page.	[Index]
To access Subtitle service directly (if the channel has the Subtitle service broadcasting).	[Subtitle]
To display Hidden text. ex. The answers of the Quiz or the Game page. Press again to close the revealed answer.	[Reveal]
To return to actual broadcast temporarily while searching for the Teletext page you request. When the search is done, the designated page # will be displayed on the upper left of the screen. Press again to return to Teletext page.	[Cancel]
To access the link pages which are displayed at the bottom of the page. (Select the buttons corresponding to the colors of the letters on screen.)	[Color]
To hold the text picture.	[Hold]




Information

- Each time the button is pressed, the screen will be switched from double screen to signal screen.
- Some Teletext pages do not display Link Pages at the bottom of the screen. Press button to display them.

FUNCTION (continued)


Size Switching

Each time  button of the remote control is pressed, the screen display size is switched in sequence, and the status will be displayed at the bottom of the screen.


TV/AV signal input

● Watching Standard Definition Pictures (480i, 480p, 576i, 576p)

TV/AV1/AV2/AV3/AV4/HDMI1/HDMI2




ZOOM button


















● Watching High Definition Pictures (720p, 1080i, 1080p (HDMI only))

AV1/AV2/HDMI1/HDMI2



You can display the image at optimum condition by selecting display size depending on the current output image as shown below.

Input Signal	Display Screen	Display Size	To display suitable screen as follows.
When Watching SD Pictures:			
 (4:3 Signal)		4:3	Play a 4:3 image on screen faithfully. Blanking occurs on both sides.
		Panoramic1	Play a 4:3 image which enlarges horizontal and vertical size of the middle in equal scales, and displays both sides appearing much wider.
		Panoramic2	The vertical size of Panoramic1 is reduced so that you can see the whole image, including any subtitles, that might otherwise not be fully visible on the screen.
 (Vista)		Zoom	Play a 16:9 image in 4:3 frame (Vista size) faithfully. *In some case, slight blanking may remain at the top and bottom.
 (Cinema)		Cinema	Play a 21:9 image in 4:3 frame (Cinema size) expanding vertically. *In some case, slight blanking may remain at the top and bottom.
 (Squeeze)		Full	Play a 4:3 image faithfully in the standard vertical size and horizontally squeezed.
When Watching HD Pictures:			
 (16:9 Signal)		Full 1	Play a 16:9 image faithfully showing 95% of the size.
		Full 2	Play a 16:9 image faithfully showing 100% of the size. *In some case, the screen display has unnecessary blanking or noise at the edges.
 (4:3 Image in 16:9 Frame)		Panoramic	Play a 4:3 image in 16:9 frame which enlarges horizontal and vertical size of the middle in equal scales, and displays both sides appearing much wider.

Information

Aspect ratio represents horizontal : vertical ratio on screen.

For example, vista image is 16:9 in 4:3 image.



FUNCTION (continued)

Size Switching (continued)

TV/AV signal input (continued)


• Position Adjustment

Vertical picture position can be adjusted for **Panoramic1**, **Zoom**, **Cinema**, and **Full 2** mode as follows.

1. Press  button while operating the picture size display.
2. "Position" display will appear.
3. Adjust the position by  button.

Adjustment range of each picture size are as shown below.

Display Size	Adjustable Range	Condition/Remark
Panoramic1	-12 ~ +12	
Zoom, Cinema	-31 ~ +31	
Full 2	±1	Component signal only



Press ▲



Press ▼


CAUTION

Using a wide-screen television

- This television has a screen mode selection feature. If an incompatible screen mode is selected to play certain software, such as a TV program, the image would appear different from the original. Take this into consideration when making screen mode choices.
- Use of the wide feature displaying enlarged pictures in coffee shops, hotel and other establishments for commercial or public viewing purposes could infringe on the copyright holder's right protected by Copyright Law.
- When a normal 4:3 image (not wide screen) is displayed over the entire screen in the Panoramic mode, the peripheral image may disappear partly and/or appear distorted in some cases. Use 4:3 mode to view the image reflecting original intention.


FUNCTION (continued)

Picture Freezing

By pressing  button, you can change to freeze mode easily anytime you like. Press it again to return to normal picture.

FREEZE button



There are two types of freeze mode. You can select these in the “Freeze Mode” from Function Menu.  (25)

Single:

It freezes a picture on a single frame.


[Single]



Split:

It displays 2 pictures from the same source. One is active (left), while the other is still picture (right). This is very useful in order to avoid missing something or to make a note of something, such as a recipe.

[Split]




* The size of the pictures differs depending on the signal format received.

FUNCTION (continued)

Audio Switching

NICAM / Sound Multiplex(including A2) (TV mode)

You can make optimum use of available audio by pressing  button of remote control. Audio can be switched only if receiving NICAM and sound multiplex signals; otherwise, pressing this button will have no effect, such as when only mono sound is received.


These can be divided into two main categories: Bilingual/Dual Sound broadcast and Stereo broadcast.

Bilingual/Dual Sound broadcast

Bilingual broadcast is the broadcast available on the main and sub languages, while dual sound broadcast is available on the primary and secondary sounds; for example, some sports programs contain broadcast commentary on a game as primary sound, and a commentary about a team as the secondary.

When bilingual program is received, sound mode display appears in yellow as shown. Also, when receiving NICAM signals, NICAM display will appear.

Each time  button is pressed, the display is switched in the sequence of following.




Stereo broadcast

With stereo broadcast, you can enjoy different sound from either side.

When a stereo program is received, sound mode display will appear in red as shown.

Also, when receiving NICAM signals, NICAM display will appear.

Press  button to switch between stereo and mono sound.



NOTE

- Please select ▼ (force mono) in case of poor reception, noise, poor stereo sound due to signal condition so that you can receive a clear mono sound.
- ▽ represents the Mono broadcast.

FUNCTION (continued)

Power Save Mode

- You are provided the function to save power consumption when no signal is detected in AV input. Set to On in “Video Power Save” from Function Menu, which leads to the power save mode in AV1 /AV2 /HDMI1 /HDMI2 and the Standby mode in other AV input. (Please see the table below for details) Refer to [25](#) about “Video Power Save”.

	When no signal is detected		When signal is input during On in “Video Power Save”
	Condition	Indicating Lamp	
AV1, AV2, HDMI1, HDMI2	Power Save	Orange	Turns On automatically.
AV3, AV4	Standby	Red	Remains as Standby mode.

FUNCTION (continued)

DVD Player / STB Selection

You can use this remote control to operate DVD Player and Set Top Box of other makers as well as this set. After pressing **SEL** button, press (or hold) the required buttons to select the maker and type as shown below.

Set up

Example: HITACHI DVD②

1. Set up the maker.

Press **SEL** button to indicate the DVD LED on the remote control. While the DVD LED is blinking (Approx. 30 Seconds), press **Ⓢ** and **①** buttons.

2. Set up the maker type.

Release the **①** button while keeping **Ⓢ** button depressed. Then press **②** button.

3. Confirm the setting.

After setting the maker and type, press the SUB POWER button on the remote control. If the DVD does not switch ON, repeat step 1 and 2 using other maker types as listed.



ENGLISH

<“DVD” Selection>

Makers of DVD Player	Set Maker	Set type	Makers of DVD Player	Set Maker	Set type
HITACHI	Ⓢ ①	①~③	RCA	Ⓢ ①	Ⓢ ①
FUNAI	Ⓢ ②	①	Mitsubishi	Ⓢ	Ⓢ ①
Pioneer	Ⓢ ③	①~⑥	ONKYO	Ⓢ RED	Ⓢ ①~③
Panasonic	Ⓢ ④	①~④	ZENITH	Ⓢ GREEN	Ⓢ ①
TOSHIBA	Ⓢ ⑤	①~④	THOMSON	Ⓢ YELLOW	Ⓢ ①
Philips	Ⓢ ⑥	①~②	SHINCO	Ⓢ BLUE	Ⓢ ①
JVC	Ⓢ ⑦	①	SKYWORTH	Ⓢ	Ⓢ ①
SAMSUNG	Ⓢ ⑧	①	BUBUKO	Ⓢ	Ⓢ ①
Sony	Ⓢ ⑨	①~④	DENON	Ⓢ	Ⓢ ①~②
Sharp	Ⓢ Ⓢ	①~②	YAMAHA	Ⓢ	Ⓢ ①~②

<“STB” Selection>

Makers of STB Player	Set Maker	Set type
HITACHI	Ⓢ ①	Ⓢ ①~②
TOSHIBA	Ⓢ ②	Ⓢ ①
DGTEC	Ⓢ ③	Ⓢ ①
Panasonic	Ⓢ ④	Ⓢ ①

NOTE

Please note that not all models of the listed makers can be operated using this remote control.






TROUBLESHOOTING

Before calling service technician, check the following tables first. If the problem is not be solved with the suggested procedures, contact your local dealer. For your safety, NEVER try to repair the product by yourself.

When Following Messages Appear on the Screen




















Message	Condition / Action	Page
Power Save	This indicates it is in Power Save mode. The indicating lamp lights in orange.	25 , 37
No Sync. Signal	The unit cannot detect any signals from any input terminals. • Check if the cable is connected correctly and firmly. • Check if the power of any external equipment is ON. • Check if the input selection matches the connection terminal.	14 ~ 16
Invalid Scan Freq.	The unit receives unsupported signals. • Check if the cable is connected correctly and firmly. • Check if the input signal is compatible with the specification of the television.	41 , 42
Not Available	This shows when the selected operation is not available.	
Check Antenna	Check the connection status when this message appears.	13

Symptom and Check List

Symptoms		Check list	Page
No picture - no sound		<ul style="list-style-type: none"> • Check the Indicating lamp status (Off, Red, Green, or Orange). • Check the connection of the Power Cord and/or other cables. • Check if the Main Power of the unit or external equipments is ON. • Check if the TV mode is selected. • Check if the TV is in "Standby mode" or "Power Save mode". • Adjust the values in "Picture menu" and "Audio menu". 	13 ~ 18 , 20 , 37
Snowy picture-poor sound		<ul style="list-style-type: none"> • Check the antenna connection and direction. • The TV station may have broadcast difficulties. Try another channel. 	13
Multiple images-normal sound		<ul style="list-style-type: none"> • Check the antenna connection and direction. • Fine tuning the TV. • Check the connection of the external equipments. • The TV station may have broadcast difficulties. Try another channel. 	13 , 23
Intermittent interference		<ul style="list-style-type: none"> • Check if the source of interference is shielded well. • Remove those kinds of electrical devices away from the TV. 	
Normal picture, but no sound		<ul style="list-style-type: none"> • Check the volume level. • Check if the  button has been pressed or not. • Make sure that the headphone is NOT connected. • Check the connection of the external equipments. 	19
No picture - normal sound		<ul style="list-style-type: none"> • Check the value level of "Brightness", "Contrast" and "Back Light" in "Picture Menu". 	26
The remote control does not work.		<ul style="list-style-type: none"> • Check if the batteries are installed correctly. • The batteries might be exhausted. Replace them with new ones. • Remove all the obstructions in front of the sensor window on the unit. • Check if you select the correct function by  button on the remote control. • Check if the buttons of the control panel can work. 	10 , 11
Normal picture but no color-normal sound		<ul style="list-style-type: none"> • Check the connection of the external equipments. • Check the "Sound System" and "Color System" in "Setup Menu". 	14 ~ 16 22 ~ 24

TROUBLESHOOTING (continued)

Symptom and Check List (continued)

Symptoms	Check list	Page
• Image is paused.	• Check if the TV is in freeze mode by pressing  button.	 35
• No picture The Indicating lamp → Off	• Check if the Power Cord is plugged into the socket firmly. • Check if the Main Power is ON.	 17 ,  18
• No picture The Indicating lamp → Orange It means that the unit is in "Power Save mode".	• Check if all the cables of the external equipments are connected correctly and firmly. • Check if the power of the external equipments is ON. • Check if the TV/AV mode has been selected correctly. • Refer to "Power Save mode" and "When following messages appears on the screen".	 37 ,  39
• No picture The indicating lamp → Green	• Check if the signal cable is connected correctly and firmly. • Adjust the level of Brightness and Contrast lower.	 14 ~  16
• The rear of the TV makes a buzzing sound.	• This could be the sound produced by the inverter. This is not a malfunction.	
• The top of the unit and surface of the panel heat up.	• It may happen when you use the unit for long hours. Turn off the Main Power of the unit for a while. Please note that this is not malfunction.	 41
• Image cannot be displayed in the correct position.	• Press  button to check if the input signal of the displayed image is compatible with the specification of the television.	 41 ,  42
• When the VCR is in special playback features (Fast Forward or Rewind), the screen gets dark and cannot see the image at all.	• It could happen when the VCR is connected to Component output, such as 480i. This is not malfunction. • Try Composite output or S-video output and check the picture again.	
• Some screen display size cannot be switched.	• Check the signal status by pressing the  button on the remote control. The available screen display size is different depending on the current signal status.	 20 ,  33 ,  34
• Cannot be displayed the image from HDMI 1 or 2.	• Check if the cables are connected correctly. • Check the output format of the equipments. • (Please refer to "Connecting Procedure" and "Recommended Signal List".)	 41 ,  42
• The image and audio are mismatched in HDMI1/2 mode.	• Check if the HDMI analog audio input terminal is connected to the same external device.	 15

PRODUCT SPECIFICATIONS

SPECIFICATION			
Panel	Display dimensions	Approx. 32 inches (698 (H) x 392 (V) mm, diagonal 801mm)	Approx. 37 inches (820 (H) x 461 (V) mm, diagonal 941mm)
	Resolution	1366 (H) x 768 (V) pixels	1366 (H) x 768 (V) pixels
Net dimensions		including Stand: 822(W)x653(H)x365(D) mm excluding Stand: 822(W)x591(H)x115(D) mm	including Optional Stand: 949(W)x726(H)x365(D) mm excluding Optional Stand: 949(W)x664(H)x119(D) mm
Net weight		including Stand: 25.7 kg excluding Stand: 19.8 kg	including Optional Stand: 28.9 kg excluding Optional Stand: 23.0 kg
Ambient conditions	Temperature	Operating : 5°C to 35°C, Storage : 0°C to 40°C	
	Relative humidity	Operating : 20% to 80%, Storage : 20% to 90% (non-condensing)	
Power supply		AC110 - 240V, 50/60Hz	
Power consumption/ at standby		137W/<1W	174W/<1W
Audio output		speaker total 20W	speaker total 20W
(VIDEO input)			
Input terminals		AV1•2: composite video input terminal (RCA) component video input terminal (RCA) L/R audio input terminal (RCA) AV3•4: composite video input terminal (RCA) S video input terminal. L/R audio input terminal (RCA) HDMI 1•2 : HDMI input terminal Audio input terminal (L/R audio input terminal (RCA))*	
Input signals		Composite video: PAL, SECAM, NTSC3.58, NTSC4.43, PAL60 Component video: 480i, 576i, 480p, 576p, 720p/50, 720p/60, 1080i/50, 1080i/60 HDMI: VGA/60, 480i, 576i, 480p, 576p, 720p/50, 720p/60, 1080i/50, 1080i/60, 1080p/50, 1080p/60	
Output Signal		OUTPUT (MONITOR): composite video monitor-output terminal (RCA) OUTPUT (MONITOR): L/R audio monitor- output terminal (RCA) OUTPUT (HEADPHONE): L/R audio monitor- output terminal (Mini-pin) OUTPUT (SUB-WOOFER): Woofer output terminal (RCA)	
(RF input)			
Input terminal / Receiving range		ANT : 75Ω Unbalanced / 44~870MHz	
RF Video System		PAL B, G, H / I / D, K SECAM B, G / D, K / K1 NTSC-M	

• The unit takes at least 30 minutes to attain the status of optimal picture quality.


* This analog audio input terminal can be used for HDMI1/2 only.

PRODUCT SPECIFICATIONS (continued)

Signal Input


S-input connector pin specifications

Pin	Input signal
1	Y
2	Y-GND
3	C
4	C-GND
Frame	GND



HDMI connector pin specifications

Pin	Input signal	Pin	Input signal
1	TMDS Data2+	11	TMDS Clock Shield
2	TMDS Data2 Shield	12	TMDS Clock-
3	TMDS Data2-	13	CEC
4	TMDS Data 1+	14	Reserved(N.C. on device)
5	TMDS Data1 Shield	15	SCL
6	TMDS Data1-	16	SDA
7	TMDS Data0+	17	DDC/CED Ground
8	TMDS Data0 Shield	18	+5V Power
9	TMDS Data0-	19	Hot Plug Detect
10	TMDS Clock+		



Recommended Signal List

With HDMI input

No.	Signal mode			Horizontal frequency (kHz)	Dot clock frequency (MHz)	Remarks
	Signal Name	Resolution	Vertical frequency (Hz)			
1	VGA	640 X 480	59.94	31.47	25.18	EIA/CEA-861B
2	576i	720(1440) X 576	50.00	15.63	27.00	EIA/CEA-861B
3	480i	720(1440) X 480	59.94	15.73	27.00	EIA/CEA-861B
4	576p	720 X 576	50.00	31.25	27.00	EIA/CEA-861B
5	480p	720 X 480	59.94	31.47	27.00	EIA/CEA-861B
6	1080i/50	1920 X 1080	50.00	28.13	74.25	EIA/CEA-861B
7	1080i/60	1920 X 1080	60.00	33.75	74.25	EIA/CEA-861B
8	720p/50	1280 X 720	50.00	37.50	74.25	EIA/CEA-861B
9	720p/60	1280 X 720	60.00	45.00	74.25	EIA/CEA-861B
10	1080p/50	1920 X 1080	50.00	56.25	148.50	EIA/CEA-861B
11	1080p/60	1920 X 1080	60.00	67.50	148.50	EIA/CEA-861B

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>