

Emerson™ Digital Camera

User Guide EDC180

Location of controls

In the box

- Digital Camera
- USB Cable (connects to your computer)
- CD (ArcSoft® Media Impression software)
- User Guide
- Screwdriver

Battery Installation

Battery Installation

- To insert the batteries (not included), use the screw driver (included) to open the battery cover located on the side of the unit.
- Insert 3 x AAA, alkaline batteries (not included) according to the correct polarity +/- symbol as shown on the inside of the battery cover.
- Close the battery cover and tighten the screw using the screwdriver.
- When the battery is running low, the icon on the LCD display will blink for a short period. When the batteries are dead, the camera will automatically turn itself off.

Important battery precautions:

- only use AAA Alkaline batteries
- batteries should not be exposed to direct sunlight or heat source such as fire, oven or the like.
- When inserting new batteries, do not mix old batteries with new ones.
- Remove the batteries if the camera is not to be used for a long time.

AAA Batteries (not included)

Information: Please make sure you have downloaded all your images before the batteries go dead as you will lose all your saved images when batteries are replaced.

Using your camera

Turning the camera on/off

- To turn the camera on, press the **[POWER]** button until the display turns on.
- To turn the camera off, press and HOLD the **[POWER]** button until the display turns off.

[POWER] button

The camera has 2 different modes: Capture mode and Playback mode.

Press the **[Playback]** button to select between capture mode and playback mode.

Mode Selection:

- Capture mode
- Picture Playback mode

Taking a photo

The Digital Camera allows you to take digital still photos. To take digital still photos:

- Press the **[Power]** button to turn the camera on, the icon appears on the LCD screen.
- Use the LCD screen to view your subject.
- Press the **[Shutter]** button to take a picture. After the picture has been taken the LCD will display image for a brief second. The Picture Counter in the bottom right of the LCD Screen will decrease as each image is taken.

Resolution Mode Icon **[Power] button** **[Shutter] button**

Resolution Mode Icon **Picture Counter**

Information: The Status LED will illuminate when the camera is busy (such as picture taking, and charging the LED lamp). Do not press any buttons while the Status LED is illuminated.

Camera Settings

Resolution Settings

There are two photo resolution modes that can be changed on the camera which affect the quality of the photos as well as how many photos may be taken before you have to download them to your computer.

- Press the **[Power]** button to turn the camera on.
- Press the **[Mode]** button to switch between the two photo resolution modes.

Resolution Mode	Screen Icon	Resolution	Approximate Number of Pictures*
Low-Res		VGA 640x480	109
High-Res		1.3mp 1280x1024	21

*Actual picture storage may vary depending on shooting conditions.

LED Light

- To turn on the LED light press the **[Right/LED on-off]** button, a icon will appear on the screen.
- To turn off the LED light press the **[Right/LED on-off]** button, the will disappear from the screen.

Display On/Off

- To turn the display off, and conserve battery power, press the **[Display on/off]** button. Press again to turn the display back on.

Playback Mode

- Press the **[Power]** button to turn the camera on.
- Press the **[Playback]** button (the playback icon is displayed on the upper-left corner of the screen).
- Use the **[Left]** and **[Right]** buttons to browse through your photos.
- The "No Image" icon appears when there are no stored photos.
- Press the **[Playback]** button at any time to go back to camera mode.

Playback Mode Icon **[Playback] Button**

[Left] Button **[Right] Button**

Deleting Photos

Deleting a single photo

- Press the **[Playback]** button to enter Playback Mode.
- In Playback mode, use the **[Left]** or **[Right]** buttons to select and view the photo you would like to delete, and then press the **[Delete]** button.
- A delete single photo icon appears on the LCD screen with the following two options:
 - Delete:** Automatically DELETES the selected photo.
 - Cancel:** Exits without deleting the photo and returns to Playback mode.
- Press the **[Left]** or **[Right]** buttons to choose between Delete and Cancel.
- Press the **[OK]** button to confirm your choice.

Deleting all photos

- Press the **[Playback]** button to enter Playback Mode.
- Press the **[Delete]** button twice. A delete all photos icon appears on the LCD screen with the following two options:
 - Delete:** Automatically DELETES all photos.
 - Cancel:** Exits without deleting all photos and returns to Playback mode.
- Press the **[Left]** or **[Right]** buttons to choose between Delete and Cancel.
- Press the **[OK]** button to confirm your choice.

Connecting the camera

Downloading photos to your computer

To edit or upload and share your photos, you must first transfer them to your computer. Follow the steps below to connect the camera to your computer, and use the provided ArcSoft® software to manage, view, edit and share your photos.

- Insert the smaller end of the USB cable into the camera's USB port.
- Connect the larger end of the USB cable into your computer's USB port.
- You will see a icon on the LCD screen, this means you are connected to the computer.
- Look for your camera by clicking on "My Computer", it should usually appear as "Removable Disk". Open the DCIM folder then select a file and simply move it into your computer (we recommend copying the photos into the "My Pictures" folder of your computer) in the usual way (drag-and-drop, copy-paste), OR open the ArcSoft® software to easily locate your camera and transfer, view, edit, and upload your photos (see "ArcSoft® MediaImpression").
- Before disconnecting the camera, click on the "Safely Remove Hardware" icon usually located on the lower right corner of your desktop.
- Please do not disconnect the USB cable during loading, as it may cause damage to the camera and/or files.

ArcSoft® MediaImpression 2

Installing

Follow these steps to install the included ArcSoft® MediaImpression 2 software. With this software you will be able to manage, view, edit, transfer, and easily upload / share your photos.

- Insert the provided CD into the CD-ROM drive of your computer, and click on "ArcSoft MediaImpression 2".
- When the "Choose Setup Language" menu appears, select your language.
- When the "Welcome" screen appears, click "Next."
- When the "License Agreement" menu appears, please read through and click "Yes."
- When "Select Program Folder" menu appears, click "Next."
- The software will now start installing on your computer.
- The "Associated File Formats" screen will appear. Check the selected formats that you would like MediaImpression to open by default.
- Now that MediaImpression has been installed, it is recommended to restart your computer. This ArcSoft® MediaImpression 2 appears on your desktop and in your program files.

Using MediaImpression 2

When MediaImpression 2 is opened, the following window will be displayed:

The software will allow you to perform many tasks with your photos. For detailed instructions on how to use the software, click the "Extras" tab located in the top right corner, and select "Help" from the dropdown menu.

Troubleshooting

Camera will not turn on

- Check that the batteries are properly inserted.
- Replace the batteries.

I can't upload photos to my computer

- Check the connection of the USB cable; make sure it is properly connected.
- Try a different USB cable.

My photos are fuzzy or poor quality

- Make sure to keep the camera steady when taking photos (when you hear a beep, this indicates the photo has been taken; hold the camera steady until then).
- Be aware of the lighting (the more light, the better your photos will turn out).
- Clean the lens of your camera, and make sure it is free of finger prints (clean only with a non-abrasive dry cloth and make sure the camera is turned off before cleaning).

I press the [Shutter] button, but the camera doesn't respond

- Wait until data processing is complete, then press the [Shutter] button.

Safety Precautions

Always follow these basic safety precautions when using your camera. This will reduce the risk of product damage and personal injury.

- Do not disassemble, repair or modify the camera by yourself. Refer servicing to qualified personnel.
- If the LCD display breaks, do not touch the glass or liquid, and contact customer support.
- The use of a NON-RECOMMENDED accessory may cause fire, electric shock, or injury. For approved accessories, please contact customer support.
- Keep the camera away from direct sunlight and any direct heat source.
- Do not expose the camera to rain or moisture.
- Avoid using the camera in dry environments to avoid static.
- Never apply heavy impact on the player, or place it on a magnet.
- When connecting the camera to a computer or TV, route the cable so that people and pets are not likely to trip over it.
- Clean only with a dry cloth. Make sure the player is turned off before cleaning. Do not use a liquid cleaner.

Important Battery Precautions

- Use only the type of battery specified in this user manual.
- Batteries may present a risk of fire, explosion, or chemical burn if abused. Do not try to charge a battery that is not intended to be recharged.
- Do not dispose of a battery (ies) in a fire. They may explode. Check with local codes for disposal instructions.
- Non-rechargeable batteries, such as alkaline batteries, may leak if left in your product for a long period of time. Remove the batteries from the product if you are not going to use it for a month or longer.
- If your product uses more than one battery, do not mix different types of batteries. Make sure you replace the old with all new batteries. Mixing different types of batteries or inserting them incorrectly, may cause them to leak.
- In the event that the battery is leaking, do not handle the device with your bare hands. Contact the service center for help since the liquid may remain in the player. If your body or clothes had contact with the battery liquid, wash it off thoroughly with water. Also, if some liquid gets into your eyes, do not rub your eyes but immediately wash them with clean water and consult a doctor.
- Please help to protect the environment by recycling or disposing of batteries according to federal, state, and local regulations.

FCC information

FCC Part 15: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center; and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit with the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

Southern Telecom, Inc.
Attention: Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11232

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM, INC. IS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Should you have any questions or problems concerning this product, please contact our customer service department at:

Customer Support:
1-877-768-8483 (Toll Free)
cs@southern telecom.com

Monday - Thursday: 9AM - 5PM (EST)
 Friday: 9AM - 3PM (EST)

Made in China / Designed in the USA
 Distributed by: AIT, Inc. Brooklyn NY 11232
 © 2012 All rights reserved

Emerson and the G-Clef logo are registered trademarks of Emerson Radio Corp. Parsippany, New Jersey USA

ArcSoft® and MediaImpression software are trademarks of ArcSoft, Inc. Other trademarks and trade names are those of their respective owners.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>