

# Tumble dryer

Instructions for installation and use  
**G85C**



# Contents

Safety Advice	3 - 4
Electrical Requirements	5
Features - Get to know the main parts of your Dryer	6
Where to put your Dryer	7
How to use your Dryer	8
The Controls	9-10
Easy Iron Programme	11
Sorting your laundry	12
Items not suitable for drying	13
Items requiring special attention	14
Emptying the Water Container	15
Guide to Drying Times	16
Caring for your Dryer	17
If something goes wrong	18
If it still won't work	19

## Register your purchase now

Simply complete and return the **Registration Form** supplied with the appliance documents.

## Retention of this Instruction Book

This Instruction Book must be kept handy for reference as it contains important details on the safe and proper use of the appliance.

If you sell or pass the appliance to someone else, or move house and leave it behind, make sure this Book is also provided so the new owner can become familiar with the appliance and safety warnings.

---

# For your safety

---

## IMPORTANT

Using your Tumble Dryer is easy.

Nevertheless, for your own safety and to get the best results it is important to know your Dryer by reading right through this handbook **before** using your dryer for the first time.

- NEVER** ● Allow children to play with or otherwise interfere with the dryer.
- NEVER** ● Allow the air inlet at the front of the dryer or the air outlet at the back to be obstructed.
- NEVER** ● Switch the machine off leaving a hot load in the drum.
- NEVER** ● Tumble dry without the Filter, Water Container or Condenser in position.
- NEVER** ● Exceed the maximum load capacity recommended or place dripping wet items in the drum.
- NEVER** ● Allow lint to collect around the dryer.
- NEVER** ● Add liquid fabric conditioner to the dryer, use liquid conditioner in the final rinse of your wash.
- NEVER** ● Use the dryer for commercial drying, the dryer is only suitable for domestic use.
- NEVER** ● Dry Acrylics or synthetics on the high heat setting.
- NEVER** ● Tumble dry articles that have **NOT** been well washed in water and detergent then well rinsed and spun.
- NEVER** ● Tumble dry articles that have had chemicals used for cleaning.
- NEVER** ● Dry articles that are contaminated with flammable substances such as: petrol, oil, paint, hair lacquer, creams, cooking fat or oil.
- NEVER** ● Tumble dry: rubber, foam rubber, plastic, plastic foam, nappy pants or liners, polythene or paper.  
Large, very bulky items including duvets and sleeping bags.
- NEVER** ● Attempt to stand on top of your dryer, it is not designed for such use and you could injure yourself or damage the dryer by such abuse.
- NEVER** ● Switch electricity On or Off with wet hands.

## IMPORTANT


**A CHILD COULD CLIMB INTO OR TAMPER WITH AN UNATTENDED TUMBLE DRYER.**

**WHEN THE MACHINE IS NOT IN USE SWITCH OFF, REMOVE THE PLUG AND CLOSE THE DOOR.**

---

# For your safety




---

- ALWAYS** ● Empty the Water Container after **EACH** drying cycle.
- ALWAYS** ● **Finish** every programme with the cool tumble cycle provided on the control.
- ALWAYS** ● **Clean the filter**, it is essential that the filter is kept clear of fluff after **EACH** drying cycle.
- ALWAYS** ● Ensure Condenser is free of fluff, regular cleaning is recommended.
- ALWAYS** ● When the dryer is not in use, switch off, remove plug and close the door.
- ALWAYS** ● Comply with the specified electrical requirements.
- ALWAYS** ● Ensure that your dryer is installed correctly and has adequate ventilation. (see, "Where to put your dryer.")
- ALWAYS** ● Observe the rules for drying garments:  
**In particular woollen articles should not be dried in a tumble dryer unless they are labelled 'Superwash', 'Machine washable' or have the 'May be tumble dried' symbol: **  
**If in any doubt do not dry wool in the machine.**  
**Unlike other materials, the mechanism of wool shrinkage is irreversible, i.e. it will not stretch back to the original size and shape.**
- ALWAYS** ● Buy genuine accessories and spares.




**CAUTION:**  
**When the dryer is in use avoid touching the rear of the dryer as it may be hot!**

# Electrical Requirements

<b>Supply</b>	<div><b>WARNING: This appliance must be earthed!</b></div> <p><b>REFER TO THE RATING PLATE FOR VOLTAGE AND CURRENT REQUIREMENTS. (see diagram for location.)</b></p> <p>The flexible mains lead is supplied fitted with a BS1363 plug and with a 13 amp BS1362 fuse.</p> <p>The plug should be connected to the mains supply via a suitable switched socket which is accessible after installing your dryer.</p>
<b>Changing the fuse</b>  <b>Moulded plug</b>  	<div><b>WARNING: The plug must not be used without a fuse cover.</b></div> <p>If a replacement fuse holder/cover is required, it must be of the same colour coding or wording as shown on the base of the plug. Replacements are available from your Spares stockist.</p>
<b>Changing the plug</b>  <b>Rewirable plug</b>  	<p>The wires in the mains lead are coloured in accordance with the following:</p> <p>GREEN/YELLOW - EARTH BLUE - NEUTRAL BROWN - LIVE</p> <p>If a replacement plug is to be fitted, the appropriate wire must be connected to the correct terminal,as follows:</p> <p>Connect:</p> <p>Green/Yellow to terminal marked Earth or Green or </p> <p>Blue to terminal marked Neutral or N or Black</p> <p>Brown to terminal marked Live or L or Red.</p> <p>If the plug being replaced is a non-rewirable type then the cut-off plug must be disposed of safely. <b>DO NOT</b> leave where it can be inserted into a socket and create a shock hazard.</p>
<b>Changing the mains cable</b>	<p>Should the mains lead ever require replacing at any time please contact your nearest Service Centre. A charge will be made for the replacement of the mains lead or if you require a longer lead.</p> <p><b>The mains lead must only be replaced by a specially prepared cable obtainable from your Spares Stockist and fitted by a qualified electrician.</b></p>


**NOTE: IF IN DOUBT ABOUT ANY OF THE ABOVE CONSULT A QUALIFIED ELECTRICIAN.**

# Features - Get to know the main parts of your dryer



**NOTE:** If your dryer is new wipe out the inside of the drum before you first use it to remove any dust which may have accumulated during transit.

Plinth Moulding  
(Not fitted to all models)




# Where to put your dryer

Your Tumble Dryer should **NOT** be located adjacent to a gas hob, cooker, heater or eye level grill as flames from the burners could cause damage to your machine.. When the dryer is fitted under a work surface, allow space for air to exit the rear grille, a 15mm gap each side of the dryer is recommended. This airflow is essential to condense the water produced drying the washing, the dryer will not operate efficiently in an enclosed space or cupboard.

If using your dryer in a small or cold room some condensation could be experienced.

**DO NOT** use 2-way adaptors or extension leads.



## Door Reversal Instructions

The door of your Dryer is reversible and can easily be changed. Exchange diagonally hinge brackets and blanking plugs. Exchange door latch and catch with their opposite blanking plates. See diagram above.

# How to use your dryer


1. Plug in, switch on electricity.

**WARNING: WHEN SWITCHING ON OR OFF, PLEASE ENSURE THAT YOUR HANDS ARE DRY**

2. Sort your laundry (see section "Sorting Your Laundry")



3. Open the door by pressing and releasing the front panel in the position shown.



4. Always check the following:

**FLUFF FILTER**  
is clean and in place

**WATER CONTAINER**  
is empty and in place

**CONDENSER**  
is clean and in place

5. Load the dryer placing the clothes carefully in the drum pushing them well towards the back and away from the door seal. Close the door.



6. Select the alarm, if required. (see section "The Controls")

7. Select the required programme or drying time. (see section "The Controls")

8. Press the START switch to commence the drying programme.

9. When finished open the door and take out the laundry. Clean and replace the fluff filter, and empty the water container.

10. Switch off electricity and remove plug from socket.


**WARNING: WHEN SWITCHING ON OR OFF, PLEASE ENSURE THAT YOUR HANDS ARE DRY**

## Removing Items

By opening the door you can check the dryness of the load as often as you wish and if you want, remove some items before they are fully dry. (This is particularly useful for a mixed load where you want to iron some items, but others are to be fully dried.) **You will need to press the start button after closing the door to re-start the programme.** See section 'The Controls'.



# The Controls



## Setting the Programme

To set the programme, all you have to do is turn the Programme Control knob until the required selection appears in line with the indicator.

## Programme Options

### Automatic programmes (for load sizes more than 1kg)

1. Dry Cottons (HIGH heat) This gives driest results. Some bulky items or large load of towels may appear slightly damp after this programme and require a short period of timed drying.
2. Damp Cottons (HIGH heat)
3. Iron Dry Cottons (HIGH heat)
4. Dry Synthetics (LOW heat)
5. Damp Synthetics (LOW heat)
6. Iron Dry Synthetics (LOW heat)

### Timed programmes (for load sizes less than 1kg)

7. 40 minutes (LOW heat) include cool tumble followed by the Crease Care phase.
  8. 30 minutes (LOW heat) include cool tumble followed by the Crease Care phase.
  9. 20 minutes (LOW heat) include cool tumble followed by the Crease Care phase.
  10. Airing, 20 minutes of cool tumble.
  11. Easy Iron Programme, see section "Easy Iron Programme".
- For description of other programmes see next page.

## Starting the Dryer

Press and release the START button to commence a drying programme (The drying programme must have been selected first). The Active Light will then glow.

**NOTE: If the door is opened during a programme, the Dryer will automatically stop. To continue the programme, after closing the door, the START button must be pressed.**

## Alarm Switch

The alarm option is selected with the switch in the OUT position, if you do not need this option press the switch to the IN position. The alarm (if selected) will sound at the end of the programme or intermittently during the Crease Care phase.

---

# The Controls

---

## Indicator Lamp

The indicator lamp turns **orange** during a drying programme when the water container is full. When this happens, you must empty the water container. The programme goes directly to the cooling phase and the dryer stops. The **orange** light warns you that the load will not be dried correctly. Empty the water container and start the programme again by pressing the start button.

At the end of the drying programme if the water container has filled the indicator lamp will glow **red**. A programme cannot be started when the lamp is **red**.

The indicator lamp goes off (or turns **green** if a programme is running) a few seconds after the empty water container has been put back.

If this light flashes it shows that an automatic programme has exceeded 180 minutes. For safety reasons this being the maximum drying time available.

Should this occur, the causes may be:

- The load is too big, or bulky.
- The filter is blocked.
- A cotton load was spun at LOW speed.
- There may be a fault.

Turn the dryer Off, check through the first three causes, and then try again.

## Cool Tumble phase

About 10 minutes before the programme is completed, the heating elements will be switched off, and the programme enters the final 'Cool Drying' phase. During this phase, the fabric is cooled. You should always allow the dryer to complete this phase.

By opening the door, you can check the dryness of the load as often as you wish and if you want remove some items before they are fully dry. (This is particularly useful for a mixed load where you want to iron some items, but others to be fully dried.)

**You will need to press the START button after closing the door to re-start the programme.** See previous page.

## Crease Care phase

At the end of the drying programme it may not be convenient to take out the clothes immediately. Do not worry, the dryer will protect your clothes from creasing by gently turning them over occasionally by means of a few revolutions of the drum. At the same time, if you have not cancelled the Alarm (Buzzer) a warning buzz will sound intermittently to remind you that the clothes are ready to take out.

---

# Easy Iron Programme

---

'Easy Iron' provides a short programme consisting of approximately 8 minutes of heat with an approximately 2 minutes cool tumble period. It is a short conditioning programme that softens the fibres allowing them to relax making handling and ironing easier and less time consuming.

## When to use 'Easy Iron'

However garments are dried, outside on the line, inside on a radiator, hung around the home or using a tumble dryer, once dry they usually get left in the same position/place for a long period of time. This tends to cause garment fibre stiffness which can make the handling of garments difficult and therefore the ironing time longer. Garments dried in any of the ways described above and left will benefit from the 'Easy Iron' programme.

## Important!

- The 'Easy Iron' cycle is **not a drying programme**. It has been designed to condition/soften garments that have already been dried and left unattended in this state for a period of time.
- All materials do not behave in exactly the same way when heated. For instance, our testing has shown that materials such as Tencel® and Acrylics are not relaxed quite as effectively by applying the 'Easy Iron' cycle as we found on the more traditional Cottons and Polycottons.
- To obtain the best results from 'Easy Iron' it is important that the weights recommended below are not exceeded.
- **For best results We recommend garments should be removed from the dryer immediately after the 'Easy Iron' programme to be hung, folded neatly or ironed.**  
**When this is not possible the 'Easy Iron' programme should be repeated.**

## Recommended weights and materials

Material	Maximum load	
Cotton and Cotton mixtures	2.5kg	5.5lb
Synthetics	2kg	4.4lb
Denim	2kg	4.4lb

## Audio Signal

On completion of the programme an audio signal is sounded (if selected) to remind you to remove garments from the dryer.

# Sorting your laundry

1. Always separate laundry into the correct fabric groups before washing and drying.
2. See that all zips are closed, hooks and eyes are fastened and belt, strings etc. are tied loosely in bows, you will normally have done this for each item before the washing stage.
3. It is important to extract as much water as possible from each item before drying. This saves you time and money.

**WARNING: CLOTHES SHOULD NEVER BE LOADED DRIPPING WET**

4. Make sure that the items to be dried are suitable for tumble drying, or are not of a type requiring 'special attention' (see "Wash Care Labels" section).

## Maximum load size

Your dryer will hold a load of 6kg (13lb) dry weight of natural fabrics. if you are drying items of man-made fibres (synthetic or acrylics), the maximum load should not exceed 3kg (6.6lb) dry weight. This difference is that man-made fibres require more space to tumble-dry without creasing.

**WARNING: DO NOT OVERLOAD AS THIS COULD RESULT IN REDUCED DRYING PERFORMANCE AND A POSSIBLE FIRE HAZARD.**

## Typical load

To help you estimate how many items it takes to make up a drying load, the charts below show the approximate weights of some every-day washing items.

Clothes			
Blouse	Cotton	150g	5oz
	Other	100g	3½oz
Dress	Cotton	500g	1lb 2oz
	Other	350g	12oz
Jeans		700g	1lb 6oz
10 Nappies		1000g	2lb 3oz
Shirt	Cotton	300g	10½oz
	Other	200g	7oz
T-Shirt		125g	4½oz

Household Items			
Duvet cover (Double)	Cotton	1500g	3lb 5oz
	Other	1000g	2lb 3oz
Large Tablecloth		700g	1lb 6oz
Small Tablecloth		250g	9oz
Tea Towel		100g	3½oz
Bath Towel		700g	1lb 8oz
Hand Towel		350g	12oz
Double Sheet		500g	1lb 2oz
Single Sheet		350g	12oz

If you group small cotton or terry-towelling items with a synthetic fabric load they could be damp at the end of the drying cycle. If this happens simply give them an additional short period of drying to finish them off.

---

# Wash Care Labels

---

Most of today's fabrics can be tumble dried in your Dryer with no trouble at all, but there are certain fabric finishes which should be dried away from direct heat.

The majority of garments now have wash-care labels on them, giving full washing and drying instructions. These should always be followed carefully especially when you are drying something for the first time.

Typical symbols are:



May be tumble dried



Do **not** tumble dry

Or:



Tumble dry at high heat setting



Tumble dry at low heat setting

---

## Items not suitable for tumble drying

- Those containing foam rubber or rubber-like materials or plastic film (e.g. pillows, cushions, PVC rainwear), or any other articles which are inflammable or contain inflammable substances (e.g. towels contaminated with hair lacquer)
- Fibreglass (e.g. some types of curtains)
- Items which have been dry cleaned
- Woollens. Woollen items need as much care in drying as they do in washing. The movement of the tumble-drying action causes the woollen fibre to shrink and distort.
- Garments with the ITCL Code (see 'Items Requiring Special Attention').



Do **not** tumble dry.

- Large bulky items e.g. continental quilts, sleeping bags, pillows, cushions, double blankets and large bedspreads. These expand when drying and would prevent airflow through the Dryer.

**WARNING: THE DRYER IS INTENDED FOR USE ONLY WHERE WATER SOLUTION IS USED FOR THE CLEANING PROCESS. MISUSE OF A TUMBLE DRYER MAY CREATE A FIRE HAZARD.**

---

# Items requiring special attention

---

## Blankets and Bedspreads

The drying requirements of blankets and bedspreads will, of course, vary tremendously according to size and weight. Some, however are simply too big. if you have difficulty getting them into the Dryer, the machine will have difficulty drying them properly. Blankets (and Garments) made from Acrylic fibres (e.g. Acilan, Courtele, Orion and Dralon) **must be dried** with special care on Low heat setting. Overdrying should be avoided to ensure heat creasing does not occur.

## Permanently pleated or creased garments

Your dryer will cope with such clothes very well, but you should always read the manufacturer's drying instructions attached to the garment before you begin.

## Starched articles


Starched articles should be dried together in the same load to avoid the distribution of starch to non-starched items. You should use a slightly heavier starch solution than you would when drying the items on the washing line. Make sure that as much of the solution is removed from the load as possible before placing it in the Dryer. Remove the items from the dryer as soon as they reach ironing dampness. If they are overdried the starch will powder, leaving the fabric limp - which rather defeats the purpose of the exercise!

## Fabric conditioner


To make sure all your tumble dried clothes come out really fresh and soft we recommend you use a liquid fabric conditioner in the final rinse of your **wash**. A liquid fabric conditioner restores bounce and softness and helps eliminate static cling.

**WARNING: ON NO ACCOUNT SHOULD LIQUID FABRIC CONDITIONER BE ADDED TO THE DRYER ITSELF.**

## Home Dry Cleaning

Garments with the ITCL Code  may be cleaned using one of the Home Dry Cleaning Kits available. The instructions supplied with the Home Dry Cleaning Kit must be strictly followed.

# Emptying the Water Container



**Empty the water container after EVERY programme. Failure to do this will result in the water container becoming full and the load will not dry.**

## **To Empty Water Container**

Remove plinth (where fitted) by slightly lifting and sliding to the left.

Pull the container out of the dryer and empty it into a sink or other suitable drain).

# Guide to drying times

Please note that the drying times stated below and on appliance control panel; are a GUIDE only and drying times are affected by:-

**The amount of water remaining in the clothes after spinning**

Items such as towelling retain a lot of water after spinning, also the suggested wash programme for small items such as T-Shirts may sometimes incorporate a low spin speed which has the same effect.

**The type of fabric**

Your drying load may contain the same type of fabric but of different thicknesses. Thinner items will take less time to dry. Some fabrics, such as those used for jeans are of closer texture than others and although light when dry will be heavy after washing and spinning.

**The quantity of clothes to be dried**

Single items of clothes or small loads may take disproportionately longer to dry. It is more energy efficient to dry larger loads.

**How dry you want the clothes**

As it takes longer to fully dry clothes than to have them ready for ironing, you may wish to remove some clothes when they are slightly damp, ready for ironing and then continue to dry the remainder until they are fully dry.

**The heat setting you have selected**

The label on the garment should tell you the correct heat setting to select. See 'Wash Care Labels'.

**The temperature of the room**

If the room in which the dryer is situated is cold, your clothes will take longer to dry than if the room is warm.

**Bulky items**

Some bulky items such as padded jackets can be dried, with care, and we do advise that you remove these items several times, shake them and return them to the dryer.

**THERE ARE HOWEVER SOME ITEMS THAT WE DO NOT ADVISE YOU TO DRY. SEE 'ITEMS NOT SUITABLE FOR TUMBLE DRYING'**

**Drying Guide** - approximate drying time in minutes (weights specified are when dry)

COTTONS						SYNTHETICS			ACRYLICS	
Drying times 800 - 1000rpm in washing machine						Drying times on reduced spin in washing machine			Drying times on reduced spin in washing machine	
		Half load			Full load		Half load	Full load	Half load	Full load
1 kg	2 kg	3 kg	4 kg	5 kg	6 kg	1 kg	2 kg	3 kg	1 kg	2 kg
30 - 40	40 - 55	55 - 70	70 - 80	80 - 90	95 - 120	40 - 50	50 - 70	70 - 90	40 - 60	55 - 75

**Be careful not to overdry**

All fabrics contain a little natural moisture even when 'dry' and this natural moisture should not be lost if the clothes are to remain soft and fluffy.

Clothes that are dried for too long tend to wrinkle and will need more ironing than usual, giving you extra work that the Dryer was designed to remove.



# Caring for your Dryer

## When finished

Your Tumble Dryer needs very little attention. The following simple steps will keep it performing well.


**Switch off electricity and remove plug. Ensure hands are dry.**

## After each load

Always clean the filter, by rinsing under the tap or using a vacuum cleaner. Turn the dryer by hand to check that small items like handkerchiefs do not get missed. Always empty the water container.

## Every Week

Wipe the drum and seal with a damp cloth.



## Every Month

Remove condenser unit and clean any build up of fluff from between the plates by rinsing it under the tap with cold water. This should be done with cold water from the rear of the condenser. Refit with the handle at the front.

Occasionally clean the surface of the stainless steel sensor inside the drum with vinegar to remove water contaminates. Apply carefully with a cloth this will maintain the drying performance of the dryer. The sensor is approx 50mm (2") round and located between the vanes of the drum towards the front of the dryer, rotate the drum if necessary to locate it.

## Cleaning

Every 6 months vacuum the front air intake grille and Vents at the rear of the dryer, to remove the build up of fluff, lint or dust.

To remove accumulation of fluff from the door, front of condenser and filter areas, clean occasionally with a vacuum cleaner.

## Do not use

Abrasive cleaners, scouring agents, acids, chlorine bleach or metal polish to clean any part of the machine.

## Lubrication

Your tumble dryer uses special bearing components. Lubrication by the user is not necessary and must not be attempted.

We strongly recommend that all appliances are regularly checked for electrical and mechanical safety.

---

# If something goes wrong

---

First, don't panic! **There may be nothing wrong at all.** Look for your problem below, then check the things we suggest. More often than not, this will give you the answer to your problem, and you'll be able to carry on without having to telephone your Service Office.

If after this you still cannot get your machine to work, follow the advice given on the next page.

Problem	Check these things first
'It won't start'	<ol style="list-style-type: none"><li>1. Is the machine plugged in and switched on at the socket?</li><li>2. Is the Control set to required programme?</li><li>3. Is the door securely closed?</li><li>4. Have you pressed the START button?</li><li>5. Has the fuse blown? (Try plugging in another appliance to check).</li><li>6. Have you used an extension lead? Many are not suitable. Try plugging the dryer directly into a socket to check.</li></ol>
'It is taking a long time to dry'	<ol style="list-style-type: none"><li>1. Have you forgotten to clean the filter? It should be cleaned after each load.</li><li>2. Does the water container need emptying? Is the Indicator lamp glowing <b>red / orange</b>? The bottle should be emptied after every load.</li><li>3. Does the Condenser need cleaning? It should be cleaned every month.</li><li>4. Have you selected the correct programme setting for the type of fabric you are drying?</li><li>5. Have the air intake grille or rear vents of the Dryer been obstructed?</li><li>6. Were the clothes 'excessively wet' when they were put in?</li><li>7. Was the correct programme selected?</li><li>8. Have you overloaded the dryer?</li></ol>
'The Dryer is tumbling occasionally'	This is perfectly normal - it means that the Dryer is on 'Crease Care' and has reached the end of the drying cycle and the clothes are ready to take out.
'The dryer keeps beeping'	This is perfectly normal, the dryer is on 'Crease Care' as above. Press the Alarm (Buzzer) button and the beeping will stop.
Indicator Lamp is flashing	See section "The Controls", this indicates a possible fault.
Any other problem	Have you re-read this instruction book?

# If it still won't work...

## Contact the Service Office (0870 6070805)

if something is still wrong with your machine after you've been through the check-list on the previous page:

1. Switch off and unplug your machine from the mains.
2. Call your nearest Service Office or local importer on the telephone number provided on the guarantee card.

When you contact us we will want to know the following:

1. Your name, address and postcode.
2. Your telephone number.
3. Clear and concise details of the fault.
4. The model number and the serial number of your dryer.
5. The date of purchase enter the date here.

.....  
Please make sure you have all these details ready when you call.

---

## Spare parts

Please remember your new appliance is a complex piece of equipment.

'DIY' repairs or unqualified and untrained service people may put you in danger, could damage the appliance, and might mean you lose cover under the Parts Guarantee.

If you do experience a problem with the appliance don't take risks, call in our Service Engineer. Our Spare Parts are designed exclusively to fit your appliance. Do not use them for any other purpose as you may create a safety hazard.

---

## Disposal of your product

To minimise the risk of injury to children please dispose of your product safely. The door and lid should be removed and mains cable cut off flush with the appliance ensuring that the mains plug can no longer be plugged into a mains socket. The items must then be disposed of safely.

This appliance conforms to the following EEC Directives.

Low Voltage Equipment

72/23/EEC

93/68/EEC

Electromagnetic Compatibility

89/336/EEC

92/31/EEC

93/68/EEC





## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>