



# ***Intel<sup>®</sup> IXDP465 Development Platform***

## **Quick Start Guide**

---

*May 2005*

Order Number: 305825, Revision: 002  
May 2005



INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL® PRODUCTS. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER, AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY RELATING TO SALE AND/OR USE OF INTEL PRODUCTS, INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT.

Intel Corporation may have patents or pending patent applications, trademarks, copyrights, or other intellectual property rights that relate to the presented subject matter. The furnishing of documents and other materials and information does not provide any license, express or implied, by estoppel or otherwise, to any such patents, trademarks, copyrights, or other intellectual property rights.

Intel products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or in nuclear facility applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

Contact your local Intel sales office or your distributor to obtain the latest specifications and before placing your product order.

Copies of documents which have an ordering number and are referenced in this document, or other Intel literature may be obtained by calling 1-800-548-4725 or by visiting Intel's website at <http://www.intel.com>.

BunnyPeople, CablePort, Celeron, Chips, Dialogic, DM3, EtherExpress, ETOX, FlashFile, i386, i486, i960, iCOMP, InstantIP, Intel, Intel Centrino, Intel Centrino logo, Intel logo, Intel386, Intel486, Intel740, IntelDX2, IntelDX4, IntelSX2, Intel Inside, Intel Inside logo, Intel NetBurst, Intel NetMerge, Intel NetStructure, Intel SingleDriver, Intel SpeedStep, Intel StrataFlash, Intel Xeon, Intel XScale, IPLink, Itanium, MCS, MMX, MMX logo, Optimizer logo, OverDrive, Paragon, PDCharm, Pentium, Pentium II Xeon, Pentium III Xeon, Performance at Your Command, RemoteExpress, SmartDie, Solutions960, Sound Mark, StorageExpress, The Computer Inside, The Journey Inside, TokenExpress, VTune, and Xircom are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

\*Other names and brands may be claimed as the property of others.

Copyright © 2005, Intel Corporation

# Contents

---

<b>1.0</b>	<b>Purpose</b> .....	<b>5</b>
<b>2.0</b>	<b>Applicable Documents and Revisions</b> .....	<b>5</b>
<b>3.0</b>	<b>Known Issues</b> .....	<b>6</b>
<b>4.0</b>	<b>Inspection</b> .....	<b>6</b>
<b>5.0</b>	<b>Intel® IXDP465 Development Platform Overview</b> .....	<b>7</b>
5.1	Emulation with the Intel® IXDP465 Development Platform.....	8
<b>6.0</b>	<b>Default Switch Settings</b> .....	<b>9</b>
<b>7.0</b>	<b>Default Jumper Settings</b> .....	<b>12</b>
7.1	Intel® IXDP465 Baseboard Jumpers .....	12
7.2	Intel® IXP465 Network Processor/DDR Module Jumpers .....	15
7.3	Intel® IXPETM465 Ethernet PHY Mezzanine Card Jumpers.....	17
<b>8.0</b>	<b>LCD Display and LED Indicators</b> .....	<b>18</b>
<b>9.0</b>	<b>Preparing the Platform for Initial Use</b> .....	<b>21</b>
<b>10.0</b>	<b>Starting the Platform</b> .....	<b>21</b>
<b>11.0</b>	<b>Operating the Platform</b> .....	<b>22</b>
<b>12.0</b>	<b>Technical Support</b> .....	<b>22</b>

## Figures

1	Photo of IXDP465 Development Platform Setup for Quick Start Operation .....	8
2	Intel® IXDP465 Development Platform Switch Locations.....	11
3	Intel® IXDP465 Baseboard Jumper Locations.....	14
4	Intel® IXP465 Network Processor/DDR Module Jumper Locations.....	16
5	Intel® IXPETM465 Ethernet PHY Mezzanine Card Jumper Locations .....	18
6	Intel® IXDP465 Development Platform LED Locations .....	20
7	LCD Display for Wind River* VxWorks* Bootloader .....	22

## Tables

1	Reference Documents .....	5
2	Fuse Bit Settings for Network Processor Emulation .....	9
3	Intel® IXDP465 Development Platform Switch Descriptions and Default Settings .....	10
4	Intel® IXDP465 Baseboard Jumper Descriptions and Default Settings .....	12
5	Intel® IXP465 Network Processor/DDR Module Jumper Descriptions and Default Settings .....	15
6	Intel® IXPETM465 Ethernet PHY Mezzanine Card Jumper Descriptions and Default Settings .....	17
7	Intel® IXDP465 Development Platform LED Descriptions and Default Settings.....	19
8	UART Communications Configuration.....	21

## Revision History

---

Date	Revision	Description
May 2005	002	Text updates for this release include: <ul style="list-style-type: none"><li>• Added paragraph about using zoom feature to read PDF in <a href="#">Section 1.0</a>. (SCR 4282)</li><li>• Added references to <i>Intel® IXDP465 Development Platform Specification Update</i>.</li><li>• Added detail to procedure in <a href="#">Section 4.0</a>.</li><li>• Added <a href="#">Section 5.1</a>, “Emulation with the Intel® IXDP465 Development Platform” on page 8.</li><li>• Clarified default settings for J127 and J128 in <a href="#">Table 4</a>. (SCR 4280)</li><li>• Added info about updating flash memory to <a href="#">Section 11.0</a>. (SCR 4281)</li><li>• Updated Figures 1-6, replacing line art with board photos.</li></ul>
April 2005	001	Initial release of this document.

## 1.0 Purpose

This document, the *Intel® IXDP465 Development Platform Quick Start Guide*, contains instructions for unpacking, inspecting, setting up, and starting the Intel® IXDP465 Development Platform.

Before the IXDP465 development platform is powered up for the first time, it is very important to first become familiar with the platform. Therefore, [Section 5.0](#) through [Section 8.0](#) provide the required information for powering up the platform for first time use. These sections provide the following information:

- Photo of the IXDP465 development platform setup for Quick Start operation, showing the location of factory-installed mezzanine modules and location of key interfaces to assist with connection of console, Ethernet, and power cables.
- Factory default settings of all switches and jumpers, allowing the user to ensure they were not accidentally changed during transport, or repositioned by a previous platform user.
- Location and definitions of the LCD display and all the platform LEDs, so that they can be visually monitored for proper power-up and booting.

Instructions for preparing and starting the IXDP465 development platform begin in [Section 9.0](#).

*Note:* It is *highly* recommended that a printout of this entire Quick Start Guide is obtained prior to preparing and powering up the platform for the first time. All tables in this Quick Start Guide include checkboxes so that items in the printout can be checked off to insure that all platform switches, jumpers, and LEDs operate in their default state, which will ensure a successful first-time bootup of the platform.

Use the Zoom feature in Adobe\* Reader\* to optimize viewing of the figure details contained in this document, for example, the switch and jumper locations on the IXDP465 development platform.

*Note:* If any deviations from the factory default settings of this Quick Start Guide are planned, or for more detailed information about this platform, including design definition of all boards, mezzanine cards, platform components, optional modules, optional switch and jumper settings, and overall development capabilities, please see the *Intel® IXDP465 Development Platform User's Guide*.

## 2.0 Applicable Documents and Revisions

The documents referenced below may be obtained online unless noted otherwise.

**Table 1. Reference Documents (Sheet 1 of 2)**

Title	Document Number	Location
<i>Intel® IXDP465 Development Platform User's Guide</i>	306462	Documentation Web Page <sup>†</sup>
<i>Intel® IXDP465 Development Platform Specification Update</i>	306509	Intel Representative
<i>Intel® IXDP465 Development Platform Documentation Kit</i>	N/A	Documentation Web Page <sup>†</sup>

† This document is available at:

<http://www.intel.com/design/network/products/npfamily/docs/ixp4xx.htm>

†† This document is available at: <http://www.intel.com/design/network/products/npfamily/ixp425swr1.htm>

Table 1. Reference Documents (Sheet 2 of 2)

Title	Document Number	Location
Intel® IXP4XX Product Line of Network Processors Specification Update	306428	Intel Representative
Intel® IXP45X and Intel® IXP46X Product Line of Network Processors Datasheet	306261	Documentation Web Page <sup>†</sup>
Intel® IXP45X and Intel® IXP46X Product Line of Network Processors Developer's Manual	306262	Documentation Web Page <sup>†</sup>
Intel® IXP400 Software Release - Software Release Notes	N/A	Software Web Page <sup>††</sup>
Intel® IXP400 Software - Software Specification Update	273795	Documentation Web Page <sup>†</sup>
Intel® IXP400 Software Programmer's Guide	252539	Documentation Web Page <sup>†</sup>

† This document is available at:  
<http://www.intel.com/design/network/products/npfamily/docs/ixp4xx.htm>

†† This document is available at: <http://www.intel.com/design/network/products/npfamily/ixp425swr1.htm>

## 3.0 Known Issues

Known issues are described in the following documents:

- Silicon errata: Intel® IXP4XX Product Line of Network Processors Specification Update
- Software errata: Intel® IXP400 Software - Software Specification Update
- Platform errata: Intel® IXDP465 Development Platform Specification Update

## 4.0 Inspection

Before the contents of the box are unpacked, ensure that all precautions are observed prior to removing Electrostatic Sensitive Device (ESD) assemblies from their protective packaging.

Unpack the contents of the box. After all the components are unpacked, verify that all the items listed in the packing list are present. The packing list is included in the STOP Readme First document shipped with the kit. If any item is missing, refer to [Section 12.0, “Technical Support”](#) for instructions.

After verifying all items are present:

- Inspect each item for any visible damage.
- Inspect the cable connectors to ensure that none of the pins are bent or damaged.
- Inspect the overall platform assembly to ensure that all mezzanine cards (modules) are properly seated. This can be done by first ensuring that all four 5/8 inch standoffs and nuts on each corner of the mezzanine cards are not loose. If they appear loose either due to shipping or previous handling, then they need to be re-seated per the following procedure:
  - a. Remove all four nuts, by hand-turning them in a counter-clockwise direction as viewed from the top of the assembly.
  - b. Ensure that all four 5/8 inch standoffs are tight, by hand-turning each of them in a clockwise direction while the mezzanine card is still plugged in.

- c. Re-seat the mezzanine card into the connector by applying finger pressure from one hand to the top-side of the mezzanine card directly over the connector while applying finger pressure from your other hand to the bottom-side of the base platform directly under the connector.

**Caution:** Make sure that your fingers on both hands **do not** press against installed components on the assembly.

- d. Verify that the mezzanine card is properly re-seated, by visually confirming there are no gaps between the connectors and no gaps between the four standoffs and the mezzanine card.
- e. Replace all four nuts, by hand-turning and tightening them in a clockwise direction.

If any item is damaged or missing, refer to [Section 12.0, “Technical Support”](#) for instructions.

*Note:*

A set of extra jumpers is included with the kit. These jumpers are not required for default operation of the platform as described in this manual. The extra jumpers are provided for any deviations from the factory default settings which may be required to support optional platform configurations.

## 5.0 Intel<sup>®</sup> IXDP465 Development Platform Overview

The IXDP465 development platform is used for development with the Intel<sup>®</sup> IXP46X Product Line of Network Processors, and consists of:


- one Intel<sup>®</sup> IXDP465 development platform baseboard
- one Intel<sup>®</sup> IXP465 Network Processor/DDR module (defaulted to 533 MHz operation)
- one Intel<sup>®</sup> IXPETM465 MII Ethernet PHY mezzanine card

Both the Intel<sup>®</sup> IXP465 Network Processor/DDR Module and the Intel<sup>®</sup> IXPETM465 MII Ethernet PHY Mezzanine card plug into the baseboard. These three separate card assemblies are shipped pre-assembled by the factory and should appear per the photo as shown in [Figure 1 on page 8](#). The IXDP465 development platform also ships with a Intel<sup>®</sup> PRO/100+ Adapter (packaged separately).

[Figure 1](#) represents the top side view of IXDP465 development platform setup and shows all key interfaces and components. This figure should be compared against the platform that was contained in the box, so that familiarity is gained of all key platform components. The platform should also be viewed from the back side, to observe all provisions for optional mezzanine cards, but if more data is required, please see the *Intel<sup>®</sup> IXDP465 Development Platform User's Guide*.

[Figure 1](#) should also be referenced while preparing the platform for initial use per [Section 9.0](#), to use as a visual aid to validating proper setup of the IXDP465 development platform for Quick Start operation.

Figure 1. Photo of IXDP465 Development Platform Setup for Quick Start Operation



## 5.1 Emulation with the Intel® IXDP465 Development Platform

The Intel® IXDP465 Development Platform can be used for development of products using the Intel® IXP45X and Intel® IXP46X Product Line of Network Processors. Although the IXDP465 development platform is shipped with a fully-featured Intel® IXP465 Network Processor operating at 533 MHz, the platform can also be used to develop products that require either an Intel® IXP460 Network Processor or an Intel® IXP455 Network Processor. These processors support subsets of the IXP465 processor’s features, therefore software can be used to disable certain features on the IXP465 to emulate the IXP460 and IXP455 processors.



Emulation is accomplished by accessing the EXP\_UNIT\_FUSE\_RESET register via software and writing a 1 to the fuse bit number that corresponds to the feature to be disabled. For a full description of this register, see the *Intel® IXP45X and Intel® IXP46X Product Line of Network Processors Developer’s Manual*.

Table 2 shows the default fuse bit settings for the fully-featured IXP465 network processor. Other rows in the table show the fuse bit settings which can disable a feature to emulate IXP460 or IXP455 network processor operation.

**Table 2. Fuse Bit Settings for Network Processor Emulation**

Processor	Features of Intel® IXP45X and Intel® IXP46X Product Line of Network Processors																			
	ECC/1588	PCI	NPE-C (crypto)	NPE-B (no crypto)	NPE-A (WAN)	Ethernet C (crypto)	Ethernet B (no crypto)	UTOPIA	HSS/HDLC	Hash/AES/DES	UDC (USB Device)	RCOMP_disable	Core speed	Core speed	RSA	Ethernet B [1-3]	Ethernet A	USB Host	UCP (phy_limit[1])	UCP (phy_limit[0])
Intel® IXP465 (533 MHz)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Intel® IXP460 (533 MHz)	0	0	0	0	1	0	0	1	1	1	0	0	0	0	1	1	1	0	0	0
Intel® IXP455 (533 MHz)	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
<b>Fuse Bit Number†</b>	23	22	21	20	19	18	17	16	13	10	9	8	7	6	5	4	3	2	1	0

† Available to software via EXP\_UNIT\_FUSE\_RESET register.

## 6.0 Default Switch Settings

This section describes the factory default settings of all platform switches, to ensure they were not accidentally changed during transport, or repositioned by a previous user of the platform.

The IXDP465 development platform has all switches located on the top-side of the entire assembly. Figure 2 on page 11 identifies the exact location of all switches, clustered into two different areas, one for GPIO LED Switches and one for Expansion Bus Address Strap Switches.


- The GPIO LED Switches (SW1, SW2) allow the choice of connecting any of the 16 GPIO signals to a LED, which can be useful for development purposes. Each GPIO has a green LED indicator attached to it, which when illuminated, indicates a “low” state. A switch is placed on each LED to allow the LED to be disconnected from the GPIO and reduce loading. See Figure 2 on page 11 for the DIP Switch locations. Although the factory default setting for these switches is “LED Illuminated,” these 16 switches can be set to other settings if desired.
- The Expansion Bus Address Strap switches (SW3, SW4, SW5) allows the choice of either floating, or a 1 K pull-down resistor on each of the 24 expansion bus address lines. If set to floating, then a weak internal pull-up resistor in the IXP465 network processor controls the strap value. For operation as defined in this guide, ensure that all switches are set as shown in Figure 2.

All platform switches are summarized in Table 3, which provides a high-level description of each switch and their factory default settings, all of which must be checked prior to powering up the platform for the first time.

**Table 3. Intel® IXDP465 Development Platform Switch Descriptions and Default Settings**

Board Location (See Figure 2)	Ref ID	Switch Description	Default Settings	Quick Start Check?
GPIO LED Switches	SW1	Select individual LED illumination settings of all odd GPIO signals	All odd GPIO illuminated. Switch in ON position.	<input type="checkbox"/>
GPIO LED Switches	SW2	Select individual LED illumination settings of all even GPIO signals	All even GPIO illuminated. Switch in ON position.	<input type="checkbox"/>
Expansion Bus Address Strap Switches	SW3	Select floating or pull down straps for EX_ADDR[8:1] signals	All EX_ADDR floating. Switch in OFF position.	<input type="checkbox"/>
Expansion Bus Address Strap Switches	SW4	Select floating or pull down straps for EX_ADDR[16:9] signals	All EX_ADDR floating. Switch in OFF position.	<input type="checkbox"/>
Expansion Bus Address Strap Switches	SW5	Select floating or pull down straps for EX_ADDR[24:17] signals	All EX_ADDR floating. Switch in OFF position.	<input type="checkbox"/>

Figure 2. Intel® IXDP465 Development Platform Switch Locations



## 7.0 Default Jumper Settings

This section defines the factory default settings for all IXDP465 development platform jumpers, to ensure they were not accidentally changed during transport, or repositioned by a previous user of the platform. The jumper settings are discussed in the following sections:

- “Intel® IXDP465 Baseboard Jumpers” on page 12
- “Intel® IXP465 Network Processor/DDR Module Jumpers” on page 15
- “Intel® IXPETM465 Ethernet PHY Mezzanine Card Jumpers” on page 17

Each section contains a jumper summary table which provides a high-level description of each jumper and their factory default settings, all of which must be checked prior to powering up the platform for the first time.

### 7.1 Intel® IXDP465 Baseboard Jumpers

The Intel® IXDP465 baseboard jumpers are located on the top-side of the platform assembly as shown in Figure 3. This figure illustrates the exact location of these jumpers clustered into three different detailed views, along with their default settings.


**Table 4. Intel® IXDP465 Baseboard Jumper Descriptions and Default Settings (Sheet 1 of 2)**

Board Location (See Figure 3)	Ref ID	Jumper Description for Installed State	Default Settings	Quick Start Check?
WRITE	JP126	Disables write protection of the I2C EEPROM device.	Installed.	<input type="checkbox"/>
A24	JP127	EX_ADDR24 jumper used in conjunction with JP128 to partition and access the flash device in any of four sections. <ul style="list-style-type: none"> <li>• For RedHat* RedBoot*, install both JP127 and JP128.</li> <li>• For Wind River* VxWorks*, install JP127 only.</li> </ul>	Installed.	<input type="checkbox"/>
A23	JP128	EX_ADDR23 jumper used in conjunction with JP127 to partition and access the flash device in any of four sections. <ul style="list-style-type: none"> <li>• For RedHat* RedBoot*, install both JP127 and JP128.</li> <li>• For Wind River* VxWorks*, install JP127 only.</li> </ul>	Installed.	<input type="checkbox"/>
MII/SMII/UTOPIA: SMII	JP1	Connects SMII-specific shared NPE signals to the SMII multi-port PHY	Not installed.	<input type="checkbox"/>
MII/SMII/UTOPIA: ETH A	JP2	Connects ETH A-specific shared NPE signals to the NPE A mezzanine card	Installed.	<input type="checkbox"/>
MII/SMII/UTOPIA: UTOPIA	JP3	Connects UTOPIA-specific NPE signals to the UTOPIA mezzanine card	Not installed.	<input type="checkbox"/>

Table 4. Intel® IXDP465 Baseboard Jumper Descriptions and Default Settings (Sheet 2 of 2)

Board Location (See Figure 3)	Ref ID	Jumper Description for Installed State	Default Settings	Quick Start Check?
MII/SMII/UTOPIA: ETH B	JP4	Connects ETH B-specific shared NPE signals to the NPE B mezzanine card	Installed.	<input type="checkbox"/>
MII/SMII/UTOPIA: ETH C	JP65 JP95	Connects ETH C-specific shared NPE signals to the NPE C mezzanine card	Installed. Installed.	<input type="checkbox"/>
MII/SMII/UTOPIA	JP9 JP11	Connects a 33 MHz signal on both UTP_OP_CLK and UTP_IP_CLK	Not installed. Not installed.	<input type="checkbox"/>

Figure 3. Intel® IXDP465 Baseboard Jumper Locations




## 7.2 Intel® IXDP465 Network Processor/DDR Module Jumpers

Figure 4 identifies the jumper locations and Table 5 describes the jumper settings for the Intel® IXDP465 Network Processor/DDR module.

**Table 5. Intel® IXDP465 Network Processor/DDR Module Jumper Descriptions and Default Settings**

Board Location (See Figure 4)	Ref ID	Jumper Description for Installed State	Default Settings	Quick Start Check?
SCL	P4	Selects I2C pin, instead of GPIO	Shunt 1-2.	<input type="checkbox"/>
SDA	P2	Selects I2C pin, instead of GPIO	Shunt 1-2.	<input type="checkbox"/>
IXP 3.3V	JP45	Enables monitoring of +3.3V current	Not installed.	<input type="checkbox"/>
XTAL OUT	JP50	Reserved	Not installed.	<input type="checkbox"/>
XTAL IN	JP49	Reserved	Not installed.	<input type="checkbox"/>
BYPSSCLK	JP41	Connects oscillator to OSC_IN	Installed.	<input type="checkbox"/>
REFCLK	JP1	Enables Spreadpectrum clock reference	Not installed.	<input type="checkbox"/>
SSCLK	JP2	Connects Spreadpectrum clock to OSC_IN	Not installed.	<input type="checkbox"/>
ENSSCLK	JP44	Enables Spreadpectrum clock output	Not installed.	<input type="checkbox"/>
IXP COREV	JP47	Enables monitoring of +1.3V/+1.4V current	Not installed.	<input type="checkbox"/>
667 MHz	JP48	Enables selection of +1.3V as core voltage, instead of +1.4V as required for 667 MHz operation	Installed.	<input type="checkbox"/>
IXP 2.5V	JP46	Enables monitoring of +2.5V current	Not installed.	<input type="checkbox"/>

Figure 4. Intel® IXP465 Network Processor/DDR Module Jumper Locations






### 7.3 Intel® IXPETM465 Ethernet PHY Mezzanine Card Jumpers

Figure 5 identifies the jumper locations and Table 6 describes the jumper settings for the Ethernet card.

**Table 6. Intel® IXPETM465 Ethernet PHY Mezzanine Card Jumper Descriptions and Default Settings**

Board Location (See Figure 5)	Ref ID	Jumper Description for Installed State	Default Settings	Quick Start Check?
GND	JP1	GND	Not installed.	<input type="checkbox"/>
GND	JP3	GND	Not installed.	<input type="checkbox"/>
A0	JP2	PHY Address A0 for MII-0 NPE-B Ethernet mezzanine slot	Shunt 2-3.	<input type="checkbox"/>
A1	JP5	PHY Address A1 for MII-0 NPE-B Ethernet mezzanine slot	Shunt 2-3.	<input type="checkbox"/>
A2	JP6	PHY Address A2 for MII-0 NPE-B Ethernet mezzanine slot	Shunt 2-3.	<input type="checkbox"/>
A3	JP7	PHY Address A3 for MII-0 NPE-B Ethernet mezzanine slot	Shunt 2-3.	<input type="checkbox"/>
A4	JP8	PHY Address A4 for MII-0 NPE-B Ethernet mezzanine slot	Shunt 2-3.	<input type="checkbox"/>
GND	JP4	GND	Not installed.	<input type="checkbox"/>

Figure 5. Intel® IXPETM465 Ethernet PHY Mezzanine Card Jumper Locations



## 8.0 LCD Display and LED Indicators

This section provides an overview of the LCD display, and also defines the locations, colors, and definitions of all LEDs, so that they can be visually monitored for proper power-up and booting.

The IXP465 development platform provides a 2 x16-digit LCD display that can be used for software debug. The IXP465 Expansion Data Bus directly drives this display. When booting the factory-installed boot images for either Wind River\* VxWorks\* or RedHat\* RedBoot\*, this LCD display can be monitored for visual indication of a successful boot, as described in [Section 10.0](#) of this guide.


The IXP465 development platform also uses many LEDs scattered throughout the different board assemblies, each of which provides a different visual indication of status, as summarized in [Table 7](#). After powering up the platform for the first time, all of the default settings must be checked to ensure correct operation.

Figure 6 on page 20 shows the exact locations for all LEDs on the IXDP465 development platform, per the descriptions and colors summarized in Table 7.

**Table 7. Intel® IXDP465 Development Platform LED Descriptions and Default Settings**

Board Location (See Figure 6)	LED Indication when ON	Color	Default Settings	Quick Start Check
Power LED: +12V	+12V power is on	Green	ON	<input type="checkbox"/>
Power LED: +5V	+5V power is on	Green	ON	<input type="checkbox"/>
Power LED: -12V	-12V power is on	Green	ON	<input type="checkbox"/>
Power LED: +3.3V	+3.3V power is on	Green	ON	<input type="checkbox"/>
Power LED: +1.5V <sup>†</sup>	+1.3V/+1.4V power is on	Green	ON	<input type="checkbox"/>
PCI LED: Option	PCI operating as option	Green	OFF	<input type="checkbox"/>
PCI LED: 66 MHz	PCI operating at 66 MHz	Green	ON	<input type="checkbox"/>
PCI LED: 33 MHz	PCI operating at 33 MHz	Green	OFF	<input type="checkbox"/>
PCI LED: Host	PCI operating as host	Green	ON	<input type="checkbox"/>
CPU Power LED: Reset	IXP465 system is in reset	Green	OFF	<input type="checkbox"/>
CPU Power LED: 3.3V	+3.3V power is applied to IXP465	Green	ON	<input type="checkbox"/>
CPU Power LED: 2.5V	+2.5V power is applied to IXP465	Green	ON	<input type="checkbox"/>
CPU Power LED: COREV	+1.3V/+1.4V power is applied to IXP465	Green	ON	<input type="checkbox"/>
GPIO LEDs: GPIO 0 - GPIO 15	GPIO[15:0] driven low	Green	ON	<input type="checkbox"/>
GPIO LEDs: Power LED	+2.5V power is on	Green	ON	<input type="checkbox"/>
FLASH STATUS	Flash device is being programmed	Yellow	OFF	<input type="checkbox"/>
<sup>†</sup> Board silkscreen text reads "+1.5V" however, core voltage is actually 1.3/1.4V.				

Figure 6. Intel® IXDP465 Development Platform LED Locations



## 9.0 Preparing the Platform for Initial Use

After unpacking the board and before powering on the board, the IXDP465 development platform needs to be prepared for first time use.

To prepare the platform, follow these steps:

1. Verify that all default switch settings in [Table 3 on page 10](#) are checked off.
2. Verify that all default jumper settings in [Table 4 on page 12](#), [Table 5 on page 15](#), and [Table 6 on page 17](#) are checked off.
3. Confirm that either one of two boot options is selected, controlled by jumper(s) JP127 (A24) and JP128 (A23) as shown in [Figure 3 on page 14](#).
  - For RedBoot, install both JP127 and JP128.
  - For VxWorks, install JP127 only.
4. Install the Intel® PRO/100+ Adapter into PCI slot 0. Connect the straight Ethernet cable provided with the IXDP465 development platform and connect to a hub.

**Note:** An alternative option is to use a cross-over Ethernet cable between the Intel® PRO/100+ Adapter and the host system.

5. Connect the serial cable between COM1 on the host system:
  - to UART0 for Linux\* developers
  - to UART1 for VxWorks\* developers

[Table 8](#) shows the UART serial communication values.

**Table 8. UART Communications Configuration**

Parameter	Linux* Value	VxWorks* Value
Port	UART0	UART1
Bits per Second	115,200	9,600
Data Bits	8	8
Parity	None	None
Stop Bit	1	1
Flow Control	None	None


## 10.0 Starting the Platform

To start the platform, follow these steps:

1. Verify that the power switch is in the OFF position on the Autec Power Systems\* power supply provided with the IXDP465 development platform.
2. The power module plugs into the baseboard through a standard ATX 20-pin power supply connector (P1). Connect the ATX power supply cable to ATX connector on the IXDP465 development platform.
3. Power on the board by flipping the black switch on the power supply.
4. Verify that all LED illuminations match the defaults settings listed in [Table 7 on page 19](#).

5. Verify the board booted properly by checking the LCD display
  - for RedBoot bootloader:
    - line 1 = RedBoot
    - line 2 = 0001
  - for VxWorks bootloader: see Figure 7.

**Figure 7. LCD Display for Wind River\* VxWorks\* Bootloader**



## 11.0 Operating the Platform

The software release notes are intended to guide the user through software installation and setup of the host computer, and can be found at the following Web site:

<http://www.intel.com/design/network/products/npfamily/ixp425swr1.htm>

*Note:* You must register and login to download Intel software.

In the “Software Available” section of the above Web site, first click Register/Login, then select the latest current software release; for example, “Intel® IXP400 Software v2.0”. Then click the link for the release notes; for example, “2.0 Release Notes”.

Developers should continue by following the instructions in the software release notes.

Refer to the *Intel® IXP465 Development Platform User’s Guide* for detailed instructions on using the IXP465 development platform, including how to update the IXP465 development platform’s flash memory.

## 12.0 Technical Support

If any of the contents are missing or if you have any questions, contact your local Intel representative.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>