

JVC



CD/CASSETTE RECEIVER

KW-XC550

ENGLISH

**RECEPTOR-REPRODUCTOR
DE CD-CASSETTE**


KW-XC550

ESPAÑOL

RADIOCASSETTE/CD

KW-XC550

FRANÇAIS



For installation and connections, refer to the separate manual.
Para la instalación y las conexiones, refiérase al manual separado.
Pour l'installation et les raccordements, se référer au manuel séparé.

INSTRUCTIONS **MANUAL DE INSTRUCCIONES** **MANUEL D'INSTRUCTIONS**

For customer Use:

Enter below the Model No. and Serial No. which are located on the top or bottom of the cabinet. Retain this information for future reference.

Model No. _____

Serial No. _____

VNN3828-631



INFORMATION (For USA)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Identification and Certification Labels

Bottom of the main unit

**Notes:**

- *1 The date of manufacture.
- *2 The ID code of manufacturing plant.
- *3 Marking of country origin.

IMPORTANT FOR LASER PRODUCTS (For USA only)**Precautions:**

1. CLASS 1 LASER PRODUCT
2. **DANGER:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION:** Do not open the top cover. There are no user-serviceable parts inside. Leave all servicing to qualified service personnel.
4. **CAUTION:** This CD player uses invisible laser radiation, however, is equipped with safety switches to prevent radiation emission when unloading CDs. It is dangerous to defeat the safety switches.
5. **CAUTION:** Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION on Volume Setting

CDs produce very little noise compared with other sources. If the volume level is adjusted for the tuner, for example, the speakers may be damaged by the sudden increase in the output level. Therefore, lower the volume before playing a CD and adjust it as required during playback.

Thank you for purchasing a JVC product. Please read all instructions carefully before operation, to ensure your complete understanding and to obtain the best possible performance from the unit.

CONTENTS

BASIC OPERATIONS 5



RADIO OPERATIONS 6

Listening to the radio 6

Storing stations in memory 7

FM station automatic preset: SSM 7

Manual preset 8

Tuning into a preset station 9

Other convenient tuner functions 10

Scanning broadcast stations 10

Selecting FM reception sound 10



CD OPERATIONS 11

Playing a CD 11

Locating a track or a particular portion on a CD 12

Selecting CD playback modes 13



TAPE OPERATIONS 14

Listening to a tape 14

Finding the beginning of a tune 16

Other convenient tape functions 17

Skipping the blank portions on the tape 17

Playing the current tune repeatedly 17



SOUND ADJUSTMENTS 18

Selecting preset sound modes 18

Adjusting the sound 19

Storing your own sound adjustments 20




SPECTRUM ANALYSER 21

Selecting spectrum analyzer patterns 21



CONTINUED TO THE NEXT PAGE

OTHER MAIN FUNCTIONS	23
Changing general settings (PSM)	23
Setting the clock	23
Selecting the name of the auxiliary source	24
Turning on or off the key-touch tone function	24
Selecting the dimmer mode	25
Changing the AM/FM channel intervals	25
REMOTE OPERATIONS	26
Installing the batteries	26
Using the remote controller	26
CD CHANGER OPERATIONS	27
Playing CDs	27
Selecting CD playback modes	29
LISTENING TO AN EXTERNAL DEVICE	30
Listening to the auxiliary source	30
MAINTENANCE	31
Handlings cassettes	31
Handling CDs	32
How to Reset your unit	32
TROUBLESHOOTING	33
SPECIFICATIONS	35



BEFORE USE


* For safety...

- Do not raise the volume level too much, as this will block outside sounds, making driving dangerous.
- Stop the car before performing any complicated operations.

* Temperature inside the car...

If you have parked the car for a long time in hot or cold weather, wait until the temperature in the car becomes normal before operating the unit.

BASIC OPERATIONS



Note:

When you use this unit for the first time, set the built-in clock correctly, see page 23.

1




Turn on the power.

Note on One-Touch Operation:

When you select a source in step 2 below, the power automatically comes on. You do not have to press this button to turn on the power.

2



Select the source.

To operate the tuner, see pages 6 – 10.


To operate the CD player, see pages 11 – 13.

To operate the tape deck, see pages 14 – 17.

To operate the CD changer, see pages 27 – 29.

To operate an external device, see page 30.

3



To turn up the volume

To turn down the volume

Adjust the volume.



Volume level appears.

4

Adjust the sound as you want (see pages 18 – 20).

- If you need to change the spectrum analyser pattern, see page 21.

To drop the volume in a moment

Press **P/I / ATT** briefly while listening to any source. “ATT” starts flashing on the display, and the volume level will drop in a moment.

To resume the previous volume level, press the button briefly again.

To turn off the power


Press **P/I / ATT** for more than 1 second.



RADIO OPERATIONS

ENGLISH

Listening to the radio




1



Select the band (FM1, FM2, FM3 or AM).


You can select any one of FM1, FM2, and FM3 to listen to an FM station.



2


Start searching a station.

When a station is received, searching stops.



To search stations of higher frequencies

To search stations of lower frequencies



To stop searching before a station is received, press the same button you have pressed for searching.

To tune in a particular frequency manually:

- 1 Press TUNER/BAND repeatedly to select the band (FM or AM).
- 2 Press and hold **▶▶|▲** or **◀◀|▼** until "MANU" flashes on the display. Now you can manually change the frequency while "MANU" is flashing.
- 3 Press **▶▶|▲** or **◀◀|▼** repeatedly until the frequency you want is reached.
 - If you hold down the button, the frequency keeps changing until you release the button.


Storing stations in memory

You can use one of the following two methods to store broadcasting stations in memory.



- Automatic preset of FM stations: SSM (Strong-station Sequential Memory)
- Manual preset of both FM and AM stations

FM station automatic preset: SSM


You can preset 6 local FM stations in each FM band (FM1, FM2, and FM3).


1


Select the FM band number (FM1, FM2 or FM3) you want to store FM stations into.


2


Press and hold both buttons for more than 2 seconds.



“SSM” appears, then disappears when automatic preset is over.


Local FM stations with the strongest signals are searched and stored automatically in the band number you have selected (FM1, FM2 or FM3). These stations are preset in the number buttons — No. 1 (lowest frequency) to No. 6 (highest frequency).

When automatic preset is over, the station stored in number button 1 will be automatically tuned in.

Manual preset

You can preset up to 6 stations in each band (FM1, FM2, FM3 and AM) manually.

EXAMPLE: Storing an FM station of 88.3 MHz into the preset number 1 of the FM1 band




1



Select the FM1 band.



2




Tune into a station of 88.3 MHz.



See page 6 to tune into a station.



3



Press and hold the button for more than 2 seconds.



"P1" flashes for a few seconds.

4



Repeat the above procedure to store other stations into other preset numbers.

Notes:



- A previously preset station is erased when a new station is stored in the same preset number.
- Preset stations are erased when the power supply to the memory circuit is interrupted (for example, during battery replacement). If this occurs, preset the stations again.

Tuning into a preset station

You can easily tune into a preset station. Remember that you must store stations first. If you have not stored them yet, see pages 7 and 8.




Select the band (FM1, FM2, FM3 or AM) you want.



Select the number (1 – 6) for the preset station you want.

Other convenient tuner functions



Scanning broadcast stations




When you press SCAN while listening to the radio, station scanning starts. ("SCAN" appears on the display.) Each time a broadcast is tuned in, scanning stops for about 5 seconds (tuned frequency number flashes on the display), and you can check what program is now being broadcasted.

If you want to listen to that program, press the same button again to stop scanning.


Selecting FM reception sound

When an FM stereo broadcast is hard to receive:

Press MO RPT (Monaural/Repeat) while listening to an FM stereo broadcast. The sound you hear becomes monaural but reception will be improved.



Lights up when receiving an FM broadcast in stereo.





To restore the stereo effect, press the same button again.

When using this unit in an area other than North or South America:

You need to change the AM/FM channel intervals. See "Changing the AM/FM channel intervals" on page 25.




Playing a CD



Insert a disc into the loading slot.

The unit turns on, draws a CD and starts playback automatically.

- Insert the CD with the printed face facing upside.



Note on One-Touch Operation:

When a CD is already in the loading slot, pressing CD/CD-CH turns on the unit and starts playback automatically.

To stop play and eject the CD

Press ▲.


CD play stops and the CD automatically ejects from the loading slot ("CD EJECT" appears on the display). The source changes to the last selected source.

If you change the source, the CD play also stops (without ejecting the CD this time).


- If the ejected disc is not removed for about 15 seconds, the disc is automatically inserted again into the loading slot to protect it from dust. (CD play will not start this time.)
- You can eject the CD even when the unit is turned off.



Locating a track or a particular portion on a CD




To fast-forward or reverse the track



Press and hold ►►| ▲ while playing a CD, to fast-forward the track.

Press and hold |◄◄ ▼ while playing a CD, to reverse the track.


To go to the next track or the previous track



Press ►►| ▲ briefly while playing a CD, to go ahead to the beginning of the next track. Each time you press the button consecutively, the beginning of the next track is located and played back.

Press |◄◄ ▼ briefly while playing a CD, to go back to the beginning of the current track. Each time you press the button consecutively, the beginning of the previous track is located and played back.

To go to a particular track directly




Press the number button corresponding to the track number to start its playback.

- To select a track number from 1 – 6:
Press 1 (7) – 6 (12) briefly.
- To select a track number from 7 – 12:
Press and hold 1 (7) – 6 (12) for more than 1 second.




Selecting CD playback modes



To play back tracks at random (Random Play)

You can play back all tracks on the CD at random.



Each time you press B.SKIP RND (Blank Skip/Random) while playing a CD, CD random play mode turns on and off alternatively. When the random mode is turned on, the RND indicator lights up on the display and a track randomly selected starts playing.




To play back tracks repeatedly (Repeat Play)

You can play back the current track repeatedly.



Each time you press MO RPT (Monaural/Repeat) while playing a CD, CD repeat play mode turns on and off alternatively. When the repeat mode is turned on, the RPT indicator lights up on the display.



To prohibit CD ejection

You can prohibit the CD ejection and can "lock" a CD in the loading slot.



Press and hold CD and ▲ for more than 2 seconds. "EJECT" flashes on the display for about 5 seconds, and the CD is "locked."



(at the same time)


To cancel the prohibition and "unlock" the CD, press and hold CD and ▲ for more than 2 seconds again. "EJECT" flashes on the display for about 5 seconds, and the CD is "unlocked."




TAPE OPERATIONS

ENGLISH

Listening to a tape



1




Insert a cassette.

The unit turns on and tape play starts automatically. When one side of the tape reaches its end during play, the other side of the tape automatically starts playing. (Auto Reverse)

Note on One-Touch Operation:

When a cassette is already in the cassette compartment, pressing TAPE/PROG turns on the unit and starts tape play automatically.

2




Turn on or off the Dolby B NR* as needed.

Each time you press the button, the Dolby B NR turns on and off.




This indicator lights up when the Dolby B NR is turned on.

3



Select the tape direction.

Each time you press the button, the tape direction changes alternatively.



* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby" and the double-D symbol □□ are trademarks of Dolby Laboratories Licensing Corporation.



To stop play and eject the cassette

Press ▲.

Tape play stops and the cassette automatically ejects from the cassette compartment.

If you change the source, the tape play also stops (without ejecting the cassette this time).

- You can also eject the cassette with the unit turned off.


To fast-forward and rewind a tape

- Press ►► ▲ for more than 1 second to fast-forward the tape.

When the tape reaches its end, the tape is reversed and playback starts from the beginning of the other side.

- Press ◀◀ ▼ for more than 1 second to rewind the tape.

When the tape reaches its end, playback of the same side starts.




To stop fast-forward and rewind at any position on the tape, press TAPE/PROG.

Tape play starts from that position on the tape.

About Automatic Tape Type Detection

With the Automatic Tape Type Detection mechanism provided for this unit, you can listen to type I, II and IV tapes without changing any settings.

To prohibit tape ejection



You can prohibit the tape ejection and can "lock" a tape in the cassette compartment.

Press and hold TAPE/PROG and ▲ for more than 2 seconds. "EJECT" flashes on the display for about 5 seconds, and the tape is "locked."




(at the same time)


To cancel the prohibition and "unlock" the tape, press and hold TAPE/PROG and ▲ for more than 2 seconds again. "EJECT" flashes on the display for about 5 seconds, and the tape is "unlocked."

Finding the beginning of a tune

Multi Music Scan allows you to automatically start playback from the beginning of a specified tune. You can specify up to 9 tunes ahead or before the current tune.



1 During playback



To locate a tune ahead of the current tune on the tape

To locate a tune before the current tune on the tape

Specify how many tunes ahead of or before the current tune the tune you want is located.



Each time you set the tune, the number changes up to ± 9 .


When the beginning of the specified tune is located, playback starts automatically.

Notes:

- While locating a specified tune:
 - If the tape is rewound to its beginning, playback starts from the beginning of that side.
 - If the tape is fast-forwarded to the end, it is reversed and played from the beginning of the other side.
- In the following cases, Multi Music Scan may not operate correctly.
 - Tapes with tunes having long pianissimo passages (very quiet parts) or non-recorded portions during tunes.
 - Tapes with short non-recorded sections.
 - Tapes with high level noise or humming between tunes.
 - The Dolby NR setting does not match. For example, if the tape is recorded with the Dolby C NR.



Other convenient tape functions



MO RPT B.SKIP RND

Skipping the blank portions on the tape


You can skip blank portions between the tunes. (Blank Skip)

B.SKIP RND



Each time you press B.SKIP RND (Blank Skip/Random) while playing a tape, the blank skip function turns on and off alternatively.

When this function is on, the B.SKIP indicator lights up on the display and the unit skips blank portions of 15 seconds or more, fast-forwards to the next tune, then starts playing it.



- When the tape reaches its end while fast-forwarding, the tape direction will be changed automatically.


Playing the current tune repeatedly

You can play the current tune repeatedly. (Repeat Play)

MO RPT



Each time you press MO RPT (Mono/Repeat) while playing a tape, Repeat Play turns on and off alternatively. When this function is on, the RPT indicator lights up on the display.



Note:

In the following cases, Blank Skip and Repeat Play may not operate correctly.


- Tapes with tunes having long pianissimo passages (very quiet parts) or non-recorded portions during tunes.
- Tapes with short non-recorded sections.
- Tapes with high level noise or humming between tunes.
- The Dolby NR setting does not match. For example, if the tape is recorded with the Dolby C NR.



SOUND ADJUSTMENTS

Selecting preset sound modes

You can select a preset sound adjustment suitable to the music genre.




1



Select the sound mode you want.

Each time you press the button, the sound mode changes as follows.




Indication	For:	Preset values		
		Bass	Treble	Loudness
SCM OFF	(Flat sound)	00	00	On
BEAT	Rock or disco music	+02	00	On
SOFT	Quiet background music	+01	-03	Off
POP	Light music	+04	+01	Off

Notes:

- You can adjust the preset sound mode to your preference, and store it in memory. If you want to adjust and store your original sound mode, see “Storing your own sound adjustments” on page 20.
- To adjust the bass and treble reinforcement levels or to turn on/off the loudness function temporarily, see “Adjusting the sound” on page 19.

Adjusting the sound

You can adjust the sound characteristics to your preference.



1



Select the item you want to adjust.




Indication	To do:	Range
BAS (Bass)	Adjust the bass	-06 (min.) — +06 (max.)
TRE (Treble)	Adjust the treble	-06 (min.) — +06 (max.)
FAD (Fader)*	Adjust the front and rear speaker balance	R06 (rear only) — F06 (front only)
BAL (Balance)	Adjust the left and right speaker balance	L06 (left only) — R06 (right only)
LOUD (Loudness)	Turn on or off the loudness function**	ON — OFF
VOL (Volume)	Adjust the volume	00 (min.) — 50 (max.)

Notes:

* If you are using a two-speaker system, set the fader level to “00” (center).

** The loudness function can boost low and high frequencies to produce a well-balanced sound at low volume levels. When the loudness function is “ON,” the LOUD indicator lights up.

2



Adjust the level.


Note:

Normally the + and – buttons work as the volume control buttons. So you do not have to select “VOL” to adjust the volume level.



Storing your own sound adjustments

You can adjust the sound modes (BEAT, SOFT, POP: see page 18) to your preference and store your own adjustments in memory.



1



Call up the sound mode you want to adjust.
See page 18 for details.

**Within
5 seconds**


2



Select “BAS (bass),” “TRE (treble)” or “LOUD (loudness).”

**Within
5 seconds**

3



Adjust the selected item.
See page 19 for details.

**Within
5 seconds**

4



Press and hold SOUND until “MEMO” flashes on the display.
Your setting is stored in memory.

5


Repeat the same procedure to store other settings.

To reset to the factory settings

Repeat the same procedure and reassign the preset values listed in the table on page 18.

Selecting spectrum analyzer patterns

You can select any one from 8 different spectrum analyzer patterns or a demonstration of all the mode.



1



Select the spectrum analyzer pattern you want.


Each time you press the button, the pattern changes as follows:

1. **ALL DEMO** (default setting)
Demonstrate all the spectrum analyzer patterns (2 to 9), each for 10 seconds.
2. **PEAK HOLD 1**
Hold the peak for about 2 seconds, displayed from the top.
3. **STANDARD 1**
Standard spectrum analyser, displayed from the top.
4. **PEAK HOLD 2**
Same as PEAK HOLD 1, but displayed from the bottom.
5. **STANDARD 2**
Same as STANDARD 1, but displayed from the bottom.
6. **PEAK**
Display only the peak and the two segments below it from the top.
7. **TALKING MOUTH**
Display the upper and lower peaks together.
8. **MIRROR**
Symetrical display.
9. **SIDE WINDER**
Spectrum analyser displayed horizontally. In this case the frequency indications at the bottom of the display disappear.
10. **OFF**
No pattern displayed



Spectrum Analyser Examples:


2. PEAK HOLD 1




3. STANDARD 1



6. PEAK




7. TALKING MOUTH



8. MIRROR



9. SIDE WINDER




The lower frequencies are shown on the top and the higher ones at the bottom. (From 60 Hz, 150 Hz, 400 Hz, 1 kHz..12 kHz.)

Changing general settings (PSM)

You can change the following settings for this unit by using the PSM (Preferred Setting Mode) control.

- **CLOCK (H/M)**: Adjusts the built-in clock (see below).
- **AUX**: Selects the name which will be displayed when you press AUX (see page 24).
- **BEEP**: Turn on or off the key-touch tone function (see page 24).
- **DIMMER**: Selects the dimmer mode (see page 25).
- **AREA**: Selects the area you use this unit — when using this unit in an area other than North or South America (see page 25).




Setting the clock

After installation, set the built-in clock correctly.

1 Press SEL for more than 2 seconds.

One of the PSM items appears on the display.

2 If "PSM CLOCK H" does not appear, press **▶▶|▲** or **◀◀|▼** repeatedly until it appears.



The current setting appears.

3 Press + or – to adjust the hour.

4 Press **▶▶|▲** or **◀◀|▼** until "PSM CLOCK M" appears on the display.

5 Press + or – to adjust the minute.

6 Press DISP to start clock.

To check the current clock time (changing the display mode)

Press DISP repeatedly. Each time you press the button, the display mode changes as follows.

<p>During tuner operation:</p> <p>Frequency ↔ Clock</p>	<p>During tape operation:</p> <p>Play mode ↔ Clock</p>	<p>During CD operation:</p> <p>Elapsed playing time ↔ Clock</p>
--	---	--

- If the unit is not in use when you press DISP, the power turns on, the clock time is shown for 5 seconds, then the power turns off.

Selecting the name of the auxiliary source

When shipped from the factory, the auxiliary source name appears as "AUX" on the display. You can change it to "MD" or "TV."

1 Press SEL for more than 2 seconds.

One of the PSM items appears on the display.


2 If "PSM AUX" does not appear, press ►►▲ or ◀◀▼ repeatedly until it appears.



The current setting appears.

3 Press + or – to select the name you want to use.

Each time you press the button, the name changes as follows:




Turning on or off the key-touch tone function

When shipped from the factory, the key-touch tone function is on so that you can hear a "beep" each time you press a button. If you want to turn off this function, follow the procedure below.

1 Press SEL for more than 2 seconds.

One of the PSM items appears on the display.

2 If "PSM BEEP" does not appear, press ►►▲ or ◀◀▼ repeatedly until it appears.



The current setting appears.

3 Press – to turn off this function (or press + to turn on the function again).

Selecting the dimmer mode

When you turn on the car head lights, the display automatically dims (Auto Dimmer).

When shipped from the factory, Auto Dimmer function has been activated.


If you want to cancel this function, follow the procedure below and select "OFF:"

- AUTO: Activates Auto Dimmer
- OFF: Cancels Auto Dimmer

1 Press SEL for more than 2 seconds.

One of the PSM items appears on the display.

2 If "PSM DIMMER" does not appear, press ►►| ^ or |◄◄ v repeatedly until it appears.



The current setting appears.

3 Press - to select "OFF" (or press + to select "AUTO" again).

Changing the AM/FM channel intervals

When using this unit in an area other than North or South America:

When this unit is shipped from the factory, the channel intervals are set to 10 kHz for AM and 200 kHz for FM. You can change the channel intervals by following the procedure below.

1 Press SEL for more than 2 seconds.

One of the PSM items appears on the display.

2 If "PSM AREA" does not appear, press ►►| ^ or |◄◄ v repeatedly until it appears.

3 Press +.

"AREA EU" appears and the channel intervals are set to 9 kHz for AM and 50 kHz (for manual tuning) / 100 kHz (for searching) for FM.




To reset to the factory setting, follow the above step 1 and 2, then press - in step 3 ("AREA US" appears on the display).

- AREA EU: Select this when used in an area other than North and South America.
- AREA US: Select this when used in North or South America.


REMOTE OPERATIONS

Before using the remote controller:

- Aim the remote controller directly at the remote sensor on the main unit. Make sure there is no obstacle in between.
- Do not expose the remote sensor to strong light (direct sunlight or artificial lighting).




Installing the batteries



When the controllable range or effectiveness of the remote controller decreases, replace the batteries — R03(UM-4)/AAA(24F).

Using the remote controller



- 1 Selects the source.
Each time you press FUNC (function), the source changes.
- 2 Functions as the +/- button on the main unit.
 - Does not function for the PSM adjustments.
- 3 Functions as the SEL button on the main unit.
 - Does not function for the PSM adjustments.
- 4 • Functions as the TUNER/BAND button while listening to the radio.
• Functions as the TAPE/PROG button while listening to a tape.
• Functions as the +DISC button while listening to the CD changer.
Each time you press the button, the disc number increases, and selected disc starts playing.
- 5 • Functions as the station searching button while listening to the radio.
• Functions as the fast forward or rewind button or Multi Music Scan button while listening to a tape.
• Functions as the fast forward or reverse button or track selecting button while listening to a CD.
- 6 Turns on or off the power.

CD CHANGER OPERATIONS

We recommend that you use one of the CH-X series with your KW-XC550.


If you have another CD automatic changer, consult your JVC car audio dealer for connections.

- For example, if your CD automatic changer is one of the KD-MK series, you need a cord (KS-U15K) for connecting it to this unit.

Before operating your CD automatic changer:

- Refer also to the Instructions supplied with your CD changer.
- If no discs are in the magazine of the CD changer or the discs are inserted upside down, "NO DISC" will appear on the display. If this happens, remove the magazine and set the discs correctly.
- If "RESET 1 - RESET 8" appears on the display, something is wrong with the connection between this unit and the CD changer. If this happens, check the connection, connect the connecting cord(s) firmly if necessary, then press the reset button of the CD changer.

Playing CDs



1




Select the CD automatic changer.


If there is one CD in this unit, press the button twice.

Play back starts from the first track of the first disc.

All tracks of all discs are played back.




Note on One-Touch Operation:

When you press CD/CD-CH, the power automatically comes on. You do not have to press  / ATT to turn on the power.




To fast-forward or reverse the track



Press and hold **▶▶** **▲** while playing a CD, to fast-forward the track.

Press and hold **◀◀** **▼** while playing a CD, to reverse the track.


To go to the next track or the previous track



Press **▶▶** **▲** briefly while playing a CD, to go ahead to the beginning of the next track. Each time you press the button consecutively, the beginning of the next track is located and played back.

Press **◀◀** **▼** briefly while playing a CD, to go back to the beginning of the current track. Each time you press the button consecutively, the beginning of the previous track is located and played back.


To go to a particular disc directly



Press the number button corresponding to the disc number to start its playback (while CD changer is playing).


- To select a disc number from 1 – 6:
Press 1 (7) – 6 (12) briefly.
- To select a disc number from 7 – 12:
Press and hold 1 (7) – 6 (12) for more than 1 second.

Ex. When disc number 3 is selected.





Selecting CD playback modes



MO RPT B.SKIP RND

To play back tracks at random (Random Play)

B.SKIP RND



Each time you press B.SKIP RND (Blank Skip/Random) while playing a CD, CD random play mode changes as follows:



Mode	RND indicator	Plays at random
RND1	Lights	All tracks of the current disc, then the tracks of the next disc, and so on.
RND2	Flashes	All tracks of all discs inserted in the magazine.

To play back tracks repeatedly (Repeat Play)

MO RPT



Each time you press MO RPT (Monaural/Repeat) while playing a CD, CD repeat play mode changes as follows:




Mode	RPT indicator	Plays repeatedly
RPT1	Lights	The current track (or specified track).
RPT2	Flashes	All tracks of the current disc (or specified disc).



LISTENING TO AN EXTERNAL DEVICE

You can listen to an external unit connected to the AUX jack on the front panel.

Listening to the auxiliary source



1



Select the auxiliary source.


Note on One-Touch Operation:

When you press **AUX**, the power automatically comes on. You do not have to press **⏻ / I / ATT** to turn on the power.

2

Turn on the connected device and start playing the source.

3



Adjust the volume.


Notes:

- For the external device connection, see the separate manual.
- See also “Selecting the name of the auxiliary source” on page 24 if you want to match the name shown on the display with the name of the connected device.

Handling cassettes

The cassette deck built in this unit requires very little attention, but you will be able to extend the life of the cassette deck if you follow the instructions below.

To clean the heads




- Clean the heads after every 10 hours of use using a wet-type head cleaning tape (available at an audio store).

When the head becomes dirty, you may realize the following symptoms:

- Sound quality is reduced.
- Sound level decreases.
- Sound drops out.
- Do not play dirty or dusty tapes.
- Do not touch the highly-polished head with any metallic or magnetic tools.

To keep the tape clean



- Always store the tapes to their storage cases after use.
- Do not store tapes in the following places:
 - Subject to direct sunlight
 - With high humidity
 - At extremely hot temperatures

CAUTIONS:

- Do not play the tapes with peeling labels; otherwise, they can damage the unit.
- Tighten tapes to remove slack since loose tape may become entangled with the mechanism.
- Do not leave a cassette in the cassette compartment after use, as the tape may become slack.


The function below is also provided to ensure the longer life of the cassette deck.

Ignition key-off Release/Ignition key-on play

- When you turn off the ignition key with a cassette in the compartment, the unit automatically releases the tape from its head.
- When you turn on the ignition key with a cassette in the compartment, playback automatically starts.



Handling CDs

The CD player built in this unit has been designed only to play back the CDs bearing the  mark. Other discs cannot be played back.

How to handle CDs

When removing a CD from its case, press down the center holder of the case and lift the CD out, holding it by the edges.

- Always hold the CD by the edges. Do not touch its recording surface.

When storing a CD into its case, gently insert the CD around the center holder (with the printed surface facing up).

- Make sure to store CDs into the cases after use.

To keep CDs clean

A dirty CD may not play correctly. If a CD does become dirty, wipe it with a soft cloth in a straight line from center to edge.

To play new CDs

New CDs may have some rough spots around the inner and outer edges. If such a CD is used, this unit may reject the CD.

To remove these rough spots, rub the edges with a pencil or ball-point pen, etc.


Moisture condensation

Moisture may condense on the lens inside the CD player in the following cases:

- After starting the heater in the car.
- If it becomes very humid inside the car.

Should this occur, the CD player may malfunction. In this case, eject the CD and leave the unit turned on for a few hours until the moisture evaporates.

Center holder



CAUTIONS:


- Do not insert any CD of unusual shape — like a heart or flower; otherwise, it will malfunction.
- Do not expose CDs to direct sunlight or any heat source or place them in a place subject to high temperature and humidity. Do not leave them in a car.
- Do not use any solvent (for example, conventional record cleaner, spray, thinner, benzene, etc.) to clean CDs.

About mistracking:


Mistracking may result from driving on extremely rough roads. This does not damage the unit and the CD, but will be annoying.

We recommend that you stop CD play while driving on such rough roads.

How to Reset your unit

Press and hold both the SEL and  / ATT buttons at the same time for several seconds. This will reset the built-in microcomputer.

NOTE: Your preset adjustments — such as preset channels or sound adjustments — will also be erased.



TROUBLESHOOTING ?!

What appears to be trouble is not always serious. Check the following points before calling a service center.

Symptoms	Causes	Remedies
• CD cannot be played back.	CD is inserted upside down.	Insert the CD correctly.
• CD sound is sometimes interrupted.	You are driving on rough roads.	Stop CD play while driving on rough roads.
	CD is scratched.	Change the CD.
	Connections are incorrect.	Check the cords and connections.
• "NO DISC" appears on the display.	No CD is in the loading slot. (or in the magazine).	Insert CD.
	CD is inserted incorrectly.	Insert it correctly.
• A cassette tape cannot be inserted.	You have tried to insert a cassette in the wrong way.	Insert the cassette with the exposed tape facing right.
• Cassette tapes become hot.	This is not a malfunction.	_____
• Tape sound is at very low level and sound quality is degraded.	The tape head is dirty.	Clean it with a head cleaning tape.
• Sound is sometimes interrupted.	Connections are not good.	Check the cords and connections.
• Sound cannot be heard from the speakers.	The volume control is turned to the minimum level.	Adjust it to the optimum level.
	Connections are incorrect.	Check the cords and connections.
• SSM automatic preset does not work.	Signals are too weak.	Store stations manually.
• Static noise while listening to the radio.	The antenna is not connected firmly.	Connect the antenna firmly.
• "NO MAG" appears on the display.	No magazine is in the CD changer.	Insert the magazine.

CONTINUED TO THE NEXT PAGE



Symptoms	Causes	Remedies
<ul style="list-style-type: none">• “RESET 8” appears on the display.	This unit is not connected to a CD changer correctly.	Connect this unit and the CD changer correctly and press the reset button of the CD changer.
<ul style="list-style-type: none">• “RESET 1-RESET 7” appears on the display.	_____	Press the reset button of the CD changer.
<ul style="list-style-type: none">• CD can neither be played back nor ejected.	The CD player may function incorrectly.	While holding SEL, press CD/CD-CH for more than 2 seconds. Be careful not to drop CD when it is ejected.
<ul style="list-style-type: none">• This unit does not work at all.• The CD changer does not work at all.	The built-in microcomputer may function incorrectly due to noise, etc.	While holding SEL, press ⏪/I / ATT for more than 2 seconds to reset the unit. (The clock setting and preset stations stored in memory are erased.) (See page 32.)

AUDIO AMPLIFIER SECTION

Maximum Power Output:

Front: 40 watts per channel

Rear: 40 watts per channel

Continuous Power Output (RMS):

Front: 16 watts per channel into 4 Ω , 40 to 20,000 Hz at no more than 0.8% total harmonic distortion.

Rear: 16 watts per channel into 4 Ω , 40 to 20,000 Hz at no more than 0.8% total harmonic distortion.

Load Impedance: 4 Ω (4 to 8 Ω allowance)

Tone Control Range:

Bass: ± 10 dB at 100 Hz

Treble: ± 10 dB at 10 kHz

Frequency Response: 40 to 20,000 Hz

Signal-to-Noise Ratio: 70 dB

Line-Out Level/Impedance:

2.0 V/20 k Ω load (full scale)

Output Impedance: 1 k Ω

Input: AUX (3.5 mm dia. stereo mini jack)

TUNER SECTION

Frequency Range:

FM: 87.5 to 107.9 MHz

(with channel interval set to 200 kHz)

87.5 to 108.0 MHz

(with channel interval set to 50 kHz)

AM: 530 to 1,710 kHz

(with channel interval set to 10 kHz)

531 to 1,602 kHz

(with channel interval set to 9 kHz)

[FM Tuner]

Usable Sensitivity: 11.3 dBf (1.0 μ V/75 Ω)

50 dB Quieting Sensitivity:

16.3 dBf (1.8 μ V/75 Ω)

Alternate Channel Selectivity (400 kHz):

65 dB

Frequency Response: 30 to 15,000 Hz

Stereo Separation: 35 dB

Capture Ratio: 1.5 dB

[AM Tuner]

Sensitivity: 20 μ V

Selectivity: 35 dB

CD PLAYER SECTION

Type: Compact disc player

Signal Detection System: Non-contact optical pickup (semiconductor laser)

Number of channels: 2 channels (stereo)

Frequency Response: 5 to 20,000 Hz

Dynamic Range: 96 dB

Signal-to-Noise Ratio: 98 dB

Wow and Flutter: Less than measurable limit

CASSETTE DECK SECTION

Wow and Flutter: 0.11% (WRMS)

Fast-Wind Time: 100 sec. (C-60)

Frequency Response:

Metal/CrO₂ Tape: 30 to 18,000 Hz

Normal Tape: 30 to 16,000 Hz

Signal-to-Noise Ratio (Normal Tape):

Dolby B NR ON: 65 dB

Dolby B NR OFF: 56 dB

Stereo Separation: 40 dB

GENERAL

Power Requirement:

Operating Voltage: DC 14.4 volts (11 to 16 volts allowance)

Grounding System: Negative ground

Allowable Working Temperature:

0°C to +40°C (32°F to 104°F)

Dimensions (W x H x D):

Installation Size: 178 x 100 x 150 mm

(7-1/16" x 3-15/16" x 5-15/16")

Front Panel Size: 170 x 92 x 13 mm

(6-3/4" x 3-5/8" x 9/16")

Mass: 2.4 kg (5.3 lbs) (excluding accessories)

Design and specifications subject to change without notice.

If a kit is necessary for your car, consult your telephone directory for the nearest car audio speciality shop.

**Having TROUBLE with operation?
Please reset your unit**

**Refer to page of How to Reset
Still having trouble??**

USA ONLY

Call 1-800-252-5722

<http://www.jvcservice.com>

We can help you!

JVC

VICTOR COMPANY OF JAPAN, LIMITED



EN, SP, FR



1298MNMMDWJES

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>