




RC-EZ35S





Enter below the Model No. and Serial No. which are located either on the rear, bottom or side of the cabinet. Retain this Model No Serial No.

> 601-EZ3500-010 LVT1527-001C [J/C]

Thank you for purchasing this JVC product. Please read these instructions carefully before starting operation to be sure to obtain optimum performance and a longer service life from the unit.

SAFETY PRECAUTIONS





The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

For U.S.A.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Changes or modification not approved by JVC could void the user's authority to operate this equipment

For Canada:

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

Caution — ()/| STANDBY/ON switch!

Disconnect the mains plug to shut the power off completely. The 6/1 STANDBY/ON switch in any position does not disconnect the mains line. The power can be remote controlled.

- To reduce the risk of electrical shocks, fire, etc.:
- 1. Do not remove screws, covers or cabinet. 2. Do not expose this appliance to rain or moisture.

© 2005 Victor Company of Japan, Limited


- 3. To disconnect power from the mains, pull out the mains plug.
- When installing the product, ensure that the plug is easily accessible.

IMPORTANT FOR LASER PRODUCTS

- 1. CLASS 1 LASER PRODUCT
- 2. CAUTION: Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to
- 3. CAUTION: Do not open the top cover. There are no user serviceable parts inside the Unit; leave all servicing to qualified service personnel.

FIRST THINGS

This portable system operates on battery or AC power.




INSERTING BATTERIES

- 1 Open the battery compartment cover.
- Pull the battery compartment cover toward you while pressing the sections marked by the arrows.
- 2 Insert eight R20 (SUM-1)/D (13D)-size batteries. (not supplied) Be sure to insert the batteries with the (+) and (-) terminals positioned correctly.



3 Replace the battery compartment cover.

Inserting Batteries into the Remote Control Unit: Match the polarity (+ and -) of the batteries. R03 (UM-4)/AAA (24F)×2 (not supplied)



Note: The battery power will be switched off when you plug the power cord into the AC IN \sim jack on the unit.

- To avoid battery leakage or explosion, handle batteries properly.
- If you are not going to use your system for a month or more, remove the batteries from the battery
- Dispose of batteries in the proper manner, according to federal, state, and local regulations.
- Do not mix with different battery types or with new and old ones, or do not attempt to charge a battery not intended to be recharged
- Discard leaky batteries immediately. Leaking batteries can cause skin burns or other personal injury.

SUPPRLYING AC POWER

Plug the power cord into the AC IN \sim jack on the back of the unit, and into an AC power outlet. Note: To switch off the system completely, unplug the power cord.

CAUTIONS:

- 1. ONLY USE JVC POWER CORD PROVIDED WITH THIS UNIT TO AVOID MALFUNCTION OR DAMAGE TO THE UNIT. REMOVE BATTERIES WHEN USING THE POWER CORD.
- 2. BE SURE TO UNPLUG THE POWER CORD FROM THE OUTLET WHEN GOING OUT OR WHEN THE UNIT IS NOT IN USE FOR AN EXTENDED PERIOD OF TIME.


USING HEADPHONES

Connect commercially available headphones to the PHONES jack on the rear of the main unit. While the headphones are connected, the speakers do not produce any sound. Before connecting the headphones, make sure to turn down the sound volume.

The AM antenna is built in, so adjusting the position of the unit may help AM reception. The FM telescopic antenna on the back of the unit can be extended and rotated for better FM reception.

NAMES OF PARTS AND CONTROLS

Top and front sides: Main unit



10 11 12 13 14 15

1 VOLUME UP/DOWN buttons

2 STANDBY/ON **b/**I button

3 HBS button

4 Tape operation buttons PAUSE II button STOP/EJECT ■/▲ button

FF ◀◀ button REW ▶► button PLAY **⋖** button

REC • button 5 Disc door

6 PRESET EQ button 7 PROGRAM/CLOCK SET button

Names of buttons: Remote control unit 8 PRESET UP/REPEAT button 9 FM MODE button 10 RANDOM button


DISPLAY button FOLDER - button FOLDER + button

11 Display window 12 Cassette deck

13 REMOTE SENSOR 14 I◀◀ button ▶/II button

button **▶** button

15 TAPE button 16 TUNER button



1 STANDBY/ON ()/| button

2 TAPE button CD/►/II button TUNER button

3 I◀◀ button ■ button ▶►I button

4 FOLDER ▲/▼ buttons

5 Number buttons 6 MUTING button

7 DISPLAY button 8 RANDOM/PRESET - button REPEAT/PRESET + button PROGRAM/CLOCK button

9 EQ button

10 VOL ▲/▼ buttons

GENERAL CONTROLS

STANDBY/ON (1)/I - Press to turn on/off the unit.

The display window lights up when the unit is turned on. (Note, however, that the display window does not light even when the unit is turned on if the unit is operated on batteries.)


SETTING THE CLOCK

Before operating the unit any further, first set the clock built in this unit.


The clock uses 12-hour indication. "AM 12:00" indicates midnight, and "PM 12:00" indicates noon.

1 Press STANDBY/ON (¹)/| to turn off the unit, if it is turned on. The clock flashes on the display window

2 Press and hold PROGRAM/CLOCK SET for more than 2 seconds. The hour digits start flashing.



3 Press I or ▶ to adjust the hour, then press PROGRAM/CLOCK SET. The minute digits start flashing.



4 Press ← or ► to adjust the minutes, then press PROGRAM/CLOCK SET.

- If there is a power failure, the clock loses the setting and is reset to "AM 12:00." The clock indication will keep flashing until you set the clock again.
- · You can also set the clock when the unit is in STANDBY mode. In this case, follow the procedures from step 2.

ADJUSTING THE SOUND

Press VOLUME UP/DOWN (or VOL ▲ or ▼ on the remote control unit) to increase or decrease the volume to desired level. The volume level can be adjusted in 41 steps from "MIN" to "MAX".

 Turning off the sound temporarily During playback, press MUTING on the remote control unit to turn the sound off. "MUTING" appears in the display window. Press it again to restore the sound.

 Reinforcing the bass sound Press HBS so that the HBS indicator appears in the display window. You can enjoy powerful bass sound with the Hyper-Bass Sound effect.

· Selecting the sound mode

You can select one of the 5 preset sound modes. Press PRESET EQ repeatedly until the indicator for the sound mode you want appears in the display

ROCK: Powerful sound emphasizing treble and bass. JAZZ: Accented lower frequencies for jazz-type music.

POP: More presence in the vocals and midrange.

CLASSIC: Enriched sound with fine treble and ample bass. No indication: Equalizer effect is canceled.

USING THE RADIO

TUNING IN RADIO STATIONS 1 Press TUNER to enter the tuner mode

- 2 Press TUNER to select the band, FM or AM.
- 3 Press and hold I◄◄ or ▶▶I for more than 1 second.
- The unit starts searching and stops when a station of sufficient signal strength is tuned in.

If you press I◄◄ or ▶►I briefly and repeatedly, the frequency changes step by step.

Changing the FM reception mode

When an FM stereo broadcast is hard to receive or noisy, press FM MODE so that the STEREO indicator disappears from the display window.

To restore the stereo effect, press FM MODE again so that the STEREO indicator appears in the display

PRESETTING STATIONS

You can preset 24 FM and 16 AM stations.

1 Press TUNER to select the band, FM or AM.

2 Press I or ▶ to tune in the station you want to preset. 3 Press PROGRAM/CLOCK SET.

"--- " flashes in the display window

4 Press PRESET UP/REPEAT to select the preset number.

You can use the number buttons on the remote control unit to select the preset number directly. Example: To select preset number 5, press 5. To select preset number 15, press 1, then 5. To select preset number 20, press 2, then 0.



5 Press PROGRAM/CLOCK SET. The tuned station in step 2 is stored in the preset number selected in step 4.

Storing a new station on a used number erases the previously stored one.

6 Repeat steps 2 to 5 to preset other stations, using different preset numbers. Tuning in a preset station

1 Press TUNER to select the band, FM or AM. 2 Press PRESET UP/REPEAT repeatedly until the desired preset number appears.

To select preset number 5, press 5.

To select preset number 15, press 1, then 5.


To select preset number 20, press 2, then 0.

If you unplug the AC power cord or if a power failure occurs, the preset stations will be erased in a few days. If this happens, preset the stations again.

You can use the number buttons on the remote control unit to select the preset number directly.

USING THE TAPE





PAUSE II - Press to interrupt tape play or record mode. Press a second time to resume tape play or tape record mode

STOP/EJECT ■/▲ - Press to stop the current tape activity, or to open the cassette compartment door when no buttons are active. FF ◄ - In stop mode, press to advance the tape toward the end. (When the tape reaches the end. press

STOP/EJECT ■/▲ to release the depressed button.) **REW** ►► - In stop mode, press to rewind the tape toward the beginning. (When the tape reaches the end,

press STOP/EJECT ■/▲ to release the depressed button.) **PLAY ◄** – Press to play cassettes.

REC • – Press to record from the radio or CD player.

PLAYING A CASSETTE TAPE

1. Press TAPE to enter the tape mode.

2. Press STOP/EJECT ■/▲ to open the cassette compartment door.

3. Load a cassete. Use only a type-I normal tape. 4. Close the door securely.

5. Press PLAY ◀ to begin playing the tape. The cassette tape plays until it reaches the end of the side, then it automatically stops.

Fast-winding a tape Press REW ▶► or FF ◄◄.

When the tape reaches the end, press STOP/EJECT ■/▲ to release REW ▶▶ or FF ◄◄.

Download from Www.Somanuals.com. All Manuals Search And Download.

RECORDING ON CASSETTE TAPES

You can record from the radio or the CD player

- · It should be noted that it may be unlawful to re-record pre-recorded tapes, records, or discs without the consent of the owner of copyright in the sound or video recording, broadcast or
- cable program and in any literary, dramatic, musical, or artistic work embodied therein. · The recording level is automatically set correctly, so it is not affected by the other sound settings. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording
- If recordings you have made have excessive noise or static, the unit may be too close to a TV. Increase
- the distance between the TV and the unit. You can only use type I tape for recording.
- . DO NOT turn off the unit while playing back or recording a tape. The cassette deck or tapes may be
- DO NOT use type II and type IV tapes since the unit is not compatible with such tapes.
- The use of C-120 or longer tape is not recommended, since characteristic deterioration may occur and this tape easily jams in the pinch rollers and the capstans.

To protect your recordings

Cassettes have two small tabs on the back to protect against unexpected erasure or re-recording. To protect your recording, remove these tabs.

To re-record on a protected tape, cover the holes with adhesive tape.



RECORDING FROM THE RADIO

- 1. Insert a cassette tape into the cassette deck and close the door.
- 2. Press TUNER and select a radio station.
- 3. Press REC to begin recording. REC and PLAY ◀ are locked down.
- Press STOP/EJECT ■/▲ to stop recording.

Using the beat-cut function

When recording an AM broadcast, beats may occur. If this happens while recording an AM broadcast, switch the BEAT CUT switch on the rear of the unit to "1" or "2" (MONO).

To temporarily pause the recording, press PAUSE **II** on the cassette deck. Press PAUSE **II** again to resume

SYNCHRONIZED RECORDING FROM A CD

- 1. Insert a cassette tape into the cassette deck and close the door.
- 2. Press ►/II (or CD/►/II on the remote control unit).
- Place a CD you want to record into CD compartment.
- 4. Select the track you want to record by pressing I◄◀ or ▶►I.

- When the tape reaches the end, the CD playback enters in pause. To continue recording: turn over the tape and press REC .
- To continue the CD playback: press ►/II.
- To stop the CD playback: press ■. When the CD playback stops, the cassette tape continues running.
- To stop the cassette tape, press STOP/EJECT ■/▲.

Using the PAUSE **II** button on the cassette deck instead of the STOP/EJECT **I**/**≜** button to momentarily interrupt recording gives you a much clearer sound recording.

ERASING

When recording on a pre-recorded tape, the previous recording is erased and only the new recording is heard next time the tape is played back

Erasing a recording on a tape without making a new recording

- Press TAPE to enter the tape mode.
- 2 . Press REC to start recording.

USING THE CD

THINGS TO KNOW BEFORE PLAYING CDs

Playable CDs:

Only CDs bearing these marks can be used with this system.



This unit has been designed only to play back the following CDs.

- Digital audio CD
- Recordable digital audio CD (CD-R)
- Rewritable digital audio CD (CD-RW)

When playing a CD-R or CD-RW

You can play back finalized CD-R or CD-RW recorded in music CD format or in MP3 format. (If a CD-RW has been recorded in a different format, erase all the data on the CD-RW completely before recording


- You can play back CD-R or CD-RW like an audio CD.
- Some CD-R or CD-RW may not be played back on this unit because of their disc characteristics,
- damage or stain on them, or if the player lens is dirty. · The reflection factor of CD-RW is lower than that of other CDs, possibly causing CD-RW to take longer


time to read. Notes for MP3 files

- The unit can only recognize files with "MP3" or "mp3" as the extensions, which can be in any combination of upper and lower cases. The file name can contain up to 30 characters.
- This unit recognizes maximum number of 511 folders and files on a disc.
- It is recommended that you record your material at a 44.1-kHz sampling rate, using the 128-kbps
- Some MP3 files or discs may not be played back because of their characteristics or recording
- conditions. · MP3 discs require a longer readout time than normal discs because of the complexity of the folder/
- MP3i and MP3 Pro are not available.
- The title, artist name and album name can be displayed as the ID3 TAG V1 and V2 information.

Caution for DualDisc playback

The Non-DVD side of a "DualDisc" does not comply with the "Compact Disc Digital Audio" standard. Therefore, the use of Non-DVD side of a DualDisc on this product may not be recommended.





LOADING A CD

- 1. Press ▶/III (or CD/▶/III on the remote control unit); "READING" appears, then "NO DISC" appears in the display if no CD is loaded.
- 3. Place a CD into the tray with the label facing up.
- 4. Close the CD door. Then the total number of tracks and total playing time appear.
- 6. When loading an MP3 disc, the MP3 indicator lights, and the total number of groups (albums) and total number of tracks appear in the display window.



PLAYING A CD

Press ►/II (or CD/►/II on the remote control unit) to play all the tracks in order starting with track 1. The current track number and elapsed playing time appear in the display

When an MP3 disc is loaded, it may take more than 30 seconds to be read, depending on the amount of information compiled in the disc.

- Press ►/II to temporarily stop the CD. The track number and elapsed playing time flash in the display.
- Press ▶/II again to resume playing the CD.
- Adjust VOLUME to a comfortable level.
- open the CD door and remove the CD. "NO DISC" may appear when the disc is loaded upside down. Reload the disc correctly.

Skipping

- To skip back to the previous track
- During playback, press I◄◄ once to return to the beginning of the current track, press twice to skip back to the beginning of the previous track.
- · To skip to the next track During playback, press ►►I to skip to the beginning of the next track

Selecting a desired track directly

Use the number buttons on the remote control unit.

In case of an audio CD:

Example

To select track 8, press 8. To select track 21, press 2, then 1.

In case of an MP3 disc (during playback):

Press FOLDER + or FOLDER - (or FOLDER ▲ or FOLDER ▼ on the remote control unit) to select

the desired folder To select track 8, press "8".

To select track 21, press "2", then "1".

To select track 115, press "1", "1", then "5".

In case of an MP3 disc (while in stop mode):

To select track 8 in folder 4.

press "4" for folder number, then "8" for track number. To select track 21 in folder 15,

press "1" and "5" for folder number, then "2" and "1" for track number To select track 115 in folder 4.

press "4" for folder number, then "1", "1" and "5" for track number Playback starts from the specified track.

When using the number buttons, press the next button within 3 seconds after pressing the previous button. Otherwise the unit recognizes the previously pressed number and starts playback.

Search – locating a desired position on the disc

Press and hold I◄◄ or ▶►I during playback. Monitor the sound and release the button when the desired position is located.

The sound is not produced when searching an MP3 disc.

Selecting a desired track for MP3 discs

- 1 Press FOLDER + or FOLDER repeatedly in stop mode, until the desired folder number is
- 2 Press | ◄ or ▶ > | to select a desired track from the current folder.
- 3 Press ►/II (or CD/►/II on the remote control unit) to start playback.

During playback, if you press FOLDER + or FOLDER -, playback skips to the first track of the next or previous folder, and the track number is shown in the display window.

Displaying the disc information* (ID3 TAG) (MP3 disc only)

Press DISPLAY on the remote control unit during playback.

Each time you press the button, the display changes in the following order File information

ID3 TAG information

Normal display (display mode is canceled)

* There may be some cases that the text information is not displayed.

REPEAT

The PRESET UP/REPEAT button (or REPEAT/PRESET + button on the remote control unit) repeats one track (REPEAT), all tracks (REPEAT ALL), or all tracks within a folder (FOLDER REPEAT) (for MP3 only). Each time you press the button, the repeat mode changes in the following order: The following chart illustrates how REPEAT works in various modes.

 ${\color{red} \longmapsto} \mathsf{NORMAL} {\color{red} \longrightarrow} \mathsf{REPEAT} {\color{red} \longrightarrow} \mathsf{REPEAT} \; \mathsf{ALL} {\color{red} \longrightarrow} \; (\mathsf{For} \; \mathsf{audio} \; \mathsf{CD})$ NORMAL ---> REPEAT ---> FOLDER REPEAT ---> REPEAT ALL--- (For MP3 disc)

RANDOM

In CD mode, press RANDOM so that "RANDOM" appears in the display.

To quit random play, press RANDOM again.

PROGRAMMING

- 1 Press ►/II to enter CD mode, if the unit is in TUNER or TAPE mode. You can press CD/►/II on the remote control unit to enter CD mode.
- 2 Press PROGRAM/CLOCK SET (or PROGRAM/CLOCK on the remote control unit) in stop mode. The PROGRAM indicator appears in the display window.

P R:0 1

3 Press I or ▶►I to select a desired track to be programmed You can use the number buttons on the remote control unit to select a desired track



- 4 Press PROGRAM/CLOCK SET.
- 5 Repeat steps 3 and 4 to program other tracks.
- 6 Press ►/II.

Press ■

The tracks are played in the order you have programmed.

Stopping programmed playback

Before starting programmed playback, press PROGRAM/CLOCK SET when "PROGRAM" is displayed. Each time you press the button, the programmed tracks are shown in the display window.

1 Press PROGRAM/CLOCK SET repeatedly until "-- -- " appears as a track number.

- 2 Press I◄◄ or ▶► (or the number buttons on the remote control unit) to select a new track number, then press PROGRAM/CLOCK SET.
- 1 Press PROGRAM/CLOCK SET repeatedly until the program number you want to edit appears. 2 Press I◄◄ or ▶►I (or the number buttons on the remote control unit) to select a new track number, then

press PROGRAM/CLOCK SET. Erasing the entire program in the memory

Press PROGRAM/CLOCK SET so that the "PROGRAM" appears, and press ■ while the

Editing the program

The program is also cleared when you open the CD door, turn off the unit or change to other audio

sources.

You cannot program more than 32 tracks.

"FULL" is displayed.

For MP3 disc:

- 1 Press PROGRAM/CLOCK SET in stop mode. The PROGRAM indicator appears in the display window.
- 2 Press FOLDER + or FOLDER to select a desired folder.
- The first track number in the selected folder is shown. 3 Press I or ▶►I to select a desired track in the folder.
- 4 Press PROGRAM/CLOCK SET.

HANDLING DISCS

5 Repeat steps 2 to 4 to program other tracks. 6 Press ►/II

The tracks are played in the order you have programmed.

CARE AND MAINTENANCE

CLEANING THE EXTERIOR

· Disconnect the system from AC power before cleaning the exterior of the unit with a soft dry cloth.

· Remove the disc from its case by holding it at the edge while pressing the center

· Be careful not to scratch the surface of the disc when placing it back in its case.

- . Do not touch the shiny surface of the disc, or bend the disc. Put the disc back in its case after use to prevent warping.



To clean the disc

· Wipe the disc with a soft cloth in a straight line from center to edge.

· Avoid exposure to direct sunlight, temperature extremes, and moisture.

• DO NOT use any solvent-such as conventional record cleaner, spray, thinner, or benzine-to clean the disc.

HANDLING CASSETTE TAPES



If the tape is loose, it may get stretched, cut, or caught in the cassette.

· If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels



Be careful not to touch the tape surface.



· Avoid storing tapes in any of the following places:



- In dusty places
 - In direct sunlight or heat
 - In moist areas - On a TV or speaker

Near a magnet

CLEANING THE TAPE HEADS

Clean the heads after every 10 hours of use with a wet-type head cleaning tape (available at electronic and audio shops).




TROUBLESHOOTING TIPS

Problem	Solution
System does not turn on.	 Make sure the power cord is securely plugged into the AC power outlet (or that the batteries are fresh). Unplug the unit for a moment, and then plug it back in again. Check the outlet by plugging in another device.
No sound	Adjust the volume setting. Make sure you have selected the correct function: CD, TAPE, or TUNER and the headphones are disconnected.
Poor radio reception	 Adjust the FM telescopic antenna for better FM reception. Rotate the unit to achieve better AM reception. Try turning off electrical appliances near the unit, such as TV, hair dryers, vacuum cleaners, or fluorrescent lights.
CD does not play.	 Make sure the tray contains a CD. Make sure the CD's label is facing up. Make sure that pause mode is not activated. Make sure the CD function is selected.
CD sound skips.	Clean the CD (as explained in "CARE AND MAINTENANCE"). Check the CD for warping, scratches, or other damage. Check for vibration or shock that may affect the unit; move system if necessary.
Distorted or noisy recordings	Inspect the recording head and clean it if necessary.

Resetting the unit

If "TROUBLESHOOTING" does not eliminate malfunctioning (failure to operate or display properly, etc.), press and hold the RESET button on the rear of the unit for 2 to 3 seconds with something having a sharp



user being deleted.

Number of channels

Antennas

Resetting causes the unit to restore its factory default settings and results in all the settings made by the

SPECIFICATIONS

Compact disc player section

: Compact disc player : Non-contact optical pick-up (semicondicator lazer) Signal detection

: 2 channels

Radio section Frequency ranges : FM 87.5 MHz - 108.0 MHz

Cassette deck section

Track : 4-track 2-channel stereo Motor Electronic governor DC motor for capstan

: AM 520 kHz - 1 710 kHz

Telescopic antenna for FM

Ferrite core antenna for AM

Hard permalloy head for recording/playback, magnetic head for erase Heads Approx. 120 sec. (C-60 cassette)

Fast wind time

Power consumption

<u>General</u>

10 cm \times 2 (4 Ω , 3 W) Speaker 2 W per channel, min. RMS, driven into 4 Ω at 1 kHz with no more Power output

than 10 % total harmonic distortion PHONES × 1 (Ø 3.5 mm, stereo) Output terminals AC 120 V √, 60 Hz Power supply DC 12 V ("R20/D (13F)" cells × 8)

1.5 W (at standby) **Dimentions** 435 mm (W) × 156 mm (H) × 241 mm (D)

 $(17^{3}/_{16} \text{ in} \times 6^{3}/_{16} \text{ in} \times 9^{1}/_{12} \text{ in})$ Approx. 2.8 kg (6.2 lbs) (without batteries) Accessories provided AC power cord × 1

Remote control unit × 1

: 17 W (at operation)

Design and specifications are subject to change without notice.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com