


Use & Care Guide



12-Cup Glass Carafe Coffeemaker

Model No.
100.80006 - Black
100.81006 - White
100.82006 - Red



CAUTION: Read, understand and follow all Important Safeguards and Operating Instructions in this Manual before using this product.



Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.
www.kenmore.com

WARRANTY

KENMORE FULL WARRANTY

If this product fails due to a defect in material or workmanship within two years from the date of purchase, return it to any Sears store or other Kenmore outlet in the United States for free replacement.

This warranty does not include expendable parts, such as filters or blades, which can wear out from normal use within the warranty period.

This warranty applies for only 90 days if this product is ever used for other than private household purposes.

This warranty applies only while this product is used in the United States.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears, Roebuck and Co., Hoffman Estates, IL 60179

IMPORTANT SAFEGUARDS


When using electrical appliances, basic safety precautions should always be followed, including the following:

1. **READ** all instructions.
2. **DO NOT** touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock and injury to persons, **DO NOT** immerse cord, plug, or the coffeemaker in water or other liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. **ALWAYS UNPLUG** coffeemaker from power outlet before cleaning, and when storing. Allow to cool before putting on or taking off parts, cleaning or storing.
6. **DO NOT** operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injury to persons.
8. **DO NOT** use outdoors.
9. **NEVER** let the cord hang over the edge of table or counter or touch hot surfaces.
10. **DO NOT** place coffeemaker on or near a hot gas or electric burner or in a heated oven.
11. **DO NOT** use this coffeemaker for anything other than its intended use.

IMPORTANT SAFEGUARDS

12. The carafe is designed for use only with this coffeemaker.
13. Scalding may occur if the lid is removed during the brewing cycles. **ALWAYS** keep the lid on the carafe when in use.
14. To protect against electrical shock, this appliance is equipped with a cord having a 3-prong grounding-type plug for insertion into a proper grounding-type receptacle. **DO NOT** alter the plug for use in a 2-prong receptacle. If the plug will not fit into a receptacle, have the proper receptacle installed by a qualified electrician.
15. **SAVE THESE INSTRUCTIONS!**

PARTS AND FEATURES




PREPARING TO USE YOUR COFFEEMAKER

Before the first use of the coffeemaker wash the brew basket, the permanent gold-tone filter, the carafe and carafe lid in either the top rack of your dishwasher, or by hand in warm, sudsy water.

The exterior of the coffeemaker, the control panel area and the warming plate should only be cleaned with a soft damp cloth.

NOTE: NEVER clean the warming plate unless it is completely cool.

To clean the inside of the reservoir cover, open the one-piece cover, allowing it to rest in the open position. Pull the water spreader hose out from under the guide on the inside of the lid (See Fig. 2), wipe surfaces with a damp cloth, replace water spreader hose under guide, and close cover.



NOTE: DO NOT use abrasive cleansers or scouring pads when cleaning your coffeemaker. NEVER immerse the coffeemaker in water or any liquid.




After all parts are washed for the first time, pour cold water up to the 12 cup level mark in the water reservoir. Brew it through the coffeemaker as instructed in BREWING, but do not add coffee grounds to the paper filter. When done, turn off the coffeemaker and discard the water from the carafe.

OPERATING YOUR COFFEEMAKER

The easy-to-use programmable digital controls let you know when the coffee is ready, and even keeps track of the freshness of each brewed carafe. It's never been easier to brew the perfect cup of coffee.

BREWING COFFEE

- 1 Press the Open button on the control panel and lift the one-piece cover (See Fig. 3)
- 2 Use the carafe to fill the water reservoir of the coffeemaker to the desired level with cold water. There is a gauge marked from 2 to 12 cups (300ml to 1800ml) on both the coffeemaker's water reservoir and on the sides of the carafe (see Fig. 4). These marks show the amount of cold water needed for each cup of coffee. The amount of brewed coffee will differ slightly due to the coffee grinds absorbing some water.
- 3 Place either the permanent gold-tone filter or a size 1 X 4 paper filter into the brew basket (see Fig. 5).
- 4 Add ground coffee. The amount of coffee you use is a matter of personal taste (we recommend one heaping tablespoon for every two cups). **Experiment** . . . try different amounts of ground coffee per cup until you brew your perfect cup of coffee. You can also try using the paper filter along with the gold-tone filter.
- 5 Close the cover. Place carafe on the warming plate and plug in the appliance. The display window illuminates green and the coffeemaker beeps for about 3 seconds to let you know the clock is not set. The clock does not have to be set to brew coffee. To set the clock time, see **SETTING THE CLOCK, TIMER AND AUTO-BREWING**.



OPERATING YOUR COFFEEMAKER cont.

BREWING COFFEE cont.

- 6 Turn on the coffeemaker by pushing in the BREW ON/OFF button. The ON/OFF button will illuminate green and the word Brew will show up in the control panel display showing that the coffeemaker is brewing.

In a few seconds, hot water flows into the filter. When the water has stopped flowing, the coffeemaker automatically switches to the warming mode. For delayed brewing, see SETTING THE CLOCK, TIMER AND AUTO-BREWING.

- 7 When you have poured out all the coffee in the carafe, press the BREW ON/OFF button to turn off the appliance, and remove the carafe from the warming plate.

NOTE: If the coffeemaker is not turned off, it will automatically shut itself off after two hours.

PAUSE AND POUR FEATURE

The pause and pour feature enables you to remove the carafe from the Coffeemaker and pour a cup of coffee before brewing is finished. When the carafe is removed, a special valve stops the flow of coffee from the brew basket to the carafe. Brewing does not stop if the carafe is not replaced under the brew basket after 20 seconds, water and coffee will overflow from the brew basket.

OPERATING THE CONTROL PANEL

SETTING THE CLOCK, TIMER AND AUTO-BREWING

USE THE Set Clock Button TO SET THE CLOCK :

1. Press Set Clock button and the button's indicator light will flash.
2. Set the time of day by pressing the Hour and Minute buttons. Be sure to set the time with the correct AM and PM designation.
3. You can make the hours and minutes move more quickly in the clock display by holding the buttons down.
4. If you press the Set Clock button and don't do anything for 5 seconds, the button's light flashes 5 times then turns off. To resume, press the Set Clock button again. The clock starts a few seconds after you finish setting it.

SET THE Set Auto Button TO PROGRAM IN A BREW TIME:

1. First set the clock. See directions above.
2. Press the Set Auto button and the button's indicator light will flash.
3. Set the time you wish the coffeemaker to begin brewing by pressing the Hour and Minute buttons. Be sure to set the correct designation of AM or PM.
4. You can make the hours and minutes move more quickly in the clock display by holding the buttons down.

OPERATING THE CONTROL PANEL cont.

USE THE Auto On Button TO SET THE AUTOMATIC BREW TIME:

Once you have set the correct time to begin the automatic brewing and the clock has returned to the time of day, push in the Auto On button. On the display panel under the time of day the word Auto will come on, along with the icon of a clock face. These indicate that the automatic timer is now activated.

The Auto Brew can be cancelled at any time by pressing the Auto On button a second time. The Auto On light goes out. To check what time the Auto Brew is set for, push in the Set Auto button and the time will be displayed.

1-4 CUP BUTTON

This special cycle optimizes the flavor when brewing 1 to 4 cups of coffee, but it can also be used to increase the brew strength of any number of cups you are brewing.

Press 1-4 Cup button once and the green light illuminates and the stronger brewing option is activated. An icon of a coffee carafe and 1-4 Cup will show on the panel display under the time (See Fig. 6). Now press the ON/OFF button to start the brewing process.

NOTE: The 1-4 Cup cycle button must be pushed **before** the ON/OFF button is pressed. If not, the 1-4 Cup cycle will not be activated.



TIME SINCE BREW IN PANEL DISPLAY

Time Since Brew is an indicator of the freshness of your carafe of coffee is designed into your coffeemaker. After you have brewed a pot of coffee, the coffeemaker keeps track of its freshness.

For the first 15 minutes after you brew, there are no Freshness Bars. After 15 minutes and up to 30 minutes, one Bar appears under the indication Time Since Brew under the number 15. At this time a long beep will sound to notify you of the change of freshness. Once the carafe has been sitting for 30 to 45 minutes, a Bar also appears under the number 30. Another long beep sounds (Fig. 7).

After 45 to 60 minutes a Bar also appears under the number 45 along with a beep, and after 60 minutes and longer a bar appears under the number 60 with another long beep. The coffeemaker will shut itself after 2 hours. At this time another long beep will sound. A long beep also sounds when the coffeemaker is turned OFF.

Fig. 6



CARE AND CLEANING

ALWAYS UNPLUG the coffeemaker from the electric outlet before cleaning. The exterior of the coffeemaker, the control panel area and the warming plate should only be cleaned with a soft damp cloth.



WARNING: NEVER immerse the coffeemaker in water or any liquid.



WARNING: DO NOT clean the warming plate unless it is completely cool. DO NOT use abrasive cleansers or scouring pads.

To clean the inside of the reservoir cover, open the one-piece cover, allowing it to rest in the open position. Pull the water spreader hose out from under the guide on the inside of the lid (See Fig. 2), wipe surfaces with a damp cloth, replace water spreader hose under guide, and close cover. Do not use abrasive cleansers or scouring pads.

CARAFE CARE

A damaged carafe may result in possible burns from a hot liquid.

To avoid breaking:

1. **DO NOT** allow all liquid to evaporate from the carafe while on the warming plate and never heat the glass carafe when empty.
2. **DISCARD** the carafe if chipped, cracked, or damaged in any manner.
3. **NEVER** use abrasive scouring pads or cleansers; they will scratch and weaken the glass.
4. **DO NOT** place the carafe on or near a gas or electric burner, in a heated oven, or in a microwave oven.
5. Avoid rough handling and sharp blows.
6. **DO NOT** set a hot carafe down on a wet or cold surface.

CLEANING THE COFFEEMAKER AND CHANGING THE CHARCOAL FILTER

After every 70 cycles, or carafes of coffee, a reminder will appear in the control panel display, **change filter and clean** along with three beeps, to tell the user it is time to clean the inside of the coffeemaker of all mineral buildup, and to change the water filter. Mineral deposits left by hard water can clog your coffeemaker. Cleaning is recommended about every 70 uses, when the coffeemaker's reminder lets you know you have reached this point.

CARE AND CLEANING

To Clean:

- 1 Press the Filter Reset button on the control panel to stop the blinking words icon and the beeps (Fig. 8)
- 2 Open the lid of reservoir, and pull out the water filter (Fig. 9).
- 3 Pour white vinegar into water reservoir up to the 6-cup level shown inside reservoir.
- 4 Add cold water up to the 12-cup line
- 5 Put a paper filter in the brew basket, close cover, and place empty carafe on the warming plate.
- 6 Turn ON the coffeemaker and let half of the vinegar water solution brew through and into carafe.
- 7 Turn the coffeemaker OFF at this point and let it soak for at least 15 minutes to soften any deposits.
- 8 Turn the coffeemaker back ON and brew the remaining solution into the carafe. When brew cycle has stopped, turn OFF coffeemaker, empty carafe, and discard soiled paper filter.
- 9 Refill reservoir with cold water and turn ON to run another brew cycle. You may want to repeat again to eliminate any vinegar smell/taste.
- 10 Wash the brew basket and carafe
- 11 Open the Water Filter, pull out the old charcoal, discard and replace with a new one (Fig. 10)
- 12 Place the Water Filter with new charcoal into the reservoir. Coffeemaker is cleaned and ready for use.

Fig. 8




Fig. 9





Fig. 10



To reset the cycle count and remove the reminder in the control panel display, push the "Filter Reset" button

Get it fixed, at your home or ours!

Your Home

For repair – in **your home** – of all major brand appliances, lawn and garden equipment, or heating and cooling systems, **no matter who made it, no matter who sold it!**

For the replacement parts, accessories and owner's manuals that you need to do-it-yourself

For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4-MY-HOME[®] Call anytime, day or night
(1-800-469-4663) (U S A and Canada)
www.sears.com www.sears.ca

For expert home solutions advice: www.managemyhome.com

Our Home

For repair of carry-in products like vacuums, lawn equipment, and electronics, call or go on-line for the nearest **Sears Parts & Repair Service Center**

1-800-488-1222 (U S A) **1-800-469-4663** (Canada)

Call anytime, day or night

www.sears.com www.sears.ca

To purchase a protection agreement on a product serviced by Sears:

1-800-827-6655 (U.S.A.) **1-800-361-6665** (Canada)

Para pedir servicio de reparación a domicilio, y para ordenar piezas:

1-888-SU-HOGAR[®]
(1-888-784-6427)

Au Canada pour service en français:

1-800-LE-FOYER^{MC}
(1-800-533-6937)
www.sears.ca



© Sears Brands, LLC

® Registered Trademark / TM Trademark / SM Service Mark of Sears Brands, LLC

® Marca Registrada / TM Marca de Fábrica / SM Marca de Servicio de Sears Brands, LLC

^{MC} Marque de commerce / ^{MD} Marque déposée de Sears Brands, LLC

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>