



LevelOne

GNS-8000B

4-bay Sata NAS w/2 Gigabit Ethernet

User`s Manual

Ver 1.00-0512

CUSTOMER SERVICE

To obtain service or technical support for your system, please refer to the registration card for detailed contacts.

Trademarks

GNS-8000B and LevelOne® are trademarks of Digital Data Communications Asia Co., Ltd.

Microsoft®, Windows® and Internet Explorer® are registered trademarks of Microsoft Inc. Novell® and NetWare® are registered trademarks of Novell Inc. Apple® and Macintosh® are registered trademarks of Apple Computer Inc. Linux® is a registered trademark of Linus Torvald. All other brand or product names are trademarks of their respective companies or organizations.

LIMITED WARRANTY

In no event shall DDC's liability exceed the price paid for the product from direct, indirect, special, incidental, or consequential software, or its documentation. DDC offers no refunds for its products. DDC makes no warranty or representation, expressed, implied, or statutory, with respect to its products or the contents or use of this documentation and all accompanying software, and specifically disclaims its quality, performance, merchantability, or fitness for any particular purpose. DDC reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity.

CAUTION




Please be aware of the danger causing explosion if battery is replaced incorrectly. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instruction.








CAUTION

1. Back up your system periodically to avoid any potential data loss. LevelOne disclaims any responsibility of all sorts of data loss or recovery.
2. Should you return any components of GNS-8000B Server package for refund or maintenance, make sure they are carefully packed for shipping. Any form of damages due to improper packaging will not be compensated.

Table of Contents

Chapter 1	Overview of GNS-8000B	6
1.1	Introduction	6
1.2	Package Contents	6
1.3	System Overview	7
Chapter 2	Install GNS-8000B	8
2.1	Install Hard Disk	8
2.2	Hard Disk Recommendation List	12
2.3	Connect GNS-8000B to Office Network	13
Chapter 3	Use LCD Panel	15
Chapter 4	Quick Install Wizard	19
Chapter 5	Start to Enjoy the Services of GNS-8000B	26
5.1	File Server	26
5.2	FTP Server	26
5.3	Backup Server	27
Chapter 6	Administer GNS-8000B	28
6.1	Access Administration Page	29
6.2	Server Administration	31
6.3	Quick Configuration 	32
6.4	System Settings 	38
6.4.1	Server Name	38
6.4.2	Date & Time	39
6.4.3	Language Setting	41
6.4.4	View System Settings	41
6.5	Network Settings 	42
6.5.1	TCP/ IP Configuration	42
6.5.2	Microsoft Networking	48
6.5.3	Apple Network	50
6.5.4	Linux (NFS) Service	50
6.5.5	Web File Manager	51
6.5.6	FTP Service	51
6.5.7	View Network Settings	52

6.6	Disk Configuration 	54
6.6.1	Create Disk Volume	54
6.6.2	Delete Disk Volume.....	56
6.6.3	Examine Disk Volume.....	57
6.6.4	Format Disk Volume.....	58
6.6.5	View Disk & Volume Status	58
6.7	User Management 	59
6.7.1	Users.....	59
6.7.2	User Groups.....	61
6.7.3	Quota	66
6.8	Network Share Management 	68
6.8.1	Create	69
6.8.2	Property.....	70
6.8.3	Access Control	70
6.8.4	Delete.....	71
6.9	System Tools 	72
6.9.1	SNMP Settings	72
6.9.2	Alert Notification.....	73
6.9.3	Restart/ Shutdown.....	73
6.9.4	Hardware Settings.....	74
6.9.5	UPS.....	75
6.9.6	System Update.....	77
6.9.7	Change Logo.....	79
6.9.8	Tape Backup.....	80
6.9.9	Remote Replication	83
6.9.10	Backup/ Restore/ Reset Settings.....	86
6.9.11	USB CD/ DVD Backup/ Restore	87
6.10	Statistics & Logs 	91
6.10.1	Active Users.....	91
6.10.2	Event Logs	91
6.10.3	DHCP Logs.....	91
Chapter 7	Access GNS-8000B	92
7.1	By Microsoft Windows	92

7.2	By Apple MAC OS	94
7.3	By Linux OS.....	100
7.4	By Web Browser	100
7.5	By File Transfer Protocol (FTP).....	101
Chapter 8	GNS-8000B Maintenance.....	104
8.1	Restart/ Shut down Server.....	104
8.2	Reset Administrator Password and Network Settings.....	105
8.3	Disk Failure or Malfunction	106
8.4	Power Outage or Abnormal Shutdown.....	106
Appendix A	Web File Manager.....	107
Appendix B	Configuring AD Authentication.....	112
Appendix C	Messages of Hard Disk and Disk Configuration Status.....	122
Appendix D: Virus Scan	124
	Installing Virus Scan Agent.....	124
	Enabling Virus Scan Support.....	128
	Viewing Details of Infected Files	128

Chapter 1 Overview of GNS-8000B

1.1 Introduction

Thank you for choosing LevelOne GNS-8000B, 4-bay Sata NAS Server. This product has the following key features:

- Simple installation, 5 minutes configuration and user-friendly management interface for SMB users.
- High speed SATA HDD, supports hotswap, maximum capacity up to 2.0TB.
- Dual Gigabit ports for load balance, fail over and standalone settings.
- LCD panel for instant display of IP address and important system info; IP settings can be configured directly without access to PC.
- Built-in virus-scanning mechanism. Supports instant online virus scanning to protect data with an existing virus scanning server.
- Supports redundant power supply to increase system reliability.
- Provides various practical backup mechanisms.
 - ✓ Professional remote replication to remote NAS
 - ✓ USB 2.0 interface for CD/DVD data burning
 - ✓ SCSI interface for tape backup
 - ✓ Provides backup software for Windows users, instant and scheduled backup can be performed without IT professional assistance

1.2 Package Contents

Your GNS-8000B package contains:

1. GNS-8000B Sata NAS Server
2. Power cord
3. CD-ROM (user manual, Quick Install Wizard and software inclusive)
4. Ethernet cable x 2
5. Mount kit x 6
6. Flat head screws x 16
7. Round head screws x 35
8. Hard disk lock x 4



1. GNS-8000B



2. Power cord



3. CD-ROM



4. Hard disk lock



5. Ethernet Cable



6. Mount kit




7. Flat head screw




8. Round head screw

1.3 System Overview


Front View



Rear View



Power Rear View



Chapter 2 Install GNS-8000B

2.1 Install Hard Disk

To install hard disks to GNS-8000B, please make sure you have the following items in place.

1 GNS-8000B



2 HDD tray x 4
(included in GNS-8000B)



3 3.5" SATA hard disk (optional)



4 Flat head screw
(included in GNS-8000B)



5 Round head screws
(included in GNS-8000B)



6 Mount kit (included
in GNS-8000B)



7 Hard disk lock



8 Screw driver (not included)

Hard Disk Installation Procedure



It is highly recommended that you install disks of the same brand and same size on GNS-8000B. The server may function improperly if disks of different brands and size are installed. Please refer to Chapter 2.2 for hard disk recommendation list.

1. Push the side locks in the front of GNS-8000B and then pull forwards to open the front panel.



Open front panel


2. Unlock the disk tray with hard disk lock and take out the hard disk tray.




3. Place a hard disk in a hard disk tray.



4. Turn over the disk tray. Make sure the disk holes match the holes at the base of the tray. Fasten the disk with four flat head screws.



5. Insert the hard disk tray to GNS-8000B. Then lock the tray with the hard disk lock. (You can install 4 disks at maximum.)



6. When finished, close the front panel of GNS-8000B. Note that all disks should be inserted in order from left to right (HDD1~HDD4).




Note: You can install 1~4 hard disks depending on the type of disk configuration you select for GNS-8000B. If less than 4 disks are installed and the server is turned on, the system will beep continuously. In such case, please go to Hardware Settings in System Tools (refer to Chapter 6.9.4) and disable the buzzer. You can then continue to use GNS-8000B.

Install Rackmount Kit

Please follow the steps below to install the rackmount kit of GNS-8000B.


1. Attach brackets (**a**) to both sides of GNS-8000B in the front.
2. Lock the brackets (**b**) to GNS-8000B. Then attach and fasten z-shape brackets (**c**).
3. Push GNS-8000B into the rack.
4. Fasten the screws to fix the position of GNS-8000B.



Important Notice: Please back up your disk data periodically to avoid data loss due to improper operation or disk failure of GNS-8000B. LEVELONE is not responsible for any data loss or recovery.

2.2 Hard Disk Recommendation List


The following HDD models are verified by LEVELONE that are compatible with GNS-8000B. It is recommended to use the same brand and same size listed here for GNS-8000B if more than one hard disk is installed. Other HDD brands that are not tested by LEVELONE may or may not work properly with GNS-8000B. For more updated hard disk recommendation list, please visit LEVELONE website at <http://www.Level1.com>

 **LEVELONE disclaims any responsibility for product damage/ malfunction or data loss/ recovery due to misuse or improper installation of hard disks in any occasions for any reasons.**

Brand	Model Name	Interface	Capacity (GB)	Rotational Speed (RPM)	Buffer Size (MB)
Seagate	Barracuda 7200.9 SATA NCQ	SATA II 3.0Gb/s	500	7200	16
	Barracuda 7200.8 SATA NCQ	SATA 1.5Gb/s	400	7200	8
	Barracuda 7200.8 SATA NCQ	SATA 1.5Gb/s	300	7200	8
	Barracuda 7200.8 SATA NCQ	SATA 1.5Gb/s	250	7200	8
	Barracuda 7200.7 SATA NCQ	SATA 1.5Gb/s	160	7200	8
	Barracuda 7200.7 SATA NCQ	SATA 1.5Gb/s	120	7200	8
Maxtor	DiamondMax 10	SATA II 150Mb/s	300	7200	16
	MaXLine Plus II	SATA 150Mb/s	250	7200	8
	DiamondMax 10	SATA II 150Mb/s	200	7200	8
	DiamondMax 10	SATA 150Mb/s	120	7200	8
Hitachi	Deskstar 7K250	SATA 1.5Gb/s	250	7200	8
Western Digital	WD Caviar® SE Serial ATA	SATA 1.5Gb/s	160	7200	8


2.3 Connect GNS-8000B to Office Network

When connecting GNS-8000B to office network: **1.** It is recommended to install GNS-8000B in LAN with DHCP server. **2.** You can use any PC in the same subnet to connect to the server by IE browser. **3.** You may also connect a CD/DVD burner to GNS-8000B for data backup and restore.



To install GNS-8000B in office network, please follow the steps: **a, b, c, d, e** below.

a. Connect Gigabit port LAN 1 or LAN 2[#] to a switch/ hub/ router by a network cable.



d. Connect the power cord and plug in the other end of the cord to power outlet.

c. Connect tape drive to the SCSI connector for tape back up service*.

b. Connect CD/DVD burner*.

e. Turn on the server.

[#] To use fail over or load balance function, please connect both LAN 1 and LAN 2 to switch/ hub/ router. For further details, please refer to Chapter 6.5.1.


* Optional step. You can skip this step if you are not using CD/DVD backup/restore or tape backup service.



Note: To connect GNS-8000B to a PC, please use a network cable to connect the PC to LAN 1 or LAN 2 of GNS-8000B. For further details about accessing GNS-8000B, please refer to Chapter 6.


Chapter 3 Use LCD Panel

When GNS-8000B is turned on, the server name, IP address, date, and time will be shown.




Check System Information


1. Press Down button to view disk information, i.e. number of disks and disk size. Note that the disk size displayed is the total size of all installed disks but may not be the actual disk size you can use. If you configure the disks as RAID 1 disk volume, the actual disk size you can use is smaller than the displayed disk size on the panel.




2. Press Down button again to view system temperature and system fan speed.



3. Press Down button again to view CPU temperature and CPU fan speed.




4. Press Down button again to view model number and version information.




System Setting Function

1. Press Enter button for two seconds to enter configuration page.



2. Press Down button to select an item: NETWORK SETTINGS, POWER DOWN, REBOOT SYSTEM, and EXIT.



Network Settings

Enter NETWORK SETTINGS configuration page and press Down button to select one of the following options.

- DHCP
DHCP will obtain IP address automatically.
- STATIC IP
Press Enter button to select STATIC IP. Then configure the IP address.
 - i. SET STATIC IP
Press Down button to enter 0~255 and press Enter button to set the next number for the IP address.
 - ii. SET NETMASK
Follow the above procedure to set the netmask address.
 - iii. SET GATEWAY
Follow the above procedure to set the gateway address.
 - iv. SELECT STATIC IP
Press Down button to select YES or NO. When YES is selected, you will be asked to restart the system.
- EXIT
To return to the previous menu.


POWER DOWN

Press Down button to select POWER DOWN and press Enter button to confirm shutting down GNS-8000B.



REBOOT SYSTEM

Press Down button to select REBOOT SYSTEM and press Enter button to confirm restarting the system.



Exit Configuration Page (EXIT)

Press Enter button and select EXIT, then press the button again to confirm exiting the configuration page.




Chapter 4 Quick Install Wizard

Quick Install Wizard enables you to search for all available GNS-8000B within the local network, and view the server name, IP address, and workgroup etc. You can also configure the disk name, date and time, etc. via Quick Install Wizard.

To use Quick Install Wizard, run GNS-8000B CD-ROM in your PC and install the program.



Run Quick Install wizard shortcut on the desktop, the following screen will be shown.




Operation

1. Configure GNS-8000B

Select a GNS-8000B displayed on Quick Install Wizard and click **Configure**.

Enter the administrator password.



Upon successful login, the following screen will appear. Enter the configuration values and click OK.

Basic Configuration

System

Name:

Date (mm/dd/yyyy): / /

Time (hh:mm:ss): : :

TCP/IP

Obtain the IP address automatically (DHCP)

Use Fixed IP Address

IP Address: . . .

Subnet Mask: . . .

Gateway: . . .

OK Cancel

Set the name, date and time for GNS-8000B. The length cannot exceed 14 characters.

The system will obtain IP address automatically.



To use fixed IP address for connection, enter the IP address, subnet mask and gateway for the server.

For further configuration of the system, please login the administration page of GNS-8000B via web browser.


 **Note:** You may have to restart GNS-8000B after changing the network configuration.

2. View GNS-8000B details

Select a GNS-8000B available on Quick Install Wizard and click **Details**. The following screen will be shown:




3. Search for all available GNS-8000B again.
To refresh the search results, click **Refresh** to display all available servers within the network.




4. Help

If you have any enquiries about Quick Install Wizard when using the program, you can click the **Help** button to view the help text.



5. Enter the homepage of GNS-8000B

Double click on GNS-8000B to enter the administration page.



Chapter 5 Start to Enjoy the Services of GNS-8000B

GNS-8000B provides the following powerful services and applications

5.1 File Server

You can make use of the following means to access and share the folders of GNS-8000B easily:

- a. By Quick Install Wizard: By the Map Drive function of Quick Install Wizard, you can configure the share folders on GNS-8000B as a drive of your PC quickly. For further information, please refer to Chapter 4.
- b. By samba: GNS-8000B supports Microsoft, MAC and Linux (NFS) OS for data sharing to enable you to share data across different platforms, please refer to Chapter 7.1-7.3.
- c. By Web File Manager: GNS-8000B provides a simple-to-use web administration interface for you to access share folders, upload and download files from GNS-8000B, please refer to Chapter Appendix A.

5.2 FTP Server

GNS-8000B supports FTP file transfer. You can use the following methods to access share files by FTP:

- a. By IE browser or
- b. By Web File Manager

For further information, please refer to Chapter 7.5.

5.3 Backup Server

GNS-8000B provides versatile backup mechanisms to help you back up or restore disk data completely to enhance more efficient and secure system management. The backup/ restore applications are listed below:

a. Remote Replication

Remote replication is a built-in backup feature of GNS-8000B. You can set up instant or scheduled backup to replicate the data of GNS-8000B to another LEVELONE NAS server. Please refer to Chapter 6.9.9.

b. USB CD/DVD Restore/ Backup

You can connect USB CD/DVD burner to the high speed USB 2.0 transfer interface of GNS-8000B and enjoy data backup and restore functions to and fro GNS-8000B and CD/DVD. Please refer to Chapter 6.9.11.

c. Tape Backup

You can use tape backup function of GNS-8000B to perform backup and restore jobs by a tape drive for secure data protection. Please refer to Chapter 6.9.8.

Chapter 6 Administer GNS-8000B

When you have installed GNS-8000B and connected it to the network or PC, you can manage the server via web browser. It is recommended to use Microsoft Internet Explorer 6.0 or above to access GNS-8000B.

GNS-8000B Network Configuration for the First Time of Use

By factory default, GNS-8000B will search the network via DHCP (Dynamic Host Configuration Protocol) to detect IP address settings automatically. If your network does not support DHCP protocol, GNS-8000B will use the default settings as below:

IP Address: 192.168.0.1
Subnet Mask: 255.255.255.0

When GNS-8000B boots up, the LCD panel will display current IP address settings. If your network does not support DHCP protocol, you must configure your GNS-8000B to proper LAN settings before using it for the first time. If you are not sure about the LAN settings, please contact your network administrator.


You can change the network settings of GNS-8000B by the following ways:

1. Use the LCD panel to change the network settings. For more information, please refer to Chapter 3. OR
2. Use Quick Install Wizard in the CD-ROM to change the network settings. For more information, please refer to Chapter 4.


6.1 Access Administration Page

You can access GNS-8000B administration page by the following means:

3. Launch the web browser. Enter the IP address of GNS-8000B to access the administration page. You can check the IP address of GNS-8000B on the LCD panel (see Chapter 3). OR
4. Install and Quick Installation Wizard (see Chapter 4). Search for GNS-8000B in the network and double click the server name on the list.



5. When the administration page is shown, click **Administration**.



6. Enter the user name and password to login.

Default user name: **administrator**


Password: **admin**

The first time you login GNS-8000B, Quick Configuration page will be shown. Please refer to 6.3 Quick Configuration for more details.


To connect GNS-8000B by MAC, open a web browser in MAC and enter the IP address of GNS-8000B. Login the server and continue the software configuration. Please use the built-in browser in MAC-Safari for browsing.


6.2 Server Administration


There are eight main sections in server administration:





6.3 Quick Configuration

Please follow the step-by-step guide in Quick Configuration to complete the settings of GNS-8000B. If you have any questions during web administration, please click the help button  on the top right hand corner of the page. Other buttons are described as below:

: Return to previous page

: Return to home page

: Logout system



level®
one

GNS-8000B Configuration

LEVELONE
ONE WORLD, ONE BRAND, ONE LEVEL

Quick Configuration

- Welcome
- Step 1
- Step 2
- Step 3
- Step 4
- Step 5
- Step 6
- Step 7
- Step 8
- Step 9
- Step 10
- Finish


– Welcome

Welcome to the quick configuration wizard. This wizard will guide you through the following steps to configure this system quickly:

1. Enter the name for this server.
2. Change the administrator password.
3. Enter the date, time and time zone for this server.
4. Select the language that this server will use for file names.
5. Enter the IP address, subnet mask and default gateway for this server.
6. Select the network file services that you want to provide on this server.
7. Configure disk volume on this server.
8. Configure the method of user authentication.
9. Manage users and user groups for this server.
10. Manage network shares on this server.

Next

Step 1. Enter the server name.



– 1. Enter the name for this server.

Server Name :

Back Next

Step 2. Change the administrator password or select to use the original password.

- 2. Change the administrator password.

Password :

Verify Password :

Use the original password

Note: If you select "Use the original password", the administrator password will not be changed.

Step 3. Enter the date, time and select the time zone for the server.

- 3. Enter the date, time and time zone for this server.

Time Zone :

Current date and time:

Change the server's time and date as below:

Date: , , (mm dd, yyyy)

Time: : : (hh:mm:ss)

Step 4. Select the language the server uses to display files and directories. The default setting is **English**.

- 4. Select the language that this server will use for file names.

Language:

- Chinese-Simplified
- Chinese-Traditional
- Cyrillic
- Greek
- Icelandic
- Japanese
- Korean
- Slavic/Latin 2
- English**
- Western Europe/Latin 1

Step 5. Enter the IP address, subnet mask and default gateway for the server.
Select network interface configuration: fail over or load balance.

– 5. Enter the IP address, subnet mask and default gateway for this server.

Obtain TCP/IP settings automatically via DHCP

Use the following settings

IP Address: . . .

Subnet Mask: . . .

Default Gateway: . . .

Configuration of Network Interfaces Fail Over Load Balance

Note: If you don't need a default gateway for this server, please enter "0.0.0.0".

Step 6. Select the network file services to provide on the server.

– 6. Select the network file services you want to provide on this server.

Enable File Service for Microsoft Networking

Enable AppleTalk File Service for Apple Networking

Enable Linux (NFS) Service

Enable Web File Manager


Enable FTP Service

Step 7. Configure disk volume on the server.


- 7. Configure disk volume on this server.

You can click on the disk volume you want to configure on the **New Disk Volume Configuration** list. The **Current Disk Volume Configuration** list shows the current disk volume configuration of this server.


New Disk Volume Configuration




Single Disk Volume
Create single disk volume(s).




RAID 1 Mirroring Disk Volume
Create mirroring disk volume (s).



RAID 0 Striping Disk Volume
Create one striping disk volume.



Linear Disk Volume
Create one linear disk volume.



RAID 5 Disk Volume
Create one RAID 5 disk volume.

Current Disk Volume Configuration

Volume	Total Size	Free Size	Status
Striping Disk Volume: Drive 1 2	304685.00 MB	296874.00 MB	Ready

← Back Next →

Step 8. Configure the method of user authentication. Please refer to Chapter 6.5.2 for further information.

- 8. Configure the method of user authentication.

Enable file service for Microsoft networking

Standalone Server
 NT Domain Member
 AD Domain Member

Server Description:

Workgroup:

AD Server Name:

Domain Name:

Domain Username:

Password:

← Back Next →

Step 9. Manage users and user groups of this server.

- 9. Manage users of this server.

To add a user, enter the user information in the following fields, then click Add. To remove an existing user, click on the user name on the left list and click Remove. You can remove multiple users at a time.

Andrew Bella Cynthia Derek administrator	<input type="button" value="← Add"/>	User Name <input type="text"/>
	<input type="button" value="Remove →"/>	Password <input type="text"/>
		Verify Password <input type="text"/>

Note: For increased security, password should be at least 6 characters.

- 9.1 Set user groups of this server.

To add a user group, enter the group name in the box below. Select the user(s) to add to the group from the list on the right, then click Add. To remove a user group, select the group name on the left list, and click Remove. You can remove multiple user groups at a time.

administrators everyone	<input type="button" value="← Add"/>	User Group Name <input type="text"/>
	<input type="button" value="Remove →"/>	Andrew Bella Cynthia Derek administrator

You can choose one or more users to add into the user group from the above field.

Step 10. Manage network shares on this server.

- 10. Manage network shares on this server.

To add a network share, enter the network share information in the fields on the right below, then click Add. To remove an existing network share, select the network share on the left list, and click Remove.

NAS0E0036PR public	<input type="button" value="Add"/>	Network Share Name <input type="text"/>
	<input type="button" value="Remove"/>	Volume Striping Disk Volume: Drive12
		Comment <input type="text"/>

Step 11. Finish. It may take several to tens of minutes to complete Quick Configuration, depending on your system settings.

- Finish

Congratulations. You have finished all the steps for Quick Configuration.

To start using the server, click Finish. Or you can click Back to make more changes to the settings.


6.4 System Settings

Basic system settings include the server name, date, time, and view system settings.



6.4.1 Server Name

Enter the name of GNS-8000B. The server name can be 14 characters long at maximum, which can contain alphabets, numbers and hyphen (-). The server does not accept names with space, period (.), or names in pure numbers.



6.4.2 Date & Time

Set the date, time, and time zone according to your location. If the settings are incorrect, the following problems may occur:

- ✓ When using a web browser to access or save a file, the display time of the action will be incorrect.
- ✓ The system event log time will be incorrect compared to the actual time when an action occurs.

- Adjust the date, time and time zone of this server

Time Zone: (GMT+08:00) Taipei

Current date and time: 2005 / 8 / 10 PM 05 : 48 : 31

Change date and time manually

Date: January , (mm dd, yyyy)

Time: : : AM (hh:mm:ss)

Configure NTP server or client setting

Use the specified NTP server

IP Address of NTP Server: time.windows.com Test (Status: --)

Time Interval: 60 minute(s)

Enable NTP server

NTP Server #1: Test (Status: --)

NTP Server #2: Test (Status: --)

NTP Server #3: Test (Status: --)

Apply

✓ **NTP Server**

You can enable or use specified NTP (Network Time Protocol) server to update the date and time of the system automatically. To enable NTP server, please enable **Configure NTP server or client setting** and enter the IP address or domain name of the NTP server, e.g. time.nist.gov, time.windows.com in **Use the specified NTP server** field. Then enter the time interval for adjusting the time (minimum value is 1 minute and maximum value is 99 days).

Configure NTP server or client setting

Use the specified NTP server

IP Address of NTP Server (Status: --)

Time Interval

To enable multiple NTP servers, you can select **Enable NTP server** and enter the IP address or domain name of the servers. You can enter 3 NTP servers at maximum. If the system fails to connect to the first NTP server, it will try to connect the second one automatically, so on so forth.

You can click **Test** to try to connect to the NTP server. If there is no specified IP address for the NTP server, the system will refer to internal clock for date and time settings.

Enable NTP server

NTP Server #1 (Status: --)

NTP Server #2 (Status: --)


NTP Server #3 (Status: --)



Note: The first time you enable NTP server, it may take several minutes for time synchronization before the time is correctly adjusted.

6.4.3 Language Setting

Select the language GNS-8000B uses to display files and directories.



Note: All files and directories on GNS-8000B will be created using Unicode encoding. If your FTP clients or PC does not support Unicode, e.g. Windows 95, 98, ME OS is used, select the language the same as the language of your OS in order to view the files and directories on the server properly.

- Language Setting

Language: English ▼

Chinese-Simplified

Chinese-Traditional

Cyrillic

English

Greek

Icelandic

Japanese

Korean

Slavic/Latin 2

Western Europe/Latin 1

● Apply

6.4.4 View System Settings

You can view all current system settings, e.g. server name, on this page.

- View System Settings

Server Name	
Server Name	NAS1E0041

Date & Time	
Date	October 22, 2005
Time	12:33:4 PM
Time Zone	(GMT) Greenwich Mean Time : Dublin, Edinburgh, Lisbon, London

Language	
Code Page	English (437)


System Information	
Version	1.0.0 Build 1004

➔ OK

6.5 Network Settings



6.5.1 TCP/ IP Configuration



The screenshot shows the 'Network Settings' window with the 'TCP/IP Configuration' tab selected. The 'Configuration of Network Interfaces' section has 'Fail Over' selected. The 'Network Speed' is set to 'auto-negotiation'. The 'Fail Over' sub-tab is active, showing options for 'Obtain IP address settings automatically via DHCP' (selected) and 'Use static IP address'. The static IP fields are filled with 192.168.0.1, 255.255.255.0, and 0.0.0.0. The DHCP server section is disabled, with fields for Start IP Address (192.168.0.100), End IP Address (192.168.0.200), Lease Time (1 Day(s), 0 Hour(s)), and DNS servers.

Network Settings

- TCP/IP Configuration
- Microsoft Networking
- Apple Networking
- Linux (NFS) Service
- Web File Manager
- FTP Service
- View Network Settings

TCP/IP Configuration

Configuration of Network Interfaces Fail Over Load Balance Standalone

Network Speed **auto-negotiation**

Fail Over

Obtain IP address settings automatically via DHCP

Use static IP address

Fixed IP Address 192 . 168 . 0 . 1

Subnet Mask 255 . 255 . 255 . 0

Default Gateway 0 . 0 . 0 . 0

Primary DNS Server 0 . 0 . 0 . 0

Secondary DNS Server 0 . 0 . 0 . 0

Enable DHCP Server

Start IP Address 192 . 168 . 0 . 100

End IP Address 192 . 168 . 0 . 200

Lease Time 1 Day(s) 0 Hour(s)

Primary DNS Server 0 . 0 . 0 . 0

Secondary DNS Server 0 . 0 . 0 . 0

Apply

Configuration of Network Interfaces

✓ Fail Over (Default)

The system supports the configuration of multiple network interfaces, which enables you to perform Fail Over or Load Balance functions. Fail over ensures server availability to the network. If the primary port is disconnected due to a hardware or cable problem, the secondary port will replace its network identity. If the failed port resumes the network connection, it will also resume the role as the primary interface.

Fail Over

Obtain IP address settings automatically via DHCP

Use static IP address

Fixed IP Address 172 . 17 . 28 . 126

Subnet Mask 255 . 255 . 254 . 0

Default Gateway 0 . 0 . 0 . 0

Primary DNS Server 10 . 8 . 2 . 11

Secondary DNS Server 0 . 0 . 0 . 0

Enable DHCP Server

Start IP Address 172 . 17 . 10 . 100

End IP Address 172 . 17 . 10 . 200

Lease Time 1 Day(s) 0 Hour(s)

Primary DNS Server 0 . 0 . 0 . 0

Secondary DNS Server 0 . 0 . 0 . 0

✓ **Load Balance**

In load balance* mode, the transmission load is distributed among aggregated network ports.

Load Balance

Obtain IP address settings automatically via DHCP

Use static IP address

Fixed IP Address 172 . 17 . 28 . 126

Subnet Mask 255 . 255 . 254 . 0

Default Gateway 0 . 0 . 0 . 0

Primary DNS Server 10 . 8 . 2 . 11

Secondary DNS Server 0 . 0 . 0 . 0

Enable DHCP Server

Start IP Address 172 . 17 . 10 . 100

End IP Address 172 . 17 . 10 . 200

Lease Time 1 Day(s) 0 Hour(s)

Primary DNS Server 0 . 0 . 0 . 0

Secondary DNS Server 0 . 0 . 0 . 0

* An intelligent software adaptive agent will repeatedly analyze the traffic flow from the server and distribute the packets based on the destination address. Load balance can only occur on Layer 3 routing protocols (IP or NCP IPX). Multicast/Broadcast and non-routing protocols, such as NetBEUI and Microsoft IPX, are transmitted over the primary port.

✓ **Standalone**

Standalone settings enable each port to have a unique IP, which allows users on different network areas to share one GNS-8000B and maintain their independence from one another in the network. When using this mode, fail over cannot be used and only LAN 1 can be configured as DHCP server.

LAN Configuration

Configuration of Network Interfaces Fail Over Load Balance Standalone

Network Speed **auto-negotiat** ▼

LAN1 LAN2

Obtain IP address settings automatically via DHCP

Use static IP address

Fixed IP Address 192 . 168 . 0 . 1

Subnet Mask 255 . 255 ▼ . 255 ▼ . 0 ▼

Default Gateway 0 . 0 . 0 . 0

Primary DNS Server 0 . 0 . 0 . 0

Secondary DNS Server 0 . 0 . 0 . 0

Enable DHCP Server

Start IP Address 192 . 168 . 0 . 100

End IP Address 192 . 168 . 0 . 200

Lease Time 1 Day(s) 0 Hour(s)

Primary DNS Server 0 . 0 . 0 . 0

Secondary DNS Server 0 . 0 . 0 . 0

LAN1 **LAN2**

Obtain IP address settings automatically via DHCP

Use static IP address


Fixed IP Address 192 . 168 . 0 . 1

Subnet Mask 255 . 255 ▼ . 255 ▼ . 0 ▼

Default Gateway 0 . 0 . 0 . 0

Network Speed

Network speed settings provide an advanced option for configuring network speed. You can select auto-negotiation (default), 10 Mbps, 100 Mbps, or 1000 Mbps. It is recommended to use the default setting that the server will determine network speed automatically.



A screenshot of a 'Network Speed' dropdown menu. The menu is open, showing the following options: 'auto-negotiation' (highlighted in blue), '10', '100', and '1000'. The label 'Network Speed' is visible to the left of the dropdown.

- **Obtain IP address settings automatically via DHCP**


If your network supports DHCP, GNS-8000B will automatically use DHCP protocol to retrieve the IP address and related information.



A screenshot of a radio button option labeled 'Obtain IP address settings automatically via DHCP'. The radio button is selected, indicated by a green dot.

- **Use static IP address**

To use fixed IP address for network connection, enter fixed IP address, subnet mask and default gateway.



A screenshot of the 'Use static IP address' configuration section. It includes a radio button labeled 'Use static IP address' which is selected. Below it are three rows of input fields: 'Fixed IP Address' with values 172, 17, 28, 126; 'Subnet Mask' with values 255, 255, 254, 0; and 'Default Gateway' with values 0, 0, 0, 0.

Primary DNS Server: Enter the IP address of primary DNS server that provides DNS service for GNS-8000B in external network.

Secondary DNS Server: Enter the IP address of secondary DNS server that provides DNS service for GNS-8000B in external network.

Primary DNS Server	<input type="text" value="10"/>	.	<input type="text" value="8"/>	.	<input type="text" value="2"/>	.	<input type="text" value="11"/>
Secondary DNS Server	<input type="text" value="0"/>	.	<input type="text" value="0"/>	.	<input type="text" value="0"/>	.	<input type="text" value="0"/>

You can also configure the following settings:

✓ **Enable DHCP server**

If there is no DHCP server on your network, you can enable this option to provide IP address settings to the clients.

Start IP address

The first IP address to be dynamically allocated for DHCP service.

End IP address

The last IP address to be dynamically allocated for DHCP service.

Lease time

Define the lease time for the dynamic IP address.

Primary DNS server

When the system allocates an IP address to your computer, the primary DNS server address is also specified to it.

Secondary DNS Server

When the system allocates an IP address to your computer, the secondary DNS server address is also specified to it.

<input type="checkbox"/> Enable DHCP Server							
Start IP Address	<input type="text" value="172"/>	.	<input type="text" value="17"/>	.	<input type="text" value="10"/>	.	<input type="text" value="100"/>
End IP Address	<input type="text" value="172"/>	.	<input type="text" value="17"/>	.	<input type="text" value="10"/>	.	<input type="text" value="200"/>
Lease Time	<input type="text" value="1"/>	Day(s)	<input type="text" value="0"/>	Hour(s)			
Primary DNS Server	<input type="text" value="0"/>	.	<input type="text" value="0"/>	.	<input type="text" value="0"/>	.	<input type="text" value="0"/>
Secondary DNS Server	<input type="text" value="0"/>	.	<input type="text" value="0"/>	.	<input type="text" value="0"/>	.	<input type="text" value="0"/>

6.5.2 Microsoft Networking

Microsoft Networking

Enable file service for Microsoft networking

Standalone Server

NT Domain Member

AD Domain Member

Server Description:

Workgroup:

AD Server Name:

Domain Name:

Domain Username:

Password:

Enable WINS server

Use the specified WINS server

WINS server IP address:

Domain Master

Enable file service for Microsoft networking: If you are using Microsoft Windows, enable this service to access the files on network share folders. Assign a workgroup name.

✓ **Standalone Server**

Use local users for user authentication.

✓ **NT Domain Member**

Use Microsoft NT domain for user authentication.

✓ **AD Domain Member**

GNS-8000B supports Windows 2003 AD (Active Directory) to provide quick and direct import of user accounts to the existing AD server available in your network. This function helps you to save time and effort on creating user accounts and passwords and lowers IT maintenance cost by automatic configuration procedure.

- **Server Description:** Describe GNS-8000B for users to identify the server. To use GNS-8000B on the Microsoft Windows OS, you must enable

Microsoft Network Services.

- Workgroup: Specify the workgroup GNS-8000B belongs to. The workgroup is a computer group unit in Microsoft Windows network for network sharing.
- AD Server Name: Enter the name of the AD server when AD domain is selected for authentication.
- Domain Name: Microsoft domain name. Enter the domain name when you select NT domain or AD domain.

✓ **WINS server**

If the local network has a WINS server installed, specify the IP address. GNS-8000B will automatically register its name and IP address with WINS service. If you do not want to enable WINS server support, or you do not have a WINS server on your network, enter **0.0.0.0** in the field for WINS server IP address.

Enable WINS server

Use the specified WINS server

WINS server IP address . . .

✓ **Domain Master**

There is a unique Domain Master Browser for collecting and recording resources and services available for each PC in the network or workgroup of Windows. When a domain master browser (Windows NT/ 200x/ XP PC) exists already in the network, there is no need to configure GNS-8000B as the domain master.

When you find the waiting time for accessing Network Neighborhood too long, it may due to failure of an existing master browser, or there is no master browser available. If the reason is the latter one, you can check the box Domain Master in this section to configure GNS-8000B as the master browser to enhance the speed of accessing information on Network Neighborhood.

Domain Master

6.5.3 Apple Network

To use GNS-8000B on Apple MAC operating system, enable AppleTalk network support.

If your AppleTalk network uses extended networks, and is assigned with multiple zones, assign a zone name to GNS-8000B. If you do not want to assign a network zone, enter an asterisk (*) to use the default setting. **This setting is disabled by default.**



- Apple Networking


Enable AppleTalk file service for Apple networking

Zone

Apply

6.5.4 Linux (NFS) Service

To use GNS-8000B on Linux OS computer or server, enable Linux (NFS) service. GNS-8000B supports NFS version 2.0 and 3.0. **This setting is disabled by default.**




- Linux (NFS) Service

Enable Linux (NFS) Service

Apply

6.5.5 Web File Manager

To access files on GNS-8000B via web browser, enable Web File Manager. If GNS-8000B is connected to the Internet and uses a valid IP address, you can access files on the server by web browser from anywhere. For further details, please refer to Appendix A.




– Web Service

Enable Web File Manager

Apply

6.5.6 FTP Service

Select to enable or disable Unicode Support. The default setting is **No**. As most FTP clients do not support Unicode currently, it is recommended that you disable Unicode support and select a language the same as your OS in “System Settings—Language Setting” page (refer to Chapter 6.4.3) so that the folders and files on FTP can be properly shown.



– FTP Service

Enable FTP Service

Port Number

Maximum Connections

Unicode Support Yes No

Apply

6.5.7 View Network Settings

You can view current network settings and status in this section.

- View Network Settings

Network	Network File Services	Miscellaneous
Connection Type		
Connection Type	DHCP	
IP Address	10.8.10.126	
Subnet Mask	255.255.255.0	
Default Gateway	10.8.10.1	
MAC Address	00:30:02:0E:00:30	
Connection Status	Ready	
Configuration of Network Interfaces	Fail Over	
DHCP Service		
Enabled	No	
Address Range	172.17.10.100 - 172.17.10.200	
Lease Time	1 Day(s) 0 Hour(s)	

- Close

- View Network Settings

Network	Network File Services	Miscellaneous
Microsoft Networking		
Enabled	Yes	
Server Type	Standalone Server	
Workgroup	NAS	
WINS server Enabled	No	
Domain Master Enabled	No	
Apple Networking		
Enabled	No	
Apple Zone Name	*	
Linux (NFS) Service		
Enabled	No	
Web File Manager		
Enabled	Yes	
FTP Service		
Enabled	Yes	
Port Number	21	
Max Connections	30	
Unicode Support	Yes	

- Close


- View Network Settings

Network	Network File Services	Miscellaneous
Printer Service		
Enabled	Yes	
Printer Name	NAS0E0036PR	
Printer Comment	USB port on NAS	

- Close

6.6 Disk Configuration

In the section, you can create, delete, examine and format disk volume, as well as view disk and volume status of GNS-8000B.



6.6.1 Create Disk Volume

GNS-8000B can accommodate four disks at maximum. You can set the disk volume to the following configurations by clicking on the icons on Create Disk Volume page:


a. **Single Disk Volume**

You can create an individual disk volume. In case of disk crash, all data will be lost.



b. **RAID 5 Disk Volume**


Three or more hard disks can be integrated to form RAID 5 disk volume. Data will be distributed and stored among the disks. If a disk fails, you can replace a new disk with the damaged one, and the system will restore the data to the new disk. You can also use three disks for RAID 5 and a fourth disk as a backup disk. If a disk of RAID 5 volume is damaged, the spare disk can replace that damaged disk, which enhances server stability and efficiency.



Note: When configuring RAID 5 disk volume, at least 3 disks are required.


c. **RAID 1 Mirroring Disk Volume**

Mirroring Disk protects your data by automatically backing up the contents of one disk onto the second disk of a mirrored pair. This protects your data if one of the disks fails. However, the storing capacity is equal to a single disk, as the second disk is used to automatically back up the first one.




d. **RAID 0 Striping Disk Volume**

Striping disk combines two or more disks into one larger disk. It offers the fastest disk access but does not have any protection of your data if the striped array fails. The disk capacity equals the number of disks in the array times the size of the smallest disk.



e. **Linear Disk Volume**

You can combine two or more disks into one larger disk. Files will be saved on physical disks sequentially but does not have a disk failure file protection function. The overall capacity of linear disk is the sum of all disks.



6.6.2 Delete Disk Volume

To delete a disk volume, select the disk volume to remove and click OK.

- Delete Disk Volume

Please select the disk volume you want to remove and click OK.
Warning: All data and network shares on the disk volume you select will be deleted. The connection of all active users on this volume will be terminated.
Note: To view all shares and active users on the volume you have selected, click Show Shares.

Volume	Total Size	Free Size	Status
<input checked="" type="radio"/> RAID 5 Disk Volume: Drive 1 2 3 4	233632.50 MB	224784.51 MB	Ready

OK Cancel Show Shares

6.6.3 Examine Disk Volume

To examine a disk volume, select the disk volume to examine and click OK. You can check the **Fix errors** box and the server will fix errors automatically during disk checking.

– Examine Disk Volume

Please select the disk volume you want to examine and click OK. You can check the Fix errors option to resolve errors automatically.
Warning: All active users on this disk volume will be terminated.
Note: To view all shares and active users on the volume you have selected, click Show Shares.

Volume	Total Size	Free Size	Status
<input checked="" type="radio"/> RAID 5 Disk Volume: Drive 1 2 3 4	233632.50 MB	224784.51 MB	Ready

Fix errors

✓ Disk Volume Operation Report

After click OK on Examine Disk Volume page, a page like below will display to show the current status and information of disk volume operation.

– Disk Volume Operation Report

Operation Type	Format Disk Volume
Source Disk Volume	Mirroring Disk Volume: Drive 1 2
Target Disk Volume	--
Snapshot Settings	Disabled
Status	Formatting...
Result	--
Comment	This operation may take several minutes to hours, depending on the disk capacity.


Note: This page will automatically refresh every 5 seconds. Click Close to exit this page. You can choose to view the operation result later on the View Disk & Volume Status page.




6.6.4 Format Disk Volume

To format disk volume, select the disk volume to format and click OK.

– Format Disk Volume

Please select the disk volume you want to format and click OK.
Warning: All data and network shares on the disk volume you select will be deleted. The connection of all active users on this volume will be terminated.
Note: To view all shares and active users on the volume you have selected, click Show Shares.

Volume	Total Size	Free Size	Status
 RAID 5 Disk Volume: Drive 1 2 3 4	233632.50 MB	224784.51 MB	Ready

6.6.5 View Disk & Volume Status

You can view details of physical disks and logical volumes in the section.

– Physical Disks

Disk	Model	Capacity	Status
Drive 1	Maxtor 6Y120L0	117246.94MB	Ready
Drive 2	Maxtor 6Y120L0	117246.94MB	Ready
Drive 3	Maxtor 6Y120L0	117246.94MB	Ready
Drive 4	Maxtor 6Y120L0	117246.94MB	Ready

– Logical Volumes

Volume	Total Size	Free Size	Status
Striping Disk Volume: Drive 1 2 3 4	467878.12 MB	460403.27 MB	Ready


 



Note: When configuring disk volume, make sure there are no active users connecting to GNS-8000B to avoid any potential damage to the disks. You can check all currently active users in Statistics & Logs—Active Users (refer to Chapter 6.10.1) and inform those users to logout before configuring disk volume.

6.7 User Management

The files on GNS-8000B can be shared among multiple users. For easier management and better control of users' access right, you have to organize users, user groups and their access right control.



6.7.1 Users

The system has created the following users by default:

① Administrator

By default, administrator has access to system administration and cannot be deleted.

② Guest

This is a built-in user and will not be displayed on User Management page. When you use a non-registered user name to login, the server will recognize the user as a guest and will allow limited access. A guest does not belong to any user group.

③ Anonymous

This is a built-in user and will not be displayed on User Management page. When you connect to the server by FTP service, you can use this name to login as a guest.

512 users can be created at maximum (including system default users). You can create a new user according to your needs. The following information is required to create a new user:

✓ **User name**


The user name must not exceed 32 characters. It is case-insensitive and can contain double-byte characters, such as Chinese, Japanese, and Korean except:

" / \ [] : ; | = , + * ? < > ` '

✓ **Password**

The password is case-sensitive and can be 16 characters long at maximum. It is recommended to use a password of at least 6 characters.

You can perform the following settings for users:



6.7.2 User Groups


User group is a collection of users with the same access right to files or folders. GNS-8000B has created the following user groups by default:

① Administrators

All members in this group have administration right. You cannot delete this group.

② Everyone

All registered users belong to everyone group. You cannot delete this group.



You can manage user groups with the following options:



User groups name must not exceed 256 characters. It is case-insensitive and can contain double-byte characters, such as Chinese, Japanese, and Korean, except the following ones:

" / \ [] : ; | = , + * ? < > ` '


To properly manage security, it is very important to manage users and user groups. You may set the share access parameters of each user or user group accordingly.

Create Users and Assign Users to User Group



The following example demonstrates how to create new users and assign users to a user group.

ABC Co. has recently recruited two employees Mr. Jones Lee for Administration Department and Ms. Jane Wu for Sales Department. The IT Department therefore needs to create two user accounts for them to access company data on GNS-8000B.



- i. To create a user account, go to User Management-Users. Click **Create**.




- ii. Enter the user name (Jones Lee/ Jane Wu) and password. Check the box "Continue to set the user groups to which this user belongs" and click **OK**.

A screenshot of the 'Add a user' dialog box. The 'User Name' field contains 'Jones Lee'. The 'Password' and 'Verify Password' fields are filled with six dots. A note below the fields states: 'Note: For increased security, password should be at least 6 characters.' Below the note, the checkbox 'Continue to set the user groups to which this user belongs' is checked and circled in red. At the bottom right, the 'OK' button is circled in red, along with a green status indicator.A screenshot of the 'Add a user' dialog box. The 'User Name' field contains 'Jane Wu'. The 'Password' and 'Verify Password' fields are filled with six dots. A note below the fields states: 'Note: For increased security, password should be at least 6 characters.' Below the note, the checkbox 'Continue to set the user groups to which this user belongs' is checked and circled in red. At the bottom right, the 'OK' button is circled in red, along with a green status indicator.

- iii. Select the user groups the users belong to on the right list, i.e. Mr. Jones Lee for Administration Dept and Ms. Jane Wu for Sales Dept, and click **Add**. Then click **Close**.




- iv. After creating the users, the users will appear on the list on Create User Page.



Create Private Network Share for User Groups

You can create particular network share for each user group. The procedure is described as below:

1. To create a network share called **media** accessible by Administration Department only, please go to "User Management—User Groups" page. Select the user group Administration Dept and click **Create Private Network Share** on the right.




2. Enter the network share name **media**. Select to disk volume that the share will be created in and specify the path automatically or manually. Enter the comment for the network share, e.g. media folder for Admin Dept and click **Apply**.


— Enter new network share's name, volume and path. Only users that are the members of Administration Dept user group can access this network share.

Network Share Name	<input type="text" value="media"/>
Disk Volume	<input type="text" value="Striping Disk Volume: Drive13"/>
Path	<input checked="" type="radio"/> Specify path automatically <input type="radio"/> Enter path manually
	<input type="text"/> <input type="button" value="Browse..."/>
Comment	<input type="text" value="media folder for Admin Dept"/>

3. You can see the folder **media** in **Network Share Management** page.




4. Enter Access Control. You can see that only Administration Dept has full access right to the folder.



6.7.3 Quota

To allocate disk volume efficiently, you can specify the quota that can be used by each user. When this function is enabled and a user has reached his/her disk quota, he/she cannot upload data to the server anymore. By default, no limitations are set for users. You can modify the following two options:


- i. Enable quota for all users
- ii. Quota size on each disk volume




Please refer to the following example to configure the quota setting of users:

The IT department is planning to set the disk quota of Mr. Jones Lee from Administration Department and Ms. Jane Wu from Sales Department on GNS-8000B. The disk quota is 2000MB for Mr. Jones Lee and 4000MB for Ms. Jane Wu.


1. Please go to **Quota** page in **User Management** to enable quota for all users. Enter the quota size on each disk volume, e.g. 1000MB. The quota for individual user can be modified later.




2. Select Jones Lee on User page and click **Quota Settings** on the right.



3. Enter the quota size 2000MB and click **OK**.




4. Follow the same steps and enter the quota size 4000MB for Jane Wu and click **OK**. The quota setting is successfully applied.




6.8 Network Share Management

The primary purpose of network storage is file sharing. In a standard operation environment, you can create different network share folders for various types of files, or provide different file access rights to users or user groups.



There are four options in Network Share Management:



6.8.1 Create

To create a network share, enter the following information:

- ✓ Network share name
The share name must not exceed 12 characters and cannot contain the following characters:
" . + = / \ : | * ? < > ; [] %
- ✓ Disk volume
This area shows the disk volume status.
- ✓ Path
All data are stored under the assigned path onto the disk volume. You can select "Specify path automatically" or assign a path manually. The path cannot exceed 256 characters and cannot contain the characters below:
" . + = / \ : | * ? < > ; [] %
- ✓ Comment
Enter a brief description for the share folder. The comment cannot exceed 128 characters.

The screenshot shows a 'Create' dialog box for setting up a network share. It includes the following fields and options:

- Network Share Name:** An empty text input field.
- Disk Volume:** A dropdown menu currently showing 'Mirroring Disk Volume: Drive12'.
- Path:** Two radio buttons: 'Specify path automatically' (selected) and 'Enter path manually'. Below the radio buttons is a text input field and a 'Browse...' button.
- Comment:** A text input field.
- Permissions:** Three checkboxes: 'Grant full access right for everyone' (checked), 'Grant read access right for guest' (unchecked), and 'Continue to set access right for this network share' (checked).
- Buttons:** 'OK' and 'Cancel' buttons at the bottom right.

6.8.2 Property

To edit the property of an existing network share, select a share and click **Property**. You can then edit the content of that share.

The screenshot shows the 'Property' tab of a network share configuration window. It includes the following fields and controls:

- Network Share Name:** A text box containing 'test'.
- Disk Volume:** A dropdown menu showing 'RAID 5 Disk Volume: Drive1340'.
- Path:** A text box containing '/test'.
- Comment:** An empty text box.
- Note:** A blue text note stating: "Note: If you change the share's volume or path of the share, all data that has already existed in the original volume or path will not be moved."
- Buttons:** 'Browse...' (next to Path), 'OK' (with a green dot), and 'Cancel' (with a red X).

6.8.3 Access Control

Once the network share is created, you can assign access rights to users or user groups:


- ✓ Deny access
Access to the network share will be denied when this option is selected.
- ✓ Read only
Users can read the files only on the network share when read only is assigned.
- ✓ Full access
Users with full access are allowed to read, write, create, or delete files and folders on the network share.

The screenshot shows the 'Access Control' tab of a network share configuration window. It features two lists of users and groups, control buttons, and radio buttons for guest access rights.

- Users or Groups Configured with Access Right to test:** A list containing '===User Group=== everyone(Full access)'.
- Users or Groups Not Configured with Access Right to test:** A list containing '===User Group=== administrators', '===User=== administrator', and 'test'.
- Control Buttons:** 'Add' (with a green left arrow), 'Remove' (with a red right arrow), and a 'Permission' dropdown menu set to 'Full access'.
- Guest Access Right:** Three radio buttons: 'Deny access' (selected), 'Read only', and 'Full access'.
- Close Button:** A 'Close' button at the bottom right.

6.8.4 Delete

Select a share and click delete. Click **OK** to confirm.



6.9 System Tools



System Tools enable you to optimize the maintenance and management of GNS-8000B.

The screenshot shows the 'System Tools' interface. On the left, a sidebar lists various tools: SNMP Settings, Alert Notification, Restart/ Shutdown, Hardware Settings, UPS, System Update, Change Logo, Tape Backup, Remote Replication, Anti-virus Configuration, Backup/ Restore/ Reset Settings, and USB CD/DVD Backup/ Restore. The main area is titled 'SNMP Settings' and contains two sections: 'SNMP Service Setting' and 'SNMP Trap Setting'. In the 'SNMP Service Setting' section, the 'Enable SNMP Service' checkbox is unchecked. Below it are three text input fields for 'Community Name', 'System Contact', and 'System Location'. In the 'SNMP Trap Setting' section, the 'Enable SNMP Trap Notification' checkbox is unchecked. Below it are two text input fields for 'Community Name' and 'Trap Host IP Address', and a 'Send a test trap message' checkbox. An 'Apply' button is located at the bottom right of the main area.

6.9.1 SNMP Settings

Enable SNMP (Simple Network Management Protocol) service and complete all necessary settings to manage network components of the server by SNMP. When enabling SNMP Trap Notification, a message will be sent to a specified trap host when an error occurs.

This is a close-up view of the 'SNMP Settings' configuration page. The 'SNMP Service Setting' section shows the 'Enable SNMP Service' checkbox checked. The 'Community Name' text input field contains the text 'test'. The 'System Contact' and 'System Location' text input fields are empty. The 'SNMP Trap Setting' section shows the 'Enable SNMP Trap Notification' checkbox unchecked. The 'Community Name' and 'Trap Host IP Address' text input fields are empty. The 'Send a test trap message' checkbox is also unchecked. An 'Apply' button is visible at the bottom right.

6.9.2 Alert Notification

Enter the e-mail address of administrator and SMTP server IP address. In case of warning or malfunction, e.g. CPU fan fails, a disk drive fails or is unplugged, an email will be sent to the administrator automatically. You can refer to Event Logs section in Statistics & Logs (refer to Chapter 6.10.2) to check all happened errors and warnings.

If your mailbox requires SMTP authentication, enter the user name and password.



Note: It is recommended to send a test e-mail to make sure you can receive the alert mails.

Alert Notification

Alert level: High: Send e-mails on any errors or warning events
 Medium: Send e-mails only on critical errors
 Low: No alert e-mails will be sent

E-mail (SMTP) server IP address: . . .

Enable SMTP Authentication

User Name :

Password :

E-mail address 1:

E-mail address 2:

Send a test e-mail

6.9.3 Restart/ Shutdown


Select to restart or shut down GNS-8000B.

Restart / Shutdown

To restart the server, click Restart.
To shut down the server, click Shut Down.

6.9.4 Hardware Settings


You can enable or disable the hardware functions of GNS-8000B.



- i. **Enable LCD panel setting function**
To enable users to configure TCP/IP settings via the LCD panel.
- ii. **Enable configuration reset switch**
By enabling this option, you can press the reset button for a few seconds to reset the administrator password and system settings to default.
- iii. **Enable buzzer**
When buzzer is enabled, an alert sound will be played in case of system error.
- iv. **Power Supply Type**
Select power supply type. There is one power supply by default. **Do NOT change the position of default power supply.** To use a second power supply, you can purchase from the distributor.

To use two power supplies, follow the steps below:

1. Set power supply type as Redundant.



2. Shut down the system properly.
3. Insert the second power supply and turn on the system.

If a power supply fails, the system will send an alert notification to the administrator.

6.9.5 UPS

If your UPS device provides USB interface, you can enable UPS (uninterruptible power supply) support to protect your system from abnormal system shutdown caused by power outage. In case of utility power failure, the system will shut down automatically by probing the power status of the connected UPS unit.

UPS

Enable UPS Support

The system will be shut down in 5 minute(s) when the AC power status is abnormal.

UPS Model APC UPS with SNMP Management

IP Address of UPS 0 . 0 . 0 . 0

UPS Model

Test AC Power Status: --

Battery Power Status: --

After selecting the UPS model, click Test to make sure selection is correct.

Refresh Apply

✓ Enable UPS support

To activate the UPS support, you can select this option. You can set the shutdown timer to turn off the system automatically after the system detects the AC power is abnormal. In general, the UPS can keep supplying the power for the system for about 5~10 minutes, depending on the maximum load of the UPS and the number of the loads connected to it.

UPS Model

Select the UPS model from the list. If the UPS model you are using is not available on the list, please contact our technical support.

IP Address of UPS

If you have selected APC UPS with SNMP for UPS model, enter the IP address of the UPS.

UPS

Enable UPS Support
The system will be shut down in minute(s) when the AC power status is abnormal.

UPS Model

IP Address of UPS . . .

UPS Model AC Power Status: --
Battery Power Status: --

After selecting the UPS model, click Test to make sure selection is correct.



Note: When UPS support is not enabled, the **Test** button will not function.

6.9.6 System Update



Note: If the system is running properly, you do not need to update the firmware.

Before updating system firmware, please make sure the product model and firmware version are correct. Follow the steps below to update firmware:

Step 1: Download the release notes of the same version as the firmware from LEVELONE website <http://www.Level1.com/>. Read the release notes carefully to make sure you need to upgrade the firmware.

Step 2: Before upgrading system firmware, back up all disk data on the server to avoid any potential data loss during system update.

Step 3: Click the [Browse...] button to select the correct firmware image for system update. Click **Update System** to update the firmware.

Note: System update may take tens of seconds to several minutes to complete depending on the network connection status. Please wait patiently. The system will inform you when system update is completed.

- System Update

Note: If the system is running properly, you do not need to update the firmware.

Current firmware version: 1.0.0 Build 1118


Before updating system firmware, please make sure the product model and firmware version are correct. Follow the steps below to update firmware:

Step 1: Download the release notes of the same version as the firmware from QNAP website <http://www.qnap.com.tw/> Read the release notes carefully to make sure you need to upgrade the firmware.

Step 2: Before upgrading system firmware, back up all disk data on the server to avoid any potential data loss during system update.

Step 3: Click the [Browse...] button to select the correct firmware image for system update. Click the [Update System] button to update the firmware.

Note: System update may take tens of seconds to several minutes to complete depending on the network connection status. Please wait patiently. The system will inform you when system update is completed.



GNS-8000B firmware

6.9.7 Change Logo

You can choose a personal picture to display on the login page of GNS-8000B. The size of the picture cannot exceed 20K bytes.

Change Logo

Please select an image from the **To be displayed** pull-down menu. Then click **Apply** to confirm the change.







To upload your own image, click **Browse** to select the image. Then click **Upload** to upload the image.

To replace an image, select an appropriate image from the **To be replaced to** pull-down menu and click **Apply**.

Uploaded image:

To be replaced to:

To be displayed:

		
Image 1	Image 2	Uploaded Image
		
Image 3	Image 4	Current Logo Image

Note: For the best image effect, the recommended size for the image is 100 x 100 pixels.

6.9.8 Tape Backup

Tape backup enables you to perform backup or restoration jobs by a tape drive. GNS-8000B supports **full backup** and **incremental backup**. By full backup, all source files will be backed up. By incremental backup, only modified or new files after last backup will be backed up.

✓ Backup Now


To back up files to the tape drive immediately.

Backup Now	Restore	Scheduled Jobs	Tools	Job Status
------------	---------	----------------	-------	------------

Backup Label	<input type="text"/>
Backup Source	Single Disk: Drive1 ▾
Backup Type	Full Backup ▾
Tape Volume	Auto-detect ▾

Note:

1. If you need a second tape to continue the backup job and the tape drive cannot detect it automatically, please set the tape volume manually.
2. Make sure the label name does not contain any double-byte characters, e.g. Chinese and Japanese.


 Apply

✓ Restore

To restore data from the previously backup tape. Select the restore destination and whether or not to overwrite existing files.



Backup Now	Restore	Scheduled Jobs	Tools	Job Status
------------	---------	----------------	-------	------------

Restore Destination	Single Disk: Drive1 ▾
Overwrite Existing Files	Yes ▾

 Apply

✓ Scheduled Jobs

You can schedule a backup job to be executed automatically. Click **New** and define the job name, backup source, backup type, and schedule.



✓ Tools

There are several useful tape functions to operate on the tape drive. For example, you can rewind, eject or erase the tape here. Click **Apply** to execute the action.

Backup Now | Restore | Scheduled Jobs | **Tools** | Job Status

Please choose the operation and click the "Apply" button to execute.

- Rewind Tape
- Eject Tape
- Erase Tape
- Tape Information
- Cancel Current Task

Note: When "Cancel Current Task" is executed, it will take a few seconds to stop the operation of the tape drive.

Apply

✓ Job Status

You can view the status of backup or restore job.

Backup Now | Restore | Scheduled Jobs | Tools | **Job Status**

Job Status	The tape drive is not connected
Backup Source	--
Backup Label	--
Tape Number	--
Total Files	--
Total Size	--
Start Time	--

Close



Note:


1. The SCSI tape drive has to be properly connected and turned on before starting up GNS-8000B for proper detection.
2. HVD (High Voltage Differential) SCSI tape drive is not supported.

6.9.9 Remote Replication

Remote Replication enables you to replicate local files to remote folders on another server. The files will be compressed before the replication process in order to save time for data transfer. **Make sure a network share is created before creating a remote replication job.**


Using Remote Replication

Login GNS-8000B, go to Remote Replication in System Tools.



i. New

- a. Click **New** to enter the following page.



- b. Complete all settings and click OK to save or Cancel to quit.

Add a remote replication job

Job Name

Remote Destination

Remote Host Name / IP Address

Destination Path (Network Share/Directory) /

User Name

Password

Remote Host Testing (Status: --)

Local Source

Source Path (Network Share/Directory) /

Replicate Now

Replication Schedule Hour : Minute

Daily

Weekly

Monthly Day

Activate file compression

Stop network file services while replicating

Perform incremental replication


Delete extra files on remote destination



Note: To use remote replication, enable Microsoft Networking service, make sure the destination network share and directory have been created, and the user name and password are valid to login the destination folder.


ii. Edit

- a. Select the job to be edited.
- b. Click **Edit**.
- c. Modify the settings.
- d. Click OK to save or **Cancel** to quit.



iii. Delete

- a. Select the job to be deleted.
- b. Click **Delete**.



6.9.10 Backup/ Restore/ Reset Settings

To backup the setting(s), select the appropriate option(s) and click **Backup**. To restore a backup settings file, click **Browse** to select the file and click **Restore**. To reset the setting(s) to factory default(s), select the appropriate option and click **Reset**.

- Backup/Restore/Reset Settings

- To restore a backup settings file, click Browse to choose the backup settings file. Then click Restore.
- To back up the setting(s), select the appropriate option(s) and click Backup.
- To reset the setting(s) to factory default(s), select the appropriate option and click Reset.

User / User Group Settings

Disk Configuration

Share Volume Settings

Hardware Settings

System Settings

Network Configuration

All Settings

6.9.11 USB CD/ DVD Backup/ Restore

USB Backup/Restore function enables you to back up local data to CD/DVD discs via USB CD/DVD burner, and CD/DVD data to local disk.

Using USB Backup/Restore

USB CD/DVD Backup/ Restore

Device: No device detect
Media Type: No media detect
Maximum Write Speed:
Status: **No Disc**

Write Data

Volume Label:
Source Path (Network Share/ Directory): test /
Write Speed: 1x

Status: Idling

Load Data

CD Label
Destination Path (Network Share/ Directory): test /
 Overwrite existing files
 Skip existing files

Status: Idling

i. USB CD/DVD Detection

- a. Connect USB burner to GNS-8000B. Turn on the burner and input a writable disc.
- b. Click **Re-detect**. The system will display information of the detected burner.



- c. Click **Eject Disc** to eject the disc from the burner.
- d. Insert the disc again and click **Re-detect** and continue to use writing and loading functions.

ii. Write data

- a. To write data from GNS-8000B to disc, enter the volume label name.
- b. In Source Path (Network Share/Directory), select a network share from the drop-down menu and enter a directory name. You can also use stroke to indicate multiple directories, e.g. sales/jenny.

Write Data

Volume Label:

Source Path (Network Share/ Directory): /

Write Speed:

Status: Idling

- c. Select Write Speed.
- d. Click **Write to disc** to write data to the disc. To view updated writing status, click Refresh.

Write Data

Volume Label:

Source Path (Network Share/ Directory): /

Write Speed:

Status: 11.32%

- e. The disc will be ejected after burning.

iii. Load data

- Insert the disc for loading data to GNS-8000B network share. The volume label is shown in CD Label.
- In Destination Path (Network Share/Directory), select a network share from the drop-down menu and enter a directory name. You can also use stroke to indicate multiple directories, e.g. sales/jenny.
- Select **Overwrite existing files** to overwrite existing files in the directory or **Skip existing files** to skip loading files that have existed in the directory during loading process.

The screenshot shows the 'Load Data' interface. At the top, the title is 'Load Data'. Below it, the 'CD Label' is 'Sales'. The 'Destination Path (Network Share/ Directory):' is set to 'test' (selected in a dropdown) followed by a slash and 'sales/jenny' in a text input field. There are two radio buttons: 'Overwrite existing files' (which is selected) and 'Skip existing files'. At the bottom right, there are two buttons: 'Load' and 'Stop Loading'. The 'Status:' is 'Idling', and there is a 'Refresh' button.

- Click **Load** to load data to destination path.

The screenshot shows the 'Load Data' interface after clicking 'Load'. The 'CD Label' is 'Sales'. The 'Destination Path (Network Share/ Directory):' is 'test' (selected in a dropdown) followed by a slash and 'sales/jenny' in a text input field. There are two radio buttons: 'Overwrite existing files' (selected) and 'Skip existing files'. At the bottom right, there are two buttons: 'Load' and 'Stop Loading'. The 'Status:' is 'Initialize', and there is a 'Refresh' button.


- The disc will be ejected after loading.

6.10 Statistics & Logs

You can view the event logs of all currently online users on GNS-8000B for system monitoring.

6.10.1 Active Users


This page shows all users that are currently logged on to Web File Manager.



Network Share	User	From	Login Time	Connection Type
public	administrator	10.8.10.123	10:39:38 Mon Dec 5 2005	Microsoft Networking

6.10.2 Event Logs

GNS-8000B can store thousands of recent event logs, including warning, error and information messages. In case of system malfunction, event logs can be retrieved to analyze system problems.



Type	Date	Time
Error	09/08/2005	16:19:35
Error	09/07/2005	17:45:34


6.10.3 DHCP Logs

When DHCP service is enabled, you can refer to DHCP logs to monitor all assigned dynamic addresses, client MAC addresses and other information.


Chapter 7 Access GNS-8000B

7.1 By Microsoft Windows

1. You can access GNS-8000B in Windows OS by the following ways:
 - a. By Quick Install Wizard. For further information, please refer to Chapter 4.
 - b. You may also search for GNS-8000B within the Network Neighborhood. Locate the workgroup and find the name of your GNS-8000B. When the server is found, double-click on the server name to connect.
 - c. You may also use "Search for Computers" function to look for your GNS-8000B in Windows. Under Windows OS, please follow these steps:
 - i. Open "My Network Places".
 - ii. Under the tool bar, click **Search**.
 - iii. Enter the name of GNS-8000B in Computer Name field.
 - iv. Click **Search**.When GNS-8000B is found, double click the item to access the server.
 - d. Use Run function in Windows. Type \\[server name] or \\[server IP] to access share folder on GNS-8000B.



2. Once the connection to GNS-8000B is successful, all listing on your available network share will be displayed. Use the option **Map Network Drive** to map the folder(s) as your network drive.




7.2 By Apple MAC OS


If you are an Apple MAC user, you can access GNS-8000B by the following ways:

1. Using Network Browser


- a. Choose "Network Browser" in Apple menu.




- b. In "Network Browser", choose AppleTalk. A list of computers on the AppleTalk network will appear. Select GNS-8000B.




- c. Enter the login name and password, or use "Guest" to enter. Click **Connect**.



- d. When GNS-8000B is connected, all network shares will be shown.




- e. Choose a network share to connect. The network share will appear on the desktop.




2. Using Chooser


- a. Select **Chooser** on Apple menu bar.




- b. Click on **AppleShare**. The name of GNS-8000B will appear on the right side of the window.




- c. Use the mouse to highlight GNS-8000B and click OK.




- d. Enter the correct login name and password or use "Guest" to login, and then click **Connect**.



- e. All available network shares will be listed. Select a network share and click OK.



- f. Close the Chooser program. Double click on the icon on the desktop to access the files.



7.3 By Linux OS

In addition to Microsoft and MAC OS, GNS-8000B also supports Linux systems through the NFS service:

1. On Linux, run the following command:

```
mount -t nfs <GNS-8000B IP address>:/<Network Share Name>  
<Directory to Mount>
```

For example, if the IP address of your GNS-8000B is 192.168.0.1 and you want to link the network share folder "public" under the /mnt/pub directory, use the following command:

```
mount -t nfs 192.168.0.1:/public /mnt/pub
```



Note: You must login as "root" user to initiate the above command.

2. Login as the user id you define, you can use the mounted directory to access your network share files.


7.4 By Web Browser

Other than OS support, your GNS-8000B also provides a convenient web file management interface that allows using a standard web browser to access your data. If you link GNS-8000B to the Internet and use a public IP address, you can access the files on the server anywhere. For more information, please refer to Appendix A.

7.5 By File Transfer Protocol (FTP)


In addition to working with multiple operating systems, GNS-8000B also supports connection via FTP. Enter the correct user name and password to connect the server or access the public share folders as guest.

Please go to **Network Settings—FTP service** and enable FTP service before using FTP service.



Follow the steps below to use FTP service:


1. Open an IE browser and type ftp://[server IP] or ftp://[server name]. OR
2. By Web File Manager of GNS-8000B.
 - a. Go the GNS-8000B administration and click Web File Manager. Enter user name and password to login GNS-8000B.




b. Click the share folder in **FTP** section.



c. When the ftp folder is shown, enter user name and password.



- d. The share folder will be shown. You can then manage the folder by dragging and dropping files to it, as well as rename or delete the files.



Chapter 8 GNS-8000B Maintenance

GNS-8000B is specially designed to run 24x7 and be ready at all times against system crash caused by power outage. This section provides a general overview on system maintenance.

8.1 Restart/ Shut down Server

Follow the steps below to restart or shut down GNS-8000B.

1. Ask all active users of GNS-8000B to save their files and disconnect from the server.
2. Enter the administration page and select Restart/ Shutdown in System Tools.
3. Click **Restart** to reboot the server or **Shut Down** to turn off the server. You can perform these actions by the LCD panel.



8.2 Reset Administrator Password and Network Settings

To reset the administrator password and network settings of GNS-8000B,

1. Press the reset button of GNS-8000B for a few seconds. A beep sound will be heard.
2. Login GNS-8000B with the default user name and password:

Default user name: **administrator**
Password: **admin**



Note: To reset the system by the reset button, the option "Enable configuration reset switch" in Hardware Settings must be activated.

- Hardware Settings

- Enable LCD panel setting function
- Enable configuration reset switch
- Enable buzzer

Power Supply Type

8.3 Disk Failure or Malfunction

When you encounter disk malfunction or failure, please do the following:

1. Record the malfunction status or error messages.
2. Stop using the failed GNS-8000B and turn off the server.
3. Contact customer service for technical support.



Note: Your GNS-8000B must be repaired by professional technicians, please do not try to repair the server yourself. Please back up any important files or folders to avoid potential data loss due to disk crash.

8.4 Power Outage or Abnormal Shutdown

In case of power outage or improper shutdown of GNS-8000B, the system will resume to the state before it is shut down. If your server does not function properly after restart, please do the following:

1. If the system configuration is lost, configure the system again.
2. In the event of abnormal operation of the server, contact customer service for technical support.


To avoid the above situations, please back up your data periodically and make sure you have done the following:

- Follow the instructions described in Chapter 8.1 to restart or shut down the server.
- If there is an anticipated power outage, back up all important data and turn off the server properly until power supply is resumed.

Appendix A Web File Manager

Using Web File Manager


To use Web File Manager, enable Web File Manager in Network Settings first.




Launch the web browser and go to GNS-8000B home page. Select **Web File Manager** and enter the correct login name and password. You may also enter "guest" in the login name field with no password to access the network shares on GNS-8000B as an anonymous guest.




Note: Make sure a network share has been created before using Web File Manager.



Select an existing network share for management.




You can organize network share folders of GNS-8000B. With Web File Manager, you can upload, rename, or delete files and folders in the network shares.




View files online

Click on a file displayed on the web page. The information of the file will be displayed. If your browser does not support the file format, the download window pops up automatically. Once the file is downloaded, you can open it on your computer.


Create folder

- i. Select a network share or folder in which you want to create a new folder.
- ii. Click  (Create Folder) on the toolbar.
- iii. Enter the name of the new folder and click OK.

Rename file or folder

- i. Select a file or folder to rename.
- ii. Click  (Rename) on the toolbar.
- iii. Enter the new file or folder name and click OK.

Delete file or folder

- i. Select a file or folder to delete.
- ii. Click  (Delete) on the toolbar.
- iii. Confirm to delete the file or folder.

To delete all files and folders, click  (Select All) and then  (Delete).


Upload file

- i. Open the folder to upload file to.
- ii. Click **Browse** to select the file.
- iii. Click **Upload**.

Download file

- i. Select a file to download.
- ii. Right click the mouse and select "Save Target As" to save the file.



Logout

To exit Web File Manager, click  (Logout).

Viewing Files Named in Chinese













To view files named in Chinese, you may have to configure the browser settings. Take Internet Explorer as an example, follow the steps below to configure the settings.

1. Click on **Tools** in IE browser.




5. Restart the browser.

Web File Manager Icons

Icon	Description
	Up-return to the parent folder
	Refresh-reload the current page
	Home-return to network share list home page
	Create folder
	Rename file or folder
	Delete file or folder
	Select all
	Cancel selection
	Logout
	Full access network share folder
	Read-only network share folder
	Malfunction network share folder

Appendix B Configuring AD Authentication

AD environment mixed mode can be supported by GNS-8000B. For example, qatest.com.tw and sub2.qatest.com.tw are domains controlled by Windows 2003 server, and sub1.qatest.com.tw domain is controlled by Windows 2000 server.



Please make sure you have enabled the Active Directory Service on the Windows Server and check the following items:

1. DNS Server setting on GNS-8000B has to be directed to AD server.
2. GNS-8000B and AD server can synchronize only if their time difference is less than 5 minutes.
3. GNS-8000B and AD server will synchronize each 5 minute. To configure the settings manually, GNS-8000B has to be set as standalone mode and then added to AD domain.
4. When adding GNS-8000B to AD domain, please login by domain_name\Username. GNS-8000B local user cannot login AD domain.
5. Inter-network segments can be used.
6. If you are using NT Domain, please select standalone mode when you want to upgrade the system, then join AD domain.
7. It is suggested to use Windows 2000 Service Pack 4, or Windows 2003 Service Pack 1.
8. When GNS-8000B is added to AD domain, the authority of "everyone" will not work, "everyone" is the original account of GNS-8000B, but doesn't include AD. Therefore the authority has to be reset.
9. The DNS setting on Windows 2000 server should be added as "Active Directory DNS", the server should be rebooted after DNS setting is set.
10. You should use the full domain name on the AD setting of GNS-8000B. For example, if your FQDN name of AD server is "ad.test.com.tw", you should use "test.com.tw" as the ad domain setting on GNS-8000B.
11. The DNS setting on AD server should have the IP of AD server itself.
12. You must change the password of "administrator" after you create "Active Directory" service on AD server.
13. The DNS server on the AD Server should have two records on it.

For example, AD Server Name: 2003tc.testad.com

DNS record on DNS Server


2003tc.testad.com	A	192.168.1.100
-------------------	---	---------------

testad.com	A	192.168.1.100
------------	---	---------------

One is "A record" for AD server, and the other is the domain "A record" for DNS queries.

Adding GNS-8000B to Windows Server 2003 Active Directory Domain

1. Go to TCP/IP Configuration in Network Settings. Enter the IP address of primary DNS server. You can inquire AD domain via this DNS server.



2. Go to Microsoft Networking of Network Settings. Enable AD Domain Member, and enter the domain name and the user name with administrator access right to that domain.

Network Settings

- TCP/IP Configuration
- Microsoft Networking
- Apple Networking
- Linux (NFS) Service
- Web File Manager
- FTP Service
- Network Printer Service
- View Network Settings

Microsoft Networking

Enable file service for Microsoft networking

Standalone Server

NT Domain Member

AD Domain Member

Server Description:

Workgroup:

AD Server Name:

Domain Name:

Domain Username:

Password:

Enable WINS server

Use the specified WINS server

WINS server IP address:

Domain Master


Apply




Note:

- a. Make sure that a fully qualified domain name such as qtest.com.tw has been filled in.
- b. Make sure the user name with administrator access right to that domain.


3. When the following message appears after applying the settings in step 2, check the DNS IP.




- When the following message appears after applying the settings in step 2, domain name, domain user name, and the password.




- When the following message appears after applying the settings in step 2, check the time zone settings. Make sure the difference of your time and that of AD server is less than 5 minutes. If the time difference is larger than 5 minutes, you will not be able to add the domain member.



- Upon successful adding of domain member, you can view the list for domain users and local users in User Management.




- Go to Access Control in Network Share Management to configure the access control right of AD users for all available network shares.




Using AD users to access services

To access services like FTP, Network Neighborhood, or Apple Talk with an AD user account, add **DomainName** before the user name when logging in.




Adding GNS-8000B to Windows Server 2000 NT Domain

1. Go to Microsoft Networking to enable NT Domain member and then enter the domain name such as sub1 and the user who has administrator access right for identification.




Note:

- a. Please notice that GNS-8000B and Windows 2000/2003 server must be in the same section or the system will show the following error message.




- b. Make sure that a domain name such as sub1 has been filled in.
- c. Make sure the user name with administrator access right to that domain.


- When the following message appears after applying the settings in step 1, check the domain name, domain user name, and the password.




When the following message appears after applying the settings in step 2, check the time zone settings. Make sure the difference of your time and that of AD server is less than 5 minutes. If the time difference is larger than 5 minutes, you will not be able to add the domain member.



- Upon successful adding of domain member, you can view the list for domain users and local users in User Management.




- Go to Access Control in Network Share Management to configure the access control right of domain users for all available network shares.



Using domain users to access services

To access services like FTP, Network Neighborhood, or Apple Talk with an domain user account, add **DomainName** before the user name when logging in.



Note: To join AD domain again, set GNS-8000B as standalone server in Microsoft Networking section. Make sure all domain users are removed in User Management before joining GNS-8000B to AD domain.

Appendix C Messages of Hard Disk and Disk Configuration Status

Hard Disk	
English Display	Status Description
Ready	The hard disk status is normal
No disk	No disk currently ✓ Disk tray is not installed or there is main board error. Users can check disk tray. If there is main board error, please contact LEVELONE customer service.
Invalid	Indicates the disk does not have a record on GNS-8000B ✓ The disk is used on GNS-8000B the first time, or the disk on the same GNS-8000B model is used. Users can re-configure disk volume.
R/W error	Disk fails ✓ When R/W error is shown, users should back up data immediately and replace the failed disk.

Disk Configuration/ RAID Configuration	
English Display	Status Description
Initializing	Initializing disk
Formatting	Formatting disk
Creating	Creating RAID configuration
Removing	Removing RAID configuration
Rebuilding	Rebuilding RAID configuration
Checking	Error checking on hard disk or disk configuration in process ✓ GNS-8000B will check disk automatically if it is shut down improperly

Disk Configuration/ RAID Configuration	
English Display	Status Description
Ready	The status of current disk or disk configuration is normal
Unmounted	Hard disk is not installed or hard disk configuration is not configured
Not Active	RAID configuration is damaged and cannot be enabled ✓ When this message is shown, users should back up disk data immediately and replace the failed disk.
Uninitialized	Initialization fails ✓ Single disk does not support hot swap. If the hard disk is unplugged when GNS-8000B is turning on, disk configuration will be damaged and will lead to data loss.
In degraded mode	A disk of RAID 1 or RAID 5 configuration is unplugged or fails. RAID data protection mechanism fails. ✓ In this situation, users should back up disk data immediately and replace the failed disk to rebuild RAID configuration.



Note:

1. When R/W error is displayed for hard disk status, or "Not active" or "In degraded mode" is displayed for RAID configuration, please replace the hard disk immediately to ensure RAID data protection can work properly. LEVELONE is not responsible for any data loss caused by delay in replacing failed disks in a RAID configuration by users intentionally or unintentionally.
2. LEVELONE Systems, Inc. guarantees that all GNS-8000B (GNS-8000B) released have passed strict and complete QA test and can operate properly in normal condition. LEVELONE offers conditional and limited maintenance for GNS-8000B within warranty period. However, LEVELONE disclaims the responsibility for any data loss or damage, or business loss of users. In no event shall the liability of LEVELONE exceed the price paid for the product from direct, indirect, special, incidental, or consequential software, or its documentation.

Appendix D: Virus Scan

A network share may not be able to detect a virus without an automatic virus scan function when there is a transfer of infected files. The user computer may have been infected in this situation. To prevent virus infection of the user computers, the system provides a virus scan program to comprehend with available virus scan agent for the best data protection.



In System Tools, enter the IP address of the network share and set up the user account and password for the virus scan agent. Specify the IP address of the virus scan agent. When there is a file transfer, the virus scan agent will notify the virus scan software on the system to scan the file.

Installing Virus Scan Agent


Make sure the virus scan agent and software are installed on the same computer that performs virus scanning before activating the agent.

Follow the following steps to installing Virus Scan Agent:


1. Run the CD-ROM enclosed in the Disk On-line Server package. When the following screen appear, click Install Virus Scan Agent.
2. Click Next to continue the Virus Scan Agent Setup.



3. Click Finish to complete the Setup.



A screen will pop up to show the system information the first time you have successfully installed the virus scan agent.




The description of the fields is as below:

Fields	Description
Server Name	Name of the network share under the protection of virus scan agent

IP Address	The IP address of the network share
Status	<p>Connection status of the host network share with the virus scan agent:</p> <ul style="list-style-type: none"> • <i>Disconnect</i>: Not connected to the network • <i>Idle</i>: Connection has been enabled but there is no file transfer for three minutes or more. • <i>Ready</i>: Connection has been enabled and ready to be scanned • <i>--</i>: User name and password have not been set up
Infected	Number of infected files
Last Scan Time	Date and time of the most recent virus scanning job
Result	<p>Scanning result:</p> <p>OK: No files are infected</p> <ul style="list-style-type: none"> • <i>Virus Found</i>: Virus is found. The name of the infected file(s) may not be displayed due to the scanning of other files. Go to the administration page to view the name and location of the infected file(s). • <i>Access Denied</i>: Access to the server is denied. • <i>Authentication Failed</i>: The login user ID is not authorized to access the folder of the network share.
Path	The file location on the network share

Enabling Virus Scan Support

Go to Virus Scan of System Tools. To enable virus scan support, tick the box Enable Virus Scan Support. Enter the IP address of the virus scan server and click Apply.



Viewing Details of Infected Files

To view the details of infected files of the network share, go to Event Logs of Statistics & Logs. A warning message will be shown in the table.

The screenshot shows the LEVELONE GNS-8000B Configuration web interface. The header includes the LEVELONE logo and the slogan "ONE WORLD ONE BRAND ONE LEVEL". The left sidebar contains "Statistics & Logs" with links for "Active Users", "Event Logs", and "DHCP Logs". The main content area displays a table of events, with two events listed. The first event is an "Error" type with the content "Virus found in the file: //public/virus" and occurred on 05/15/2003 at 17:03:02. The second event is an "Information" type with the content "Connection to Virus Scan Agent is successful.Virus Scan protection is activated" and occurred on 05/15/2003 at 17:02:52. Below the table are "Refresh" and "Clear" buttons.

Type	Content	Date	Time
Error	Virus found in the file: //public/virus	05/15/2003	17:03:02
Information	Connection to Virus Scan Agent is successful.Virus Scan protection is activated	05/15/2003	17:02:52

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all. The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

Terms And Conditions For Copying, Distribution And Modification

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in

themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it. Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies,

or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING,

REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

All the source code of LevelOne GPL products are uploaded to

<http://www.level1.com>

All the users can download freely.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>