

WIRE FEED MODULE™


IM 513-B

February, 2011

For Wire Feed Module Code Number: 10066, 10914, 11806

Safety Depends on You

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation **on your part**. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.



OPERATOR'S MANUAL



Copyright © Lincoln Global Inc.

LINCOLN®
ELECTRIC

- World's Leader in Welding and Cutting Products •
- Sales and Service through Subsidiaries and Distributors Worldwide •

Cleveland, Ohio 44117-1199 U.S.A. TEL: 216.481.8100 FAX: 216.486.1751 WEB SITE: www.lincolnelectric.com

Download from Www.Somanuals.com. All Manuals Search And Download.

⚠ WARNING

⚠ CALIFORNIA PROPOSITION 65 WARNINGS ⚠

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

The Above For Diesel Engines

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

The Above For Gasoline Engines

ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



FOR ENGINE powered equipment.

1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.



1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.

1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.

1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.



1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.

1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



ELECTRIC AND MAGNETIC FIELDS may be dangerous

2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines

2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.

2.c. Exposure to EMF fields in welding may have other health effects which are now not known.

2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

2.d.1. Route the electrode and work cables together - Secure them with tape when possible.

2.d.2. Never coil the electrode lead around your body.

2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.

2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.

2.d.5. Do not work next to welding power source.

Mar '95



ELECTRIC SHOCK can kill.

3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.

3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.

3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".

3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.

3.e. Ground the work or metal to be welded to a good electrical (earth) ground.

3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.

3.g. Never dip the electrode in water for cooling.

3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.

3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.

3.j. Also see Items 6.c. and 8.



ARC RAYS can burn.

4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.

4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.

4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



FUMES AND GASES can be dangerous.

5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep

fumes and gases away from the breathing zone. **When welding with electrodes which require special ventilation such as stainless or hard facing (see instructions on container or MSDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.**


5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.

5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.

5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.

5.e. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet (MSDS) and follow your employer's safety practices. MSDS forms are available from your welding distributor or from the manufacturer.

5.f. Also see item 1.b.



WELDING and CUTTING SPARKS can cause fire or explosion.

6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire.

Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.

- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.
- 6.i. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, Ma 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.



CYLINDER may explode if damaged.

7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.

- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association 1235 Jefferson Davis Highway, Arlington, VA 22202.



FOR ELECTRICALLY powered equipment.

- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Refer to <http://www.lincolnelectric.com/safety> for additional safety information.

PRÉCAUTIONS DE SÛRETÉ

Pour votre propre protection lire et observer toutes les instructions et les précautions de sûreté spécifiques qui paraissent dans ce manuel aussi bien que les précautions de sûreté générales suivantes:

Sûreté Pour Soudage A L'Arc

1. Protégez-vous contre la secousse électrique:
 - a. Les circuits à l'électrode et à la pièce sont sous tension quand la machine à souder est en marche. Eviter toujours tout contact entre les parties sous tension et la peau nue ou les vêtements mouillés. Porter des gants secs et sans trous pour isoler les mains.
 - b. Faire très attention de bien s'isoler de la masse quand on soude dans des endroits humides, ou sur un plancher métallique ou des grilles métalliques, principalement dans les positions assis ou couché pour lesquelles une grande partie du corps peut être en contact avec la masse.
 - c. Maintenir le porte-électrode, la pince de masse, le câble de soudage et la machine à souder en bon et sûr état de fonctionnement.
 - d. Ne jamais plonger le porte-électrode dans l'eau pour le refroidir.
 - e. Ne jamais toucher simultanément les parties sous tension des porte-électrodes connectés à deux machines à souder parce que la tension entre les deux pinces peut être le total de la tension à vide des deux machines.
 - f. Si on utilise la machine à souder comme une source de courant pour soudage semi-automatique, ces précautions pour le porte-électrode s'appliquent aussi au pistolet de soudage.
2. Dans le cas de travail au dessus du niveau du sol, se protéger contre les chutes dans le cas où on reçoit un choc. Ne jamais enrouler le câble-électrode autour de n'importe quelle partie du corps.
3. Un coup d'arc peut être plus sévère qu'un coup de soliel, donc:
 - a. Utiliser un bon masque avec un verre filtrant approprié ainsi qu'un verre blanc afin de se protéger les yeux du rayonnement de l'arc et des projections quand on soude ou quand on regarde l'arc.
 - b. Porter des vêtements convenables afin de protéger la peau de soudeur et des aides contre le rayonnement de l'arc.
 - c. Protéger l'autre personnel travaillant à proximité au soudage à l'aide d'écrans appropriés et non-inflammables.
4. Des gouttes de laitier en fusion sont émises de l'arc de soudage. Se protéger avec des vêtements de protection libres de l'huile, tels que les gants en cuir, chemise épaisse, pantalons sans revers, et chaussures montantes.
5. Toujours porter des lunettes de sécurité dans la zone de soudage. Utiliser des lunettes avec écrans latéraux dans les zones où l'on pique le laitier.

6. Eloigner les matériaux inflammables ou les recouvrir afin de prévenir tout risque d'incendie dû aux étincelles.
7. Quand on ne soude pas, poser la pince à un endroit isolé de la masse. Un court-circuit accidentel peut provoquer un échauffement et un risque d'incendie.
8. S'assurer que la masse est connectée le plus près possible de la zone de travail qu'il est pratique de le faire. Si on place la masse sur la charpente de la construction ou d'autres endroits éloignés de la zone de travail, on augmente le risque de voir passer le courant de soudage par les chaînes de levage, câbles de grue, ou autres circuits. Cela peut provoquer des risques d'incendie ou d'échauffement des chaînes et des câbles jusqu'à ce qu'ils se rompent.
9. Assurer une ventilation suffisante dans la zone de soudage. Ceci est particulièrement important pour le soudage de tôles galvanisées plombées, ou cadmiées ou tout autre métal qui produit des fumées toxiques.
10. Ne pas souder en présence de vapeurs de chlore provenant d'opérations de dégraissage, nettoyage ou pistolage. La chaleur ou les rayons de l'arc peuvent réagir avec les vapeurs du solvant pour produire du phosgène (gas fortement toxique) ou autres produits irritants.
11. Pour obtenir de plus amples renseignements sur la sûreté, voir le code "Code for safety in welding and cutting" CSA Standard W 117.2-1974.

PRÉCAUTIONS DE SÛRETÉ POUR LES MACHINES À SOUDER À TRANSFORMATEUR ET À REDRESSEUR

1. Relier à la terre le châssis du poste conformément au code de l'électricité et aux recommandations du fabricant. Le dispositif de montage ou la pièce à souder doit être branché à une bonne mise à la terre.
2. Autant que possible, l'installation et l'entretien du poste seront effectués par un électricien qualifié.
3. Avant de faire des travaux à l'intérieur de poste, la débrancher à l'interrupteur à la boîte de fusibles.
4. Garder tous les couvercles et dispositifs de sûreté à leur place.

Mar. '93

Thank You — for selecting a **QUALITY** product by Lincoln Electric. We want you to take pride in operating this Lincoln Electric Company product
 ... as much pride as we have in bringing this product to you!

CUSTOMER ASSISTANCE POLICY

The business of The Lincoln Electric Company is manufacturing and selling high quality welding equipment, consumables, and cutting equipment. Our challenge is to meet the needs of our customers and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for advice or information about their use of our products. We respond to our customers based on the best information in our possession at that time. Lincoln Electric is not in a position to warrant or guarantee such advice, and assumes no liability, with respect to such information or advice. We expressly disclaim any warranty of any kind, including any warranty of fitness for any customer's particular purpose, with respect to such information or advice. As a matter of practical consideration, we also cannot assume any responsibility for updating or correcting any such information or advice once it has been given, nor does the provision of information or advice create, expand or alter any warranty with respect to the sale of our products.

Lincoln Electric is a responsive manufacturer, but the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

Subject to Change – This information is accurate to the best of our knowledge at the time of printing. Please refer to www.lincolnelectric.com for any updated information.

Please Examine Carton and Equipment For Damage Immediately

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, Claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

Please record your equipment identification information below for future reference. This information can be found on your machine nameplate.

Product _____

Model Number _____

Code Number or Date Code _____

Serial Number _____

Date Purchased _____

Where Purchased _____

Whenever you request replacement parts or information on this equipment, always supply the information you have recorded above. The code number is especially important when identifying the correct replacement parts.

On-Line Product Registration

- Register your machine with Lincoln Electric either via fax or over the Internet.
 - For faxing: Complete the form on the back of the warranty statement included in the literature packet accompanying this machine and fax the form per the instructions printed on it.
 - For On-Line Registration: Go to our **WEB SITE at www.lincolnelectric.com**. Choose "Quick Links" and then "Product Registration". Please complete the form and submit your registration.

Read this Operators Manual completely before attempting to use this equipment. Save this manual and keep it handy for quick reference. Pay particular attention to the safety instructions we have provided for your protection. The level of seriousness to be applied to each is explained below:

⚠ WARNING

This statement appears where the information **must** be followed **exactly** to avoid **serious personal injury** or **loss of life**.

⚠ CAUTION

This statement appears where the information **must** be followed to avoid **minor personal injury** or **damage to this equipment**.

	PAGE
SPECIFICATIONS	8
GENERAL DESCRIPTION	8
DESIGN FEATURES	8
RECOMMENDED WIRE FEEDERS AND ACCESSORIES	8
 INSTALLATION INSTRUCTIONS	
Safety Precautions	9
Machine Grounding	9
Assembly into Engine Driven Welders	
Classic Series (K6090-5, K1406-3 and -4, K1428-2, K1433-1, K1643-1, K1754-1), K1643-3, K1643-5, K1643-7, K1643-9	
Pipeliner Series (K6090-7 and -9), K6090-10, K6090-11	
SA-250 (K1283-4 & -8) or 350SA (K1314-4), SAE-300 (K3003-1)	9
Pre-Installation	9
Tools Required	9
Assemble into Classic Series Pipeliner, SA-250 and 350SA Installation Sequence (Codes 10066, 10914)	10 thru 15
Assemble into SAE-300 Installation Sequence (Code11806)	16 thru 18
Connection of Lincoln Electric Wire Feeders	19
Connection of the LN-25 to the Wire Feed Module	19
Connection of the LN-7, LN-7 GMA to the Wire Feed Module	19
Connection of the LN-23P to the Wire Feed Module	19
 OPERATING INSTRUCTIONS	
Additional Safety Precautions	20
Wire Feed Module Operation	20
Output	20
Controls	20
Recommended Processes	20
 MAINTENANCE	
Engine Speed Adjustments	20
 TROUBLESHOOTING	
Troubleshooting Chart	20 thru 22
Troubleshooting Procedures	23 thru 25
 DIAGRAMS	
Wire Feed Module Wiring Diagram	26
Wire Feed Module / Engine Welder - Connection Diagram	27
Connection Diagram-Classic II, III, IIID, 300D, 300G, SA-250, 350SA & SAE-300 w/WFM to LN-23P w/ Adapter kit	28
Connection Diagram-Classic II, III, IIID, 300D, 300G, SA-250, 350SA & SAE-300 w/WFM to K867 Plug to LN-7	29
Connection Diagram-Classic II, III, IIID, 300D, 300G, SA-250, 350SA & SAE-300 w/WFM to K864 Adapter to LN-7 & Remote Control	30
Connection Diagram-All Classic, All Pipeliner, SA-250, 350SA & SAE-300 w/WFM to K867 Universal Adapter	31
Connection Diagram-All Classic, All Pipeliner, SA-250, 350SA & SAE-300 w/WFM to LN-25 w/ K444-2 Option	32
Connection Diagram-Classic II, III, IIID, 300D, 300G, SA-250, 350SA & SAE-300 w/WFM to LN-25 w/ K431, K433 & K432-"L" Option	33
Connection Diagram-Classic II, III, IIID, 300D, 300G, SA-250, 350SA & SAE-300 w/WFM to K867 Plug to K487 / K488 / K492 Spool Gun	34
 OUTPUT CURVES	
Classic I, Pipeliner 200D and 200G with Wire Feed Module Output Curves	35
Classic II with Wire Feed Module Output Curves	36
Classic III and 300G with Wire Feed Module Output Curves	37
Classic IIID, Classic 300D, SA250 & SAE-300 (Codes 10890 & above) with Wire Feed Module Output Curves	38
350SA and SA-250 (Codes 10889 and below) Perkins with Wire Feed Module Output Curves	39
 PARTS LIST	 P-231 Series

SPECIFICATIONS

	K623-1 Wire Feed Module to be Field-Installed On: (1)	Factory-Installed Wire Feed Module & Welder Per:	Rating @ 60% Duty Cycle	Max. Output @ 35% Duty Cycle	Auxiliary Power
Classic I	K6090-6 K6090-5 (CSA)	Not Available	200 Amps @ 35V	250 Amps @ 30V	Auxiliary Power is Reduced 25% in the CV Mode
Pipeliner 200G	K6090-7				
Pipeliner 200D	K6090-9,-10,11(CSA)				
Classic II	K1406-4 K1406-3 (CSA)	K1406-6 K1406-5 (CSA)	250 Amps @ 35V	310 Amps @ 32V	
SA250	K1283-4 (CSA)	K1283-5 (CSA)	300 Amps @ 35V	325 Amps @ 34V	
	K1283-8 (CSA)	Not Available			
350SA (International)	K1314-4 (CSA)	K1314-5 (CSA)	250 Amps @ 35V	310 Amps @ 32V	
Classic III	K1428-2 (CSA)	K1428-3 (CSA)	300 Amps @ 35V	325 Amps @ 34V	
Classic IIID	K1433-1 (CSA)	K1433-2 (CSA)			
Classic 300D	K1643-1 (CSA)	K1643-2 (CSA)			
	K1643-3 (CSA)	K1643-4 (CSA)			
	K1643-5 (CSA)	K1643-6 (CSA)			
	K1643-7 (CSA)	K1643-8 (CSA)			
SAE-300	K3003-1 (CSA)	Not Available			
Classic 300G	K1754-1	Not Available			

(1) K623-1 Wire Feed Module can only be installed on welders with code 10061 and above.

GENERAL DESCRIPTION

The Wire Feed Module (WFM) is an additional output control device designed to be easily installed into the Classic® and Pipeliner Series of Engine Welders or the SA-250 Perkins or 350SA Perkins engine driven welders (with code 10061 and above). The WFM modifies the dynamic output characteristics of the welder to provide excellent voltage control for semiautomatic wire electrode welding and other open arc processes. With the module installed, the welder can be easily set to operate in either the constant voltage or the standard constant current modes. The constant voltage mode is adjusted with the controls conveniently mounted on the control panel or with an optional remote control. The main module contains a capacitor bank, electronic control circuit and a "COLD TIP" contactor. This module easily attaches to the welders fuel tank support. Field installation takes approximately 60 minutes.

DESIGN FEATURES

- Easy access to the controls located on the welder control panel.

- Greatly enhanced welding arc performance. Now a wider range of wire electrodes and processes are supported by this device.
- Improved arc starting characteristics.
- Low spatter MIG welding with CO₂ Gas.
- Built into the WFM is a power contactor that provides a "COLD" electrode when the gun trigger is released.
- Simplified field installation process. All control wiring connections between the welder, the control panel, and the WFM are easily made with in-line plug type connections.
- Includes thermostatic protection to protect the welder from over current and over temperature.

RECOMMENDED WIRE FEEDERS AND ACCESSORIES

The WFM is designed to work with the complete family of LN-7, LN-25, and LN-23P wire feeders.

Please refer to the connection diagram in the back of this manual for details.

INSTALLATION INSTRUCTIONS

Safety Precautions

WARNING

Do not attempt to use this equipment until you have thoroughly read all operating and maintenance manuals supplied with your machine. They include important safety precautions, detailed engine starting, operating and maintenance instructions and parts lists.

Have a qualified technician do the maintenance and troubleshooting work. Turn engine off before working inside the machine. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring removal is complete. Always use the greatest care when working near moving parts.



ELECTRIC SHOCK can kill.

- Do not touch electrically live parts such as output terminals or internal wiring.



ENGINE EXHAUST can kill.

- Use in open, well ventilated areas or vent exhaust outside.



MOVING PARTS can injure.

- Do not operate with doors open or guards off.
- Stop engine before servicing.
- Keep away from moving parts.

Only qualified personnel should install, use, or service this equipment.

Machine Grounding

Because a portable engine driven welder or generator creates its own power, it is not necessary to connect its frame to an earth ground, unless the machine is connected to premises wiring (your home, shop, etc.)

To prevent dangerous electric shock, other equipment to which an engine driven welder supplies power must:

- a) Be grounded to the frame of the welder using a grounded type plug,

or

- b) Be double insulated.

When a welder is mounted on a truck or trailer, its frame must be securely connected to the metal frame of the vehicle.

Where an engine driven welder is connected to premises wiring such as that in your home or shop, its frame must be connected for the system earth ground. See further connection instructions in the section entitled "Standby Power Connections" as well as the article on grounding in the latest U.S. National Electrical Code and the local code.

In general, if the machine is to be grounded, it should be connected with a #8 or larger copper wire to a solid earth ground such as a metal water pipe going into the ground for at least 10 feet and having no insulated joints or to the metal framework of a building which has been effectively grounded. The U.S. National Electrical Code lists a number of alternate means of grounding electrical equipment. A machine grounding stud marked with the symbol $\frac{\perp}{\perp}$ is provided on the Generator Mount of the welder.

ASSEMBLY INTO ENGINE DRIVEN WELDERS: CLASSIC SERIES (K6090-5, K1406-3, -4, K1428-2, K1433-1, K1643-1, -3, -5, -7, -9, K1754-1) Pipeliner (K6090-7, -9, -10, -11) and SA-250 (K1283-4, -8) or 350SA (K1314-4). SAE-300 (K3003-1)

Pre Installation

Unpack WFM and check the contents against the listed items.

ITEM	DESCRIPTION	QTY.
1	Control Module Assembly	1
2	Control Panel Assembly	1
3	CV Negative Output Panel Assembly	1
4	Mounting Hardware Packet	1
5	Instruction Manual and Literature	1
6	WFM Nameplate SAE-300	1

Tools Required

- Large and Small Flat Head Screwdriver
- Pliers
- 3/32" Allen Wrench
- 3/8" Drive Ratchet with Small Extension
- 1/2" Socket
- 9/16" Deep Well Socket
- 3/4" Socket
- 5/16" Nut Driver and Socket
- 1/2" Open End Wrench
- 9/16" Open End Wrench
- Voltmeter

ASSEMBLE INTO CLASSIC SERIES PIPELINER, SA-250 and 350SA INSTALLA- TION SEQUENCE:

(For codes 10066, 10914)

- 1) Remove current range selector and fine current adjustment control knobs from front of machine. (small flat screwdriver and 3/32" Allen wrench.)
- 2) Remove 5 upper nameplate screws, or fastener buttons.
- 3) Break-off upper half of machine nameplate. Nameplate is scored for easy bending and break-off.




- 4) Install control panel assembly. (Wiring connections will be made later).




- 5) Secure control panel assembly with (7) screws from the mounting hardware packet. (5/16" Nut Driver)
- 6) Reinstall current range selector and fine current adjustment control knobs to front of machine. (Small flat screwdriver and 3/32" Allen wrench).




- 7) (For Classic II models ONLY) Remove the side panel. (3/8" Socket wrench).




- 8) Remove 2 screws from brush wraparound cover. Loosen and rotate the wraparound cover until negative brushholder is exposed. (Large flat head screwdriver and pliers).




- 9) The negative brushholder is in the 11:00 position looking at the control panel end of the generator. Remove negative brushholder 5/16" bolt. (1/2" Socket, ratchet, and small extension.)
- 10) **(NOTE:)** If you are installing the WFM on the Classic I, you must change the "250H" thermostat to the thermostat marked "200", (provided in the mounting hardware packet). Make certain the nut and bolt is tightened and the 608 and 609 leads are connected to the thermostat. (1/2" Socket, ratchet, and 1/2" open end.)




- 11) Position Wire Feed Module control box next to the right side of the machine (as shown). Place one plain washer (provided in the mounting hardware packet) over each mounting stud.




- 12) Feed power cable assembly through the rectangular window on the bottom of the generator.



- 13) Connect power cable/thermostat assembly and the existing cables to the negative brushholder using the .75" long 5/16" hex head cap screw, (provided in the mounting hardware packet). Make certain the thermostat assembly does not touch the brushholder spring and the cable is clear of any moving parts. Make certain the thermostat is assembled under the cable connections. (1/2" socket, ratchet, small extension).




- 14) Reposition the brush wraparound cover and tighten with the hardware removed in step 8. Keep the tightening flanges below the 3:00 position. (Large flat head screwdriver and pliers.)




- 15) Locate and remove 12-pin jumper plug and install 12-pin connector from control box to 12-pin connector. Connect control box 6-pin connector to control panel 6-pin connector. Connect control box 9-pin connector to control panel 9-pin connector.

For Classic 300D with Codes (11547, 11548, 11572, 11573) and Pipeliner 200D Code 11591. Remove U (BLUE) and 602C wires from flyback bridge. See machine wiring diagram. Keep U and 602C lead terminals connected and insulate with electrical tape.




- 16) For Classic I, III, IIID, 300D, 300G and SA250 (Codes 10889 and Below), 350 SA, Pipeliner 200D and 200G remove two (2) fuel tank hold down bolts on the right side of the machine and save hardware. (9/16" deep well socket, ratchet, and 9/16" open end wrench.) For the Classic II and SA250 (Codes 10890 and Above), do not remove the fuel tank hold down bolts. On these machines, the WFM mounts to the adjacent holes with two (2) 1" spacers, flat washer, lock washer and hex nuts, (provided in the mounting hardware packet).



- 17) For the Classic I & III, the carburetor choke cable must be unclamped at the frame. Reclamp at the flange provided on the WFM.



- 18) Position control box into place. On some models, the control box must be maneuvered out, up and back to clear the door latch catch. On Classic II machines, make sure the battery cable is not caught between the wire feed module and generator.
- 19) Install flat washer, lockwasher, and hex nut to control box mounting studs and tighten. (9/16" Socket, ratchet, and 9/16" open end wrench).




- 20) Remove both the positive and negative output terminal bolts. (3/4" Socket wrench).
NOTE: On the Classic II machines, the weld output terminals are located on the right side (facing the control panel) of the machine under the side access door. On all other machines the weld output terminals are located on the left side (facing the control panel) of the machine under the left access door.




- 21) Using bolts from step 20, connect control box's positive and negative power cables and machine's positive and negative output cables to the respective output terminals. Tighten bolts. (3/4" Socket wrench).
NOTE: Use caution when routing the CV power cables; ensure that there is adequate clearance from any sharp surfaces.


- 22) Connect the remaining lead from the control box to CV output terminal, using bolt supplied with the output terminal assembly. Output panel leg attaches to the front of the machine (3/4" Socket wrench).




- 23) Drive three (3) self-tapping screws into output panel. (5/16" Nut driver or socket wrench).
NOTE: The CV outout terminal assembly mounts under the weld output terminals on all machines.



- 24) With the CC/CV switch set to CC, start the engine and check the open circuit voltage on the output terminals. The voltage should be 80 to 100 volts with the thermostat and range switch set at maximum. **NOTE:** OCV may be slightly higher when the unit is cold. (Voltmeter)




- 25) Switch the CC/CV switch to CV and check the voltage between the Positive output terminal and the CV output terminal. The voltage should be 45 to 55 volts at maximum output position and 7 to 12 volts at minimum output position. (Voltmeter)



- 26) (For Classic II's only) Reassemble the side panel. (3/8" Socket wrench)


**ASSEMBLY INTO SAE-300 WELDER:
INSTALLATION SEQUENCE:
(For Code 11806)**

1. Remove the bottom 3 mounting screws from the upper control nameplate. Keep the screws for later use to fasten the WFM nameplate. Once, the screws have been removed snap / break off the lower section of the nameplate (the section with the welder name on it).



1. Remove 3 mounting screws.
2. Snap or Break off lower section on this dotted line.

2. Attach the WFM nameplate to the upper control panel on the welder below the original nameplate with 5 mounting screws.




5 mounting screws.


3. Remove the 2 toggle switches, amphenol & cap and the potentiometer with knob from the original control panel assembly. DO NOT disconnect the wiring from the switches.

4. Insert the local / remote toggle switch (most wires connected to it) first into the upper control panel on the welder with the mounting tab down. Next mount the potentiometer and secure the knob. Next mount the cv / cc toggle switch with the mounting tab down. Mount the amphenol and cap.


5. Remove 2 screws from brush wraparound cover. Loosen and rotate the wraparound cover until negative brushholder is exposed. (Large flat head screwdriver and pliers).




6. The negative brushholder is in the 11:00 position looking at the control panel end of the generator. Remove negative brushholder 5/16" bolt. (1/2" Socket, ratchet, and small extension.)




7. Position Wire Feed Module control box next to the right side of the machine (as shown). Place one plain washer (provided in the mounting hardware packet) over each mounting stud.




8. Feed power cable assembly through the rectangular window on the bottom of the generator.



9. Connect power cable/thermostat assembly and the existing cables to the negative brushholder using the .75" long 5/16" hex head cap screw, (provided in the mounting hardware packet). Make certain the thermostat assembly does not touch the brushholder spring and the cable is clear of any moving parts. Make certain the thermostat is assembled under the cable connections. (1/2" socket, ratchet, small extension).




10. Reposition the brush wraparound cover and tighten with the hardware removed in step 5. Keep the tightening flanges below the 3:00 position. (Large flat head screwdriver and pliers.)



11. Locate and remove 12-pin jumper plug and install 12-pin connector from control box to 12-pin connector. Connect control box 6-pin connector to control panel 6-pin connector. Connect control box 9-pin connector to control panel 9-pin connector.



12. Remove two (2) fuel tank hold down bolts on the right side of the machine and save hardware.



13. Position control box into place. On some models, the control box must be maneuvered out, up and back to clear the door latch catch. On SAE-300 4 plastic fuel tank mounting bolts require loosening to slide the tank towards the engine.




14. Mount the WFM using .62 spacers, flat washer, lock washer and hex nuts provided in the mounting hardware packet. Tighten all fuel tank bolts to rail.

15. Remove both the positive and negative output terminal bolts. (3/4" Socket wrench).



16. Using bolts from step 15, connect control box's positive and negative power cables and machine's positive and negative output cables to the respective output terminals. Tighten bolts. (3/4" Socket wrench).


NOTE: Use caution when routing the CV power cables; ensure that there is adequate clearance from any sharp surfaces.




17. Connect the remaining lead from the control box to CV output terminal, using bolt supplied with the output terminal assembly. Output panel leg attaches to the front of the machine (3/4" Socket wrench).

18. Drive three (3) self-tapping screws into output panel. (5/16" Nut driver or socket wrench).


NOTE: The CV output terminal assembly mounts under the weld output terminals on all machines.



19. With the CC/CV switch set to CC, start the engine and check the open circuit voltage on the output terminals. The voltage should be 80 to 100 volts with the thermostat and range switch set at maximum. **NOTE:** OCV may be slightly higher when the unit is cold. (Voltmeter)



20. Switch the CC/CV switch to CV and check the voltage between the Positive output terminal and the CV output terminal. The voltage should be 45 to 55 volts at maximum output position and 7 to 12 volts at minimum output position. (Voltmeter)



CONNECTION OF LINCOLN ELECTRIC WIRE FEEDERS

WARNING

Shut off welder before making any electrical connections.

Connection of LN-25 to the Wire Feed Module

The LN-25 with internal “COLD TIP” contactor requires the K444-2 Control Cable for voltage control at the feeder.

The LN-25 with internal “Cold Tip” Contactor can be operated without a control cable (Volt sensing mode) if voltage control at the wire feeder is not desired.

See the appropriated connection diagrams in the Diagrams section.

- a) Shut off the welder.
- b) Connect the electrode cable from the LN-25 to the positive stud of the welder. Connect the work cable to the CV negative stud of the welder. (**NOTE:** reverse the connections for negative electrode polarity.)
- c) For LN-25's with internal contactor, connect the K444-2 remote voltage control cable from the LN-25 to the 14-pin receptacle on the control panel.
- d) Attach the single lead from the front of the LN-25 to the work using the spring clip on the end of the lead. This is a control lead to supply current to the wire feeder motor; it does not carry welding current. Set the polarity switch on the LN-25 to the proper polarity.
- e) Set the “Current Range Selector” switch to the “190-120” position for most common processes, this may be changed if a different arc characteristic is preferred.
- f) Set the “LOCAL/REMOTE” Control switch to the “REMOTE” position. If operating an LN-25 with internal “Cold Tip” Contactor but without the K444-2 Remote Voltage Control Cable set the “Local/Remote” Control Switch to the “Local” position.
- g) Set the “IDLER” switch to the “HIGH” position. The “AUTO” position may be used with some high current processes.

Connection of the LN-7, LN-7 GMA to the Wire Feed Module

Requires K584-(L) input cable, K864 adapter and optionally the K857 for remote control. See the connection diagram in the Diagrams section.

- a) Shut the welder off.
- b) Connect the electrode cable from the LN-7 to the positive stud of the welder. Connect the work cable to the CV negative stud of the welder. (**NOTE:** Reverse the connections for negative electrode polarity.)
- c) Connect the LN-7 per the instructions on the appropriate connection diagram.
- d) Set the “Current Range” switch to the “190-120” position for most common processes, this may be changed if a different arc characteristic is desired.
- e) Set the “LOCAL/REMOTE” control toggle switch to “REMOTE”.
- f) Set the “IDLER” switch to the “AUTO” position. The “HIGH” position may be required when used with some low current processes.

Connection of the LN-23P to the Wire Feed Module

Requires the K350-1 adapter kit. Adapter kit provides an isolated trigger voltage and allows connection of two wire feeders. See connection diagram in the Diagrams section.

- a) Shut the welder off.
- b) Connect the electrode cable from the LN-23P to the CV negative output stud of the engine welder. Connect the work cable to the positive output stud.
- c) Mount K350-1 adapter per instructions included with adapter.
- d) Connect LN-23P per instructions on appropriate connection diagram.
- e) Connect control lead marked “21” to work connection. Refer to connection diagram in Diagrams section for routing instructions and wire size.
- f) Set the “Current Range Selector” switch to the “190-120” (middle position) for most common processes, this may be changed if a different arc characteristic is preferred.
- g) Set the “LOCAL/REMOTE” control toggle switch to “REMOTE”.
- h) Set the idler switch to the “AUTO” position. The “HIGH” position may be required when welding with low current processes.

OPERATING INSTRUCTIONS

Additional Safety Precautions

WARNING

The output terminals are energized when the engine is running. The CV output will be de-energized only if WFM mode switch is in remote position.

WIRE FEED MODULE OPERATION

Output

For constant voltage welding, place the CC/CV mode switch in the CV position. Connect the wire feeder to the CV negative output terminal and connect the work to the positive standard output terminal. For electrode positive, reverse the output leads. The negative standard output terminal is not used for CV welding of either polarity. Refer to diagrams section to determine the correct connection to the remote control receptacle.

When the WFM is in the "CV" mode, the maximum auxiliary power will be reduced by 25%. To obtain maximum auxiliary output, place the CC/CV switch in the CC position.

If the current rating of the welder is exceeded, a thermostat will reduce the output voltage to approximately 5 volts. The thermostat will reset automatically as the machine cools. If the thermostat trips, lower the wire feed speed and output voltage or reduce Duty Cycle.

Controls

The output voltage is set with the voltage control dial mounted on the control panel. Set the "Current Range Selector" to the "190-120" position for optimum welding characteristics. Changing the "Current Range Selector" affects arc characteristics. Setting the "Current Range Selector" one position to the right of the "190-120" position will give a softer arc. If this switch is placed one position to the left from the "190-120" set point, the machine will produce a crisp arc characteristic. The setting of the "Fine Current Adjustment" has no effect on the operation in "CV" mode.

For Coarse Current Control on the SAE-300 see operator manual.

Recommended Processes

Refer to latest Lincoln Bulletins on (Gas Metal Arc Welding) and (Innershield Welding) with the following electrodes:

.030" Super Arc L-50, 56 with C-25 or CO₂ Gas
.035" Super Arc L-50, 56 with C-25 or CO₂ Gas
.045" Super Arc L-50, 56 with C-25 or CO₂ Gas

.068" NR-203MP
5/64" NR-203MP
5/64" NR-207
5/64" NR-203Ni%

MAINTENANCE

Engine Speed Adjustments

CAUTION

Any increase in the engine RPM by changing the governor setting or overriding the throttle linkage will cause an increase in the A.C. auxiliary voltage. If this voltage goes above 140 volts, the control circuits of the WFM and wire feeders will be damaged. The engine governor setting is pre-set at the factory -- do not adjust above RPM specifications listed in the engine welder operating manual.

TROUBLESHOOTING CHART

WARNING

Have qualified personnel do the maintenance and troubleshooting work. Turn the engine off before beginning to troubleshoot.

TROUBLESHOOTING

TROUBLE	CAUSES	WHAT TO DO
1. Machine has no output with machine switch in CV mode.	<ul style="list-style-type: none"> a. Electrode or work lead loose or broken. b. No generator output. c. CR4 is not working, or no input to CR4. d. Protective circuits operating due to output short circuit. e. Broken or loose wiring connections. f. Defective P.C. Board 	<ul style="list-style-type: none"> a. Repair Connection. b. Refer to quick check procedure for generator only. c. Refer to procedure for Checking the Cold Tip Contactor (CR4). d. Turn engine off. Remove short circuit. e. Broken or loose connections from WFM to control panel and engine welder. Refer to wiring diagram to check. f. Refer to P.C. Board Troubleshooting Procedure.
2. Machine has minimum output and no control.	<ul style="list-style-type: none"> a. No shunt field voltage. b. Excessive current, thermal shutdown. c. Open in feedback circuitry. d. Voltage adjust potentiometer circuit open or misconnected. e. Defective P.C. Board. 	<ul style="list-style-type: none"> a. In CV mode, check for 10-60 VDC across pin 8 of J3 and pin 1 of J4 on WFM P.C. Board. -- Check for loose or broken connections in wiring harness. -- Refer to P.C. Board Troubleshooting Procedure. b. Remove load and allow machine to cool down. If output returns after cool down, reduce output or duty cycle. -- Check for continuity at quick connects between leads 609 and 608 inside the WFM. -- Check wiring harness with these connections. -- Check continuity of the thermostat located on the generator negative brushholder. c. Check in-line connector, P.C. Board, and wiring harness plugs, especially leads 667 and 621. d. Refer to procedure for checking Voltage Control Potentiometer on Machine. Check wiring of lead numbers 75, 76, and 77. e. Refer to P.C. Board Troubleshooting Procedure.

TROUBLESHOOTING

TROUBLE	CAUSES	WHAT TO DO
<p>3. Machine does not have maximum output.</p>	<p>a. Voltage adjust potentiometer leads open.</p> <p>b. Voltage adjust potentiometer defective.</p> <p>c. Faulty P.C. Board.</p>	<p>a. Check and repair broken leads.</p> <p>b. Refer to procedure for checking Voltage Control Potentiometer on Machine.</p> <p>c. Refer to Procedure for Replacing P.C. Boards.</p>
<p>4. Poor welding characteristics. Poor arc striking with sticking or "blast-offs", weld porosity, narrow and ropey looking bead, or electrode stubbing into the plate.</p>	<p>a. Poor work or electrode connection.</p> <p>b. Improper settings for wire feed speed and volts.</p> <p>c. Capacitor Bank Contactor not working.</p> <p>d. Capacitors in power source output circuit failed. A failure is indicated if the small vent plug on the top of a capacitor is raised or blown out.</p> <p>e. Opening in feedback circuit.</p> <p>f. Faulty P.C. Board.</p>	<p>a. Check and clean all connections.</p> <p>b. Refer to a welding procedures guide for proper settings.</p> <p>c. Refer to the procedure for Checking the Capacitor Bank Contactor CR3.</p> <p>d. Replace entire bank of capacitors, observe correct polarity. Do not replace individual capacitors. WARNING: The liquid electrolyte in these capacitors is toxic. Avoid contact with any portion of your body. Clean up vented electrolyte using rubber gloves and a water dampened cloth. Any electrolyte which gets on skin, clean with soap and water.</p> <p>e. Check wiring and P.C. Board wiring harness plugs. Pay special attention to leads 667 and 621.</p> <p>f. Refer to procedure for replacing P.C. Board.</p>

TROUBLESHOOTING PROCEDURES

A. P.C. Board Troubleshooting Procedures

Perform the following checks before replacing the P.C. Board.

1. Remove the cover to the Wire Feed Module box located on the right side of the machine. With the engine running the green and red LED on the P.C. Board must be glowing. If not, check the following:
 - a) Check for loose connections in the P.C. Board plugs, pay close attention to J3.
 - b) With machine running at high idle, check the following voltages accessible at P.C. Board plug J3:

<u>Lead Number</u>	<u>Voltage</u>
610 - 600	120 + 13/-10 Volts DC

If these voltages are not present, check the wiring connections between the engine welder and the Wire Feed Module. If wiring is good, then refer to the "Quick Check Procedure for Generator Only". If generator is operating properly, refer to "Procedure for Replacing P.C. Boards".

B. Procedures for Replacing P.C. Boards

Before replacing a P.C. Board which is suspected of being defective, visually inspect the P.C. Board in question for any electrical or mechanical damage to any of its components and conductors on the back of the board.

1. If there is no visible damage to the P.C. Board, install a new one and see if this remedies the problem. If the problem is remedied, reinstall the old P.C. Board to see if the problem still exists. If it does no longer exist with the old P.C. Board:
 - a) Check the P.C. Board harness connector pins for corrosion, contamination, or looseness.
 - b) Check leads in the plug harness for loose or intermittent connection.
2. If P.C. Board is visibly damaged electrically, before possibly subjecting the new P.C. Board to the same cause of failure, check for possible shorts, opens, or grounds caused by:
 - a) Frayed or pinched lead insulation.

- b) Poor lead termination, such as a poor contact or a short to adjacent connection or surface.
 - c) Shorted or open leads, or other external leads.
 - d) Foreign matter or interference behind the P.C. Boards.
3. If P.C. Board is visibly damaged mechanically, inspect for cause then remedy before installing a replacement P.C. Board.

If there is damage to the P.C. Board or if replacing P.C. Board corrects problem, return it to the local Lincoln Electric Field Service Shop.

C. Output Voltage

Constant Voltage Mode -- The open circuit voltage in CV mode is 7-55 volts DC. If any other conditions exist, refer to the Troubleshooting Chart.

D. Procedure for Checking the Cold Tip Contactor (CR4)

1. If there is no output during the initial start up of the machine, check to see if the "Local/Remote" switch is in "LOCAL", if so, switch to "REMOTE" and then back to "LOCAL" and check for output voltage. If switch is in "Remote" switch to the "LOCAL" position and check for output voltage.
2. Open side panel of wire feed module. With machine running, verify the P.C. Board is working by checking to see if the green and red LED's are on. If LED's are not on, see P.C. Board Troubleshooting Procedures. If the LED's are on, check the voltage between the top left stud of the cold tip contactor (CR4) and the positive output stud. The voltage should measure between 7 and 55 volts DC depending on the position of the CV voltage control setting. Try adjusting the voltage control to see if this voltage changes. If voltage is present, go to step 3. If no voltage is present, check for loose cable or wiring connections. If voltage is still not present, refer to Troubleshooting Chart.

3. Check to see that leads 2 and 4 are connected. Put a voltmeter across these leads and the meter should read close to zero volts. If voltage reads approximately 15 volts, then the trigger circuit (leads 2-4) is open. Check the wiring from the WFM control box to the WFM control panel for loose or broken connections. Turn machine off and check the operation of the "LOCAL/REMOTE" switch by connecting an ohmmeter across leads 2 and 4 at the switch with switch positioned in "LOCAL" mode, if resistance is high or open replace the switch.
4. Check for coil voltage across leads 633 and 634 at P2 plug to the P.C. Board. If voltage is present, check for loose or broken leads from the plug to the contactor coil. If connections are good and voltage correct, replace contactor CR4.
5. If no voltage is present at CR4 contactor coil, see Procedure for Replacing P.C. Boards.

E. Procedure for Checking the Capacitor Bank Contactor (CR3)

1. Verify machine is in CV (wire) mode. Measure voltage across leads 630 and 631 at the contactor. The voltage should be approximately 120 +/- 15V DC with engine set on high idle. If voltage is not present, go to step 3 of this procedure.
2. If the proper voltage is present at leads 630 - 631, measure the voltage between L2 terminal and terminal opposite L2. If the voltage is equal to the output voltage across the positive and negative output terminals, replace the contactor CR3.
3. If the proper voltage is not present at leads 630 - 631, check the wiring to CR3 coil for loose or broken connections. If connections are good, see Procedure for Replacing P.C. Boards.

F. Checking Voltage Control Potentiometer on Machine

1. Turn machine off.
2. Remove the control panel screws and open the front cover. Turn the "LOCAL/REMOTE" switch (S2) to "REMOTE".

3. Disconnect P.C. Board harness plug P2 from the P.C. Board.
4. With an ohmmeter on X1K, connect it to lead 76A and 77A on S2. Rotate the voltage control potentiometer. The resistance reading should be from approximately zero to 10K ohms. Check the resistance reading between lead 75 on potentiometer and 77A on switch S2. The reading must be 10K ohms. No reading will indicate an open potentiometer and a low reading will indicate a shorted or partially shorted potentiometer; in either case, replace. Reconnect P.C. Board plug P2.


G. Remote Control Check

1. The remote control connector pin assignments are: pin G-75A, pin F-76B, pin E-77B. Make sure remote control connections are tight and check for any physical damage to the control cable. Connect an ohmmeter across lead 75 and 76B on switch S2. With S2 in remote mode, rotate the potentiometer in the remote control. The resistance reading should vary from zero to 10K ohms. Repeat with ohmmeter across 77B and 76B with the same results. Connect an ohmmeter across 75 and 77B. The reading should be 10K ohms. If an open or short is measured replace the potentiometer.

H. Quick Check Procedure for Generator Only


1. Try running the machine with the mode switch on STICK (CC mode), and check output at CC+ and CC- studs. If a voltage of 45 to 100 volts DC is measured, the generator is working properly. If the generator is working properly, the problem exists in the Wire Feed Module. Refer to Troubleshooting chart.
2. If there is no generator output in step 1, proceed with the following:
 - a) If jumper plug P10 is available, a quick check can be performed to see if the generator is operating properly. Disconnect P5 and connect P10. When P10 is connected, the machine will only run in Stick (CC mode). If generator voltage is present between CC+ and CC- studs, then the generator is operating properly.
 - b) The measured voltage should be between 43-100 volts DC. This level may be higher when the machine is cold. If the generator is operating properly, disconnect P10 and reconnect P5. Refer to Wire Feed Module Troubleshooting chart.
3. If the generator is not working with the jumper plug P10, then refer to the engine welder Troubleshooting chart.

WIRE FEED MODULE - WIRING DIAGRAM



NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

WIRE FEED MODULE / ENGINE WELDER CONNECTION DIAGRAM



CAUTION: THIS UNIT IS PREASSEMBLED WITH A 250 AMP THERMOSTAT ASSEMBLY. INSTALLING THIS UNIT INTO A CLASSIC 1 OR ANY 200 AMP MACHINE REQUIRES REPLACEMENT OF THE 250 AMP THERMOSTAT AS'BLY WITH THE 200 AMP THERMOSTAT AS'BLY PROVIDED IN THE MOUNTING HARDWARE PACKET.


★ **MACHINE MUST NOT BE RUNNING WHEN MAKING THESE CONNECTIONS.**

3-18-94
M17220

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

CONNECTION DIAGRAM: COMMANDER 400 S & W, CLASSIC II, III, IIID, 300D, 300G, SA-250, 350A & SAE-300 ENGINE WELDERS WITH WIRE FEED MODULE TO LN-23P WITH ADAPTER KIT

WARNING



- Turn off input power to the Welding Power Source using the disconnect switch at the fuse box Before connecting the wire feeder.
- Only qualified persons should install, use or service this machine.

ELECTRIC SHOCK CAN KILL

N.A. WELDING CABLES MUST BE OF PROPER CAPACITY FOR THE CURRENT AND THE DUTY CYCLE OF IMMEDIATE AND FUTURE APPLICATIONS. SEE LN-23P OPERATING MANUAL FOR PROPER SIZES.


N.B. IF ONLY ONE LN-23P IS USED, CONNECT TO FEEDER "A" TERMINAL STRIP IN ADAPTER.

N.C. REMOTE VOLTAGE SENSING LEAD TO BE EXTENDED BY CUSTOMER DIRECTLY TO WORK USING #12 OR LARGER RUBBER COVERED FLEX WIRE. WRAP WIRE AROUND WORK LEAD AND TAPE.

N.D. BOLT AND TAPE CONNECTION.

N.E. MOUNT ADAPTER IN A CONVENIENT LOCATION - AS NOT TO INTERFERE WITH THE NORMAL MACHINE OPERATION.


CAUTION: WHEN MOUNTING ADAPTER TO WELDER, SPECIAL CARE IS TO BE TAKEN AS NOT TO DAMAGE ANY MACHINE COMPONENTS, SUCH AS/BUT NOT LIMITED TO ELECTRICAL COMPONENTS, WIRES OR FUEL TANKS.



M17323

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.


CONNECTION DIAGRAM: CLASSIC II, III, IIID, 300G, SA-250, 350SA & SAE-300 ENGINE WELDERS WITH WIRE FEED MODULE TO K867 PLUG TO LN-7.



S21036

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

CONNECTION DIAGRAM: CLASSIC II, III, IIID, 300G, 300G, SA-250, 350SA & SAE-300 ENGINE WELDERS WITH WIRE FEED MODULE TO K864 ADAPTER TO LN-7 & REMOTE CONTROL




- N.A. WELDING CABLE MUST BE SIZED FOR CURRENT AND DUTY CYCLE OF APPLICATION.
- N.B. DIAGRAM SHOWS ELECTRODE POSITIVE. TO CHANGE POLARITY, TURN POWER "OFF", REVERSE ELECTRODE AND WORK CABLE AT POWER SOURCE.
- N.C. WHEN MACHINE IS IN "REMOTE" MODE, A K857 MUST BE USED.
- N.D. WELDER OUTPUT STUDS ON THE OPPOSITE SIDE FOR CLASSIC II.
- N.E. IF MACHINE IS IN "LOCAL" MODE, GUN IS ALWAYS "HOT".

S21037

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.


CONNECTION DIAGRAM: ALL CLASSIC, ALL PIPELINER, SA-250, 350SA & SAE-300 ENGINE WELDERS WITH WIRE FEED MODULE TO K867 UNIVERSAL ADAPTER



S21038

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.


CONNECTION DIAGRAM: ALL CLASSIC, ALL PIPELINER, SA-250, 350SA & SAE-300 ENGINE WELDERS WITH WIRE FEED MODULE TO LN-25 WITH K444-2 OPTION



S21039

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

CONNECTION DIAGRAM: CLASSIC II, III, IIID, 300D, 300G, SA-250, 350SA & SAE-300 ENGINE WELDERS WITH WIRE FEED MODULE TO LN-25 WITH K431, K433 & K432-"L" OPTION




- N.A. WELDING CABLE MUST BE SIZED FOR CURRENT AND DUTY CYCLE OF APPLICATION.
- N.B. DIAGRAM SHOWS ELECTRODE POSITIVE. TO CHANGE POLARITY, TURN POWER "OFF", REVERSE ELECTRODE AND WORK CABLES AT POWER SOURCE, SWITCH LN-25 POLARITY SWITCH.
- N.C. WELDER OUTPUT STUDS ON OPPOSITE SIDE FOR CLASSIC II.
- N.D. MOUNT K433 TO ENGINE WELDER PER INSTRUCTIONS PACKAGED WITH K433.
- N.E. INSULATE EACH UNUSED LEAD INDIVIDUALLY.
- N.F. SPLICE LEADS AND INSULATE.

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

S21053

CONNECTION DIAGRAM: CLASSIC II. III, IIID, 300D, 300G, SA-250, 350SA & SAE-300 ENGINE WELDERS WITH WIRE FEED MODULE TO K867 PLUG TO K487 / K488 / K492 SPOOL GUN




S21268

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

CLASSIC I and PIPELINER 200D and 200G with WIRE FEED MODULE

Reference Output Curves


For Selected Open Circuit Volts (OCV) at Wire Feeder



CLASSIC II with WIRE FEED MODULE

Reference Output Curves


For Selected Open Circuit Volts (OCV) at Wire Feeder



CLASSIC III and 300G with WIRE FEED MODULE

Reference Output Curves


For Selected Open Circuit Volts (OCV) at Wire Feeder



CLASSIC IIID, CLASSIC 300D, SA250 and SAE-300
(CODES 10890 and above) with WIRE FEED MODULE


Reference Output Curves

For Selected Open Circuit Volts (OCV) at Wire Feeder



350 SA and SA-250 (CODES 10889 AND BELOW) with WIRE FEED MODULE

Reference Output Curves For Selected Open Circuit Volts (OCV) at Wire Feeder



NOTES

WIRE FEED MODULE



NOTES

WIRE FEED MODULE



			
WARNING	<ul style="list-style-type: none"> Do not touch electrically live parts or electrode with skin or wet clothing. Insulate yourself from work and ground. 	<ul style="list-style-type: none"> Keep flammable materials away. 	<ul style="list-style-type: none"> Wear eye, ear and body protection.
Spanish AVISO DE PRECAUCION	<ul style="list-style-type: none"> No toque las partes o los electrodos bajo carga con la piel o ropa mojada. Aíslese del trabajo y de la tierra. 	<ul style="list-style-type: none"> Mantenga el material combustible fuera del área de trabajo. 	<ul style="list-style-type: none"> Protéjase los ojos, los oídos y el cuerpo.
French ATTENTION	<ul style="list-style-type: none"> Ne laissez ni la peau ni des vêtements mouillés entrer en contact avec des pièces sous tension. Isolez-vous du travail et de la terre. 	<ul style="list-style-type: none"> Gardez à l'écart de tout matériel inflammable. 	<ul style="list-style-type: none"> Protégez vos yeux, vos oreilles et votre corps.
German WARNUNG	<ul style="list-style-type: none"> Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung! Isolieren Sie sich von den Elektroden und dem Erdboden! 	<ul style="list-style-type: none"> Entfernen Sie brennbares Material! 	<ul style="list-style-type: none"> Tragen Sie Augen-, Ohren- und Körperschutz!
Portuguese ATENÇÃO	<ul style="list-style-type: none"> Não toque partes elétricas e electrodos com a pele ou roupa molhada. Isole-se da peça e terra. 	<ul style="list-style-type: none"> Mantenha inflamáveis bem guardados. 	<ul style="list-style-type: none"> Use proteção para a vista, ouvido e corpo.
Japanese 注意事項	<ul style="list-style-type: none"> ● 通電中の電気部品、又は溶材にヒフやぬれた布で触れないこと。 ● 施工物やアースから身体が絶縁されている様にして下さい。 	<ul style="list-style-type: none"> ● 燃えやすいものの側での溶接作業は絶対にしてはなりません。 	<ul style="list-style-type: none"> ● 目、耳及び身体に保護具をして下さい。
Chinese 警告	<ul style="list-style-type: none"> ● 皮肤或湿衣物切勿接触带电部件及焊条。 ● 使你自已与地面和工件绝缘。 	<ul style="list-style-type: none"> ● 把一切易燃物品移离工作场所。 	<ul style="list-style-type: none"> ● 佩戴眼、耳及身体劳动保护用具。
Korean 위험	<ul style="list-style-type: none"> ● 전도체나 용접봉을 젖은 헝겍 또는 피부로 절대 접촉치 마십시오. ● 모재와 접지를 접촉치 마십시오. 	<ul style="list-style-type: none"> ● 인화성 물질을 접근시키지 마십시오. 	<ul style="list-style-type: none"> ● 눈, 귀와 몸에 보호장구를 착용하십시오.
Arabic تحذير	<ul style="list-style-type: none"> ● لا تلمس الاجزاء التي يسري فيها التيار الكهربائي أو الألكترود بجلد الجسم أو بالملابس المبللة بالماء. ● وضع عازلا على جسمك خلال العمل. 	<ul style="list-style-type: none"> ● ضع المواد القابلة للاشتعال في مكان بعيد. 	<ul style="list-style-type: none"> ● ضع أدوات وملابس واقية على عينيك وأذنيك وجسمك.

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HERSTELLERS. DIE UNFALLVERHÜTUNGSVORSCHRIFTEN DES ARBEITGEBERS SIND EBENFALLS ZU BEACHTEN.

			
<ul style="list-style-type: none"> • Keep your head out of fumes. • Use ventilation or exhaust to remove fumes from breathing zone. 	<ul style="list-style-type: none"> • Turn power off before servicing. 	<ul style="list-style-type: none"> • Do not operate with panel open or guards off. 	WARNING
<ul style="list-style-type: none"> • Los humos fuera de la zona de respiración. • Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases. 	<ul style="list-style-type: none"> • Desconectar el cable de alimentación de poder de la máquina antes de iniciar cualquier servicio. 	<ul style="list-style-type: none"> • No operar con panel abierto o guardas quitadas. 	Spanish AVISO DE PRECAUCION
<ul style="list-style-type: none"> • Gardez la tête à l'écart des fumées. • Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail. 	<ul style="list-style-type: none"> • Débranchez le courant avant l'entretien. 	<ul style="list-style-type: none"> • N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés. 	French ATTENTION
<ul style="list-style-type: none"> • Vermeiden Sie das Einatmen von Schweißrauch! • Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes! 	<ul style="list-style-type: none"> • Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öffnen; Maschine anhalten!) 	<ul style="list-style-type: none"> • Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen! 	German WARNUNG
<ul style="list-style-type: none"> • Mantenha seu rosto da fumaça. • Use ventilação e exaustão para remover fumo da zona respiratória. 	<ul style="list-style-type: none"> • Não opere com as tampas removidas. • Desligue a corrente antes de fazer serviço. • Não toque as partes elétricas nuas. 	<ul style="list-style-type: none"> • Mantenha-se afastado das partes moventes. • Não opere com os painéis abertos ou guardas removidas. 	Portuguese ATENÇÃO
<ul style="list-style-type: none"> ● ヒュームから頭を離すようにして下さい。 ● 換気や排煙に十分留意して下さい。 	<ul style="list-style-type: none"> ● メンテナンス・サービスに取りかかる際には、まず電源スイッチを必ず切して下さい。 	<ul style="list-style-type: none"> ● パネルやカバーを取り外したまま機械操作をしないで下さい。 	Japanese 注意事項
<ul style="list-style-type: none"> ● 頭部遠離煙霧。 ● 在呼吸區使用通風或排風器除煙。 	<ul style="list-style-type: none"> ● 維修前切斷電源。 	<ul style="list-style-type: none"> ● 儀表板打開或沒有安全罩時不準作業。 	Chinese 警告
<ul style="list-style-type: none"> ● 얼굴로부터 용접가스를 멀리하십시오. ● 호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시오. 	<ul style="list-style-type: none"> ● 보수전에 전원을 차단하십시오. 	<ul style="list-style-type: none"> ● 판넬이 열린 상태로 작동치 마십시오. 	Korean 위험
<ul style="list-style-type: none"> ● ابعدها رأسك بعيداً عن الدخان. ● استعمل التهوية أو جهاز ضغط الدخان للخارج لكي تبعد الدخان عن المنطقة التي تتنفس فيها. 	<ul style="list-style-type: none"> ● اقطع التيار الكهربائي قبل القيام بأية صيانة. 	<ul style="list-style-type: none"> ● لا تشغيل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه. 	Arabic تحذير

LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的說明以及應該使用的銀焊材料，並請遵守貴方的有閣勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.



• World's Leader in Welding and Cutting Products •

• Sales and Service through Subsidiaries and Distributors Worldwide •

Cleveland, Ohio 44117-1199 U.S.A. TEL: 216.481.8100 FAX: 216.486.1751 WEB SITE: www.lincolnelectric.com

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>