

MAGNAVOX

PRI909B / PRI907X

Owner's Manual (Use and Setup Guide)




TABLE OF CONTENTS

Getting Started

Warning/Precautions	1
Features	1
Registration	1
Hooking Up Your TV (Antenna/Cable Connections)	2-3
VCR Connections	3
First Time Setup	4
Basic TV and Remote Control Operation	4

On-screen Features

Automatic Channel Setup	5
Save/Delete Channels	5
Channel Review	5
Language Selection	5
Channel Reminder	5
Volume Bar	6
Sleep Timer	6
SmartLock	6
Picture Adjustments	7
Closed Captioning	7

General Information

Glossary	7
Tips	8
Index	8
Warranty	8

Federal Communications Commission
Warning: Any unauthorized changes or modifications to this equipment void the user's authority to operate it.

For Customer Use

Enter below the Serial Number and the Model Number of this television (located on the back of the TV). Keep this information for future reference.

Model No. _____
Serial No. _____

This manual, your new product, and the packaging contain materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount that needs to be disposed properly. Your product uses batteries that should not be thrown away when depleted but should be disposed as small chemical waste.

Please find out about the local regulations on disposal of your old product, batteries, manual, and packaging whenever you replace existing equipment.

FEATURES

- **First Time Setup** automatically sets the TV for local channels and the correct picture signal (antenna or cable).
- **Infrared Remote Control** operates your TV and helps you set up on-screen features.
- **Standard Broadcast (VHF/UHF) or Cable TV (CATV) channel capability**
- **Closed Captioning** allows you to read TV program dialogue as on-screen text.
- **Automatic Channel Setup** quickly and easily selects stations available in your area.
- **Sleep Timer** automatically turns the TV OFF at preset times.
- **Language Selection** allows you to choose English or Spanish on-screen menus. This does not affect the language of Closed Captioning.
- **Automatic Shut Off** turns off the TV after 15 minutes when it is on a channel that is not receiving a broadcast signal (for example, if a station has gone off the air for the night).



This owner's manual is made of recycled paper.



Return your Warranty Registration card today to ensure you receive all the benefits you're entitled to.

Once your PHILIPS MAGNAVOX purchase is registered, you're eligible to receive all the privileges of owning a PHILIPS MAGNAVOX product. So complete and return the Warranty Registration Card enclosed with your purchase at once. And take advantage of these important benefits.

Warranty Verification

Registering your product within 10 days confirms your right to maximum protection under the terms and conditions of your PHILIPS MAGNAVOX warranty.

Owner Confirmation

Your completed Warranty Registration Card serves as verification of ownership in the event of product theft or loss.

Model Registration

Returning your Warranty Registration Card right away guarantees you'll receive all the information and special offers which you qualify for as the owner of your model.

Congratulations on your purchase, and welcome to the "family!"

PHILIPS MAGNAVOX



Dear PHILIPS MAGNAVOX product owner:

Thank you for your confidence in PHILIPS MAGNAVOX. You've selected one of the best-built, best-backed products available today. And we'll do everything in our power to keep you happy with your purchase for many years to come.

As a member of the PHILIPS MAGNAVOX "family," you're entitled to protection by one of the most comprehensive warranties and outstanding service networks in the industry.

What's more, your purchase guarantees you'll receive all the information and special offers for which you qualify, plus easy access to accessories from our convenient home shopping network.

And most importantly you can count on our uncompromising commitment to your total satisfaction.

All of this is our way of saying welcome—and thanks for investing in a PHILIPS MAGNAVOX product.

Sincerely,

Robert Minkhorst
President and Chief Executive Officer

P.S. Remember, to get the most from your PHILIPS MAGNAVOX product, you must return your Warranty Registration Card within 10 days. So please mail it to us right now!

Know these
safety symbols



This "bolt of lightning" indicates uninsulated material within your unit which may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

CAUTION: To prevent electric shock, match wide blade of plug to wide slot and fully insert.

ATTENTION: Pour éviter les choc électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

PHILIPS MAGNAVOX Visit our World Wide Web Site at <http://www.philipsmagnavox.com>

HOOKING UP YOUR TV (ANTENNA/CABLE CONNECTIONS)

ANTENNA

BEGIN

COMBINATION UHF/VHF
A combination antenna receives normal broadcast channels (VHF 2-13 and UHF 14-69). Your connection is easy since there is only one 75Ω (ohm) antenna jack on the back of your TV - and that's where the antenna goes.


1 If your antenna has a round connector (75Ω), then you're ready to connect it to the TV.
If your antenna has flat twin-lead wire (300Ω), you first need to attach the antenna wires to the screws on a 300 to 75Ω adaptor.

2 Push the round end of the adaptor (or cable) onto the ANT(enna) IN jack on the back of the TV. If the round end of the adaptor or cable is threaded, screw it down tight.

STOP

SMART HELP

To set the TV to select only the channel numbers in your area, see First Time Setup on page 4.



HOOKING UP YOUR TV (ANTENNA/CABLE CONNECTIONS) (CONT'D)

VCR TO TV

BEGIN

BASIC CONNECTION


The basic Antenna/Cable to VCR to TV connection is shown here. If you have a Cable Box, refer to the VCR owner's manual for details.

1 Connect your Antenna or Cable signal to the IN FROM ANT(enna) jack on the VCR.

2 Connect a coaxial cable to the OUT TO TV jack on the VCR and to the ANT(enna) IN jack on the TV. The coaxial cable may be supplied with the VCR.

3 Refer to the VCR owner's manual for other possible connections and for operating details.

STOP



SEPARATE UHF/VHF

You may have two separate antennas. One antenna is for VHF channels (2-13) and the other antenna is for UHF channels (14-69). For homes with separate UHF/VHF antennas, you will need an optional combiner before you can connect the antennas to the TV.


1 Attach the separate UHF and VHF antennas to the correct screws on the combiner.

2 Push the round end of the combiner onto the ANT(enna) IN jack on the back of the TV.

STOP

SMART HELP

To order any optional accessory, contact your dealer or call 1-800-851-8885.
• UHF/VHF Combiner: 4835 466 97016
• 75-300Ω Adaptor: M61009
• 300-75Ω Adaptor: 4835 218 27003



CABLE TV

BEGIN

CABLE/CABLE BOX

Your Cable TV signal may be a single (75Ω) cable or a Cable Box installation. In either case, the connection to the TV is very easy.

1 If you do not have a Cable Box, then you're ready to connect your Cable TV signal to the TV.
If you have a Cable Box: Connect the Cable TV signal to the IN jack on the Cable Box.


2 Connect the Cable TV signal to the ANT(enna) IN jack on the TV.
If you have a Cable Box: Use a coaxial cable to connect the OUT jack of the Cable Box to the ANT(enna) IN jack on the TV.
NOTE: The coaxial cable might be supplied by the Cable TV company.

STOP

SMART HELP

To select only the channels on your Cable system, see First Time Setup (page 4). If you use a Cable Box, set the TV to the same channel as the CH 3/4 switch on the back of the Cable Box.

Note to the Cable TV System Installer: This reminder is provided to call the Cable TV system installer's attention to Article 820-40 of the National Electrical Code, which provides guidelines for proper grounding - in particular, specifying that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as possible.



HOW TO SET UP AND USE YOUR TV

ON-SCREEN FEATURES

MENU

FIRST TIME SETUP
First Time Setup takes care of some basic TV settings for you. Follow these steps:

- to set the language of the TV's on-screen menu, and
- to quickly add area channels into the TV's memory.

BEGIN

- Press the **POWER** button to turn ON the TV. The language selection menu appears on the TV screen.
- Press the **CH(annel) ▲/▼** buttons to select English or Spanish menus. Then, press the **MENU** button.
- Press the **VOL(ume) ►** button to begin automatic channel setup. When setup is complete, "CHANNELS ARE SET" will appear on the screen.

STOP

If you do not want to set up channels now, press the **STATUS/EXIT** button.

The menu shown at step 1 will appear only the first time you turn on the TV. If it does not appear, follow the instructions on page 5 to select a language and set up channels.

If you have not connected the antenna or cable to the TV, an on-screen message will prompt you to do so. You may need to follow the steps for Automatic Channel Setup on page 5 in order to finish setting the channels available in your area.

REMOTE

To load the batteries into the remote:

- Slide off the battery compartment lid on the remote control.
- Insert two AA batteries (supplied) into the battery compartment as indicated inside the compartment. Batteries installed incorrectly may damage the remote control.
- Replace the lid.

BEGIN

- Point the remote control toward the remote sensor on the TV when operating the TV with the remote.

POWER Button
Press to turn the TV ON and OFF.

MENU Button
Press to access the on-screen menu. Press the CH(annel) ▲/▼ buttons to select an item in the menu. Press the VOL(ume) ►/◄ buttons to adjust an item in the menu or to advance to the next menu.

Number Buttons
Press to select channels.

- Cable Users**
Enter channel numbers as a two-digit number for the quickest results. For example, to select channel 6, press 0,6. If you only press the Number 6 button, channel 6 will be selected after a brief delay. (There also may be a brief delay when you select channels 10, 11, and 12.) If you want to select channels 100 and above, enter channel numbers as a three-digit number. For example, to select channel 117, press 1, 1, 7.
- Antenna Users**
Enter channel numbers as a two-digit number for the quickest results. You may only select channels 2-69. For example, to select channel 5, press 0,5. If you only press the Number 5 button, channel 5 will be selected after a brief delay.

SLEEP Button
Press to set the TV to turn itself OFF automatically. Details are on page 6.

CH(annel) ▲/▼ Buttons
Press to scan through programmed channel numbers. Press to select an item in the on-screen menu.

VOL(ume) ►/◄ Buttons
Press to adjust the TV sound level. Press to adjust an item in the on-screen menu, or to advance to the next menu, or to return to a previous menu.

MUTE Button
Press to turn OFF the sound on the TV. Press again to return the sound to its previous level.

STATUS/EXIT Button
Press to see the current channel number on the TV screen. Press to remove the on-screen menu. You also may remove the menu by pressing the CH(annel) ▲/▼ buttons to select EXIT, then pressing the VOL(ume) ► button.

ALT.CH (Alternate Channel) Button
Press to return to the TV channel you were viewing immediately before switching to your current channel.

TELEVISION

BEGIN

- Press the **POWER** button to turn ON the TV. Be sure to connect the TV power cord to a standard AC outlet.
- Press the **VOLUME ▲/▼** buttons to adjust the sound level.
- Press the **CHANNEL ▲/▼** buttons to select TV channels.
- Press the **MENU** button to display the TV's on-screen menu. Press the **CHANNEL ▲/▼** buttons to select an item in the menu. Press the **VOLUME ▲/▼** buttons to adjust an item in the menu or to advance to the next menu.

STOP

SMART HELP
The current channel number will appear briefly when the TV is first turned ON and with channel changes. To display the channel number for five seconds, press the **STATUS/EXIT** button. Or, to remove the channel number, press the **CHANNEL ▲/▼** buttons to select EXIT. Then, press the **VOLUME ▲** button.

Note:
You can connect earphones (not supplied) to the **EARPHONE** jack on the front of the TV for private, personal listening.

CHANNEL

BEGIN

AUTOMATIC CHANNEL SETUP
Although the TV can memorize channels when you first turn it on, you may want to set up or reprogram channels by following these steps.

- Press the **MENU** button, then press the **CH(annel) ▲/▼** buttons to select **SETUP**. Then, press the **VOL(ume) ►** button.
- Press the **CH(annel) ▲/▼** buttons to select **AUTO PROGRAMMING**.
- Press the **VOL(ume) ►** button to begin automatic channel setup. When setup is complete, "CHANNELS ARE SET" will appear on the screen.

STOP

SAVE/DELETE CHANNELS

BEGIN

Automatic Channel Setup (see above) adds all the channels it can find (on your Antenna or Cable TV system) into the TV's memory. Save/Delete channels makes it easy for you to add other channels or drop unwanted channels from the TV's memory.

- Press the **MENU** button, then press the **CH(annel) ▲/▼** buttons to select **CHANNEL**.
- Press the **Number** buttons to select the channel you want to **SAVE** (or **DELETE**).
- Press the **VOL(ume) ►/◄** buttons to select **SAVED** (to add the channel) or **DELETED** (to delete the channel).
- Press the **STATUS/EXIT** button when you finish adding (or deleting) all the channels you want.

STOP

CHANNEL REVIEW

BEGIN

To review the channels programmed into the TV's memory, follow these steps.

- Press the **MENU** button, then press the **CH(annel) ▲/▼** buttons to select **SETUP**. Then, press the **VOL(ume) ►** button.
- Press the **CH(annel) ▲/▼** buttons to select **CH MEMORY REVIEW**. Then, press the **VOL(ume) ►** button. A list of programmed channels will appear on the screen for 10 seconds.
- Press the **STATUS/EXIT** button once or twice when you are finished.

STOP

SMART HELP
If all the programmed channels don't fit on the screen, press the **VOL(ume) ►** button to see the remaining channels. If you do not press the **VOL(ume) ►** button within 10 seconds, the remaining channels will appear on the screen automatically. When all channels have been displayed, the **SETUP** menu will reappear.

LANGUAGE

BEGIN

LANGUAGE SELECTION
Follow these steps to change the language of the on-screen menus.

- Press the **MENU** button, then press the **CH(annel) ▲/▼** buttons to select **SETUP**. Then, press the **VOL(ume) ►** button.
- Press the **CH(annel) ▲/▼** buttons to choose **SELECT LANGUAGE**. Then, press the **VOL(ume) ►** button.
- Press the **CH(annel) ▲/▼** buttons to select **ENGLISH** or **ESPAÑOL** (Spanish).
- Press the **STATUS/EXIT** button.

STOP

SMART HELP
If you accidentally chose Spanish and need English: 1) Press the **MENU** button. 2) Press the **CH(annel) ▲/▼** buttons to select **PREPARACION**, then press the **VOL(ume) ►** button. 3) Press the **CH(annel) ▲/▼** buttons to choose **SELECCION IDIOMA**, then press the **VOL(ume) ►** button. 4) Press the **CH(annel) ▲/▼** buttons to select **ENGLISH**. 5) Press the **STATUS/EXIT** button.

REMINDER

BEGIN

CHANNEL REMINDER
The channel number will remain on the screen at all times when you set **REMINDER** to ON.

- Press the **MENU** button, then press the **CH(annel) ▲/▼** buttons to select **REMINDER**.
- Press the **VOL(ume) ►/◄** buttons so that **ON** or **OFF** appears to the right of **REMINDER**.
- Press the **STATUS/EXIT** button.

STOP

SMART HELP
The channel number will not remain on the screen if a Closed Captioning mode is selected. **CAPTION** must be set to **OFF**. Details are on page 7.

ON-SCREEN FEATURES (CONT'D)

VOLUME BAR

BEGIN

- 1 Press the **MENU** button, then press the **CH(annel)** ▲/▼ buttons to select **VOLUME BAR**.
- 2 Press the **VOL(ume)** ►/◄ buttons so that **ON** or **OFF** appears beside **VOLUME BAR**.
- 3 Press the **STATUS/EXIT** button.

STOP

SMART HELP

Try it out. Press the **VOL(ume)** ►/◄ buttons. The **VOLUME BAR** should appear on the screen.

To avoid delays in Closed Captioning when you adjust or mute the volume, set the **VOLUME BAR** to **OFF**.

SLEEP TIMER

BEGIN

- 1 Press the **SLEEP** button repeatedly to pick the amount of time (30 minutes to 120 minutes) before the TV turns itself off. The length of time will appear on the screen. One minute before the TV shuts itself off, the seconds will count down on the screen. **GOOD NIGHT** appears on the TV screen 10 seconds before the TV shuts itself off.

STOP

SMART HELP

To see how many minutes remain before the TV shuts itself off, press the **SLEEP** button once.

To cancel a **SLEEP TIMER** setting, press the **SLEEP** button repeatedly until **SLEEP 0 MIN** appears on the screen.

SMARTLOCK

BEGIN

- 1 Press the **MENU** button, then press the **CH(annel)** ▲/▼ buttons to select **SMARTLOCK**. Then, press the **VOL(ume)** ► button.
- 2 Use the **Number** buttons to enter your access code. The default code is 0711. If you have not set up your personal access code, you should use 0711.
- 3 Press the **CH(annel)** ▲/▼ buttons to select **BLOCK**. Then, press the **VOL(ume)** ► button.
- 4 Press the **CH(annel)** ▲/▼ buttons to select **Movie Ratings** or **Parental Guidelines**. Then, press the **VOL(ume)** ► button.
- 5 Press the **CH(annel)** ▲/▼ buttons to select the rating you want to block. Then, press the **VOL(ume)** ► button so that **ON** appears beside the rating. For example, if you set **PG** to **ON**, you may not view **PG** programming because the block is on. Programs with a **PG** or higher rating will be blocked.
- 6 Press the **STATUS/EXIT** button.

STOP

SMART HELP

To check the **SmartLock** settings, press the **MENU** button, then press the **CH(annel)** ▲/▼ buttons to select **REVIEW**. Press the **VOL(ume)** ► button so that the **SmartLock** settings appear. Ratings that are blocked will appear on the screen. An "X" will appear if a specific rating is blocked, such as **V** for **Violence** in the **TV-14** category.

If the "Incorrect Access Code..." message appears after step 2, enter the correct access code. In order to protect the privacy of the access code, an **X** will appear on the screen instead of the number you enter.

A "CHANNEL XX BLOCKED..." message will appear when someone tries to access the blocked programming. If you want to view this programming, enter your access code. The channel will remain blocked until you enter the correct code. If you do not know the code, you will have to select another channel. When you turn off the TV once, the programming is blocked again.

RATING EXPLANATIONS

- **V**-Violence
- **S**-Sexual situations
- **L**-Language
- **D**-Inappropriate dialogue
- **FV**-Fantasy Violence may frighten children under seven; **TV-Y7** category only. Some cartoons may have this rating.
- **TV-Y** - Appropriate for all children.
- **TV-Y7** - Appropriate for children seven and older.
- **TV-G** - General Audience
- **TV-PG** - Parental Guidance suggested.
- **TV-14** - Unsuitable for children under 14.
- **TV-MA** - Mature audience only.

MOVIE RATINGS

G	[OFF]
PG	[OFF]
PG-13	[OFF]
R	[OFF]
NC-17	[OFF]
X	[OFF]

PARENTAL GUIDELINES

TV-Y	[OFF]
TV-Y7	[OFF]
TV-G	[OFF]
TV-PG	[OFF]
TV-14	[OFF]
TV-MA	[OFF]

TV-PG

TV-PG	[OFF]
D	[OFF]
L	[OFF]
S	[OFF]
V	[OFF]

ACCESS CODE

BEGIN

- 1 Press the **MENU** button, then press the **CH(annel)** ▲/▼ buttons to select **SMARTLOCK**. Then, press the **VOL(ume)** ► button.
- 2 Press the **Number** buttons to enter your old access code. If you have never set up your personal access code, use 0711.
- 3 Press the **CH(annel)** ▲/▼ buttons to select **CHANGE CODE**. Then, press the **VOL(ume)** ► button.
- 4 Use the **Number** buttons to enter your desired access code in the **New Code** space. Then, enter the same code in the **Confirm Code** space. Your new access code should be recorded. You will return to the **SMARTLOCK** menu.
- 5 Press the **STATUS/EXIT** button.

STOP

SMART HELP

You cannot use the default code after you set up your personal access code.

To restore 0711 as your personal access code, unplug the TV's power cord for 10 seconds, then plug it in again.

ON-SCREEN FEATURES (CONT'D)

PICTURE

BEGIN

- 1 Press the **MENU** button, then press the **CH(annel)** ▲/▼ buttons to select a control.
- 2 Press the **VOL(ume)** ►/◄ buttons to adjust the selected picture control.
- 3 Press the **STATUS/EXIT** button.

STOP

SMART HELP

To reset the picture controls to the original factory settings, press the **MENU** button, then press the **CH(annel)** ▲/▼ buttons to select **TV RESET**. Press the **VOL(ume)** ► button. **TV RESET COMPLETED** will appear briefly on the screen.

PICTURE ADJUSTMENTS

To adjust your TV picture controls, select a channel and follow these steps.

BRIGHTNESS Press the **VOL(ume)** ►/◄ buttons until the darkest parts of the picture are as bright as you prefer.

PICTURE Press the **VOL(ume)** ►/◄ buttons until the lightest parts of the picture show good detail.

COLOR Press the **VOL(ume)** ►/◄ buttons to add or reduce color.

TINT Press the **VOL(ume)** ►/◄ buttons to obtain natural skin tones.

SHARPNESS Press the **VOL(ume)** ►/◄ buttons to improve detail in the picture.

CAPTION

BEGIN

- 1 Press the **MENU** button, then press the **CH(annel)** ▲/▼ buttons to select **CAPTION**.
- 2 Press the **VOL(ume)** ►/◄ buttons to select a Closed Caption mode, for example **CAPTION 1**. Note: Usually **CAPTION 1** is the preferred mode for viewing captioned material. **CAPTION 1** or **2** modes: dialogue (and descriptions) for the action on the captioned TV program shows on the screen. **TEXT 1** or **2** modes: only a black box appears on the TV screen. If the **TEXT** mode is active, text or information will appear.
- 3 Press the **STATUS/EXIT** button. Closed Captions will appear if they are available for the current program.

STOP

SMART HELP

Closed Captions will be delayed briefly when you mute or adjust the volume, change channels, or press the **STATUS/EXIT** button to see the current channel number. Closed Captions will not be delayed when you mute or adjust the volume if you set the **VOLUME BAR** to **OFF**. Details are on page 6.

To cancel Closed Captions, set **CAPTION** to **OFF** at step 2.

CLOSED CAPTIONING

Closed Captioning allows you to read the voice content of television programs on the TV screen. Designed to help the hearing impaired, this feature uses on-screen text boxes to show dialogue and conversations while the TV program is in progress.

Note: Broadcast stations will often use spelling abbreviations, symbols, dropouts and other grammatical shortcuts in order to keep pace with the on-screen action. These factors vary with the source of the captioned text material and do not indicate a need for TV service.

Notes:

- Captions and texts may not match the TV voice broadcast exactly.
- Interference may cause the Closed Captioning system to function improperly.
- The caption or text characters will not appear if the menu is on the screen.
- Remember, not all TV programs and commercials are broadcast with Closed Captioning. Neither are all Closed Caption modes necessarily being used by a broadcast station during the transmission of a program. Refer to your area's TV program listings for the stations and times of shows with Closed Captioning.
- If a black box appears on the screen, your TV is set to a **TEXT** mode. To remove the black box, select **CAPTION 1**, **CAPTION 2**, or **OFF** at step 2 above.

GLOSSARY

Coaxial Cable - A single cable with a metal connector that screws (or pushes) directly onto a 75Ω jack (ANT(enna) In jack) on the Television or VCR.

Display - Allows the user to quickly confirm what channel number is being viewed currently.

Jack Panel - The area on the back of the TV.

Menu - An on-screen listing of features that are available for adjustments.

On-screen Displays (OSD) - The wording or messages that help you set up features (color adjustment, channel setup, etc.).

Programming - Adding or deleting channels in the television's memory. The television "remembers" only the locally available or desired channel numbers and skips over any unwanted channel numbers.

Reminder - Continuously displays the current channel number on the TV screen.

Remote Sensor - A window or opening on the front of the TV through which remote control signals are received.

Twin Lead Wire - The two-strand 300Ω antenna wire used with many indoor and outdoor antenna systems. In many cases, this type of antenna wire requires an additional adaptor (or balun) in order to connect to the ANT(enna) In jack on the TV.

Volume Bar - Appears on the TV screen when you adjust the volume.

GENERAL INFORMATION

TIPS

TROUBLESHOOTING

Please make these simple checks before calling for service. These tips can save you time and money since charges for TV installation and adjustment of customer controls are not covered under your warranty.

As an ENERGY STAR® Partner, Philips Consumer Electronics Company has determined that this product meets the ENERGY STAR® guidelines for energy efficiency. ENERGY STAR® is a U.S. registered mark. Using products with the ENERGY STAR® label can save energy. Saving energy reduces air pollution and lowers utility bills.

Power Failure

- When you disconnect the power cord from the AC outlet, or if you have a power failure, the Sleep Timer will be cancelled. You may reset the Sleep Timer.

BEGIN

1 No Power

- Check the TV power cord.
- Make sure the power outlet is not on a wall switch.

2 No Sound

- Check the VOL(ume) ►/◄ buttons.
- Check the MUTE button.

3 No Picture

- Check antenna/cable connections. Is the antenna or cable properly secured to the ANT(enna) IN jack on the TV?

4 Remote Doesn't Work

- Check batteries. Replace with AA Heavy Duty (Zinc Chloride) or Alkaline batteries if necessary.
- Clean the remote and the remote sensor on the TV.
- Check the TV power cord.

5 Wrong Channel

- Repeat channel selection.
- Add desired channel numbers into the TV memory. See page 5 for details.

Cleaning and Care

- Unplug the TV before cleaning.
- Avoid using anything abrasive that could scratch the screen.
- Wipe the TV screen with a clean cloth dampened with water.
- Gently wipe cabinet surfaces with a clean cloth or sponge dampened with cool clear water. Use a clean dry cloth to dry the wiped surfaces.
- Occasionally vacuum the ventilation holes or slots in the cabinet back.
- Never use thinners, insecticide sprays, or other chemicals on or near the cabinet.

SmartLock

- Programming may be rated by the Motion Picture Association of America (MPAA) or according to the Television Parental Guidelines. In order to block any inappropriate programming, set your limits in both places (Movie Ratings and Parental Guidelines).
- Ratings will remain blocked even after a power failure.
- You cannot access the menu when the "CHANNEL XX BLOCKED..." message appears.
- If you enter the access code once, you may change channels without seeing the "CHANNEL XX BLOCKED" message again. If you turn off the TV power, you will be asked for the access code again when you tune to a blocked channel.
- If a power failure occurs, the default code, 0711, will be the active access code again.
- If you connect the power cord to an AC outlet that is controlled by a wall switch, your personal access code will be erased every time you turn off the power at the wall switch. The default code will be the active code again.
- To restore 0711 as your personal access code, unplug the TV's power cord for 10 seconds, then plug it in again.

INDEX

ALT. CH Button 4	Controls/Remote 4	MUTE Button 4	Safety Notes 1	Tips 8
Antenna Connections . . . 2-3	Controls/TV 4	Number Buttons 4	Save Channels 5	VCR Connections 3
Batteries 4	Delete Channels 5	Picture Adjustments 7	Service 8	Volume Bar 6
Cable TV Connections . . . 3	Features 1	POWER Button 4	Setup 4	VOL(ume) ►/◄ Buttons . . 4
Channel Setup 4-5	First Time Setup 4	Precautions 1, 8	SLEEP Button 4, 6	Warranty 8
CH(annel) ▲/▼ Buttons . . 4	Glossary 7	Reminder 5	Sleep Timer 6	
Closed Captioning 7	Language Selection 5	Remote Control 4	SmartLock 6	
Coaxial Cable 3	MENU Button 4	Remote Sensor 4	STATUS/EXIT button 4	

WARRANTY

COLOR TELEVISION

90 Days Free Labor

One Year Free Replacement of Parts (Two Years Free Replacement on Color Picture Tube)

This product must be carried in for repair.

WHO IS COVERED?

You must have proof of purchase to receive warranty service. A sales receipt or other document showing that you purchased the product is considered proof of purchase.

WHAT IS COVERED?

Warranty coverage begins the day you buy your product. For 90 days thereafter, all parts will be repaired or replaced free, and labor is free. From 90 days to one year from the day of purchase, all parts will be repaired or replaced free, but you pay for all labor charges. From one to two years from the day of purchase, you pay for the replacement or repair of all parts except the picture tube, and for all labor charges. After two years from the day of purchase, you pay for the replacement or repair of all parts, and for all labor charges.

All parts, including repaired and replaced parts, are covered only for the original warranty period. When the warranty on the product expires, the warranty on all replaced and repaired parts also expires.

WHAT IS EXCLUDED?

Your warranty does not cover:

- labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna systems outside of the product.
- product repair and/or part replacement because of misuse, accident, unauthorized repair, or other cause not within the control of Philips Consumer Electronics Company.
- reception problems caused by signal conditions or cable or antenna systems outside the unit.
- a product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved, and/or authorized, or repair of products damaged by these modifications.
- incidental or consequential damages resulting from the product. (Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This includes, but is not limited to, prerecorded material, whether copyrighted or not copyrighted.)
- a product used for commercial or institutional purposes.

WHERE IS SERVICE AVAILABLE?

Warranty service is available in all countries where the product is officially distributed by Philips Consumer Electronics Company. In countries where Philips Consumer Electronics Company does not distribute the product, the local Philips service organization will attempt to provide service (although there may be a delay if the appropriate spare parts and technical manual(s) are not readily available).

MAKE SURE YOU KEEP...

Please keep your sales receipt or other document showing proof of purchase. Attach it to this owner's manual and keep both nearby. Also keep the original box and packing material in case you need to return your product.

BEFORE REQUESTING SERVICE...

Please check your owner's manual before requesting service. Adjustments of the controls discussed there may save you a service call.

TO GET WARRANTY SERVICE IN U.S.A., PUERTO RICO, OR U.S. VIRGIN ISLANDS...

Contact a Philips factory service center (see enclosed list) or authorized service center to arrange repair.

(In U.S.A., Puerto Rico, and U.S. Virgin Islands, all implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the duration of this express warranty. But, because some states do not allow limitations on how long an implied warranty may last, this limitation may not apply to you.)

TO GET WARRANTY SERVICE IN CANADA...

Please contact Philips at:

1-800-661-6162 (French Speaking)
1-800-363-7278 (English Speaking)

(In Canada, this warranty is given in lieu of all other warranties. No other warranties are expressed or implied, including any implied warranties of merchantability or fitness for a particular purpose. Philips is not liable under any circumstances for any direct, indirect, special, incidental, or consequential damages, howsoever incurred, even if notified of the possibility of such damages.)

REMEMBER...

Please record below the model and serial numbers found on the product. Also, please fill out and mail your warranty registration card promptly. It will be easier for us to notify you if necessary.

MODEL # _____
SERIAL # _____

Philips Service Solutions Group, P.O. Box 2976, Longview, Texas 75606
(903) 242-4800

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>