


Angle Sander

MODEL 9060L





INSTRUCTION MANUAL

⚠ WARNING:

For your personal safety, READ and UNDERSTAND before using. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

www.makitatools.com

SPECIFICATIONS

Model	9060L
No load speed (RPM)	6,000/min
Overall length	458 mm (18")
Net weight	4.2 kg (9.3 lbs)
Spindle thread	5/8"

- Manufacturer reserves the right to change specifications without notice.
- · Specifications may differ from country to country.

GENERAL SAFETY RULES

USA002-2

(For All Tools)

↑ WARNING:

Read and understand all instructions. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

SAVE THESE INSTRUCTIONS

Work Area

- Keep your work area clean and well lit.
 Cluttered benches and dark areas invite accidents
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep bystanders, children, and visitors away while operating a power tool. Distractions can cause you to lose control.

Electrical Safety

4. Double insulated tools are equipped with a polarized plug (one blade is wider than the other.) This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Do not change the plug in any way. Double insulation eliminates the need for the three wire grounded power cord and grounded power supply system.

- Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is grounded.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- 7. Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock
- When operating a power tool outside, use an outdoor extension cord marked "W-A" or "W". These cords are rated for outdoor use and reduce the risk of electric shock.

Personal Safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools may result in serious personal injury.
- 10. Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
- 11. Avoid accidental starting. Be sure switch is off before plugging in. Carrying tools with your finger on the switch or plugging in tools that have the switch on invites accidents.
- 12. Remove adjusting keys or wrenches before turning the tool on. A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.
- 13. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enables better control of the tool in unexpected situations.
- 14. Use safety equipment. Always wear eye protection. Dust mask, non-skid safety shoes, hard hat, or hearing protection must

be used for appropriate conditions. Ordinary eye or sun glasses are NOT eye protection.

Tool Use and Care

- 15. Use clamps or other practical way to secure and support the workpiece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.
- 16. Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.
- 17. Do not use tool if switch does not turn it on or off. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- 18. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.
- 19. Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.
- 20. Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.
- 21. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tools operation. If damaged, have the tool serviced before using. Many accidents are caused by poorly maintained tools.
- 22. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool, may become hazardous when used on another tool.

SERVICE

23. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury. 24. When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance section of this manual.

Use of unauthorized parts or failure to follow Maintenance instructions may create a risk of electric shock or injury.

USE PROPER EXTENSION CORD: Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. Table 1 shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.

Amner	Volts	Total length of cord in feet						
Allipei	Ampere Rating			50 ft.	100 ft.	150 ft.		
More Than	Not More Than			AWG				
0	6		18	16	16	14		
6	10		18	16	14	12		
10	12		16	16	14	12		
12	16		14	12	Not Reco	mmended		

Table 1: Minimum gage for cord

SPECIFIC SAFETY RULES

USB038-5

DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to sander safety rules. If you use this tool unsafely or incorrectly, you can suffer serious personal injury.

- Accessories must be rated for at least the speed recommended on the tool warning label. Wheels and other accessories running over rated speed can fly apart and cause injury.
- Hold tool by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will make exposed metal parts of the tool "live" and shock the operator.
- Always use safety glasses or goggles. Ordinary eye or sun glasses are NOT safety glasses.

- 4. Use only flanges specified for this tool.
- NEVER use tool with wood cutting blades or other sawblades. Such blades when used on a sander frequently kick and cause loss of control leading to personal injury.
- 6. Hold the tool firmly.
- 7. Keep hands away from rotating parts.
- Be careful not to damage the spindle, the flange (especially the installing surface) or the lock nut. Damage to these parts could result in wheel breakage.

- Make sure the abrasive disc or the wheel is not contacting the workpiece before the switch is turned on.
- Watch out for flying sparks. Hold the tool so that sparks fly away from you and other persons or flammable materials.
- Do not leave the tool running. Operate the tool only when hand-held.
- Do not touch the workpiece immediately after operation; it may be extremely hot and could burn your skin.
- 13. Ventilate your work area adequately when you perform sanding operations.
- 14. ALWAYS wear proper apparel including long sleeve shirts, leather gloves and shop aprons to protect skin from contact with hot grindings.
- 15. Use of this tool to grind or sand some products, paints and wood could expose user to dust containing hazardous substances. Use appropriate respiratory protection.

IF USED AS A GRINDER

- 16. Always use proper guard with grinding wheel. A guard protects operator from broken wheel fragments.
- When using depressed center grinding wheels, be sure to use only fiberglassreinforced wheels.
- 18. Check the wheel carefully for cracks or damage before operation. Replace cracked or damaged wheel immediately. Run the tool (with guard) at no load for about a minute, holding tool away from others. If wheel is flawed, it will likely separate during this test.
- Before using the tool on an actual workpiece, let it run for a while. Watch for vibration or wobbling that could indicate poor installation or a poorly balanced wheel.
- 20. Use the specified surface of the wheel to perform the grinding.

5

SAVE THESE INSTRUCTIONS

↑ WARNING:

MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury.

SYMBOLS USD201-2

The followings show the symbols used for tool.

/volts	n₀no load speed
4 amperes	☐Class II Construction
1z hertz	/minrevolutions or reciprocation pe
alternating current	minute

FUNCTIONAL DESCRIPTION

⚠ CAUTION:

 Always be sure that the tool is switched off and unplugged before adjusting or checking function on the tool.

001026

Shaft lock

↑ CAUTION:

Never actuate the shaft lock when the spindle is moving.
 The tool may be damaged.

Press the shaft lock to prevent spindle rotation when installing or removing accessories.

1. Shaft lock

001041

Switch action

△ CAUTION:

- Before plugging in the tool, always check to see that the switch trigger actuates properly and returns to the "OFF" position when released.
- Switch can be locked in "ON" position for ease of operator comfort during extended use. Apply caution when locking tool in "ON" position and maintain firm grasp on tool.


To start the tool, simply pull the switch trigger. Release the switch trigger to stop. For continuous operation, pull the switch trigger and then push in the lock lever. To stop the tool from the locked position, pull the switch trigger fully, then release it.

Switch trigger
 Lock lever

ASSEMBLY

⚠ CAUTION:


 Always be sure that the tool is switched off and unplugged before carrying out any work on the tool.




Installing side grip (handle)

 Always be sure that the side grip is installed securely before operation.

Screw the side grip securely on the position of the tool as shown in the figure.



- 1. Lock nut
- 2. Abrasive disc
- 3. Rubber pad



- 1. Lock nut wrench
- 2. Shaft lock

Installing or removing abrasive disc (optional accessory)

NOTE:

• Use sander accessories specified in this manual. These must be purchased separately.

Mount the rubber pad onto the spindle. Fit the disc on the rubber pad and screw the lock nut onto the spindle.

To tighten the lock nut, press the shaft lock firmly so that the spindle cannot revolve, then use the lock nut wrench and securely tighten clockwise.

To remove the disc, follow the installation procedure in reverse.

IF USED AS A GRINDER

NOTE:

• Use grinder accessories specified in this manual. These must be purchased by separate.

⚠ WARNING:

- Always use guard assembly or accessory kit, noted below, for type 27 depressed center grinding wheel/ Multi-disc.
- · Guard assembly


Part No. 192578-8 ... For 180 mm (7")

Part No. 192588-5 ... For 230 mm (9")


Guard accessory kit

Part No. 192606-9 ... For 180 mm (7")


Part No. 192607-7 ... For 230 mm (9")



- 1. Wheel guard
- 2. Bearing box
- 3. Screw



- 1. Lock nut
- Depressed center grinding wheel/ Multi-disc
- 3. Inner flange



- 1. Lock nut wrench
- 2. Shaft lock

Installing or removing wheel guard

⚠ CAUTION:

 When using a depressed center grinding wheel/Multidisc, flex wheel or wire wheel brush, the wheel guard must be fitted on the tool so that the closed side of the guard always points toward the operator.

Mount the wheel guard with the protrusion on the wheel guard band aligned with the notch on the bearing box. Then rotate the wheel guard around 180 degrees. Be sure to tighten the screw securely.

To remove wheel guard, follow the installation procedure in reverse.

Installing or removing depressed center grinding wheel/Multi-disc (optional accessory)


⚠ WARNING:

 Always use optional guard when depressed center grinding wheel/Multi-disc is on tool. Wheel can shatter during use and guard helps to reduce chances of personal injury.

Mount the inner flange onto the spindle. Fit the wheel/disc on the inner flange and screw the lock nut onto the spindle.

To tighten the lock nut, press the shaft lock firmly so that the spindle cannot revolve, then use the lock nut wrench and securely tighten clockwise.

To remove the wheel, follow the installation procedure in reverse.



- 1. Lock nut
- 2. Flex wheel
- 3. Plastic pad
- 4. Inner flange

OPERATION

Installing or removing flex wheel (optional accessory)

⚠ WARNING:


 Always use specific guard when depressed center grinding wheel/Multi-disc is on tool. Wheel can shatter during use and guard helps to reduce chances of personal injury.

Follow instructions for depressed center grinding wheel/ Multi-disc but also use plastic pad over wheel. See order of assembly on accessories page in this manual.

⚠ WARNING:

- It should never be necessary to force the tool. The weight of the tool applies adequate pressure. Forcing and excessive pressure could cause dangerous wheel breakage.
- ALWAYS replace wheel if tool is dropped while grinding.
- NEVER bang or hit grinding disc or wheel onto work.
- Avoid bouncing and snagging the wheel, especially when working corners, sharp edges etc. This can cause loss of control and kickback.
- NEVER use tool with wood cutting blades and other sawblades. Such blades when used on a grinder frequently kick and cause loss of control leading to personal injury.

 After operation, always switch off the tool and wait until the wheel has come to a complete stop before putting the tool down.




Grinding and sanding operation

ALWAYS hold the tool firmly with one hand on rear handle and the other on the side handle. Turn the tool on and then apply the wheel or disc to the workpiece.

In general, keep the edge of the wheel or disc at an angle of about 15 degrees to the workpiece surface.

During the break-in period with a new wheel, do not work the grinder in the B direction or it will cut into the workpiece. Once the edge of the wheel has been rounded off by use, the wheel may be worked in both A and B direction.



1. Wire cup brush

2. Urethane washer


Operation with wire cup brush (optional accessory)

- Check operation of brush by running tool with no load, insuring that no one is in front of or in line with brush.
- Do not use brush that is damaged, or which is out of balance. Use of damaged brush could increase potential for injury from contact with broken brush wires.

Unplug tool and place it upside down allowing easy access to spindle. Remove any accessories on spindle. Mount ure-thane washer then thread wire cup brush onto spindle and tighten with supplied wrench. When using brush, avoid applying too much pressure which causes over bending of wires, leading to premature breakage.

NOTE:

 When using wire cup brush, mount urethane washer to the spindle. It will make it easier to remove wire cup brush.



1. Wire wheel brush

Operation with wire wheel brush (optional accessory)


↑ CAUTION:

- Check operation of wire wheel brush by running tool with no load, insuring that no one is in front of or in line with the wire wheel brush
- Do not use wire wheel brush that is damaged, or which is out of balance. Use of damaged wire wheel brush could increase potential for injury from contact with broken wires.
- ALWAYS use guard with wire wheel brushes, assuring diameter of wheel fits inside guard. Wheel can shatter during use and guard helps to reduce chances of personal injury.

Unplug tool and place it upside down allowing easy access to spindle. Remove any accessories on spindle. Thread wire wheel brush onto spindle and tighten with the wrenches.

When using wire wheel brush, avoid applying too much pressure which causes over bending of wires, leading to premature breakage.

MAINTENANCE




- 1. Exhaust vent
- 2. Inhalation vent

⚠ CAUTION:

 Always be sure that the tool is switched off and unplugged before attempting to perform inspection or maintenance.


The tool and its air vents have to be kept clean. Regularly clean the tool's air vents or whenever the vents start to become obstructed



- 1. Commutator
- 2. Insulating tip
- 3. Carbon brush

Replacing carbon brushes

When the resin insulating tip inside the carbon brush is exposed to contact the commutator, it will automatically shut off the motor. When this occurs, both carbon brushes should be replaced. Keep the carbon brushes clean and free to slip in the holders.



- 1. Brush holder cap
- 2. Screwdriver

Use a screwdriver to remove the brush holder caps. Take out the worn carbon brushes, insert the new ones and secure the brush holder caps.

To maintain product SAFETY and RELIABILITY, repairs, any other maintenance or adjustment should be performed by Makita Authorized or Factory Service Centers, always using Makita replacement parts.


ACCESSORIES

↑ CAUTION:

- These accessories or attachments are recommended for use with your Makita tool specified in this manual. The use of any other accessories or attachments might present a risk of injury to persons. Only use accessory or attachment for its stated purpose.
- If you decide to use your Makita sander with approved accessories which you purchase from your Makita distributor or factory service center, be sure to obtain and use all necessary fasteners and guards as

recommended in this manual. Your failure to do so could result in personal injury to you and others.

If you need any assistance for more details regarding these accessories, ask your local Makita service center.



	9060L
1	Grip 36
2	Wheel guard
3	Inner flange 89
4	Depressed center grinding wheel/Multi-disc
5	Lock nut 5/8-40
6	Plastic pad
7	Flex wheel
8	Rubber pad 170
9	Abrasive disc
10	Sanding lock nut 5/8-48
11	Wire wheel brush
12	Urethane washer 14
13	Wire cup brush
-	Lock nut wrench 28
-	Accessory kit 7" or 9"

First-Class
Postage
Required

Post Office will
not deliver
without proper
postage.

Makita U.S.A., Inc. 14930 Northam Street La Mirada, CA 90638-5753

Haladlandlandlaladaddaddaddadladdd

MAIL THIS PORTION

Your answer to the following questions are appreciated.

AREA	1. This product was purchased from:						3.	3. How did you learn of about this product:							
Tool Distributor Newspaper From Friend Industrial Supply Store Display Previous Usage Construction Supply Catalog Other (Home Cente	ər	c	Other ()		Maga	zine			Ra	adio		
Industrial Supply Store Display Previous Usage Construction Supply Catalog Other () Use of the product is intended for: Construction Trade Design Repair Service Industrial Maintenance Peatures Durability Home Maintenance Size Power Hobby Price Other () Other () Any comments: DATE PURCHASED MODEL NO. MONTH DAY YEAR SERIAL NO. STATUS SEX Married Single M F STREET ADRESS CITY	Hardware/L	umber Store						From	Dealer			E)	chibition		
Construction Supply Catalog Other () Use of the product is intended for: Construction Trade Design Repair Service Industrial Maintenance Industrial Mainte	Tool Distribu	ıtor						News	paper			Fr	om Frier	nd	
Use of the product is intended for: Construction Trade	Industrial Su	upply						Store	Display	/		Pr	evious (Jsage	
Construction Trade Industrial Maintenance Ind	Construction	n Supply						Catal	og			Of	her ()
Industrial Maintenance	. Use of the pr	oduct is inte	nded for:	:			4.	Most fa	vored	points a	are:				
Home Maintenance Size Power Hobby Price Other() Other() Makita Brand Any comments: DATE PURCHASED MODEL NO. MONTH DAY YEAR SERIAL NO. STATUS SEX Married Single M F STREET ADRESS CITY AREA CODE	Construction	n Trade						Desig	ın			Re	epair Se	rvice	
Hobby Price Other () Other () Makita Brand Other () Any comments: DATE PURCHASED MODEL NO. MONTH DAY YEAR SERIAL NO. INTL. LAST NAME / COMPANY NAME STATUS SEX Married Single M F STREET ADRESS CITY	Industrial M	aintenance						Featu	ires			Du	urability		
Other () Makita Brand Any comments: DATE PURCHASED MONTH DAY YEAR SERIAL NO. STATUS SEX Married Single M F STREET ADRESS CITY AREA CODE	Home Main	tenance													
Any comments: DATE PURCHASED MODEL NO. MONTH DAY YEAR SERIAL NO. STATUS SEX Married Single M F STREET ADRESS CITY AREA CODE	Hobby							Price				01	her ()
DATE PURCHASED MONTH DAY YEAR SERIAL NO. STATUS SEX Married Single M F STREET ADRESS CITY AREA CODE	Other ()						Makit	a Brand	i		_			
SERIAL NO. STATUS SEX Married Single M F STREET ADRESS CITY AREA CODE							MODE	EL NO.							
STATUS SEX Married Single M F STREET ADRESS AREA CODE	MONTH	D	AY	1	YE	AH	05014								
INTL. LAST NAME / COMPANY NAME Married Single M F STREET ADRESS CITY AREA CODE							SERIA	IL NO.							
STREET ADRESS CITY AREA CODE												STA	TUS		
CITY AREA CODE	INTL. LAST	NAME / COI	MPANY N	IAME								Married	Single	М	F
CITY AREA CODE															
AREA	STREET ADRE	ESS						I		<u> </u>				1	
AREA															
CODE	CITY														
CODEL															
STATE ZIP CODE PHONE	STATE				_							CODE	1		
			ZIF	CODI	E				PHONE						

BE SURE TO COMPLETE THE CUSTOMER'S PORTION OF THIS FORM AND RETAIN FOR YOUR RECORDS.

30-39

40-49

50-60

Please return this portion by facsimile or mail.

Facsimile No: (714) 522-8133

20-29

Under 19

AGE:

Over 60

FACTORY SERVICE CENTERS

1-800-4-MAKITA

RETAIN THIS PORTION FOR YOUR RECORDS

ALABAMA

2365 Pelham Parkway Pelham, AL 35124 (205) 620-1791

ADIZONA

3707 E. Broadway Rd., Ste. 6 Phoenix, AZ 85040 (602) 437-2850

ARKANSAS

Shackleford Shopping Center 240 South Shackleford Rd., Little Rock, AR 72211 (501) 224-5733

CALIFORNIA

41850 Christy St. Fremont, CA 94538-5107 (510) 657-9881

1421 N. Clovis Ave., Ste. 112 Fresno, CA 93727 (559) 252-5166

14930 Northam St. La Mirada, CA 90638-5753 (714) 522-8088

Sacramento, CA 95825

1440 South "E" Street San Bernardino, CA 92408 (909) 885-1289

7674 Clairemont Mesa Blvd. San Diego, CA 92111 (858) 278-4471

1714 E.McFadden Ave., Unit M Santa Ana. CA 92705

(714) 667-5066 1565 Winchester B.

Campbell, CA 95008-0501 (408) 379-0377 16735 Saticov St., Ste. 105

Van Nuys, CA 91406 (818) 782-2440

COLOBADO 11839 E. 51st Ave

Denver, CO 80239-2709 (303) 371-2850

CONNECTICUT 508 Spring St.

Windsor Locks, CT 06096 (860) 292-6405

620 Douglas Ave. Suite 1302 Altamonte Springs, FL 32714 (407) 774-6000

750 East Sample Road Pompano Beach, FL 33064 (954) 781-6333

Thompson Center Waters 5501 W. Waters Ave., Ste. 406 Tampa, FL 33634 (813) 886-8292

GEORGIA

4680 River Green Parkway Duluth, GA 30096-2566 (770) 476-8911

HAWAII

4510 Salt Lake Blvd., Suite A7 Honolulu, HI 96818 (808) 847-0038

1450 Feehanville Dr Mt. Prospect, IL 60056-6011 (847) 297-3100

8403 Michigan Road, Unit 1 Indianapolis, IN 46268 (317) 334-9980

KANSAS

8819 W. 95th St. Overland Park, KS 66212 (913) 642-1111

KENTUCKY

1215 S. Hurstbourne Parkway Louisville, KY 40222 (502) 326-3740

LOUSIANA 5626 Jefferson Hwy Harahan, LA 70123 (504) 733-4138

MARYLAND

7541 - 45 Ritchie Highway Glen Burnie, MD 21061 (410) 590-0160

MASSACHUSETTS 232 Providence Hwy Westwood, MA 02090 (617) 461-9754

MICHIGAN 37454 Ann Arbor Trail Livonia, MI 48150

(313) 432-1012

MINNESOTA 6427 Penn Ave. South Richfield MN 55423

MISSOURI

9876 Watson Road St Louis MO 63126-2221 (314) 909-9889

NEBRASKA

4129 S. 84th St. Omaha NF 68127 (402) 597-2925

NEVADA

3375 S. Decatur Blvd. Suites. 22 - 24 Las Vegas, NV 89102 (702) 368-4277

NEW JERSEY

251 Herrod Blvd. Dayton, NJ 08810-1539 (609) 655-1212

NEW MEXICO

5805 Menaul Blvd. NF Albuquerque, NM 87110

NEW YORK 4917 Genessee Street

Cheektowaga, NY 14225 (716) 685-9503

131-35 31st Ave Flushing, NY 11354 (718) 886-0971

NORTH CAROLINA

3501-G S. Tryon St. Charlotte, NC 28217 (704) 527-0611

6253 E. Main St Columbus, OH 43213 (614) 860₀0222

6379 Pearl Road Parma Heights, OH 44130 (440) 843-7555

1617 E. Kemper Rd. Sharonville OH 45246 (513) 771-0788

OKLAHOMA

552 E. Memorial Road Oklahoma City, OK 73114 (405) 752-2655

OREGON 828 19th Avenue., N.W.

Portland OR 97209 (503) 222-1823

DENINGVI VANIA

Springwater Plaza 364 Wilmington W. Chester Pike Glen Mills PA 19342 (610) 459-4122

6200 Babcock Blvd Pittsburgh, PA 15237 (412) 366-6363

PUERTO RICO

200 Guavama St Hato Rey, PR 00917 (787) 250-8776

TENNESSEE 4655 Nolensville Rd

(615) 331-9922

12801 Stemmons Fwy Ste 809 Farmers Branch, TX 75234 (972) 243-1150

12701 Directors Dr Stafford, TX 77477-3701 (281) 565-8665

3453 IH-35 North, Ste. 101 San Antonio, TX 78219 (210) 228-0676

145 E. 1300 S., Ste. 101 Salt Lake City, UT 84115 (801) 359-3410

VIRGINIA

5760 Northampton Blvd,. Ste Virginia Beach, VA 23455 (757) 460-0280

WASHINGTON 22220 84th Ave So Bldg A

Kent, WA 98032 (253) 395-8055

WISCONSIN

Lincoln Plaza Shopping Ctr. 2245 S. 108th St. West Allis, WI (414) 541-4776

CUSTOMER'S RECORD

When you need service: Send	Date Purchased						
complete tool (prepaid) to one of the Makita Factory Service	Dealer's Name & Address						
Centers listed, or to an Authorized Makita Service Center. Be sure							
to attach a letter to the outside of the carton detailing the problem with your tool.	Model No.						
	Serial No.						

WARNING

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

MAKITA LIMITED ONE YEAR WARRANTY

Warranty Policy

Every Makita tool is thoroughly inspected and tested before leaving the factory. It is warranted to be free of defects from workmanship and materials for the period of ONE YEAR from the date of original purchase. Should any trouble develop during this one-year period, return the COMPLETE tool, freight prepaid, to one of Makita's Factory or Authorized Service Centers. If inspection shows the trouble is caused by defective workmanship or material, Makita will repair (or at our option, replace) without charge.

This Warranty does not apply where:

- · repairs have been made or attempted by others:
- repairs are required because of normal wear and tear:
- The tool has been abused, misused or improperly maintained:
- alterations have been made to the tool.

IN NO EVENT SHALL MAKITA BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THE PRODUCT. THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THIS WARRANTY.

MAKITA DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF "MERCHANTABILITY" AND "FITNESS FOR A SPECIFIC PURPOSE," AFTER THE ONE-YEAR TERM OF THIS WARRANTY.

This Warranty gives you specific legal rights, and you may also have other rights which vary form state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Makita Corporation

Anjo, Aichi Japan Made in China Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com