

Alexxa Series

In-Wall & In-Ceiling Speakers

MAXXSONICS USA, INC. 1290 Ensell Road Lake Zurich, Illinois 60047 USA Phone +1 847 - 540 - 7700 FAXX +1 847 - 540 - 9776 E-Mail info@maxxsonics.com Website www.maxxsonics.com

MAXXSONICS EUROPE GMBH Neckarstraße 20 74847 Obrigheim, Germany Phone +49 (0) 62 61 - 6 38-0 FAXX +49 (0) 62 61 - 6 38-129 E-Mail info@mbquart.de Website www.mbquart.de



Installation & Operation

ALEXXA SERIES

MB QUART IN-CEILING / IN-WALL SPEAKER INSTALLATION INSTRUCTIONS

Thank you for purchasing the MB QUART In-Ceiling / In-Wall speaker system.

To ensure proper installation and operation of the speakers, please follow the manual carefully and thoroughly.

- Be sure to follow the directions carefully and in the order provided below.
- Do not discard the manual. You will need this for future removal and installation.
- Be sure to adhere to all of the safety and caution tips through out the manual.
- Do not install or operate the speakers near water.
- During the installation, be sure to avoid in-wall and in-ceiling heater/AC ducts, electrical power lines, plumbing and fire retardant insulation.
- Avoid direct exposure to heat producing sources such as heat ducts, and exhaust vents.
- Do not alter the physical elements of the assembly such as the enclosure, speaker grille or electrical contact points.
- Route speaker wires away from heat producing sources, moving parts and exposure to water.
- Use a clean dry cloth to clean the speakers when necessary.
- Refer all service to a qualified authorized service center.

Minimum Tool Required

- Wire Strippers
- Carpenters Level
- # 2 Phillips Screwdriver
- Flat Blade Screwdriver
- Electronic Stud Finder
- Drywall Hand Saw

Material Supplied

- Grille Removal Tool
- Speaker Cut-Out Template
- Paint Shield
- Owner / Install manual

- Miniature Flat Blade Screwdriver for Point Source Speakers

SPEAKER PLACEMENT (ALX2PS / ALX3PS / ALX5.25IC / ALX6.5IC / ALX6.5IC DM / ALX8.0IC)

These speakers are designed to operate in a standard drywall or suspended acoustical panel ceiling. The speaker enclosure allows for different mounting depths that may be encountered in different ceiling applications.

Although the speakers sound best when the back section of the speaker is left in tact.


The back section of the speaker can be removed to lessen the over all mounting height if needed. Some building codes may require that the back enclosure half be removed so please check with your local building codes.


When mounting to a drywall ceiling, be sure the drywall is at least 3/8" thick.


If you are mounting the speakers to typical acoustical suspended ceiling panels, you will need to reinforce the acoustical panel with ½" plywood to ensure the speaker does not cause the acoustical panel to sag over time.

- 1. Choose mounting locations that are an equal distance left and right of the listening area as shown in **DIAGRAM 1**.
- 2. Use the speaker cut-out template supplied to mark your speaker hole locations. (Be sure there is clearance behind the area you have chosen for the speaker. Avoid electrical wiring, plumbing, moving parts, air ducts and Fire Stops.

- 3. Use a drywall saw or other appropriate tool to carefully cut out the speaker holes. The cut-out is the exact size required for the speaker. You also can go as much as 1/4" over this size as "Mistake Room".
- **4.** Connect the speaker wires (18 gauge wire not supplied) to the speakers as shown in **DIAGRAM 2**. (Be sure to get the + and polarity correct)
- **5.** Place the speaker into the speaker opening and using a # 2 phillips screw driver, turn the Dog-Ear fastening screws clockwise (be sure to support the weight of the speaker until all Doq-Ear screws are securely tightened).
 - The Dog-Ear Clamps will rotate away from the speaker enclosure and begin to tighten against the mounting surface to secure the speaker as shown in **DIAGRAM 3**.
- **6.** Carefully route the speaker wires to the amplifier or other power source. Be sure to avoid moving parts, heat producing items and water exposure.








IN-WALL SPEAKER PLACEMENT (ALX5.25IW / ALX6.5IW / ALX8.0IW)


These speakers are designed to operate in a standard drywall or wood paneling type wall. The In-Wall speakers may also be used for front left and right main speakers or even a center channel. You can mount the speakers in a vertical or horizontal position depending on the limitations of the wall.


- 1. Choose mounting locations that are an equal distance left and right of the listening area as shown in **DIAGRAM 4**.
- 2. Use the speaker cut-out template supplied to mark your hole locations.

 (Be sure there is clearance behind the area you have chosen for the speaker. Avoid electrical wiring, plumbing, moving parts, air ducts and Fire Stops.
- **3.** Use a drywall saw or other appropriate tool to carefully cut out the speaker holes. The cut-out is the exact size required for the speaker. You also can go as much as 1/4" over this size as "Mistake Room".
- **4.** Connect the speaker wires (18 gauge wire not supplied) to the speakers as shown in **DIAGRAM 5**. (Be sure to get the + and polarity correct)
- **5.** Place the speaker into the speaker opening and using a # 2 phillips screw driver, turn the Dog-Ear fastening screws clockwise (be sure to support the weight of the speaker until all Doq-Ear screws are securely tightened).
 - The Doq-Ear Clamps will rotate away from the speaker enclosure and begin to tighten against the mounting surface to secure the speaker as shown in **DIAGRAM 6**.
- **6.** Carefully route the speaker wires to the amplifier or other power source. Be sure to avoid moving parts, heat producing items and water exposure.

Note: To ensure your total surround sound experience, be sure to consider the SW10 and SW12 powered subwoofer system which will provide heart pounding bass to your favorite action movies. For the ultimate in Hi Fidelity sound quality, check out the MB QUART 5.1 speaker systems (tower speakers, center channel and book shelf speakers) in several classic and modern finishes.









ADDITIONAL INSTALLATION AND OPERATIONAL INFORMATION

- If you do not have the installation cut-out template, the cut-out dimensions are also located on the speaker label located on the side of the speaker. You can also down load the template by going to our web site at: www.maxxsonics.com
- The speaker trim bezels and grilles can also be spray painted.
 There is a paint shield located in the speaker kit to prevent from getting paint on the speaker cone.
 Tip: Do not use roll-on paint because it will fill-in the holes in the grille which will dramatically effect the sound quality.
 - Be sure to paint the grille separate from the speaker and do not re-install the grille until the paint has dried.
- You may order additional parts such as Dog-Ear Clamps, Grilles, Grille removal tools by contacting Maxxsonics at: www.maxxsonics.com




Angled Baffle Adjustment

The Alexxa series speaker feature an angled baffle design which positions the speaker on a 30% angle to the speaker enclosure. This allows you to rotate the speaker enclosure so that the speaker cone is facing towards the listening area as shown on Diagram 4. This is ideal for cathedral or pitched ceilings or walls do not permit the ideal mounting locations.



Tweeter Angle Adjustment

The tweeter element can be swivelled to allow you to aim or point the tweeter towards the listening area as shown above. In the event the mid bass speaker can not be aimed towards



Tweeter Angle Adjustment

The tweeter element can be swivelled to allow you to aim or point the tweeter towards the listening area as shown above. In the event the mid bass speaker can not be aimed towards

ALEXXA SPEAKER SPECIFICATIONS

MODEL	POWER RATING	IMPEDANCE	CUT-OUT
ALX2PS	5 - 20 WATTS	8-Ohms / 6-Ohms nom.	3.9" / 99mm Diameter
ALX3PS	5 - 30 WATTS	8-Ohms / 6-Ohms nom.	4.35" / 111 mm Diameter
ALX5.25IC	80 WATTS	8-Ohms / 6-Ohms nom.	8.9" / 227mm Diameter
ALX6.5IC	100 WATTS	8-Ohms / 6-Ohms nom	10.25" / 260mm Diameter
ALX6.5IC DM	100 WATTS	4+4-Ohms / 3+3-Ohms nom.	10.25" / 260mm Diameter
ALX8.0IC	120 WATTS	8-Ohms / 6-Ohms nom.	12.4" / 315mm Diameter
ALX5.25IW	80 WATTS	8-Ohms / 6-Ohms nom.	W: 7.26" / 184.5mm x L: 14.1" / 358mm
ALX6.5IW	100 WATTS	8-Ohms / 6-Ohms nom.	W: 7.9" / 200.5mm x L: 14.1" / 358mm
ALX8.0IW	120 WATTS	8-Ohms / 6-Ohms nom.	W: 10.3" / 262mm x L: 20.2" / 513mm

5-Year Limited Warranty

Domestic Warranty (U.S.A. AND CANADA ONLY)

The MB Quart Home Audio Speaker warranty for In-Wall and In-Ceiling Speakers is valid only for consumers in the United States or Canada.

MB QUART, Maxxsonics Europe GmHb ("MB QUART") warrants this product to be free from defects in workmanship and materials (subject to the below terms) for a period of (five) 5-years from the date of original purchase to the original purchaser. During the Warranty period, MB QUART will repair or replace (at MB QUART's sole option) this product or any defective parts. To obtain Warranty service, please contact the MB QUART authorized dealer from which you purchased this product. If your authorized MB Quart Dealer is not equipped to perform the repair of your MB QUART product, it can be returned, freight paid, to MB QUART for repair. Please call MB QUART at (847-540-7700) for instructions. Only ship this product in its original packaging or packaging with an equal degree of protection. All damages resulting from insufficient packing are the sole responsibility of the products owner.

Proof of purchase in the form of a Bill Of Sale or receipted invoice, issued by an authorized MB Quart dealer is always required for any and all warranty related services.

This receipt and or Bill of Sale which is evidence that this genuine MB Quart product is within the manufacturer's warranty period. Said evidence must be presented or included to obtain any warranty service. This warranty is invalidated when and if the factory-applied serial number has been altered or removed from this product or this product was not purchased from a MB QUART authorized dealer.

Call Maxxsonics at 847-540-7700 to confirm your purchase was from an MB QUART authorized dealer. Be prepared to supply the unaltered serial number when requested. Return instructions and a coded Return Authorization number will be given to the purchaser. Following these steps prior to returning a product to MB Quart for warranty prevents your package from being refused upon delivery.

Valid only to the original purchaser, this warranty automatically terminates before expiration if the product is sold or otherwise transferred to another party.

This warranty does not cover product sold AS IS or when sold WITH ALL FAULTS. This warranty does not cover abuse, damage, cosmetic damage or damage due to misuse, accidents, negligence, Acts of God, Commercial Use, or modification of, or to any part of the product. This warranty does not cover damage due to improper operation, maintenance or installation, or attempted repair by anyone other than MB QUART or a MB QUART dealer which is authorized to do MB QUART warranty work. Unauthorized repairs void this warranty.

THE EXCLUSIVE REMEDY OF THE CONSUMER PROVIDED UNDER THIS WARRANTY IS REPAIRS OR REPLACEMENTS OF PRODUCT.

MB QUART SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY LAW.

THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER IMPLIED AND EXPRESS WARRANTIES WHATSOEVER, INCLUDING BUT NOT LIMITED TO, THE WARRANTY OF FITNESS AND MERCHANTABILITY FOR A PRACTICAL PURPOSE.

Some states do not allow the exclusion or limitation of incidental or consequential damages or implied warranties so the above exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

WARRANTY OUTSIDE THE UNITED STATES & CANADA.

The warranty on this product if it is sold to a consumer outside of the United States or Canada shall comply with applicable law and shall be the sole responsibility of the distributor that supplied this product. To obtain any applicable warranty service, please contact the dealer from which you purchased this product, or the distributor that supplied this product. Products purchased outside the United States are not to be returned to any Maxxsonics Dealer or Maxxsonics facility within the United States under any circumstances.



MAXXSONICS USA, INC. 1290 Ensell Road Lake Zurich, Illinois 60047 USA Phone +1 847 - 540 - 7700 FAXX +1 847 - 540 - 9776 E-Mail info@maxxsonics.com Website www.maxxsonics.com

MAXXSONICS EUROPE GMBH Neckarstraße 20 74847 Obrigheim, Germany Phone +49 (0) 62 61 - 638-0 FAXX +49 (0) 62 61 - 638-129 E-Mail info@mbquart.de Website www.mbquart.de



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com