



Basic Installation Layout

Default Features

Default Features for Lines	
1.	All lines are loop start DTMF. <ul style="list-style-type: none">Use <i>3101-01: Line Type</i> to change this assignment.
2.	<ul style="list-style-type: none">Lines 1-12 ring on line keys 1-12 for extensions 300-315. (Lines 13-64 do not appear on line keys.)All other extensions are lamp only for lines 1-12.
3.	To customize line ringing, use one of the following: <ul style="list-style-type: none">User Programmable Features code #RAL. (See the <i>User Programmable Features</i> feature for more.)Use <i>2132-[01-64]: Line Ringing</i>.

Default Features for Extensions	
1.	The circuit types for keyset extensions are automatically set when the extension is plugged in.
2.	Keyset users can place outside calls by: <ul style="list-style-type: none">Pressing a line key and dialing the outside number. (See the <i>Central Office Calls, Placing</i> feature for more.)Pressing INTERCOM, dialing 9, then dialing the outside number. (See the <i>Line Group Routing</i> feature for more.)Line Dial-Up and Direct Line Access are disabled. (See the <i>Central Office Calls, Placing</i> feature for more.)
3.	All extensions have full incoming and outgoing access to all outside lines. <ul style="list-style-type: none">See <i>Initial Startup Programming</i> below to change this assignment.
4.	By default, Feature Keys 1-12 are line keys. Keys 13-24 are undefined. See the <i>Feature Keys</i> feature for more.

Default Features for IntraMail	
1.	Each extension has an IntraMail voice mailbox.
2.	All mailboxes are enabled. To disable a mailbox, see <i>2141-01: Station Mailbox Type</i> .
3.	The IntraMail Automated Attendant does not answer outside calls. (See the <i>Automated Attendant</i> feature for more.)

Initial Startup Programming

- 1. Enter the programming mode.**
 - From any display telephone, press **INTERCOM** + Dial **###** + Enter the system password + **HOLD**.
 - The system passwords are:
 - 632379 (NECDSX)** for Installer (level 3), **9999** for System Administrator 2 (level 2), **0000** for System Administrator 1 (level 1).
- 2. Assign the correct circuit type to each of your installed lines.**
 - In *3101-01: Line Type*, assign the correct circuit type for each line. Analog line types are:
 - 51** for loop start DTMF, **52** for loop start DP.
- 3. By default, each extension has full incoming and outgoing access to each line. To change this assignment:**
 - In *2131-[01-64]: Line Access*, change each extension's line access as required. The options are:
 - 0** for no access, **1** for incoming access only, **2** for outgoing access only, **3** for full access
 - Using *902x-Copy* may save you time.
- 4. By default, extensions 300-315 ring immediately day and night for lines 1-12. To change this assignment:**
 - In *2132-[01-64]: Line Ringing*, set the ringing option for each extension, The options are:
 - 0** for lamp only (no ringing) day and night, **1** for day and night ringing, **2** for night ringing only, **3** for delay ringing day and night
 - Using *902x-Copy* may save you time.
- 5. To change the default system passwords:**
 - Turn to the *System Programming Password Protection* feature to learn more about system passwords.

(1 0 9 3 0 8 8)

June 15, 2006, Rev 1
Printed in U.S.A.

Empowered by Innovation **NEC**

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>