

Reference Manual for the Model DG814 DSL Modem Internet Gateway

NETGEAR

NETGEAR, Inc.
4500 Great America Parkway
Santa Clara, CA 95054 USA
Phone 1-888-NETGEAR

SM-DG814NA-2
June 2002

© 2002 by NETGEAR, Inc. All rights reserved.

Trademarks

NETGEAR is a trademark of Netgear, Inc.

Microsoft, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

Other brand and product names are registered trademarks or trademarks of their respective holders.

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, NETGEAR reserves the right to make changes to the products described in this document without notice.

NETGEAR does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Federal Communications Commission (FCC) Compliance Notice: Radio Frequency Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

EN 55 022 Declaration of Conformance

This is to certify that the Model DG814 DSL Modem Internet Gateway is shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class B (CISPR 22).

Bestätigung des Herstellers/Importeurs

Es wird hiermit bestätigt, daß das Model DG814 DSL Modem Internet Gateway gemäß der im BMPT-AmtsblVfg 243/1991 und Vfg 46/1992 aufgeführten Bestimmungen entstört ist. Das vorschriftsmäßige Betreiben einiger Geräte (z.B. Testsender) kann jedoch gewissen Beschränkungen unterliegen. Lesen Sie dazu bitte die Anmerkungen in der Betriebsanleitung.

Das Bundesamt für Zulassungen in der Telekommunikation wurde davon unterrichtet, daß dieses Gerät auf den Markt gebracht wurde und es ist berechtigt, die Serie auf die Erfüllung der Vorschriften hin zu überprüfen.

Certificate of the Manufacturer/Importer

It is hereby certified that the Model DG814 DSL Modem Internet Gateway has been suppressed in accordance with the conditions set out in the BMPT-AmtsblVfg 243/1991 and Vfg 46/1992. The operation of some equipment (for example, test transmitters) in accordance with the regulations may, however, be subject to certain restrictions. Please refer to the notes in the operating instructions.

Federal Office for Telecommunications Approvals has been notified of the placing of this equipment on the market and has been granted the right to test the series for compliance with the regulations.

Voluntary Control Council for Interference (VCCI) Statement

This equipment is in the second category (information equipment to be used in a residential area or an adjacent area thereto) and conforms to the standards set by the Voluntary Control Council for Interference by Data Processing Equipment and Electronic Office Machines aimed at preventing radio interference in such residential areas.

When used near a radio or TV receiver, it may become the cause of radio interference.

Read instructions for correct handling.

Customer Support

Refer to the Support Information Card that shipped with your Model DG814 DSL Modem Internet Gateway.

World Wide Web

NETGEAR maintains a World Wide Web home page that you can access at the universal resource locator (URL) <http://www.netgear.com>. A direct connection to the Internet and a Web browser such as Internet Explorer or Netscape are required.

Contents

About This Guide

Technical Support	xiii
Related Publications	xiii
Typographical Conventions	xv
Special Message Formats	xv

Chapter 1

Introduction

About the Gateway	1-1
Key Features	1-1
Content Filtering	1-3
Security	1-3
Autosensing 10/100 Ethernet	1-3
TCP/IP	1-4
Easy Installation and Management	1-4
Maintenance and Support	1-5

Chapter 2

Setting Up the Hardware

Package Contents	2-1
Local Network Hardware Requirements	2-2
PC Requirements	2-2
Access Requirement	2-2
The Gateway's Front Panel	2-2
The Gateway's Rear Panel	2-3
Connecting the Gateway	2-4
Connecting to your Local Ethernet Network	2-5
Connecting to Your ADSL Service and Telephone Provider	2-6
ADSL through a modular RJ-11 wall jack.	2-6
ADSL through other wall jacks	2-7
Connecting the Power Adapter	2-7

Verifying Power	2-7
-----------------------	-----

Chapter 3

Preparing Your Network

Preparing Your Personal Computers for IP Networking	3-1
Configuring Windows 95, 98, and ME for IP Networking	3-2
Install or Verify Windows Networking Components	3-2
Assign TCP/IP configuration by DHCP	3-4
Selecting Internet Access Method	3-4
Verifying TCP/IP Properties (Windows)	3-5
Configuring Windows NT or 2000 for IP Networking	3-5
Install or Verify Windows Networking Components	3-5
Verifying TCP/IP Properties	3-6
Configuring the Macintosh for IP Networking	3-6
MacOS 8.6 or 9.x	3-6
MacOS X	3-7
Verifying TCP/IP Properties (Macintosh)	3-8
Your Internet Account	3-8
Login Protocols	3-9
Account Information	3-9
Obtaining ISP Configuration Information (Windows)	3-10
Obtaining ISP Configuration Information (Macintosh)	3-11
Restarting the Network	3-11
Ready for Configuration	3-11

Chapter 4

Basic Configuration of the Gateway

Accessing the Web Configuration Manager	4-1
Configuration using the Setup Wizard	4-4
Configuring for Dynamic IP Account	4-5
Configuring for Fixed IP Account	4-6
Configuring for an Account with Login	4-7
Manual Configuration	4-8
Completing the Configuration	4-9

Chapter 5

Content Filtering

Configuring for Content Filtering	5-1
---	-----

Logs	5-2
Log entries are described in Table 5-1	5-2
Block Sites	5-3
Schedule	5-4
E-Mail	5-5
Chapter 6	
Maintenance	
Gateway Status	6-1
Attached Devices	6-6
Configuration File Settings Management	6-7
Restore and Backup the Configuration	6-7
Erase the Configuration	6-8
Changing the Configuration Password	6-8
Gateway Upgrade	6-9
Chapter 7	
Advanced Configuration of the Gateway	
Configuring for Port Forwarding to Local Servers	5-1
Add a Custom Service	5-2
Edit or Delete a Port Forwarding Entry	5-3
Local Web and FTP Server Example	5-3
Tip: Multiple Computers for Half Life, KALI or Quake III	5-3
NAT Status	5-4
Security	5-5
DMZ Server	5-5
Respond to Ping on Internet WAN Port	5-6
Dynamic DNS	5-6
LAN IP Setup	5-7
DHCP	5-8
Use router as DHCP server	5-8
Static Routes	5-9
Static Route Example	5-11
Chapter 8	
Troubleshooting	
Basic Functioning	7-1
PWR LED Not On	7-1

Test LED Never Blinks or LED Stays On	7-2
Troubleshooting the Web Configuration Interface	7-2
Troubleshooting the ISP Connection	7-3
ADSL link	7-3
WAN LED Blinking Yellow	7-3
WAN LED Off	7-4
Obtaining a WAN IP Address	7-4
Troubleshooting PPPoE or PPPoA	7-5
Troubleshooting Internet Browsing	7-5
Troubleshooting a TCP/IP Network Using a Ping Utility	7-6
Testing the LAN Path to Your Gateway	7-6
Testing the Path from Your PC to a Remote Device	7-7
Restoring the Default Configuration and Password	7-8
Using the Default Reset button	7-8
Problems with Date and Time	7-8

Appendix A

Technical Specifications

General Specifications	A-1
------------------------------	-----

Appendix B

Networks and Routing Basics

Basic Router Concepts	B-1
What is a Router?	B-1
Routing Information Protocol	B-2
IP Addresses and the Internet	B-2
Netmask	B-4
Subnet Addressing	B-4
Private IP Addresses	B-7
Single IP Address Operation Using NAT	B-7
MAC Addresses and Address Resolution Protocol	B-9
Domain Name Server	B-9
IP Configuration by DHCP	B-10
Ethernet Cabling	B-11
Uplink Switches, Crossover Cables, and MDI/MDIX Switching	B-11
Cable Quality	B-12

Glossary

Figure 2-1.	DG814 Front Panel	2-2
Figure 2-2.	DG814 Rear Panel	2-3
Figure 2-3.	Typical installation	2-5
Figure 4-1.	Login window	4-2
Figure 4-2.	Browser-based configuration main menu	4-3
Figure 4-3.	Setup Wizard menu for Dynamic IP address	4-5
Figure 4-4.	Setup Wizard menu for Fixed IP address	4-6
Figure 4-5.	Setup Wizard menu for PPPoE login accounts	4-7
Figure 6-1.	Gateway Status screen	6-2
Figure 6-2.	Gateway Statistics screen	6-4
Figure 6-3.	PPPoE Status screen	6-5
Figure 6-4.	Ping Status screen	6-6
Figure 6-5.	Attached Devices menu	6-6
Figure 6-6.	Backup Settings menu	6-7
Figure 6-7.	Set Password menu	6-8
Figure 6-8.	Gateway Upgrade menu	6-9
Figure 7-1.	Port Forwarding Menu.	5-1
Figure 7-2.	Security menu.	5-5
Figure 7-3.	LAN IP Setup Menu	5-7
Figure 7-4.	Static Route Summary Table	5-10
Figure 7-5.	Static Route Entry and Edit Menu	5-10
Figure B-1.	Three Main Address Classes	B-3
Figure B-2.	Example of Subnetting a Class B Address	B-5
Figure B-3.	Single IP Address Operation Using NAT	B-8

Table 2-1.	LED Descriptions	2-3
Table 5-1.	Log entry descriptions	5-2
Table 5-2.	Log action buttons	5-5
Table 6-1.	Menu 3.2 - System Status Fields	6-2
Table 6-2.	Gateway Statistics Fields	6-4
Table B-1.	Netmask Notation Translation Table for One Octet	B-6
Table B-2.	Netmask Formats	B-6
Table B-3.	UTP Ethernet cable wiring, straight-through	B-11

About This Guide

Congratulations on your purchase of the NETGEAR™ Model DG814 DSL Modem Internet Gateway.

The Model DG814 gateway provides a secure connection for multiple personal computers (PCs) to the Internet through an internal ADSL modem that is normally intended for use by a single PC.



Note: If you are unfamiliar with networking and routing, refer to [Appendix B, “Networks and Routing Basics”](#), to become more familiar with the terms and procedures used in this manual.

Technical Support

For help with any technical issues, contact Customer Support, or visit us on the Web at www.NETGEAR.com. The NETGEAR Web site includes an extensive knowledge base, answers to frequently asked questions, and a means for submitting technical questions online.

Related Publications

As you read this document, you may be directed to various RFC documents for further information. An RFC is a Request For Comment (RFC) published by the Internet Engineering Task Force (IETF), an open organization that defines the architecture and operation of the Internet. The RFC documents outline and define the standard protocols and procedures for the Internet. The documents are listed on the World Wide Web at www.ietf.org and are mirrored and indexed at many other sites worldwide.

For more information about address assignment, refer to the IETF documents RFC 1597, *Address Allocation for Private Internets*, and RFC 1466, *Guidelines for Management of IP Address Space*.

For more information about IP address translation, refer to RFC 1631, *The IP Network Address Translator (NAT)*.

Typographical Conventions

This guide uses the following typographical conventions:

<i>italics</i>	Book titles and UNIX file, command, and directory names.
<code>courier font</code>	Screen text, user-typed command-line entries.
Initial Caps	Menu titles and window and button names.
[Enter]	Named keys in text are shown enclosed in square brackets. The notation [Enter] is used for the Enter key and the Return key.
[Ctrl]+C	Two or more keys that must be pressed simultaneously are shown in text linked with a plus (+) sign.
ALL CAPS	DOS file and directory names.

Special Message Formats

This guide uses the following formats to highlight special messages:



Note: This format is used to highlight information of importance or special interest.



Caution: This format is used to highlight information that will help you prevent equipment failure or loss of data.



Warning: This format is used to highlight information about the possibility of injury or equipment damage.



Danger: This format is used to alert you that there is the potential for incurring an electrical shock if you mishandle the equipment.

Chapter 1

Introduction

This chapter describes the features of the NETGEAR Model DG814 DSL Modem Internet Gateway.

About the Gateway

The Model DG814 DSL Modem Internet Gateway with 4-port switch connects your local area network (LAN) to the Internet using a built-in ADSL modem.

The Model DG814 gateway provides you with multiple Web content filtering options, plus browsing activity reporting and instant alerts via e-mail. Parents and network administrators can establish restricted access policies based on time-of-day and address keywords, and share high-speed ADSL Internet access for up to 253 personal computers. Network Address Translation (NAT) protects you from hackers.

With minimum setup, you can install and use the gateway within minutes.

Key Features

The Model DG814 gateway provides the following features:

- Easy, web-based setup for installation and management
 - Smart Wizard automatically senses Internet connection type
- Security
 - Parental control of web browsing using Web Address (URL) keyword blocking
 - Auditing and e-mail reporting of web browsing activities

- Blocking can be scheduled by day and time
- Network Address Translation (NAT) hides local PCs from the Internet
- Incoming port forwarding and DMZ for specific services
- Built in 4-port 10/100 Mbps Switch
 - Allows LAN connections at 10 megabits per second (Mbps) or 100 Mbps
 - Autosensing for Ethernet (10BASE-T) or Fast Ethernet (100BASE-Tx) transmissions
 - Half-duplex or full-duplex operation
- Direct connection to the wide area network (WAN) using the built-in ADSL modem
- Protocol Support
 - IP routing
 - Network Address Translation (NAT) for operation with a single static or dynamic IP address
 - Dynamic Host Configuration Protocol (DHCP) server for dynamically assigning network configuration information to PCs on the LAN
 - DHCP client for dynamically obtaining configuration information from the Internet Service Provider (ISP)
 - DNS Proxy for simplified configuration
 - PPP over Ethernet (PPPoE) support
 - PPP over ATM (PPPoA) support
 - Classical IP support
- Login capability
 - Automatically executes user login for:
 - Automatically executes user login for PPP over Ethernet or PPP over ATM accounts
- Easy, web-based setup for configuration
- Front panel LEDs for easy monitoring of status and activity
- Flash memory for firmware upgrade
- Free technical support seven days a week, twenty-four hours a day

Content Filtering

With its content filtering features, the Model DG814 gateway prevents objectionable content from reaching your PCs. Its content filtering features include:

- **Content filtering by domain or keyword**
The Model DG814 gateway uses content filtering to enforce your network's Internet access policies. The gateway allows you to control access to Internet content by screening for keywords within Website names or newsgroup names.
- **Logging of inappropriate use**
You can configure the Model DG814 gateway to log access to Web sites and to e-mail the log to you. You can also configure the gateway to send an immediate alert e-mail message to you whenever a local user attempts to access a blocked Web site.

Security

The Model DG814 gateway is equipped with several features designed to maintain security, as described in this section.

- **PCs Hidden by NAT**
Network address translation (NAT) opens a temporary path to the Internet for requests originating from the local network. Requests originating from outside the LAN are discarded, preventing users outside the LAN from finding and directly accessing the PCs on the LAN.
- **Port Forwarding with NAT**
Although NAT prevents Internet locations from directly accessing the PCs on the LAN, the gateway allows you to direct incoming traffic to specific PCs based on the service port number of the incoming request, or to one designated "DMZ" host computer. You can specify forwarding of single ports or ranges of ports.

Autosensing 10/100 Ethernet

With its internal, 4-port 10/100 switch, the Model DG814 gateway can connect to either a 10 Mbps standard Ethernet network or a 100 Mbps Fast Ethernet network. The local LAN interface is autosensing and is capable of full-duplex or half-duplex operation.

The Model DG814 gateway incorporates Auto Uplink™ technology (also called MDI/MDIX). Each LOCAL Ethernet port will automatically sense whether the Ethernet cable plugged into the port should have a 'normal' connection (e.g. connecting to a PC) or an 'uplink' connection (e.g. connecting to a router, switch, or hub). That port will then configure itself to the correct configuration. This feature also eliminates the need to worry about crossover cables, as Auto Uplink™ will accommodate either type of cable to make the right connection.

TCP/IP

The Model DG814 gateway supports the Transmission Control Protocol/Internet Protocol (TCP/IP) and Routing Information Protocol (RIP).

For further information about TCP/IP, refer to [Appendix B, “Networks and Routing Basics.”](#)

- **IP Address Sharing by NAT**
The Model DG814 gateway allows several networked PCs to share an Internet account using only a single IP address, which may be statically or dynamically assigned by your Internet service provider (ISP). This technique, known as Network Address Translation (NAT), allows the use of an inexpensive single-user ISP account.
- **Automatic Configuration of Attached PCs by DHCP**
The Model DG814 gateway dynamically assigns network configuration information, including IP, gateway, and domain name server (DNS) addresses, to attached PCs on the LAN using the Dynamic Host Configuration Protocol (DHCP). This feature greatly simplifies configuration of PCs on your local network.
- **DNS Proxy**
When DHCP is enabled and no DNS addresses are specified, the gateway provides its own address as a DNS server to the attached PCs. The gateway obtains actual DNS addresses from the ISP during connection setup and forwards DNS requests from the LAN.
- **PPP over Ethernet (PPPoE and PPP over ATM (PPPoA))**
PPP over Ethernet is a protocol for connecting remote hosts to the Internet over an always-on connection by simulating a dial-up connection. This feature eliminates the need to run a login program such as Entersys or WinPOET on your PC.

Easy Installation and Management

You can install, configure, and operate the Model DG814 DSL Modem Internet Gateway within minutes after connecting it to the network. The following features simplify installation and management tasks:

- **Animated installation assistant**
The Resource CD contains an animated installation assistant to guide you through set up.
- **Browser-based management**
Browser-based configuration allows you to easily configure your gateway from almost any type of personal computer, such as Windows, Macintosh, or Linux. A user-friendly Setup Wizard is provided and online help documentation is built into the browser-based Web Management Interface.
- **Smart Wizard**
The Model DG814 gateway automatically senses the type of Internet connection, asking you only for the information required for your type of ISP account.
- **Visual monitoring**
The Model DG814 gateway's front panel LEDs provide an easy way to monitor its status and activity.

Maintenance and Support

NETGEAR offers the following features to help you maximize your use of the Model DG814 gateway:

- Flash memory for firmware upgrade
- Free technical support seven days a week, twenty-four hours a day

Chapter 2

Setting Up the Hardware

This chapter describes the Model DG814 DSL Modem Internet Gateway hardware and provides instructions for installing it.

Package Contents

The product package should contain the following items:

- Model DG814 DSL Modem Internet Gateway
- AC power adapter, 18 V AC output (varies by region)
- Category 5 (Cat 5) Ethernet cable, straight-through wiring
- Telephone cable
- Microfilters (quantity and type vary by region)
- *Model DG814 Resource CD*, including:
 - This guide
 - Application Notes
- *DG814 DSL Modem Internet Gateway Installation Guide*
- Warranty Card
- Support Information Card

If any of the parts are incorrect, missing, or damaged, contact your NETGEAR dealer. Keep the carton, including the original packing materials, in case you need to return the gateway for repair.

Local Network Hardware Requirements

The Model DG814 DSL Modem Internet Gateway is intended for use in a network of personal computers (PCs) that are interconnected by twisted-pair Ethernet cables.

PC Requirements

To install and run the Model DG814 gateway over your network of PCs, each PC must have an installed Ethernet Network Interface Card (NIC) and an Ethernet cable. If the PC will connect to your network at 100 Mbps, you must use a Category 5 (CAT5) cable such as the cable provided with your gateway.

Access Requirement

The Model DG814 DSL Modem Internet Gateway contains a built-in ADSL modem, which connects directly to an ADSL service provider.

The Gateway's Front Panel

The front panel of the Model DG814 gateway ([Figure 2-1](#)) contains status LEDs.








Figure 2-1. DG814 Front Panel

You can use some of the LEDs to verify connections. [Table 2-1](#) lists and describes each LED on the front panel of the Model DG814 gateway. These LEDs are green when lit.

Table 2-1. LED Descriptions

Label	Activity	Description
Power 	On Off	Power is supplied to the gateway. Power is not supplied to the gateway.
Test 	On Off	The system is initializing. The system is ready and running.
ADSL (Wide Area Network) 	On (Green) Blink (Green) Blink (Yellow) Off	The ADSL port has linked with the service provider. Data is being transmitted or received over the ADSL port. The ADSL port is attempting to train with the service provider. The ADSL port is not making contact with the service provider.
Local (Local Area Network) 	On (Green) Blink (Green) On (Yellow) Blink (Yellow) Off	The Local port has detected link with a 100 Mbps device. Data is being transmitted or received at 100 Mbps. The Local port has detected link with a 10 Mbps device. Data is being transmitted or received at 10 Mbps. No link is detected on this port.

The Gateway's Rear Panel

The rear panel of the Model DG814 gateway ([Figure 2-2](#)) contains port connections and a power switch.




Figure 2-2. DG814 Rear Panel

The rear panel contains the following features (from left to right):

- Power switch
- 18 V AC power adapter outlet
- Four Local (LAN) Ethernet ports for connecting the gateway to the local PCs
- Factory Default Reset push-button
- ADSL (WAN) port, with two identical connectors, for connecting the gateway to the ADSL service provider. One of the ports can be connected to a telephone using an external microfilter.

Connecting the Gateway

Before using your gateway, you need to do the following:

- Connect your local Ethernet network to the Local port(s) of the gateway (see [page 2-5](#)).
- Connect the line from your ADSL service provider to the ADSL port of the gateway (see [page 2-6](#)).
- Connect the power adapter (see [page 2-7](#)).

A typical installation is shown in [Figure 2-3](#), below




Figure 2-3. Typical installation

Connecting to your Local Ethernet Network

Your local network (LAN) will attach to the four Local gateway ports shown in [Figure 2-2](#). The Local ports operate at either 10 Mbps (10BASE-T) or 100 Mbps (100BASE-Tx), depending on the Ethernet interface of the attached PC, hub, or switch. For any connection which will operate at 100 Mbps, you must use a Category 5 (Cat 5) rated Ethernet cable, such as the cable included with the gateway.

The Model DG814 gateway incorporates a four-port switch for connecting to your local network. To connect the Model DG814 gateway to your LAN:

- Connect up to four PCs directly to any of the four Local ports of the gateway using standard Ethernet cables.

If your local network consists of more than four computers, you will need to connect your gateway to another hub or switch:

- Connect any Local port of your gateway to any port of an Ethernet hub or switch using a standard or crossover Ethernet cable.

Because the gateway incorporates Auto Uplink™ technology (also called Auto MDI/MDI-X), it is capable of automatically sensing the polarity of the Ethernet connection. You can therefore connect to the other hub's normal or uplink port using a standard or crossover Ethernet cable. The Local port of your Model DG814 gateway will automatically configure itself properly.

Connecting to Your ADSL Service and Telephone Provider

The ADSL and telephone connections may vary by region.

ADSL through a modular RJ-11 wall jack.



Note: The wall jack attached to the ADSL port of the gateway must provide the ADSL signal on the inner pair of wires (pins 2 and 3 of the 4-pin jack). If this is not the case, a swapper (not included) is necessary to move the connection to the inner pair.

To install the Model DG814 gateway directly to the wall jack without installing a telephone:

1. Connect the provided telephone cable to the wall jack.
2. Connect the other end of the telephone cable to the ADSL port on the gateway.

To install both the Model DG814 gateway and a telephone:

1. Plug the "LINE" connection from the included microfilter into the wall jack.
2. Connect the "DSL" jack of the microfilter to the ADSL port of your gateway using the telephone cable provided.
3. Connect the "PHONE" side of the microfilter to your telephone, using your existing telephone cable.

ADSL through other wall jacks

1. Plug the “LINE” connection from the included microfilter into the wall jack.
2. Connect the “DSL” jack of the microfilter to the ADSL port of your gateway using the telephone cable provided.
3. Connect the “PHONE” side of the microfilter to your telephone, using your existing telephone cable.

A telephone can be attached to the second RJ-11 jack on your gateway. However, a microfilter should be connected between the gateway and the telephone. Be careful to connect the microfilter according to its markings, with the “LINE” side plugged into the gateway and the “PHONE” side connected to your telephone.

If you have additional telephones, you will need to purchase additional microfilters and connect them between the telephones and the wall jack. A microfilter is required for each telephone on the line.



Note: Microfilters are required to isolate your ADSL signal from your telephone signal. If microfilters are not used, or if they are connected backward, you may notice a “ticking” noise on your telephone, and the performance of your ADSL line may be affected.

Connecting the Power Adapter

To connect the power adapter to the gateway:

1. Plug the connector of the power adapter into the 18 V AC adapter outlet on the rear panel of the gateway.
2. Plug the other end of the adapter into a standard wall outlet.
3. Set the gateway’s Power switch to the ON position.
4. Verify that the PWR LED on the gateway is lit.

Verifying Power

After applying power to the gateway, complete the following steps to verify that power is correctly applied:

1. When power is first applied, verify that the Power LED comes on.

All LEDs will briefly be tested.

2. After approximately 10 seconds, verify that:
 - The Test LED is not lit.
 - The Local port LEDs are lit for any local ports that are connected.
3. If a port's LED is lit, a link has been established to the connected device. If a Local port is connected to a 100 Mbps device, verify that the port's LED is green. If the port is 10 Mbps, the LED should be yellow.

You are now ready to begin configuration of your network, as described in the following chapter.

Chapter 3

Preparing Your Network

This chapter describes how to prepare your PC network to connect to the Internet through the Model DG814 DSL Modem Internet Gateway and how to order broadband Internet service from an Internet service provider (ISP).



Note: If an ISP technician configured your PC during the installation of a broadband modem, or if you configured it using instructions provided by your ISP, you may need to copy the current configuration information for use in the configuration of your gateway. Write down this information before reconfiguring your PCs. Refer to “[Obtaining ISP Configuration Information \(Windows\)](#)” on [page 3-10](#) or “[Obtaining ISP Configuration Information \(Macintosh\)](#)” on [page 3-11](#) for further information.

Preparing Your Personal Computers for IP Networking

Personal Computers access the Internet using a protocol called TCP/IP (Transmission Control Protocol/Internet Protocol). Each PC on your network must have TCP/IP installed and selected as its networking protocol. If a Network Interface Card (NIC) is already installed in your PC, then TCP/IP is probably already installed as well.

Note: In this chapter, we use the term “PC” to refer to personal computers in general, and not necessarily Windows computers.

Most PC operating systems include the software components you need for networking with TCP/IP:

- Windows® 95 or later includes the software components for establishing a TCP/IP network.
- Windows 3.1 does not include a TCP/IP component. You need to purchase a third-party TCP/IP application package such as NetManage Chameleon.

- Macintosh Operating System 7 or later includes the software components for establishing a TCP/IP network.
- All versions of UNIX or Linux include TCP/IP components. Follow the instructions provided with your operating system or networking software to install TCP/IP on your computer.

In your IP network, each PC and the gateway must be assigned a unique IP addresses. Each PC must also have certain other IP configuration information such as a subnet mask (netmask), a domain name server (DNS) address, and a default gateway address. In most cases, you should install TCP/IP so that the PC obtains its specific network configuration information automatically from a DHCP server during bootup. For a detailed explanation of the meaning and purpose of these configuration items, refer to “[Appendix B, “Networks and Routing Basics.”](#)”

The Model DG814 gateway is shipped preconfigured as a DHCP server. The gateway assigns the following TCP/IP configuration information automatically when the PCs are rebooted:

- PC or workstation IP addresses—192.168.0.2 through 192.168.0.254
- Subnet mask—255.255.255.0
- Gateway address (the gateway)—192.168.0.1

These addresses are part of the IETF-designated private address range for use in private networks.

Configuring Windows 95, 98, and ME for IP Networking


As part of the PC preparation process, you need to manually install and configure TCP/IP on each networked PC. Before starting, locate your Windows CD; you may need to insert it during the TCP/IP installation process.

Install or Verify Windows Networking Components

To install or verify the necessary components for IP networking:

1. On the Windows taskbar, click the Start button, point to Settings, and then click Control Panel.
2. Double-click the Network icon.

The Network window opens, which displays a list of installed components:



You must have an Ethernet adapter, the TCP/IP protocol, and Client for Microsoft Networks.



Note: It is not necessary to remove any other network components shown in the Network window in order to install the adapter, TCP/IP, or Client for Microsoft Networks.

If you need the adapter:

- a. Click the Add button.
- b. Select Adapter, and then click Add.
- c. Select the manufacturer and model of your Ethernet adapter, and then click OK.

If you need TCP/IP:

- a. Click the Add button.
- b. Select Protocol, and then click Add.
- c. Select Microsoft.
- d. Select TCP/IP, and then click OK.

If you need Client for Microsoft Networks:

- a. Click the Add button.
 - b. Select Client, and then click Add.
 - c. Select Microsoft.
 - d. Select Client for Microsoft Networks, and then click OK.
3. Restart your PC for the changes to take effect.

Assign TCP/IP configuration by DHCP

After the TCP/IP protocol components are installed, each PC must be assigned specific information about itself and resources that are available on its network. The simplest way to configure this information is to allow the PC to obtain the information from the internal DHCP server of the Model DG814 gateway. To use DHCP with the recommended default addresses, follow these steps:

1. Connect all PCs to the gateway, then restart the gateway and allow it to boot.
2. On each attached PC, open the Network control panel (refer to the previous section) and select the Configuration tab.
3. From the components list, select TCP/IP->(your Ethernet adapter) and click Properties.
4. In the IP Address tab, select “Obtain an IP address automatically”.
5. Select the Gateway tab.
6. If any gateways are shown, remove them.
7. Click OK.
8. Restart the PC.

Repeat steps 2 through 8 for each PC on your network.

Selecting Internet Access Method

1. On the Windows taskbar, click the Start button, point to Settings, and then click Control Panel.
2. Double-click the Internet Options icon.
3. Select “I want to set up my Internet connection manually” or “I want to connect through a Local Area Network” and click Next.

4. Select “I want to connect through a Local Area Network” and click Next.
5. Uncheck all boxes in the LAN Internet Configuration screen and click Next.
6. Proceed to the end of the Wizard.

Verifying TCP/IP Properties (Windows)

After your PC is configured and has rebooted, you can check the TCP/IP configuration using the utility *wiipcfg.exe*:

1. On the Windows taskbar, click the Start button, and then click Run.
2. Type **wiipcfg**, and then click OK.

The IP Configuration window opens, which lists (among other things), your IP address, subnet mask, and default gateway.

3. From the drop-down box, select your Ethernet adapter.

The window is updated to show your settings, which should match the values below if you are using the default TCP/IP settings that NETGEAR recommends:

- The IP address is between 192.168.0.2 and 192.168.0.254
- The subnet mask is 255.255.255.0
- The default gateway is 192.168.0.1

Configuring Windows NT or 2000 for IP Networking

As part of the PC preparation process, you need to manually install and configure TCP/IP on each networked PC. Before starting, locate your Windows CD; you may need to insert it during the TCP/IP installation process.

Install or Verify Windows Networking Components

To install or verify the necessary components for IP networking:

1. On the Windows taskbar, click the Start button, point to Settings, and then click Control Panel.
2. Double-click the Network and Dialup Connections icon.
3. If an Ethernet adapter is present in your PC, you should see an entry for Local Area Connection. Double-click that entry.

4. Select Properties.
5. Verify that 'Client for Microsoft Networks' and 'Internet Protocol (TCP/IP)' are present. If not, select Install and add them.
6. Select 'Internet Protocol (TCP/IP)', click Properties, and verify that "Obtain an IP address automatically" is selected.
7. Click OK and close all Network and Dialup Connections windows.
8. Make sure your PC is connected to the gateway, then reboot your PC.

Verifying TCP/IP Properties

To check your PC's TCP/IP configuration:

1. On the Windows taskbar, click the Start button, and then click Run.

The Run window opens.

2. Type `cmd` and then click OK.

A command window opens

3. Type `ipconfig /all`

Your IP Configuration information will be listed, and should match the values below if you are using the default TCP/IP settings that NETGEAR recommends:

- The IP address is between 192.168.0.2 and 192.168.0.254
- The subnet mask is 255.255.255.0
- The default gateway is 192.168.0.1

4. Type `exit`


Configuring the Macintosh for IP Networking

Beginning with Macintosh Operating System 7, TCP/IP is already installed on the Macintosh. On each networked Macintosh, you will need to configure TCP/IP to use DHCP.

MacOS 8.6 or 9.x

1. From the Apple menu, select Control Panels, then TCP/IP.

The TCP/IP Control Panel opens:




2. From the “Connect via” box, select your Macintosh’s Ethernet interface.
3. From the “Configure” box, select Using DHCP Server.
You can leave the DHCP Client ID box empty.
4. Close the TCP/IP Control Panel.
5. Repeat this for each Macintosh on your network.

MacOS X

1. From the Apple menu, choose System Preferences, then Network.
2. If not already selected, select Built-in Ethernet in the Configure list.
3. If not already selected, Select Using DHCP in the TCP/IP tab.
4. Click Save.

Verifying TCP/IP Properties (Macintosh)

After your Macintosh is configured and has rebooted, you can check the TCP/IP configuration by returning to the TCP/IP Control Panel. From the Apple menu, select Control Panels, then TCP/IP.



The panel is updated to show your settings, which should match the values below if you are using the default TCP/IP settings that NETGEAR recommends:

- The IP Address is between 192.168.0.2 and 192.168.0.254
- The Subnet mask is 255.255.255.0
- The Router address is 192.168.0.1

If you do not see these values, you may need to restart your Macintosh or you may need to switch the “Configure” setting to a different option, then back again to “Using DHCP Server”.

Your Internet Account

For access to the Internet, you need to contract with an Internet service provider (ISP) for a single-user Internet access account using ADSL. The Model DG814 DSL Modem Internet Gateway includes a built-in ADSL modem that connects directly to your ADSL line.

For a single-user Internet account, your ISP supplies TCP/IP configuration information (such as IP address, subnet mask and default gateway) and VPI and VCI multiplexing information for one PC. Your ISP may also provide other login information, such as User Name and Password, in the case where the PPPoE or PPPoA protocol is required. With a typical account, much of the configuration information is dynamically assigned when your PC is first booted up while connected to the ISP, and you will not need to know that dynamic information.

In order to share the Internet connection among several computers, your gateway takes the place of the single PC, and you need to configure it with the TCP/IP information that the single PC would normally use. When the gateway's ADSL port is connected, the gateway appears to be a single PC to the ISP. The gateway then allows the PCs on the local network to masquerade as the single PC to access the Internet through the broadband modem. The method used by the gateway to accomplish this is called Network Address Translation (NAT) or IP masquerading.

Login Protocols

Some ISPs require a special login protocol, in which you must enter a login name and password in order to access the Internet. If you normally log in to your Internet account by running a program such as WinPOET or EnterNet, then your account uses PPP over Ethernet (PPPoE).

When you configure your gateway, you will need to enter your login name and password in the gateway's configuration menus. After your network and gateway are configured, the gateway will perform the login task when needed, and you will no longer need to run the login program from your PC. It is not necessary to uninstall the login program.

Account Information

Unless these items are dynamically assigned by the ISP, your ISP should give you the following basic information for your account:

- An IP address and subnet mask
- A gateway IP address, which is the address of the ISP's router
- One or more domain name server (DNS) IP addresses
- Host name and domain suffix

For example, your account's full server names may look like this:

```
mail.xxx.yyy.com
```

In this example, the domain suffix is `xxx.yyy.com`.

If any of these items are dynamically supplied by the ISP, your gateway automatically acquires them. If an ISP technician configured your PC during the installation of the broadband modem, or if you configured it using instructions provided by your ISP, you need to copy configuration information from your PC's Network TCP/IP Properties window (or Macintosh TCP/IP Control Panel) before reconfiguring your PC for use with the gateway. These procedures are described next.

Obtaining ISP Configuration Information (Windows)

As mentioned above, you may need to collect configuration information from your PC so that you can use this information when you configure the Model DG814 gateway. Following this procedure is only necessary when your ISP does not dynamically supply the account information.

To get the information you need to configure the gateway for Internet access:

1. On the Windows taskbar, click the Start button, point to Settings, and then click Control Panel.
2. Double-click the Network icon.

The Network window opens, which displays a list of installed components.

3. Select TCP/IP, and then click Properties.

The TCP/IP Properties dialog box opens.

4. Select the IP Address tab.

If an IP address and subnet mask are shown, write down the information. If an address is present, your account uses a fixed (static) IP address. If no address is present, your account uses a dynamically-assigned IP address. Click "Obtain an IP address automatically".

5. Select the Gateway tab.

If an IP address appears under Installed Gateways, write down the address. This is the ISP's gateway address. Select the address and then click Remove to remove the gateway address.

6. Select the DNS Configuration tab.

If any DNS server addresses are shown, write down the addresses. If any information appears in the Host or Domain information box, write it down. Click Disable DNS.

7. Click OK to save your changes and close the TCP/IP Properties dialog box.

You are returned to the Network window.

8. Click OK.

9. Reboot your PC at the prompt. You may also be prompted to insert your Windows CD.

Obtaining ISP Configuration Information (Macintosh)

As mentioned above, you may need to collect configuration information from your Macintosh so that you can use this information when you configure the Model DG814 gateway. Following this procedure is only necessary when your ISP does not dynamically supply the account information.

To get the information you need to configure the gateway for Internet access:

1. From the Apple menu, select Control Panels, then TCP/IP.

The TCP/IP Control Panel opens, which displays a list of configuration settings. If the “Configure” setting is “Using DHCP Server”, your account uses a dynamically-assigned IP address. In this case, close the Control Panel and skip the rest of this section.

2. If an IP address and subnet mask are shown, write down the information.
3. If an IP address appears under Router address, write down the address. This is the ISP’s gateway address.
4. If any Name Server addresses are shown, write down the addresses. These are your ISP’s DNS addresses.
5. If any information appears in the Search domains information box, write it down.
6. Change the “Configure” setting to “Using DHCP Server”.
7. Close the TCP/IP Control Panel.

Restarting the Network

Once you’ve set up your computers to work with the gateway, you must reset the network for the devices to be able to communicate correctly.

1. Turn off the Model DG814 gateway, and then turn it on again and wait until the Test light turns off.
2. Restart any computer that is connected to the firewall.

Ready for Configuration

After configuring all of your PCs for TCP/IP networking and connecting them to the local network of your Model DG814 gateway, you are ready to access and configure the gateway. Proceed to the next chapter.

Chapter 4

Basic Configuration of the Gateway


This chapter describes how to perform the basic configuration of your Model DG814 DSL Modem Internet Gateway using the Setup Wizard, which walks you through the configuration process for your Internet connection.

Accessing the Web Configuration Manager

In order to use the browser-based Web Configuration Manager, your PC must have a web browser program installed such as Microsoft Internet Explorer or Netscape Navigator. Because the Configuration Manager uses Java, your Web browser must be Java-enabled and support HTTP uploads. NETGEAR recommends using Microsoft Internet Explorer or Netscape Navigator 4.0 or above. Free browser programs are readily available for Windows, Macintosh, or UNIX/Linux.

To configure for Internet access using your browser:

1. Turn on the gateway and wait for initialization to complete.

Allow at least ten seconds and verify that the Test LED is off. 

2. Reboot your PC to obtain DHCP configuration from the gateway.
3. Launch your web browser.

Note: If you normally use a login program (such as Enternet or WinPOET) to access the Internet, do not launch that program.

4. Click your browser's Stop button.
5. In the Address (or Location) box of your browser, type **http://192.168.0.1** and press ENTER.

A login window opens as shown in [Figure 4-1](#) below:.




Figure 4-1. Login window

This screen may have a different appearance in other browsers.

6. Type **admin** in the User Name box, **password** in the Password box, and then click OK.

If your gateway password was previously changed, enter the current password.

If your gateway has not yet been configured, the Setup Wizard should launch automatically. Otherwise, the main menu of the Web Configuration Manager will appear as shown in [Figure 4-2](#) below:

NETGEAR DSL Modem Internet Gateway DG814
settings

Setup

- Basic Settings
- Content Filtering
- Logs
- Block Sites
- Schedule
- E-mail

Maintenance

- Gateway Status
- Attached Devices
- Backup Settings
- Set Password
- Gateway Upgrade

Advanced

- Port Forwarding
- Security
- Dynamic DNS
- LAN IP Setup
- Static Routes

Logout

Basic Settings

Does Your Internet Connection Require A Login?

Yes
 No

Account Name (If Required)

Domain Name (If Required)

Internet IP Address

Get Dynamically From ISP
 Use Static IP Address

IP Address

IP Subnet Mask

Gateway IP Address

Domain Name Server (DNS) Address

Get Automatically From ISP
 Use These DNS Servers

Primary DNS

Secondary DNS

ISP Parameters for Internet Access

Multiplexing Method

Virtual Circuit

VPI (0~255)

VCI (0~65535)

Help

The DG814 *Settings* pages allow you to configure, upgrade and check the status of your NETGEAR DSL Modem Internet Gateway.

Click an item in the leftmost column. The current settings or information for that area appear in the center column.

Helpful information related to the selected *Settings* page appears in this column. If you are using Internet Explorer, you may click an item in the center column to jump directly to the related help section, otherwise, scroll down until you reach it.

Basic Settings Help

Note: If you are setting up the gateway for the first time, the default settings may work for you with no changes.

Does Your Internet Connection Require A Login?

Select this option based on the type of account you have with your ISP. If you need to enter login information every time you connect to the Internet or you have a PPPoE account with your ISP, select **Yes**. Otherwise, select **No**.

Account Name

(also known as Host Name or System Name)

For most users, type your account name or user name in this box. For example, if your main mail account is JerAB@ISP.com, then put JerAB in this box.

If your ISP has given you a specific Host name, then type it (for example, CCA7324-A).

Domain Name

For most users, you may leave this box blank, unless required by your ISP. You may type the domain name of your ISP. For example, if your ISP's mail server is mail.xxx.yyy.zzz, you would type xxx.yyy.zzz as the Domain Name.

Figure 4-2. Browser-based configuration main menu

You can manually configure your gateway using this menu as described in “[Manual Configuration](#)” on page 4-8, or you can allow the Setup Wizard to determine your configuration as described in the following chapter.

Configuration using the Setup Wizard

The Web Configuration Manager contains a Setup Wizard that can automatically determine your network connection type. If the Setup Wizard does not launch automatically, click on the Setup Wizard heading in the upper left of the opening screen, shown in [Figure 4-2](#).

When the Wizard launches, allow the gateway to automatically determine your connection type by selecting Yes in the menu below and clicking Next:

Setup Wizard

System Can Now Detect The Connection Type Of WAN Port, Or You Can Configure It By Yourself.

Do You Want System To Detect The Connection Type?

- Yes.
- No. I Want To Configure By Myself.
-

Next

The Setup Wizard will now check for a connection on the Internet port. If the Setup Wizard determines that there is no connection to the Internet port, you will be prompted to check the physical ADSL connection. When the connection is properly made, the gateway's Internet LED should be on.



Next, the Setup Wizard will attempt to determine which of the following connection types your Internet service account uses:

- Dynamic IP assignment
- Fixed IP address assignment
- A login protocol such as PPPoE

The Setup Wizard will report which connection type it has discovered, and it will then use the appropriate configuration menu for that connection type.

Configuring for Dynamic IP Account

If the Setup Wizard determines that your Internet service account uses Dynamic IP assignment, you will be directed to the menu shown in [Figure 4-3](#) below.

Dynamic IP

Account Name (If Required)

Domain Name (If Required)

Domain Name Server (DNS) Address

Get Automatically From ISP

Use These DNS Servers

Primary DNS

Secondary DNS

Figure 4-3. Setup Wizard menu for Dynamic IP address

1. Enter your Account Name (may also be called Host Name) and Domain Name. These parameters may be necessary to access your ISP's services such as mail or news servers. If you leave the Domain Name field blank, the gateway will attempt to learn the domain automatically from the ISP. If this is not successful, you may need to enter it manually.
2. Domain Name Server (DNS) Address: If you know that your ISP does not automatically transmit DNS addresses to the gateway during login, select "Use these DNS servers" and enter the IP address of your ISP's Primary DNS Server. If a Secondary DNS Server address is available, enter it also.

A DNS server is a host on the Internet that translates Internet names (such as www addresses) to numeric IP addresses. Typically your ISP transfers the IP addresses of one or two DNS servers to your gateway during login. If the ISP does not transfer an address, you must obtain it from the ISP and enter it manually here. If you enter an address here, you should reboot your PCs after configuring the gateway.

3. Click on Apply, then proceed to ["Completing the Configuration"](#) on page 4-9.

Configuring for Fixed IP Account

If the Setup Wizard determines that your Internet service account uses Fixed IP assignment, you will be directed to the menu shown in [Figure 4-4](#) below:

Fixed IP

Internet IP Address

IP Address

IP Subnet Mask

Gateway IP Address

Domain Name Server (DNS) Address

Primary DNS

Secondary DNS

Figure 4-4. Setup Wizard menu for Fixed IP address

1. Enter your assigned IP Address, Subnet Mask, and the IP Address of your ISP's gateway router. This information should have been provided to you by your ISP.
2. Domain Name Server (DNS) Address: If you know that your ISP does not automatically transmit DNS addresses to the gateway during login, select "Use these DNS servers" and enter the IP address of your ISP's Primary DNS Server. If a Secondary DNS Server address is available, enter it also.

A DNS server is a host on the Internet that translates Internet names (such as www addresses) to numeric IP addresses. Typically your ISP transfers the IP addresses of one or two DNS servers to your gateway during login. If the ISP does not transfer an address, you must obtain it from the ISP and enter it manually here. If you enter an address here, you should reboot your PCs after configuring the gateway.

3. Click on Apply, then proceed to ["Completing the Configuration" on page 4-9](#).

Configuring for an Account with Login

If the Setup Wizard determines that your Internet service account uses a login protocol such as PPP over Ethernet (PPPoE) or PPP over ATM (PPPoA), you will be directed to a menu like the PPPoE menu shown in [Figure 4-5](#) below.

The screenshot shows a configuration window titled "PPPoE". It contains several input fields and a section for DNS settings. The fields are: "Account Name", "Domain Name", "Login", "Password", and "Idle Timeout" (with a value of 5). Below these is a section "Domain Name Server (DNS) Address" with two radio buttons: "Get automatically from ISP" (which is selected) and "Use these DNS servers". Under the second radio button are two more input fields: "Primary DNS" and "Secondary DNS". At the bottom of the window are three buttons: "Apply", "Cancel", and "Test".

Figure 4-5. Setup Wizard menu for PPPoE login accounts

1. Enter your Account Name (may also be called Host Name) and Domain Name. These parameters may be necessary to access your ISP's services such as mail or news servers. If you leave the Domain Name field blank, the gateway will attempt to learn the domain automatically from the ISP. If this is not successful, you will need to enter it manually.
2. Enter the PPPoE or PPPoA login user name and password provided by your ISP. These fields are case sensitive. If you wish to change the login timeout, enter a new value in minutes.

Note: You will no longer need to launch the ISP's login program on your PC in order to access the Internet. When you start an Internet application, your gateway will automatically log you in.

3. Domain Name Server (DNS) Address: If you know that your ISP does not automatically transmit DNS addresses to the gateway during login, select "Use these DNS servers" and enter the IP address of your ISP's Primary DNS Server. If a Secondary DNS Server address is available, enter it also.

A DNS server is a host on the Internet that translates Internet names (such as www addresses) to numeric IP addresses. Typically your ISP transfers the IP addresses of one or two DNS servers to your gateway during login. If the ISP does not transfer an address, you must obtain it from the ISP and enter it manually here. If you enter an address here, you should reboot your PCs after configuring the gateway.

4. Click on Apply, then proceed to [“Completing the Configuration” on page 4-9](#).

Manual Configuration

You can manually configure the gateway in the Basic Settings menu shown in [Figure 4-2](#) using these steps:

1. Select whether your Internet connection requires a login.

Select ‘Yes’ if you normally must launch a login program such as Enternet or WinPOET in order to access the Internet.

- If your service provider does not require a login program enter your Account Name (may also be called Host Name) and Domain Name. These parameters may be necessary to access your ISP’s services such as mail or news servers.

Proceed to Step 2

- If your service provider uses PPP over Ethernet (PPPoE), select Encapsulation as PPP over Ethernet, and enter these additional parameters:
 - a. Enter the PPPoE login user name and password provided by your ISP. These fields are case sensitive.
 - b. If your connection supports multiple ISPs, enter the Service Name of the one you use. Otherwise leave Service Name blank.
 - c. If you wish to change the idle timeout, enter a new value in minutes.

Proceed to Step 2

Note: You will no longer need to launch the ISP’s login program on your PC in order to access the Internet. When you start an Internet application, your gateway will automatically log you in.

- If your service provider uses PPP over ATM (PPPoA), select Encapsulation as PPP over ATM, and enter these additional parameters:
 - a. Enter the PPPoA login user name and password provided by your ISP. These fields are case sensitive.

- b. If you wish to change the idle timeout, enter a new value in minutes..



Note: PPPoE and PPPoA will authenticate with the network when you have data to transmit. The gateway will stay connected until you stop transmitting and will then wait for the login timeout to expire before disconnecting.

2. Internet IP Address: If your ISP has assigned you a permanent, fixed (static) IP address for your PC or gateway, select “Use static IP address”. Enter the IP address that your gateway has been assigned. Also enter the netmask and the Gateway IP address. The Gateway IP Address is the ISP’s router to which your gateway will connect.
3. Domain Name Server (DNS) Address: If you know that your ISP does not automatically transmit DNS addresses to the gateway during login, select “Use these DNS servers” and enter the IP address of your ISP’s Primary DNS Server. If a Secondary DNS Server address is available, enter it also.

A DNS server is a host on the Internet that translates Internet names (such as www addresses) to numeric IP addresses. Typically your ISP transfers the IP addresses of one or two DNS servers to your gateway during login. If the ISP does not transfer an address, you must obtain it from the ISP and enter it manually here. If you enter an address here, you should reboot your PCs after configuring the gateway.

4. ISP Parameters for Internet Access. Your ISP will indicate whether your Multiplexing Method is VC-BASED or LLC-BASED and which VPI and VCI is used. Enter the information in this screen. The most common Multiplexing Method is LLC-based. If your service provider does not indicate which one is used, use LLC-BASED.

Note: The Multiplexing Method and VPI/VCI combination has been preconfigured for your ISP. You should not have to change these parameters.

Note: The Setup Wizard may be able to detect the VPI/VCI configuration automatically, in which case the values will be selected in the VPI/VCI field.

5. Click on Apply, then proceed to [“Completing the Configuration” on page 4-9](#).

Completing the Configuration

Click on the Test button to test your Internet connection. If the NETGEAR website does not appear within one minute, refer to [Chapter 8, “Troubleshooting”](#).

Your gateway is now configured to provide Internet access for your network. When your gateway and PCs are configured correctly, your gateway automatically accesses the Internet when one of your LAN devices requires access. It is not necessary to run a dialer or login application such as Dial-Up Networking or Enternet to connect, log in, or disconnect. These functions are performed by the gateway as needed.

To access the Internet from any PC connected to your gateway, launch a browser such as Microsoft Internet Explorer or Netscape Navigator. You should see the gateway's Internet LED blink, indicating communication to the ISP. The browser should begin to display a Web page.

The following chapters describe how to configure the Advanced features of your gateway, and how to troubleshoot problems that may occur.

Chapter 5

Content Filtering

This chapter describes how to use the Content Filtering features of your Model DG814 ADSL Modem Internet Gateway. These features can be found by clicking on the Content Filtering heading in the Main Menu of the browser interface.

Configuring for Content Filtering


The Model DG814 ADSL Modem Internet Gateway provides you with Web content filtering options, plus browsing activity reporting and instant alerts via e-mail. Parents and network administrators can establish restricted access policies based on time-of-day, web and newsgroup addresses and web and newsgroup address keywords.

To configure these features of your gateway, click on the subheadings under the Content Filtering heading in the Main Menu of the browser interface. The subheadings are described below:

Logs

The log is a detailed record of what websites you have accessed or attempted to access. Up to 128 entries are stored in the log. Log entries will only appear when keyword blocking is enabled, and no log entries will be made for the Trusted User. An example is shown below:

Logs



```

0|Fri, 15 Feb 2002 16:38:14
Source:192.168.0.2 BLOCK:www.yahoo.com
1|Fri, 15 Feb 2002 16:34:07
Source:192.168.0.2 ALLOW:ar.atwola.com
2|Fri, 15 Feb 2002 16:34:06
Source:192.168.0.2 ALLOW:www.cnn.com
3|Fri, 15 Feb 2002 16:34:05
Source:192.168.0.2
ALLOW:toolbar.netscape.com
4|Fri, 15 Feb 2002 16:34:03
Source:192.168.0.2 ALLOW:i.cnn.net
5|Fri, 15 Feb 2002 16:34:02
Source:192.168.0.2 ALLOW:www.cnn.com
6|Fri, 15 Feb 2002 16:33:03
Source:192.168.0.2 ALLOW:i.cnn.net

```

Refresh Clear Log Send Log

Log entries are described in [Table 5-1](#)

Table 5-1. Log entry descriptions

Field	Description
Number	The index number of the content filter log entries. 128 entries are available numbered from 0 to 127. The log will keep the record of the latest 128 entries.
Date and Time	The date and time the log entry was recorded.
Source IP	The IP address of the initiating device for this log entry.
Action	This field displays whether the access was blocked or allowed.
Address	The name or IP address of the website or newsgroup visited or attempted to access.

Block Sites

The Model DG814 gateway allows you to restrict access based on web and newsgroup addresses and web and newsgroup address keywords. Up to 255 entries are supported in the Keyword list. The Keyword Blocking menu is shown below:

Block Sites

Turn Keyword Blocking On

Add Keyword

Block Sites Containing These Keywords Or Domain Names:

yahoo

Delete Keyword Clear List

Allow Trusted IP Address To Visit Blocked Sites

Trusted IP address

Apply Cancel

To enable keyword blocking, check “Turn keyword blocking on”, then click Apply. Be sure that a time period for blocking is specified on the Schedule menu.

To add a keyword or domain, type it in the Keyword box, click Add Keyword, then click Apply.

To delete a keyword or domain, select it from the list, click Delete Keyword, then click Apply.

Keyword application examples:

- If the keyword "XXX" is specified, the URL <http://www.badstuff.com/xxx.html> is blocked, as is the NNTP newsgroup alt.XXX.
- If the keyword “.com” is specified, only websites with other domain suffixes (such as .edu or .gov) can be viewed.
- If you wish to block all Internet browsing access during a scheduled period, enter the keyword “. ” and set the schedule in the Schedule menu.

To specify a Trusted User, enter that PC’s IP address in the Trusted User box and click Apply.

You may specify one Trusted User, which is a PC that will be exempt from blocking and logging. Since the Trusted User will be identified by an IP address, you should configure that PC with a fixed IP address.

Schedule

The Model DG814 gateway allows you to specify when blocking will be enforced. The Schedule tab is shown below:

Schedule

Days To Block:

Every day
 Sunday
 Monday
 Tuesday
 Wednesday
 Thursday
 Friday
 Saturday

Time Of Day To Block: (use 24-hour clock)

All Day

Start Blocking: Hour Min

End Blocking: Hour Min

- Use this schedule for blocking content
Check this box if you wish to enable a schedule for Content Filtering. Click Apply.
- Days to Block
Select days to block by checking the appropriate boxes. Select Everyday to check the boxes for all days. Click Apply.
- Time of Day to Block
Select a start and end time in 23:59 format. Select All day for 24 hour blocking. Click Apply.

Be sure to select your Time Zone in the E-Mail menu.

Log action buttons are described in [Table 5-2](#)

Table 5-2. Log action buttons

Field	Description
Refresh	Click this button to refresh the log screen.
Clear Log	Click this button to clear the log entries.
Send Log	Click this button to email the log immediately.

E-Mail

In order to receive logs and alerts by email, you must provide your email information in the E-Mail subheading:

E-mail

Turn E-mail Notification On.

Send Alert And Logs Via E-mail
 Your Outgoing Mail Server:

 Send To This E-mail Address:

Send Alert Immediately
 When Someone Attempts To Visit Blocked Site.

Send Logs According To This Schedule

 A.M. P.M.

Time Zone

 Adjust for Daylight Savings Time

Current Time : 10:14:38, Fri.

- Turn e-mail notification on
 Check this box if you wish to receive e-mail logs and alerts from the gateway.

- Your outgoing mail server
Enter the name of your ISP's outgoing (SMTP) mail server (such as mail.myISP.com). You may be able to find this information in the configuration menu of your e-mail program. If you leave this box blank, log and alert messages will not be sent via e-mail.
- Send to this e-mail address
Enter the e-mail address to which logs and alerts are sent. This e-mail address will also be used as the From address. If you leave this box blank, log and alert messages will not be sent via e-mail.

You can specify that logs are automatically sent to the specified e-mail address with these options:

- Send alert immediately
Check this box if you would like immediate notification of attempted access to a blocked site.
- Send logs according to this schedule
Specifies how often to send the logs: Hourly, Daily, Weekly, or When Full.
 - Day for sending log
Specifies which day of the week to send the log. Relevant when the log is sent weekly or daily.
 - Time for sending log
Specifies the time of day to send the log. Relevant when the log is sent daily or weekly.

If the Weekly, Daily or Hourly option is selected and the log fills up before the specified period, the log is automatically e-mailed to the specified e-mail address. After the log is sent, the log is cleared from the gateway's memory. If the gateway cannot e-mail the log file, the log buffer may fill up. In this case, the gateway overwrites the log and discards its contents.

The Model DG814 gateway uses the Network Time Protocol (NTP) to obtain the current time and date from one of several Network Time Servers on the Internet. In order to localize the time for your log entries, you must specify your Time Zone:

- Time Zone
Select your local time zone. This setting will be used for the blocking schedule and for time-stamping log entries.
- Daylight Savings Time
Check this box if your time zone is currently under daylight savings time.

Chapter 6

Maintenance

This chapter describes how to use the maintenance features of your Model DG814 DSL Modem Internet Gateway. These features can be found by clicking on the Maintenance heading in the Main Menu of the browser interface.

Gateway Status

The Gateway Status menu provides a limited amount of status and usage information. From the Main Menu of the browser interface, click on Maintenance, then select System Status to view the System Status screen, shown in [Figure 6-1](#).

Gateway Status

System Name
Firmware Version 4.3 RC1 May 08, 2002

WAN Port
MAC Address 00:30:AB:00:00:05
IP Address 0.0.0.0
DHCP Client
IP Subnet Mask 0.0.0.0

LAN Port
MAC Address 00:30:AB:00:00:05
IP Address 192.168.0.1
DHCP Server
IP Subnet Mask 255.255.255.0

Modem
ADSL Firmware Version 3.8.231
Modem Status Connecting
Connect Mode -
Down Stream 0 Kb/s
Up Stream 0 Kb/s
VPI 0
VCI 38

Show Statistics Show PPPoE Status

Ping Status Show PPPoA Status

Figure 6-1. Gateway Status screen

This screen shows the following parameters:

Table 6-1. Menu 3.2 - System Status Fields

Field	Description
System Name	This field displays the Host Name assigned to the gateway.
Firmware Version	This field displays the gateway firmware version.
WAN Port	These IP parameters apply to the ADSL (WAN) port of the gateway.
IP Address	This field displays the IP address being used by the ADSL (WAN) port of the gateway. If no address is shown, the gateway cannot connect to the Internet.
IP Subnet Mask	This field displays the IP Subnet Mask being used by the ADSL(WAN) port of the gateway.

Table 6-1. Menu 3.2 - System Status Fields

Field	Description
DHCP	If set to None, the gateway is configured to use a fixed IP address on the WAN. If set to Client, the gateway is configured to obtain an IP address dynamically from the ISP.
LAN Port	These IP parameters apply to the Local (WAN) port of the gateway.
IP Address	This field displays the IP address being used by the Local (LAN) port of the gateway. The default is 192.168.0.1
IP Subnet Mask	This field displays the IP Subnet Mask being used by the Local (LAN) port of the gateway. The default is 255.255.255.0
DHCP	If set to None, the gateway will not assign IP addresses to local PCs on the LAN. If set to Server, the gateway is configured to assign IP addresses to local PCs on the LAN.
Modem	These parameters apply to the ADSL modem section of the gateway.
ADSL Firmware Version	This field displays the ADSL chipset firmware version.
Modem Status	This field displays the state of the ADSL connection to your service provider, either "Connecting" or "Connected"
Connect Mode	This field displays the protocol used to connect to your service provider. When the ADSL link comes up, the connection will be either "Fast" or "Interleaved", depending on the way the telephone company has configured its equipment
Down Stream	This field displays the connection rate from the service provider to the gateway in bits per second
Up Stream	This field displays the connection rate from the gateway to the service provider in bits per second
VPI	This field displays the VPI entered in the Setup Wizard or Basic Settings screen
VCI	This field displays the VCI entered in the Setup Wizard or Basic Settings screen

Click on the “Show Statistics” button to display gateway usage statistics, as shown in [Figure 6-2](#) below:




Figure 6-2. Gateway Statistics screen

This screen shows the following statistics:.

Table 6-2. Gateway Statistics Fields

Field	Description
Port	The statistics for the ADSL (Internet) and LAN (local) ports. For each port, the screen displays:
Status	The link status of the port.
TxPkts	The number of packets transmitted on this port since reset or manual clear.
RxPkts	The number of packets received on this port since reset or manual clear.
Collisions	The number of collisions on this port since reset or manual clear.
Tx B/s	The current line utilization—percentage of current bandwidth used on this port.
Tx B/s	The average line utilization —average CLU for this port.
Up Time	The time elapsed since this port acquired link.
System up Time	The time elapsed since the last power cycle or reset.
Poll Interval	Specifies the intervals at which the statistics are updated in this window. Click on Stop to freeze the display.

Click the “PPPoE Status” or “PPPoA Status” button to display the progress of the PPPoE or PPPoA connection, as shown in [Figure 6-3](#), below.





Figure 6-3. PPPoE Status screen

The gateway will automatically authenticate with the PPPoE or PPPoA network when you have data to transmit. You can manually connect to the network by clicking on the Connect button.

This screen gives you more detailed information about your PPPoE or PPPoA link. When the connection is up and working, the amount of time that has elapsed since it came up is indicated in the Connection Time field. The Model DG814 gateway goes through the following steps to bring up a PPPoE or PPPoA connection.

1. The WAN LED indicates whether the ADSL physical layer can connect to the telephone company’s ADSL equipment, called a DSL Access Multiplexor (DSLAM). The WAN LED will be solid green when this connection is made.
2. “Connecting to server”, “PPP LCP negotiation” and “Authentication” indicate whether the gateway is able to reach the PPPoE or PPPoA server and authenticate the User Name and Password. If one of these steps fail it may indicate that the values entered in the Setup Wizard or Basic Settings screens are not correct.
3. “Getting IP addresses“ indicates whether the gateway has successfully received a DHCP assignment from the DHCP server. This step is not necessary if a static IP address has been assigned.

Click the “Ping Status” button to perform a connectivity test from your gateway, as shown in [Figure 6-4](#) below.



The screenshot shows a web interface for performing a ping test. It features a label "IP Address:" followed by a text input field containing the IP address "192.168.0.2". To the right of the input field is a button labeled "PING".

PING Status:
Receive reply from 192.168.0.2, time = 10 ms
Receive reply from 192.168.0.2, time = 10 ms
Receive reply from 192.168.0.2, time = 10 ms
Receive reply from 192.168.0.2, time = 10 ms

Figure 6-4. Ping Status screen

This screen allows you to “ping” an IP address on the LAN to verify connectivity. Enter the IP address and click the “PING” button to perform the test.

Attached Devices

The Attached Devices menu contains a table of all IP devices that the gateway has discovered on the local network. From the Main Menu of the browser interface, under the Maintenance heading, select Attached Devices to view the table, shown in [Figure 6-5](#)

Attached Devices

#	IP Address	Device Name	MAC Address
1	192.168.0.2	emachine	00:48:54:8d:d7:d3

Refresh

Figure 6-5. Attached Devices menu

For each device, the table shows the IP address, NetBIOS Host Name (if available), and Ethernet MAC address. Note that if the gateway is rebooted, the table data is lost until the gateway rediscovers the devices. To force the gateway to look for attached devices, click the Refresh button.

Configuration File Settings Management

The configuration settings of the Model DG814 gateway are stored within the gateway in a configuration file. This file can be saved (backed up) to a user's PC, retrieved (restored) from the user's PC, or cleared to factory default settings.

From the Main Menu of the browser interface, under the Maintenance heading, select the Backup Settings heading to bring up the menu shown in [Figure 6-6](#).

The screenshot shows a web interface titled "Backup Settings". It is divided into three sections by horizontal lines. The first section is "Save A Copy Of Current Settings" and contains a "Back Up" button. The second section is "Restore Saved Settings From a File" and contains a text input field, a "Browse..." button, and a "Restore" button. The third section is "Revert To Factory Default Settings" and contains an "Erase" button.

Figure 6-6. Backup Settings menu

Three options are available, and are described in the following sections.

Restore and Backup the Configuration

The Restore and Backup options in the Backup Settings menu allow you to save and retrieve a file containing your gateway's configuration settings.

To save your settings, select the Backup Settings tab. Click the Backup button. Your browser will extract the configuration file from the gateway and will prompt you for a location on your PC to store the file. You can give the file a meaningful name at this time, such as pacbell.cfg.

To restore your settings from a saved configuration file, enter the full path to the file on your PC or click the Browse button to browse to the file. When you have located it, click the Restore button to send the file to the gateway. The gateway will then reboot automatically.

Erase the Configuration

It is sometimes desirable to restore the gateway to a known blank condition. This can be done by using the Erase function, which will restore all factory settings. After an erase, the gateway's password will be **password**, the LAN IP address will be 192.168.0.1, and the gateway's DHCP client will be enabled.


To erase the configuration, click the Erase button.

To restore the factory default configuration settings without knowing the login password or IP address, you must use the Default Reset button on the rear panel of the gateway. See [“Using the Default Reset button“](#) on page 8-8.

Changing the Configuration Password

The default password for the gateway's Web Configuration Manager is **password**. Netgear recommends that you change this password to a more secure password.

From the Main Menu of the browser interface, under the Maintenance heading, select Set Password to bring up the menu shown in [Figure 6-7](#).



Set Password

Old Password

New Password

Repeat New Password

Figure 6-7. Set Password menu


To change the password, first enter the old password, and then enter the new password twice. Click Apply.

Gateway Upgrade

The routing software of the Model DG814 gateway is stored in FLASH memory, and can be upgraded as new software is released by NETGEAR. Upgrade files can be downloaded from Netgear's website. If the upgrade file is compressed (.ZIP file), you must first extract the binary (.BIN) file before sending it to the gateway. The upgrade file can be sent to the gateway using your browser.

Note: The Web browser used to upload new firmware into the Model DG814 gateway must support HTTP uploads. NETGEAR recommends using Microsoft Internet Explorer or Netscape Navigator 3.0 or above.

From the Main Menu of the browser interface, under the Maintenance heading, select the Gateway Upgrade heading to display the menu shown in [Figure 6-8](#).



Gateway Upgrade

Locate And Select The Upgrade File From Your Hard Disk:

Browse...

Upload Cancel

Figure 6-8. Gateway Upgrade menu

To upload new firmware:

1. Download and unzip the new software file from NETGEAR.
2. In the Gateway Upgrade menu, click the Browse button and browse to the location of the binary (.BIN) upgrade file
3. Click Upload.

Note: When uploading software to the Model DG814 gateway, it is important not to interrupt the Web browser by closing the window, clicking a link, or loading a new page. If the browser is interrupted, it may corrupt the software. When the upload is complete, your gateway will automatically restart. The upgrade process will typically take about one minute.

In some cases, you may need to reconfigure the gateway after upgrading.

Chapter 7

Advanced Configuration of the Gateway

This chapter describes how to configure the advanced features of your Model DG814 DSL Modem Internet Gateway. These features can be found under the Advanced heading in the Main Menu of the browser interface.

Configuring for Port Forwarding to Local Servers

Although the gateway causes your entire local network to appear as a single machine to the Internet, you can make a local server (for example, a web server or game server) visible and available to the Internet. This is done using the Port Forwarding menu. From the Main Menu of the browser interface, under Advanced, click on Port Forwarding to view the port forwarding menu, shown in [Figure 7-1](#).

Port Forwarding

Service & Game: HTTP

#	Service Name	Start Port	End Port	Server IP Address
1	FTP	21	21	192.168.0.100
2	HTTP	80	80	192.168.0.101

NAT Status:

Figure 7-1. Port Forwarding Menu.



Note: Some residential broadband ISP accounts do not allow you to run any server processes (such as a Web or FTP server) from your location. Your ISP may periodically check for servers and may suspend your account if it discovers any active services at your location. If you are unsure, refer to the Acceptable Use Policy of your ISP.



Note: Port Forwarding settings will not work when NAT is disabled in NAT Status.

Use the Port Forwarding menu to configure the gateway to forward incoming protocols to computers on your local network. In addition to servers for specific applications, you can also specify a Default DMZ Server to which all other incoming protocols are forwarded. The DMZ Server is configured in the Security Menu.

Before starting, you'll need to determine which type of service, application or game you'll provide and the IP address of the computer that will provide each service. Be sure the computer's IP address never changes. To configure port forwarding to a local server:

1. From the Service & Game box, select the service or game that you will host on your network. If the service does not appear in the list, refer to the following section, "[Add a Custom Service](#)".
2. Enter the IP address of the local server in the corresponding Server IP Address box.
3. Click the Add button.

Add a Custom Service

To define a service, game or application that does not appear in the Services & Games list, you must determine what port numbers are used by the service. For this information, you may need to contact the manufacturer of the program that you wish to use. When you have the port number information, follow these steps:

1. Click the Add Custom Service button.
2. Enter the first port number in an unused Start Port box.
3. To forward only one port, enter it again in the End Port box. To specify a range of ports, enter the last port to be forwarded in the End Port box.
4. Enter the IP address of the local server in the corresponding Server IP Address box.

5. Type a name for the service.
6. Click Apply at the bottom of the menu.

Edit or Delete a Port Forwarding Entry

To edit or delete a Port Forwarding entry, follow these steps.

1. In the table, select the button next to the service name.
2. Click Edit or Delete.

Local Web and FTP Server Example

If a local PC with a private IP address of 192.168.0.33 acts as a Web and FTP server, configure the Ports menu to forward HTTP (port 80) and FTP (port 21) to local address 192.168.0.33

In order for a remote user to access this server from the Internet, the remote user must know the IP address that has been assigned by your ISP. If this address is 172.16.1.23, for example, an Internet user can access your Web server by directing the browser to `http://172.16.1.23`. The assigned IP address can be found in the Maintenance Status Menu, where it is shown as the WAN IP Address.

Some considerations for this application are:

- If your account's IP address is assigned dynamically by your ISP, the IP address may change periodically as the DHCP lease expires.
- If the IP address of the local PC is assigned by DHCP, it may change when the PC is rebooted. To avoid this, you can manually configure the PC to use a fixed address.
- Local PCs must access the local server using the PCs' local LAN address (192.168.0.33 in this example). Attempts by local PCs to access the server using the external IP address (172.16.1.23 in this example) will fail.

Tip: Multiple Computers for Half Life, KALI or Quake III

To set up an additional computer to play Half Life, KALI or Quake III:

1. Click the button of an unused port in the table.
2. Select the game again from the Services/Games list.

3. Change the beginning port number in the Start Port box.
For these games, use the supplied number in the default listing and add +1 for each additional computer. For example, if you've already configured one computer to play Hexen II (using port 26900), the second computer's port number would be 26901, and the third computer would be 26902.
4. Type the same port number in the End Port box that you typed in the Start Port box.
5. Type the IP address of the additional computer in the Server IP Address box.
6. Click Apply.

Some online games and videoconferencing applications are incompatible with NAT. The Model DG814 gateway is programmed to recognize some of these applications and to work properly with them, but there are other applications that may not function well. In some cases, one local PC can run the application properly if that PC's IP address is entered as the default in the PORTS Menu. If one local PC acts as a game or videoconference host, enter its IP address as the default.

NAT Status

The NAT Status selection will enable you to disable Network Address Translation.



Note: NAT should only be disabled by advanced users. When NAT is disabled it loses much of the protection of the gateway, and is exposed to many exploits from the Internet. If compromised, the computer can be used to attack your network.

By default, the gateway will perform Network Address Translation (NAT), allowing all the PCs on your network to share one public IP address. Alternatively, you can disable NAT, in which case the gateway will perform traditional routing. With traditional routing, each PC on your LAN can access the Internet directly using its own IP address as the source address. Also, any PC on the Internet can directly access any PC on your LAN. The PCs on your LAN must have real, registered IP addresses, not private, nonroutable IP addresses such as 192.168.0.x.

Security

DMZ Server

Incoming traffic from the Internet is normally discarded by the gateway unless the traffic is a response to one of your local computers or a service that you have configured in the Port Forwarding menu. Instead of discarding this traffic, you can have it forwarded to one computer on your network. This computer is called the Default DMZ Server.

The Default DMZ Server feature is helpful when using some online games and videoconferencing applications that are incompatible with NAT. The gateway is programmed to recognize some of these applications and to work properly with them, but there are other applications that may not function well. In some cases, one local PC can run the application properly if that PC's IP address is entered as the Default DMZ Server.

The Security menu, shown in [Figure 7-2](#), allows the configuration of a Default DMZ Server.

Security

Default DMZ Server 192.168.0.0

Respond To Ping On Internet WAN Port

Apply Cancel

Figure 7-2. Security menu.



Note: For security, you should avoid using the Default DMZ Server feature. When a computer is designated as the Default DMZ Server, it loses much of the protection of the gateway, and is exposed to many exploits from the Internet. If compromised, the computer can be used to attack your network.

To assign a computer or server to be a Default DMZ server:

1. Click Default DMZ Server.
2. Type the IP address for that server.
3. Click Apply.

Respond to Ping on Internet WAN Port

If you want the gateway to respond to a 'ping' from the Internet, click the 'Respond to Ping on Internet WAN Port' check box. This should only be used as a diagnostic tool, since it allows your gateway to be discovered. Don't check this box unless you have a specific reason to do so.

Dynamic DNS

If your network has a permanently assigned IP address, you can register a domain name and have that name linked with your IP address by public Domain Name Servers (DNS). However, if your Internet account uses a dynamically assigned IP address, you will not know in advance what your IP address will be, and the address can change frequently. In this case, you can use a commercial dynamic DNS service, who will allow you to register your domain to their IP address, and will forward traffic directed at your domain to your frequently-changing IP address.

The gateway contains a client that can connect to many popular dynamic DNS services. You can select one of these services and obtain an account with them. Then, whenever your ISP-assigned IP address changes, your gateway will automatically contact your dynamic DNS service provider, log in to your account, and register your new IP address.

From the Main Menu of the browser interface, under Advanced, click on Dynamic DNS. To configure Dynamic DNS:

1. Access the website of one of the dynamic DNS service providers whose names appear in the 'Select Service Provider' box, and register for an account.
For example, for dyndns.org, go to www.dyndns.org.
2. Select the Use a dynamic DNS service check box.
3. Select the name of your dynamic DNS Service Provider.
4. Type the Host Name that your dynamic DNS service provider gave you.
The dynamic DNS service provider may call this the domain name.
5. Type the User Name for your dynamic DNS account.
6. Type the Password (or key) for your dynamic DNS account.
7. If your dynamic DNS provider allows the use of wildcards in resolving your URL, you may select the Use wildcards check box to activate this feature.
For example, the wildcard feature will cause `*.yourhost.dyndns.org` to be aliased to the same IP address as `yourhost.dyndns.org`

8. Click Apply to save your configuration.



Note: If your ISP assigns a private WAN IP address (such as 192.168.x.x or 10.x.x.x), the dynamic DNS service will not work because private addresses will not be routed on the Internet.

LAN IP Setup

The LAN IP Setup menu allows configuration of LAN IP services such as DHCP and RIP. From the Main Menu of the browser interface, under Advanced, click on LAN IP Setup to view the LAN IP Setup menu, shown in [Figure 7-3](#)

LAN IP Setup

Use Router as DHCP server.

Starting IP Address 192 . 168 . 0 . 2

Ending IP Address 192 . 168 . 0 . 100

LAN TCP/IP Setup

IP Address 192 . 168 . 0 . 1

IP Subnet Mask 255 . 255 . 255 . 0

RIP Direction None ▼

RIP Version RIP-1 ▼

Apply Cancel

Figure 7-3. LAN IP Setup Menu

The gateway is shipped preconfigured to use private IP addresses on the LAN side, and to act as a DHCP server. The gateway's default LAN IP configuration is:

- LAN IP addresses—192.168.0.1
- Subnet mask—255.255.255.0

These addresses are part of the IETF-designated private address range for use in private networks, and should be suitable in most applications. If your network has a requirement to use a different IP addressing scheme, you can make those changes in this menu.

DHCP

By default, the gateway will function as a DHCP (Dynamic Host Configuration Protocol) server, allowing it to assign IP, DNS server, and default gateway addresses to all computers connected to the gateway's LAN. The assigned default gateway address is the LAN address of the gateway. IP addresses will be assigned to the attached PCs from a pool of addresses specified in this menu. Each pool address is tested before it is assigned to avoid duplicate addresses on the LAN.

For most applications, the default DHCP and TCP/IP settings of the gateway are satisfactory. See [“IP Configuration by DHCP”](#) on [page B-10](#) for an explanation of DHCP and information about how to assign IP addresses for your network.

Use router as DHCP server

If another device on your network will be the DHCP server, or if you will manually configure the network settings of all of your computers, clear the ‘Use router as DHCP server’ check box. Otherwise, leave it checked.

Specify the pool of IP addresses to be assigned by setting the Starting IP Address and Ending IP Address. These addresses should be part of the same IP address subnet as the gateway’s LAN IP address. Using the default addressing scheme, you should define a range between 192.168.0.2 and 192.168.0.253, although you may wish to save part of the range for devices with fixed addresses.

The gateway will deliver the following parameters to any LAN device that requests DHCP:

- An IP Address from the range you have defined
- Subnet Mask
- Gateway IP Address (the gateway’s LAN IP address)
- Primary DNS Server (if you entered a Primary DNS address in the Basic Settings menu; otherwise, the gateway’s LAN IP address)
- Secondary DNS Server (if you entered a Secondary DNS address in the Basic Settings menu)

LAN TCP/IP Setup

The LAN IP parameters are:

- IP Address
This is the LAN IP address of the gateway.

- **IP Subnet Mask**
This is the LAN Subnet Mask of the gateway. Combined with the IP address, the IP Subnet Mask allows a device to know which other addresses are local to it, and which must be reached through a gateway or router.
- **RIP Direction**
RIP (Router Information Protocol) allows a router to exchange routing information with other routers. The RIP Direction selection controls how the gateway sends and receives RIP packets. Both is the default.
 - When set to Both or Out Only, the gateway will broadcast its routing table periodically.
 - When set to Both or In Only, it will incorporate the RIP information that it receives.
 - When set to None, it will not send any RIP packets and will ignore any RIP packets received.
- **RIP Version**
This controls the format and the broadcasting method of the RIP packets that the gateway sends. (It recognizes both formats when receiving.) By default, this is set for RIP-1.
 - RIP-1 is universally supported. RIP-1 is probably adequate for most networks, unless you have an unusual network setup.
 - RIP-2 carries more information. RIP-2B uses subnet broadcasting..



Note: If you change the LAN IP address of the gateway while connected through the browser, you will be disconnected. You must then open a new connection to the new IP address and log in again.

Static Routes

Static Routes provide additional routing information to your gateway. Under normal circumstances, the gateway has adequate routing information after it has been configured for Internet access, and you do not need to configure additional static routes. You must configure static routes only for unusual cases such as multiple routers or multiple IP subnets located on your network.

From the Main Menu of the browser interface, under Advanced, click on Static Route to view the Static Route menu, shown in [Figure 7-4](#).

IP Static Routes

#	Name	Destination	Gateway
1	isdn_rtr	134.177.0.0	192.168.0.100
2	-
3	-
4	-
5	-
6	-
7	-
8	-

Figure 7-4. Static Route Summary Table

To add or edit a Static Route:

1. Select a number and click the Edit button to open the Edit Menu, shown in [Figure 7-5](#).

Route Name

Private

Active

Destination IP Address . . .

IP Subnet Mask . . .

Gateway IP Address . . .

Metric

Figure 7-5. Static Route Entry and Edit Menu

2. Type a route name for this static route in the Route Name box under the table. (This is for identification purpose only.)
3. Select Private if you want to limit access to the LAN only. The static route will not be reported in RIP.
4. Select Active to make this route effective.
5. Type the Destination IP Address of the final destination.

6. Type the IP Subnet Mask for this destination.
If the destination is a single host, type 255.255.255.255.
7. Type the Gateway IP Address, which must be a router on the same LAN segment as the gateway.
8. Type a number between 1 and 15 as the Metric value.
This represents the number of routers between your network and the destination. Usually, a setting of 2 or 3 works, but if this is a direct connection, set it to 1.
9. Click Apply to have the static route entered into the table.

Static Route Example

As an example of when a static route is needed, consider the following case:

- Your primary Internet access is through the Model DG814 gateway to an ISP.
- You have an ISDN router on your home network for connecting to the company where you are employed. This router's address on your LAN is 192.168.0.100.
- Your company's network is 134.177.0.0.

When you first configured your gateway, two implicit static routes were created. A default route was created with your ISP as the gateway, and a second static route was created to your local network for all 192.168.0.x addresses. With this configuration, if you attempt to access a device on the 134.177.0.0 network, your gateway will forward your request to the ISP. The ISP forwards your request to the company where you are employed, and the request will likely be denied by the company's firewall.

In this case you must define a static route, telling your gateway that 134.177.0.0 should be accessed through the ISDN router at 192.168.0.100. The static route would look like [Figure 7-5](#).

In this example:

- The Destination IP Address and IP Subnet Mask fields specify that this static route applies to all 134.177.x.x addresses.
- The Gateway IP Address fields specifies that all traffic for these addresses should be forwarded to the ISDN router at 192.168.0.100.
- A Metric value of 1 will work since the ISDN router is on the LAN.
- Private is selected only as a precautionary security measure in case RIP is activated.



Chapter 8

Troubleshooting

This chapter gives information about troubleshooting your Model DG814 DSL Modem Internet Gateway. After each problem description, instructions are provided to help you diagnose and solve the problem.

Basic Functioning

After you turn on power to the gateway, the following sequence of events should occur:

1. When power is first applied, verify that the Power LED  is on.
2. Verify that the Test LED  lights within a few seconds, indicating that the self-test procedure is running.
3. After approximately 10 seconds, verify that:
 - a. The Test LED is not lit.
 - b. The LAN port LEDs are lit for any local ports that are connected.
If a port's LED is lit, a link has been established to the connected device. If a LAN port is connected to a 100 Mbps device, verify that the port's LED is green. If the port is 10 Mbps, the LED will be amber.

If any of these conditions does not occur, refer to the appropriate following section.

PWR LED Not On

If the PWR and other LEDs are off when your gateway is turned on:

- Make sure that the power cord is properly connected to your gateway and that the power supply adapter is properly connected to a functioning power outlet.

- Check that you are using the 18 V AC power adapter supplied by NETGEAR for this product.

If the error persists, you have a hardware problem and should contact technical support.

Test LED Never Blinks or LED Stays On

When the gateway is turned on, the Test LED turns on for about 10 seconds and then turns off. If the Test LED does not turn on, or if it stays on, there is a fault within the gateway.

If you experience problems with the Test LED:

- Cycle the power to see if the gateway recovers and the LED blinks for the correct amount of time.

If all LEDs including the Test LED are still on one minute after power up:

- Cycle the power to see if the gateway recovers.
- Clear the gateway's configuration to factory defaults. This will set the gateway's IP address to 192.168.0.1. This procedure is explained in [“Using the Default Reset button“](#) on page 8-8.

If the error persists, you might have a hardware problem and should contact technical support.

Troubleshooting the Web Configuration Interface

If you are unable to access the gateway's Web Configuration interface from a PC on your local network, check the following:

- Check the Ethernet connection between your PC and the gateway as described in the previous section.
- Make sure your PC's IP address is on the same subnet as the gateway. If you are using the recommended addressing scheme, your PC's address should be in the range of 192.168.0.2 to 192.168.0.254. Refer to [“Verifying TCP/IP Properties \(Windows\)“](#) on page 3-5 or [“Verifying TCP/IP Properties \(Macintosh\)“](#) on page 3-8 to find your PC's IP address. Follow the instructions in [Chapter 3](#) to configure your PC.

Note: If your PC's IP address is shown as 169.254.x.x:

Recent versions of Windows and MacOS will generate and assign an IP address if the computer cannot reach a DHCP server. These auto-generated addresses are in the range of 169.254.x.x. If your IP address is in this range, check the connection from the PC to the gateway and reboot your PC.

- If your gateway's IP address has been changed and you don't know the current IP address, clear the gateway's configuration to factory defaults. This will set the gateway's IP address to 192.168.0.1. This procedure is explained in [“Erase the Configuration“ on page 6-8](#).
- Make sure your browser has Java, JavaScript, or ActiveX enabled. If you are using Internet Explorer, click Refresh to be sure the Java applet is loaded.
- Try quitting the browser and launching it again.
- Make sure you are using the correct login information. The factory default login name is **admin** and the password is **password**. Make sure that CAPS LOCK is off when entering this information.

If the gateway does not save changes you have made in the Web Configuration Interface, check the following:

- When entering configuration settings, be sure to click the APPLY button before moving to another menu or tab, or your changes are lost.
- Click the Refresh or Reload button in the Web browser. The changes may have occurred, but the Web browser may be caching the old configuration.

Troubleshooting the ISP Connection

ADSL link

If your gateway is unable to access the Internet, you should first determine whether you have an ADSL link with the service provider. The state of this connection is indicated with the WAN LED.

WAN LED Green or Blinking Green

If your WAN LED is green or blinking green, then you have a good ADSL connection. You can be confident that the service provider has connected you line correctly and that your wiring is correct.

WAN LED Blinking Yellow

If your WAN LED is blinking yellow then your gateway is attempting to make an ADSL connection with the service provider. The LED should turn green within several minutes.

If the WAN LED does not turn green, disconnect all telephones on the line. If this solves the problem, reconnect the telephones one at a time, being careful to use a microfilter on each telephone. If the microfilters are connected correctly, you should be able to connect all your telephones.

If disconnecting telephones does not result in a green WAN LED there may be a problem with your wiring. If the telephone company has tested the ADSL signal at your Network Interface Device (NID), then you may have poor quality wiring in your house.

WAN LED Off

If the WAN LED is off, disconnect all telephones on the line. If this solves the problem, reconnect the telephones one at a time, being careful to use a microfilter on each telephone. If the microfilters are connected correctly, you should be able to connect all your telephones.

If disconnecting telephones does not result in a green WAN LED the problem may be one of the following:

- Check that the telephone company has made the connection to your line and tested it.
- Verify that you are connected to the correct telephone line. If you have more than one phone line, be sure that you are connected to the line with the ADSL service. It may be necessary to use a swapper if you ADSL signal is on pins 1 and 4 or the RJ-11 jack. The Model DG814 gateway uses pins 2 and 3.

Obtaining a WAN IP Address

If your gateway is unable to access the internet, and your WAN LED is green or blinking green, you should determine whether the gateway is able to obtain a WAN IP address from the ISP. Unless you have been assigned a static IP address, your gateway must request an IP address from the ISP. You can determine whether the request was successful using the browser interface.

To check the WAN IP address from the browser interface:

1. Launch your browser and select an external site such as www.netgear.com
2. Access the Main Menu of the gateway's configuration at <http://192.168.0.1>
3. Under the Maintenance heading check that an IP address is shown for the WAN Port
If 0.0.0.0 is shown, your gateway has not obtained an IP address from your ISP.

If your gateway is unable to obtain an IP address from the ISP, the problem may be one of the following:

- Your ISP may require a login program.
Ask your ISP whether they require PPP over Ethernet (PPPoE) or PPP over ATM (PPPoA) login.
- If you have selected a login program, you may have incorrectly set the Service Name, User Name and Password. See “[Troubleshooting PPPoE or PPPoA](#)”, below.
- Your ISP may check for your PC's host name.
Assign the PC Host Name of your ISP account to the gateway in the browser-based Setup Wizard.
- Your ISP only allows one MAC address to connect to Internet, and may check for your PC's MAC address. In this case, inform your ISP that you have bought a new network device, and ask them to use the gateway's MAC address.

Troubleshooting PPPoE or PPPoA

The PPPoA or PPPoE connection can be debugged as follows:

1. Access the Main Menu of the gateways configuration at <http://192.168.0.1>.
2. Under the Maintenance heading, click the “Show PPPoE Status” or “Show PPPoA Status” button, depending on your connection type.
3. If all of the steps indicate “OK” then your PPPoE or PPPoA connection is up and working.
4. If any of the steps indicates “Failed”, you can attempt to reconnect by clicking “Connect”. The gateway will continue to attempt to connect indefinitely.

If you cannot connect after several minutes, you may be using an incorrect Service Name, User Name or Password. There also may be a provisioning problem with your ISP.



Note: Unless you connect manually, the gateway will not authenticate using PPPoE or PPPoA until data is transmitted to the network.

Troubleshooting Internet Browsing

If your gateway can obtain an IP address but your PC is unable to load any web pages from the Internet:

- Your PC may not recognize any DNS server addresses.

A DNS server is a host on the Internet that translates Internet names (such as www addresses) to numeric IP addresses. Typically your ISP will provide the addresses of one or two DNS servers for your use. If you entered a DNS address during the gateway's configuration, reboot your PC and verify the DNS address as described in [“Verifying TCP/IP Properties \(Windows\)” on page 3-5](#). Alternatively, you may configure your PC manually with DNS addresses, as explained in your operating system documentation.

- Your PC may not have the gateway configured as its TCP/IP gateway.

If your PC obtains its information from the gateway by DHCP, reboot the PC and verify the gateway address as described in [“Verifying TCP/IP Properties \(Windows\)” on page 3-5](#).

Troubleshooting a TCP/IP Network Using a Ping Utility

Most TCP/IP terminal devices and gateways contain a ping utility that sends an echo request packet to the designated device. The device then responds with an echo reply. Troubleshooting a TCP/IP network is made very easy by using the ping utility in your PC or workstation.

Testing the LAN Path to Your Gateway

You can ping the gateway from your PC to verify that the LAN path to your gateway is set up correctly.

To ping the gateway from a PC running Windows 95 or later:

1. From the Windows toolbar, click the Start button and select Run.
2. In the field provided, type Ping followed by the IP address of the gateway, as in this example:
ping 192.168.0.1
3. Click OK.

You should see a message like this one:

```
Pinging <IP address> with 32 bytes of data
```

If the path is working, you see this message:

```
Reply from < IP address >: bytes=32 time=NN ms TTL=xxx
```

If the path is not working, you see this message:

```
Request timed out
```

If the path is not functioning correctly, you could have one of the following problems:

- Wrong physical connections
 - Make sure the LAN LNK/ACT LED is on. If the LNK/ACT LED is off, follow the instructions in [“Troubleshooting the Web Configuration Interface”](#) on page 8-2.
 - Check that the corresponding Link LEDs are on for your network interface card and for the hub ports (if any) that are connected to your workstation and gateway.
- Wrong network configuration
 - Verify that the Ethernet card driver software and TCP/IP software are both installed and configured on your PC or workstation.
 - Verify that the IP address for your gateway and your workstation are correct and that the addresses are on the same subnet.

Testing the Path from Your PC to a Remote Device

After verifying that the LAN path works correctly, test the path from your PC to a remote device. From the Windows run menu, type:

```
PING -n 10 <IP address>
```

where <IP address> is the IP address of a remote device such as your ISP’s DNS server.

If the path is functioning correctly, replies as in the previous section are displayed. If you do not receive replies:

- Check that your PC has the IP address of your gateway listed as the default gateway. If the IP configuration of your PC is assigned by DHCP, this information will not be visible in your PC’s Network Control Panel. Go to the Run... window and run winipcfg. Verify that the IP address of the gateway is listed as the default gateway as described in [“Verifying TCP/IP Properties”](#) on page 3-6.
- Check to see that the network address of your PC (the portion of the IP address specified by the netmask) is different from the network address of the remote device.
- If your ISP assigned a host name to your PC, enter that host name as the gateway name in the Setup Wizard.

Restoring the Default Configuration and Password

This section explains how to restore the factory default configuration settings, changing the gateway's administration password to **password** and the IP address to 192.168.0.1. You can erase the current configuration and restore factory defaults in two ways:

- Use the Erase function of the Web Configuration Manager (see [“Erase the Configuration“ on page 6-8](#)).
- Use the Default Reset button on the rear panel of the gateway. Use this method for cases when the administration password or IP address is not known.

Using the Default Reset button

To restore the factory default configuration settings without knowing the administration password or IP address, you must use the Default Reset button on the rear panel of the gateway.

1. Press and hold the Default Reset button until the Test LED turns on (about 10 seconds).
2. Release the Default Reset button and wait for the gateway to reboot.

Problems with Date and Time

The E-Mail menu in the Content Filtering section displays the current date and time of day. The Model DG814 gateway uses the Network Time Protocol (NTP) to obtain the current time from one of several Network Time Servers on the Internet. Each entry in the log is stamped with the date and time of day. Problems with the date and time function can include:

- Date shown is January 1, 2000
Cause: The gateway has not yet successfully reached a Network Time Server. Check that your Internet access settings are configured correctly. If you have just completed configuring the gateway, wait at least five minutes and check the date and time again.
- Time is off by one hour
Cause: The gateway does not automatically sense Daylight Savings Time. In the E-Mail menu, check or uncheck the box marked “Adjust for Daylight Savings Time”.

Appendix A

Technical Specifications

This appendix provides technical specifications for the Model DG814 DSL Modem Internet Gateway.

General Specifications

Network Protocol and Standards Compatibility

Data and Routing Protocols:	TCP/IP
	RIP-1/RIP-2
	DHCP server and DHCP relay
	RFC 1483, 2684 Bridged Ethernet Encapsulation
	RFC 2516 PPP over Ethernet (PPPoE)
	RFC 2364 PPP over ATM (PPPoA)
	RFC 1577 Classical IP over ATM

Power Adapter

North America:	120V, 60 Hz, input
United Kingdom, Australia:	240V, 50 Hz, input
Europe:	230V, 50 Hz, input

Japan: 100V, 50/60 Hz, input
All regions (output): 18 V AC @ 0.4A output, 30W maximum

Physical Specifications

Dimensions: 255 by 169 by 34 mm
10.0 by 6.7 by 1.3 in.
Weight: 0.54 kg
1.2 lb.

Environmental Specifications

Operating temperature: 0° to 40° C
Operating humidity: 90% maximum relative humidity, noncondensing

Electromagnetic Emissions

Meets requirements of: FCC Part 15 Class B
VCCI Class B
EN 55 022 (CISPR 22), Class B

Interface Specifications

LAN: 10BASE-T or 100BASE-Tx, RJ-45
WAN: ADSL, Dual RJ-11, pins 2 and 3
T1.413, G.DMT, G.Lite
ITU Annex A

Appendix B

Networks and Routing Basics

This chapter provides an overview of IP networks, routing, and firewalls.

Basic Router Concepts

Large amounts of bandwidth can be provided easily and relatively inexpensively in a local area network (LAN). However, providing high bandwidth between a local network and the Internet can be very expensive. Because of this expense, Internet access is usually provided by a slower-speed wide-area network (WAN) link such as a cable or DSL modem. In order to make the best use of the slower WAN link, a mechanism must be in place for selecting and transmitting only the data traffic meant for the Internet. The function of selecting and forwarding this data is performed by a router.

What is a Router?

A router is a device that forwards traffic between networks based on network layer information in the data and on routing tables maintained by the router. In these routing tables, a router builds up a logical picture of the overall network by gathering and exchanging information with other routers in the network. Using this information, the router chooses the best path for forwarding network traffic.

Routers vary in performance and scale, number of routing protocols supported, and types of physical WAN connection they support. The Model DG814 DSL Modem Internet Gateway is a residential or small office router that routes the IP protocol over a single-user ADSL connection.

Routing Information Protocol

One of the protocols used by a router to build and maintain a picture of the network is the Routing Information Protocol (RIP). Using RIP, routers periodically update one another and check for changes to add to the routing table.

The Model DG814 gateway supports both the older RIP-1 and the newer RIP-2 protocols. Among other improvements, RIP-2 supports subnet and multicast protocols. RIP is not required for most home applications.

IP Addresses and the Internet

Because TCP/IP networks are interconnected across the world, every machine on the Internet must have a unique address to make sure that transmitted data reaches the correct destination. Blocks of addresses are assigned to organizations by the Internet Assigned Numbers Authority (IANA). Individual users and small organizations may obtain their addresses either from the IANA or from an Internet service provider (ISP). You can contact IANA at www.iana.org.

The Internet Protocol (IP) uses a 32-bit address structure. The address is usually written in dot notation (also called dotted-decimal notation), in which each group of eight bits is written in decimal form, separated by decimal points.

For example, the following binary address:

```
11000011 00100010 00001100 00000111
```

is normally written as:

```
195.34.12.7
```

The latter version is easier to remember and easier to enter into your computer.

In addition, the 32 bits of the address are subdivided into two parts. The first part of the address identifies the network, and the second part identifies the host node or station on the network. The dividing point may vary depending on the address range and the application.

There are five standard classes of IP addresses. These address classes have different ways of determining the network and host sections of the address, allowing for different numbers of hosts on a network. Each address type begins with a unique bit pattern, which is used by the TCP/IP software to identify the address class. After the address class has been determined, the software can correctly identify the host section of the address. The follow figure shows the three main address classes, including network and host sections of the address for each address type.




Figure B-1. Three Main Address Classes

The five address classes are:

- Class A
Class A addresses can have up to 16,777,214 hosts on a single network. They use an eight-bit network number and a 24-bit node number. Class A addresses are in this range:
1.x.x.x to 126.x.x.x.
- Class B
Class B addresses can have up to 65,354 hosts on a network. A Class B address uses a 16-bit network number and a 16-bit node number. Class B addresses are in this range:
128.1.x.x to 191.254.x.x.
- Class C
Class C addresses can have 254 hosts on a network. Class C addresses use 24 bits for the network address and eight bits for the node. They are in this range:
192.0.1.x to 223.255.254.x.
- Class D
Class D addresses are used for multicasts (messages sent to many hosts). Class D addresses are in this range:
224.0.0.0 to 239.255.255.255.
- Class E
Class E addresses are for experimental use.

This addressing structure allows IP addresses to uniquely identify each physical network and each node on each physical network.

For each unique value of the network portion of the address, the base address of the range (host address of all zeros) is known as the network address and is not usually assigned to a host. Also, the top address of the range (host address of all ones) is not assigned, but is used as the broadcast address for simultaneously sending a packet to all hosts with the same network address.

Netmask

In each of the address classes previously described, the size of the two parts (network address and host address) is implied by the class. This partitioning scheme can also be expressed by a netmask associated with the IP address. A netmask is a 32-bit quantity that, when logically combined (using an AND operator) with an IP address, yields the network address. For instance, the netmasks for Class A, B, and C addresses are 255.0.0.0, 255.255.0.0, and 255.255.255.0, respectively.

For example, the address 192.168.170.237 is a Class C IP address whose network portion is the upper 24 bits. When combined (using an AND operator) with the Class C netmask, as shown here, only the network portion of the address remains:

```
11000000 10101000 10101010 11101101 (192.168.170.237)
```

combined with:

```
11111111 11111111 11111111 00000000 (255.255.255.0)
```

Equals:

```
11000000 10101000 10101010 00000000 (192.168.170.0)
```

As a shorter alternative to dotted-decimal notation, the netmask may also be expressed in terms of the number of ones from the left. This number is appended to the IP address, following a backward slash (/), as “/n.” In the example, the address could be written as 192.168.170.237/24, indicating that the netmask is 24 ones followed by 8 zeros.

Subnet Addressing

By looking at the addressing structures, you can see that even with a Class C address, there are a large number of hosts per network. Such a structure is an inefficient use of addresses if each end of a routed link requires a different network number. It is unlikely that the smaller office LANs would have that many devices. You can resolve this problem by using a technique known as subnet addressing.

Subnet addressing allows us to split one IP network address into smaller multiple physical networks known as subnetworks. Some of the node numbers are used as a subnet number instead. A Class B address gives us 16 bits of node numbers translating to 64,000 nodes. Most organizations do not use 64,000 nodes, so there are free bits that can be reassigned. Subnet addressing makes use of those bits that are free, as shown below.




Figure B-2. Example of Subnetting a Class B Address

A Class B address can be effectively translated into multiple Class C addresses. For example, the IP address of 172.16.0.0 is assigned, but node addresses are limited to 255 maximum, allowing eight extra bits to use as a subnet address. The IP address of 172.16.97.235 would be interpreted as IP network address 172.16, subnet number 97, and node number 235. In addition to extending the number of addresses available, subnet addressing provides other benefits. Subnet addressing allows a network manager to construct an address scheme for the network by using different subnets for other geographical locations in the network or for other departments in the organization.

Although the preceding example uses the entire third octet for a subnet address, note that you are not restricted to octet boundaries in subnetting. To create more network numbers, you need only shift some bits from the host address to the network address. For instance, to partition a Class C network number (192.68.135.0) into two, you shift one bit from the host address to the network address. The new netmask (or subnet mask) is 255.255.255.128. The first subnet has network number 192.68.135.0 with hosts 192.68.135.1 to 192.68.135.126, and the second subnet has network number 192.68.135.128 with hosts 192.68.135.129 to 192.68.135.254.



Note: The number 192.68.135.127 is not assigned because it is the broadcast address of the first subnet. The number 192.68.135.128 is not assigned because it is the network address of the second subnet.

The following table lists the additional subnet mask bits in dotted-decimal notation. To use the table, write down the original class netmask and replace the 0 value octets with the dotted-decimal value of the additional subnet bits. For example, to partition your Class C network with subnet mask 255.255.255.0 into 16 subnets (4 bits), the new subnet mask becomes 255.255.255.240.

Table B-1. Netmask Notation Translation Table for One Octet

Number of Bits	Dotted-Decimal Value
1	128
2	192
3	224
4	240
5	248
6	252
7	254
8	255

The following table displays several common netmask values in both the dotted-decimal and the masklength formats.

Table B-2. Netmask Formats

Dotted-Decimal	Masklength
255.0.0.0	/8
255.255.0.0	/16
255.255.255.0	/24
255.255.255.128	/25
255.255.255.192	/26
255.255.255.224	/27
255.255.255.240	/28
255.255.255.248	/29
255.255.255.252	/30
255.255.255.254	/31
255.255.255.255	/32

NETGEAR strongly recommends that you configure all hosts on a LAN segment to use the same netmask for the following reasons:

- So that hosts recognize local IP broadcast packets

When a device broadcasts to its segment neighbors, it uses a destination address of the local network address with all ones for the host address. In order for this scheme to work, all devices on the segment must agree on which bits comprise the host address.

- So that a local router or bridge recognizes which addresses are local and which are remote

Private IP Addresses

If your local network is isolated from the Internet (for example, when using NAT), you can assign any IP addresses to the hosts without problems. However, the IANA has reserved the following three blocks of IP addresses specifically for private networks:

10.0.0.0 - 10.255.255.255
172.16.0.0 - 172.31.255.255
192.168.0.0 - 192.168.255.255

NETGEAR recommends that you choose your private network number from this range. The DHCP server of the Model DG814 gateway is preconfigured to automatically assign private addresses.


Regardless of your particular situation, do not create an arbitrary IP address; always follow the guidelines explained here. For more information about address assignment, refer to RFC 1597, *Address Allocation for Private Internets*, and RFC 1466, *Guidelines for Management of IP Address Space*. The Internet Engineering Task Force (IETF) publishes RFCs on its Web site at www.ietf.org.

Single IP Address Operation Using NAT

In the past, if multiple PCs on a LAN needed to access the Internet simultaneously, you had to obtain a range of IP addresses from the ISP. This type of Internet account is more costly than a single-address account typically used by a single user with a modem, rather than a router. The Model DG814 gateway employs an address-sharing method called Network Address Translation (NAT). This method allows several networked PCs to share an Internet account using only a single IP address, which may be statically or dynamically assigned by your ISP.

The router accomplishes this address sharing by translating the internal LAN IP addresses to a single address that is globally unique on the Internet. The internal LAN IP addresses can be either private addresses or registered addresses. For more information about IP address translation, refer to RFC 1631, *The IP Network Address Translator (NAT)*.

The following figure illustrates a single IP address operation.



7786EA

Figure B-3. Single IP Address Operation Using NAT

This scheme offers the additional benefit of simple firewall-like protection because the internal LAN addresses are not available to the Internet through the translated connection. All incoming inquiries are filtered out by the router. This filtering can prevent intruders from probing your system. However, using port forwarding, you can allow one PC (for example, a Web server) on your local network to be accessible to outside users.

MAC Addresses and Address Resolution Protocol

An IP address alone cannot be used to deliver data from one LAN device to another. To send data between LAN devices, you must convert the IP address of the destination device to its media access control (MAC) address. Each device on an Ethernet network has a unique MAC address, which is a 48-bit number assigned to each device by the manufacturer. The technique that associates the IP address with a MAC address is known as address resolution. Internet Protocol uses the Address Resolution Protocol (ARP) to resolve MAC addresses.

If a device sends data to another station on the network and the destination MAC address is not yet recorded, ARP is used. An ARP request is broadcast onto the network. All stations on the network receive and read the request. The destination IP address for the chosen station is included as part of the message so that only the station with this IP address responds to the ARP request. All other stations discard the request.

The station with the correct IP address responds with its own MAC address directly to the sending device. The receiving station provides the transmitting station with the required destination MAC address. The IP address data and MAC address data for each station are held in an ARP table. The next time data is sent, the address can be obtained from the address information in the table.

Domain Name Server

Many of the resources on the Internet can be addressed by simple descriptive names such as *www.NETGEAR.com*. This addressing is very helpful at the application level, but the descriptive name must be translated to an IP address in order for a user to actually contact the resource. Just as a telephone directory maps names to phone numbers, or as an ARP table maps IP addresses to MAC addresses, a domain name system (DNS) server maps descriptive names of network resources to IP addresses.

When a PC accesses a resource by its descriptive name, it first contacts a DNS server to obtain the IP address of the resource. The PC sends the desired message using the IP address. Many large organizations, such as ISPs, maintain their own DNS servers and allow their customers to use the servers to look up addresses.

IP Configuration by DHCP

When an IP-based local area network is installed, each PC must be configured with an IP address. If the PCs need to access the Internet, they should also be configured with a gateway address and one or more DNS server addresses. As an alternative to manual configuration, there is a method by which each PC on the network can automatically obtain this configuration information. A device on the network may act as a Dynamic Host Configuration Protocol (DHCP) server. The DHCP server stores a list or pool of IP addresses, along with other information (such as gateway and DNS addresses) that it may assign to the other devices on the network. The Model DG814 gateway has the capacity to act as a DHCP server.

The Model DG814 gateway also functions as a DHCP client when connecting to the ISP. The router can automatically obtain an IP address, subnet mask, DNS server addresses, and a gateway address if the ISP provides this information by DHCP.

Ethernet Cabling

Although Ethernet networks originally used thick or thin coaxial cable, most installations currently use unshielded twisted pair (UTP) cabling. The UTP cable contains eight conductors, arranged in four twisted pairs, and terminated with an RJ45 type connector. A normal "straight-through" UTP Ethernet cable follows the EIA568B standard wiring and pinout as described in [Table B-3](#).

Table B-3. UTP Ethernet cable wiring, straight-through

Pin	Wire color	Signal
1	Orange/White	Transmit (Tx) +
2	Orange	Transmit (Tx) -
3	Green/White	Receive (Rx) +
4	Blue	
5	Blue/White	
6	Green	Receive (Rx) -
7	Brown/White	
8	Brown	

Uplink Switches, Crossover Cables, and MDI/MDIX Switching

In the wiring table above, the concept of transmit and receive are from the perspective of the PC, which is wired as Media Dependent Interface (MDI). In this wiring, the PC transmits on pins 1 and 2. At the hub, the perspective is reversed, and the hub receives on pins 1 and 2. This wiring is referred to as Media Dependent Interface - Crossover (MDI-X). When connecting a PC to a PC, or a hub port to another hub port, the transmit pair must be exchanged with the receive pair. This exchange is done by one of three mechanisms:

- Uplink switch
Most hubs provide an Uplink switch which will exchange the pairs on one port, allowing that port to be connected to another hub using a normal Ethernet cable.

- **Crossover cable**
A crossover cable is a special cable in which the transmit and receive pairs are exchanged at one of the two cable connectors. Crossover cables are often unmarked as such, and must be identified by comparing the two connectors. Since the cable connectors are clear plastic, it is easy to place them side by side and view the order of the wire colors on each. On a straight-through cable, the color order will be the same on both connectors. On a crossover cable, the orange and blue pairs will be exchanged from one connector to the other.
- **Auto MDI/MDI-X switching**
Some Ethernet switch products, such as the Model DG814 gateway, are able to sense the polarity of a connection and automatically adapt to the proper mating polarity.

Cable Quality

A twisted pair Ethernet network operating at 10 Mbits/second (10BASE-T) will often tolerate low quality cables, but at 100 Mbits/second (10BASE-Tx) the cable must be rated as Category 5, or "Cat 5", by the Electronic Industry Association (EIA). This rating will be printed on the cable jacket. A Category 5 cable will meet specified requirements regarding loss and crosstalk. In addition, there are restrictions on maximum cable length for both 10 and 100 Mbits/second networks.

Glossary

10BASE-T	IEEE 802.3 specification for 10 Mbps Ethernet over twisted pair wiring.
100BASE-Tx	IEEE 802.3 specification for 100 Mbps Ethernet over twisted pair wiring.
ADSL	<i>See</i> Asymmetric Digital Subscriber Line
Asymmetric Digital Subscriber Line	A technology for sending data over regular telephone lines. ADSL allows data rates up to 8 Mbps downstream and 640 Kbps upstream.
Denial of Service attack	A hacker attack designed to prevent your computer or network from operating or communicating.
DHCP	<i>See</i> Dynamic Host Configuration Protocol.
DNS	<i>See</i> Domain Name Server.
Domain Name	A descriptive name for an address or group of addresses on the Internet. Domain names are of the form of a registered entity name plus one of a number of predefined top level suffixes such as .com, .edu, .uk, etc. For example, in the address mail.NETGEAR.com, mail is a server name and NETGEAR.com is the domain.
Domain Name Server	A Domain Name Server (DNS) resolves descriptive names of network resources (such as www.NETGEAR.com) to numeric IP addresses.
DSLAM	DSL Access Multiplexor. The piece of equipment at the telephone company central office that provides the ADSL signal.
Dynamic Host Configuration Protocol	DHCP. An Ethernet protocol specifying how a centralized DHCP server can assign network configuration information to multiple DHCP clients. The assigned information includes IP addresses, DNS addresses, and gateway (router) addresses.
IP	<i>See</i> Internet Protocol.

IP Address	A four-byte number uniquely defining each host on the Internet. Ranges of addresses are assigned by Internic, an organization formed for this purpose. Usually written in dotted-decimal notation with periods separating the bytes (for example, 134.177.244.57).
IPSec	Internet Protocol Security. IPSec is a series of guidelines for securing private information transmitted over public networks. IPSec is a VPN method providing a higher level of security than PPTP.
IPX	<i>See</i> Internet Packet Exchange.
ISP	Internet service provider.
Internet Packet Exchange	Novell's internetworking protocol.
Internet Protocol	The main internetworking protocol used in the Internet. Used in conjunction with the Transfer Control Protocol (TCP) to form TCP/IP.
LAN	<i>See</i> local area network.
Local Area Network	LAN. A communications network serving users within a limited area, such as one floor of a building. A LAN typically connects multiple personal computers and shared network devices such as storage and printers. Although many technologies exist to implement a LAN, Ethernet is the most common for connecting personal computers.
MAC address	Media Access Control address. A unique 48-bit hardware address assigned to every Ethernet node. Usually written in the form 01:23:45:67:89:ab.
MSB	<i>See</i> Most Significant Bit or Most Significant Byte.
MRU	<i>See</i> Maximum Receive Unit.
Maximum Receive Unit	The size in bytes of the largest packet that can be sent or received.
Most Significant Bit or Most Significant Byte	The portion of a number, address, or field that is farthest left when written as a single number in conventional hexadecimal ordinary notation. The part of the number having the most value.
NAT	<i>See</i> Network Address Translation.
Netmask	A number that explains which part of an IP address comprises the network address and which part is the host address on that network. It can be expressed in dotted-decimal notation or as a number appended to the IP address. For example, a 28-bit mask starting from the MSB can be shown as 255.255.255.192 or as /28 appended to the IP address.

Network Address Translation	A technique by which several hosts share a single IP address for access to the Internet.
NID	Network Interface Device. The point of demarcation, where the telephone line comes into the house.
Packet	A block of information sent over a network. A packet typically contains a source and destination network address, some protocol and length information, a block of data, and a checksum.
PPP	<i>See</i> Point-to-Point Protocol.
PPPoA	<i>See</i> PPP over ATM
PPPoE	<i>See</i> PPP over Ethernet
PPP over ATM	PPPoA. PPP over ATM is a protocol for connecting remote hosts to the Internet over an always-on connection by simulating a dial-up connection.
PPP over Ethernet	PPPoE. PPP over Ethernet is a protocol for connecting remote hosts to the Internet over an always-on connection by simulating a dial-up connection.
PPTP	Point-to-Point Tunneling Protocol. A method for establishing a virtual private network (VPN) by embedding Microsoft's network protocol into Internet packets.
PSTN	Public Switched Telephone Network.
Point-to-Point Protocol	PPP. A protocol allowing a computer using TCP/IP to connect directly to the Internet.
RFC	Request For Comment. Refers to documents published by the Internet Engineering Task Force (IETF) proposing standard protocols and procedures for the Internet. RFCs can be found at www.ietf.org .
RIP	<i>See</i> Routing Information Protocol.
Router	A device that forwards data between networks. An IP router forwards data based on IP source and destination addresses.
Routing Information Protocol	A protocol in which routers periodically exchange information with one another so that they can determine minimum distance paths between sources and destinations.
Subnet Mask	<i>See</i> netmask.
UTP	Unshielded twisted pair. The cable used by 10BASE-T and 100BASE-Tx Ethernet networks.

VCI	Virtual Channel Identifier. Together with the VPI, defines a Virtual Channel through an ATM network. Used by ATM switching equipment to route data through the network.
VPI	Virtual Path Identifier. Together with the VCI, defines a Virtual Channel through an ATM network. Used by ATM switching equipment to route data through the network.
VPN	Virtual Private Network. A method for securely transporting data between two private networks by using a public network such as the Internet as a connection.
WAN	<i>See</i> wide area network.
Wide Area Network	WAN. A long distance link used to extend or connect remotely located local area networks. The Internet is a large WAN.
Windows Internet Naming Service	WINS. Windows Internet Naming Service is a server process for resolving Windows-based computer names to IP addresses. If a remote network contains a WINS server, your Windows PCs can gather information from that WINS server about its local hosts. This allows your PCs to browse that remote network using Network Neighborhood.
WINS	<i>See</i> Windows Internet Naming Service.

A

Account Name 4-5, 4-7, 4-8
Address Resolution Protocol B-9
ADSL
 connecting through other jacks 2-7
 connecting through RJ11 2-6
ARP B-9
Auto MDI/MDI-X 1-4, 2-6, B-11, B-12
Auto Uplink 1-4, 2-6

B

backup configuration 6-7

C

cables, pinout B-11
Cabling B-11
Cat5 cable 2-2, 2-5, B-12
Classical IP 1-2
configuration
 automatic by DHCP 1-4
 backup 6-7
 erasing 6-8
 restore 6-7
 router, initial 4-1
Connect Mode 6-3
connection rate
 ADSL 6-3
content filtering 1-3, 5-1
conventions
 typography xv
crossover cable 1-4, 2-6, B-12
customer support iii

D

date and time 7-8
daylight savings time 5-6, 7-8
default reset button 7-8
DHCP 1-2, 1-4, 3-2, 5-8, B-10
DHCP Client ID 3-7

DHCP Setup field, Ethernet Setup menu 6-2
DMZ 1-3, 5-2, 5-5
DNS Proxy 1-2, 1-4
DNS server 3-10, 3-11, 4-5, 4-6, 4-7, 4-9
DNS, dynamic 5-6
domain 3-10
Domain Name 4-5, 4-7, 4-8
domain name server (DNS) B-9
DSLAM 6-5
Dynamic DNS 5-6

E

End Port 5-2
EnterNet 3-9
erase configuration 6-8
Ethernet cable 2-6, B-11

F

factory settings, restoring 6-8
features 1-1
Firmware Version
 ADSL 6-3
flash memory, for firmware upgrade 1-2
front panel 2-2

G

gateway address 3-10, 3-11

H

Half Life 5-3
host name 4-5, 4-7, 4-8

I

IANA
 contacting B-2
IETF xiii
 Web site address B-7
installation 1-4
Internet account

- address information 3-9
- establishing 3-8
- IP addresses 3-10, 3-11
 - and NAT B-7
 - and the Internet B-2
 - assigning xiii, B-2
 - auto-generated 7-2
 - private B-7
 - translating xiv
- IP configuration by DHCP B-10
- IP networking
 - for Macintosh 3-6
 - for Windows 3-2, 3-5

K

- KALI 5-3

L

- LAN IP Setup Menu 5-7
- LEDs 2-2
 - description 2-3
- Linux 3-2
- LLC-BASED
 - multiplexing method 4-9
- log
 - sending 5-5
- log entries 5-2

M

- MAC address B-9
- Macintosh 3-10
 - configuring for IP networking 3-6
 - DHCP Client ID 3-7
 - Obtaining ISP Configuration Information 3-11
 - OS 8.6 or 9.x configuration 3-6
- Macintosh Operating System 7 3-2
- MDI/MDI-X 1-4, 2-6, B-11, B-12
- metric 5-11
- microfilter 2-4
- Modem Status 6-3
- Multiplexing Method 4-9

Multiplexing, VPI, VCI 3-9

N

NAT Status 5-4

NAT. *See* Network Address Translation

NETGEAR

contacting xiii

netmask B-4

translation table B-6

Network Address Translation 1-2, 1-4, 3-9, B-7

disabling 5-4

Network Time Protocol 5-6, 7-8

newsgroup 5-3

NNTP newsgroup 5-3

NTP 5-6, 7-8

P

package contents 2-1

password

restoring 7-8

PC, using to configure 3-11

Ping 6-6, 5-6

pinout, Ethernet cable B-11

Port Forwarding 5-1, B-8

Port Forwarding Menu 5-1

PPP over ATM 1-2, 1-4, 4-7, 4-8, 6-5

login 3-9

Status 6-5

PPP over Ethernet 1-2, 1-4, 3-9, 4-7, 4-8, 6-5

login 3-9

Status 6-5

PPPoA. *See* PPP over ATM

PPPoE *See* PPP over Ethernet

Primary DNS Server 4-5, 4-6, 4-7, 4-9

protocols

Address Resolution B-9

DHCP 1-2, 1-4, B-10

PPPoA 1-2

PPPoE 1-2

RIP B-2

Routing Information 1-4, B-2

support 1-2
publications, related xiii

Q

Quake 5-3

R

range, port forwarding 5-2
rear panel 2-3
requirements
 access device 2-2
 hardware 2-2
reset button, clearing config 7-8
restore configuration 6-7
restore factory settings 6-8

RFC

1466 xiii, B-7
1597 xiii, B-7
1631 xiv, B-8
finding B-7

RIP B-2

RIP (Router Information Protocol) 5-9

router concepts B-1

Routing Information Protocol 1-4, B-2

S

Secondary DNS Server 4-5, 4-6, 4-7, 4-9

security 1-1, 1-3

Service Name 4-8

Setup Wizard 4-1

SMTP 5-6

Start Port 5-2

Static Routes 5-9

subnet addressing B-4

subnet mask 3-10, 3-11, B-5

T

TCP/IP

 configuring 3-1

- TCP/IP properties
 - verifying for Macintosh 3-8
 - verifying for Windows 3-5, 3-6
- technical support xiii
- time of day 7-8
- time zone 5-6
- time-stamping 5-6
- troubleshooting 7-1
- Trusted Host 5-4
- typographical conventions xv

U

- UNIX 3-2
- uplink switch B-11

V

- VC-BASED
 - multiplexing method 4-9
- VCI 3-9
- VPI 3-9
- VPI/VCI 6-3
 - autoconfiguration 4-9
 - configuration 4-9

W

- Windows, configuring for IP routing 3-2, 3-5
- winipcfg utility 3-5
- WinPOET 3-9
- World Wide Web iii

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>