
Nortel Communication Server 1000

Nortel Communication Server 1000 Release 4.5

Telephones and Consoles

Description, Installation, and Operation

Document Number: 553-3001-367

Document Release: Standard 3.00

Date: August 2005

Copyright © Nortel Networks Limited 2005

All Rights Reserved

Produced in Canada

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

Nortel, Nortel (Logo), the Globemark, This is the Way, This is Nortel (Design mark), SL-1, Meridian 1, and Succession are trademarks of Nortel Networks.

Revision history

August 2005

Standard 3.00. This document is up-issued for Communication Server 1000 Release 4.5.

September 2004

Standard 2.00. This document is up-issued for Communication Server 1000 Release 4.0.

October 2003

Standard 1.00. This document is a new NTP for Succession 3.0. It was created to support a restructuring of the Documentation Library, which resulted in the merging of multiple legacy NTPs. This new document consolidates information previously contained in the following legacy documents, now retired:

- *Attendant Console Description (553-2201-117)*
- *Digital Telephones Line Engineering(553-2201-180)*
- *Meridian 1 Telephones (553-3001-108)*
- *Meridian 1 European Digital Telephones (553-3001-114)*
- *Telephone and Attendant Console Installation (553-3001-215)*
- *M3900 Series Meridian Digital Telephones (553-3001-216)*
- *Option 11C and 11C Mini Technical Reference Guide (553-3011-100)*

Content from *Option 11C and 11C Mini Technical Reference Guide* also appears in *Circuit Card: Description and Installation (553-3001-211)*.

Contents

List of procedures	11
About this document	19
Subject	19
Applicable systems	20
Intended audience	21
Conventions	21
Related information	22
How to get Help	24
Attendant consoles	27
Contents	27
Introduction	28
Engineering codes	29
Features	31
Physical description	48
Wiring	57
Installation	59
Operation	77
M2016S Secure Set	103
Contents	103
Introduction	104
Physical description	106

Features	108
Specifications	109
Installation	113
M 3900 description	123
Contents	123
Introduction	124
Automatic Call Failover	126
Physical description	127
Features	137
M3900 accessories and add-ons	147
Key descriptions	159
M3900 (single site) Virtual Office	173
Contents	173
Introduction	173
Description	173
Operating parameters	176
Feature implementation	177
M3900 installation and configuration	183
Contents	183
Reliability	184
Environmental and safety considerations	185
Installation	189
Configuration	206
M3900 Flash Download	227
Contents	227
Introduction	227
Summary of steps	228
Determining software, M3900 PSWV, or firmware versions	261

Flash Download advisements	263
PSDL installation	267
Dynamic PSDL installation	267
Detailed Flash Download procedure	269
Configuration parameters in LD 32	274
Print Firmware Versions on M3900 Telephones	279
Query Disk Firmware Versions	281
Commands for system-wide Flash Download of M3900 telephones	284
Digital telephones line engineering	289
Contents	289
Engineering a telephone line	290
Selecting a Loop	299
Calculating DC Loop Resistance	299
Performing Loop Diagnostic Tests	300
Measuring Impulse Noise	302
Measuring Background Noise	302
Calculating Expected Pulse Loss	302
Measuring DC Loop Resistance	306
Analog (500/2500-type) telephones	309
Contents	309
Introduction	309
Installation and removal	309
Operation	320
Appendix A: Meridian Modular Telephones	323
Contents	323
Introduction	324
General description	325
Physical description	330

Features and options	334
Relocation	340
Specifications	342
Handsets	353

**Appendix B: Meridian Modular Telephones
installation 355**

Contents	355
Packing and unpacking	355
Installation and removal	356
Designate telephones	367
Cross-connect the telephones	368

**Appendix C: Meridian Modular Telephones
add-on modules installation 371**

Contents	371
Packing and unpacking	372
Meridian Modular Telephones	373
Analog Terminal Adapter	375
Meridian Communications Adapter and Meridian Programmable Data Adapter	381
Power Supply Board (NTZK models)	392
Power Supply Board (NT2K models)	401
Installing displays	404
External Alerter Board	416
Key Expansion Modules	420
Asynchronous Data Option	423
M2317 Data Option	426
Meridian Communications Unit	430
Wall mounting	432
Troubleshooting	433

Appendix D: M2317 telephone	439
Contents	439
Introduction	439
Feature description	441
Physical description	442
Specifications	453
Appendix E: M3110, M3310, and M3820 telephones	
459	
Contents	459
Feature description	460
Physical description	466
Terminal options	472
Configuration and installation	474
Specifications	486
Index	493

List of procedures

Procedure 1	
Connecting the BLF/CGM to the M2250 attendant console	35
Procedure 2	
Checking the functionality of the Busy Lamp Field/Console Graphics Module	42
Procedure 3	
Removing the Busy Lamp Field/Console Graphics Module	43
Procedure 4	
Installing an Attendant Supervisory Module on an M2250 attendant console	45
Procedure 5	
Installing wiring	57
Procedure 6	
Installing the M2250 attendant console	60
Procedure 7	
Removing the M2250 attendant console	61
Procedure 8	
Removing the M2250 attendant console top cover	62
Procedure 9	
Installing the M2250 attendant console top cover	63

Procedure 10	
Performing a loopback test on the M2250 attendant console	64
Procedure 11	
Designating keys on an M2250 attendant console	65
Procedure 12	
Cross-connecting attendant consoles	69
Procedure 13	
Entering the M2250 Diagnostics mode	81
Procedure 14	
Testing the Keyboard	82
Procedure 15	
Testing the LCD indicators	83
Procedure 16	
Testing the data port	83
Procedure 17	
Testing the ICS	83
Procedure 18	
Testing the Busy Lamp Field/Console Graphics Module	84
Procedure 19	
Checking the Alerter	84
Procedure 20	
Testing the Display	85
Procedure 21	
Displaying the firmware version numbers	85
Procedure 22	
Displaying and resetting the QMT2 switch status	85

Procedure 23	
 Toggling control gates	86
Procedure 24	
 Installing the M2016S telephone	114
Procedure 25	
 M2016S self-test	116
Procedure 26	
 Designating the M2016S telephone	119
Procedure 27	
 Cross-connecting the telephones	119
Procedure 28	
 Installing the M3900 Series Digital Telephone	189
Procedure 29	
 Changing the telephone position	190
Procedure 30	
 Changing the telephone angle	190
Procedure 31	
 Wall-mounting the telephone	191
Procedure 32	
 Installing the ACM	192
Procedure 33	
 Installing the wall transformer	194
Procedure 34	
 Installing the ATA	195
Procedure 35	
 Installing the Personal Directory PC Utility software	197

Procedure 36	
Installing the KBA	198
Procedure 37	
Installing the Single KBA footstand	201
Procedure 38	
Installing the Expansion KBA footstand	201
Procedure 39	
Installing the DBA	202
Procedure 40	
Removing the HookSwitch cover	203
Procedure 41	
Installing the cradle	203
Procedure 42	
Installing the key caps	205
Procedure 43	
Installing the Full Duplex Handsfree cartridge	206
Procedure 44	
Displaying the M3900 Diagnostics	263
Procedure 45	
Engineering a telephone line	290
Procedure 46	
Calculating DC loop resistance	299
Procedure 47	
Testing foreign voltage	300
Procedure 48	
Testing insulation resistance	301
Procedure 49	
Testing DC continuity	301

Procedure 50	
Testing capacitance unbalance	301
Procedure 51	
Measuring impulse noise	302
Procedure 52	
Measuring background noise	302
Procedure 53	
Calculating expected pulse loss	304
Procedure 54	
Installing an analog (500/2500-type) telephone	310
Procedure 55	
Removing an analog (500/2500-type) telephone	310
Procedure 56	
Designating 500-type telephones	311
Procedure 57	
Removing the finger wheel from analog 500-type telephone	311
Procedure 58	
Designating analog 2500-type telephone	312
Procedure 59	
Connecting analog (500/2500-type) telephones	312
Procedure 60	
Cross-connecting the telephones	313
Procedure 61	
Installing Meridian Modular Telephones (M2006/M2008/M2008HF/M2616/M2216ACD)	356
Procedure 62	
Meridian Modular Telephones self-test	358

Procedure 63	
Installing the M2317 telephone	361
Procedure 64	
Performing the M2317 telephone self-test	364
Procedure 65	
Designating Meridian Modular Telephones	368
Procedure 66	
Cross-connecting the telephones	368
Procedure 67	
Installing and removing the Analog Terminal Adapter	377
Procedure 68	
Installing and removing the Meridian Communications Adapter or the Meridian Programmable Data Adapter	389
Procedure 69	
Connecting the data terminal	392
Procedure 70	
Installing and removing the M2006/M2008 Power Supply Board on NTZK sets	393
Procedure 71	
Installing and removing the M2616/M2216ACD Power Supply Board on NTZK sets	397
Procedure 72	
Installing and removing the M2006 or M2008 Power Supply Board on NT2K sets	401
Procedure 73	
Installing and removing the M2616/M2216ACD Display on NTZK sets	405

Procedure 74	
Installing and removing the M2616 Display on NT2K sets	408
Procedure 75	
Installing NT2K28AA displays on NT2K or NT2K sets	411
Procedure 76	
Installing and removing the External Alerter Board	416
Procedure 77	
Installing and removing Key Expansion Module(s) on the M2616 and M2216ACD telephones	420
Procedure 78	
Installing the M2317 data option	427
Procedure 79	
Installing the M2317 data terminal	428
Procedure 80	
Wall mounting instructions for Meridian Modular Telephones	432
Procedure 81	
Installing Meridian European digital telephones	480
Procedure 82	
Installing the Power Board	481
Procedure 83	
Adding a Headset (M3310 and M3820 only)	483
Procedure 84	
Adjusting the telephone to the desktop shallow-angle position	484

Procedure 85
Wall mounting the telephone485

About this document

This document is a global document. Contact your system supplier or your Nortel representative to verify that the hardware and software described are supported in your area.

Subject

This document provides technical information about Meridian analog, digital and modular telephones and attendant consoles. This information includes descriptions, features and specifications; installation and configuration procedures; operation; administration; software, wiring and power requirements; environmental and safety considerations; installing and using add-on modules, data options, and software. A section is also provided on engineering and configuring digital telephone lines.

This document does not provide information about IP Phones. For information on IP Phones, refer to *IP Phones: Description, Installation, and Operation* (553-3001-368).

Note on legacy products and releases

This NTP contains information about systems, components, and features that are compatible with Nortel Communication Server 1000 Release 4.5 software. For more information on legacy products and releases, click the **Technical Documentation** link under **Support** on the Nortel home page:

www.nortel.com

Applicable systems

This document applies to the following systems:

- Communication Server 1000S (CS 1000S)
- Communication Server 1000M Chassis (CS 1000M Chassis)
- Communication Server 1000M Cabinet (CS 1000M Cabinet)
- Communication Server 1000M Half Group (CS 1000M HG)
- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Communication Server 1000E (CS 1000E)
- Meridian 1 PBX 11C Chassis
- Meridian 1 PBX 11C Cabinet
- Meridian 1 PBX 51C
- Meridian 1 PBX 61C
- Meridian 1 PBX 81
- Meridian 1 PBX 81C

Note: When upgrading software, memory upgrades may be required on the Signaling Server, the Call Server, or both.

System migration

When particular Meridian 1 systems are upgraded to run CS 1000 Release 4.5 software and configured to include a Signaling Server, they become CS 1000M systems. Table 1 lists each Meridian 1 system that supports an upgrade path to a CS 1000M system.

Table 1
Meridian 1 systems to CS 1000M systems (Part 1 of 2)

This Meridian 1 system...	Maps to this CS 1000M system
Meridian 1 PBX 11C Chassis	CS 1000M Chassis
Meridian 1 PBX 11C Cabinet	CS 1000M Cabinet

Table 1
Meridian 1 systems to CS 1000M systems (Part 2 of 2)

This Meridian 1 system...	Maps to this CS 1000M system
Meridian 1 PBX 51C	CS 1000M Half Group
Meridian 1 PBX 61C	CS 1000M Single Group
Meridian 1 PBX 81	CS 1000M Multi Group
Meridian 1 PBX 81C	CS 1000M Multi Group

For more information, see one or more of the following NTPs:

- *Communication Server 1000M and Meridian 1: Small System Upgrade Procedures (553-3011-258)*
- *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures (553-3021-258)*
- *Communication Server 1000S: Upgrade Procedures (553-3031-258)*
- *Communication Server 1000E: Upgrade Procedures (553-3041-258)*

Intended audience

This document is intended for individuals responsible for installing, configuring, operating, administering, and troubleshooting Meridian proprietary telephones, attendant consoles and add-on modules, and engineering and configuring digital telephone lines.

Conventions

Terminology

In this document, the following systems are referred to generically as “system”:

- Communication Server 1000S (CS 1000S)
- Communication Server 1000M (CS 1000M)

- Communication Server 1000E (CS 1000E)
- Meridian 1

The following systems are referred to generically as “Small System”:

- Communication Server 1000M Chassis (CS 1000M Chassis)
- Communication Server 1000M Cabinet (CS 1000M Cabinet)
- Meridian 1 PBX 11C Chassis
- Meridian 1 PBX 11C Cabinet

The following systems are referred to generically as “Large System”:

- Communication Server 1000M Half Group (CS 1000M HG)
- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Meridian 1 PBX 51C
- Meridian 1 PBX 61C
- Meridian 1 PBX 81
- Meridian 1 PBX 81C

Related information

This section lists information sources that relate to this document.

NTPs

The following NTPs are referenced in this document:

- *Spares Planning* (553-3001-153)
- *Equipment Identification* (553-3001-154)
- *Circuit Card: Description and Installation* (553-3001-211)
- *Features and Services* (553-3001-306)
- *Software Input/Output: Administration* (553-3001-311)
- *Attendant PC: Description, Installation, and Operation* (553-3001-320)

- *Software Input/Output: System Messages (553-3001-411)*
- *Software Input/Output: Maintenance (553-3001-511)*
- *Communication Server 1000M and Meridian 1: Small System Upgrade Procedures (553-3011-258)*
- *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures (553-3021-258)*
- *Analog Terminal Adapter Quick Reference Card*
- *PC Console Interface Unit Installation Guide*
- *PC Console Interface Unit Quick Reference Guide*
- *Installing the Analog Terminal Adapter*
- *Meridian Digital Telephones: M3901, M3902, M3903, M3904 User Guide*
- *Meridian Digital Telephones: M3902, M3903, M3904 Quick Reference Guide*
- *Meridian Digital Telephone: M3905 Call Center User Guide*
- *Nortel M2016S Secure Set Quick Reference Guide*
- *Nortel M2016S Secure Set User Guide*

For information on IP Phones, refer to *IP Phones: Description, Installation, and Operation (553-3001-368)*.

Online

To access Nortel documentation online, click the **Technical Documentation** link under **Support** on the Nortel home page:

<http://www.nortel.com>

CD-ROM

To obtain Nortel documentation on CD-ROM, contact your Nortel customer representative.

How to get Help

Getting Help from the Nortel Web site

The best source of support for Nortel products is the Nortel Support Web site:

www.nortel.com/support

This site enables customers to:

- download software and related tools
- download technical documents, release notes, and product bulletins
- sign up for automatic notification of new software and documentation
- search the Support Web site and Nortel Knowledge Base
- open and manage technical support cases

Getting Help over the phone from a Nortel Solutions Center

If you have a Nortel support contract and cannot find the information you require on the Nortel Support Web site, you can get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7865).

Outside North America, go to the Web site below and look up the phone number that applies in your region:

www.nortel.com/callus

When you speak to the phone agent, you can reference an Express Routing Code (ERC) to more quickly route your call to the appropriate support specialist. To locate the ERC for your product or service, go to:

www.nortel.com/erc

Getting Help through a Nortel distributor or reseller

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, you can contact the technical support staff for that distributor or reseller.

Attendant consoles

Contents

This section contains information on the following topics:

Introduction	28
Engineering codes	29
Features	31
Busy Lamp Field/Console Graphics Module	32
Display backlight power supply option	44
DSS-9000 Direct Station Select/Busy Lamp Field	44
Attendant Supervisory Module	44
Physical description	48
Dimensions	48
Keyboard layout	51
Display screen messages	55
Display screen messages	55
Connections	56
Local console controls	56
Wiring	57
Installing wiring	57
Installation	59
Normal operating ranges	59
Packing and unpacking	59
Installation and removal	60
Installing the M2250 attendant console	60
Removing the M2250 attendant console	61

Removing the M2250 attendant console top cover	62
Installing the M2250 attendant console top cover	63
Performing a loopback test	64
Designating keys on the M2250 attendant console	64
Cross-connecting attendant consoles	68
Operation	77
M2250 configurations	77
Attendant PC requirements	78
M2250 feature key modes	79
M2250 console diagnostics	81
M2250 failure codes.	87
M2250 feature operation	89

Introduction

Attendant consoles are designed to assist in placing and extending calls into and out of a telephone switching system. The console is operated by an attendant who is the human interface between the system and the users.

The M2250 attendant console is a stand-alone, digital attendant console designed for telephone traffic control in the CS 1000 and Meridian 1. A Digital Line Card (DLC) connects the M2250 to the system.

The PC-based Console application software allows all functions supported by the M2250 to be performed on a computer workstation within a Windows 95®, Windows 98®, Windows 2000®, or Windows NT® operating system environment. The PC-based Console application operates with the PC Console Interface Unit (PCCIU). The PCCIU is typically installed under the attendant's PC monitor, and provides connection to the Main Distribution Frame (MDF) and PC communications port. The PCCIU is configured as an M2250 attendant console in LD 12. Refer to *Software Input/Output: Administration* (553-3001-311) for configuration information

In the North America, Asia Pacific and CALA market regions, the PCCIU and the Attendant PC software are available as a bundled package. In the EMEA market region, the PCCIU is available on its own or with a separate PC software application called SMILE.

For more information on Attendant PC and the PCCIU, refer to the following documents:

- *Attendant PC: Description, Installation, and Operation (553-3001-320)*
- *PC Console Interface Unit Installation Guide*
- *PC Console Interface Unit Quick Reference Guide*

Engineering codes

Refer to Table 2 for engineering codes for available M2250 attendant console models and related equipment. For ordering information, refer to *Equipment Identification (553-3001-154)*. For EMEA codes, please contact your local Nortel representative.

Table 2
Engineering codes for the M2250 and related equipment (Part 1 of 3)

Engineering code	Model	Color	Order code	Availability
NT3G40BB-35	BLF/CGM	Chameleon	A0652760	CALA, Spain, US
NT3G41BB-35	BLF/CGM	Chameleon Grey	A0652758	APAC, Canada
NT3G41BB-98	BLF/CGM	Dark Grey	A0652759	APAC
NT3G42BA-35	BLF/CGM	N/A	A0642991	Africa, Australia, Austria, Belgium, CIS, Denmark, Europe, Finland, France, Germany, Greece, Holland, Ireland, Middle East, Norway, Portugal, Sweden, Switzerland, Turkey, UK
NT3G42BA-93	BLF/CGM	Dolphin	A0656519	Australia, UK

Table 2
Engineering codes for the M2250 and related equipment (Part 2 of 3)

Engineering code	Model	Color	Order code	Availability
NT3G42BA-98	BLF/CGM	N/A	A0642994	Finland, France, Germany
NT6G00AF-35	M2250	Chameleon Grey	A0393450	Africa, APAC, CALA, CIS, Greece, Ireland, Middle East, NA, Portugal, Turkey
NT6G40BA-35	M2250	Chameleon Grey	A0642786	Switzerland
NT6G41BB-35	M2250	Chameleon Grey	A0642787	APAC, Norway
NT6G42BC-35	M2250	Chameleon Grey	A0642788	Denmark
NT6G43BA-35	M2250	Chameleon Grey	A0642789	Finland, Germany
NT6G43BA-98	M2250	Dark Grey	A0642790	Finland, Germany
NT6G44BA-35	M2250	Chameleon Grey	A0642791	Austria
NT6G45BA-35	M2250	Chameleon Grey	A0642792	Belgium
NT6G47BB-35	M2250	Chameleon Grey	A0642793	France
NT6G47BB-98	M2250	Dark Grey	A0642794	France
NT6G48BC-35	M2250	Chameleon	A0642795	UK
NT6G48BC-93	M2250	Dolphin	A0642796	New Zealand, UK
NT6G50BA-35	M2250	Chameleon	A0642797	Australia
NT6G50BA-93	M2250	Dolphin	A0642798	Australia

Table 2
Engineering codes for the M2250 and related equipment (Part 3 of 3)

Engineering code	Model	Color	Order code	Availability
NT6G53BB-35	M2250	Chameleon	A0655900	Holland
NT6G55BA-35	M2250	Chameleon Grey	A0642799	Spain
NT6G56BB-35	M2250	Chameleon Grey	A0642802	Sweden
NT6G57BA-35	M2250	Chameleon Grey	A0642803	Italy
NT6G57BA-98	M2250	Dark Grey	A0642804	Italy
NT3G30AA-35	Adjustable stand	Chameleon gray (ash)	A0348780	Global
NT3G30AA-98	Adjustable stand	BTS dark gray	A0348778	Global
NT7G10AA	Attendant Supervisory Module (ASM)	N/A	A0366221	Global

Features

The M2250 has the following features:

- A four-line, 40 character, liquid crystal display (LCD) with backlighting. Power, including backlighting, is maintained during building power failures with the system's battery backup, if equipped.
- Angle adjustment of the display screen, which can be tilted through 90° from horizontal to fully vertical.
- Scrolling control of lines 2 and 3 of the display screen.
- In Shift mode, the M2250 can have up to 20 Trunk Group Busy (TGB) keys.

- In Shift mode, the M2250 can have up to 10 extra flexible feature keys for a total of 20.
- An optional supporting stand that can be adjusted to nine different positions.
- A handset and headset volume slider control, situated below the dial pad.
- A physical connection to a serial data port through a subminiature D-type female connector on the console back wall. This permits connection of the console to the serial port of a personal computer.
- An optional Busy Lamp Field/Console Graphics Module (BLF/CGM), which displays the status of up to 150 consecutive extensions (SBLF) or any group of 100 extensions within the system (EBLF) and has many text and graphics capabilities.
- An optional Attendant Supervisory Module (ASM) can be installed.
- Supports transmission level adjustment to meet international requirements by accepting and processing downloaded information from the system (when this messaging is supported in software). The transmission level can be adjusted to one of 16 different levels.
- Multi-language selection.
- Menus for local console features (Options menu) and diagnostics (Diagnostics menu).
- Code blue or emergency relay (associated with ICI 0).
- Time and date system download.
- Alert tone volume and frequency selection.
- Electret or carbon transmitter support.
- Power Fail Transfer switch.
- Keyclick.

Busy Lamp Field/Console Graphics Module

The Busy Lamp Field/Console Graphics Module (BLF/CGM) can be added to an M2250 attendant console.

The BLF/CGM can do the following:

- display the status (busy or idle) of up to 150 consecutive extensions within the system Standard Busy Lamp Field (SBLF)
- display the status (busy or idle) of any hundred group of DN's within the system Enhanced Busy Lamp Field (EBLF)
- display which attendant console is the supervisory console and which consoles are active
- display supplementary information about individual extensions, such as the reason the person is away (business, vacation, or illness), when the person is due to return, and an alternate extension where calls to the person should be directed
- display a company logo
- display graphics
- display text in any one of eight languages
- have its screen contrast adjusted for easy viewing

Power requirements

The BLF/CGM obtains its power through the attendant console. See Figure 1 on [page 35](#). The requirements are as follows:

- a reference ground line (0 V)
- power source of 5 V for the CMOS electronics that control the Lamp Field Array module (c. 50 mA)
- power source of -12 V for the display of the Console Graphics Module (c. 10 mA)
- backlighting power

The BLF/CGM has a battery that provides backup power to maintain the Supplementary Information when the console is powered down. The battery lifetime is five years. To replace the battery, return the BLF/CGM to the supplier.

Installation

The BLF/CGM mounts on the back of the attendant console and is held on by snap-fits and screws. It is connected to the console using a 16-way connector that is located on the keyboard Printed Circuit Board (PCB). This connector is accessed through a rectangular knockout section located underneath the casing overhang at the Meridian logo location. The attendant console's top cover must be removed to install the BLF/CGM.

Refer to the following procedures to install the BLF/CGM:

- Procedure 1, "Connecting the BLF/CGM to the M2250 attendant console", on page [35](#)
- Procedure 2, "Checking the functionality of the Busy Lamp Field/Console Graphics Module", on page [42](#)
- Procedure 3, "Removing the Busy Lamp Field/Console Graphics Module", on page [43](#)


Refer to the *M1250/M2250 Attendant Console User Guide* or the *Busy Lamp Field/Console Graphics Module User Guide* for further information.



CAUTION WITH ESDS DEVICES

Follow normal antistatic precautions when installing the BLF/CGM on the attendant console.


Figure 1
Busy Lamp Field/Console Graphics Module on the M2250 attendant console



Procedure 1
Connecting the BLF/CGM to the
M2250 attendant console

- 1 Disconnect the main power/system cable from the rear of the attendant console, and remove the handset jack plug from the side.
- 2 Move the adjustable display to the down position to protect it from damage while installing the BLF/CGM. Move the volume slider switch to the far left. See Figure 2 on [page 36](#).


Figure 2
Volume slider position



- 3** Place the attendant console facedown on a properly prepared work surface, taking care to avoid scratching or damaging the top cover or display. Remove the adjustable stand, if required.


The stand is secured with four screws. Remove the stand as a complete assembly, and set aside.
- 4** Remove the 12 fastening screws in the base of the attendant console that secure the top cover to the console base. See Figure 3 on [page 37](#). Holding the console base and cover firmly, turn it over so that the top cover is on, facing up.

Figure 3
Removing the fastening screws




- 5 Raise and hold the top cover to remove the single cable connector only. The alerter cable does not need to be removed. See Figure 4 on [page 38](#).
- 6 Remove the top cover, and place it upside down to the left of the attendant console.

Figure 4
Removing the top cover




- 7** Remove the knockout section on the back of the attendant console (see Figure 5 on [page 39](#)) with a small screwdriver or similar tool. Remove any remnants of the breakaway tags.
- 8** Feed the flat ribbon cable for the Busy Lamp Field/Console Graphics Module (BLF/CGM) through the knockout hole in the base of the attendant console.
- 9** Hold the BLF/CGM unit over the console in a vertical position, ensuring that the two locators on the bottom bracket of the BLF/CGM are located in the knockout hole.

Figure 5
Attendant console knockout section



- 10** Push down on the attendant console, while holding the BLF/CGM unit, until the two locators snap into place. See Figure 6 on [page 40](#).
- 11** Fit the BLF/CGM ribbon cable onto the top cover circuit board, into the flexible strip connector J4 (so that the blue line on the cable faces away from the circuit board).
- 12** Hold the top cover over the attendant console and reconnect the cable connector(s) onto the base of the attendant console.
- 13** Place the top cover on the console. Slide it back and down into place. See Figure 7 on [page 41](#). Check that all the cables are in the correct positions and that none are trapped.
- 14** Push the BLF/CGM display into position by rotating it back (see Figure 7).
- 15** Ensuring that the volume slider is fully engaged in the correct slider, hold the top cover and console base firmly together. Turn the assembly upside down. See Figure 8 on [page 42](#).
- 16** Reinsert the 12 screws that secure the top cover to the console base and tighten.
- 17** Insert the two new screws supplied with the BLF/CGM that attach it to the base, and tighten. See Figure 8 on [page 42](#).

Figure 6
Connecting the BLF/CGM to the attendant console



- 18** Cable in BLF power at the local Main Distribution Frame (MDF) as per M2250 cross-connections.
- 19** If required, replace the adjustable stand.
- 20** Reconnect the main system cable to the rear of the console.
- 21** If the BLF/CGM has been correctly installed, the main menu appears when power is supplied to the attendant console. Test the BLF/CGM by selecting a menu option. Refer to *Busy Lamp Field/Console Graphics Module User Guide* for programming information.

- 22 Define the Busy Lamp Field in the system database. Refer to *Features and Services* (553-3001-306).
- 23 Test the Busy Lamp Field features using *M1250/M2250 Attendant Console User Guide*.

Figure 7
Positioning the top cover and the BLF/CGM





Figure 8
Attaching the top cover to the attendant console base and BLF/CGM



End of Procedure

Procedure 2
Checking the functionality of the
Busy Lamp Field/Console Graphics Module

Use this procedure to check the functionality of the BLF/CGM. Once in this menu, the dial pad is in CGM mode. When any dial pad keys are pressed, except the pound (#) key, the keys are echoed on the BLF/CGM.

- 1 From Diagnostics menu 1, press 5.
- 2 Press keys 0 through 9 and the asterisk (*) on the dial pad. Check the CGM to see that they are echoed.

- 3 Press the pound (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 3
Removing the Busy Lamp
Field/Console Graphics Module

- 1 Disconnect the main power/system cable from the rear of the attendant console, and remove the handset jack plug from the side.
- 2 Move the adjustable display to the down position to protect it from damage while removing the BLF/CGM. Also move the volume slider switch to the far left (see Figure 2 on [page 36](#)).
- 3 Place the attendant console facedown on a properly prepared work surface, taking care to avoid scratching or damaging the top cover or display. Remove the adjustable stand, if required.

The stand is secured with four screws. Remove the stand as a complete assembly, and set it aside.
- 4 Remove the 12 fastening screws in the base of the attendant console that secure the top cover to the console base. See Figure 3 on [page 37](#).

Remove the two screws securing the BLF/CGM to the base of the attendant console.
- 5 Holding the console base and cover firmly, turn it back over so that the top cover is on, facing up.
- 6 Raise and hold the top cover to remove the single cable connector only. The alerter cable does not need to be removed (see Figure 4 on [page 38](#)).
- 7 Unplug the BLF/CGM ribbon cable from the attendant console.
- 8 Remove the top cover and place it upside down to the left of the attendant console.
- 9 Pull back the snap-fits on the BLF/CGM to disengage the BLF/CGM from the attendant console.
- 10 Place the top cover on the console. Slide it back and down into place (see Figure 7 on [page 41](#)). Reconnect all cables in the correct positions, and make sure that none are trapped.

- 11 Ensuring that the volume slider is fully engaged in the correct slider, hold the top cover and console base firmly together. Turn the assembly upside down (see Figure 8 [page 42](#)).
- 12 Reinsert the 12 screws that secure the top cover to the console base and tighten.
- 13 If required, replace the adjustable stand.
- 14 Reconnect the main system cable to the rear of the console.

End of Procedure

For more on the features and operation of the BLF/CGM, refer to the *Busy Lamp Field/Console Graphics Module User Guide*.

Display backlight power supply option

An optional 16 V DC power supply (A0367601) can be installed to the Main Distribution Frame (MDF) to improve the backlight brightness of the BLF/CGM display.

The display backlight power supply must be cabled in at the local MDF at a maximum of 120 ft (36 m) from the attendant console when the BLF/CGM is installed (A0367601 – Transformer). This provides all the power requirements for the M2250 applications.

DSS-9000 Direct Station Select/Busy Lamp Field

The DSS-9000 is a combined 150-lamp busy field and 150-button direct station select console that can be attached to an M2250 attendant console. The DSS-9000 emulates either a QMT-3 Busy Lamp Field array (standard Busy Lamp Field mode) or the Enhanced Busy Lamp Field Mode of a Console Graphics Module. For more information on DSS-9000 Direct Station Select/Busy Lamp Field, refer to the *DSS-9000 Direct Station Select/Busy Lamp Field User Guide*.

Attendant Supervisory Module

A customer may wish to supervise an attendant console. To allow the M2250 to be supervised, an Attendant Supervisory Module (ASM) must be added.

An attendant console configured as a supervisor does not need the ASM installed.

To accept the ASM, the minimum vintage M2250 attendant console is M2250AD. To fully support the ASM, the minimum vintage BLF/CGM is AB. The third PWR TN must be programmed and wired out to support the ASM. See Figure 17 on [page 71](#).

Follow the steps in Procedure 4 to install an ASM on an M2250 attendant console.

Procedure 4
Installing an Attendant Supervisory Module
on an M2250 attendant console



CAUTION WITH ESDS DEVICES

Damage to Equipment

Before handling internal set components, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

- 1** Disconnect the main power/system cable from the rear of the attendant console, and remove the handset jack plug from the side.
- 2** Move the adjustable display to the down position to protect it from damage while installing the ASM. Move the volume slider switch to the left-most position.
- 3** Place the attendant console facedown on a properly prepared work surface, taking care to avoid scratching or damaging the top cover or display. Remove the adjustable stand, if equipped.

The stand is secured with four screws. Loosen the screws and remove the stand as a complete assembly, and set aside.
- 4** Remove the 12 fastening screws in the base of the attendant console that secure the top cover to the console base (see Figure 3 on [page 37](#)). Holding the console base and cover firmly, turn it back over so that the top cover is on, facing up.

- 5 Raise and hold the top cover to remove the single cable connector. The alerter cable does not need to be removed (see Figure 4 on [page 38](#)). Remove the top cover and place it upside down to the left of the attendant console.
- 6 Holes are located in the upper right-hand side of the attendant console's main PCB, near grid positions D1, D5, and A5. See Figure 9 on [page 47](#). Insert one standoff in each of the holes, twisting it until it is secure.



CAUTION


Damage to Equipment

Once a standoff is inserted, it cannot be removed. Be sure to place each standoff in the correct hole on the main PCB, as shown in Figure 9 on [page 47](#).

- 7 Position the ASM board over the J3 connector on the console's main PCB. Align the holes on the ASM board with the standoffs, and carefully work the ASM pin connector onto connector J3 until firmly seated. See Figure 9 on [page 47](#).
- 8 Hold the top cover over the attendant console, and reconnect the cable connector onto the base of the console.
- 9 Place the top cover on the console. Slide it back and down into place. Check that all the cables are in the correct positions, and that none are trapped.
- 10 Ensure that the volume switch is fully engaged in the correct slider. Hold the top cover and console base firmly together. Turn the assembly upside down.
- 11 Reinsert the 12 screws that secure the top cover to the console base and tighten.
- 12 If required, replace the adjustable stand.
- 13 Reconnect the main system cable to the rear of the console.
- 14 Test the supervisory console feature to make sure you can now properly supervise the M2250 attendant console. Refer to *M1250/M2250 Attendant Console User Guide*.

End of Procedure

Figure 9
Identifying the correct grid positions on the main PCB and attaching the ASM



Physical description

Figure 10 on [page 49](#) shows a top view of the M2250 attendant console layout. The user-accessible components are labeled using a row/column grid arrangement. Figure 11 on [page 50](#) shows rear, left side, and bottom views of the console. These illustrations show where to find the various components.

Dimensions

Dimensions of the M2250 attendant console are as follows:

Table 1
Dimensions

Width	425 mm (16.75 in.)
Depth	245 mm (9.6 in.)
Height (front)	25 mm (1 in.)
Height (back)	65 mm (2.5 in.)
Height (with display screen panel up)	115 mm (4.5 in.)
Weight	approximately 2.75 kg (6 lbs)

Figure 10
M2250 attendant console – top view





Figure 11
M2250 attendant console – rear, left side, and bottom views



Keyboard layout

Refer to Table 3 for the description of keys and Figure 10 on [page 49](#) and Figure 11 on [page 50](#) for the location of switches and keys mentioned in this section.

Function keys

The attendant console has eight function keys, located directly below the display screen. Refer to Table 3 for the positions, functions, and markings of these keys. For an explanation of the functions assigned to the other attendant console keys, refer to “Operation” on [page 77](#).

Table 3
Softkey definitions and functions (Part 1 of 3)




Key number (see Figure 10)	Symbol	Function
(1)		Centralized Attendant Service (CAS) File
(2)		Prime function (normal): Position Busy feature Level 1 function (Shift): Night Service feature
(3)		Prime function (normal): Selects display screen line 2 for scrolling. Level 1 function (Shift): Selects the Options menu on the display screen. Alternating between the idle and active call display. From the idle display, press this key to show the active call display.

Table 3
Softkey definitions and functions (Part 2 of 3)






Key number (see Figure 10)	Symbol	Function
(4)		<p>Prime function (normal): Scrolls the currently selected line to the left.</p> <p>Level 1 function (Shift): Decreases the alert speaker volume.</p>
(5)		<p>Prime function (normal): Scrolls the currently selected line to the right.</p> <p>Level 1 function (Shift): Increases the alert speaker volume.</p>
(6)		<p>Prime function (normal): Selects line 3 on display screen for scrolling.</p> <p>Level 1 function (Shift): Selects the Diagnostics menu on the display screen. The Diagnostics menu is password-protected. To display it, the user must enter a 4-digit password and press * on the dial pad.</p> <p>Alternating between the idle and active call display. From the active call display, press this key to show the idle display.</p>

Table 3
Softkey definitions and functions (Part 3 of 3)

Key number (see Figure 10)	Symbol	Function
(7)		Prime function (normal): Signal Source feature key Level 1 function (Shift and Conf/ Busy Lamp Field key): Used with the Busy Lamp Field/ Console Graphics Module, as CGM key.
(8)		Prime function (normal): Signal Destination feature key Level 1 function (Shift): Used with the Busy Lamp Field/ Console Graphics Module, as the Mode key.

Switches

A slider control, located below the dial pad, between columns DI/EI and FI, controls the handset and headset receive volume level. See Figure 10 on [page 49](#).

A Power Fail Transfer (PFT) switch is located in the baseplate. See Figure 11 on [page 50](#). Both the line connector and the RS-232 connector for the PC port are located at the back of the console.

Shift key

The Shift key is positioned in column FK, row 1, just above the Hold key. See Figure 10 on [page 49](#). It is used to access Level 1 mode functions.

Handset and headset jacks

Two pairs of jacks are provided for plugging in handsets or headsets. The jacks are located on both sides of the console beneath the faceplate in the recessed area shown by the arrows. See Figure 10 on [page 49](#). The console

accepts both carbon and electret handsets or headsets and automatically adapts itself to each type.

Note: Electret headsets and handsets are polarity sensitive and must be correctly inserted into the jack.

LCD indicators

The LCD indicators on the M2250 display triangular symbols that normally point towards the key with which they are associated. Certain keys in the QMT2 mode of operation and loop keys have two LCDs associated with each key instead of one.

Every LCD can flash at 30, 60, or 120 impulses per minute (ipm). Refer to “Operation” on [page 77](#) for more details.

The M2250 attendant console has 10 additional flexible features. These are programmed in LD 12 and accessed using the **Shift** key.

Display screen messages

Source information appears on line 2 of the display screen. Destination information appears on line 3 of the display screen.

The status messages listed below appear on line 4 of the display screen panel.

- MN (minor alarm)
- MJ (major alarm)
- C/H (CAS/History File)
- CW (Call Waiting)
- BUSY (Position Busy)
- NIGHT (Night Service)
- IDLE (Idle)
- ACTIVE (lpk has been selected)
- S (Shift mode)
- EMERGENCY (Power Fail Transfer (PFT) feature is activated.)

The first four status messages appear as MN, MJ, C/H, and CW on line 4 of the display screen panel. BUSY and NIGHT are combined with the status of the Release lamp to indicate the console status as shown in Table 4.

Table 4
Release lamp indicator status

Type	Indicator	Status	
Night	Busy	Release	Display screen status (line 4)
ON	X	X	NIGHT
OFF	ON	X	BUSY
OFF	OFF	ON	IDLE
OFF	OFF	OFF	ACTIVE
X	X	X	EMERGENCY

If the emergency power fail transfer feature is activated, the console status will be displayed as EMERGENCY.

Connections

The line cord connects to the rear of the M2250 attendant console through a 25-pin subminiature D-type connector. The jack connector is attached to the line cord for user safety and equipment protection (pins are not exposed). Having the plug connector mounted in the console also prevents interchanges between the line cord and the serial data port connectors (the serial data port in the console has a jack connector).

Identical two-prong G3 type connectors are provided on each side of the console body to permit handset or headset connection at either side of the console. The M2250 attendant console is compatible with both carbon and electret handsets or headsets. The electret handset plug is orientation-dependent and is labeled accordingly.

The attendant console is connected to the system through two digital ports – one port for Call Service processing and one for Call Destination processing – with three additional ports for powering, for a total of five ports. The PCCIU interface used for the PC-based Console software application requires only three ports in total.

The attendant console requires a Digital Line Card (DLC) or an Integrated Services Digital Line Card (ISDLC) NT8D02 or later.

Local console controls

Visual contrast on the display panel can be adjusted using the Contrast option on the **Options** menu.

From the **Options** menu, four-line mode can be changed to two-line mode for easier viewing and to use larger fonts.

The pitch and volume of the buzz tone on the console can be adjusted by the user.

Any one of 15 languages can be chosen for the console screen displays: English, French, Spanish, German, Italian, Norwegian, Irish (Gaeilge),

Turkish, Katakana, P.R.C. (People's Republic of China), Taiwan, Korean, Polish, Czech/Slovak, or Hungarian.

When the languages P.R.C., Taiwanese, and Korean are chosen, the attendant console uses two-line display.

The attendant console is equipped with a real-time clock/calendar. The time of day (hours, minutes, and seconds) and the date (day, month, and year) are displayed on line 1 of the display screen.

The sound of key clicks can be turned on or off. The pitch and volume of key clicks can be adjusted.

Wiring

The M2250 attendant console requires a 16-pair cable terminated on an Amphenol connector.

When zone cabling and conduit are used, assign a block of numbers or letters to each zone. Allow for growth when assigning blocks of numbers.

Cable markers are normally an adhesive-backed cloth tape 1/2 inches wide by 3-1/2 inches long (15 mm by 65 mm) with preprinted numbers.

For limits and cabling for analog (500/2500-type) telephones, refer to Figure 12 on [page 58](#).

For a list of terminal connections, see Table 5 on [page 59](#).

Installing wiring


Follow the steps in Procedure 5 to install the wiring for a telephone.

Procedure 5 **Installing wiring**

- 1 Assign a number to the wire or cable used.
- 2 Attach the assigned number to the wire or cable at the end nearest the telephone, using a cable marker.

- 3 Run the wire or cable between the telephone location and nearest cross-connect point (if not previously run).
- 4 Connect the cable or wire to the telephone connecting block.
- 5 Designate the telephone connecting block.

Figure 12
Zone cabling and conduit assignment



- 6 Cross-connect the pairs at intermediate cross-connect points (if required) and terminate at the cross-connect terminal.

- 7 Terminate leads at the cross-connect terminal and designate the blocks according to the house cable plan.

Table 5
Terminal connections

Connecting block Designations			Inside wiring Colors	
NE-47QA or QBB1B	NE-284-74-500 1 adapter	NE-625F TELADAPT plugs and jacks	Z station wire	16/25-pair cable
G	1T	T1 (G)	G	W-BL
R	1R	R1 (R)	R	BL-W
BK	X1	AUX (BK)	BK	W-O
Y	X2	GND (Y)	Y	O-W
5	R	T2 (BL)		W-SL
6	B	R2 (W)		SL-W

Normal operating ranges

The M2250 attendant console has a maximum permissible loop length of 3500 ft (915 m), assuming 24 AWG (0.5 mm) wire with no bridge taps. A 15.5 dB loss at 256 kHz defines the loop length limit.

Installation

This section provides installation instructions for the M2250 attendant console. For Attendant PC Software installation instructions, refer to *Meridian 1 Attendant PC: Software Installation Guide*.

Packing and unpacking

Use proper care while unpacking the M2250 attendant console. Check for damaged containers so that appropriate claims can be made to the transport company for items damaged in transit.

If an attendant console must be returned to the factory, pack it in the appropriate container to avoid damage during transit. Remember to include all loose parts (cords, handset, power unit, labels, and lenses) in the shipment.

Installation and removal

Use the following procedures to install and remove M2250 attendant consoles.

Note: Although M2250 attendant consoles do not require a static discharge ground connection, the connection should be installed to protect any earlier vintage attendant consoles that may be used as replacements.

Choose a clean, level work surface and place several sheets of soft, clean paper between the attendant console and the work surface. This will prevent scratching or otherwise damaging the top cover, LCD indicators and screen, and the feature keys of the attendant console.

Installing the M2250 attendant console

Follow the steps in Procedure 6 to install the M2250 attendant console.

Procedure 6 **Installing the M2250 attendant console**

- 1 Ensure that a 16-pair or 25-pair cable equipped with a 25-pair Amphenol connector is installed at the attendant console's location.
- 2 Unpack and inspect the attendant console for damage. If the console is damaged, notify the supplier.
- 3 Designate the console according to the features provided.
- 4 Connect the Amphenol plug on the attendant console to the Amphenol jack coming from the Main Distribution Frame (MDF).
 - a. Fasten the Amphenol connectors together and secure the captive screws on the cable.
 - b. Ensure that the connectors are secured in a connector mounting, if provided, or to the wall. Do not leave connectors unprotected on the floor.

- 5 Add a line circuit for the attendant console, if not already done. Refer to *Circuit Card: Description and Installation* (553-3001-211).
- 6 Cross-connect the attendant console at the cross-connect terminal. See Procedure 12 on [page 69](#).
- 7 Enter the related attendant console data in the system. Refer to *Software Input/Output: Administration* (553-3001-311).
- 8 Test the console features using the attendant console user guide.

Note: Refer to *Circuit Card: Description and Installation* (553-3001-211) for circuit card installation procedures.

End of Procedure

Removing the M2250 attendant console

Follow the steps in Procedure 7 if it is necessary to remove an M2250 attendant console.

Procedure 7

Removing the M2250 attendant console

- 1 Remove related attendant console data from the system memory. Refer to the *Software Input/Output: Administration* (553-3001-311).
- 2 Locate and remove cross-connections from the attendant console cable at the cross-connect terminal. See Procedure 12 on [page 69](#).
- 3 Remove the circuit card if required. Refer to *Circuit Card: Description and Installation* (553-3001-211).

Note: Do not remove the circuit card if any of the remaining units on the card are assigned.

- 4 Disconnect the Amphenol connector on the end of the cable leading to the cross-connect terminal from the connector on the cable leading to the attendant console.
- 5 Pack the attendant console, handset, and cords in a suitable container.

End of Procedure

Removing the M2250 attendant console top cover


Follow the steps in Procedure 8 to remove the M2250 Attendant top cover.

Procedure 8

Removing the M2250 attendant console top cover

- 1 Disconnect any plugs and cords from the attendant console.
- 2 Remove the ten 10-mm fastening screws in the flange of the attendant console, as well as one 10-mm and one 40-mm screw on the base of the attendant console. See Figure 13 for the M2250 assembly drawing.

Figure 13
M2250 assembly drawing (exploded view)



- 3 Holding the top cover and the base together by hand, turn the attendant console right-side up and place it back on the work surface.
- 4 Carefully lift the faceplate straight up and disconnect the 20-pin plug ribbon cable located at J2.

Note: On attendant consoles with a display attached to the top cover, do not connect or disconnect the cable to the display unless the attendant console line cord is disconnected.

End of Procedure

Installing the M2250 attendant console top cover

Follow the steps in Procedure 9 to install the M2250 attendant console top cover.

Procedure 9

Installing the M2250 attendant console top cover

- 1 Set the QMT2 dip switch. To locate the dip switch, look at the attendant console from the top. The QMT2 dip switch is the only dip switch on the topmost circuit board. Set the switch to ON (enable QMT2) or OFF (disable QMT2).

Note: The QMT2 feature must be enabled in system software. Refer to LD 12 in *Software Input/Output: Administration* (553-3001-311).
- 2 Carefully lift the top cover straight up and connect the 20-pin plug ribbon cable to J2.
- 3 Put the top cover back on the attendant console:
 - a. Place the top cover onto the base housing, and turn the attendant console upside down.
 - b. Reinsert and tighten the ten 10-mm fastening screws on the flange.
 - c. Reinsert and tighten one 10-mm and one 40-mm fastening screw on the back.
- 4 Return the attendant console to its working position, reconnect the plugs and cords, and test the features.

End of Procedure

Performing a loopback test

Follow the steps in Procedure 10 to perform a loopback test on the M2250 attendant console.

Procedure 10 **Performing a loopback test on the** **M2250 attendant console**

- 1 Make a loopback connector. Prepare a blank 25-way RS-232 plug by internally connecting pins 2 and 3 together with strapping wire.
- 2 Press the **Shift** key to access Level 1 mode.
- 3 Press the **F4** (function) key to access the Diagnostics menu on the LCD screen.
- 4 Plug the loopback connector into the Data Port RS-232 jack in the back of the console.
- 5 Select the Data Port option from the Diagnostics menu by dialing **3**. The LCD screen displays OK when the test is successfully completed.

If there is a hardware fault on the M2250, A0H is displayed.

If the blank RS-232 connector is not plugged into the data port correctly (as described in Step 4), the display reads 90H or A0H.
- 6 Press the asterisk (*) key to repeat the test.
- 7 To exit the test mode press the octothorpe (#). to return to the main Diagnostics menu.
- 8 Press the octothorpe (#) to return to normal operating mode.
- 9 Remove the loopback connector from the Data Port RS-232 jack.

End of Procedure

Designating keys on the M2250 attendant console

Refer to the work order to determine the features and key designations for each attendant console. Designate each key on the attendant console by placing its feature name (from the designation sheet) in the key cap that fits on the key.

The Directory Number (DN) designation window on the attendant console is located above the keypad.

Follow the steps in Procedure 11 to designate keys on an M2250 attendant console.

Procedure 11**Designating keys on an M2250 attendant console**

- 1** Remove the cap from each key requiring a designation by gently pulling upward on the cap.
- 2** Remove the appropriate designation from the sheet of designations.
- 3** Place the designation in the cap, place the cap over the corresponding key, and gently press down. Repeat this procedure for all keys requiring a designation.
- 4** Insert a paper clip in the hole at the left or right end of the DN designation window. Pry the window open.
- 5** Insert the number tag, and replace the designation window.

End of Procedure

The following figures show the typical key designations for the M2250 attendant console:

- Figure 14 on [page 66](#) shows the key designations for the M2250 attendant console in Shift mode.
- Figure 15 on [page 67](#) and Figure 16 on [page 68](#) show the M2250 attendant console in Unshift mode.

Figure 14
M2250 key designations in Shift mode (QMT2 not enabled)




Figure 15
M2250 key designations in Unshift mode (QMT2 enabled)





Figure 16
M2250 designations in Unshift mode (QMT2 not enabled)



Cross-connecting attendant consoles

Terminations are located on the vertical side of the distributing frame when frame-mounted blocks are used and located in the blue field when wall-mounted blocks are used.

Line circuit card (TN) terminations are located on the horizontal side of the distributing frame when frame-mounted blocks are used and located in the white field and wall-mounted blocks are used.

Follow the steps in Procedure 12 on [page 69](#) to cross-connect attendant consoles.

Procedure 12**Cross-connecting attendant consoles**

- 1 Locate the attendant console terminations at the cross-connect terminal.
- 2 Connect Z-type cross-connecting wire to the leads of the attendant console.
- 3 Locate the line circuit card (TN) terminations.
- 4 Run and connect the other end of the cross-connecting wire to the assigned TN terminal block.

End of Procedure

Refer to Table 6 for details on Z-type cross-connecting wire and Table 7 on [page 70](#) for a list of inside wiring colors.


Table 6**Z-type cross-connecting wire**

Size	Gauge	Color	Designation
1 pr	24	Y-BL	Tip
		BL-Y	Ring
3 pr	24	W-BL	Voice T
		BL-W	Voice R
		W-O	Signal T
		O-W	Signal R
		W-G	Power
		G-W	Power

Table 7
Inside wiring colors

Z station wire	16/25-pair cable	Connect to equipment TN
G	W-BL	First pair Tip
R	BL-W	First pair Ring
BK	W-O	Second pair Tip
Y	O-W	Second pair Ring

Figure 17
M2250 attendant console cross-connections



The following notes refer to Figure 17 on [page 71](#), which illustrates the M2250 attendant console cross-connections.

Note 1: The M2250 is powered by means of the line circuits. In addition to the primary TN, secondary TN, and ASM TN, two TNs are cabled to the M2250 using the +AUX and -AUX leads. The maximum loop length is 3000 ft of 24 AWG wire.

Note 2: When additional options are used (BLF or display backlight option), an additional 16 V DC power supply is required. The 16 V DC source is cabled using +VPS and VPS RTN leads. The maximum distance from the console to the power source is 120 feet of 24 AWG wire. Please note: if both options are installed, only one 16 V DC power supply is required.

Note 3: Nortel recommends that five consecutive TNs on the line circuit be allocated for each console.

Note 4: When used with the ISDLC, the M2250 requires NT8D02 or later.

Note 5: The third TN must be cross-connected to the console cable WH/SL pair whether or not an ASM (Attendant Supervisory Module) is installed. This third TN provides additional console power which is required.

Table 8 on [page 73](#) explains where each M2250 cable pair is connected. Table 9 on [page 75](#) lists the M2250 typical cross-connections.

Table 8
M2250 attendant console connections (Part 1 of 3)

Mounting cord	16/25-pair connector cable			
Lead designation	Pin number	Pair number	Color	Connected to
TCM primary	26 1	1T R	W-BL BL-W	TN #1
TCM secondary	27 2	2T R	W-O O-W	TN #2
Attendant Supervisory Module	30 5	5T R	W-SL SL-W	TN #3
Spare	31 6	6T R	R-BL BL-R	
+AUX	32 7	7T R	R-O O-R	TN #4
-AUX	33 8	8T R	R-G G-R	TN #5
Spare	34 9	9T R	R-BR BR-R	

Table 8
M2250 attendant console connections (Part 2 of 3)

Mounting cord	16/25-pair connector cable			
Lead designation	Pin number	Pair number	Color	Connected to
Spare	35	10T	R-SL	
	10	R	SL-R	
Power Fail or Energy Transfer	36	11T	BK-BL	GND (Note 1)
	11	R	BL-BK	TC (Note 2)
Spare	37	12T	BK-O	
Spare	12	R	O-BK	
Spare	38	13T	BK-G	
Spare	13	R	G-BK	
GND Major Alarm	39	14T	BK-BR	GND (Note 1)
	14	R	BR-BK	ALM (Note 2)
Spare	40	15T	BK-SL	
	15	R	SL-BK	
VPS	41	16T	Y-BL	
	16	R	BL-Y	
VPS RTN	42	17T	Y-O	
	17	R	O-Y	
Spare				
Code Blue	50	25T	Y-SL	Relay 2
	25	R	SL-Y	Relay 1

Table 8
M2250 attendant console connections (Part 3 of 3)

Mounting cord	16/25-pair connector cable			
Lead designation	Pin number	Pair number	Color	Connected to
<i>Note 1:</i> Connect to Pin 3 or 28 of the appropriate PFJ5 terminal block.				
<i>Note 2:</i> Connect TC to Pin 29 or 5 and ALM to Pin 4 or 31 of the appropriate PFJ5 terminal block.				

Table 9
M2250 typical cross-connections (Part 1 of 2)

Pair	Pins	Pair Color	DLC Connections	ISDLC Connections
1T	26	W-BL	Unit	Unit
1R	1	BL-W	0	0
2T	27	W-O	Unit	Unit
2R	2	O-W	1	8
3T	28	W-G	Unit	Unit
3R	3	G-W	2	1
4T	29	W-BR	Unit	Unit
4R	4	BR-W	3	9
5T	30	W-S	Unit	Unit
5R	5	S-W	4	2
6T	31	R-BL	Unit	Unit
6R	6	BL-R	5	10
7T	32	R-O	Unit	Unit
7R	7	O-R	6	3

Table 9
M2250 typical cross-connections (Part 2 of 2)

Pair	Pins	Pair Color	DLC Connections	ISDLC Connections
8T 8R	33 8	R-G G-R	Unit 7	Unit 11
9T 9R	34 9	R-BR BR-R	Unit 8	Unit 4
10T 10R	35 10	R-S S-R	Unit 9	Unit 12
11T 11R	36 11	BK-BL BL-BK	Unit 10	Unit 5
12T 12R	37 12	BK-O O-BK	Unit 11	Unit 13
13T 13R	38 13	BK-G G-BK	Unit 12	Unit 6
14T 14R	39 14	BK-BR BR-BK	Unit 13	Unit 14
15T 15R	40 15	BK-S S-BK	Unit 14	Unit 7
16T 16R	41 16	Y-BL BL-Y	Unit 15	Unit 15

Operation

This section contains operating procedures for the M2250 attendant console. The attendant console faceplate layout is shown in Figures 14 through 16, starting on [page 66](#). Refer to these figures as the basis for component location references throughout this section.

M2250 configurations

The M2250 attendant console can be configured to operate with the QMT2 feature, which is provided by a QMT2 add-on module incorporated in the console. Instead of having to add a keystrip unit, the technician can set a dip switch on the keyboard/controller Printed Circuit Panel (PCP) to ON (enable QMT2) or OFF (disable QMT2). It is important that the system software configuration and the QMT2 dip switch be set correctly.

For more information, refer to the section on LD15 in the following documents:

- *Features and Services* (553-3001-306)
- *Software Input/Output: Administration* (553-3001-311)

QMT2 feature disabled

When the QMT2 feature is disabled, the following conditions apply:

- If the console is not in Shift mode, keystrip AK is inactive.
- If the console is in Shift mode, the keys in strip AK function as Trunk Group Busy (TGB) keys, if configured in the system software.
- If the operator presses any of these keys, the associated trunk group is busied out.
- The triangle points aimed to the left of keystrip AK are never active.
- If the operator presses any key outside keystrip AK when the console is in Shift mode, the console performs the function associated with that key. The Shift indicator remains on.
- The keys in keystrip BK function as Incoming Call Identification (ICI) keys.

QMT2 feature enabled

When the QMT2 feature is enabled, the following conditions apply:

- If the console is not in Shift mode, the keys in strip AK and/or BK function as Incoming Call Identification (ICI) keys.
- If the console is in Shift mode, the keys in keystrips AK and BK function as Trunk Group Busy (TGB) keys. That is, they imitate the keystrips of the QMT2 add-on module as follows:
 - The LCD indicators pointing to the left indicate busy trunks.
 - The LCD indicators pointing to the right indicate incoming calls.


Attendant PC requirements

To install the PC-based Console software application, a PC-compatible Pentium system is required, with the following:

- minimum 16 MB RAM
- hard disk with at least 10 MB free disk space
- 17-inch SVGA color monitor
- 16 bit sound board
- Network interface adapter
- RS232 serial port

For complete installation and operation instructions, refer to the *Attendant PC: Description, Installation, and Operation* (553-3001-320).

Figure 18
PC Console Interface Unit



M2250 feature key modes

Functions shown for some of the feature keys in Table 3 [page 51](#) vary depending on which console mode is in effect while the key is being pressed. Table 10 on [page 80](#) lists the various alternate feature key functions.

When a feature key is pressed while the attendant console is in a mode other than normal or Level 1, nothing happens.

When in the normal call processing mode, access the Level 1 mode by pressing the **Shift** key. The LCD indicator beside the shift key lights and remains on throughout all options and menus. It goes out only upon return to normal call processing. All call processing keys that do not have a dual function perform normally while the console is in Level 1 mode. Press the **Shift** key again to return to normal call processing.

On the M2250 attendant console, press the pound (#) key to exit from any submenu from the Options menu, or from the Diagnostics menu to normal operating mode. Press the Shift key to return to the Level 1 mode.

Level 1 mode also provides access to additional call processing features, as well as to options and maintenance features. One of the additional call processing features is access to Trunk Group Busy (TGB) keys that are locked out in normal mode. For example, in normal mode, there are ten

available TGB keys on the M2250. With QMT2 enabled, the number of TGB keys on each console is doubled.

Table 10
Softkey alternate functions


Key	Operational mode	Function
F1	Normal	Selects line 2 of the display for scrolling.
F2	Normal	Scrolls left on the selected line, at 8 characters per step.
F3	Normal	Scrolls right on the selected line, at 8 characters per step.
F4	Normal	Selects line 3 of the display screen for scrolling.
Shift, F1	Level 1	Selects the Options menu.
Shift, F2	Level 1	Turns down the alerter speaker volume.
Shift, F3	Level 1	Turns up the alerter speaker volume.
Shift, F4	Level 1	Selects the Diagnostic menu. (A password must be entered on the M2250 before the Diagnostics menu appears.)
Example:		
Press Shift and F1 (in sequence)	Options menu	The Options menu is displayed.
	Press dial pad key 1	Accesses Contrast menu. (Refer to user guide for contrast setting routines.)
	Press dial pad key #	Returns to Options menu.

M2250 console diagnostics

Use the Diagnostics menu to check the functions of the console and to perform tests. To enter the Diagnostics mode, use Procedure 13. Figure 19 shows the main Diagnostics menu for the M2250 attendant console.

Procedure 13


Entering the M2250 Diagnostics mode

- 1 Press the **Shift** key.
- 2 Press the  key (**F4** function key).
- 3 On M2250 consoles, enter the password **9999**.
- 4 Press the asterisk (*) key to enter Diagnostics menu 1. To toggle between menu 1 and menu 2, press the asterisk (*) key.
- 5 To quit the Diagnostics mode, press the octothorpe (#) key.

————— **End of Procedure** —————

Follow the procedures listed below to perform the Diagnostic tests.

Figure 19
Console Diagnostics menus



Procedure 14
Testing the Keyboard

Use this procedure to check the functionality of each key on the console. When a key is pressed, its location code is displayed within parentheses. For example, (00) denotes the upper left-hand ICI key.

- 1 From Diagnostics menu 1, press 1.
- 2 Press any key on the console. The display shows the key's location code, indicating that the key is functional. Table 11 shows the key location codes.
- 3 Press the octothorpe (#) key to exit and return to Diagnostics menu 1.

Table 11
Key location codes for console diagnostics

		22	21	20	34		54	60	61	62		
00	10								70		80	90
01	11								71		81	91
02	12								72		82	92
03	13	23						63	73		83	93
04	14	24						64	74		84	94
05	15	25		35	45	55		65	75		85	95
06	16	26		36	46	56		66	76		86	96
07	17	27		37	47	57		67	77		87	97
08	18	28		38	48	58		68	78		88	98
09	19	29						69	79		89	99

Procedure 15
Testing the LCD indicators

Use this procedure to check the functionality of each LCD indicator on the console.

- 1 From the Diagnostics menu 1, press **2**.
- 2 Press 1 to turn all lamps ON. Press the asterisk (*) to turn each lamp OFF one by one.
- 3 Press 2 to turn all lamps OFF. Press the asterisk (*) to turn each lamp ON one by one.
- 4 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 16
Testing the data port

Use this procedure to perform a loopback test on the RS-232 port at the back of the console. Before performing the test, a connector (25-way D-plug) with pin 2 shorted to pin 3 should be inserted in RS-232 port. A failure code is displayed if any error is found.

- 1 From Diagnostics menu 1, press **3**. The display shows **OK** if the test is successful.
- 2 Press the asterisk (*) to repeat the loopback test.
- 3 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 17
Testing the ICS

Use this procedure to check the functionality of any peripheral devices connected to the User Interface Printed (UIP) and the Audio System Interface Printed (ASIP) microprocessor circuit cards within the console. A failure code is displayed if any error is found.

- 1 From Diagnostics menu 1, press **4**.
- 2 Press the asterisk (*) to perform the ICS test.

- 3 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 18
Testing the Busy Lamp Field/Console
Graphics Module

Use this procedure to check the functionality of the BLF/CGM. Once in this menu, the dial pad is in CGM mode. When any dial pad keys are pressed, except the octothorpe (#) key, the keys are echoed on the BLF/CGM.

- 1 From Diagnostics menu 1, press 5.
- 2 Press keys from 0 – 9 and the asterisk (*) on the dial pad. Check the CGM to see that they are echoed.
- 3 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

Note: For more information on installation and operation of this feature, see “Busy Lamp Field/Console Graphics Module” on [page 32](#), or refer to the *Busy Lamp Field/Console Graphics Module User Guide*.

End of Procedure

Procedure 19
Checking the Alerter

Use this procedure to check the pitches and volume levels of the alerter and auxiliary tone channel.

- 1 From Diagnostics menu 1, press 6.
- 2 Follow these instructions in any order:
 - Press key 1 to turn the buzz and auxiliary tones ON.
 - Press key 2 to turn the buzz and auxiliary tones OFF.
 - Press key 3 to increase the pitch of the buzz and auxiliary tones.
 - Press key 4 to decrease the pitch of the buzz and auxiliary tones.
 - Press key 5 to increase the volume of the buzz and auxiliary tones.
 - Press key 6 to decrease the volume of the buzz and auxiliary tones.
- 3 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 20
Testing the Display

Use this procedure to check the functionality of the alphanumeric display panel. Cycle through a number of different display patterns to check for visual defects.

- 1 From Diagnostics menu 2, press **1**.
- 2 Press the asterisk (*) to change the display screen pattern. Continue changing the pattern until all the patterns have been cycled through.
- 3 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 21
Displaying the firmware version numbers

Use this procedure to display the release and issue numbers of the firmware installed on the UIP and ASIP microprocessor circuit cards.

- 1 From Diagnostics menu 2, press **2**. The display shows the firmware release and issue numbers, as shown below:

```
DIAGNOSTICS:  FIRMWARE  
              ASIP: XX XX  
              UIP:  XX XX
```

- 2 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 22
Displaying and resetting the QMT2 switch status

Use this procedure to display the current state of the QMT2 dip switch inside the console and to change the setting for verification testing (LD 31). After a change, the actual switch setting will return to its original state after a time-out period of about three minutes.

- 1 From Diagnostics menu 2, press **3**.
- 2 Press the asterisk (*) to toggle between QMT2 ON and OFF.

- 3 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Procedure 23
Toggleing control gates

Use this procedure to turn the conference bridge analog control gates, the auxiliary tone channel, and the Code Blue Relay ON or OFF. Note that the auxiliary control only affects the control gate on the ASIP circuit card. To actually generate a tone, use the Alerter menu.

- 1 From Diagnostics menu 2, press "4."

DIAGNOSTICS: CONTROL

1. SCR	2. DST	3. ARX	4. ATX	5. TON	6. REL
{ 0 }	{ 0 }	{ 0 }	{ 0 }	{ 0 }	{ 0 }
* <OFF>				# <exit>	

- 2 Follow the appropriate instruction below:

Press key **1** to toggle the primary control gate between ON and OFF.

Press key **2** to toggle the secondary control gate between ON and OFF.

Press key **3** to toggle the attendant receive control between ON and OFF.

Press key **4** to toggle the attendant transmit control between ON and OFF.

Press key **5** to toggle the auxiliary tone control between ON and OFF.

Press key **6** to toggle the relay control between ON and OFF.

- 3 Press the asterisk (*) to turn all the control gates OFF.
- 4 Press the octothorpe (#) to exit and return to Diagnostics menu 1.

End of Procedure

Reset

To perform a hard reset of the console, from Diagnostics menu 2, press **5**. The reset is performed immediately. All devices and memory on the UIP and ASIP boards are reset as if the power cord were unplugged and plugged in again.

M2250 failure codes

A failure code appears on the display in response to the detection of a hardware fault.

Refer to Table 12 for an explanation of failure codes and possible solutions.

Table 12
M2250 failure codes (Part 1 of 2)

Failure code	Printed circuit pack (PCP)	Reason	What to do
40H	UIP	The PSG, U13, is not responding.	Unplug the line cord and plug it in again. If the failure code still appears, there is an electrical fault in the console, and it should be returned.
			Note: Log the failure code with the returned unit, as it gives an indication of which component has failed.
20H	UIP	The RTC, U16, is faulty.	Same as for 40H .
10H	UIP	The RAM IC, U1, is faulty.	Same as for 40H .
08H	UIP	A key in column A is stuck.	Unplug the line cord. Free the key if it is stuck. Plug in the line cord. If the failure code still appears, the console is faulty and should be returned.
09H	UIP	A key in column B is stuck.	Same as for 08H .

Table 12
M2250 failure codes (Part 2 of 2)

Failure code	Printed circuit pack (PCP)	Reason	What to do
0AH	UIP	A key in column C is stuck.	Same as for 08H .
0BH	UIP	A key in column D0 is stuck.	Same as for 08H .
0CH	UIP	A key in column D1 is stuck.	Same as for 08H .
0DH	UIP	A key in column D2 is stuck.	Same as for 08H .
0EH	UIP	A key in column E is stuck.	Same as for 08H .
0FH	UIP	A key in column F is stuck.	Same as for 08H .
A0H	ASIP	The RS-232 has failed the loopback test.	Check to see if the loopback connector is inserted. If not, insert it and perform the loopback test again. If the failure code still appears, turn the console off and on while the connector is inserted. Perform the loopback test again. If the failure code still appears, the console is faulty and should be returned.
90H	ASIP	ASM A44#3, U1, is faulty.	Same as for 40H .
88H	ASIP	Secondary A44#2, U2, is faulty.	Same as for 40H .
84H	ASIP	Primary A44#1, U1, is faulty.	Same as for 40H .
82H	ASIP	The UART, U5, is faulty.	Same as for 40H .
81H	ASIP	The RAM, U8, is faulty.	Same as for 40H .

The failure codes produced by the firmware in response to the detection of a hardware fault are bit-significant as follows:

B7	B6	B5	B4	B3	B2	B1	B0
0	PSG	RTC	RAM	KEYS	c2*	c1*	c0*
1	ASIP	RS-232	A44#3	A44#2	A44#1	UART	RAM
<p>* Refers to key's column number.</p> <p>Note: Bit 7 indicates whether the failure occurred on the user interface printed circuit card (UIP) (B7=0) or on the audio and system interface printed circuit card (ASIP) (B7=1).</p>							

In most instances, the failure code accurately identifies the faulty hardware component. However, if the microprocessor is faulty, the readings may be unreliable or misleading.

Failure code A0H is always shown if the loopback test has not been performed. Refer to "Testing the data port" on [page 83](#).

M2250 feature operation

Time and date

On the M2250, the time and date are automatically downloaded from the system on power-up or console reset. The time and date are downloaded by the switch whenever it runs a lamp audit. Only the visual format can be changed.

Trunk Group Busy indicators

Trunk Group Busy (TGB) indicators show the status of each group of trunks. If a TGB indicator is on steadily, the attendant has busied out all trunks in that group by pressing the Shift key plus the TGB key. If a TGB indicator is flashing, all the trunks in that group are actually busy.

In Supervisory mode, TGB indicators show the status of other consoles in the customer group. If the indicator is off, the attendant position is in a Position

Busy mode. When an indicator associated with a particular attendant is on, the attendant is available to service calls.

Note: The M2250 attendant console must be equipped with the Attendant Supervisory Module (NT7G10AA) to allow attendant supervision.

Incoming Call Indicators

Incoming Call Indicators (ICI) display the various types of incoming calls presented to the attendant console. They also indicate the number of calls and the length of time calls have been queued.

- If the indicator is on, one call has been queued for less than a certain length of time (as defined by software).
- If the indicator is flashing, one call has been queued for more than the defined length of time, or there is more than one call in the queue.

Night service/busy

When the **Shift** key is off, press the **Busy** key to put the attendant console into Position Busy mode. When the **Shift** key is on, press the **Busy** key to put the console into Night Service mode. To return to normal operating mode, press the **Busy** key again.

In a multi-console system, activating Night Service mode will busy out all attendant consoles in the system.

Enhanced Night Service

This feature allows Public Network (Central Office [CO], Direct Inward Dial [DID], Foreign Exchange [FEX], and Wide Area Telephone service [WAT]) trunks to be assigned to specific Directory Numbers (DN) during Night Service.

With this feature each customer will be able to assign Public Network trunks to one of nine Night Groups. Each Night Group will allow the customer to define up to nine Night DNs. During Night Service incoming calls will be routed to one of the Night DNs defined for the group. The actual DN the call will be routed to is determined by the Night Service Option number selected at that time.

The customer will also be able to define whether Night Call Waiting tone will be given to Night stations. With Night Call Waiting tone allowed, busy Night stations are notified when an incoming call is terminating on them. The incoming call will be queued on the Night station until it becomes idle. When the Night station becomes idle, the incoming call will be presented.

This enhancement allows incoming DID trunks to be queued against busy Night stations, thereby making the operation of the DID trunks the same as for all other Public Network trunks.

Attendant Blocking of DN

The Attendant Blocking of DN (ABDN) feature enables the attendant to block a DN for a telephone from receiving or making calls. This is particularly useful when a caller dials the attendant DN and requests an external (long distance) call. If the caller chooses to disconnect until the attendant successfully places the call, the requesting DN becomes idle and can receive or make calls. Therefore, the requesting DN could be busy when the attendant establishes the requested call.

To prevent the requesting DN from being busy when the requested call is completed, the attendant can block the DN from making or receiving calls. To callers attempting to contact the blocked DN, the line appears busy. To a caller attempting to use the blocked DN, the line is connected to the attendant.

When the attendant completes the external call, the attendant can call the blocked DN and extend the call. This feature applies to both stand-alone and ISDN network environments.

The Attendant Blocking of DN feature is available on the M2250 attendant consoles. It is not valid on M2616 telephones used as attendant consoles.

Attendant and Network Wide Remote Call Forward

This modification to the Remote Call Forward feature (RCFW) allows a user to program a call forward Directory Number from any attendant console or station throughout the network. An RFW key on the attendant console allows an attendant to view any station's call forward status and to activate or deactivate call forward for a station.

Refer to *ISDN Primary Rate Interface: Features (553-3001-369)* for further details.

Network Attendant Services

This feature allows attendant services to be distributed anywhere within a Meridian ISDN network. If, at the time of an attendant request, attendant services are not available at a station's local node, connection to an attendant at a remote node takes place. Call treatment is the same as for a connection to a local attendant node.

Call processing

The attendant answers an incoming call by pressing the flashing loop key.

To answer a specific type of incoming call, press the ICI key next to the appropriate ICI indicator. This removes the call from the queue and presents it to the attendant.

ICI key assignments

An ICI key may be assigned more than one call type. Refer to *Software Input/Output: Administration (553-3001-311)*. If the Attendant Call Party Name Display (ACPND) feature is equipped, all incoming calls are displayed by calling party name or external call source. The following examples list possible ICI key assignments:

- **Attendant Intercept** indicates that a call is being made by a station to a facility to which that station is restricted, and the call has been routed to the attendant console.
- **Listed Directory Numbers (maximum four)** indicates that a call is being made to an attendant console associated with one of the listed directory numbers.
- **Dial 0** indicates that a station that is not fully restricted has dialed 0.
- **Fully Restricted Station** indicates that a fully restricted station has dialed 0.
- **Foreign Exchange** indicates that the incoming call is from a foreign exchange.

- **Wide Area Telephone Service** indicates that the incoming call originated at a wide area telephone exchange.
- **Recall** indicates that a camped-on call or a call extended to an idle station has not been answered for 30 seconds or that a station is recalling the attendant.
- **Call Forward** indicates that the call is being forwarded to the console from a station within the system.
- **Tie Trunk** indicates that the incoming call is on a tie trunk.

Operating keys

The operating key/lamp strips CI/CK, DI, EI, and FI/FK allow the attendant to process calls from the console.

Key/lamp strips CI/CK and FI/FK have permanently assigned functions as given in the following list.

- **Release** allows the attendant to release a call presented to the console. When the LCD associated with the RLS key is lit, it indicates that no incoming calls are being presented to the console.
- **Loop Keys/Lamps** allow the attendant to answer and originate calls from the console. The first call in the incoming queue is automatically presented to an idle loop key. Subsequent calls are queued and presented to a loop key when a loop becomes idle. Call selection is made by pressing the required ICI key. This action causes the call, which was automatically presented to the loop key by the system, to be replaced by the selected incoming call. In all cases, when the loop key is pressed, all ICIs go dark except the one associated with the call presented to the loop key.
- **Position Busy** enables the attendant to put the console in Position Busy mode. All calls directed to a console in Position Busy mode are redirected to a free console in multiconsole installations or to the night connection in single console installations. When a console is in Position Busy mode, "BUSY" is shown on line 4 of the display.

- **Night Service** permits incoming calls to the attendant to be routed to a preselected station. The Night Service key enables the attendant to assign the Night Directory Number (DN) and to initiate Night Service. When assigning the Night Service DN, “NIGHT” flashes on line 4 of the display. When Night Service is on, “NIGHT” appears without flashing on the display.
- In a multiconsole system, activating Night Service will busy out all attendant consoles in the system.
- **Hold** allows the attendant to hold an active call at the console while serving other calls.
- **Conference** permits the attendant to set up a conference of up to five conferees plus the attendant.
- **Release Destination** allows the attendant to release the called party from a call held at the console while holding the calling party.
- **Release Source** allows the attendant to release the calling party from a call held at the console while holding the called party.
- **Signal Source and Destination** allows the operator to recall either party to a call held on the console.
- **Exclude Destination** excludes the called party from an established call held at the console, allowing the attendant to speak privately with the calling party.
- **Exclude Source** excludes the calling party from an established call held at the console, allowing the attendant to speak privately with the called party.

Feature keys

Any of the keys on keystrip FK can be assigned any of the optional features in the list that follows except the Barge-In and Busy Verify features. These require five LCD indicator states (off, on, and flash at 30, 60, or 120 impulses per minute). If Barge-In or Busy Verify is required, it must be assigned to keys FK-0 and FK-1.

All other features may be assigned to any of the keys on strip FK. Refer to *Software Input/Output: Administration* (553-3001-311) for additional information. The following are some of the more common feature keys:

- **Attendant End to End Signaling** enables the attendant to send dual tone multifrequency (DTMF) signals to either the source or destination party.
- **Busy Verify** allows the attendant to confirm that a station returning a busy signal is actually being used.
- **Barge-In** allows the attendant to enter an established trunk connection for the purpose of talking to one or both parties.
- **Paging** allows access to a public address facility.
- **Speed Call** allows numbers to be dialed automatically by pressing the SPEED CALL key and dialing a 1- or 2-digit code.

Call Waiting indicator

The Call Waiting indicator indicates that there is a queue of calls to be answered. When one or more calls are waiting, “CW” appears on line 4 of the display. The CW display changes from steady to flashing when waiting calls exceed a certain number or when a call has been waiting longer than a specified time.

The maximum number of waiting calls and the maximum hold time for each waiting call to be answered can be set with a data administration task. Refer to *Features and Services* (553-3001-306) for more information.

An optional buzz is available to indicate when the first call enters the queue. The number of waiting calls can be viewed on the LCD screen by pressing a key assigned on the attendant console. On the M2250, the number of waiting calls can be displayed continuously on line 4 of the display, if defined in LD15 and selected from the Options menu.

Alarm indicators

Alarms appear on line 4 of the display. “MN” indicates a minor alarm condition; “MJ” indicates a major alarm. A minor alarm is an indication of a minor system failure affecting a limited number of lines or trunks. A major alarm indicates that Emergency Transfer may have been initiated. See “Emergency Transfer” on [page 96](#).

Emergency Transfer

If a major equipment or power failure halts local call processing, preselected CO trunks are automatically connected to preselected stations (predetermined and hard-wired at installation time) through relays in the system. Emergency Transfer can also be activated manually by a switch underneath the attendant console.

If the switch is activated while the console has power, the word “EMERGENCY” appears on line 4 of the display.

Attendant Administration

Attendant Administration is an optional feature that allows the attendant to modify some of the features assigned to selected telephone sets within the attendant’s customer group. The attendant can enter a special program mode with an assigned key.

Once in the program mode, the console key/lamp strips have different functions from those during normal call processing. A plastic overlay can be placed over the console keyboard to identify the altered key functions. Refer to *Features and Services* (553-3001-306) for Attendant Administration description and operating procedures.

Collect Call Blocking

The Collect Call Blocking feature enables a system administrator to block long distance collect call service calls on incoming Direct Inward Dialing (DID) and Public Exchange/Central Office trunks (analog or DT12).

Under the following conditions, the system sends a special answer signal to the Central Office to indicate that collect calls cannot be accepted:

- The Collect Call Blocking (CCB) package 290 is enabled.
- The incoming route has CCB enabled via the CCB prompt in the Route Data Block.
- The call is answered by a CCB user (that is, Collect Call Blocking Allowed Class of Service or option).

Classes of service and prompts are provided which enable administrators to inhibit specific users from receiving collect DID and Central Office calls. These can be configured for the following:

- PBX and BCS through the Collect Call Blocking Allowed/Denied (CCBA/CCBD) option
- Attendant and Network Alternate Route Selection calls on a per customer basis through CCBA/CCBD option
- Automatic Call Distribution (ACD) queues through the CCBA prompt
- Direct Inward System Access (DISA) through the CCBA prompt
- Tandem calls dialed with Coordinated Dialing Plan (CDP) (Trunk Steering Code, Distant Steering Code) through the CCBA prompt
- Tandem non-CDP calls through the CCBA prompt in the Route Data Block from the outgoing trunk route

When a call is answered by a CCB user, the system sends the CCB answer signal in place of the regular signal for incoming DID/CO calls from the routes with CCB enabled. If the call is a collect call, The CO will disconnect the call.

Alarm Management

The Integrated Alarm Management feature is a series of subfeatures which improve the handling of key alarm messages generated by the system and its Application Processors.

It also clarifies existing alarm messages and makes attendant console alarm lamp signals more meaningful. The system has three levels of alarm: critical, major, and minor. The attendant console alarm lamp will light when critical alarms occur.

Digital Trunk Interface – CIS

The CIS DTI trunk feature provides connectivity between the system and digital trunks used in the Commonwealth of Independent States (CIS).

The CIS 2 Mbps DTI feature enables the system to connect digital DID/COT trunks to a CIS Local Central Office and to a CIS Toll Exchange (through Local CO and Public Network, or directly for incoming toll call connections).

This link supports DID/COT trunking types, and requires that the system be equipped with at least one CDTI2/CSDTI2 digital trunks pack, as well as associated software.

DPNSS Executive Intrusion

Executive Intrusion (EI) allows an originating party to break into an established call between two other parties (the wanted and the unwanted parties) under certain circumstances. If intrusion succeeds, a conference takes place on the wanted node between the originating, wanted and unwanted parties.

EI succeeds in breaking into the call based on comparisons between the Intrusion Capability Level (ICL) of the originating party and the Intrusion Protection levels (IPL) of the wanted and unwanted parties.

The system provides Executive Intrusion from attendant consoles. Executive Intrusion from Telephone Sets is not supported. However, a Meridian 1, CS 1000M, or CS 1000S PBX will accept an EI activation request from an ordinary set on a third party PBX.

Attendant Monitor

Attendant Monitor is a customer-defined option which allows the attendant to monitor – in listen only mode – any established call involving a set or trunk on the customer with or without the connected parties being aware that monitoring is taking place (depending on the configuration of the customer tone option).

The differences between the existing Busy Verify and Barge-in features and the Attendant Monitor feature are the following:

- Attendant Monitor provides a listen only path for the attendant.
- There is no click sound given to the connected parties upon Attendant connection when the no tone option is configured.
- The tone to the connected parties may or may not be given depending on the customer tone options for Attendant Monitor.
- The display (if there is one) on any of the parties involved in the calls does not indicate that the Attendant is monitoring.

Busy Verify and Barge-in Enhancement

Attendant Monitor changes the operation of Busy Verify and Barge-in slightly. Tone is now configurable. Busy Verify and Barge-in restrictions relating to the Warning Tone Allowed/Denied Class of Service apply to Attendant Monitor as well.

Attendant Forward No Answer

Attendant Forward No Answer allows two enhancements to existing operations. The first enhancement permits calls presented to the attendant to forward to a second attendant or the night DN when a customer-defined time expires. The second enhancement allows DID or CO calls to any set during night service to disconnect if not answered within a predefined number of ring cycles.

Attendant Forward No Answer is selectable on a customer basis, and is included in the package 134, AFNA.

Semi-Automatic Camp-On

Semi-Automatic Camp-On is an option to the current camp-on operation. When the party to which a call is camped-on becomes free, the attendant is recalled first instead of the wanted party being rung immediately. The modification is implemented under the Semi-Automatic Camp-on (SACP) package.

When an external call is camped on to a busy DN by an attendant or a set, the called party receives a buzz (for digital sets) or a burst of tone (for analog [500/2500-type] sets), indicating camp-on. Without SACP, if the called party becomes idle within a customer-defined time, the camped-on call rings the station immediately.

With SACP, if the called party becomes idle, the camped-on call recalls the attendant instead of ringing the called party. The called party meanwhile is kept busy from receiving any calls (but is still able to originate calls).

A programmable key, the Semi-Automatic Camp-on Recall (SACP) key is included with the SACP feature. When a recall is presented to the console, the RECALL ICI lamp and the SACP lamp light up. After answering the recall from the calling party, the attendant can ring the called party by pressing the

SACP key. The attendant can then hold the call on the console, or release the call as usual.

When the attendant tries to present the call (after it has recalled to the attendant) to the wanted party, this party may have originated another call. In that case, the attendant receives the indication that the set is busy, and can then camp-on the call again or release it, as usual. On a second camp-on, the attendant must activate the SACP feature again, if needed.

The SACP feature is active either for all camped-on calls or on a per-call basis depending on the customer option. When the per-call basis is chosen, the attendant activates the feature by pressing the SACP key before camping-on the call. If the SACP key is pressed twice, the associated lamp goes dark, and the SACP feature becomes inactive for the call.

Series Call

The Series Call feature causes a source call (either an attendant-answered incoming call, or an attendant-originated trunk call), that has been extended to an internal destination party, to be recalled to the attendant when the destination party hangs up. The attendant can then send the source call to another destination party. This feature enables a caller to talk to more than one party without having to disconnect and call again. Recall to Same Attendant must be allowed, otherwise the recall is routed to the first available attendant. This process can be repeated for as many destinations as requested by the caller.

A Series Call is canceled if one of the following occurs:

- the attendant presses the SECL key while the associated lamp is lit
- the attendant extends the source to a trunk while the SECL lamp is lit
- the attendant enters Night Service after extending the call and prior to receiving the recall
- the destination is call forwarded to a trunk
- the source disconnects

Powering and reset

After a power failure or a temporary corruption of data, the M2250 attendant console is reset automatically.

If a permanent fault condition is detected, the console enters the maintenance mode (Position Busy), and a failure message is displayed on the LCD screen.

Note 1: The failure code format is XXH, where XX is a two-digit hex-code indicating where the fault has been detected. Refer to Table 12 on [page 87](#) for explanations of the failure codes.

Note 2: When the BLF/CGM is attached to the console, an additional 16 V DC power supply (A0367601) is required for optional backlighting.

M2016S Secure Set

Contents

This section contains information on the following topics:

Introduction	104
Software requirements	105
Physical description	106
LCD indicators	106
Volume control	106
Message Waiting lamp	107
Features	108
Display Module	108
Program key	108
On-hook security	109
Specifications	109
Environmental and safety considerations	109
Line engineering	110
Local alerting tones	110
Power requirements	111
Installation	113
Packing and unpacking	113
Installation and removal of M2016S Secure Set	114
Designate the telephone	119
Cross-connect the telephone	119

Introduction

The M2016S is a Telephone Security Group Class II-approved telephone designed to provide on-hook security. It is a high-performance multi-line telephone with 16 programmable feature keys. The M2016S uses relay circuitry that physically disconnects the handset from the telephone circuit when the switchhook is depressed. The red LED triangle lights steadily when the phone is not secure (that is, when the handset is off the hook, the phone is ringing, or the handset/piezo relays are connected). The red LED triangle blinks when a message is waiting.

The M2016S has no handsfree capability. The M2016S does not support any accessories, options, or add-on modules.

The telephone's dimensions are as follows:

Length: 9.75 in. (250 mm.)


Width: 9.45 in. (235 mm.)

Height: 3.64 in. (93 mm.)

Weight: approximately 2 lbs. (1 kg.)

Figure 20 illustrates the M2016 Secure Set.

Figure 20
M2016S Secure Set



Software requirements

The option number for the M2016S is 170. The mnemonic is ARIE. The DSET package (88) and the TSET package (89) are required.

Physical description

The M2016S is equipped with:

- LCD indicators
- Volume control
- Message Waiting lamp
- Hold key
- Release key
- Speaker

LCD indicators

The M2016S has a number of programmable keys with LCD indicators that can be assigned to any combination of directory numbers and features. The lower right-hand key (key 0) is reserved for the Primary DN.

When equipped with a Display module, key 07 is automatically assigned as the Program key and cannot be changed.

LCD indicators support 4 key/LCD states:

Function	LCD state
idle	off
active	on (steady)
ringing	flash (60 Hz)
hold	fast flash (120 Hz)

Note: An indicator fast flashes when a feature key is pressed but the procedure necessary to activate the feature has not been completed.

Volume control

One key with two toggle positions controls volume. Pressing the right “volume up” or left “volume down” side of the key incrementally increases or decreases the volume for the tone or sound which is currently active. The volume settings are retained for subsequent calls until new volume

adjustments are made. If the telephone is equipped with a Display Module, volume can be adjusted at any time with the setting displayed on the screen (in Program mode).

Handset volumes can be configured to return to nominal on a per call basis.

You can adjust the volume of the following tones, while they are audible:

- ringing
- handset/headset
- buzz
- on-hook dialing

When the telephone is disconnected, all volume levels will return to default values upon reconnection.

Message Waiting lamp

The telephone has a red triangle in the upper right-hand corner that lights brightly to indicate a message is waiting. This LED is the primary message waiting indicator and lets you know a message is waiting regardless of whether the telephone has a message waiting key/lamp pair. You must have Message Waiting CCOS configured.

If you do assign a message waiting key/lamp pair, there will be two indications of a message waiting:

- the red Message Waiting triangle blinks, and
- the LCD associated with the Message Waiting key flashes.

You may assign an Autodial key that dials the message center (or voice mail system) to avoid the double indication, or have no key/lamp pair assigned to the message center.

The Message Waiting lamp is also used to indicate security of the M2016S. The red LED triangle lights steadily when the phone is not secure (handset is off-hook, phone is ringing or any time the handset/piezo relays are connected). The red LED triangle blinks when a message is waiting.

Features

The M2016S has 16 programmable keys. Earlier models can have a Display Module added. Later models of the set come with a display pre-installed.

Note: If the set is equipped with a Display, the number of programmable keys is reduced by one, as key 07 automatically becomes the Program key.

The features of the M2016S are as follows:

- Display Module (field-installable)
- Program key
- On-hook security

For more information on M2016S features and operation, refer to *Nortel M2016S Secure Set User Guide* or *Nortel M2016S Secure Set Quick Reference Guide*.

Display Module

A 2-line by 24-character Display Module (NT2K28ABxx) provides system prompts, feedback on active features and valuable calling party information. In addition, you can modify various set features such as volume and screen contrast using the Program key (top right function key). You can enable a Call Timer which times calls made or received on the prime DN.

The Display Module supports normal business features in several languages, including English, Spanish, and Quebec French.

Note: You can adjust the display screen contrast so that it is too light or too dark to read. If you cannot read the display, disconnect and then reconnect the line cord to return to the default settings.

Program key

The Program key is automatically assigned to telephones with a Display Module. The Program key allows you to change a variety of display features such as screen format, contrast and language.

The upper right-hand key (key 07) automatically becomes the Program key when a Display Module is configured with the telephone. The Program key is local to the set and shows blank when you print key assignments in LD 20.

On-hook security

The M2016S is a Telephone Security Group Class II-approved telephone designed to provide on-hook security. The M2016S uses relay circuitry that physically disconnects the handset from the telephone circuit when the switchhook is depressed.

On-hook security is indicated by the Message Waiting lamp. The red LED triangle lights steadily when the phone is not secure (handset is off-hook, phone is ringing or any time the handset/piezo relays are connected). The red LED triangle blinks when a message is waiting.

Specifications

The following specifications govern the performance of the M2016S telephone under the environmental conditions described.

Environmental and safety considerations

The M2016S meets the requirements of Electronic Industries Association (EIA) specification PN-1361.

Temperature and humidity

Tables 13 and 14 show the M2016S temperature and humidity requirements.

Table 13
M2016S operating state temperature and humidity requirements

Temperature range	0° to 50° C (32° to 104° F)
Relative humidity	5% to 95% (non-condensing). At temperatures above 34°C (93°F) relative humidity is limited to 53 mbar of water vapor pressure.

Table 14
M2016S storage state temperature and humidity requirements

Temperature range	-50° to 70° C (-58° to 158° F)
Relative humidity	5% to 95% (non-condensing). At temperatures above 34°C (93°F) relative humidity is limited to 53 mbar of water vapor pressure.

Electromagnetic interference

The radiated and conducted electromagnetic interference meets the requirements of Subpart J of Part 15 of the FCC rules for Class A computing devices.

Line engineering

The maximum permissible loop length is 3500 ft. (915 m), assuming 24 AWG (0.5 mm) standard twisted wire with no bridge taps. A 15.5 dB loss at 256 KHz defines the loop length limit (longer lengths are possible, depending on the wire's gauge and insulation).

The M2016S uses a 6 conductor line cord (A0346862).

Note: Use only the line cord provided with the telephone. Using a cord designed for other digital telephones could result in damage to the M2016S.

Local alerting tones

The M2016S telephone provides four alerting tones and a buzz sound. The system controls the ringing cadence by sending tone-ON and tone-OFF messages to the telephone. The alerting tone cadences cannot be changed from the telephone, but can be altered for individual telephones by software-controlled adjustments.

Alerting tone characteristics

The tone frequency combinations are:

Tone	Frequencies	Warble Rate (Hz)
1	667 Hz, 500 Hz	10.4
2	667 Hz, 500 Hz	2.6
3	333 Hz, 250 H	10.4
4	333 Hz, 250 Hz	2.6

A 500 Hz buzz signal is provided for incoming call notification while the receiver is off-hook.

Power requirements

Power Supply Board

The power supply option consists of a Power Supply Board which mounts inside the telephone, coupled with an external wall-mount transformer which provides power to the Power Supply Board. The Power Supply Board receives its power through pins 1 and 6 of the line cord.

The Power Supply Board connects to the telephone through a 14 pin bottom entry connector.

The Power Supply Board comes factory installed with any configuration of the M2016S.

Local plug-in transformer

A single winding transformer equipped with a 10 ft. (3 m) cord of 22 AWG two-conductor stranded and twisted wire with a modular RJ-11 duplex

adapter (refer to Figure 21 on [page 113](#)) can provide the additional power needed to operate the telephone and its options.



WARNING

Do not plug any equipment (computer, modem, LAN card) other than the M2016S into the RJ-11 transformer adapter, as damage to equipment may result.

120 V transformer (AO367335 or equivalent). The following minimum specifications must be met by this transformer:

Input voltage: 120 V AC / 60 Hz

No load output voltage: 29 V AC maximum

Voltage at rated current: 26.7 V AC minimum

Rated load current: 700 mA

240 V transformer (AO367914 or equivalent). The following minimum specifications have to be met by this transformer:

Input voltage: 240 V AC / 50 Hz


No load output voltage: 29 V AC maximum

Voltage at rated current: 26.7 V AC minimum

Rated load current: 700 mA

Note: You cannot wall mount the telephone over the wall jack when using a transformer, due to the size of the RJ-11 adapter. Hang it above or to the side of the jack and run the line and power cords to it.

Figure 21
Configuration of local plug-in transformer



Installation

Packing and unpacking

Use proper care when unpacking the M2016S. Check for damaged containers so that appropriate claims can be made to the transport company for items damaged in transit.

If a telephone must be returned to the factory, pack it in the appropriate container to avoid damage during transit. Remember to include all loose parts (cords, handset, power unit, labels, and lenses) in the shipment.

Installation and removal of M2016S Secure Set

Follow the steps in Procedure 24 on [page 114](#) to install the M2016S.

Procedure 24

Installing the M2016S telephone

- 1 Complete the wiring and cross-connections (loop power) before connecting the telephone to the TELADAPT connector. See Figure 22 on [page 115](#) and Figure 23 on [page 116](#).
- 2 Place the telephone upside down on a number of sheets of soft, clean paper on a solid, level work surface to prevent damage to movable keys and the telephone's face.
- 3 Connect the handset cord (5-conductor TELADAPT connectors) to the handset and snap it into place.
- 4 Connect the other end of the handset cord to the connector in the bottom cover of the telephone. Turn the smooth side of the handset cord up (away from the telephone bottom cover) before tucking it under the restraining tab to ensure that the telephone will sit level on the desk after installation is complete.
- 5 Connect the line cord to the telephone bottom cover. Route the cord through the channels.
- 6 Turn the telephone right-side up and place it in the normal operating position.
- 7 Print the directory number on the designation card. Using a paper clip, remove the number lens from the telephone. Insert the designation card and snap the lens back into place.
- 8 Designate the feature keys.
- 9 Insert the line cord TELADAPT connector into the connecting block (jack) and snap it into place.
- 10 Perform the self-test (see Procedure 25 on [page 116](#)) and acceptance test procedures. See LD 31 in the *Software Input/Output: Administration* (553-3001-311).

- 11 Supply the user with a Quick Reference Card and all user documentation. Make sure the SPRE number is printed on the Quick Reference Card.

————— End of Procedure —————

Figure 22
M2016S Secure Set connections





Figure 23
M2016S cross-connections.



The M2016S set has a self-testing capability. Follow the steps in Procedure 25 to perform the self-test after installing an M2016S set, or any of the hardware options, to ensure proper operation.

Procedure 25
M2016S self-test

- 1 Unplug the line cord from the telephone.
- 2 While holding down the RLS key, plug in the line cord to the telephone. Let go of the RLS key.

- 3 Follow the steps in Table 15 to perform the necessary steps and check results.

Table 15
M2016S telephone self-test steps and results (Part 1 of 2)

Step	Action	Result
1	Begin test (plug in line cord while holding down the RLS key). The handset is on hook.	Speaker beeps once, all LCDs flash. Message Waiting lamps light steadily. Display reads:LOCAL DIAGNOSTIC MODE PRESS RLS KEY TO EXIT
2	Press each Function key, from zero to fifteen (if there are Key Expansion Modules, continue pressing the Function keys, in any order).	Adjacent LCD goes off when a key is pressed.
3	Press the Hold key.	Speaker beeps.
4	Press each dial pad key.	Speaker beeps each time a key is pressed.
5a	Lift the handset (if applicable). Press the dial pad keys. Replace the handset.	Speaker beeps. Handset beeps.

Table 15
M2016S telephone self-test steps and results (Part 2 of 2)

Step	Action	Result
5b	Plug in the headset (if applicable). Press the dial pad keys. Unplug the headset.	Speaker beeps. Headset beeps.
6	Press the right side of the volume control key. Press the right side of the volume control key. Press the right side of volume control key. Press the right side of the volume control key. Press the right side of the volume control key. Press the right side of the volume control key. Press the right side of the volume control key.	Speaker beeps. Display is filled with dark squares. Speaker beeps. Display is blank. Speaker beeps. Display shows symbols including digits 0–9 and uppercase alphabet Speaker beeps. Display shows symbols including upper- and lowercase alphabet. Speaker beeps. Display shows various symbols. Speaker beeps. Display shows symbols. Speaker beeps. Display is filled with dark squares.
7	Press the RLS key (end of test).	Message Waiting lamp goes off. Display shows idle screen within 10 seconds.

————— **End of Procedure** —————

Designate the telephone

Before designating the M2016S telephone, check the work order for the features enabled and key designations. Designate each key by placing its feature name (from the designation sheet) in the key cap that fits on the key.

Follow the steps in Procedure 26 to designate the M2016S telephone.

Procedure 26

Designating the M2016S telephone

- 1 Remove the cap from each key requiring a designation.
- 2 Place the designation in the cap, place the cap over the corresponding key, and gently press down. Repeat for all keys requiring designations.
- 3 Insert a paper clip into the hole at the left or right end of the designation window.
- 4 Gently pry the window toward the center and remove, and insert the number tag.
- 5 Replace the designation window.

End of Procedure

Cross-connect the telephone

Be sure to connect the telephones as shown in Figure 24 on [page 121](#).

Follow the steps in Procedure 27 to cross-connect the telephones.

Procedure 27

Cross-connecting the telephones

- 1 Locate the telephone terminations at the cross-connect terminal.
Telephone terminations are located on the vertical side of the frame when frame-mounted blocks are used and in the blue field when wall-mounted blocks are used.
- 2 Connect Z-type cross-connecting wire to the leads of the telephone. See Table 16 on [page 120](#) and Table 17 on [page 121](#).
- 3 Locate the line circuit card (TN) terminations.

Line circuit card (TN) terminations are located on the horizontal side of the distributing frame when frame-mounted blocks are used and in the white field when wall-mounted blocks are used.

- 4 Run and connect the other end of the cross-connecting wire to the assigned TN terminal block.

End of Procedure


Table 16
Z-type cross-connecting wire

Size	Gauge	Color	Designation
1 pr	22	Y-BL	Tip
		BL-Y	Ring
3 pr	24	W-BL	Voice T
		BL-W	Voice R
		W-O	Signal T
		O-W	Signal R
		W-G	Power
		G-W	Power

Table 17
Inside wiring colors

Inside wiring colors		Connect to equipment TN
Z station wire	16/25-pair cable	
G	W-BL	First pair Tip
R	BL-W	First pair Ring
BK	W-O	Second pair Tip
Y	O-W	Second pair Ring

Figure 24
M2016S telephone cross-connections



M 3900 description

Contents

This section contains information on the following topics:

Introduction	124
Automatic Call Failover	126
Physical description.	127
M3901 Entry Telephone.	128
M3902 Basic Telephone.	129
M3903 Enhanced Telephone	130
M3904 Professional Telephone	133
M3905 Call Center Telephone	135
Features	137
Set-to-Set Messaging	137
Personal Directory	138
Corporate Directory	139
M3900 (single site) Virtual Office	139
Full Icon Support	140
Language selection during software installation	142
Feature keys	143
M3900 accessories and add-ons	147
Accessory Connection Module.	148
Analog Terminal Adapter.	150
Computer Telephony Integration Adapter	150
Telephone Application Programming Interface (TAPI) software . .	151
Personal Directory PC Utility Software	151
Accessory Modules	154

Meridian External Alerter and Recording Interface	153
Alternate key caps for the M3905	155
Handset option for the M3905 Call Center Telephone	155
Headset options	156
Telephone wall-mount kit	157
Full Duplex Handsfree	152
Brandline insert	157
Key descriptions	159
M3901 key descriptions	159
M3902 key descriptions	161
M3903 key descriptions	162
M3904 key descriptions	166
M3905 key descriptions	169

Introduction

The M3900 Series Digital Telephones consists of the following telephones:

- **M3901 Entry Telephone** — an entry-level telephone for occasional use
- **M3902 Basic Telephone** — for manufacturing floor, warehouse, and low telephone use
- **M3903 Enhanced Telephone** — an enhanced telephone for office professionals and technical specialists
- **M3904 Professional Telephone** — a professional telephone for Managers, Executives, Administrative Assistants
- **M3905 Call Center Telephone** — a call center telephone for Agents and Supervisors

The M3900 Series Digital Telephones, X11 Release 25 and later, supports the following features:

- Context-sensitive soft keys (M3903 and M3904)
- Set-to-Set Messaging (M3903 and M3904)
- Corporate Directory (M3903 and M3904)
- M3900 (single site) Virtual Office (M3903 and M3904)

- Display-Based Accessory Module (M3904)
- Flash download of firmware (M3902, M3903, M3904, and M3905)
- Language selection during software installation for M3900 Series Digital Telephones

The M3900 Series Digital Telephones, X11 Release 25.40 (Phase III) and later, supports the following features and enhancements:

- Full Duplex Handsfree (M3904 Phase III)
- System-initiated language selection (M3902, M3903, M3904, and M3905)
- Call Forward enhancements (M3903, M3904, and M3905)
- 31-digit dialing (M3902, M3903, M3904, and M3905)
- Callers List soft key (M3903, M3904, and M3905)
- Redial List soft key (M3903, M3904, and M3905)
- Pause in dialing string (M3902, M3903, M3904, and M3905)
- Special character support (M3902, M3903, M3904, and M3905)
- Headset state support (M3903, M3904, and M3905)
- Set-to-Set Messaging enhancements (M3903, M3904, and M3905)
- One-button feature access to Corporate Directory (M3903, M3904, and M3905)
- Corporate Directory search enhancement (M3903, M3904, and M3905)
- M3900 (single site) Virtual Office enhancements
- Virtual Office clearing of the Callers List and Redial List (M3903 and M3904)
- Automatic log out of Virtual Office
- Speed Call for Virtual Office
- System-initiated language download
- Personal Directory fixed feature key

M3900 Series Digital Telephones communicate with the CS 1000 and Meridian 1 through digital transmission over standard twisted-pair wiring. M3900 Series Digital Telephones can interface with all versions of the Intelligent Peripheral Equipment (IPE) Digital Line Card (DLC). The DLC supports 16 voice ports and 16 data ports. The system software assigns a TN to each port in the system.

For more information on features and telephone operations, refer to the following documents:

- *Meridian Digital Telephones: M3901, M3902, M3903, M3904 User Guide*
- *Meridian Digital Telephones: M3902, M3903, M3904 Quick Reference Guide*
- *Meridian Digital Telephone: M3905 Call Center User Guide*

Automatic Call Failover

The Active Call Failover (ACF) feature enables an M3900 Series Digital Telephone to reregister in the ACF mode during a supported system failure.

The ACF mode preserves the following:

- active media stream
- LED status of the Mute, Handsfree, and Headset keys
- DRAM content

Note: All other elements (feature keys, soft keys and text areas) are retained until the user presses a key or the connection with the Call Server is resumed. If the user presses a key during the failover, the display is cleared and a localized “Server Unreachable” message is displayed.

The M3900 Series Digital Telephone uses this new mode of reregistration only when the Call Server explicitly tells the telephone to do so. M3900 Series Digital Telephones clear all call information if they register to a Call Server or Line Terminal Proxy Server (LTPS) that does not support the ACF feature.

For more information on Active Call Failover, refer to *IP Line: Description, Installation, and Operation* (553-3001-365).

Physical description

These telephones are digital, integrated voice/data telephones with the physical features listed in Table 18.

Table 18
M3900 features (Part 1 of 2)

	M3901 entry level	M3902 basic	M3903 enhanced	M3904 professional	M3905 call center
lines supported	1	1	4	12	7
Program- mable feature keys	5	3	4	4	4
fixed fea- ture keys	no	Options/ Program, Message (with LED), Transfer (with LED)	Options/ Program, Message, Application, Shift, Call Log	Options/ Program, Message, Application, Shift, Direc- tory/Log	Supervisor, Emergency, Not Ready, Make Busy, In-calls
fixed keys for call processing	no	Hold, Good-bye, Smart Mute (with LED), Handsfree (with LED)	Hold, Good-bye, Smart Mute (with LED), Headset (with LED), Handsfree (with LED)		Hold, Good-bye, Smart Mute (with LED), Headset (with LED)
Supervisor Observe Key (with LED)	no	no	no	no	yes
fixed appli- cation keys	no	Up, Down, Left, Right	Up, Down, Left, Right, Quit, and Copy		

Table 18
M3900 features (Part 2 of 2)

	M3901 entry level	M3902 basic	M3903 enhanced	M3904 professional	M3905 call center
Display	no	(2 x 24): 1 Text Lines, 1 Label Line	(3 x 24): 1 Info Line, 1 Text Lines, 1 Label Line	(5 x 24): 1 Info Line, 3 Text Lines, 1 Label Line	(4 x 24): 1 Info Line, 2 Text Lines, 1 Label Line
Accessory Ports	no	1	2	2	2
Accessories	no	ATA, Com- puter Tele- phony Interface Adapter (CTIA), Meridian External Alerter & Recording Interface (MEARI)	ATA, CTIA, MEARI	ATA, CTIA, Display- Based Accessory (DBA), MEARI, Full Duplex Handsfree (FDHF), Key-Based Accessory (KBA), Per- sonal Direc- tory PC Utility	ATA, CTIA, DBA, MEARI, KBA, Per- sonal Direc- tory PC Utility
Headset	through MPA jack		Direct Connect		

Note 1: All telephones are desk- or wall-mountable, have message waiting LED with visual ringing, and have volume control.

Note 2: The KBA and DBA modules cannot be wall mounted.


M3901 Entry Telephone

The features of the M3901 include:

- one line Directory Number (DN) capability

- five programmable features
- fixed feature keys: Line, Feature, Hold, Goodbye, and Volume control
- feature activation and Message waiting/incoming call status indicator LED
- support for an amplified headset

Figure 25
M3901 Entry Telephone




M3902 Basic Telephone

The features of the M3902 include:

- one line Directory Number (DN) capability
- three programmable soft keys (soft-labeled)
- fixed feature keys: Options, Message, Transfer, Goodbye, Hold, “Smart” Mute, and Volume control
- two lines by twenty-four character display area
- Group Listening

- on-hook dialing
- support for an amplified headset
- one accessory port
- handsfree calling option with LED

Figure 26
M3902 Basic Telephone




M3903 Enhanced Telephone

The features of the M3903 include:

- two programmable line/feature keys (soft-labeled) which have two layers each, giving the user access to four line/feature keys
- four Context-sensitive soft keys (soft-labeled) that change functionality depending on the features available or the application in use
- Handsfree calling with LED

- fixed feature keys: Goodbye, Message, Call log (including Redial List), Applications, Shift, Goodbye, Hold, “Smart” Mute, and volume control
- Navigation cluster, Quit, and Copy
- three line by twenty-four character display area
- Call Log (includes Redial List)
- Group Listening
- on-hook dialing
- two accessory ports
- support for an amplified or unamplified headset
- Direct connect headset port
- Full icon support (with expansion module)

Figure 27
M3903 Enhanced Telephone




M3904 Professional Telephone

The features of the M3904 telephone include:

- six programmable line/feature keys (soft-labeled) which have two layers each, giving the user access to 12 line/feature keys
- four Context-sensitive soft keys (soft-labeled) that change functionality depending on the features available or the application in use
- Handsfree calling with LED
- fixed feature keys: Options, Message, Directory/Log (including Redial List), Applications, Shift, Goodbye, Hold, “Smart” Mute, Volume control
- Navigation cluster, Quit, and Copy
- five line by twenty-four character display
- Personal Directory
- Call Log (includes Redial List)
- Group Listening
- on-hook dialing
- two accessory ports (support for an amplified/unamplified headset)
- Direct connect headset port
- Full icon support (with expansion modules)

Figure 28
M3904 Professional Telephone




M3905 Call Center Telephone

The features of the M3905 Call Center Telephone include:

- seven programmable line/feature keys (soft-labeled), giving the user access to seven line/feature keys
- four Context-sensitive soft keys (soft-labeled) that change functionality depending on the features available or the application in use
- fixed feature keys with LED: Headset, Supervisor, Emergency, Not Ready, Make Busy, In-Calls, goodbye, Hold, “Smart” Mute, Volume control
- Navigation cluster, Quit and Copy
- four line by twenty-four character display
- an optional handset
- two accessory ports (supports amplified/unamplified headset)
- Supervisor Observe Key with LED
- Full icon support (with expansion modules)
- Supervisor Headset Observe port

Figure 29
M3905 Call Center Telephone



Note: The system administrator can configure four of the bottom six fixed feature keys (Make Busy, Not Ready, Supervisor and Emergency) to feature keys that suit the business needs of the Call Center user.

Features

The following section describes the following key features supported on M3900 Series Digital Telephones:

- Set-to-Set Messaging
- Personal Directory
- Corporate Directory
- Full Icon Support
- Language selection during software installation
- Feature keys

Set-to-Set Messaging

The Set-to-Set Messaging feature provides a visual message from one M3900 telephone to another M3900 telephone when a user makes a call to that telephone. The user on an M3903, M3904, or M3905 set enters the Set-to-Set Messaging text at the telephone. Set-to-Set Messaging is accessed through the Applications key.

The maximum length for Set-to-Set Messaging text is 24 characters (one line of the set display).

Table 19 shows examples of Set-to-Set Messaging text.

Table 19
Examples of message text (Part 1 of 2)

OUT TO LUNCH
BACK TO WORK: 4 Dec 02
BACK TO OFFICE: Jan 03
WILL REPLY AFTER 1 PM
BACK @ 4:00 PM
NOT IN TODAY

Table 19
Examples of message text (Part 2 of 2)

RETURN SOON -- 8:10 AM
GONE FOR THE DAY

The user may have only one Set-to-Set message on their telephone at a time. To activate Set-to-Set Messaging, the user must first define a message. If password protection is active for the M3900, it also applies to Set-to-Set Messaging.

If the Multiple Appearance Redirection Prime (MARP) feature is active, then MARP determines which DNs receive the Set-to-Set Message. If MARP is not active, then Multiple Appearance Directory Number (MADN) determines which DNs configured on the telephone receive the Set-to-Set Message.

To use Set-to-Set Messaging, the M3903, M3904, or M3905 telephone must have:

- Set-to-Set Messaging feature Class of Service enabled
- Set-to-Set Message text created
- Set-to-Set Messaging feature enabled

When Set-to-Set Messaging is active, the caller hears an audible tone and the Set-to-Set Message appears on their display. The caller then hears ringback and the call goes to voice messaging. If the called set is busy, a call waiting tone is heard by the called party.

Personal Directory

With M3900 Phase III, press the **Directory/Log** fixed feature key to access the Personal Directory on M3904 telephones. On M3905 telephones, press the **Directory** self-labeled programmable feature key. You do not have to press the **Select** key after pressing the **Directory/Log** or **DIR/LOG** key. Once you press the **Directory/Log** or **DIR/LOG** key, you can immediately begin a search using the dial pad keys, provided that Personal Directory was highlighted in the selection list.

Note: M3900 Phase III allows you to perform a three-letter search in the Personal Directory.

Corporate Directory

The M3903, M3904, and M3905 telephones provide access from the telephone to a corporate-wide directory. The Corporate Directory is accessed through the **Applications** Key. The Corporate Directory allows users to:

- search by name
- view additional information on each entry
- dial from the Corporate Directory
- copy and paste an entry into the Personal Directory (M3904)
- view an alphabetical listing of entries by last name (system generated)

Note: When names are copied to the Personal Directory (M3904), the names are listed by first name.

The system administrator can configure Optivity Telephony Manager (OTM) to download the directory database manually or automatically to the system.

Operating parameters

The user must have an M3903, M3904, or M3905 telephone to support the Corporate Directory feature. To access the Corporate Directory from the telephone, the user must have the Corporate Directory Class of Service enabled.

When the Corporate Directory is being updated with new data, the user cannot access the Corporate Directory. The user exits the Corporate Directory by pressing the **Quit** key or the **Applications** key.

The OTM utility gathers data from OTM databases and downloads it to the system. To use Corporate Directory, OTM must be installed.

M3900 (single site) Virtual Office

The Virtual Office feature allows users to log in to a designated M3903 or M3904 Digital Telephone and use their individual telephone configurations

at that telephone. The calls to the user's primary DN are routed to the Virtual Office Host Terminal where the Virtual Office worker is logged in.

For further information on Virtual Office, refer to "M3900 (single site) Virtual Office" on [page 173](#).

Full Icon Support

The M3900 Full Icon Support feature enables distinct icons and flashing cadences for the display of different call states. These icons are displayed for the Directory Number (DN) keys on the Phase II and Phase III M3903 and M3904 telephones, as well as the Phase III M3905 telephones.

The M3900 Full Icon Support feature requires a minimum of Release 9 of the Key-Based Accessory module (KBA).

The icons also display on the Key-Based Accessory module and the Display-Based Accessory module. This feature allows the user to quickly determine the call state of a DN, instead of viewing just the flashing cadence of a single generic icon to determine the call state.

The functions displayed with the Full Icon Support feature are: I-Ringing, I-Active, U-Active, I-Hold, and U-Hold. The icons appear on the LCD displays located next to the DN keys. The scenarios for these icons are as follows:

- **I-Ringing:** The I-Ringing icon is displayed on the ringing DN of a set that is being called.
- **I-Active:** The I-Active icon is displayed on DNs on telephones in the active call state.
- **U-Active:** The U-Active icon appears on the MADN of a set when another set on the MADN is in the active call state.
- **I-Hold:** The I-Hold icon appears on the DN of the set that has a call on hold.
- **U-Hold:** The U-Hold icon appears on the MADN of a set when another set on the MADN has a call in the hold state.







The Ringing, I-Hold, U-Hold, and Active DN keys, represented by a generic icon  in previous releases, displays the following icons with the Full Icon Support feature:

Table 20
Icons and Cadences

Call/Feature state	DN key icon	Cadence
Ringing		Flash
I-Hold		Wink
U-Hold		Flicker
I-Active		On
U-Active		On

Feature interactions

There are no feature interactions associated with this feature.

Feature packaging

The M3900 Full Icon Support feature requires the following packages:

- M3900 Full Icon Support (ICON_PACKAGE) package 397
- Digital Sets (DSET) package 88

Feature implementation

Use LD 17 to enable M3900 Full Icon Support:

LD 17 - Enable M3900 Full Icon Support (Part 1 of 2)

Prompt	Response	Description
REQ	CHG	Change existing data
TYPE	PARM	System Parameters

LD 17 - Enable M3900 Full Icon Support (Part 2 of 2)

Prompt	Response	Description
..... ICON	(NO) YES	Enable the M3900 Full Icon Support feature NO = Disable the M3900 Full Icon Support feature

Feature operation

No specific operating procedures are required to use this feature.

Language selection during software installation

The system software installer selects one of seven language sets to be installed on the system. This selection determines the languages available to M3900 Series telephone users. The language sets are as follows:

- 1 **Global 10 Languages** — English, French, German, Spanish, Swedish, Italian, Norwegian, Brazilian Portuguese, Finnish, Japanese Katakana
- 2 **Western Europe 10 Languages** — English, French, German, Spanish, Swedish, Norwegian, Danish, Finnish, Italian, Brazilian Portuguese
- 3 **Eastern Europe 10 Languages** — English, French, German, Dutch, Polish, Czech, Hungarian, Russian, Latvian, Turkish
- 4 **North America 6 Languages** — English, French, German, Spanish, Brazilian Portuguese, Japanese Katakana
- 5 Spare Group A
- 6 Spare Group B (duplicate of set 4)
- 7 Packaged Languages

During the software installation process, the installer selects one of the above seven Peripheral Software DownLoad (PSDL) files. Refer to the following documents for more information on software installation:

- *Communication Server 1000M and Meridian 1: Small System Installation and Configuration (553-3011-210)*

- *Communication Server 1000M and Meridian 1: Large System Installation and Configuration (553-3021-210)*
- *Communication Server 1000S: Installation and Configuration (553-3031-210)*
- *Communication Server 1000E: Installation and Configuration (553-3041-210)*

Feature keys

The fixed feature keys (see Table 21) are the feature keys on the M3900 Series Digital Telephone that are pre-labeled with the assigned feature. The fixed feature keys appear on the telephone with text or icon labels. Telephones with icon labels are only available in specific market regions.

Table 21
Fixed Feature Key text and icon labels (Part 1 of 4)












Feature	Text Key Label	Icon Key Label
Goodbye		
Hold		
		or 
Mute		
Handsfree		
Volume		

Table 21
Fixed Feature Key text and icon labels (Part 2 of 4)

























Feature	Text Key Label	Icon Key Label
Headset		
Options		
DN line		
Feature (M3901)		
Message		
Directory/Log (M3904)		
Call Log (M3903)		
Shift		
Application		
Navigation		
Copy		
Quit		

Table 21
Fixed Feature Key text and icon labels (Part 3 of 4)























Feature	Text Key Label	Icon Key Label
Transfer (M3902)		
InCalls (M3905 Call Center)		
Not Ready (M3905 Call Center)		
Make Busy (M3905 Call Center)		
Call Supervisor (M3905 Call Center)		
Answer Agent (M3905 Call Center)		
Activity Code (M3905 Call Center)		
Answer Emergency (M3905 Call Center)		
Emergency (M3905 Call Center)		

Table 21
Fixed Feature Key text and icon labels (Part 4 of 4)

Feature	Text Key Label	Icon Key Label
Observe Agent (M3905 Call Center)		
Display Queue (M3905 Call Center)		

Note: Icon key labels are available in specific markets areas.

Programmable line/feature keys (soft-labeled)

The programmable line/feature keys (soft-labeled) are the keys located at the left and right sides of the upper section of the display area. Soft-labeled keys are keys that are labeled on the telephone’s LCD display.

The user-defined programmable line/feature keys of the M3900 Series Digital Telephones deliver the ability for a user to change the LCD labels of their set keys (with the exception of the primary Directory Number key) to meet their business needs. The M3900 soft-labeling is similar to the previous digital telephones, which required paper labels to be created and inserted under clear key caps. By design, this information is stored in the set itself. A user-defined soft label is fully controlled by the set user and will not change if the key programming is changed. It does not depend on the actual programming of the key, which is defined by the system software.

The programmable line/feature key (soft-labeled) provides two layers of functionality on the M3903 and M3904. Pressing the Shift key allows access to the second layer. The two layer keys on the M3903 and M3904 provide the user access to two lines/features per key. For example, the M3904 has six programmable line/feature keys (soft-labeled), which provide the user with 12 line/feature keys accessible on the six keys.

Soft Keys (soft-labeled)

The soft keys (soft-labeled) are the three (M3902) or four (M3903, M3904, and M3905) keys located below the display on the M3900 Series Digital

Telephones. The labels and corresponding functionality of these keys change depending on the features available or the application in use.

Programmable Features

For feature key assignment information, refer to:

- Table 24 on [page 159](#)
- Table 25 on [page 161](#)
- Table 26 on [page 162](#)
- Table 27 on [page 166](#)
- Table 28 on [page 169](#)

M3900 accessories and add-ons

Table 22 lists the accessories and optional hardware available for each M3900 Series Digital Telephone.

Table 22
M3900 series telephone accessories compatibility (Part 1 of 2)

Accessory	X11 release introduced	M3900 phase introduced	M3902	M3903	M3904	M3905
Accessory Connection Module (ACM)			Supports	Supports	Supports	Supports
Analog Terminal Adapter (ATA) ¹	Release 24.24	Phase I	Supports	Supports	Supports	Supports
Computer Telephony Integration Adapter (CTIA)	Release 25.40	Phase III	Supports	Supports	Supports	Supports ²
Display-Based Accessory Module (DBA)	Release 25.10	Phase II	NA	NA	Supports	Supports ²

Table 22
M3900 series telephone accessories compatibility (Part 2 of 2)

Accessory	X11 release introduced	M3900 phase introduced	M3902	M3903	M3904	M3905
Key-Based Accessory Module (KBA)	Release 24.24	Phase I	NA	NA	Supports	Supports
Meridian External Alerter and Recording Interface (MEARI)	Release 24.24	Phase I	Supports	Supports	Supports	Supports
Full Duplex Handsfree (FDHF)	Release 25.40	Phase III	NA	NA	Supports ³	NA
Personal Directory PC Utility	Release 24.24	Phase I	NA	NA	Supports	Supports ²
Headset (non-amplified) connects through the direct connect headset jack			NA	Supports	Supports	Supports
Headset (amplified) connects through the headset jack			Supports	Supports	Supports	Supports

1. In the EMEA market region, the ATA is not supported on the M3902, M3903, or M3905.
2. M3905 Phase III firmware is required to support the Personal Directory PC Utility, DBA, and CTIA accessories.
3. M3904 Phase III firmware and hardware are required to support Full-Duplex Handsfree accessory.

Accessory Connection Module

The Accessory Connection Module (ACM) provides the interface for adding the Analog Terminal Adapter (ATA), Meridian External Alerter and Recording Interface (MEARI), Computer Telephony Interface Adapter (CTIA), Personal Directory PC Utility, and Full Duplex Handsfree (FDHF). The ACM is available for the M3902, M3903, M3904 and the M3905. It also

acts as a footstand for the telephone. The ACM and its accessory cartridges cannot be used in wall-mount applications.

The ACM requires one of the following wall transformers to power any of the accessory cartridges:

- 110 V wall transformer (NTMN80AA)
- EU (EMEA) 230 V wall transformer (NTHC09AA)
- UK 230 V wall transformer (NTHC08AA)

You must order the wall transformer separately from your Nortel distributor to power the ACM and/or the M3900 accessories.

Table 23 shows the compatibilities of M3900 Series Digital Telephone accessories.

Table 23
Accessory compatibilities

	ATA	CTIA	Personal Directory PC Utility	FDHF	MEARI	KBA	DBA
ATA	N/A	YES	YES	NO	YES	YES	YES
CTIA	YES	N/A	YES ¹	N/A	NO	YES	YES
PC Utility	YES	YES ¹	N/A	YES	YES	YES	YES
FDHF	NO	YES	YES	N/A	YES ²	N/A	N/A
MEARI	YES	YES	YES	YES ²	N/A	YES	YES
KBA	YES	YES	YES	YES	YES	N/A	NO
DBA	YES	YES	YES	YES	YES	NO	N/A
Note: Not all of the above accessories are supported on all telephones in the M3900 Series portfolio. Refer to Table 22 on page 147.							


1. If either the CTIA or the PC Utility cartridge is installed, no additional cartridge is required. The applicable software may be purchased separately.

2. The Meridian External Alerter and Recording Interface can only be used for external alerting when used with the Full Duplex Handsfree. Call Recording is not supported.

Accessory keying

A maximum of two cartridge accessories can plug into the slots at the rear of the ACM stand. The ports provide access to a SIDL/SDI port, USART port, and GPIO0. Two accessories cannot access the same serial port. The mechanical keying prevents this situation from occurring. Refer to Figure 30 for a better understanding of mechanical keying.

Figure 30
M3900 Series mechanical keying



Analog Terminal Adapter

The Analog Terminal Adapter (ATA) lets you connect an analog device such as a fax machine or modem to your telephone. You can have simultaneous use of the telephone and the analog device. The ATA is available for the M3902, M3903, M3904 and the M3905 models. In the EMEA market region, the ATA is supported only on the M3904.

Computer Telephony Integration Adapter

The Computer Telephony Integration Adapter (CTIA), along with the desktop TAPI Service Provider software, provides an interface to connect a PC to the M3900 Series Digital Telephone. This enables PC applications to monitor or control the M3900 telephone for first-party (individual) call control type applications. The CTIA integrates the PC and the telephone,

allowing more effective management of calls using PC applications such as Microsoft Outlook™.

An RS-232C cable is required to connect the PC to the CTIA. The CTIA connects to the M3900 Series Digital Telephone through the Accessory Connection Module (ACM). The CTIA is a small cartridge accessory and can be inserted into either the small or large footstand opening.

The CTIA is powered through the ACM. The ACM receives power through the telephone through the telephone line cord which is connected to a Teladapt wall transformer power supply (see Figure 37 on [page 194](#)). Check with your Nortel distributor for the recommended wall transformer for the M3900 accessories. Install the Accessory Connection Module (ACM) into your M3900 Series Digital Telephone (refer to the ACM Installation Sheet) before you install your CTIA.

The CTIA cartridge provides the user:

- connectivity to the PC
- voice call control, using the TAPI SP software included with the CTIA

Telephone Application Programming Interface (TAPI) software

The Desktop TAPI Service Provider software accompanies your CTIA Cartridge. The Desktop TAPI Service Provider software interprets the information sent to the telephone and passes it on to a TAPI application. TAPI-compliant applications usually support activities such as placing, answering, holding transferring, and conferencing calls. This can include the information presented to the set display.

Personal Directory PC Utility Software

In addition to the TAPI software which is included with the CTIA, you may wish to purchase the Personal Directory PC Utility Software. The Personal Directory PC Utility software uses your CTIA Cartridge to connect your PC and M3904 telephone so that you may exchange data between your PC and your telephone's directory.

The Personal Directory PC Utility software provides a faster, easier way to create or modify a Personal Directory on the M3904 and M3905 telephones.

You can enter names and numbers into a Personal Directory file on your Personal Computer (PC). You can download (program) the PC file directly to the M3904 and M3905 telephones. You can upload (read) a directory from the M3904 and M3905 telephones to your PC to modify the directory.

An RS-232C cable is required to connect the PC to the Personal Directory PC Utility Interface Cartridge. The cartridge connects to the M3900 Series Digital Telephone through the Accessory Connection Module (ACM). The Personal Directory PC Utility Interface Cartridge is a small cartridge accessory and can be inserted into either the small or large footstand opening.

The Personal Directory PC Utility Interface Cartridge is powered through the ACM. The ACM receives power through the telephone via the telephone line cord which is connected to a Teladapt wall transformer power supply (see Figure 37 on [page 194](#)). Check with your Nortel distributor for the recommended wall transformer for the M3900 accessories. You must install the Accessory Connection Module (ACM) into your M3900 Series Digital Telephone (refer to the ACM Installation Sheet) before you install your Personal Directory PC Utility Interface Cartridge.

Note: The CTIA Cartridge and the Personal Directory PC Utility Interface Cartridge are identical. If both products are to be used, only one cartridge is required.

The Personal Directory PC Utility supports the following languages: English, French, Spanish, German, Danish, Portuguese, Italian, Norwegian, Swedish, Finnish, Dutch. The default language is English.

Full Duplex Handsfree

The Full Duplex Handsfree (FDHF) functionality allows simultaneous two-way communication during a handsfree call. Regular handsfree operation is half-duplex. Only one party can be heard at a time. FDHF allows a speaker to be aware when another party on the call is also speaking.

Note: To ensure optimal functionality, the receive audio level is attenuated during the FDHF mode when both parties are speaking. As a result, fluctuations in the receive volume can occur during FDHF calls. If this occurs, do not increase the set speaker volume, as this may cause the set to revert to half-duplex operation.

For Full Duplex Handsfree functionality, you require an M3904 Phase III set equipped with an FDHF cartridge.

Note: Phase III hardware is required since design modifications were made to the M3900 Series Digital Telephones to accommodate the FDHF functionality.

The FDHF functionality requires the following hardware (minimum vintages listed):

- M3904 Phase III set (NTMN34GA)
Note: NTMN34TA is the M3904 Phase III Icon set.
- Full Duplex Handsfree cartridge (NTMN72xx)
- Accessory Connection Module (ACM) (NTMN71xx)
- One of the following wall transformers to power the FDHF cartridge:
 - 110 V wall transfer (NTMN80AA)
 - EU (EMEA) 230 V wall transformer (NTHC09AA)
 - UK 230 V wall transformer (NTHC08AA)

Meridian External Alerter and Recording Interface

The Meridian External Alerter and Recording Interface (MEARI) provides an interface for a remote ringer device installed in a location separate from your M3902, M3903, M3904, or M3905 telephone. The MEARI provides access to a standard, off-the-shelf remote ringer, call status relay, audio recorder or visual indicator.

You can program the MEARI to activate a ringer (or light) when the telephone rings or when the telephone is in use (off hook). A call to any DN configured on the telephone triggers the alerter. The MEARI alerts to one active call at a time. If the telephone is already active on a call, a second call will not activate MEARI.

If used on the M3904 in conjunction with the Full Duplex Handsfree accessory, the MEARI can be used only for external alerting, not recording.

Note: The MEARI is an interface only. The ringer, light, buzzer, or other alerting device is to be obtained through a third-party vendor of the customer's choice.

Accessory Modules

The Display-Based and Key-Based Accessory Modules are mutually exclusive. A set with one or two KBAs configured or installed cannot have a DBA.

Both the KBA and DBA modules are loop-powered and do not require the 110V wall transformer. Neither the KBA nor the DBA modules is supported for wall-mount applications.

Key-Based Accessory Module

The Key-Based Accessory Module (KBA) attaches to the M3904 and M3905 Digital Telephones. The KBA provides 22 additional line/feature keys. These keys are equipped with clear key caps and paper labels. You can attach a maximum of two KBAs to the M3904 and M3905.

The KBA requires an additional footstand kit to secure the module(s) to the set. If using one KBA, Kit 1 must be ordered. If installing two KBAs on the same set, Kit 1 and Kit 2 must be used. If a second KBA is being installed on a set with an existing KBA and stand, only Kit 2 is required.

Display-Based Accessory Module

The Display-Based Accessory Module (DBA) provides additional line/programmable feature keys (soft-labeled) for the M3904 and M3905 telephones. The DBA supports up to 3 layers of 8 additional keys for a total of 24 keys.

Note: Refer to Table 22 on page 147 for a list of the telephones with which the DBA module is compatible.

A Page fixed key located on the DBA allows a user to switch between the three layers of soft-labeled programmable feature keys. Visual indication is also provided to indicate which page (or layer) of soft-labeled programmable feature keys is in use. Feature activation and deactivation on the DBA keys is the same as the programmable feature keys on the M3904 and M3905.

Note: If an incoming call is posted to a DN key located on page 2 or 3 of the DBA, the unit does not automatically scroll to that page. This prevents the disruption of other user operations already in progress.

The user may change the feature key labels by selecting “Change feature key label” from the Options list on the M3904 or M3905.

The DBA is supported only on the M3904 and M3905. You can attach a maximum of one DBA to an M3904 or M3905 telephone.

The DBA comes with its own attachment arm and plug to secure the accessory module to the set.

Alternate key caps for the M3905

The M3905 Call Center Telephone provides an alternate key cap kit to customize your M3905 telephone to fit your business needs. Use the key cap tool to remove any of the middle four fixed programmable keys, located at bottom front of the M3905, and replace them with alternate keys. The alternate key caps include: Answer Emergency, Answer Agent, Activity Code, Call Agent, Observe Agent, and Display Queue.

Handset option for the M3905 Call Center Telephone

The M3905 Call Centre Telephone is designed to have a headset always present. The M3905 does not come equipped with a headset. The optional Handset Kit (NTMN18AA) is a hardware package that can be added to the M3905 and includes a headset, handset cord, and an add-on handset cradle. To install the handset cradle, uncover the hookswitch by removing the plate at the top front of the telephone, and snap the handset cradle in over this area.

A headset, handset, or both must be plugged into the M3905 when ACD queue login is required. Login to an ACD queue is not a supported operation when neither a headset nor a handset is plugged into the M3905. If neither a headset nor a handset are present, and the hookswitch is uncovered, it may still be possible to login to the ACD queue. This could result in calls being presented to the M3905 without being answered. Therefore, care must be taken to ensure a headset or handset is plugged in before queue login is attempted. As of CS 1000 Release 4.5, if the hookswitch remains covered, or

if the handset is properly cradled on the hookswitch, login cannot occur even if a headset is not plugged in.

The handset can be used without the headset plugged in. However, some functionality, including the ability to login to the ACD queue, can vary with the version of firmware installed on the M3905 and the release of software running on the system. Refer to “M3900 Flash Download” on [page 227](#) for details on how to determine the firmware version installed on an M3900 Series Digital Telephone.

Earlier software releases and previous versions of M3900 firmware deliver different operations. Phase I and Phase II M3905 telephones report a headset present even if one is not. This allows a handset to be used without a headset plugged in. The handset can plug into the handset port and ACD queue login proceeds normally. Login can occur even if neither a handset or headset is present.

Phase III telephones correctly recognize the presence or absence of a headset. If a headset is present on a Phase III M3905, then a handset can also be used. If a headset is not present, a handset must to be plugged into the handset port to allow normal ACD queue login. However, when the handset is in the handset port, the system does not accept signals from the telephone's hookswitch. Hanging up the handset (going ONHOOK) does not disconnect calls. The Goodbye key must be used to release a call.

As of Succession 3.0 and later software, when the M3905 is in use, the system software checks the headset port to verify that a headset, or some other device, is plugged in. If no device is present and the HEADSET button is off, the system assumes a headset is being used in the handset port of the set. The system is then prepared to respond to signals from the M3905 telephone's hookswitch, even though a headset is not present. M3905 firmware version 8.9 or later is required to send these hookswitch signals to the system. This allows the set to login to the ACD queue when the handset is taken OFFHOOK, and calls to be disconnected when the handset is hung up (placed ONHOOK).

Headset options

The M3901, M3902, and M3904 supports an amplified headset when the headset connects to the handset jack.

On a M3905, plug the amplified headset into the headset port. Do not plug an amplified headset into the handset jack.

The M3903, M3904 and M3905 have a dedicated headset jack which supports a non-amplified headset. The M3903, M3904 and M3905 have a Headset fixed feature key to turn the Headset on and off.

Contact your Nortel distributor for qualified headset equipment.

Headset considerations

Test the headset with the telephone before using. In a noisy environment, an amplified headset is an option. When the amplified headset is used, two choices of volume control are available: the rocker control on the telephone and the switch on the headset. The user should adjust the telephone volume before adjusting the headset volume. To provide the best communication with the least amount of distortion, the amplifier should have a higher setting than the telephone volume control.

Telephone wall-mount kit

For the M3903, M3904, and M3905 telephones, a separate wall-mount bracket kit must be used. This kit contains a one-piece wall-mount plate that attaches the telephone to the wall. The wall-mount kit is available from your local Nortel distributor.

The footstand supplied with the M3901 and M3902 telephones can be reversed to allow wall mount installations. To provide additional support, an optional wall-mount brace kit may be purchased.

The wall-mount kit does not support the Accessory Connection Module (ACM) and its accessory cartridges.

Brandline insert

The M3900 Series Digital Telephones contain a removable insert made to accommodate your company logo. You can order blank Brandline Inserts with your company logo.

The M3903, M3904, and M3905 also support Electronic Brandline. Refer to *Features and Services* (553-3001-306) for information on the Electronic Brandline feature.

Key descriptions

This section provides key description and key configuration information for each model of the M3900 series. This section also shows the physical placement of the keys on each model: M3901, M3902, M3903, M3904, and M3905.


M3901 key descriptions

Table 24 gives a description of the keys on the M3901. Figure 31 on [page 160](#) shows the physical placement of the keys on the M3901.

Table 24
M3901 key description

Key Number	Description
Key 0	Line (Directory Number) Note: The system administrator can configure Key 0 as a Voice Call (VCC), HotLine (HOT) Key, Single Call Non-ringing (SCN), Multiple Call Ringing (MCR), Multiple Call Non-ringing (MCN), Private Line Ringing (PLR), or Private Line Non-ringing (PLN).
Key 1	Feature or Auto Dial
Key 2	Feature or Auto Dial
Key 3	Feature or Auto Dial
Key 4	Feature or Auto Dial
Key 5	Feature or Auto Dial
Note: The system administrator can configure Keys 1 - 5 with any feature that does not require a display (DAG, DWG, DSP, and RMK).	
Note: Nortel recommends that the M3901 is not configured as an ACD DN.	

Figure 31
M3901 key positions




M3902 key descriptions

Table 25 gives a description of the keys on the M3902. Figure 32 on [page 162](#) shows the physical placement of the keys on the M3902.

Table 25
M3902 key description

Key	Description
Key 0	You must configure Key 0 as the Directory Number line. Note: The system administrator can configure Key 0 as a Voice Call (VCC), HotLine (HOT) Key, Single Call Non-ringing (SCN), Multiple Call Ringing (MCR), Multiple Call Non-ringing (MCN), Private Line Ringing (PLR), or Private Line Non-ringing (PLN).
Key 1	Feature or Auto Dial
Key 2	Feature or Auto Dial
Key 3	Feature or Auto Dial
Key 4	Call Transfer (default) or 3 Party Conference or 6 Party Conference
Key 5	Message Waiting
<p>Note: The M3902 is a single-line set. Only one line can be configured, and this must be on Key 0. Do not configure Keys 1–5 as:</p> <ul style="list-style-type: none"> • Multiple Call Non-ringing • Multiple Call Ringing • Private Line Non-ringing • Private Line Ringing • Single Call Non-ringing • Single Call Ringing <p>Configuring Keys 1–5 as anything other than the allowed features will cause an error message.</p>	

Figure 32
M3902 key positions



M3903 key descriptions

Table 26 gives a description of the keys on the M3903. Figure 33 shows the physical placement of the keys on the M3903.

Table 26
M3903 key description (Part 1 of 3)

Key	Description
Key 0	Primary Directory Number
Key 1	Secondary Directory Number or Feature or Auto Dial
Key 2	Secondary Directory Number or Feature or Auto Dial


Table 26
M3903 key description (Part 2 of 3)

Key	Description
Key 3	<p>Secondary Directory Number or Feature or Auto Dial</p> <p>Note 1: Keys 1-3 cannot be configured as the following features:</p> <ul style="list-style-type: none"> • 3 Party Conference • 6 Party Conference • Call Forward • Account Charge • Calling Party Number • Call Park • Privacy Release • Ring Again • RPN • Call Transfer <p>Configuring Keys 1-3 as anything other than the allowed features will cause an error message.</p> <p>Note 2: Keys 1-3 can be configured as Speed Call (Speed Call, System Speed Call, Speed Call Controller and System Speed Call Controller). Nortel recommends that Key 23 be used for Speed Call features.</p>
Key 4-15	Not used at this time
Key 16	Message Waiting (default)
Key 17	Call Transfer (default)
Key 18	6 Party Conference (default) or 3 Party Conference
Key 19	Call Forward (default)
Key 20	Ring Again (default)
Key 21	Call Park (default)

Table 26
M3903 key description (Part 3 of 3)

Key	Description
Key 22	Ringing Number Pickup
Key 23	Configure as: <ul style="list-style-type: none">• Speed Call• System Speed Call• Speed Call Controller• System Speed Call Controller (manual configuration—needs speed call list #)
Key 24	Privacy Release (default)
Key 25	Charge Account (default)
Key 26	Calling Party number (default)
Key 27	Callers List (default)
Key 28	Redial List (default)
Keys 29-31	NUL

Figure 33
M3903 key positions



M3904 key descriptions

Table 27 gives a description of the keys on the M3904. Figure 34 on [page 168](#) shows the physical placement of the keys on the M3904.


Table 27
M3904 key description (Part 1 of 2)

Key	Description
Key 0	Primary Directory Number
Key 1-11	<p>Secondary Directory Number or Feature or Auto Dial</p> <p>Note 1: Keys 1-11 cannot be configured as the following features:</p> <ul style="list-style-type: none"> • Message Waiting • Transfer • 3 Party Conference • 6 Party Conference • Call Forward • Ring Again • Call Park • Ringing Number Pickup • Privacy Release • Charge Account • Call Party Number <p>Configuring Keys 1-11 as anything other than the allowed features will cause an error message.</p> <p>Note 2: Keys 1-11 can be configured as Speed Call (Speed Call, System Speed Call, Speed Call Controller and System Speed Call Controller). Nortel recommends that Key 23 be used for Speed Call features.</p>
Keys 12-15	Blocked
Key 16	Message Waiting is not a default feature for this key

Table 27
M3904 key description (Part 2 of 2)

Key	Description
Key 17	Call Transfer (default)
Key 18	6 Party Conference (default) or 3 Party Conference
Key 19	Call Forward (default)
Key 20	Ring Again (default)
Key 21	Call Park (default)
Key 22	Ringing Number Pickup (default)
Key 23	<p>Configure as one of the following:</p> <ul style="list-style-type: none"> • Speed Call • System Speed Call • Speed Call Controller • System Speed Call Controller <p>Note: The above services are not a default feature for this key. These features can be used on any of the programmable keys.</p>
Key 24	Privacy Release (default)
Key 25	Charge Account (default)
Key 26	Calling Party Number (default)
Key 27	Callers List (default)
Key 28	Redial List (default)
Keys 29-31	NUL

Figure 34
M3904 key positions



Note: For M3904 and M3905 telephones, One-button feature access keys for the Callers and Redial lists cannot be programmed on DBA or KBA modules.

M3905 key descriptions

Table 28 gives a description of the keys on the M3905. Figure 35 on [page 172](#) shows the physical placement of the keys on the M3905.

Table 28
M3905 key description (Part 1 of 3)

Key	Description
Key 0	<p>Primary ACD Directory Number equivalent to the * In-Calls Key</p> <p>Note 1: The user can edit the label on Key 0 to display desired information.</p> <p>Note 2: The In-Calls fixed key and the Primary DN line key are linked together and both represent Key 0.</p>
Key 1-4	<p>Secondary Directory Number or Feature or Auto Dial</p> <p>Note 1: Keys 1-4 cannot be configured as the following features:</p> <ul style="list-style-type: none"> • Message Waiting • Transfer • 3 Party Conference • 6 Party Conference • Call Forward • Ring Again • Call Park • Ringing Number Pickup • Privacy Release • Charge Account • Call Party Number <p>Configuring Keys 1-4 as anything other than the allowed features will cause an error message.</p> <p>Note 2: Keys 1-4 can be configured as Speed Call (Speed Call, System Speed Call, Speed Call Controller and System Speed Call Controller). Nortel recommends that Key 23 be used for Speed Call features.</p>


Table 28
M3905 key description (Part 2 of 3)

Key	Description
Key 5	Feature
Key 6	Feature
Key 7	Options menu key
Key 8-11	<p>Configured as one of the following standard Call Center features:</p> <p>Key 8 = * Make Set Busy</p> <p>Key 9 = * Not Ready (must have CLS = AGN)</p> <p>Key 10 = * Emergency (must have CLS = AGN)</p> <p>Key 11 = * Call Supervisor (must have CLS = AGN)</p> <p>The following features can be configured on any Key 8-11 with the change of the prelabeled key cap:</p> <p>Activity Code entry.Agent Answer Answer Emergency Call Display Queue = DWC (used with supervisor or agent telephones). Observe agent Ring Agent (must have CLS = SPV)</p> <p>Note: Keys 8-11 are prelabeled in the factory; they are marked in this table with an asterisk.</p>
Key 16	Message waiting key or another feature
Key 17	Call Transfer key (default)
Key 18	6 Party Conference (default) or A03 (3 Party Conference)
Key 19	Call Forward (default)
Key 20	Ring Again (default)
Key 21	Call Park (default)
Key 22	Ringing Number Pickup (default)

Table 28
M3905 key description (Part 3 of 3)

Key	Description
Key 23	Configured as one of the following speed call services: <ul style="list-style-type: none">• Speed Call• System Speed Call• Speed Call Controller• System Speed Call Controller
Key 24	Privacy Release (default)
Key 25	Charge Account (default)
Key 26	Calling Party Number (default)
Key 27	Callers List (default)
Key 28	Redial List (default)
Keys 29-31	NUL

Figure 35
M3905 key positions



M3900 (single site) Virtual Office

Contents

Introduction	173
Description	173
Operating parameters	176
Feature implementation	177

Introduction

The Virtual Office feature is useful for telecommuters, visitors, and workers who are frequently out of the office. Virtual Office maximizes the use of office space and desktop equipment for Hoteling or Hot-desk applications. The Virtual Office feature provides the capability for the telephone user to login to a designated telephone and be presented with their individual features and services. For example, office space could be set up with host telephones allowing visiting telecommuters to login using the Flexible Feature Code (FFC) and their individual DN. Calls to the user's primary DN are then routed to the Virtual Office host telephone where the Virtual Office worker is logged in.

Description

The Virtual Office feature allows users to log in to a designated M3903 or M3904 Digital Telephone and use their individual telephone configurations at that telephone. The calls to the user's primary DN are routed to the Virtual Office Host Terminal where the Virtual Office worker is logged in.

The Host Terminal is the physical telephone that a user can use to log in as a Virtual Office worker. Both the M3903 and the M3904 can be configured as Host Terminals; however, a Virtual Office worker is required to log in to a Host Terminal that matches their Virtual Office telephone type. For example, when the Virtual Terminal of a Virtual Office worker is configured as an M3904, the login process is blocked if they attempt to login to an M3903 Host Terminal.

The Virtual Terminal is a set of features configured for a user and defined on a phantom loop. There is no permanent physical telephone associated with a Virtual Terminal.

The Virtual Office recognizes all system configuration related to the Virtual Office Worker. The Virtual Office feature operates on a stand-alone Meridian 1 and a CS 1000 system only.

Only one active session per user login ID is allowed at one time in the system. The Virtual Office Worker is identified by their primary DN, which cannot be used as the primary DN for any other telephone, virtual or physical, in the system. Use the Station Control Password (SCPW), configured in LD 11 to validate the login. For further information on configuring the SCPW in LD 11, refer to *Software Input/Output: Administration* (553-3001-311).

Nortel recommends that the Host Terminal have at least internal call and emergency call (911 in North America) capability.

Clearing the Directory Services Password

With Phase III M3900 Series Digital Telephones, the Meridian 1 or CS 1000 system clears the Directory Services password when a Virtual Office worker logs in or logs out of an M3903 or an M3904 Host telephone. The system administrator configures this functionality by defining Class of Service as Erase List Allowed (ELA) in LD 11 for the M3903 or M3904 Virtual telephone. For further information on configuring ELA in LD 11, see LD 11 on [page 177](#).

Clearing the Directory Services Password functionality allows multiple Virtual Office worker using the same host telephone to have access to password-protected features if one of the users set the password and does not turn it off when the Virtual Office worker log out.

Clearing the Callers List and Redial List

With Phase III M3900 Series Digital Telephones, the Meridian 1, or the CS 1000 system clears the Callers List and Redial List when a Virtual Office worker logs in or logs out of an M3903 or an M3904 Host telephone. The system administrator configures this functionality by defining Class of Service as Erase List Allowed (ELA) in LD 11 for the M3903 or M3904 Virtual telephone. For further information on configuring ELA in LD 11, see LD 11 on [page 177](#).

When the ELA Class of Service is defined, the Callers List and Redial List are automatically cleared when the Virtual Office worker logs in or logs out.

Automatic Logout for Virtual Office

Phase III M3900 Series Digital Telephones introduces Automatic Logout for Virtual Office workers. If a Virtual Office worker, who is already logged in to telephone A, tries to log on to telephone B, the system automatically logs out the Virtual Office worker from telephone A and logs the Virtual Office worker in to Telephone B (provided the correct login password is entered). This feature is activated by the system administrator in LD 15 at the Virtual Office Automatic Logout (VO_ALO) prompt. For further information on configuring the Automatic Logout for Virtual Office in LD 15, see LD 15 on [page 177](#).

The system administrator can also define a time at which all Virtual Terminals are automatically logged out. The automatic log out time is configured in LD 15 at the Virtual Office Automatic Logout Time (VO_ALOHR) prompt.

If the telephone is busy at the automatic logout time, (for example, if the Virtual Office worker is using Corporate Directory or Set-to-Set Messaging), the telephone is not logged out until it is in the idle state.

Note: If the user logs in to a Virtual telephone after automatic logout occurs, the telephone does not automatically log out a second time.

Speed Call for Virtual Office

Phase III Meridian Series Digital Telephones support Speed Call (SCU/SCC) and System Speed Call (SSU only) on Virtual Terminal numbers.

Operating parameters

The Virtual Terminal Prime DN cannot be a Primary DN on another terminal. The Virtual Terminal Prime DN (user A) can be the secondary DN of another Virtual Terminal (user B). If both user A and user B are logged in, a call to user A's Primary DN can be answered by user B's Secondary DN.

If Virtual Office user A logs out, user B logs in, and another user calls the Primary DN of user A, the following scenarios can occur:

- If user A has Call Forward configured before logout, the call is forwarded.
- If user A does not have Call Forward configured, but has Default Call Forward (DCFW) configured, the call is forwarded to that DN (the DN can be Call Pilot).
- If neither of the above scenarios apply, the caller receives an overflow tone.

Feature implementation

LD 15 – Configure the automatic logout time for Virtual Office terminals

Prompt	Response	Description
REQ:	NEW CHG	Add new data Change existing data
TYPE:	FTR	Features and options
CUST		Customer number
	0-99	Range for Large System and CS 1000E system
	0-31	Range for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T
...		
VO_ALO	(NO) YES	Disable Virtual Office Automatic Logout (default). Enable Virtual Office Automatic Logout
VO_ALOHR	(0)-23	Virtual Office Automatic Logout time Use the 24-hour clock

LD 11 – Allow or deny the erasing of the Callers and Redial lists for Virtual Terminals (Part 1 of 2)

Prompt	Response	Description
REQ:	NEW CHG	Add new data Change existing data
TYPE:		M3900 series telephone types
	3903V 3904 V	M3903 Virtual Terminal M3904 Virtual Terminal

LD 11 – Allow or deny the erasing of the Callers and Redial lists for Virtual Terminals (Part 2 of 2)

Prompt	Response	Description
...		
CLS	(ELD) ELA	Erase Lists (Denied)/Allowed

LD 57 – Configure the Flexible Feature Codes for the Virtual Office feature (Part 1 of 2)

Prompt	Response	Description
REQ	NEW	Add new data block information
	CHG	Change data block information
	OUT	Remove data block information
	END	Exit data block
TYPE	FFC	Flexible Feature Codes data block
...
CODE	VTLN	FFC for logging a Virtual Terminal onto a Host Terminal
	ALL	Every FFC is prompted
	<CR>	No further prompt; returns to “REQ”
VTLN	xxxx	Enter Virtual Terminal logging code
	<CR>	Returns to “CODE”

LD 57 – Configure the Flexible Feature Codes for the Virtual Office feature (Part 2 of 2)

Prompt	Response	Description
CODE	VTLF	FFC type for logging off a Virtual Terminal
	ALL	Every FFC is prompted
	<CR>	No further prompt; returns to “REQ”
VTLF	xxxx	Enter Virtual Terminal logging off code
	<CR>	Returns to “CODE”
		Note: You cannot move or copy a Virtual Terminal Number.

LD 97 – Configure a Phantom loop for the Virtual Office feature

Prompt	Response	Description
REQ	CHG	Change the loop configuration
TYPE	SUPL	Superloops
SUPL	Naaa	N = designates the superloop as a phantom loop aaa = designates the superloop number
...

LD 20 – Print Terminal Number Block (TNB) data for Virtual and Host Terminals

Prompt	Response	Description
REQ:	PRT	Print data block for the requested terminal type(s)
	LTN	List Terminal Numbers of the requested terminal type(s)
TYPE:	xxxxx	Enter appropriate telephone model where xxxxx:
	3903V	3903V = M3903 Virtual Terminal
	3904V	3904V = M3904 Virtual Terminal
	3903H	3903H = M3903 Host Terminal
	3904H	3904H = M3904 Host Terminal
	TNB	Note 1: Only M3903 and M3904 Digital Telephones can be configured as a Virtual or Host Terminal. Note 2: The Print TNB and List TNB requests always show the logged-off TNB data. In logged-in state, an indication of the logged-in TN (“HOST TN” or “VIRTUAL TN”) is added.
...

LD 81 – Print a list or count of telephones with a specified Class of Service or feature (Part 1 of 2)

Prompt	Response	Description
REQ	LST	LST = Print list of telephones
	CNT	CNT = Print count of telephones
CUST		Customer number, where xx designates one customer number, and xx yy designates a range of customer numbers
	0-99	Range for Large System and CS 1000E system
	0-31	Range for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T

LD 81 – Print a list or count of telephones with a specified Class of Service or feature (Part 2 of 2)

Prompt	Response	Description
	<CR>	Print all customers
...
FEAT	aaaa	aaaa = Designates a feature mnemonic
	3900	3900 = prints M3900-type telephones, including Virtual and Host Terminals
	DCFW	DCFW = prints Default Call Forward Virtual Terminals
...

M3900 installation and configuration

Contents

This section contains information on the following topics:

Reliability	184
Environmental and safety considerations	185
Temperature and humidity	185
Safety and Electromagnetic compatibility	185
Line engineering	188
M3900 set power consumption	189
Installation	189
Installing the M3900 Series Digital Telephone	189
Changing telephone positions	190
Wall-mounting the telephone	191
Installing the Accessory Connection Module	192
Accessory keying	195
Installing the Analog Terminal Adapter	195
Installing Personal Directory PC Utility software	197
Installing the Key-Based Accessory Module	198
Installing the Single KBA footstand	200
Installing the Expansion KBA footstand	201
Installing the Display-Based Accessory Module	201
Installing the handset option for the M3905 Call Center Telephone	202
Installing alternate key caps for the M3905	204
Installing the Full Duplex Handsfree cartridge	206
Configuration	206
Task summary	206

Reliability

Reliability is measured by the Mean Time Between Failure (MTBF). The MTBF ratings for M3900 Series Digital Telephones are shown in Table 29.

Table 29
M3900 Mean Time Between Failure ratings

Set	MTBF	Return rate per year
M3901	250 years	0.4%
M3902	200 years	0.5%
M3903	150 years	0.4%
M3904	93 years	0.23%
M3905	100 years	0.25%
Key-Based Accessory module (KBA)	500 years	0.2%
CTI Accessory (CTIA)	50 years	2%
Power supply	30 years	3%

Environmental and safety considerations

Temperature and humidity

Table 30
M3900 operating temperature and humidity requirements

Operating state	
Temperature range	0° to 50°C (32° to 104°F)
Relative humidity	5% to 95% (noncondensing). At temperatures above 34°C (93°F) relative humidity limited to 53 mbar of water vapor pressure.

Table 31
M3900 storage temperature and humidity requirements

Storage	
Temperature range	-50° to 70°C (-58° to 158°F)
Relative humidity	5% to 95% (noncondensing). At temperatures above 34°C (93°F) relative humidity limited to 53 mbar of water vapor pressure.

Safety and Electromagnetic compatibility

The M3900 Series Digital Telephones have been tested and found to comply with Safety and Electromagnetic Compatibility (EMC) standards as shown in Table 32 on [page 186](#) and Tables 33 and 34 on [page 188](#).

Refer to Product Bulletins or check with your Nortel representative for the latest developments in EMC standards.

Table 32
M3900 Safety standards compliance

Safety	Description
EN 60950 / IEC 60950	Safety of Information Technology Equipment including Electrical Business Equipment (Europe)
UL 60950	Safety of Information Technology Equipment (USA)
CSA 22.2 60950	Safety of Information Technology Equipment (Canada)
AS3260, TS001, TA-1302	Safety (Australia)
JATE	Safety of Telecom Equipment (Japan)

Table 33
M3900 Electromagnetic Compatibility standards: Radiated and conducted (Part 1 of 2)

EMC - Radiated and Conducted	Description
FCC CFR 47 Part 15	FCC Rules for Radio Frequency Devices (USA) (See Note 1 below.)
CSA C108.8	Radiated Emissions (Canada)
ICES-003	Interference-Causing Equipment Standard: Digital Apparatus (Canada)
EN55022 / CISPR 22	Information technology equipment — Radio disturbance characteristics — Limits and methods of measurement (Europe) (See Notes 2 and 3 below.)
EN 61000-3-2	Limits for harmonic current emissions (equipment output current <= 16 A per phase)
EN 61000-3-3	Limitation of voltage fluctuations and flicker in low-voltage supply systems for equipment with rated current <= 16 A

Table 33
M3900 Electromagnetic Compatibility standards: Radiated and conducted (Part 2 of 2)

EMC - Radiated and Conducted	Description
VCCI AS/NZS 3548 CISPR 22	EMC (Japan) Limits and methods of measurement of radio disturbance characteristics of information technology equipment (Australia / New Zealand) (See Notes 2 and 3 below.)
<p>Note 1: M3900 Class A telephones comply with Part 15 of the FCC Rules to Class A limits. In a domestic environment, this equipment may cause radio interference, in which case the user may be required to provide adequate protective measures.</p> <p>M3900 Class B telephones comply with Part 15 of the FCC Rules to Class B limits. Operation of Class B equipment is subject the following conditions:</p> <ul style="list-style-type: none"> • The equipment may not cause harmful interference. • The equipment must accept any interference received, including interference that may cause undesired operation. <p>Changes or modifications not expressly approved by Nortel could void the user's authority to operate this equipment.</p> <p>Note 2: The M3903 telephone (NTMN33GA) is CISPR A compliant. The M3903 meets CISPR 22 to Class B limits in the regions of Europe, the Middle East, and Africa.</p> <p>Note 3: The Analog Terminal Adapter (NTMN68xx) is CISPR A compliant. It meets CISPR 22 to Class B limits when used with the M3904 or M3905 telephones.</p>	

Table 34
M3900 Electromagnetic Compatibility standards: Immunity

EMC - Immunity	Description
EN50082-1	Electromagnetic Compatibility - Generic immunity standard Part 1: Residential, commercial and light industry (Europe)
EN 55024	Information technology equipment — Immunity characteristics — Limits and methods of measurement (Europe)
IEC 801-2 (level 4)	Electro Static Discharge (Europe)
IEC 801-3 (level 2)	Radiated Immunity (Europe)
IEC 801-4 (level 3)	Fast Transient/Burst Immunity (Europe)

Line engineering

The M3900 Series Digital Telephones use twisted pair wiring on transmission lines determined by the rules in “Digital telephones line engineering” on [page 289](#). The maximum acceptable loop length is 1067 m. (3500 ft), assuming 24 AWG (0.5 mm) standard twisted wire with no bridge taps. A 15.5 dB loss at 256 kHz defines the loop length limit. Longer lengths are possible, depending on the wire’s gauge and insulation.

CAUTION

Use only the line cord provided with the telephone. A line cord designed for another telephone can cause damage to the equipment.

M3900 set power consumption

Table 35 shows power consumption measurements of the M3900 telephones in various states.

Table 35
M3900 set power consumption

	M3901	M3902	M3903	M3904	M3905
Idle	29.3	37.3	42.5	31.5	15.02
H/F Nominal	N/A	45.7	48.7	37.5	N/A
H/F Maximum	N/A	64.3	59.7	46.4	N/A
DBA Idle	N/A	N/A	N/A	39.29	15.31
DBA H/F Nominal	N/A	N/A	N/A	45.9	N/A
DBA H/F	N/A	N/A	N/A	52	N/A
Maximum 2 KBA Idle	N/A	N/A	N/A	33.42	14.98
Note: All measurements are in milli-amps.					

Installation

Use Procedure 28 to install the M3900 Series Digital Telephone

Procedure 28 **Installing the M3900 Series Digital Telephone**

- 1 Complete the wiring and cross-connections (loop power).
Note: The M3901, M3902, and M3903 are polarity sensitive. The Tip and Ring connections from the telephones to the Digital Line Cards (DLC) must be connected directly. If the Tip and Ring signals are crossed on an M3901, M3902, or M3903, the telephone will not function.
- 2 Connect the telephone to the connecting block.
- 3 Place the telephone upright on the desk in the normal operating position.

- 4 Supply the user with a quick reference guide.



CAUTION

Before handling internal telephone components, you must discharge static electricity from your hands and tools by touching any grounded metal surface or conductor.

Changing telephone positions

The M3903, M3904 and M3905 Digital Telephones have several different height selections for the desktop positions.

Use Procedure 29 to change the telephone position.

Procedure 29 **Changing the telephone position**

- 1 Press the tilt handle located at the top back side of the telephone.
- 2 With the tilt handle pressed in, raise or lower the telephone to the desired angle or height.
- 3 Release the tilt handle to lock the telephone in the desired position.

Note: The M3903 and M3904 can be wall-mounted using the optional wall-mount bracket.

The M3901 and M3902 Digital Telephones have three different angled height desktop positions.

Use Procedure 30 to change the telephone angle.

Procedure 30 **Changing the telephone angle**

- 1 Move the top of the footstand away from the telephone base (it has a snap connection).
- 2 Place the footstand in the desired position and snap the top of the footstand back into place.

Wall-mounting the telephone

For the M3903, M3904, and M3905 Digital Telephones, a separate wall-mount bracket kit must be used to wall-mount the telephone. The telephone wall-mount bracket kit contains a one-piece wall-mount plate to attach the telephone to the wall. For the M3901 and M3902 telephones, the supplied footstand can be reversed to allow wall-mount installation. An optional wall-mount brace kit may be purchased for the M3901 and M3902 to provide additional support.

Note: The Key-Based and Display-Based Accessory modules cannot be wall-mounted.

Use Procedure 31 to wall-mount the telephone.

Procedure 31 **Wall-mounting the telephone**

- 1 Place the wall-mount bracket against the wall and mark the spot to insert the screws.

Note: M3901 and M3902 have built-in wall-mount brackets.

- 2 Screw the five screws in and leave about 3 1/2 mm (1/8 inch) between the head of the screw and the wall.
- 3 Remove the footstand from the telephone by sliding the footstand down (using the plastic hinges) about 7 mm (1/4 inch).
- 4 Swing the footstand away from the telephone base and remove from the telephone.
- 5 Attach the wall-mount bracket onto the back of the telephone by placing the telephone at the top edge of the wall-mount bracket and sliding the telephone into place.
- 6 Mount the wall-mount bracket, attached to the telephone onto the screws located on the wall.

Installing the Accessory Connection Module

Use the Procedure 32 to install the Accessory Connection Module (ACM).

Procedure 32 **Installing the ACM**

- 1 Disconnect the line cord from the telephone base before installing the ACM.
- 2 Slide the footstand down (using the plastic hinges) about 7 mm (1/4 in.) and swing the footstand away from the telephone base.
- 3 Snap the ACM into the rectangular opening on the back of the telephone.
- 4 Connect the ACM cable to the back of the telephone.
- 5 Put the ACM attached ribbon cable into the track running down the back of the telephone base.
- 6 Put the hard plastic cable cover over the ACM ribbon cable.
- 7 Snap the ACM plastic cable cover into place.
- 8 Place the footstand on the hinges.
- 9 Swing the footstand back into place.
- 10 Snap the footstand into a non-movable position.
- 11 Reconnect the line cord to the telephone base.
- 12 Return the telephone to an upright position.

There is a cutout on the base of the footstand which displays the ACM connector ports. When ready to attach an accessory, insert the appropriate cartridge into the port slot. There is one accessory port available on the M3902. There are two accessory ports available on the M3903, M3904 and M3905.


Note 1: A wall transformer is required to power any accessory cartridges. The transformer does not come with the ACM unit. Contact your Nortel local distributor to order this ACM compatible wall transformer. Refer to the procedure “Installing the wall transformer” on [page 194](#).

Note 2: Refer to the manufacturer’s documentation for complete installation and configuration instructions for your external analog device (FAX machine, modem, or 500/2500 telephone).

Note 3: The accessories you attach to the telephone must be compatible. Table 23: “Accessory compatibilities” on [page 149](#) shows the compatibility of the available options.

Figure 36 shows the installation of the ACM into the telephone footstand.

Figure 36
ACM module



Installing the wall transformer


Use Procedure 33 to install the wall transformer.

Procedure 33 Installing the wall transformer

- 1 Remove the line cord from the telephone jack.
- 2 Insert the transformer adapter plug into the telephone wall jack.
- 3 Insert the line cord into the wall transformer adapter jack.

Figure 37 shows the connections for the wall transformer.

Figure 37
Wall transformer connections



Accessory keying

On the M3903, M3904, and M3905 Digital Telephones there are two accessory ports on the back of the telephone footstand. On the M3902, there is a single accessory port on the back of the footstand. Each port can support one cartridge accessory.

You cannot use two accessories that require the same port type at the same time. For example, you cannot use two accessories that require a serial port connection at the same time.

The shape and size of the plug in the accessory cartridge prevents the user from accidentally connecting incompatible accessories. To check the compatibility of accessories, refer to Table 23 on [page 149](#), which shows the optional accessories and their compatibility.

Installing the Analog Terminal Adapter

The Analog Terminal Adapter (ATA) allows an off-the-shelf analog device (FAX, modem, or analog [500/2500-type] telephone) to work simultaneously with your M3902, M3903, M3904, or M3905 Digital Telephone. The ATA is not supported on the M3901 telephone.

Install the Accessory Connection Module (ACM) into your M3900 Series Digital Telephone. Refer to “Installing the Accessory Connection Module” on [page 192](#) before you install your ATA. The ACM provides connection capabilities between the M3902, M3903, M3904, and M3905 telephones and the ATA.

Use the Procedure 34 to install the ATA.

Procedure 34 **Installing the ATA**

- 1 Disconnect the line cord from the telephone before installing the ATA.
- 2 Insert the ATA accessory cartridge into the ACM. The latch should be at the top.
- 3 Connect the commercial device you have selected to use, either your FAX machine, modem, or analog (500/2500-type) telephone, to the connection on your ATA cartridge interface.

- 4 Plug the transformer into the electrical outlet (use only the transformer designed for your ACM accessories).
- 5 Connect the Adapter plug, attached to your transformer, into the telephone wall jack.

The wall transformer Adapter plug attaches between the telephone line cord and the telephone wall jack.
- 6 Connect the line cord to the Adapter jack attached to the wall transformer.
- 7 Reconnect the line cord back to your telephone base.

Note: The ATA supports connections to Plain Old Telephone Service (POTS) only. ATA does not support features such as Message Waiting, Switchhook Flash/Link, Transfer, Conference, and CLASS type services.

A red LED status light located on the ATA indicates the status of the ATA.

- **Flashing red** indicates that the ATA is operating normally. For more troubleshooting guidelines, refer to the user documentation that came with your analog device.
- **Solid red** indicates that the ATA is not operating normally. Contact your system administrator.
- **Red light off** indicates that there is no power going to the ATA or the unit is not operating correctly. Check the power connections to the ATA. If problems continue, contact your system administrator.

Flexible voice and data capabilities allow you to have continuous use of both the M3900 Series Digital Telephone and the attached analog device. Your system administrator configures the flexible voice and data capabilities for your telephone on the system equipment. Contact your system administrator for more information about flexible voice and data capability.

When there is a power failure to the ATA, the Analog Device does not store or keep information (for example, outgoing FAX from your FAX machine). You must send the information again when power returns.

Table 36 shows prompts and responses when configuring the ATA.

Table 36
ATA configuration

Prompt	Response	Description
REQ	NEW	Input new data
	CHG	Change current data.
CLS	aaaa	Class of Service options, where aaaa: = (FLXD) - Flexible voice/data denied = FLXA - Flexible voice/data allowed, required if ATA equipped. = (VCE) - Voice terminal, required if ATA equipped. = DTA - Data terminal. Note: If ATA is installed, CLS must be FLXA, VCE.
KEY	0 SCR xxxx	Single Call Ringing, where xxxx = the DN for ATA

Installing Personal Directory PC Utility software

The Personal Directory PC Utility provides a faster, easier way to create or modify a personal directory. You can enter names and numbers into a Personal Directory file on your Personal Computer (PC). You can download the PC file directly to the M3904 or M3905 telephone. You can upload a directory from the M3904 to a PC to modify the M3904 directory.

Use Procedure 35 to install the Personal Directory PC Utility software.

Procedure 35 Installing the Personal Directory PC Utility software

- 1 Close all open applications before installing the Personal Directory PC Utility.
- 2 Insert the Personal Directory PC Utility disk into your floppy disk drive.
- 3 Click on **Start**.
- 4 Select **Run**.

- 5 Enter a:\setup (assuming that drive "a" is your floppy disk drive).
- 6 Click on **OK**. The Nortel logo screen appears while the installation utility loads.
- 7 The Welcome screen appears. Click **Next** to continue installation.
- 8 If you agree to the terms of the Software License Agreement, click **Yes**.
- 9 Continue to click **Next** until the installation is complete.
- 10 When asked to, remove the disk from your floppy disk drive.
- 11 Click **Finish**.

Note: You must restart your PC to access the Personal Directory PC Utility.

- 12 To select a port for the Personal Directory PC Utility; click **Phone**. Click **Set** port. The pull-down menu shows available PC ports:
 - Com1
 - Com2

Note: The program selects the same port each time until you change it.

Installing the Key-Based Accessory Module

The Key-Based Accessory (KBA) module provides 22 additional line/feature keys for the M3904 and M3905 Digital Telephones. You can add up to two KBAs, providing a total of 75 line/feature keys.

Use Procedure 36 to install the KBA.


Procedure 36 **Installing the KBA**

- 1 While depressing the telephone tilt handle, pull the telephone away from the footstand until it clears the final stop. Gently pull the footstand off the clips.

Note: If an ACM is installed, unplug the ACM and remove it from the footstand. Install the ACM in the Single KBA Footstand Assembly.
- 2 Place the telephone and the KBA face down on a padded, level surface, and align them.


- 3 Plug the cable from the KBA into the 10-pin connection port on the telephone. See Figure 38.

Figure 38
KBA Installation



- 4 Thread the cable through the opening in the side of the telephone.
- 5 Insert the clips on the telephone into the hinges on the footstand; then press on the front of the footstand until it snaps into place.
- 6 Install the Single KBA Footstand Assembly. See Figure 39.

Figure 39
KBA Footstand Assembly



- 7 To add a second KBA:
 - a. Place the telephone and the two modules face down on a non-abrasive surface.
 - b. Plug the cable from the second module into the 10-pin connection port on the first module.
 - c. Thread the cable through the routing clips on both modules.
 - d. Install the Expansion KBA footstand.

Installing the Single KBA footstand

Use Procedure 37 to install the Single KBA footstand.

Procedure 37**Installing the Single KBA footstand**

- 1 Insert the clips on both the telephone and the KBA into the hinges on the footstand assembly, and press on the front of the footstand until they snap into place.
- 2 While squeezing both the telephone and the KBA tilt handles, swing the footstand into the desired position.
- 3 Turn the completed assembly upright.

Installing the Expansion KBA footstand

Use Procedure 38 to install the Expansion KBA footstand.

Procedure 38**Installing the Expansion KBA footstand**

- 1 Place the Single KBA footstand and the Expansion KBA footstand face down on a flat surface.
- 2 Align the Expansion KBA footstand with the Single KBA footstand and slide them together.
- 3 Insert two screws through the Expansion KBA plate into the Single KBA footstand.
- 4 Tighten all four screws, ensuring that the two footstand assemblies are properly aligned.
- 5 Insert the clips on the telephone and the KBAs into the hinges on the combined Single Expansion KBA footstand Assembly, and while squeezing the Module tilt handles, swing the footstand into the desired position.
- 6 Turn the completed assembly upright.

Installing the Display-Based Accessory Module

The Display-Based Accessory Module (DBA) gives you three layers of eight programmable line/feature (soft-labeled) keys, for a total of 24 (keys 32 through 55).

The **Page** button allows you to scroll to each key layer. The soft-labeled field is 10 characters in length. You can customize the DBA labels using the program mode and the dial pad keys.

Use Procedure 39 to install the DBA.

Procedure 39
Installing the DBA


- 1 While depressing the telephone tilt handle, pull the telephone away from the footstand until it clears the final stop. Gently pull the footstand off the clips.
- 2 Place the telephone and the DBA face down on a padded level surface, and align them.
- 3 Lower the DBA into place, and insert the 10-pin plug on the Module into the 10-pin slot on the telephone. Push in gently until the retaining tabs snap into place.
- 4 Insert the clips on the telephone into the hinges on the footstand, then press on the front of the footstand until it snaps into place.
- 5 While depressing the telephone tilt handle, swing the footstand into the desired position, then release the handle.
- 6 Carefully turn the new assembly upright.

Installing the handset option for the M3905 Call Center Telephone

A handset does not accompany the M3905 Call Center Telephone. The Handset Kit is a hardware option for the M3905 Call Center Telephone, and includes a handset, cord, and add-on handset cradle. The handset can be added to the M3905 by removing the front plate of the telephone.

Note: Nortel recommends that a systems administrator or technician complete this installation.

Figure 40
Removal of the Hook Switch Cover



There are five tabs and two hidden snaps on the HookSwitch cover. There are two tabs along the right and three along the bottom edge (Front view). To remove the cover, the hidden snaps must be released (Rear view).

Use Procedure 40 to remove the HookSwitch cover.

Procedure 40
Removing the HookSwitch cover


- 1 Ease the cover to the left and pull on the left side to release the left snap.
- 2 While holding the left snap out, ease the cover to the right and pull on the right side to release the right snap.
- 3 Carefully maneuver the cover out from the three bottom slots and rotate the cover to release the two side tabs.

Use Procedure 41 to install the cradle.

Procedure 41
Installing the cradle

- 1 Hold the cradle in the same position as when you removed the Hook Switch Cover; move the cradle to the right to place the tab into the slot.
- 2 Ease the other tabs on the bottom edge of the cradle into the slots.

Figure 41
Installation of the cradle




- 3 When all tabs are in the proper position, secure the cradle into place by pushing straight downward.

Installing alternate key caps for the M3905

Use the Key Extractor Tool with the M3905 Call Center Telephone to remove the programmable keys and replace them with alternate keys customizing your telephone to fit your need.

Figure 42
Install the alternate key caps



As shown in Figure 42, place the tips of the tool into the slots at the right and left of the key, grip tightly and pull straight upward. Do not rock or twist the key during removal or insertion, as this may damage the key seat and impair the functionality of the set.

Use Procedure 42 to install the key caps.

Procedure 42
Installing the key caps

- 1 Fit the two small elastomer posts into two slots on the undersides of the keys and firmly press downward.
- 2 The key releases immediately after pressure is applied.

Note: If the key does not release, remove it. Attempt the installation again making sure that the posts and the slots are properly aligned.

Installing the Full Duplex Handsfree cartridge

Use Procedure 43 to install the Full Duplex Handsfree cartridge.

Procedure 43

Installing the Full Duplex Handsfree cartridge

- 1 Check the label on the back of your set to make sure that it is an M3904 Phase III set (NTMN34GA). If your set is an NTMN34GA, go to Step 2.

If your set is not an NTMN34GA, it is not FDHF-compatible. Please contact your system administrator to obtain the correct set.
- 2 Install the Accessory Connection Module (ACM). For information on how to install the ACM, refer to “Installing the Accessory Connection Module” on [page 192](#).
- 3 Insert the FDHF cartridge into one of the ACM ports.
- 4 Plug the wall transformer into the electrical outlet.
- 5 Disconnect the telephone line cord from the telephone wall jack. See Figure 37 on [page 194](#).
- 6 Connect the wall transformer adapter plug into the telephone wall jack. See Figure 37 on [page 194](#).
- 7 Connect the telephone line cord to the wall transformer adapter jack. See Figure 37 on [page 194](#).
- 8 Verify that the FDHF cartridge is working properly.
The FDHF cartridge is working properly when the red LED on the FDHF cartridge is flashing and when there are 18 segments on the volume bar.

Configuration

Task summary

The following is a summary of the tasks in this section:

- 1 LD 11 – Configure the M3900 Series Digital Telephone
- 2 LD 15 – Assign a default language and customize Set-to-Set Messages
- 3 LD 11 – Configure the Callers List and Redial List keys on Context-sensitive soft keys or programmable feature keys.

- 4 LD 11 – Configure the default language for M3900 telephones
- 5 LD 11 – Configure the Server-based Applications (Corporate Directory and Set-to-Set Messaging)
- 6 LD 32 – Clear or reset a Personal Directory Password for M3900 telephones.
- 7 LD 22 – Print M3900 peripheral software versions
Note: The firmware versions for each M3900 telephone type will be printed along with the versions of any other downloadable peripheral software.
- 8 LD 97 – Configure parameters for System-wide Flash Download
- 9 LD 11 – Configure Full Duplex Handsfree Class of Service
- 10 LD 32 – Flash Download commands

Note: For more information, refer to *Software Input/Output: Administration* (553-3001-311), *Software Input/Output: Maintenance* (553-3001-511), and *Software Input/Output: System Messages* (553-3001-411).

LD 11 – Configure the M3900 Series Digital Telephone (Part 1 of 5)

Prompt	Response	Description
REQ:	NEW	New data
	CHG	Change current data
TYPE:	x..x	Type of telephone 3901 = M3901 3902 = M3902 3903 = M3903 3904 = M3904 3905 = M3905 3903H = M3903 Host Terminal 3904H = M3904 Host Terminal 3903V = M3903 Virtual Terminal 3904V = M3904 Virtual Terminal Note 1: The M3903, M3904, and 3905 Digital Telephones only support the Host Terminal and the Virtual Terminal feature. Note 2: If the M3901, M3902 or M3905 are configured as a Virtual Terminal, the error message SCH0099 is output. Note 3: M3903, M3904, and M3905 Digital Telephones support Corporate Directory and Set-to-Set Messaging.

LD 11 – Configure the M3900 Series Digital Telephone (Part 2 of 5)

Prompt	Response	Description
TN		Terminal number
	l s c u	Format for Large System and CS 1000E system, where l = loop, s = shelf, c = card, u = unit. If confirmed as 3903V or 3904V, the loop must be a phantom. If confirmed as 3903H or 3904H, the loop must NOT be a phantom.
	c u	Format for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T, where c = card and u = unit. Input only the card and unit address. If confirmed as 3903V or 3904V, the card must be a phantom (card slots 61-80). If the telephone has an Analog Terminal Adapter (ATA), then use the voice Terminal Numbers 16-31.
...
DES	d...d	Designator d...d = represents an Office Data Administration System (ODAS) Station Designator of 1-6 alphanumeric characters
...
CUST	xx	Customer number as defined in LD 15
...

LD 11 – Configure the M3900 Series Digital Telephone (Part 3 of 5)

Prompt	Response	Description
KBA	(0)-2	Key-based Accessory module (configuration prompt KBA) The KBA prompt appears when the set type is M3904 or M3905. 0 = allows configuration of up to and including key number 31 1 = allows configuration of up to and including key number 53 2 = allows configuration of up to and including key number 75
DBA	(0)-1	Display-based Accessory module (configuration prompt DBA) If KBA is a non-zero value, then DBA is not prompted. If KBA is a zero value or if the carriage return is pressed, then the DBA prompt appears. 0 = allows configuration of up to and including key number 31 1 = allows configuration of up to and including key number 55
FDN	xxx...x	Flexible CFNA (Call Forward No Answer) DN
...
SCPW	xxx...x	Station Control Password
...

LD 11 – Configure the M3900 Series Digital Telephone (Part 4 of 5)

Prompt	Response	Description
CLS	aaaa	<p>Class of Service options where aaaa:</p> <ul style="list-style-type: none"> = (GRLD) Group Listening Denied, (M3902, M3903, M3904) = GRLA Group Listening Allowed, (M3902, M3903, M3904) = (HFD) Handsfree Denied, (M3902, M3903, M3904) = HFA Handsfree Allowed (M3902, M3903, M3904) = ADD Automatic Digit Display, default for M3902, M3903, M3904, M3905 = (VCE) Voice Terminal, required if ATA equipped = DTA Data Terminal = (FLXD) Flexible voice/data denied = FLXA Flexible voice/data allowed, required if ATA equipped = (STSD) Set-to-Set Messaging Denied, (M3903, M3904, and M3905) = STSA Set-to-Set messaging Allowed, (M3903, M3904, and M3905) = (CRPD) Corporate Directory Denied, (M3903, M3904, and M3905) = CRPA Corporate Directory Allowed. (M3903, M3904, and M3905) <p>Note 1: If ATA is equipped, CLS = FLXA, VCE required</p> <p>Note 2: M3903 and M3904 must have HFA Class of Service for the Headset to operate.</p>
...
DCFW	z..z	<p>Default Call Forward DN</p> <p>DN where calls are forwarded (the target DN)</p> <p>The maximum length of the DCFW is 31</p>
	x <CR>	<p>x = remove the DCFW DN</p> <p>Note: The DCFW prompt appears only for Virtual Terminals (3903V, 3904V).</p>

LD 11 – Configure the M3900 Series Digital Telephone (Part 5 of 5)

Prompt	Response	Description
KEY	xx aaa yyyy zzz	<p>Telephone function key assignments where: xx = key number aaa = key name or function yyyy, zzz = additional information required</p> <p>Refer to the Key description table for each M3900 telephone:</p> <p>“M3901 key description” on page 159 “M3902 key description” on page 161 “M3903 key description” on page 162 “M3904 key description” on page 166 “M3905 key description” on page 169</p> <p>MTAD (CS 1000 and Meridian 1 Time and Date) - the system puts a block on the time/date key on all the M3900 Series Meridian Digital Telephones</p> <p>Note 1: VTN primary DN cannot be a primary DN for any other TN, and the VTN must be defined as a MARP TN.</p> <p>Note 2: The DN of a Virtual Terminal cannot be defined on a Host Terminal, and the Host Terminal DN cannot be defined on a Virtual Terminal.</p>
...

LD 15 – Assign a default language and customize Set-to-Set Messages (Part 1 of 3)

Prompt	Response	Description
REQ:	NEW CHG	Add new data Change existing data
TYPE:	FTR	Features and options

LD 15 – Assign a default language and customize Set-to-Set Messages (Part 2 of 3)

Prompt	Response	Description
CUST		Customer number
	0-99	Range for Large System and CS 1000E system
	0-31	Range for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T
...		
DFLT_LANG		M3900 default language.
	(ENG)	English (default)
	FRE	French
	GER	German
	DUT	Dutch
	SPA	Spanish
	ITA	Italian
	NOR	Norwegian
	SWE	Swedish
	DAN	Danish
	POR	Portuguese
	FIN	Finnish
	POL	Polish
	CZE	Czech
	HUN	Hungarian
	JAP	Japanese
	RUS	Russian
STS_MSG	(NO) YES	Modify Set-to-Set messages
MSG 01	<CR> <text string>	Keeps current message Input the new message to be displayed (up to 24 characters)

LD 15 – Assign a default language and customize Set-to-Set Messages (Part 3 of 3)

Prompt	Response	Description
... MSG 10	<CR> <text string>	Keeps current message Input the new message to be displayed (up to 24 characters)

LD 11 – Configure the Callers List and Redial List keys on Context-sensitive soft keys or programmable feature keys.

Prompt	Response	Description
REQ:	NEW CHG	Add new data Change existing data
TYPE:		M3900 series telephone types
	3903H 3904H 3903V 3904V 3905	M3903 Host set M3904 Host set M3903 Virtual set M3904 Virtual set M3905 set
...		
KEY	27 CLT	Configure Callers List key on a Context-sensitive soft key. CLT and NUL are the only options for KEY 27.
KEY	28 RLT	Configure the Redial List key on a Context-sensitive soft key. RLT and NUL are the only options for KEY 28.
KEY	XX CLT	Configure the Callers List key on an available programmable feature key.
KEY	XX RLT	Configure the Redial List key on an available programmable feature key.

LD 11 – Configure the default language for M3900 telephones (Part 1 of 2)

Prompt	Response	Description
REQ:	NEW CHG	Add new data Change existing data
TYPE:		M3900 series telephone types
	3902	M3902 set
	3903H	M3903 Host set
	3904H	M3904 Host set
	3903V	M3903 Virtual set
	3904V	M3904 Virtual set
	3905	M3905 set
...		
MLNG		M3900 language selection The default is the language selection chosen for the customer in LD 15. Note: The user can change the language defined at the MLNG prompt from their set.

LD 11 – Configure the default language for M3900 telephones (Part 2 of 2)

Prompt	Response	Description
	ENG	English
	FRE	French
	GER	German
	HEB	Hebrew
	DUT	Dutch
	SPA	Spanish
	ITA	Italian
	NOR	Norwegian
	SWE	Swedish
	DAN	Danish
	POR	Portuguese
	FIN	Finnish
	POL	Polish
	CZE	Czech
	HUN	Hungarian
	JAP	Japanese
	RUS	Russian
	LAT	Latvian
	TURK	Turkish

LD 11 – Configure the Server-based Applications (Corporate Directory and Set-to-Set Messaging) (Part 1 of 2)

Prompt	Response	Description
REQ:	NEW	New data
	CHG	Change current data
TYPE:	3903 3904 3905	M3900 set types that support the Corporate Directory and the Set-to-Set Messaging.
...

LD 11 – Configure the Server-based Applications (Corporate Directory and Set-to-Set Messaging) (Part 2 of 2)

Prompt	Response	Description
CLS	aaaa	<p>Class of Service options where aaaa:</p> <ul style="list-style-type: none"> = ADD - Automatic Digit Display, default for M3903, M3904, and M3905 = (VCE), DTA - Voice Terminal, Data Terminal = (FLXD) - Flexible voice/data Denied = FLXA - Flexible voice/data Allowed <p>Note 1: Class of Service must be VCE, FLXA if telephone is equipped with the optional Analog Terminal Adapter.</p> <ul style="list-style-type: none"> = (STSD) Set-to-Set Messaging Denied = STSA, Set-to-Set Messaging Allowed <p>Note 2: STSD and STSA Class of Service applies to M3903, M3904, and M3905.</p> <ul style="list-style-type: none"> = (CRPD), Corporate Directory Denied = CRPA, Corporate Directory Allowed <p>Note 3: (CRPD) and CRPA Class of Service applies to M3903, M3904, and M3905.</p>
...

LD 32 – Clear or reset a Personal Directory Password for M3900 telephones.

Command	Description
CPWD I s c u	<p>Clear Directory Password and Terminal number, where:</p> <ul style="list-style-type: none">I = loop addresss = shelf addressc = card addressu = unit address <p>Note: The Clear command allows the system administrator to clear the M3900 Directory password of the specified M3900 Series Digital Telephone. This allows a user to access the M3900 Directory if the password has been forgotten or if the user wants to change the current password.</p>

LD 20 – Print Terminal Number Block (TNB) data for Virtual and Host Terminals

Prompt	Response	Description
REQ:	PRT	Print data block for the requested terminal type(s)
	LTN	List Terminal Numbers of the requested terminal type(s)
TYPE:	xxxxx	Enter appropriate telephone model where xxxxx:
	3903V	3903V = M3903 Virtual Terminal
	3904V	3904V = M3904 Virtual Terminal
	3903H	3903H = M3903 Host Terminal
	3904H	3904H = M3904 Host Terminal
	TNB	Note 1: Only M3903 and M3904 Digital Telephones can be configured as a Virtual or Host Terminal. Note 2: The Print TNB and List TNB requests always show the logged-off TNB data. In logged-in state, an indication of the logged-in TN (“HOST TN” or “VIRTUAL TN”) is added.
...

LD 22 – Print M3900 peripheral software versions

Prompt	Response	Description
REQ:	PRT	Print
TYPE:	PSWV	Peripheral software versions on disk

LD 97 – Configure parameters for System-wide Flash Download (Part 1 of 3)

Prompt	Response	Description
REQ	CHG	Change Flash Download Parameters
	PRT	Print Flash Download Parameters
TYPE	FDL	Flash Download for M3900 Series Digital Telephone
FDTM	t	Enter M3900 set type selected for Flash Download 3902 = M3902 3903 = M3903 3904 = M3904 3905 = M3905 ALL = All of the above NONE = None of the above (default) No further prompt; returns to "REQ"
FDTM	(NO) YES	Time interval restriction for Flash Download NO = Do not change time intervals (default) YES = Proceed to change time intervals Note 1: Flash Download is automatically paused one hour before virtual midnight (see TODR in LD 17) to allow midnight routines to run. Note 2: This option is not applicable to reporting.
FDAY	dn	Enter day and number of time intervals for Flash Download. Prompt appears only if FDTM = YES Day is reprompted until carriage return <CR> alone is entered. d = day of the week (0-6 for Sunday to Saturday) n = number of time intervals (0-4); to disallow download for the day, enter 0 Note: If two or more intervals are specified, they must be non-overlapping, non-consecutive, and in increasing order.

LD 97 – Configure parameters for System-wide Flash Download (Part 2 of 3)

Prompt	Response	Description
FINT	sl	Enter starting hour and length for a time interval. Prompted n times if n>0. s = starting hour (0-23) l = length of interval in hours (1-24)
FTNR	(NO) YES	TN range restriction option for Flash Download NO = no TN restriction (default) YES = specify TN range
FSTN		Starting Terminal Number for Flash Download. Prompt appears only if FTNR = YES.
	l s c u	Format for Large System and CS 1000E system, where l = loop, s = shelf, c = card, u = unit
	c u	Format for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T, where c = card and u = unit
FETN		Ending Terminal Number for Flash Download. Prompt appears only if FTNR = YES
	l s c u	Format for Large System and CS 1000E system, where l = loop, s = shelf, c = card, u = unit
	c u	Format for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T, where c = card and u = unit
FDNR	(NO) YES	DN range restriction option for Flash Download NO = no DN restriction (default) YES = specify DN range

LD 97 – Configure parameters for System-wide Flash Download (Part 3 of 3)

Prompt	Response	Description
FDDN	c d1 d2	Flash Download Prime Directory Number range Prompt appears only if FDNR = YES c = Customer number (0-99) d1 = starting Prime DN d2 = ending Prime DN
FRCE	(NO) YES	System-wide Flash Download control option NO = Conditional (default). System-wide Flash Download (via FDLS in LD 32) applies only to an M3900 series set whose flash firmware version is different from the version currently found on the system disk YES = Forced. Force System-wide Flash Download to all of the specified M3900 Series Digital telephones regardless of their current flash firmware versions. Note 1: Use this option with caution! Once the download tree is built (i.e., after executing FDLS in LD 32), this option automatically reverts to NO. Note 2: This option is not applicable to reporting.
FVER	0-99	Flash firmware version specified for full report. If 0, report all versions (default). Note: This option is applicable to reporting only (via FSUM ALL in LD 32).

LD 11 – Configure Full Duplex Handsfree Class of Service

Prompt	Response	Description
REQ:	NEW CHG	Add new data Change existing data
TYPE:	3904	M3900 series telephone type Full Duplex Handsfree functionality requires an M3904 Phase III set.
...		
CLS	HFA	Handsfree Allowed HFD = Handsfree Denied (default)

LD 32 – Flash Download commands (Part 1 of 2)

Command	Description
FDLU I s c u	Initiate conditional download to one telephone Terminal number, where: I = loop address s = shelf address c = card address u = unit address
FDLI I s c u	Initiate conditional download to an M3900 Series Digital Telephone when it becomes idle.
FDFL I s c u	initiate a forced download to an M3900 Series Digital Telephone regardless of its version and state.
FWVU I s c u	Query and print the firmware versions currently on an M3900 Series Digital Telephone.
FDLS	Initiate system-wide flash download to all, or a specified type of M3900 Series Digital Telephones, based on parameters specified in LD 97

LD 32 – Flash Download commands (Part 2 of 2)

Command	Description
FDLC	Cancel or gracefully stop the system-wide flash download for M3900 Series telephones.
FSUM	<p>Display summary report of current firmware versions on all M3900 Series telephones.</p> <p>The format of the report is as follows:</p> <pre> ** M390x SUMMARY REPORT ** dd - ON DISK ff (cc) - nnnn SETS FOUND ff (cc) - nnnn SETS FOUND </pre> <p>Where:</p> <p>x = 2 to 5 for M3902 to M3905 dd = the flash firmware version found on the system disk ff = the downloadable flash firmware version found on the telephone cc = the core firmware found on the telephone nnnn = the number of telephones found with firmware version ff (cc)</p>
FSUM ALL	<p>Display a complete report on all M3900 Series telephones based on parameters specified in LD 97.</p> <p>The format of the report is as follows:</p> <pre> TYPE: tttt CUST: cc PDN: dddddd TN: l s c u FW: vv </pre> <p>Where:</p> <p>tttt = 3902, 3903, 3904 or 3905 cc = 0-99 dddddd = the Primary DN of the telephone vv = the flash firmware version</p>

M3900 Flash Download

Contents

This section contains information on the following topics:

Introduction	227
Summary of steps	228
Determining software, M3900 PSWV, or firmware versions.	261
X11 software versions	261
M3900 language PSWV versions.	262
M3900 firmware versions.	262
Flash Download advisements	263
PSDL installation	267
Dynamic PSDL installation.	267
Detailed Flash Download procedure.	269
Configuration parameters in LD 32	274
Single-Set Flash Download	274
System-wide Flash Download	275
Print Firmware Versions on M3900 Telephones	279
Query Disk Firmware Versions.	281
Commands for system-wide Flash Download of M3900 telephones . .	284

Introduction

M3900 Flash Download provides the capability to download a new firmware version from the CS 1000 and Meridian 1 to an M3900 telephone. Flash

Download provides a way for installed M3900 telephones to be updated to the appropriate firmware release level for supporting features on the system. Firmware on all M3900 Series Digital Telephones can be upgraded using Flash Download, with the exception of the M3901. Flash Download can be invoked for one M3900 telephone, for a group of M3900 telephones, or all telephones on the system. It can be invoked locally or remotely for maintenance purposes. Features of the flash download procedure include the following:

- Telephone type can be specified (M3902, M3903, M3904, M3905, All)
- Day(s) of week can be specified
- Up to four intervals per day can be specified (start time, length)
- TN Range can be specified (start TN, end TN)
- DN Range can be specified (start DN, end DN)
- Force Download can be specified (yes, no)

Flash download is incorporated in the existing Peripheral SoftWare Version (PSWV) background tasks of the Work Schedule. Therefore, regular call processing is impacted as little as possible. In the context of this document, PSWV represents the firmware file that is downloaded to an M3900 telephone. It is sometimes referred to as a Peripheral Software DownLoad (PSDL). PSDL is a file that holds PSWV for hardware (for example, terminals or trunk cards) that supports a firmware upgrade.

Flash Download requires the use of two software overlays. Use LD 97 to configure the parameters for the Flash Download capability. Use LD 32 to run the feature. Before the Flash Download feature is used, configure the feature in LD 97.

Summary of steps

See Tables 37 and 38 for the overall steps needed to perform a flash download. Table 37 is for Small Systems and Table 38 is for Large Systems. These tables list the versions of system software that an M3900 customer could be running and the high-level steps needed to upgrade to the latest Reissue software. The tables reference “PSDL installation” on [page 267](#) for the steps to install the M3900 language set, PSWV. The tables also reference

the “Detailed Flash Download procedure” on [page 269](#) for the step-by-step procedure for flash downloading firmware to the M3900 Series Digital Telephones.

If you have difficulties in determining versions of X11 software, M3900 PSWV language files or firmware, refer to “Determining software, M3900 PSWV, or firmware versions” on [page 261](#).

Table 37
Flash Download procedure matrix for Small Systems (Part 1 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
24.24	25.08 (Re-issue)	Yes	Phase I	<ol style="list-style-type: none"> 1. Call Nortel technical support to find out how to obtain any necessary upgrades. <ul style="list-style-type: none"> • A SIM upgrade from 8 to 16 Meg is required. • An upgrade from MAT 6.5 is required. 2. Download software from the web. 3. Follow the “PSDL installation” on page 267. 4. Install manufactured patches. 5. Download firmware to telephones, following the Flash Download procedure.

Table 37
Flash Download procedure matrix for Small Systems (Part 2 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
			Phase II, Phase III	<p>Note: This is not a standard process. M3900 Phase II/III phones should not be configured on a Release 24.2x system.</p> <p>1. Follow the Small System Release 24.2x to Release 25.08 Reissue procedure for Phase I telephones (above).</p> <p>The Release 25.08 Reissue contains M3900 Phase I firmware for M3902 and M3905 telephones and Phase II firmware for M3903 and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase II phones to Phase II/III firmware.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 3 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.15 Re-issue	Yes	Phase I	Follow the standard software order process.
Phase II			<p>Note: This is not a standard process. M3900 Phase II/III phones should not be configured on a Release 24.2x system.</p> <p>1. Follow the Small System Release 24.2x to Release 25.15 Re-issue procedure for Phase I telephones (above).</p> <p>The Release 25.15 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>	

Table 37
Flash Download procedure matrix for Small Systems (Part 4 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.30	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. M3900 Phase II/III phones should not be configured on a Release 24.2x system.</p> <p>1. Follow the Small System Release 24.2x to Release 25.30 Re-issue procedure for Phase I telephones (above).</p> <p>The Release 25.30 contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>
	25.40, 25.40B	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. M3900 Phase II/III phones should not be configured on a Release 24.2x system.</p> <p>1. Follow the Small System Release 24.2x to Release 25.40/25.40B procedure for Phase I telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 5 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	03.00	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. M3900 Phase II/III phones should not be configured on a Release 24.2x system.</p> <p>1. Follow the Small System Release 24.2x to Release 03.00 Re-issue procedure for Phase I telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>
	04.00	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. M3900 Phase II/III phones should not be configured on a Release 24.2x system.</p> <p>1. Follow the Small System Release 24.2x to Release 04.00 Re-issue procedure for Phase I telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 6 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
25.08	25.08 Re-issue	No	Phase I, Phase II	<ol style="list-style-type: none"> 1. Download software from the web. 2. Follow “PSDL installation” on page 267. 3. Install manufactured patches. 4. Download firmware to telephones, following the Flash Download procedure.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.08 system.</p> <ol style="list-style-type: none"> 1. Follow the Small System Release 25.08 to Release 25.08 Re-issue procedure for Phase I/II telephones (above). <p>The 25.08 Reissue contains M3900 Phase I firmware for M3902 and M3905 telephones and Phase II firmware for M3903 and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 7 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.15 Re-issue	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.08 system.</p> <p>1. Follow the Small System Release 25.08 to Release 25.15 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The 25.08 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 8 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.10 Re-issue	Yes	Phase I, Phase II	<ol style="list-style-type: none"> 1. Call Nortel technical support to find out how to obtain any necessary upgrades. 2. Determine M3900 PSWV to install (see Table 40 on page 281). <p>Note: Select PSWV #5 (Phase I firmware for X11 Release 24; second PC card is needed) only if the customer is just running the Release 24 M3900 features.</p> <ol style="list-style-type: none"> 3. Download software from the web with the appropriate PSWV language file. 4. Follow the PSDL Installation Procedure (see “PSDL installation” on page 267) to install software with the selected M3900 PSWV file. 5. Install the manufactured patch. 6. Download firmware to the telephones, following the Flash Download procedure.

Table 37
Flash Download procedure matrix for Small Systems (Part 9 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.08 system.</p> <p>1. Follow the Small System Release 25.08 to Release 25.10 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The 25.10 Re-issue contains M3900 Phase I firmware for M3902 and M3905 telephones and Phase II firmware for M3903 and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 10 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.30	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.08 system.</p> <p>1. Follow the Small System Release 25.08 to Release 25.30 procedure for Phase I and Phase II telephones (above).</p> <p>The Release 25.30 contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 11 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.40, 25.40B	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.08 system.</p> <p>1. Follow the Small System Release 25.08 to Release 25.40/25.40B Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>
	03.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.08 system.</p> <p>1. Follow the Small System Release 25.08 to Release 03.00 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 12 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	04.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.08 system.</p> <p>1. Follow the Small System Release 25.08 to Release 04.00 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 13 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
25.15	25.15 Reissue	No	Phase I, Phase II	<p>1. Determine M3900 PSWV to install (see Table 40 on page 281). Select PSWV #1 Global or #4 N.A. (25% savings; second PC card needed).</p> <p>Note: Select PSWV #5 (Release 1 firmware for X11 Release 24; second PC card needed) only if the customer is just running the Release 24 M3900 features.</p> <p>2. Download software from the web with appropriate PSWV language file.</p> <p>3. Follow the PSDL Installation Procedure, see “PSDL installation” on page 267 to install software with the selected M3900 PSWV file.</p> <p>4. Install manufactured patches.</p> <p>5. Download firmware to telephones, following the Flash Download procedure.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 14 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.15 system.</p> <p>1. Follow the Small System Release 25.15 to Release 25.15 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Release 25.15 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 15 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.30	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.15 system.</p> <p>1. Follow the Small System Release 25.15 to Release 25.30 procedure for Phase I and Phase II telephones (above).</p> <p>The Release 25.30 contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>
	25.40, 25.40B	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.15 system.</p> <p>1. Follow the Small System Release 25.15 to Release 25.40/25.40B procedure for Phase I and Phase II telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 16 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	03.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.15 system.</p> <p>1. Follow the Small System Release 25.15 to Release 03.00 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>
	04.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.15 system.</p> <p>1. Follow the Small System Release 25.15 to Release 04.00 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 17 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
25.30	25.40, 25.40B	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.30 system.</p> <p>1. Follow the Small System Release 25.30 to Release 25.40/25.40B Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>
03.00	03.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.30 system.</p> <p>1. Follow the Small System Release 25.30 to Release 03.00 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 37
Flash Download procedure matrix for Small Systems (Part 18 of 18)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	04.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. M3900 Phase III phones should not be configured on a Release 25.30 system.</p> <p>1. Follow the Small System Release 25.30 to Release 04.00 Re-issue procedure for Phase I and Phase II telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>
25.40, 25.40B	03.00	Yes	Phase I, Phase II, Phase III	Follow the standard software order process.
	04.00	Yes	Phase I, Phase II, Phase III	Follow the standard software order process.
03.00	04.00	Yes	Phase I, Phase II, Phase III	Follow the standard software order process.

Table 38
Flash Download procedure matrix for Large Systems (Part 1 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
24.25	25.08 Re-issue	Yes	Phase I	<ol style="list-style-type: none"> 1. Call Nortel technical support to find out how to obtain any necessary upgrades. 2. Follow the PSDL Installation Procedure (see “PSDL installation” on page 267). 4. Install the manufactured patches. 5. Download the firmware to the telephones, following the Flash Download procedure.
			Phase II, Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase II and Phase III telephones on a Release 24.2x system.</p> <ol style="list-style-type: none"> 1. Follow the Large System Release 24.2x to 25.08 Re-issue procedure for Phase 1 telephones (above). <p>The Release 25.08 Re-issue contains M3900 Phase I firmware for M3902 and M3905 telephones and Phase II firmware for M3903 and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III telephones to Phase I/II firmware.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 2 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.15 Re-issue	Yes	Phase I	Follow the standard software order process.
Phase II, Phase III			<p>Note: This is not a standard process. There should not be M3900 Phase II and Phase III telephones on a Release 24.2x system.</p> <p>1. Follow the Large System Release 24.2x to 25.15 Re-issue procedure for Phase 1 telephones (above).</p> <p>The Release 25.15 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III telephones to Phase I/II firmware.</p>	

Table 38
Flash Download procedure matrix for Large Systems (Part 3 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.30	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase II and Phase III telephones on a Release 24.2x system.</p> <p>1. Follow the Large System Release 24.2x to 25.30 procedure for Phase I telephones (above).</p> <p>The Release 25.30 contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III telephones to Phase I/II firmware.</p>
	25.40, 25.40B	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase II and Phase III telephones on a Release 24.2x system.</p> <p>1. Follow the Large System Release 24.2x to 25.40/25.40B procedure for Phase I telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 4 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	03.00	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase II and Phase III telephones on a Release 24.2x system.</p> <p>1. Follow the Large System Release 24.2x to 03.00 procedure for Phase I telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>
	04.00	Yes	Phase I	Follow the standard software order process.
			Phase II, Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase II and Phase III telephones on a Release 24.2x system.</p> <p>1. Follow the Large System Release 24.2x to 04.00 procedure for Phase I telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 5 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
25.08	25.08 Re-issue	No	Phase I, Phase II	<ol style="list-style-type: none"> 1. Call Nortel technical support to find out how to obtain any necessary upgrades. 2. Follow the PSDL Installation Procedure (see “PSDL installation” on page 267). 4. Install the manufactured patches. 5. Download the firmware to telephones, following the Flash Download procedure.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.08 system.</p> <ol style="list-style-type: none"> 1. Follow the Large System 25.08 to 25.08 Re-issue procedure for Release 1 telephones (above). <p>The 25.08 Re-issue contains M3900 Phase I firmware for M3902 and M3905 telephones and Phase II firmware for M3903 and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 6 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.15 Re-issue	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.08 system.</p> <p>1. Follow the Large System 25.08 to 25.15 Re-issue procedure for Phase I/II telephones (above).</p> <p>The Release 25.15 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>
	25.30	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.08 system.</p> <p>1. Follow the Large System 25.08 to 25.30 Re-issue procedure for Phase I/II telephones (above).</p> <p>The Release 25.30 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 7 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.40, 25.40B	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.08 system.</p> <p>1. Follow the Large System Release 25.08 to 25.40/25.40B procedure for Phase I/II telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>
	03.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.08 system.</p> <p>1. Follow the Large System Release 25.08 to 03.00 procedure for Phase I/II telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 8 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	04.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.08 system.</p> <p>1. Follow the Large System Release 25.08 to 04.00 procedure for Phase I/II telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>
25.10	25.15 Re-issue	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.10 system.</p> <p>1. Follow the Large System Release 25.10 to 25.15 Re-issue procedure for Phase I/II telephones (above).</p> <p>The Release 25.15 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 9 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.30	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.10 system.</p> <p>1. Follow the Large System Release 25.10 to 25.30 Re-issue procedure for Phase I/II telephones (above).</p> <p>The Release 25.30 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>
	25.40, 25.40B	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.10 system.</p> <p>1. Follow the Large System Release 25.10 to 25.40/25.40B procedure for Phase I/II telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 10 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	03.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.10 system.</p> <p>1. Follow the Large System Release 25.10 to 03.00 procedure for Phase I/II telephones (above).</p> <p>The Releases 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>
	04.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.10 system.</p> <p>1. Follow the Large System Release 25.10 to 04.00 procedure for Phase I/II telephones (above).</p> <p>The Releases 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 11 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
25.15	25.15 Re-issue	No	Phase I, Phase II	<p>1. Determine M3900 PSWV to install (see Table 40 on page 281).</p> <p>Select PSWV #1 Global or #4 N.A. (25% savings; second PC card needed).</p> <p>Note: Select PSWV #5 (Release 1 firmware for X11 Release 24; second PC card needed) only if the customer is just running the Release 24 M3900 features.</p> <p>2. Download software from the web with appropriate PSWV language file.</p> <p>3. Follow the procedure “PSDL installation” on page 267 to install software with the selected M3900 PSWV file.</p> <p>4. Install manufactured patches.</p> <p>5. Download firmware to telephones, following the Flash Download procedure.</p>
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a 25.15 system.</p> <p>1. Follow the Large System Release 25.15 to 25.15 Re-issue procedure for Phase I/II telephones (above).</p> <p>The Release 25.15 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 12 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	25.30	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a Release 25.15 system.</p> <p>1. Follow the Large System Release 25.15 to 25.30 Re-issue procedure for Phase I/II telephones (above).</p> <p>The Release 25.30 Re-issue contains M3900 Phase I firmware for M3905 telephones and Phase II firmware for M3902, M3903, and M3904 telephones. Follow the Flash Download process to downgrade the M3900 Phase III phones to Phase I/II firmware.</p>
	25.40, 25.40B		Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a Release 25.15 system.</p> <p>1. Follow the Large System Release 25.15 to 25.40/25.40B procedure for Phase I/II telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 13 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	03.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a Release 25.15 system.</p> <p>1. Follow the Large System Release 25.15 to 03.00 procedure for Phase I/II telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>
	04.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a Release 25.15 system.</p> <p>1. Follow the Large System Release 25.15 to 04.00 procedure for Phase I/II telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 14 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
25.30	25.40, 25.40B	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a Release 25.30 system.</p> <p>1. Follow the Large System Release 25.30 to 25.40/25.40B procedure for Phase I/II telephones (above).</p> <p>The Releases 25.40 and 25.40B contain M3900 Phase III firmware for M3900 telephones.</p>
	03.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a Release 25.30 system.</p> <p>1. Follow the Large System Release 25.30 to 03.00 procedure for Phase I/II telephones (above).</p> <p>The Release 03.00 contains M3900 Phase III firmware for M3900 telephones.</p>

Table 38
Flash Download procedure matrix for Large Systems (Part 15 of 15)

Present software	Upgrade to software	Keycode required	M3900 telephones	Upgrade steps
	04.00	Yes	Phase I, Phase II	Follow the standard software order process.
			Phase III	<p>Note: This is not a standard process. There should not be M3900 Phase III phones configured on a Release 25.30 system.</p> <p>1. Follow the Large System Release 25.30 to 04.00 procedure for Phase I/II telephones (above).</p> <p>The Release 04.00 contains M3900 Phase III firmware for M3900 telephones.</p>
25.40, 25.40B	03.00	Yes	Phase I, Phase II, Phase III	Follow the standard software order process.
	04.00	Yes	Phase I, Phase II, Phase III	Follow the standard software order process.
03.00	04.00	Yes	Phase I, Phase II, Phase III	Follow the standard software order process.

Determining software, M3900 PSWV, or firmware versions

X11 software versions

Use the ISS command in LD 22 to identify X11 software versions. When trying to determine whether a system's software has been upgraded to the Reissue of 25.08 or 25.15, patches MPLR13167 and MPLR13247 must be loaded and the LD 22 ISS command must be issued. If "PSWV Version 32"

appears for X11 Release 25.08 software, the 25.08 Reissue software has been loaded. If “PSWV Version 33” appears for X11 Release 25.15 software, the 25.15 Reissue software has been loaded.

M3900 language PSWV versions

To find the M3900 Language PSWV version on Small Systems, see related procedures in *Communication Server 1000M and Meridian 1: Small System Upgrade Procedures* (553-3011-258). The system then prints the M3900 Language PSWV file version and name, which is referenced in Table 40 on page 281.

To find the M3900 Language PSWV version on Large Systems, follow the appropriate Large System procedure in *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures* (553-3021-258). When you get to the PSDL Installation menu under the Install M3900 telephone Language menu, select item 2 “List 3900 telephone languages”. The system then displays the PSDL file that is currently installed on the machine, as well as other PSWV files available to install.

An alternative procedure for both large and Small Systems is to download an M3900 telephone on the system and query the language version for that telephone through the telephone’s display diagnostics. See “M3900 firmware versions” on [page 262](#) for information on obtaining the firmware version through display diagnostics. Once the firmware version has been obtained, it can be cross referenced to the M3900 PSWV language version in Table 40 on page 281.

M3900 firmware versions

Use the FWVU command in LD 32 to obtain the firmware version of an M3900 telephone. The firmware version or language version can be found

through the display diagnostics on the M3900 telephone. You can obtain the display diagnostics through the following procedure.

Procedure 44**Displaying the M3900 Diagnostics**

- 1 Press the **Options** key on the M3900 telephone.
- 2 Scroll to the Display Diagnostics entry, using the up or down navigation keys.
- 3 Press the **Select** soft key.
- 4 Scroll to the screen that shows the language file and firmware version using the up or down navigation keys.

End of Procedure

For the latest firmware versions contained in the X11 software Reissue, refer to Table 40 on page 281. For information on firmware versions which fix particular M3900 problems, refer to Matrix G in the latest version of the M3900 Series Digital Telephone Advisory Bulletin.

The general rules for identifying which versions of firmware are Release 1 and which are Release 2 for the M3903, M3904 and M3905 telephones are as follows:

- Phase 1 firmware vintages are less than version 4.0 (<40 from LD 32 FWVU response).
- Phase 2 firmware vintages are greater or equal to version 4.0 (>= 40 from LD 32 FWVU response) but less than version 6.0 (<60 from LD 32 FWVU response).
- Phase 3 firmware vintages are greater or equal to version 6.0 (>=60 from LD 32 FWVU response).

Flash Download advisements

Since the Flash Downloading feature of the M3900 takes some bandwidth from the system signaling path while it is operating, it is recommended that downloading be scheduled in off-peak hours for best results. There is some real time impact to the system since the system processor is busy doing the

downloads. However, there is no impact to call processing, since call processing has a higher priority. Therefore, downloads take longer during peak traffic times because the system processor is busy doing call processing and cannot devote as much time to the M3900 downloads. There is no difference between Large Systems and Small Systems for this.

When a system is first brought into service with M3900 telephones, there is a significant amount of messaging that occurs to activate the telephones through the Lamp Audit background routine. The time required to bring all telephones into service on a system is dependent on the system configuration, and could take several hours. Performing a Flash Download directly after the system is brought into service adds to the message load on the system. Therefore, it is recommended that M3900 telephone download activities not occur in conjunction with systems being brought into service. Instead downloads should occur 24 hours after a system is brought into service.

If a user attempts to use a telephone during a flash download, all telephone activity is ignored.

When performing a flash download to an M3900 port that does not have a telephone installed, or downloading to an M3900 port that has the wrong M3900 telephone type installed, an SDL2110 error message is printed out at the system.

During the middle of flash download operation, if the telephone is disconnected or if the telephone fails download for any reason, the telephone is rendered inoperable. Flash downloading must run to completion before the telephone can be made operable.

For the manual individual download operation, if the telephone is not responding (is not operational) or if the telephone is not a M3900 telephone, flash download fails.

If the firmware file(s) used as the source for flash download to M3900 telephones are not present (in the proper location) on the system disks, the flash download operation fails.

While a system-wide flash download operation is in progress, attempts to disable telephones that are currently being downloaded result in an SCH1958 message that is printed with the list of telephones involved. If a loop, shelf, or

card that contains the telephones being downloaded is disabled, then the download to the telephones on that loop, shelf, or card fails.

According to the existing PSWV logic, when PSWV is in progress, an attempt to load an overlay is denied and result in an OVL0306 message.

Nortel strongly recommends that you not force load an overlay (load with a Suspend option) unless there is an emergency while PSWV is in progress. In this instance, existing PSWV logic aborts downloading for the current PSWV block (of cards or telephones of a given type being downloaded) and restarts the download for that block and remaining ones after the overlay is exited. If this happens to M3900 flash download, the block of telephones are out-of-service for a lengthy period of time and this prolongs the completion of the system-wide flash download.

If system warm-start (Initialization) or cold-start (Sysload) occurs while flash download is in progress, the download process is aborted abruptly. Any telephones which are in the middle of download fail to complete firmware download and are left inoperable. You must re-enter the single-telephone or system-wide flash download command later to restart and complete the download. For system-wide downloads, any previously scheduled telephones are no longer queued for download.

While a manual individual download operation is still in progress, do not abort LD 32 (except in an emergency) by using the **** command. If the overlay is aborted before completing the download, the telephone is left inoperable until a flash download command for the telephone is re-entered and completed at a later time.

During system wide download, you can use all overlays by issuing the ld x susp command. However, this ungracefully stops the download to the current group of telephones that are being downloaded and leaves them without firmware until the overlay is exited. The download to these telephones is then started again.

While a system-wide flash download operation is in progress:

- Service change (CHG, MOV, or OUT) to a unit that is currently being downloaded is blocked in LD 11. An SCH1958 message is printed.

- Move (MOV) or remove (OUT through LD 11 or Automatic Set Relocation) to an M3900 telephone before its flash download starts prevents download to the telephone in this cycle of system-wide flash download.
- A new M3900 telephone added (through LD 11 or Automatic Set Relocation) after the FDLS command is issued is not included in this round of system-side download.

When scheduling the Flash Download of telephones, note that one hour before the Midnight routines execute, the flash download process is gracefully stopped. The Flash downloading resumes once midnight routines are executed.

When a schedule is defined in LD 97 and the Flash Download is started (by entering the FDLS command in LD 32), all scheduled telephones are queued for download. The download process remains active in the background until the download is complete or is canceled (using the FDLC command in LD 32). If the download is active in the background (telephones not actively downloading per the scheduled download time) and the download schedule is removed in LD 97, the download begins immediately for the telephones that remain in the download queue. Use the LD x SUSP command to load an overlay when the download is active in the background (scheduled but not actively downloading telephones). It is also not possible to perform a single telephone download (FDLU, FDLI, or FDLF command from LD 32) while the download is active in the background. If an individual download is attempted in this case, the system indicates that the PSDL is not idle. If an individual telephone download is necessary while the download is active in the background, you must cancel the download in LD 32 using the FDLC command. Once the individual downloads are complete, you can restart the schedule download with the FLDS command in LD 32.

Note: If the force option is used with the FDLS command, all telephones in the original schedule are downloaded.

For M3900 telephones actively being flash downloaded when the Flash Download Cancel FDLC command is issued, the flash download to these telephones is completed before the flash download process cancels.

M3905 telephones acquired by the Symposium Call Center Server (SCCS) do not have to be de-acquired (pulled out of all queues) before the flash download is started. However, during the download, the agent using the M3905 telephone is placed in a maintenance-busy state for approximately 12 minutes. As a result, the SCCS is not able to record any agent statistics for agents using the M3905 telephones during the download. The SCCS agent reports for the interval in which the download occurred will, therefore, be inaccurate.

PSDL installation

During a flash download, the system downloads the contents of a PSDL/PSWV file to an M3900 telephone. This PSDL Installation Procedure can be used to load a new PSDL/PSWV file on the system in place of totally reinstalling system software. If there are concerns about system downtime in regards to performing software upgrades in cases where only a new PSDL/PSWV file is needed, this process allows the replacement of the PSDL/PSWV file only. For detailed information on the PSDL installation procedure, refer to *Communication Server 1000S: Upgrade Procedures* (553-3031-258).

Dynamic PSDL installation

The system supports Dynamic PSDL installation. It is no longer necessary to update all PSDL files to obtain the latest firmware. A loadware patch with new PSWV can be installed. The patch installation replaces the existing PSWV file and rebuilds the PSDL file. The new M3900 firmware files are available through the Enterprise Solutions PEP Library (ESPL) website.

Four new pdt commands support the Dynamic PSDL feature:

- -lload <loadware patch filename(s)>
 - loads one or more loadware patches on the switch.
- -lwinst <loadware patch number(s)>
 - rebuilds psdl.rec to include new loadware

- -lwout <loadware patch number(s)>
 - removes one or more loadware patches from the switch
- -lwstat <loadware patch number(s)>
 - displays status of loadware patches on switch
 - if no patch numbers given, displays all patches

The loadware patches must be located in the /u/loadware directory. Below is the example of loadware patching.

pd> lwload ger1ba50.p

Loading loadware patch from "c:/u/loadware/ger1ba50.p"
Loadware patch number is 0.

pd> lwinst 0

The existing c:/p/sl1/psdl.rec will be deleted
Do you wish to back up this file (y/n)? [n]

Loadware "GER1BA49" will be replaced by "GER1BA50"
Do you wish to continue (y/n) [y]

Building system loadware. This will take a few minutes.

...

Done. Must reboot for changes to take effect.

pd> lwstat 0

Base loadware version: 56
Number of patches installed: 1
Loadware patch number: 0
Patch file: c:/u/loadware/ger1ba50.p
Patchname: GER1 L/w
Ref. number: mplr12345
PRS number: mp12345
Engineer: DE
Created: Mon Feb 5 10:47:25 2001

Patch is loaded & installed
Install date: Mon Feb 5 11:15:20 2001

pdt> lwout 0

Loadware patch 0 has been removed successfully.
System loadware must now be re-built.

Detailed Flash Download procedure

- 1 Identify telephones to be downloaded. If possible, organize by Telephone type, TN Range, or DN Range. To determine telephone quantity and type, use LDs 97 and 32 to print the ranges of telephones using the commands given below.
- 2 Establish telephone quantity.
- 3 Estimate the time required for download. Downloading telephones with the North America reduced language set file takes nine minutes per telephones (on the M3905 it takes 12 minutes). Language sets other than the North America reduced language set file take 12 minutes to download. On Small Systems, you can download four sets in parallel. On Large Systems, you can download one set per XPEC in parallel, up to a maximum of 8 on CP4 and 31 on CPP.

The following formulas provide estimates of download times:

— Small System — North American 6 Language file:

$((\text{Quantity of M3902, 3, 4} \times 9 \text{ minutes}) + (\text{quantity of M3905} \times 12 \text{ minutes})) / 4$, where 4 details the number of sets that can be downloaded in parallel.

— Small System — Global 10 Language file:

$(\text{Quantity of M3902, 3, 4, 5} \times 12 \text{ minutes}) / 4$, where 4 details the number of sets that can be downloaded in parallel


- Large System — North America 6 Language file:
((Quantity of M3902,3,4 x 9 minutes)+(quantity of M3905 x 12 minutes))/ number of XPECs (assuming even distribution of sets)
- Large System — Global 10 Language file:
((Quantity of M3902,3,4,5 x 12 minutes))/ number of XPECs (assuming even distribution of sets)

- 4 Based on the quantity of telephones and the site situation, determine how the download will occur:
 - a Individual downloads (Use individual commands in LD 32)
 - b System download (Use system download command in LD 32)
 - c Scheduled download/range download (Use scheduled download commands in LD 32 and LD 97)
- 5 Issue the appropriate download command.
- 6 As the download occurs, the telephone displays the following information:

During a flash download, the M3902, M3903, and M3905 telephones display messages on the displays at the right. (See Figure 43 on page 271) Display 1 shows the “Erasing Flash Memory” message along with blocks written to the second line (each with decreasing contrast). This is followed by Display 2 that reads “Awaiting Download.” Display 3 flashes the text “Downloading Firmware” on the first line with progress bars on the second line.

When all 24 segments of the progress bars are displayed as shown, the download is complete. The telephone then resets and returns to service. All user-controlled parameters, such as screen contrast, volume settings, and key labels are not affected by the firmware download. In the event that the firmware download was not successful, the text “Terminal Out of Service is displayed on the first line. In some cases, the telephone erases the flash memory, showing Display 1 followed by Display 2.

Figure 43
Information displayed during a flash download



For the M3904, an hourglass icon is displayed during the flash memory erase process (see Figure 44). The erase process can take up to 15 seconds.

Figure 44
Hourglass icon



After a successful memory erase, an icon showing a stack of disks (left side of the display) and a phone icon (right side of the display) are displayed (see Figure 45). These icons remain on the display during the entire download.


Figure 45
Stack of disks and telephone icons



Upon receiving the first flash data packet, a page status bar is displayed (see Figure 46). Depending on the language files being downloaded, there are three or four memory pages that are downloaded (three for North American, four for Global, Eastern/Western European versions). As additional flash data packets are received, the status bar advances to the right until the current page is completely programmed.

Once the next page starts to download, a new page block is displayed and the status bar starts from the left again. This process is repeated for the remaining pages. If the download was unsuccessful, the telephone displays a telephone icon with an X through it. This indicates that the flash memory is not programmed (or is corrupt) and a new download must be initiated.

Figure 46
Status bar



Upon completion of the flash download (all 3/4 pages have been received), the telephone verifies the flash memory contents before displaying the IDLE screen. The IDLE screen consists of the Date (Jan. 1 12:00am) and the brandline (Nortel or customer programmed logo). Up to 25 seconds later, the switch downloads all the parameters to the telephone and the IDLE screen is updated according to the switch settings (for example, soft keys are shown, date is updated, and soft label keys are shown).

- 7 As the download occurs, various messages can appear on the system terminal. A complete list of these messages is in *Software Input/Output: System Messages* (553-3001-411).

For each telephone that downloads successfully, the following will print:

SDL000 hw a v m

where hw = telephone type, a = Terminal Number (TN),
v = version, m = Mode.

For each telephone that fails to download, the following will print:

SDL2110 e hw a v m

where e = reason code, hw = telephone type, a = TN, v = version,
m = Mode.

For example:

**SDL2110 REASON 21, 3903(40 0 4 6), VERSION 84, BKGD
MODE**

e (reason code, cause of the error) can be:

- 1 = Time-out error
- 2 = PSW checksum error
- 3 = Record checksum error
- 4 = Record format error
- 5 = Firmware state error
- 6 = Invalid page number received
- 7 = Unrequired page delivered during download
- 18 = Flash memory cannot be erased
- 19 = Error detected while programming flash
- 20 = An application is currently active, download cannot proceed
- 21 = Verification byte incorrect

hw (telephone type) can be:

390x (M3900 telephone model: one of 3902, 3903, 3904, 3905)

a (address — TN) can be:

M390x telephone TN (LSCU: loop, shelf, card, unit)

v is the PSW version

m (Mode) scan be:

FAST MODE (from initialization)

MAINT MODE (by ENLL command in LD 30)

BKGD MODE (second attempt after initialization from background program)

Procedure notes:

- For Symposium Call Center Server (SCCS) sites, you do not have to de-acquire telephones from the SCCS (pulled out of all queues); however, the statistics might not be valid.
- To downgrade an M3900 telephone from Release 2 firmware to Release 1 firmware, or to change the language file from North American to another language file (or vice versa) use PSWV File #5 from Table 40 on page 281.
- For the downgrades procedure and language changes, refer to the appropriate upgrade procedures NTP:
 - *Communication Server 1000M and Meridian 1: Large System Upgrade Procedures (553-3021-258)*
 - *Communication Server 1000M and Meridian 1: Small System Upgrade Procedures (553-3011-258)*
 - *Communication Server 1000S: Upgrade Procedures (553-3031-258)*
 - *Communication Server 1000E: Upgrade Procedures (553-3041-258)*

Configuration parameters in LD 32

To use the Flash Download capability, load LD 32 and issue the following commands.

Single-Set Flash Download

Flash DownLoad Unit (FDLU) - Initiate flash download for this unit. For this command to work, the telephone must be in an idle state. That is, there

can be no active call, no active application, and the telephone must be configured and in working condition (responding to a query command). Also, the firmware version on the telephone must not be current. That is, it must be different from the one on the system disk.

. FDLU l s c u

l = loop address
s = shelf address
c = card address
u = unit address

Flash DownLoad Idle (FDLI) - Initiate flash download as soon as the telephone is idle. For this command to work, the telephone must be in working condition. If the telephone is idle, the downloading occurs immediately. If the telephone is on an active call, downloading occurs immediately after the call is terminated. However, if after the active call is terminated, there is an active application on the telephone, downloading is aborted. Again, the downloading operation occurs only if the version on the telephone is not current.

. FDLI l s c u

Flash DownLoad Forced (FDLF) - Initiate flash download immediately. For this command to work, the telephone must be in working condition. If the telephone is idle, the downloading occurs immediately. If the telephone is on an active call, the call is force disconnected and then downloading occurs immediately after the disconnect. It also force downloads the system disk version even if the telephone firmware version is more current. However, if there is an application active on the telephone, the downloading operation is aborted.

. FDLF l s c u

System-wide Flash Download

To prepare and trigger the flash download for the whole system manually, access LD 32 and issue the following commands.

Flash Download System (FDLS) - Initiate system-wide flash download based on the parameters specified in LD 97. This initiates the system-wide flash download to all, or the specified type of M3900 telephones, from the system disk if the flash firmware version on the telephone is different from the version found on the disk.

During system-wide flash download, when flash download detects that an M3900 telephone is in an active call connection, the telephone is skipped. Download logic keeps track of skipped telephones, and comes back to attempt the download later.

M3900 flash download attempts download to each telephone up to three times. If download does not succeed by the third attempt (whether due to an active call connection or some problem such as a transmission error), flash download to the telephone is considered to have failed. An appropriate message is displayed for each telephone that fails the firmware upgrade process. Upon completion of system-wide flash download, a completion message is displayed on the maintenance telephone. This operation can take up to several days to complete depending on the traffic load, the total number and distribution of the equipped M3900 telephones, and the scheduling of the download. See Table 39 on page 277 for estimations on download times.

When M3900 telephones fail system-wide flash download, you can then determine the cause of the failure, perform corrective action, and repeat the flash download command – system-wide or for a specific telephone.

.FDLS

Flash Download Cancel (FDLC) - Cancel the system-wide flash download. From LD 32 or outside of the overlays, you can cancel or stop the system-wide flash download operation gracefully by issuing the FDLC command. A download in progress to the current telephone(s) completes before the download process terminates.

.FDLC

Table 39 shows the estimated Flash Download times.

Table 39
Estimated Flash Download times

System	Average Lines	M3900 Lines	Download Time 10 languages	Faster Download 6 languages
Small System	100	80 (100%)	4 hours	3 hours
Single Group	400	200 (~60%)	20hrs. (2 XPECs) 10hrs. (4 XPECs)	15 hours 7.5 hours
Multi Group	1350	650 (~60%)	22 hrs. (6 XPECs)	16.5
MSL-100	8000	4800 (~60%)	30 hrs. (32 XPECs) 20 hrs. (48 XPECs)	22.5 hours 15 hours

The following assumptions apply to Table 39:

- 20% trunking on all systems
- 100% M3900 telephones on Small Systems
- 60% M3900 telephones on Large Systems
- The Faster Download is based on using the North American language files for the M3902, M3903, and M3904 (PSWV File #4 is shown in Table 40 on page 281), which are 25% smaller than the Global language files. Therefore, they take 25% less time to download. The languages that are missing from the North American reduced language file are: Swedish, Italian, Norwegian, and Finnish. The languages contained in the North America reduced language file are: English, French, German, Spanish, Brazilian Portuguese, and Japanese Katakana.

Commands for LD 32 are shown below.

LD 32 – Flash Download commands (Part 1 of 2)

Command	Description
FDLU I s c u	Initiate conditional download to one telephone. Terminal number, where: I = loop, s = shelf, c = card, u = unit
FDLI I s c u	Initiate conditional download to an M3900 Series telephone when it becomes idle.
FDLF I s c u	Initiate a forced download to an M3900 Series telephone regardless of its version and state.
FWVU I s c u	Query and print the firmware versions currently on an M3900 Series telephone.
FDLS	Initiate system-wide Flash Download to all, or a specified type of M3900 Series telephones, based on parameters specified in LD 97.
FDLC	Cancel or gracefully stop the system-wide flash download for M3900 Series telephones.

LD 32 – Flash Download commands (Part 2 of 2)

Command	Description
FSUM	<p>Display the summary report of current firmware versions on all M3900 Series telephones.</p> <p>The format of the report is as follows:</p> <pre> ** M390x SUMMARY REPORT ** dd - ON DISK ff (cc) - nnnn SETS FOUND ff (cc) - nnnn SETS FOUND </pre> <p>Where:</p> <p>x = 2 to 5 for M3902 to M3905 dd = the flash firmware version found on the system disk ff = the downloadable flash firmware version found on the telephones cc = the core firmware found on the telephones nnnn = the number of telephones found with firmware version ff (cc)</p>
FSUM ALL	<p>Display a complete report on all M3900 series telephones based on parameters specified in LD 97.</p> <p>The format of the report is as follows:</p> <pre> TYPE: tttt CUST: cc PDN: dddddd TN: l s c u FW: vv </pre> <p>Where:</p> <p>tttt = 3902, 3903, 3904 or 3905 cc = 0-99 dddddd = the Primary DN of the telephone vv = the flash firmware version</p>

Print Firmware Versions on M3900 Telephones

To determine the firmware version information on M3900 telephones, use the following commands in LD 32:

Firmware Version on Unit (FWVU) - Print current firmware versions on the unit. You can query and print the firmware versions (downloadable flash firmware, as well as core firmware) currently on the specified telephone using

this command. See Table 40 on page 281 for a list of current firmware versions.

.FWVU l s c u

Firmware version SUMmary (FSUM) - Print the firmware version summary report for all the M3900 telephones. This command prints the M3900 firmware versions found on the system disk and lists every version together with a count of M3900 telephones that are found to have this version.

.FSUM

The format of the report is as follows:

```
**M390x SUMMARY REPORT**  
dd - ON DISK  
ff (cc) - nnnn SETS FOUND  
ff (cc) - nnnn SETS FOUND
```

Where:

x = 2 to 5 for M3902 to M3905
dd = the flash firmware version found on the system disk
ff = the downloadable flash firmware version found on the telephones
cc = the core firmware found on the telephones
nnnn = the number of telephones found with firmware version ff (cc)

Firmware version SUMmary ALL (FSUM ALL) – Displays a complete report on all M3900 Series telephones based on the parameters in LD 97.

.FSUM ALL

The format of the report is as follows:

```
TYPE: ttt CUST: cc PDN: ddddddd TN: l s c u FW: vv
```

Where:

tttt = 3902, 3903, 3904, 3905
cc = 0-99

dddddd = the Primary DN of the telephone

vv = the flash firmware version

Query Disk Firmware Versions

To determine the firmware version residing on the system disk(s) available for download to the M3900 telephones, use the PSWV command in LD 22 to print the firmware versions for M3900 telephones. See Table 40 on page 281 for a list of current firmware versions.

Table 40
Firmware and PSWV versions (Part 1 of 2)

PEC codes	PSWV codes				F/W codes	
	2	3	4	5	6	7
M3900 telephone (## = 66, 70) XX = See Note 1	PSWV File	PSWV Region	M1 F/W file (PSWV) See Note 2	LD 22 Response for PSWV See Note 3	Set F/W Diagnostic See Note 4	LD 32 FWVU Response for telephone F/W See Note 5
M3902						
NTMN32 XX-##	PSWV File #1	Global (10 lang.)	3902.loadaa 84	M3902: S/W VERSION NUMBERS: 84	Lang: L1.9 F/W Ver: 8.4	FLASH FIRMWARE VERSION = 084
	PSWV File #4	N. America (6 lang.)	3902.loadda 84	M3902: S/W VERSION NUMBERS: 84	Lang: L4.9 F/W Ver: 8.4	FLASH FIRMWARE VERSION = 084
M3903						
NTMN33 XX-##	PSWV File #1	Global R2: (10 lang.)	3903.loadaa 87	M3903: S/W VERSION NUMBERS: 84	Lang: L1.9 F/W Ver 8.7	FLASH FIRMWARE VERSION = 087

Table 40
Firmware and PSWV versions (Part 2 of 2)

PEC codes	PSWV codes				F/W codes	
1	2	3	4	5	6	7
	PSWV File #4	N. America R2 (6 lang.)	3903.loaddaa 87	M3903: S/W VERSION NUMBERS: 87	Lang: L4.9 F/W Ver 8.7	FLASH FIRMWARE VERSION = 087
NTMN33 XX-##	PSWV File #5	Rel. 1 for X11 Rel 24	3903.loadaa 36	M3903: S/W VERSION NUMBERS: 36	Lang: P1.9 F/W Ver 3.6	FLASH FIRMWARE VERSION = 036
M3904						
NTMN34 XX-##	PSWV File #1	Global R2: (10 lang.)	3904.loadaa 89	M3904: S/W VERSION NUMBERS: 89	Flash: 8.9 P0 L1.8	FLASH FIRMWARE VERSION = 089
	PSWV File #4	N. America R2 (6 lang.)	3904.loaddaa 89	M3904: S/W VERSION NUMBERS: 89	Flash: 8.9 P0 L4.8	FLASH FIRMWARE VERSION = 089
NTMN34 XX-##	PSWV File #5	Rel. 1 for X11 Rel 24	3904.loadaa 34	M3904: S/W VERSION NUMBERS: 34	Flash: 3.4 P0 L1.8	FLASH FIRMWARE VERSION = 034
M3905						
NTMN35 XX-##	PSWV File #1	Global (10 lang.)	3905.loadaa 89	M3905: S/W VERSION NUMBERS: 89	Lang: L1.9 F/W Ver 8.9	FLASH FIRMWARE VERSION = 089
	PSWV File #4	N. America (10 lang.)	3905.loadaa 89	M3905: S/W VERSION NUMBERS: 89	Lang: L1.9 F/W Ver 8.9	FLASH FIRMWARE VERSION = 089

The following notes apply to Table 40.

Note 1: For Column 1 labeled *M3900 Telephone*, XX is a two-letter alpha character that is part of the product code. For instance, a product code of NTMN32AB is a later issue than a code of NTMN32AA. Release 1 M3900 telephones all started with a “BA” designation for U.S. and Canada telephones, and “AA” for Canada only icon sets. Release 2 M3900 telephones all started with a “FA” designation for U.S. and Canada telephones and “EA” for Canada only icon sets.

Note 2: For Column 4 labeled *M1 F/W File*, the two-letter alpha character followed by two numbers (format: 390x.loadxx##) shows the release level of the PSWV file. For instance, M3902.loadaa40 is a later issue than M3902.loadaa36. The most up-to-date file names are shown.

Note 3: For Column 5 labeled *LD 22 Response for PSWV*, the two number code is the firmware version release level. The larger the number, the newer the version. The last two digits correspond to the same version number as the M3900 firmware version. For instance, M3903: S/W VERSION NUMBERS: 51 is equivalent to M3900 F/W Version 5.1. The most current versions are shown.

Note 4: Column 6, labeled *Set F/W Diagnostic*, shows the language file in use and the firmware level of the set, as seen on an M3900 display. The larger the number, the newer the version. The latest versions are shown. To view the firmware level of an M3900 telephone, press the Options key, scroll to the Display Diagnostics entry, and press Select. Use the Down Navigation key to get to the screen that shows the language file and firmware version.

Note 5: For Column 7 labeled *LD 32 FWVU Response for Telephone F/W*, the three-digit number shows the firmware version of the telephone. The larger the number, the newer the version. For example, a number of 040, refers to a firmware version of 4.0. The latest versions are shown.

Commands for system-wide Flash Download of M3900 telephones

LD 97 – Configure parameters for System-wide Flash Download. (Part 1 of 4)

Prompt	Response	Description
REQ	CHG PRT	Change Flash Download parameters. Print Flash Download parameters.
TYPE	FDL	Flash Download for M3900 telephones.
FDTP		Enter M3900 telephone type selected for Flash Download.
	3902	M3902 telephone
	3903	M3903 telephone
	3904	M3904 telephone
	3905	M3905 telephone
	ALL	All of the above
	(NONE)	None of the above (default)
FDTM		Time interval restriction for Flash Download.
	(NO)	Do not change time intervals (default).
	YES	Proceed to change time intervals.
		Note 1: Flash Download is automatically paused one hour before virtual midnight (see TODR in LD 17) to allow midnight routines to run.
		Note 2: This option is not applicable to reporting.

LD 97 – Configure parameters for System-wide Flash Download. (Part 2 of 4)

Prompt	Response	Description
FDAY	d n	<p>Enter day and number of time intervals for Flash Download, where:</p> <p>d = day of the week (0-6 for Sunday to Saturday) n = number of time intervals (0-4)</p> <p>To disallow download for the day, enter 0.</p> <p>Day is re-prompted until you enter a Carriage Return, <CR>.</p> <p>Note 1: This prompt appears only if FDTM = YES.</p> <p>Note 2: If two or more intervals are specified, they must be overlapping, non-consecutive, and in order.</p>
FINT	s l	<p>Enter starting hour and length for a time interval, where:</p> <p>s = starting hour (0-23) l = length of interval in hours (1-24)</p> <p>Note: FINT is prompted <i>n</i> time if <i>n</i> is greater than 0.</p>
FTNR	(NO) YES	<p>TN range restriction option for Flash Download.</p> <p>No TN restriction (default) Specify TN range.</p>
FSTN	l s c u c u	<p>Starting Terminal Number for Flash Download. Prompt appears only if FTNR = YES.</p> <p>Format for Large System and CS 1000E system, where l = loop, s = shelf, c = card, u = unit.</p> <p>Format for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T, where c = card and u = unit.</p>

LD 97 – Configure parameters for System-wide Flash Download. (Part 3 of 4)

Prompt	Response	Description
FETN	l s c u	Ending Terminal Number for Flash Download. Prompt appears only if FTNR = YES. Format for Large System and CS 1000E system, and Media Gateway 1000E, where l = loop, s = shelf, c = card, u = unit.
	c u	Format for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T, where c = card and u = unit.
FDNR	(NO) YES	DN range restriction option for Flash Download. No DN restriction (default). Specify DN range.
FDDN	c d1 d2	Flash Download Prime Directory Number range, where: c = Customer number (0-99) d1 = starting Prime DN d2 = ending Prime DN Note: Prompt appears only if FDNR = YES.

LD 97 – Configure parameters for System-wide Flash Download. (Part 4 of 4)

Prompt	Response	Description
FRCE	(NO) YES	<p>System-wide Flash Download control option.</p> <p>Conditional (default). System-wide Flash Download (using the FDLS command in LD 32) applies only to an M3900 series telephone whose flash firmware version is different from the version currently found on the system disk.</p> <p>Forced. Force System-wide Flash Download to all of the specified M3900 series digital telephones regardless of their current flash firmware versions.</p> <p>Note 1: Use this option with caution. Once the download tree is built (that is, after executing FDLS in LD 32), this option automatically reverts to NO.</p> <p>Note 2: This option is not applicable to reporting.</p>
FVER	0-99	<p>Flash firmware version specified for full report, where: If 0, report all versions (default).</p> <p>Note: This option is applicable to reporting only (through the FSUM ALL command in LD 32).</p>

Digital telephones line engineering

Contents

This section contains information on the following topics:

Engineering a telephone line	290
Selecting a Loop	299
Calculating DC Loop Resistance	299
Performing Loop Diagnostic Tests	300
Measuring Impulse Noise	302
Measuring Background Noise	302
Calculating Expected Pulse Loss	302
Measuring DC Loop Resistance	306

Engineering a telephone line

Use Procedure 45 on [page 290](#) to engineer a digital telephone line.

Procedure 45

Engineering a telephone line

- 1 Be sure that cable pair selections meet the following requirements:
 - AC signal loss is less than 12 dB at 256 kHz due to all sources.
 - DC loop resistance is less than 175 ohm.
 - Minimum loop length (mainframe bulkhead to telephone) is 30 m (100 ft).
 - Near-end crosstalk coupling loss is >38 dB at Nyquist frequency of 256 kHz (not an issue for typical 22, 24, and 26 AWG twisted pair cable).
 - No bridge taps are permitted.
 - No loading coils are permitted.
 - Protection devices of the carbon-block and gas-filled type are permitted if the off-state shunting impedance is better than 10 M Ω resistive and less than 0.5 pF capacitive.

- 2 Be sure that the following criteria are met where under-carpet cabling is used:
 - Characteristic impedance is at 256 kHz, 100 \pm 10 ohm.
 - Insertion loss is at 256 kHz, <4.6 dB/kft.
 - The next pair-to-pair coupling loss is at 256 kHz, >40 dB.

- 3 For a typical system with 22, 24, or 26 AWG standard twisted-pair cable, the requirements translate to the following allowable loops:
 - up to 915 m (3000 ft) of 22 or 24 AWG cable
 - up to 640 m (2100 ft) of 26 AWG cable

- 4 If the selected cable pair does not work satisfactorily, select another cable pair as shown in Figure 47.

End of Procedure

Figure 47
Engineer a telephone line (Part 1 of 8)





Figure 47
Engineer a telephone line (Part 2 of 8)



553-AAA2054

Figure 47
Engineer a telephone line (Part 3 of 8)





Figure 47
Engineer a telephone line (Part 4 of 8)



553-AAA2056

Figure 47
Engineer a telephone line (Part 5 of 8)




Figure 47
Engineer a telephone line (Part 6 of 8)




Figure 47
Engineer a telephone line (Part 7 of 8)





Figure 47
Engineer a telephone line (Part 8 of 8)



Selecting a Loop

For a Meridian digital telephone, the loop must be without bridge taps, less than 175 ohm DC resistance, and less than 12.0 dB loss at 256 kHz. For single-gauge 22 and 24 AWG cable, and D inside wiring, the length limit is 914.4 m (3000 ft). For single-gauge 26 AWG cable, the length limit is 640.08 m (2100 ft).

The allowable loop length assumes there is no under-carpet cable. If there is under-carpet cable that is a different type than Western Electric (WE) 4-pair cable, reduce the allowable loop length by using the following equation:

$$LM = [12 - (UC \times UL)] / LL$$

where:

- LM = loop length limit in km (kft) (excluding the length of the under-carpet cable)
- LL = loop loss in dB/km (dB/kft) at 256 kHz
- UC = length of the under-carpet cable in km (kft)
- UL = loss of the under-carpet cable in dB/km (dB/kft) at 256 kHz (see Table 43 on [page 306](#) for dB values)

Calculating DC Loop Resistance

Use Procedure 46 to calculate the DC loop resistance.

Procedure 46 Calculating DC loop resistance

- 1 Calculate the DC loop resistance by adding the resistance of each cable section. Calculate the resistance of each cable section by using the following formula (cable resistances are given in Table 41 on [page 300](#)):

$$LR_i = CR_i \times SL_i$$

where:

LR_{*i*} = DC resistance for cable section *i*

CR_{*i*} = conductor resistance per unit length for the cable section *i*

SL_{*i*} = length of cable section *i*

- 2 Add the total of all cable sections. If the total of all sections exceeds 175 ohm, select another loop.

Note: The loop resistance limit of 175 ohm must be reduced by 1 ohm for each percent of the loop that is aerial cable (see Table 41 on [page 300](#)).

Table 41
Conductor resistance per unit

Gauge	Ohm per loop kft	Ohm per loop km
26	83	278
24	52	173
22	33	109
19	16	54

Performing Loop Diagnostic Tests

The following equipment is required for the loop diagnostic tests in Procedure 47 on [page 300](#):

- one volt-ohmmeter (VOM) for each test
- one 77 cable analyzer or equivalent for each test

Procedure 47 **Testing foreign voltage**

- 1 Set the VOM range switch to a scale 60 V DC/V AC or greater.
- 2 Connect the VOM test probes to the loop at the line card or distributing frame.
- 3 Measure the DC and AC voltage between the following points under no-load conditions:
 - tip (T) and ring (R)
 - T and ground (GND)
 - R and GND

Requirement: Voltage readings should be less than 1 V DC/V AC.

Procedure 48**Testing insulation resistance**

- 1 Set the VOM range switch to ohm x 10,000 and adjust the meter to zero.
- 2 Connect the VOM test probes to the loop at the line card or distribution frame.
- 3 Measure the resistance between the following points under no-load conditions:
 - T and R
 - T and GND
 - R and GND

Requirement: Resistance readings must be greater than 10 M ohm.

Procedure 49**Testing DC continuity**

- 1 Short circuit the T and R at the far end.
- 2 Using the VOM, measure the resistance between the T and R.

Requirement: Resistance measurement should be approximately equal to the calculated loop resistance as described in Procedure 46 on [page 299](#).

Procedure 50**Testing capacitance unbalance**

- 1 Using the cable analyzer, measure the capacitance between the following points:
 - T and GND
 - R and GND

Requirement: The difference between the two readings must be <0.002 μ F>.

Measuring Impulse Noise

Use Procedure 51 on [page 302](#) to measure impulse noise.

Procedure 51 **Measuring impulse noise**

- 1 Measure impulse noise on selected lines during busy hours. Use an NE-58B noise measurement set or the equivalent.

Note: The termination and weighting filter required are 135 ohm and 100 kHz, respectively, and the blanking interval is 25 μ s.

- 2 Using Figure 48, determine that for a given loop loss and noise threshold the impulse noise counts for each 15-minute interval are below the corresponding curve.

Note 1: The values in Figure 48 were derived by assuming that the counter has a count rate of 512 pulses per second.

Note 2: Because of the inaccuracy of the noise-measuring set, additional errors can occur during the blanking interval, and the reading consequently is lower than the actual measurement.

Measuring Background Noise

Use Procedure 52 on [page 302](#) to measure background noise.

Procedure 52 **Measuring background noise**

- 1 Measure background noise on the loop by using an NE-58B noise-measuring set.


Note: The weighting and termination to be used are 100 kHz flat and 135 ohm, respectively.

- 2 Reject the loop being tested if the measured background noise is not less than 51 dBm.

Calculating Expected Pulse Loss

Use Procedure 53 on [page 304](#) to calculate expected pulse loss.

Figure 48
Maximum allowable impulse noise counts versus loop loss



Procedure 53
Calculating expected pulse loss

- 1 Collect loop makeup data between the line card and the terminal. For each cable section, the data required is:
 - cable type (PIC or pulp)
 - gauge
 - length
 - type of plant construction (underground, aerial, or in-building)
- 2 Calculate individual cable section losses by using the figures in Table 42 on [page 305](#) through Table 44 on [page 306](#), and the following equation:

$$CSLi = SLi \times Li$$

- CSLi = cable section loss for section *i*
- SLi = section length of section *i*
- Li = loss per unit length for section *i*

- 3 Correct individual cable section losses for maximum cable temperature by using the following equation:

$$TCLi = CSLi \times TCFi$$

- TCLi = temperature corrected loss for section *i*
- TCFi = temperature correction factor for section *i*

Correction factors:

- aerial cable TCF = 1.1
- underground cable TCF = 1.04
- in-building cable TCF = 1

- 4 Determine junction loss (see Figure 49).

Note: Junction loss due to gauge discontinuity of outside plant cables and D inside wire varies between 0.03 dB and 0.07 dB and can be ignored. However, AMP 25-pair under-carpet wiring has a characteristic impedance of 40 ohm at 256 kHz, and its junction loss is approximately 2 dB. This must be included in the calculation.

- 5 Calculate the expected pulse loss (EPL) by finding the sum of the items.

6 Reject loops whose expected pulse loss is greater than 12 dB.

Example of applying Procedure 53

Section 1:

Mainframe bulkhead to DF1 - 500m, 26 AWG PIC, underground

Section 2:

DF1 to DF2 - 200m, 26 AWG PIC, inside

Section 3:

DF2 to terminal - 24 AWG NT D-inside

Therefore:

SL1 = 1.5 km, SL2 = 0.2 km, SL3 = 0.1 km

From Table 42 on [page 305](#) and Table 43 on [page 306](#):

L1 = 13.7 dB/km, L2 = 13.7 dB/km, L3 = 13.3 dB/km.

Using the equation in Step 2, we arrive at the following:

CSL1 = 6.85 dB, CSL2 = 2.74 dB, and CSL3 = 1.33 dB

Temperature corrections:

Using correction factors of TCF1 = 1.04, and TCF2 and TCF3 = 1, and using the equation in Step 3 results in TCL1 = 7.12 dB, TLC2 = 2.74 dB, and TCL3 = 1.33 dB.

Expected pulse loss (EPL) value:

Neglecting any junction loss (see the note in Step 4), Step 5 results in an EPL value of TSL1 + TSL2 + TSL3 + 0 = 11.19 dB.

This is under the 12 dB limit and meets the criteria.

Table 42
Cable attenuation at 256 kHz and 21.1 degrees C (70 degrees F)

Cable type	26 AWG		24 AWG		22 AWG		19 AWG	
	dB/kft	dB/km	dB/kft	dB/km	dB/kft	dB/km	dB/kft	dB/km
PIC	4.2	13.7	3.1	10.2	2.5	8.1	1.7	5.6
Pulp	4.3	14.3	3.5	11.4	2.7	9.0	2.0	6.6

Table 43
Attenuation at 256 kHz for U/C cable

WE 4-pair		AMP 25-pair	
dB/kft	dB/km	dB/kft	dB/km
4.6	15.3	19.0	63.3

Table 44
Attenuation at 256 kHz for D inside wiring cable


NT		WE		Superior		General	
dB/kft	dB/km	dB/kft	dB/km	dB/kft	dB/km	dB/kft	dB/km
4.0	13.3	3.2	10.7	3.7	13.3	4.6	15.3

Measuring DC Loop Resistance

Measure DC loop resistance by using standard procedures.

Note: The DC loop resistance limit of 175 ohm should be reduced by 1 ohm for each one percent of the total loop that is aerial cable.

Figure 49
Junction loss versus cable characteristic impedance



Analog (500/2500-type) telephones

Contents

This section contains information on the following topics:

Introduction	309
Installation and removal	309
Designate 500-type telephones.	310
Designate 2500-type telephones.	312
Connect the telephones.	312
Cross-connect the telephones.	313
Cross-connect the telephones.	313
Operation.	320

Introduction

Analog (500/2500-type) telephones are regular telephones not normally associated with a business environment, but they are compatible with the system. They are configured using LD 10. The 500-type telephones have a rotary dial. The 2500-type telephones are the basic push-button models, such as the Link and Unity, which do not have feature buttons normally found on business telephones.

Installation and removal

Follow the steps in Procedure 54 to install an analog (500/2500-type) telephone.

Note: Do not remove the circuit card if any remaining units on the card are assigned.

Procedure 54
Installing an analog (500/2500-type) telephone

- 1 Ensure that the wiring is installed at the telephone's location.
- 2 Unpack and inspect the telephone for damage. Assemble the handset and line cords if necessary.
- 3 Install the required designations on the telephone.
- 4 Connect the telephone to the TELADAPT connector.
- 5 Cross-connect the telephone wiring at the cross-connect terminal.
- 6 Configure the telephone in the system. Refer to the *Software Input/Output: Administration* (553-3001-311).

End of Procedure

Follow the steps in Procedure 55 to remove an analog (500/2500-type) telephone.

Procedure 55
Removing an analog (500/2500-type) telephone

- 1 Remove telephone data from the system. Refer to the *Software Input/Output: Administration* (553-3001-311).
- 2 Disconnect the telephone from the TELADAPT connector.
- 3 Pack the telephone in a container.
- 4 If necessary, remove the cross-connections for the telephone at the cross-connect terminal.
- 5 Remove the line circuit card if required. Refer to *Circuit Card: Description and Installation* (553-3001-211).

End of Procedure

Designate 500-type telephones

Follow the steps in Procedure 56 to designate analog 500-type telephones:

Procedure 56
Designating 500-type telephones

- 1 Remove the finger wheel (refer to Procedure 57 on [page 311](#)).
- 2 Remove the number card from its envelope.
- 3 Designate the number card with the appropriate directory number and station designator.
- 4 Insert the number card into the finger wheel (making sure the number card is properly oriented).
- 5 Place the telephone on a flat surface.
- 6 Place the finger wheel over the clamp on the dial, with the "0" hole directly over the digit "9," making sure the finger wheel depressions are properly positioned on the prongs of the clamp plate.
- 7 Rotate the finger wheel counterclockwise until the clamp spring snaps into the notch on the underside of the finger wheel.

End of Procedure

Follow the steps in Procedure 57 to remove the finger wheel from 500-type telephones.

Procedure 57
Removing the finger wheel from analog 500-type telephone

- 1 Place the telephone on a flat surface.
- 2 Rotate the finger wheel clockwise as far as possible.
- 3 Insert a paper clip into the small hole between the digits "9" and "0" located on the edge of the grooved section of the finger wheel.
- 4 Press down on the releaser to disengage the finger wheel clamp spring.
- 5 Rotate the finger wheel further clockwise until the clamp spring releases.
- 6 Remove the finger wheel when it becomes loose. The dial returns to normal position.

End of Procedure

Designate 2500-type telephones

Follow the steps in Procedure 58 on [page 312](#) to designate 2500-type telephones.

Procedure 58

Designating analog 2500-type telephone

- 1 The designation window is located directly below the dial pad. Insert a paper clip into the hole at the left or right end of the designation window.
- 2 Gently pry the window toward the center and remove.
- 3 Insert number tag with the appropriate directory number and station designator, and replace the designation window.

————— **End of Procedure** —————

Connect the telephones

Follow the steps in Procedure 59 to connect analog (500/2500-type) telephones.

Table 45 on [page 313](#) lists the NE-500/2500 telephone connections.

Procedure 59

Connecting analog (500/2500-type) telephones

- 1 Ensure that the terminal connector is compatible with the telephone connector.
- 2 Connect the telephone mounting cord.
TELADAPT cords (NE-625F connector) do not require terminations. Insert the plastic connector on the end of the telephone mounting cord into the NE-625F-type receptacle.
- 3 Connect the mounting cord to an NE-284-74-5001 Amphenol adapter if re-using a 16- or 25-pair cable. Plug the adapter into the cable connector. Fasten the connector together with the screws provided at the end of each connector.

————— **End of Procedure** —————

Table 45
NE-500/2500 telephone connections

Mounting cord	NE-47QA or QBBIB block designation	NE-284-74-5001 designation	Cable color pairs (16 to 25 not used)	Connect to TN
TIP (green)	G	1T	W-BL	TIP
RING (red)	R	1R	BL-W	RING
GND (yellow)	BK	X2		
	Y	X1		

Cross-connect the telephones

Be sure to connect the telephones as shown in Figure 50 on [page 315](#).

Figure 50 on [page 315](#) provides the diagram for cross-connecting analog (500/2500-type) telephones on an Intelligent Peripheral Equipment (IPE) module.

Table 46 on [page 316](#), Table 47 on [page 317](#), and Table 48 on [page 318](#) show analog (500/2500-type) telephone cross-connections on an Intelligent Peripheral Equipment (IPE) module.

Follow the steps in Procedure 60 to cross-connect analog (500/2500-type) telephones.

Procedure 60

Cross-connecting the telephones

- 1 Locate the telephone terminations at the cross-connect terminal.

Telephone terminations are located on the vertical side of the frame when frame-mounted blocks are used and in the blue field when wall-mounted blocks are used.

- 2** Connect Z-type cross-connecting wire to the leads of the telephone. See Table 49 on [page 319](#) and Table 50 on [page 319](#).
- 3** Locate the line circuit card (TN) terminations.
Line circuit card (TN) terminations are located on the horizontal side of the distributing frame when frame-mounted blocks are used and in the white field when wall-mounted blocks are used.
- 4** Run and connect the other end of the cross-connecting wire to the assigned TN terminal block.

End of Procedure

Figure 50
NE-500/2500-type telephone cross-connections for IPE modules




Table 46
500/2500 line card pair-terminations for IPE module connectors A, E, K, R

Pair	Pins	Pair color	I/O panel connectors				Unit
			A	E	K	R	16/card
1T/1R	26/1	W-BL/BL-W	slot 0	slot 4	slot 8	slot 12	0
2T/2R	27/2	W-O/O-W					1
3T/3R	28/3	W-G/G-W					2
4T/4R	29/4	W-BR/BR-W					3
5T/5R	30/5	W-S/S-W					4
6T/6R	31/6	R-BL/BL-R					5
7T/7R	32/7	R-O/O-R					6
8T/8R	33/8	R-G/G-R					7
9T/9R	34/9	R-BR/BR-R					8
10T/10R	35/10	R-S/S-R					9
11T/11R	36/11	BK-BL/BL-BK					10
12T/12R	37/12	BK-O/O-BK					11
13T/13R	38/13	BK-G/G-BK					12
14T/14R	39/14	BK-BR/BR-BK					13
15T/15R	40/15	BK-S/S-BK					14
16T/16R	41/16	Y-BL/BL-Y					15

Table 47
500/2500 line card pair-terminations for IPE module connectors B, F, L, S

Pair	Pins	Pair color	I/O panel connectors				Unit
			B	F	L	S	16/card
1T/1R	26/1	W-BL/BL-W	slot 1	slot 5	slot 9	slot 13	0
2T/2R	27/2	W-O/O-W					1
3T/3R	28/3	W-G/G-W					2
4T/4R	29/4	W-BR/BR-W					3
5T/5R	30/5	W-S/S-W					4
6T/6R	31/6	R-BL/BL-R					5
7T/7R	32/7	R-O/O-R					6
8T/8R	33/8	R-G/G-R					7
9T/9R	34/9	R-BR/BR-R					8
10T/10R	35/10	R-S/S-R					9
11T/11R	36/11	BK-BL/BL-BK					10
12T/12R	37/12	BK-O/O-BK					11
13T/13R	38/13	BK-G/G-BK					12
14T/14R	39/14	BK-BR/BR-BK					13
15T/15R	40/15	BK-S/S-BK					14
16T/16R	41/16	Y-BL/BL-Y					15
17T/17R	42/17	Y-O/O-Y	slot 2	slot 6	slot 10	slot 14	0
18T/18R	43/18	Y-G/G-Y					1
19T/19R	44/19	Y-BR/BR-Y					2
20T/20R	45/20	Y-S/S-Y					3
21T/21R	46/21	V-BL/BL-V					4
22T/22R	47/22	V-O/O-V					5
23T/23R	48/23	V-G/G-V					6
24T/24R	49/24	V-BR/BR-V					7
25T/25R	50/25	V-S/S-V					Spare

Table 48
500/2500 line card pair-terminations for IPE module connectors C, G, M, T

Pair	Pins	Pair color	I/O panel connectors				Unit
			C	G	M	T	16/card
1T/1R	26/1	W-BL/BL-W	slot 2	slot 6	slot 10	slot 14	8
2T/2R	27/2	W-O/O-W					9
3T/3R	28/3	W-G/G-W					10
4T/4R	29/4	W-BR/BR-W					11
5T/5R	30/5	W-S/S-W					12
6T/6R	31/6	R-BL/BL-R					13
7T/7R	32/7	R-O/O-R					14
8T/8R	33/8	R-G/G-R					15
9T/9R	34/9	R-BR/BR-R	slot 2	slot 6	slot 11	slot 15	0
10T/10R	35/10	R-S/S-R					1
11T/11R	36/11	BK-BL/BL-BK					2
12T/12R	37/12	BK-O/O-BK					3
13T/13R	38/13	BK-G/G-BK					4
14T/14R	39/14	BK-BR/BR-BK					5
15T/15R	40/15	BK-S/S-BK					6
16T/16R	41/16	Y-BL/BL-Y					7
17T/17R	42/17	Y-O/O-Y					8
18T/18R	43/18	Y-G/G-Y					9
19T/19R	44/19	Y-BR/BR-Y					10
20T/20R	45/20	Y-S/S-Y					11
21T/21R	46/21	V-BL/BL-V					12
22T/22R	47/22	V-O/O-V					13
23T/23R	48/23	V-G/G-V					14
24T/24R	49/24	V-BR/BR-V					15
25T/25R	50/25	V-S/S-V					Spare

Table 49
Z-type cross-connecting wire

Size	Gauge	Color	Designation
1 pr	22	Y-BL BL-Y	Tip Ring
3 pr	24	W-BL BL-W W-O O-W W-G G-W	Voice T Voice R Signal T Signal R Power Power

Table 50
Inside wiring colors

Inside wiring colors		Connect to equipment TN
Z station wire	16/25-pair cable	
G	W-BL	First pair Tip
R	BL-W	First pair Ring
BK	W-O	Second pair Tip
Y	O-W	Second pair Ring

Operation

Although analog (500/2500-type) telephones do not have feature keys, you can access various system features using Special Prefix (SPRE) codes. SPRE codes are also useful for Meridian 1 proprietary telephones to access features without using feature keys. Dial the SPRE code (unique to each customer within the system) and then the feature code that applies to the operation you desire.

Table 51 lists the feature codes available using SPRE.

Table 51
Feature codes used with SPRE (Part 1 of 2)

Dial SPRE +	Operation performed
1	Ring Again
2	Cancel Ring Again
3	Ringing Number, Call Pickup
4	TAFAS (Trunk Answer From Any Station)
5	Charge Account for CDR
6	Authorization Code Access
70 + ACOD + mmm (Trunk Route Access Code and Member)	Trunk Verification From Station
71 + DN	Call Park, To Park
72 + DN	Call Park, To Retrieve
73	System Speed Call, To Use
74	Call Forward activate or cancel (500-type telephones)
75 + Entry Access Code + DN (500-type telephones)	Speed Call, Individual To Program Entry
76 + Entry Access Code (500-type telephones)	Speed Call, Individual To Use Entry
77	Permanent Hold (500-type telephones)
78	Stored Number Redial, To Store
79	Stored Number Redial, To Redial

Table 51
Feature codes used with SPRE (Part 2 of 2)

Dial SPRE +	Operation performed
81	Automatic Set Relocation
83	Malicious Call Trace
84	Integrated Messaging System
86 + x (status)	Room Status
86 + 1	Cleaning Request
86 + 2	Cleaning In Progress
86 + 3	Room Cleaned
86 + 4	Passed Inspection
86 + 5	Failed Inspection
86 + 6	Cleaning Skipped
86 + 7	Not For Sale
87	Disconnect Trunk, Conference 6 (analog (500/2500 type) telephones)
89	Last Number Redial
91	Access to maintenance programs by Maintenance Telephone
92	Terminal Diagnostics, telephones and attendant consoles
93	Conference Circuit Testing
94	Ringing Number, Group Pickup
95	Ringing Number, DN Pickup
96	Centrex Switchhook Flash
97	Unassigned Automatic Call Distribution (ACD) analog (500/2500 type) telephone Log in/out
98	Unassigned ACD analog (500/2500 type) telephone Activate/deactivate Not Ready

Table 1
2500-type telephone features (no SPRE code used)

# + 1 + DN	Call Forward
# + 2 + Speed Call code + DN	Speed Call, Individual, To Program Entry
# + 2 + Speed Call code + *	Speed Call, Individual, To Erase Entry
# + 3 + Speed Call code	Speed Call, Individual, To Use Entry
# + 4	Permanent Hold

Appendix A: Meridian Modular Telephones

Contents

This section contains information on the following topics:

Introduction	324
Software requirements	325
Intelligent Peripheral Equipment requirements	325
General description	325
Physical description	330
Volume control	331
Message Waiting lamp	331
Handsfree/Mute key (M2008HF & M2616 only)	332
Features and options	334
Display Module	335
Meridian Programmable Data Adapter	335
Program key	336
External Alerter Interface	336
Key Expansion Module	337
Brandline Insert	338
Headset	338
Relocation	340
Specifications	342
Environmental and safety considerations	342
Line engineering	343
Local alerting tones	344

Power requirements	345
Meridian Programmable Data Adapter	352
Handsets	353

Note: This section is for reference only. The Meridian Modular Telephones are manufacture discontinued and no longer available.

Introduction

This chapter provides feature, add-on module, relocation, and specification information for the M2006, M2008, M2008HF, M2616, and M2216ACD Meridian Modular Telephones.

The Meridian Modular Telephones are designed to provide cost-effective integrated voice and data communication capability. They interface with the Digital Line Card (DLC). No additional hardware is required at the line circuit to provide data communication.

Meridian Modular Telephones are connected to the system through a two-wire loop carrying two independent 64 Kb/s PCM Channels with associated signaling channels. One of the two PCM channels is dedicated to voice while the other is dedicated to data traffic. Line cords and handset cords on all Meridian Modular Telephones are equipped with snap-in TELADAPT connectors for easy and quick connecting procedures.

Three distinct versions of Meridian Modular telephones, distinguished by the first four letters in the upper left-hand corner of the model identification label on the bottom of the telephone, are available. The three versions are the “NTZK” models, the “NT2K” models with date code prior to April 24, 1998, and both the “NT9K” models and the “NT2K” models with date code of April 24, 1998 and later. The two jacks face in the same direction on “NT2K” and “NT9K” telephones, and in opposite directions on “NTZK” telephones. When appropriate, differences between the models are noted in this document.

Software requirements

The option number for the Meridian Modular Telephones is 170. The mnemonic is ARIE. The DSET package (88) and the TSET package (89) are required.

Intelligent Peripheral Equipment requirements

The telephones interface with the DLC. The DLC supports eight Integrated Voice and Data ports; each port supports one data and one voice channel. A voice TN and a data TN are assigned in the software.

General description

This section describes the various features and capabilities of the following Meridian Modular Telephones.

M2006 — A single line telephone with 6 programmable function keys. See Figure 51 on [page 326](#).

M2008/M2008HF — A multi-line telephone with 8 programmable function keys. The M2008HF contains an integrated Handsfree unit. See Figure 52 on [page 327](#).

M2616 — A high performance multi-line telephone with 16 programmable function keys and integrated Handsfree unit. See Figure 53 on [page 328](#).

M2216ACD-1 — A multi-line telephone for ACD operations. It has 15 programmable function keys, a special ACD Display Module and two RJ-32 jacks for modular electret headsets. See Figure 56 on [page 339](#).

M2216ACD-2 — A multi-line telephone for ACD operations. It has 15 programmable function keys, and a special ACD Display. It is similar to model 1, but with one PJ-327 jack for a carbon agent headset and one RJ-32 jack for an electret supervisor headset. See Figure 56 on [page 339](#).

Note: If a headset is desired for the M2216ACD sets, the amplified type is strongly recommended.

Figure 51
M2006 modular telephone




Figure 52
M2008/M2008HF modular telephone




Figure 53
M2616 modular telephone





Figure 54
M2216ACD-1 and -2 modular telephones



Physical description

All of the Meridian Modular Telephones are equipped with:

- Hold key
- Release key
- Volume control
- Message Waiting lamp
- Speaker

Each modular telephone also has a number of programmable keys with LCD indicators that can be assigned to any combination of directory numbers and features (only one DN for the M2006). The lower right-hand key (key 0) is reserved for the Primary DN.

When equipped with a Display module or MCA, key 07 is automatically assigned as the Program key and cannot be changed. Key 05 becomes the Program key on the M2006, if equipped with MCA.

The M2006 is a single line telephone and accepts only one DN. The remaining five key/lamp pairs can be assigned any feature that is not considered a DN, such as Transfer, Call Forward, or Conference. Features that cannot be assigned are those that are considered DNs: Voice Call and 2-way Hotline, for example. Attempting to assign more than one DN to the M2006 causes the telephone to disable itself and all LCDs light steadily. It will return to its normal operating state when service change removes all secondary DNs.

LCD indicators support 4 key/LCD states:

Function	LCD state
idle	off
active	on (steady)
ringing	flash (60 Hz)
hold	fast flash (120 Hz)

* An indicator fast flashes when a feature key is pressed but the procedure necessary to activate the feature has not been completed.

Volume control

One key with two toggle positions controls volume. Pressing the right “volume up” or left “volume down” side of the key incrementally increases or decreases the volume for the tone or sound which is currently active. The volume settings are retained for subsequent calls until new volume adjustments are made. If the telephone is equipped with a Display Module, volume can be adjusted at any time with the setting displayed on the screen (in Program mode).

Note: All Meridian Modular Telephones manufactured after June 1996 are compliant with the HAC volume-level requirements issued by the FCC for handset volume control for the hearing impaired. The highest volume-level setting provides 13.5 dB over nominal.

Handset volumes can be configured to return to nominal on a per-call basis.

You can adjust the volume of the following tones, while they are audible:

- ringing
- handsfree (M2616)
- handset/headset
- buzz
- on-hook dialing

When the telephone is disconnected, all volume levels will return to default values upon reconnection.

When the telephone is operating on loop power alone, the highest (eighth) step in volume cannot be reached (as seen when using Display in Program mode).

Message Waiting lamp

Each Meridian Modular Telephone has a red triangle in the upper right-hand corner that lights brightly to indicate a message is waiting. This LED is the primary message waiting indicator and lets you know a message is waiting

regardless of whether the telephone has a message waiting key/lamp pair. You must have Message Waiting CCOS configured.

If you do assign a message waiting key/lamp pair, there will be two indications of a message waiting:

- the red Message Waiting triangle lights, and
- the LCD associated with the Message Waiting key flashes.

You may assign an Autodial key that dials the message center (or voice mail system) to avoid the double indication, or have no key/lamp pair assigned to the message center.

Handsfree/Mute key (M2008HF & M2616 only)

Handsfree (if software assigned), allows the user to talk to another party without lifting the handset. Activate Handsfree by depressing the Handsfree/Mute key (key 15, top left) or by selecting a DN without lifting the handset. Once Handsfree is activated, it can be deactivated by picking up the handset or by ending the call using the Release (RIs) key. If Handsfree is not software assigned, you can assign any other feature to key 15.

When the Handsfree/Mute key is pressed during a Handsfree call, the microphone is deactivated while the speaker remains active, preventing the other party from overhearing local conversations. The Handsfree LCD indicator flashes while the microphone is muted. Pressing the Handsfree/mute key again reactivates the microphone and the Handsfree LCD lights steadily.

The Class of Service feature for M2616 Handsfree control enables system administrators to enable/disable the Handsfree option on the M2008HF (Handsfree) telephone through software. M2008HF telephones ship from the factory with a hardware jumper enabled to enable the Handsfree option for existing software releases.

System software overrides the hardware setting and default to Handsfree Denied (HFD.) If the handsfree option is desired, the system administrator simply enables Handsfree through the Class of Service prompt HFA included in LD 11 for the M2008 telephones (consistent with M2616).

Service Change Parameters

LD 11 – Allow/Deny Handsfree for M2008HF

Prompt	Response	Description
REQ:	NEW CHG	
TYPE:	M2008	M2008 telephone
CLS	(HFD)	Digital Telephone Handsfree Denied
	HFA	Digital Telephone Handsfree Allowed

Handsfree operates as if an off-hook operation had been performed. For example, when the telephone is idle, pressing the Handsfree/Mute key turns on the Handsfree and selects a DN (depending on line selection as assigned through COS), enabling the user to make a call. When a call comes in to an M2008HF/M2616 and the set is ringing, pressing the Handsfree/Mute key turns on the Handsfree and enables the user to answer the incoming call (depending on COS-assigned line selection) without picking up the handset.

Features and options

Table 52 lists the distinctive characteristics of each Meridian Modular Telephone and shows the optional hardware you can add to each.

Table 52
Hardware features and options

	M2006	M2008/ 2008HF	M2616	M2216 ACD-1	M2216 ACD-2
Programmable keys	6	8	16	16	16
Handsfree microphone			standard		
Optional hardware:					
Display		x	x	standard	standard
Key Expansion Module			x	x	x
Meridian Communications Adapter (MCA)	x	x	x	x	x
Meridian Programmable Data Adapter (MPDA)	x	x	x	x	x
External alerter interface	x	x	x	x	x
Analog Terminal Adapter (ATA)	x	x	x	x	x
Brandline insert	x	x	x	x	x
<p>Note 1: In this table, x indicates available features for the set type listed along the top row.</p> <p>Note 2: If the set is equipped with a Display, Meridian Programmable Data Adapter, or Meridian Communications Adapter, the number of programmable keys is reduced by one, as key 07 (key 05 on M2006) automatically becomes the Program key.</p>					

The optional hardware for Meridian Modular Telephones is described below.

Display Module

A 2-line by 24-character Display Module provides system prompts, feedback on active features and valuable calling party information. In addition, you can modify various set features such as volume and screen contrast using the Program key (top right function key). You can enable a Call Timer which times calls made or received on the prime DN.

Note: The Display Module is not supported on M2006.

Note: The Display Module requires a Power Supply Board on M2008.

Two types of Display Module are available:

- North American Display — Supports normal business features in two languages, English and Quebec French.
- Special Applications Display — Supports the following features:
 - Automatic Call Distribution (ACD)
 - Hospitality
 - 6 languages (English, Quebec French, Parisian French, German, Spanish, Dutch)

A Special Applications Display Module comes as standard equipment on the M2216ACD telephones. M2008 or M2616 telephones used as ACD telephones require the Special Applications Display.

Note: It is possible to adjust the Display screen contrast so that it is too light or too dark to read. If you cannot read the Display, disconnect and then reconnect the line cord to return to the default settings.

Meridian Programmable Data Adapter

The Meridian Programmable Data Adapter (MPDA) mounts within the telephone (see Figure 57 on [page 340](#)) and allows asynchronous ASCII terminals, personal computers and printers to be connected to the telephone using an RS-232-D (subminiature) interface. The MPDA has multilingual capability.

It requires additional power. See “Power requirements” on [page 345](#).

For more information, see “Meridian Programmable Data Adapter” on [page 352](#).

Program key

The Program key is automatically assigned to Meridian Modular Telephones with Display or MPDA added. It allows you to change a variety of display features such as screen format, contrast and language. It also lets you change data parameters such as transmission speed and parity.

The upper right-hand key (key 05 on M2006, key 07 on all others) automatically becomes the Program key when Display, MCA, or MPDA is configured with the telephone. The Program key is local to the set and shows blank when you print key assignments in LD 20.

See Appendix C: “Meridian Modular Telephones add-on modules installation” on [page 371](#) for descriptions of MCA, MPDA, and ATA and their requirements.

External Alerter Interface

The External Alerter Board provides an interface to standard remote ringing devices, such as a ringing unit installed in a location separate from the telephone. The Meridian External Alerter and Recording Interface (MEARI) is not the remote ringer itself, but provides access to standard, off-the-shelf remote ringing devices. The Alerter Board requires additional power (see “Power requirements” on [page 345](#)).

You can program the MEARI to activate a ringer (or light) when the telephone rings or when the telephone is in use (off-hook). A call to any DN configured on the telephone triggers the alerter. The MEARI alerts to one active call at a time; if the telephone is already active on a call, a second call will not activate MEARI.


For more information on installing and setting up MEARI, see “External Alerter Board” on [page 416](#).

Key Expansion Module

A modular 22-key unit can be attached to any 16-key Meridian Modular Telephone except 2016S. See Figure 55. The extra keys can be assigned to any combination of lines and features. You can add up to two expansion modules to a single telephone, providing a total of 60 line/feature keys. You will need a separate footstand for the module(s), one for a single module, one for a double. The expansion module requires additional power. See “Power requirements” on [page 345](#).

The Key Expansion Module connects to the telephone through a ribbon cable running from the base of the telephone. It is physically connected to the telephone by the footstand. NT2K22VH or later vintage key lamp modules are required for CISPR22, Class B compliance.

Figure 55
M2616 with Display Module and Key Expansion Module



Brandline Insert

The filler plate on the telephone or Display Module contains a removable insert designed to accommodate custom labeling. You can order blank Brandline Inserts and have a printer silk screen your company logo on them. Brandline Inserts snap easily into and out of the filler plate.

Headset

The M2216ACD-1 is compatible with most headsets. Amplified headsets are strongly recommended. The headset/handset interface of the M2216ACD-1 can be adjusted for optimum performance using the Program key. Three settings are available:

- Plantronics Polaris
- GN Netcom Profile
- NT Liberation

Try using the headset with each of the three settings to determine which works best. Trial with both internal and external calls is also recommended to determine optimum performance.

When the amplified headset is used, two choices for volume control are available:

- the rocker control on the telephone
- the switch on the headset

The settings which provide the clearest communication with the least amount of distortion are the amplifier setting higher than the telephone volume control.


The supervisor and agent jacks are not interchangeable. A headset must be plugged into the agent jack if the telephone is to receive ACD calls.

The M2216ACD-2 agent jack is compatible with any standard carbon headset. The headset interface of the M2216ACD-2 is not adjustable.

Any recording device connected to the receive path of a Meridian Modular Telephone must meet these requirements:

- load impedance at least 8K ohms across the audio band
- connect in parallel across pins 3 and 4 of the handset/headset jack
- isolate power source from the headset/headset jack

Figure 56
M2216ACD-1 and -2 left side showing headset jacks




M2006/M2008/M2008HF/M2616/M2216ACD telephones

You can use an electret headset in the handset port of the M2006, M2008, M2008HF, M2616, and M2216ACD telephones. Choose an amplified headset that draws power from a battery or AC transformer (power is not provided by the telephone). The amplifier must draw less than 400 micro amps from the telephone jack.

The headset should be designed to work with a telephone jack with these characteristics:

- Transmit interface: +5 V through 10K DC bias resistance with maximum current of 500 micro amps. The differential input impedance is 10K ohms. Connects to pins 2 and 5 of the handset jack.
- Receive interface: single ended output with output impedance of 180 ohms. Connects to pins 3 and 4 of the handset jack.

Figure 57
Back of telephone showing Meridian Programmable Data Adapter



Relocation

This section describes how to relocate a Meridian Modular Telephone and its associated dataport Terminal Number (TN) without the intervention of a technician.

Modular Telephone Relocation is designed specifically for the Meridian Modular Telephones and is an enhancement to Automatic Set Relocation. If dataport TN information exists for the terminal, it is automatically relocated when the telephone is relocated.

When a telephone is relocated-out, a relocation block is built to store the relocation information in the protected data area. The relocation block includes the old TN, the terminal ID information, the serial number of the telephone, and other information.

This feature uses the unique serial number and terminal ID of the Meridian Modular Telephone to identify the terminal being relocated and to reduce the number of manual steps needed for relocation.

See Automatic Set Relocation in *Features and Services* (553-3001-306) for complete details.

How to relocate a Meridian Modular Telephone

- 1** Go off-hook, receive dial tone, and enter Relocation Code (either SPRE +81 or Flexible Feature Code).
- 2** Enter optional security code as defined in LD 15 (a burst of tone confirms that the telephone is relocated-out).
- 3** Take the telephone to the new location and plug it in (a confirmation buzz from the speaker indicates the telephone is in service).

Specifications

The following specifications govern the performance of the Meridian Modular Telephones under the environmental conditions described.

Environmental and safety considerations

All digital telephones and their associated options meet the requirements of Electronic Industries Association (EIA) specification PN-1361.

Temperature and humidity

Operating state:

Temperature range	0° to 50° C (32° to 104° F)
Relative humidity	5% to 95% (non-condensing). At temperatures above 34°C (93°F) relative humidity is limited to 53 mbar of water vapor pressure.

Storage:

Temperature range	-50° to 70° C (-58° to 158° F)
Relative humidity	5% to 95% (non-condensing). At temperatures above 34°C (93°F) relative humidity is limited to 53 mbar of water vapor pressure.

Electromagnetic interference

The radiated and conducted electromagnetic interference meets the requirements of Subpart J of Part 15 of the FCC rules for class A computing devices.

NT2K model sets with all options meet CISPR22, Class B requirements.

Line engineering

Meridian Modular Telephones use twisted-pair wiring on transmission lines selected by the rules given in “Digital telephones line engineering” on [page 289](#) &c. The maximum permissible loop length is 3500 ft. (915 m), assuming 24 AWG (0.5 mm) standard twisted wire with no bridge taps. A 15.5 dB loss at 256 KHz defines the loop length limit (longer lengths are possible, depending on the wire's gauge and insulation). The Meridian Modular Telephones use a 6-conductor line cord (A0346862).

Table 53 gives detailed information on loop lengths.

Table 53
Loop lengths for digital telephones

	NT8D02
PVC insulated cable (polyvinyl chloride)	
22 or 24 AWG	0–3500 ft. (0–1067 m)
26 AWG	0–2600 ft. (0–793 m)
Note 1: No bridge taps or loading coils are allowed.	
Note 2: Effect of line protector at MDF reduces loop length by 500 ft.	



CAUTION


Damage to Equipment

Service Interruption

Use only the line cord provided with Meridian Modular Telephones. Using a cord designed for other digital telephones could result in damage to the cord or a loss of set functionality.

Figure 58 on [page 344](#) shows a simplified block diagram of the Meridian Modular Telephone, MPDA and DLC.

Figure 58
Block diagram of MPDA and Meridian Modular Telephone



Local alerting tones

Each telephone provides four alerting tones and a buzz sound. The system controls the ringing cadence by sending tone-ON and tone-OFF messages to the telephone. The alerting tone cadences cannot be changed from the telephone, but can be altered for individual Meridian Modular Telephones by software controlled adjustments in the system. See *Software Input/Output: Administration* (553-3001-311).

All other telephony tones, such as dial tone or overflow, are provided by the system from a Tone and Digit Switch.

Alerting tone characteristics

The tone frequency combinations are as follows:

Tone	Frequencies	Warble Rate (Hz)
1	667 Hz, 500 Hz	10.4
2	667 Hz, 500 Hz	2.6

M2006/M2008/M2008HF:

3	1600 Hz, 2000 Hz	10.4
4	1600 Hz, 2000 Hz	2.6

M2616/M2216ACD:

3	333 Hz, 250 Hz	10.4
4	333 Hz, 250 Hz	2.6

A 500 Hz buzz signal is provided for incoming call notification while the receiver is off-hook.

Power requirements

The M2006, M2008, M2616 (basic configuration and with Display Module) and M2216ACD-1 are loop powered. Loop power consists of a -30 V AC power source and assumes a 3500 ft. (915 m) maximum loop length of 24 AWG wire and a minimum 15.5 V AC at the telephone terminals.

Note: The loop length limit is defined by a 15.5 dB loss at 256 KHz. Longer lengths can be determined using the wire's gauge and insulation.

The Handsfree feature, which is integrated into the M2616, requires no additional power.

Some configurations of telephones and options need more than basic loop power to operate. Table 54 lists the Meridian Modular Telephones and shows

when additional power is needed to operate the telephone or its optional hardware. Power Supply Boards come installed in factory-assembled configurations which require additional power.

Note 1: If a power failure occurs, configurations that require loop power will only continue to work if the system has battery backup. Only those options which require additional power will cease to function.

Note 2: During a power failure, the carbon agent headset on the M2216ACD-2 will fail and the electret supervisor's jack can be used as an agent jack. If no headset was plugged in to the electret jack at this time, the call is dropped, the agent logged off and must log in again once the electret headset is plugged in. When power is restored, the carbon jack returns automatically.

Table 54
Power requirements

Telephone type	Loop power	Additional power (Power Supply Board)
M2006	Basic configuration	Any option(s)*
M2008/2008HF	Basic configuration	Any option(s)
M2616	Basic configuration (with Handsfree) and Display	Programmable Data Adapter Key Expansion Module External alerter interface
M2216ACD-1	Basic configuration (with Display)	Any option(s)
M2216ACD-2	No	All configurations
*No display can be added to the M2006 set.		

Power Supply Board

The power supply option consists of a Power Supply Board which mounts inside the telephone, coupled with an external wall-mount transformer or closet power supply which provides power to the Power Supply Board. The Power Supply Board receives its power through pins 1 and 6 of the line cord.

When installing an MCA or MPDA to NTZK or NT2K phone sets with a date code prior to January 1998, a Power Option board is required, along with an additional power source. When installing an MCA in an NT9K phone set or an NT2K with date code of January 1998, install only the MCA (an additional Power Option board and Jumper board are not required).

The Power Supply Board connects to the telephone through a 14 pin bottom entry connector.

The Power Supply Board comes factory installed with any configuration of the M2216ACD-2. The M2006 and M2008 require the Power Supply Board with the addition of any option. The M2616 requires the Power Supply Board with any option except the Display Module.

Refer to Figure 55 on [page 347](#) and Figure 56 on [page 348](#) for power supply board requirements.

Table 55
NT2K model Power requirements, Meridian Modular Telephone sets

Telephone type	Loop power	Additional power (Power Supply Board and Transformer)
M2006	Basic configuration	Any option(s)* (MPDA, External Alerter Interface, MCA)
M2008/M2008HF	Basic and Display configurations	MPDA, External Alerter Interface
M2616	Basic, Display, and Handsfree configurations and Key Expansion Module(s)	MCA, MPDA, External Alerter Interface, MCA
M2216ACD	Basic configurations (with Display) Key Expansion Module(s).	MPDA, Key Expansion Module, External Alerter Interface, MCA
*No display can be added to the M2006 set.		

Table 56
NTZK model Power requirements, Meridian Modular Telephone sets

Telephone type	Loop power	Additional power (Power Supply Board)
M2006	Basic configuration	MPDA, External Alerter Interface, MCA (optional),
M2008	Basic configuration	Any option(s)
M2616	Basic configuration (with Handsfree) and Display.	MPDA, Key Expansion Module, External Alerter Interface, MCA (optional)
M2216ACD-1	Basic configuration (with Display)	MPDA, Key Expansion Module, External Alerter Interface, MCA (optional)
M2216ACD-2	N/A	Any configuration

Local plug-in transformer

A single winding transformer equipped with a 10 ft. (3 m) cord of 22 AWG two-conductor stranded and twisted wire with a modular RJ-11 duplex adapter (refer to Figure 59 on [page 349](#)) can provide the additional power needed to operate the telephone and its options.



	<p>WARNING</p> <p>Do not plug any equipment (computer, modem, LAN card) other than the Meridian Modular Telephone into the RJ-11 transformer adapter, as damage to equipment may result.</p>
--	---

Figure 59
Configuration of local plug-in transformer



553-AAA0725

120 V transformer (AO367335 or equivalent)

The following minimum specifications must be met by this transformer:

Input voltage	120 V AC/60 Hz
No load output voltage	29 V AC maximum
Voltage at rated current	26.7 V AC minimum
Rated load current	700 mA

240 V transformer (AO367914 or equivalent)

The following minimum specifications must be met by this transformer:

Input voltage	240 V AC/50 Hz
No load output voltage	29 V AC maximum
Voltage at rated current	26.7 V AC minimum
Rated load current	700 mA

Note 1: The telephone cannot be wall-mounted over the wall jack when using a transformer, because of the size of the RJ-11 adapter. Hang the telephone above or to the side of the jack and run the line and power cords to it.

Note 2: The above-mentioned transformers can also be used with outlets identified as 110V or 220V.

Closet power supply

Closet power can be obtained from an AC transformer for loops of 100 ft. (30 m) or less, or a DC transformer for loop lengths of 650 ft. (197 m) or less. An equivalent power source can be used but must maintain isolation of outputs to the terminal. Refer to Figure 60 on [page 351](#).



WARNING


When using closet power, do not plug the TELADAPT connector into any equipment (computer, modem, LAN card) other than the Meridian Modular Telephone, as damage to equipment may result.

Note 1: All terminals must be isolated from the input winding and each terminal must be isolated from all other terminal windings. A separate winding is required for each terminal, and grounds should not be connected.

Note 2: The QUT1 closet power supply source is not compatible with Meridian Modular Telephones.

The AC source should be rated at 29 V AC, 700 mA isolated. The DC source should be rated at 42 V DC, 300 mA isolated, with current limiting output of 1 amp.

Figure 60
Closet power supply configuration



Meridian Programmable Data Adapter

When a Meridian Modular Telephone is equipped with the Meridian Programmable Data Adapter (MPDA), you can make a data call using keyboard dialing from your attached terminal. You can carry on voice and data communication simultaneously without causing any mutual interference.

The MPDA communicates with Data Terminal Equipment (DTE) having characteristics as shown in Table 57:

Table 57
MPDA data characteristics

Data type	ASCII
Synchronization	Asynchronous, Start-Stop
Number of Bits	8 bits
Parity	none (unchecked)
Data rate	110, 150, 300, 1200, 2400, 4800, 9600, 19200 bits per second (autobaud)
Stop bits	2 bits for 110 bits per second; 1 bit for all other speeds
Transmission	Full duplex

Note: The MPDA configuration of data parameters is stored locally (although you can set the configuration in the Cabinet system system). You cannot set the data parameters in the system before installing the MPDA in the telephone (the configuration information will be lost).

The keyboard dialing routine may vary with the data equipment being used and reference to the user's data terminal manual may be necessary. For more detailed information, see *Meridian Communications Unit User Guide and Meridian Communications Adapter Reference Guide*.

The MPDA can establish either data calls or voice calls. You can make data calls using keyboard dialing, keypad dialing or the AT command dialing feature. The AT dialing features lets you originate data calls to local and remote Data Terminal Equipment (DTE) directly from a data terminal

keyboard or personal computer. You can make voice calls using AT dialing from your terminal.

Users of personal computers already equipped with a Hayes Smartmodem or users who have a stand-alone Hayes Smartmodem can substitute the MPDA for data integration. The Hayes dialing feature, when used with third party communication software and the digital telephone, will support most of the Hayes Smartmodem features. Third party terminal emulation packages can also be used with Hayes dialing.

Features supported by the MPDA include:

- enhanced Hayes commands, including upper- and lower case dialing, voice call origination through AT dialing, hang up data call, and on-line disconnect of voice call
- script file capabilities allow you to program multiple data resources for automatic resource access
- Voice Call Origination (VCO)

Handsets

This section provides information on Meridian Modular Telephone handsets.

Table 58
Codes for handsets for Meridian Modular Telephone sets, model NTZK

Description	Order Code
Legacy handset, Black	NT0C09EA03
Legacy handset, Ash	NT0C09EA35
Legacy handset, Gray	NT0C09EA93
Note: Handsets designed for NT2K sets (Global handset) do not meet product transmission/reception specifications if used with NTZK sets.	

Table 59
Codes for handsets for Meridian Modular Telephone sets, model NT2K

Description	Order Code
Global handset, Black	NT0C09EK03 / A0400786
Global handset, Ash	NT0C09EK35 / A0400787
Global handset, Gray	NT0C09EK93 / A0400790
<p>Note 1: Handsets designed for NTZK sets (Legacy handset) do not meet product transmission/reception specifications if used with NT2K sets.</p> <p>Note 2: Noisy Location, Push-to-Talk, Push-to-Mute, and Mercury Switch handsets do not meet product transmission/reception specifications if used with NT2K sets.</p> <p>Note 3: Global handsets are not compatible with M2250 (AE or current AF versions) telephones.</p>	

Appendix B: Meridian Modular Telephones installation

Contents

This section contains information on the following topics:

Packing and unpacking	355
Installation and removal	356
Install the Meridian Modular Telephones	356
Meridian Modular Telephones self-test	358
Install an M2317 telephone	361
M2317 telephone self-test	363
Designate telephones	367
Cross-connect the telephones	368

Note: This section is for reference only. The Meridian Modular Telephones are manufacture discontinued and no longer available.

Packing and unpacking

Use proper care when unpacking any digital telephone. Check for damaged containers so that appropriate claims can be made to the transport company for items damaged in transit.

If a telephone must be returned to the factory, pack it in the appropriate container to avoid damage during transit. Remember to include all loose parts (cords, handset, power unit, labels, and lenses) in the shipment.

Installation and removal

Install the Meridian Modular Telephones

Follow the steps in Procedure 61 to install the Meridian Modular Telephones (M2006/2008/2008HF/2616/2216ACD).

Procedure 61

Installing Meridian Modular Telephones (M2006/M2008/M2008HF/M2616/M2216ACD)

- 1 Complete the wiring and cross-connections (loop power) before connecting the telephone to the TELADAPT connector. See Figure 61 on [page 357](#) and Figure 62 on [page 358](#).
- 2 Place the telephone upside down on a number of sheets of soft, clean paper on a solid, level work surface to prevent damage to movable keys and the telephone's face.
- 3 Connect the handset cord (5-conductor TELADAPT connectors) to the handset and snap it into place (not applicable to M2216ACD).
- 4 Connect the other end of the handset cord to the connector in the bottom cover of the telephone. Turn the smooth side of the handset cord up (away from the telephone bottom cover) before tucking it under the restraining tab to ensure that the telephone will sit level on the desk after installation is complete (not applicable to M2216ACD).
- 5 Connect the line cord to the telephone bottom cover. Route the cord through the channels.
- 6 Turn the telephone right side up and place it in the normal operating position.
- 7 Print the directory number on the designation card. Using a paper clip, remove the number lens from the telephone. Insert the designation card and snap the lens back into place.
- 8 Designate the feature keys.
- 9 Insert the line cord TELADAPT connector into the connecting block (jack) and snap it into place.
- 10 Perform the self-test (see Procedure 62 on [page 358](#)) and acceptance test procedures. See LD 31 in the *Software Input/Output: Administration* (553-3001-311).

- 11 Supply the user with a Quick Reference Card and all user documentation. Make sure the SPRE number is printed on the Quick Reference Card.

————— **End of Procedure** —————

Figure 61
Meridian Modular Telephone connections





Figure 62
Meridian Modular Telephone cross-connections.



Meridian Modular Telephones self-test

Meridian Modular Telephones have a self-testing capability. Follow the steps in Procedure 62 to perform the self-test after installing a Meridian Modular Telephone or any of the hardware options to ensure proper operation.

Procedure 62

Meridian Modular Telephones self-test

- 1 Unplug the line cord from the telephone.
- 2 While holding down the RLS key, plug in the line cord to the telephone. Let go of the RLS key.

- 3 Follow the steps in Table 60 to perform the necessary steps and check results.

Table 60
Meridian Modular Telephones self-test steps and results (Part 1 of 2)

Step	Action	Result
1	Begin test (plug in line cord while holding down the RLS key). The handset is on hook.	Speaker beeps once, all LCDs flash. Message Waiting lamps light steadily. Display reads:LOCAL DIAGNOSTIC MODE PRESS RLS KEY TO EXIT
2	Press each Function key, from zero to fifteen (if there are Key Expansion Modules, continue pressing the Function keys, in any order).	Adjacent LCD goes off when a key is pressed.
3	Press the Hold key.	Speaker beeps.
4	Press each dial pad key.	Speaker beeps each time a key is pressed.
5a	Lift the handset (if applicable). Press the dial pad keys. Replace the handset.	Speaker beeps. Handset beeps.

Table 60
Meridian Modular Telephones self-test steps and results (Part 2 of 2)

Step	Action	Result
5b	Plug in the headset (if applicable). Press the dial pad keys. Unplug the headset.	Speaker beeps. Headset beeps.
6	Press the right side of the volume control key. Press the right side of the volume control key. Press the right side of volume control key. Press the right side of the volume control key. Press the right side of the volume control key. Press the right side of the volume control key. Press the right side of the volume control key.	Speaker beeps. Display is filled with dark squares. Speaker beeps. Display is blank. Speaker beeps. Display shows symbols including digits 0–9 and uppercase alphabet Speaker beeps. Display shows symbols including upper- and lowercase alphabet. Speaker beeps. Display shows various symbols. Speaker beeps. Display shows symbols. Speaker beeps. Display is filled with dark squares.
7	Press the RLS key (end of test).	Message Waiting lamp goes off. Display shows idle screen within 10 seconds.

Install an M2317 telephone

Follow the steps in Procedure 63 to install an M2317 telephone.

Procedure 63

Installing the M2317 telephone


- 1** Complete the wiring and cross-connection as shown in Figure 63 on [page 363](#) before connecting the telephone to the TELADAPT connector block.
- 2** Place the telephone upside down on a number of sheets of soft, clean paper and on a solid, level work surface to prevent damage to movable keys and the telephone's face.
- 3** Connect the handset cord 4-conductor TELADAPT connectors to the handset and to the telephone and snap into place.
- 4** Turn the smooth side of the cord away from the telephone base and secure it under the restraining tab. This ensures that the telephone sits level after the installation is complete.
- 5** Connect the 6-conductor line cord to the telephone base, and place it under the restraining tabs.
- 6** Turn the telephone face up, and place it in the normal operating position.
- 7** Print the Directory Number (DN) on the designation card and place it in the designation card holder.
- 8** Designate button labels for programmable keys, and place them under the button cover.
- 9** Insert the line cord TELADAPT connector block and snap it into place. Place the line cord under the restraining tabs.
- 10** Plug the 5 V power supply connector into the back of the telephone.
- 11** Plug the power supply into an AC utility outlet.
- 12** After the M2317 digital telephone is connected to a line that is both enabled and designated as an M2317 digital line, the startup screen displays INITIALIZATION V6.4. Within 5 seconds, the Idle state screen is displayed, and the M2317 is operational. The term V6.4 represents the firmware issue number, and can differ with some installations.

- 13 If the M2317 has been connected to a line that is designated as a digital line, but is not enabled, the display prompts CONTACT SYSTEM ADMINISTRATOR. The line must be enabled using LD 32 from the maintenance terminal, and by enabling the features outlined in the work order. Refer to *Software Input/Output: Administration* (553-3001-311) for the required routines, prompts, and responses.

If the M2317 has been connected to a line that is neither defined as a digital line nor enabled, refer to *Software Input/Output: Administration* (553-3001-311) for required routines, prompts, and responses.
- 14 Verify that all the requested features are enabled by accessing them with the soft keys, or programmable keys, from the M2317 telephone and observing the display screen.
- 15 Perform the self-test (see Procedure 64 on [page 364](#)) and acceptance test procedures. See LD 31 in the *Software Input/Output: Administration* (553-3001-311).

End of Procedure

Figure 63
M2317 digital telephone cross-connections



M2317 telephone self-test

The M2317 telephone has a self-testing capability. This test can be performed whether or not the telephone is connected to the system. The test checks the proper functioning of the keys and LCD indicators on the telephone.

Follow the steps listed in Procedure 64 on [page 364](#) and Table 61 to perform the M2317 self-test.

When the M2317 digital telephone or the data option fails to function properly, follow the steps listed in Table 62 in sequence to isolate the problem area.

Table 62
M2317 trouble-locating procedures (Part 1 of 3)

Step	Action
	Loop power failure
1	Plug in the telephone.
2	The LCDs flash once to indicate the power is OK.
	Data communication failure
1	<p>If voice communication is normal but data communication fails, check for DC output voltage at the power supply connector pins or replace the power supply plug-in transformer.</p> <p>Attempt to make a data call from the terminal keyboard. Refer to “Meridian Programmable Data Adapter” on page 352. If not successful, proceed with Step 2.</p>
2	Make a call to the DN (voice or data) to verify that the port is enabled.
3	<p>Use an EIA or RS-232 breakout box in conjunction with the terminal cable to verify lead states and replace or repair cable if pinouts are incorrect.</p> <p>Attempt to make a data call from the terminal keyboard. Refer to “Meridian Programmable Data Adapter” on page 352. If unsuccessful, proceed with Step 4.</p>
4	<p>Remove the transformer from the AC receptacle, unplug the 5-pin power supply connector at the back of the telephone, and replace the data option circuit board. See Procedure 78 on page 427. Reconnect the data option power supply.</p> <p>Make a new attempt to start a data call. If trouble persists, continue with the ISDLCL failure procedure.</p>
5	Use the self-test procedure to verify that the telephone electronics are operating correctly.

Table 62
M2317 trouble-locating procedures (Part 2 of 3)

Step	Action
	ISDLC failure
1	<p>Go to the system maintenance terminal (TTY or CRT) and check for displayed error and location codes. An "NWS 401 L S C" or an "NWS 501 L S C U" code indicates that the automatic (routine) diagnostic test has detected a fault.</p> <p>Check for the following indications:</p> <p>L = faulty circuit card (ISDLC card) loop number</p> <p>S = circuit card location (shelf number)</p> <p>C = number of the faulty circuit card</p> <p>U = unit number of a faulty telephone (appears only in conjunction with the NWS 501 code)</p>
2	<p>Replace the faulty components.</p> <p>Try to establish a call. If unsuccessful, check the telephone.</p>

Table 62
M2317 trouble-locating procedures (Part 3 of 3)

Step	Action
	Telephone (voice or dialing) failure
1	<p>Check the line cord and handset cord to determine if all TELADAPT connectors are firmly in place and reconnect the loose ones. Ensure that the polarity of the Tip and Ring leads is correct.</p> <p>Lift the handset and listen for the dial tone and/or dial a directory number. If unsuccessful, proceed with Step 2.</p>
2	<p>Wiggle the line cord and/or handset cord while listening for sounds from the handset. If crackling or ticking sounds are heard, replace the cords.</p> <p>Try to establish a call. If unsuccessful, proceed with Step 3.</p>
3	<p>Replace the telephone.</p> <p>Try to establish a call. If unsuccessful, proceed with Step 4.</p>
4	<p>Check the wiring between the line card, distribution panel, and telephone for breaks or loose connections. If necessary, rerun the wiring.</p> <p>Operate the telephone.</p>
<p>Note: If no error codes are shown at the maintenance terminal, the Network and Signaling Diagnostic (LD 30) can be loaded and run manually from the system TTY. Refer to <i>Software Input/Output: Administration</i> (553-3001-311).</p>	

Designate telephones

Before designating telephones, check the work order for the features enabled and key designations. Designate each key by placing its feature name (from the designation sheet) in the key cap that fits on the key.

Follow the steps in Procedure 65 on [page 368](#) to designate Meridian Modular Telephones.

Procedure 65

Designating Meridian Modular Telephones

- 1 Remove the cap from each key requiring a designation.
- 2 Place the designation in the cap, place the cap over the corresponding key, and gently press down. Repeat for all keys requiring designations.
- 3 Insert a paper clip into the hole at the left or right end of the designation window.
- 4 Gently pry the window toward the center and remove, and insert the number tag.
- 5 Replace the designation window.

End of Procedure

Cross-connect the telephones

Follow the steps in Procedure 66 to cross-connect the telephones. Refer to Figure 64 on [page 370](#) for an illustration of cross-connections.

Procedure 66

Cross-connecting the telephones

- 1 Locate the telephone terminations at the cross-connect terminal.

Telephone terminations are located on the vertical side of the frame when frame-mounted blocks are used and in the blue field when wall-mounted blocks are used.
- 2 Connect Z-type cross-connecting wire to the leads of the telephone. See Table 63 on [page 369](#) and Table 64 on [page 369](#).
- 3 Locate the line circuit card (TN) terminations.

Line circuit card (TN) terminations are located on the horizontal side of the distributing frame when frame-mounted blocks are used and in the white field when wall-mounted blocks are used.
- 4 Run and connect the other end of the cross-connecting wire to the assigned TN terminal block.

End of Procedure


Table 63
Z-type cross-connecting wire

Size	Gauge	Color	Designation
1 pr	22	Y-BL	Tip
		BL-Y	Ring
3 pr	24	W-BL	Voice T
		BL-W	Voice R
		W-O	Signal T
		O-W	Signal R
		W-G	Power
		G-W	Power

Table 64
Inside wiring colors

Inside wiring colors		Connect to equipment TN
Z station wire	16/25-pair cable	
G	W-BL	First pair Tip
R	BL-W	First pair Ring
BK	W-O	Second pair Tip
Y	O-W	Second pair Ring

Figure 64
Meridian Modular Telephone cross-connections



Appendix C: Meridian Modular Telephones add-on modules installation

Contents

This section contains information on the following topics:

Packing and unpacking	372
Meridian Modular Telephones	373
Analog Terminal Adapter	375
Functional description	375
Meridian Communications Adapter and Meridian Programmable Data Adapter	381
Functional description	381
Power Supply Board (NTZK models).....	392
Power Supply Board (NT2K models).....	401
Installing displays	404
External Alerter Board	416
Key Expansion Modules	420
Asynchronous Data Option	423
Functional description	423
ADO operating parameters.....	424
ADO external power supply.....	424
M2317 Data Option.....	426
Meridian Communications Unit	430
Functional description	430

Wall mounting	432
Troubleshooting	433

Note: This section is for reference only. The telephone and options described in this chapter are manufacture discontinued and no longer available.

Packing and unpacking

Use proper care when unpacking any add-on module. Check for damaged containers so that appropriate claims can be made to the transport company for items damaged in transit.

If a module must be returned to the factory, pack it in the appropriate container to avoid damage during transit. Remember to include all loose parts in the shipment.

There are three distinct versions of Meridian Modular Telephones – all three are supported. The versions can be clearly distinguished by the first four letters in the upper left-hand corner of the model identification label on the bottom of the telephone.

The three versions are as follows:

- the “NTZK” models
- the “NT2K” models with date code prior to April 24, 1998
- the third version includes both the “NT9K” models and the “NT2K” models with date code of April 24, 1998 and later

In addition, the two jacks face in the same direction on “NT2K” and “NT9K” telephones, and in opposite directions on “NTZK” telephones. When appropriate, differences between the models are noted in this document.

Meridian Modular Telephones

Use the procedures in this section for adding hardware options to the M2006, M2008/M2008HF, M2016S, M2616, and M2216ACD telephones only.


**CAUTION****Damage to Equipment**

Use only the line cord provided with the Meridian Modular Telephone when installing and removing options. The acceptable line cord is A0346862.

Figure 65 on [page 374](#) shows an exploded view for reference when dismantling the telephone to get to its internal components. Some telephone types are slightly smaller than the M2616 and do not have the center screw in the base, but otherwise they are the same. The center screw may not be required.

Refer to Figure 71 on [page 395](#) to locate the various components of the M2006 and M2008/M2008HF telephones. Refer to Figure 72 on [page 396](#) to locate components on the M2616, M2016S, and M2216ACD telephones.

Figure 65
Exploded view of the M2616/M2016S/M2216ACD telephone



Analog Terminal Adapter

The Analog Terminal Adapter (ATA) enables the use of an off-the-shelf analog device (FAX, Modem, Telephone) to operate simultaneously with the Meridian Digital Telephones. The Analog Terminal Adapter board fits into the footstand space of the Meridian Digital Telephone.

Functional description

The Analog Terminal Adapter is mounted in the footstand of the Meridian Digital Telephone set. The ATA requires a separate AC adapter that provides a 24 V AC external power source. The ATA does not draw power from the Meridian Digital Telephone set.

The Analog Terminal Adapter (ATA) provides a RJ11 connection for analog equipment to operate on the same line as the Meridian Digital Telephone set. The Analog Terminal Adapter enables data to be transmitted and received using the public switched telephone network (PSTN). The ATA supports an analog device link to a desktop or laptop computer (with modems) in the digital telephone environment. Currently, it is necessary to install a separate analog phone line to be able to interface with the PSTN.

The ATA can be used for the following analog devices:

- FAX Machine
- Modem
- Analog Telephone

ATA operating parameters

The ATA data parameters are stored locally, although the configuration is set in the CS 1000 and Meridian 1 system. Do not set data parameters in the system before installing the ATA in the telephone. If the parameters are set before the telephone is installed, the configuration information is lost.

Simultaneous voice and data capabilities are available. When the ATA is installed, the System Administrator must activate the Flexible Voice and Data feature by configuring LD 11. See *Software Input/Output: Administration* (553-3001-311) for prompt and response details.

The ATA is capable of receiving dial pulse or DTMF address signaling from the analog equipment.

The ATA uses the 2nd channel of the TCM loop to add an analog port to the digital terminal. It has an RJ11 type jack accessible from the back of the telset.

The analog interface of the ATA is a 2-wire source, providing A and B leads (tip and ring) across which analog equipment (modem/fax) is connected. The loop length is >100 feet. The analog interface of the ATA is compatible with the port types listed in Table 65.

Table 65
Port types compatible with ATA

Country	Port Type(s)	Defining Standard(s)
United States	ONS Station Interface	EIA/Tia-464A
	Class A OPS Station Interface	FCC Rules Part 68
Canada	ONS Station Interface	CAN3-T512.1
	Class 1300 OPS Station Interface	CS-03 Part I

Refer to *Analog Terminal Adapter Quick Reference Card* for detailed information on this feature.

Follow the steps in Procedure 67 on [page 377](#) to add the Analog Terminal Adapter (ATA) to the telephone and to connect it to a FAX or modem. The ATA is supported on Meridian Digital Telephones only.

Procedure 67
Installing and removing the
Analog Terminal Adapter



CAUTION WITH ESDS DEVICES

Before handling internal telephone components, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

- 1 When the ATA is installed, the System Administrator must activate the Flexible Voice and Data Feature by configuring LD 11.
- 2 To Activate the Flexible Voice and Data Feature, use the following chart to configure LD 11 (for more detailed information, refer to *Software Input/Output: Administration* (553-3001-311)).

Table 66:
Flexible Voice and Data feature configuration (Part 1 of 2)


Prompt	Response	Description
REQ:	NEW/CHG	New or change
TYPE:	aaaa	Telephone type, where aaaa = 2006, 2008, 2016, or 2616
TN		Terminal Number, where u = 16-31
	l s c u	Format for Large System and CS 1000E system, and Media Gateway 1000E, where l = loop, s = shelf, c = card, u = unit.
	c u	Format for Small System, CS 1000S system, Media Gateway 1000B, and Media Gateway 1000T, where c = card and u = unit.
CLS	FLXA	Flexible voice/data allowed. This Class of Service can only be assigned to 2006, 2008, 2016, 2216 or 2617 sets. When configured to CLS=FLXA
	VCE	(FLXD) = Flexible voice/data denied. Voice Class of Service (VCE) can be assigned to the upper TN unit (16-31) and Data class of Service (DTA) can be assigned to the lower TN (0-15). A Single Call Ringing (SCR) key can be designated a Data Mode (DTNK) key.

Table 66:
Flexible Voice and Data feature configuration (Part 2 of 2)

Prompt	Response	Description
KEY		Prime Directory Number Key, SCR, SCN, MCR or MCN and xxx.
-Key	xx SCR yyyy	Single Call Ringing
	xx SCN yyyy	Single Call Non Ringing Data Mode Key, where xx = key number and yyy = Data Directory Number.


- 3 Disconnect and remove all cords (including the handset cord) from the telephone.
- 4 Place the telephone, face-down, on a padded level surface.
- 5 Using a #1 Phillips screw driver, remove both screws and separate the footstand from the phone base.
- 6 If using the NT9K ATA ready set or the NT2K with date code of April 24, 1998 or later:
 - Remove and retain the footstand (this footstand will be reattached back onto the set base after ATA installation is complete).
 - Skip to the ATA Installation Procedure 13 on [page 381](#).
- 7 If using the NT2K or the NTZK phone set, remove and discard the footstand. Use the redesigned footstand required for the installation of the ATA.
- 8 If an MCA or MPDA installed is installed, unplug it from the data line jack in the phone base.
- 9 Remove the back covering of the phone base by removing the four screws.

Figure 66
Telephone base and footstand



- 10** If the phone is equipped with a Power Option board and/or cable, you must remove it before installing the ATA. The Power Option board is located on the left side of the telephone:
- Remove the two small screws from the Power Option board (near the top) and set them aside.
 - To disconnect the Power Option board from the **NTZK** telephone, grasp the board firmly on each side and slowly rock the Power Option board while applying upward pressure until it is released from the 2X7 pin connector.
 - To disconnect the **NT2K** Power Option board from the set simply remove the screws from the Power Option board and base and lift the board out of the set.
 - If the Power Option board has a ribbon cable, disconnect the cable from the 2X7pin connector on the main board and remove the cable

Figure 67
Connector view



- 11** If the phone is equipped with the External Alerter Option, remove it before installing the ATA. The External Alerter Option board is located at the right center of the telephone:
 - Remove the screws from the External Alerter Option board.
 - Grasp the board firmly on each end and pull upward to remove from the 2X3 pin connector
- 12** Install the Jumper board on the 2X7 pin connector inside the phone set base.
 - There are 2 Jumper boards provided. Use the brown Jumper board for the NTZKxxxx phone set and the black Jumper board for the NT2Kxxxx phone set with a date code prior to April 24, 1998.
 - If a Power Option board was not installed on the NT2Kxxxx and the NTZKxxxx there will be 2 Jumper plugs on the 2X7 pin connector that must be removed before installing the Jumper board.

- 13** Remove the knockout located on the back panel of the footstand in order to install the ATA. It is the smaller knockout, located inside the large knockout. The small ATA knockout can be removed by pressing it in with a thumb presser.
- 14** Install the ATA Printed Circuit board into the footstand.
- 15** Plug the ATA 8-conductor line cord, included in the package, into the data jack in the base of the telephone. Plug the other end of this cord into the data jack of the ATA located in the footstand.
- 16** Reassemble the footstand on the base and screw it into position using a #1 Phillips screwdriver.
- 17** Plug the 24v AC Power Transformer into the circular mini DIN connector on the backpanel of the footstand.
- 18** Plug the transformer end of the AC Power Transformer into the AC commercial electrical outlet.
- 19** The analog device can now be connected to the RJ11 connector on the back of the footstand. Refer to the manufacturer's documentation for installation instructions for the FAX, modem, or telephone to be used.

End of Procedure

Meridian Communications Adapter and Meridian Programmable Data Adapter

The Meridian Communications Adapter (MCA) replaces the Meridian Programmable Data Adapter (MPDA), and offers enhanced capability over the MPDA.

Functional description

The MCA mounts within the telephone. It enables synchronous and asynchronous ASCII terminals and personal computers to be connected to the telephone using an RS-232-C or V.35 interface on a DB-25 connector. See Figure 68 on [page 385](#).

The MCA enables synchronous applications (DTEs such as video conferencing equipment and Group IV fax units) to be connected to the

telephone. System software enables access to data functions through both the keypad and service change in LD 11.

Asynchronous mode features supported by the MCA include the following:

- Asynchronous transmission at up to 19.2 kbps (autobaud)
- Enhanced Hayes commands, including upper- and lower-case dialing, voice call origination through AT dialing, hang-up data call, and on-line disconnect of voice call
- Script file capability that enables the MCA to learn a dial-up and log-on sequence that can be played back to automatically access a host or service
- Voice Call Origination (VCO)
- DCE mode
- Autodial
- Ring Again
- Speed Call
- Autobaud and Autoparity Detect
- Modem Pool Calling
- Host/Terminal Mode
- Forced Data Terminal Ready (DTR)
- Dynamic Carrier Detect (DCD)
- Inactivity Time-out
- Remote Loopback
- RTS/CTS hardware flow control capability (when calling another MCA)

Synchronous mode features supported by the MCA include the following:

- Half Duplex/Full Duplex
- Internal and external clocking
- Modem and network capability
- Synchronous transmission up to 64 kbps

- Public Switched Data Service (PSDS) compatibility. MCA extends PSDS and 64K restricted and 64K clear capabilities to Modular telephones.
- V.25 bit dialing protocol support at all synchronous speeds up to 64 kbps. High-Level Data Link Control (HDLC) and Bisynch (character oriented) framing of the V.25 commands are supported.
- Programmable echo canceller disabling for 56 and 64 kbps network calls

Synchronous *and* asynchronous mode features supported by the MCA include the following:

- T-Link and DM-DM support
- T-Link and DM-DM are Nortel proprietary protocols. The SL-100 and DMS data devices use T-Link. DM-DM is used by CS 1000 and Meridian 1 data devices such as ASIM, AIM, ADM, SADM, Asynchronous Data Option (ADO), and MPDA. MCA can use both DM-DM and T-Link.
- Hotline
- Virtual Leased Line
- V.35 interface capability selectable with jumper plugs on the MCA
- Data tandem calls across TIE trunks, provided all switches involved are Nortel machines
- PSDS tandem data calls across TIE trunks are supported with release 18 or later when each tandem node uses an ISDN Primary Rate Interface (PRI) or Basic Rate Interface (BRI) connection. See *Transparent Data Networking* (553-2731-110) for more information.

Note: Internal PSDS calls are not supported.

MCA operating parameters

The MCA data parameters are stored locally, although the configuration is set in the system. Data parameters cannot be set in the system before installing the MCA in the telephone. If the parameters are set before the telephone is installed, the configuration information is lost.

Operating parameters are downloaded after the MCA is enabled in LD 11. System parameters are downloaded when the MCA is configured in LD 11, and power is reset. See *Software Input/Output: Administration* (553-3001-311) for prompt and response details.

Data parameters can also be set through LD 11, as well as by the keypad.

The MCA communicates with Data Terminal Equipment (DTE) using the operating parameters shown below.

Synchronization	Asynchronous, Start-Stop
Number of bits	8 bits
Parity	none (unchecked)
Data rate	110, 150, 300, 1200, 2400, 4800, 9600, 19200 bits per second (autobaud) asynchronous up to 64000 bits per second synchronous
Stop bits	2 bits for 110 bits per second; 1 bit for all other speeds (asynchronous only)
Transmission	Half duplex; full duplex

When using the MCA for synchronous data connections, configure the telephone with a display option to view the data parameters. The MPDA and MCA are supported on Meridian Modular Telephones only.

When installing an MCA or MPDA into NTZK or NT2K phone sets with a date code prior to January 1998, a Power Option board is required, along with an additional power source.


When installing an MCA in an NT9K or NT2K phone set with date code of January 1998 or later, install only the MCA. An additional Power Option board and Jumper board is not required. See Table 55: “NT2K model Power requirements, Meridian Modular Telephone sets” on [page 347](#) for power requirements information.

- See Procedure 70 on [page 393](#) for M2006/M2008 NTZK sets.

- See Procedure 71 on [page 397](#) for M2616/M2216ACD NTZK sets.
- See Procedure 72 on [page 401](#) for M2006/M2008/M2008HF NT2K sets.
- See Procedure 67 on [page 377](#) for installing an MCA onto an NT9K or NT2K with date code of April 24, 1998 and later.

Figure 68 on [page 385](#) shows the back of a Modular telephone with an MCA mounted; Figure 69 on [page 386](#) shows a block diagram of the Modular telephone and MCA.


Figure 68
Back of telephone showing MCA



The MCA can be placed as far from its associated data terminal or computer port as is consistent with EIA RS-232 or V.35.

When the MCA is used as a V.35 interface, an additional cable is required to convert the DB-25 into a 34-pin rectangular connector. This does not apply to asynchronous configurations. If the pins are left in V.35 mode, asynchronous operation is not supported, and the MCA looks as though it is locked up.

Figure 69
Block diagram of MCA and Modular telephone



Remove the two 14-pin jumper plugs or one 20-pin jumper plug inside the MCA from the RS-232 socket(s) and install the V.35 socket.

Note: The female cable ordering code is A0408927. The male cable ordering code is A0408928. The A0300752 and A0300753 cables are still supported, unless used with applications similar to IBM front-end.

Modem pooling is not supported on the MCA.

When a call is connected between two MCAs, and power is removed from one, the MCA does not release until the power is restored.

The MCA always remembers the most recent data parameters. In the case of power failure, data settings do not have to be reset.

See Table 67 for a listing of the V.35 CCITT signals supported by the MCA.

Table 67
V.35 CCITT signals supported by the MCA (Part 1 of 2)

V.35 CCITT	MCA DB-25 pin no.	Abbr.	Adaptor cable		Signal Source		Description
			DB-25 Pin No.	V.35 Pin No.	DTE	MCA	
101	1	DG	1	A			Protective ground*
103A	2	SDA	2	P	X		Transmit data A
104A	3	RDA	3	R		X	Receive data A
105	4	RTS	4	C	X		Request to send
106	5	CTS	5	D		X	Clear to send
107	6	DSR	6	E		X	Data set ready
102	7	S	7	B			Signal ground
109	8	CD	8	F		X	Carrier detect
—	9/10	—	9/10	CC/L			No connection
—	11	—	11	K	X		**
115B	12	SCRIB	12	X		X	Serial clock receive B
103B	13	SDB	13	S	X		Transmit data B
114B	14	SCTB	14	AA		X	Serial clock transmit B
114A	15	SCTA	15	Y		X	Serial clock transmit A
104B	16	RDB	16	T		X	Receive data B
115A	17	SCRA	17	V		X	Serial clock receive A
—	18/19	—	18/19	M/HH			No connection
<p>Note: * Pin 1 is connected to the MCDS shelf frame. ** These leads are ignored by the MCA controller.</p>							

Table 67
V.35 CCITT signals supported by the MCA (Part 2 of 2)

V.35 CCITT	MCA DB-25 pin no.	Abbr.	Adaptor cable		Signal Source		Description
			DB-25 Pin No.	V.35 Pin No.	DTE	MCA	
108.2	20	DTR	20	H	X		Data terminal ready
—	21	—	21	EE			No connection
125	22	RI	22	J		X	Ring indicator
113B	23	SCTEB	23	W	X		Tran sign elemt time B
113A	24	SCTEA	24	U	X		Tran sign elemt time A
—	25	—	25	MM	X		**

Note: * Pin 1 is connected to the MCDS shelf frame.
 ** These leads are ignored by the MCA controller.

Use the following procedures to add the Meridian Communications Adapter (MCA) or Meridian Programmable Data Adapter (MPDA) to the telephone and to connect it to a terminal or personal computer.

See the *Meridian Communications Adapter User Guide* for more information on MCA operation.

Procedure 68
Installing and removing the Meridian
Communications Adapter or the Meridian
Programmable Data Adapter



CAUTION WITH ESDS DEVICES

Before handling internal telephone components, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

If using a NT9K phone or the NT2K with date code of April 24, 1998 and later, it is not necessary to install a Power Option board to operate the MCA.

- 1 Remove the handset and place the telephone upside down on top of a level, solid work surface (a desktop, for example) covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the footstand.
 - For NT2K and NTZK with date code prior to April 24, 1998 remove the two screws from the footstand assembly and unsnap the footstand by pressing inward at the back of the footstand where it meets the base and pull upward. Discard the footstand. The redesigned footstand ordered with the ATA is used instead.
 - For NT9K and NT2K with a date code of April 24, 1998 and later, retain the footstand and skip to Procedure 10 on [page 390](#).
- 4 If the telephone is not equipped with the Meridian Programmable Data Adapter (MPDA) or Meridian Communications Adapter (MCA), go to Procedure 6 on [page 389](#). If replacing an existing MPDA or MCA, carefully disconnect the end of the 8-pin TELADAPT jack plugged into the telephone by pressing firmly on the latch-tab and slowly lifting up.
- 5 Turn the telephone footstand assembly over and put it in the normal use position. Remove the two self-tapping screws that fasten the MPDA or MCA to the telephone footstand assembly and remove the MPDA or MCA by pulling outward and up. Go to Procedure 11 on [page 390](#) to replace the MPDA or MCA.
- 6 Remove the back covering of the phone base by removing the four screws.

- 7** If the NTZK or the NT2K (with date code prior to April 24, 1998) phone set is equipped with a Power Option board and/or cable, the Power Option board and/or cable must be removed before installing the MCA.

 - Remove the two small screws from the Power board (near the top) and set them aside.
 - To disconnect the Power Option board from the NTZK telephone, grasp the board firmly on each side and slowly rock the board while applying upward pressure, until it is released from the 2X7 pin connector.
 - To disconnect the NT2K Power Option board from the set, simply remove the screws from the base and lift the board out of the set.
 - If the Power Option board has a ribbon cable disconnect the cable from the 2X7 pin connector on the main board and remove the cable.

- 8** If the phone is equipped with the External Alerter board, it must be removed before installing the MCA with redesigned footstand.

 - The External Alerter board is located at the right center of the telephone.
 - Remove the screws from the board, grasp the board firmly on each end and pull upward to remove it from the 2X3 pin connector.


- 9** Install the Jumper board onto the 2X7 pin connector inside the phone base.

 - If the phone set did not have a Power Option board installed on the NT2K or the NTZK then there will be 2 Jumper plugs on the 2X7 connector. Remove them before installing the Jumper board.
 - The redesigned footstand will have 2 jumpers. Use the black one for the NT2K phone and the brown one for the NTZK phone.

- 10** Remove the large MCA knockout section in the rear of the telephone footstand assembly, and remove the small tabs. See Figure 70. It is best to remove this knockout with a screwdriver.

- 11** For MCA, set option plugs to the required configuration, RS-232 or V.35. The factory default is RS-232.

Figure 70
Installing the MCA



- 12** Tilt the MPDA or MCA circuit board up and insert the DB-25 connector socket into the breakout section. Then slide the board connector end-first under the tabs in the footstand assembly and position it over the locating pins. Position and lower it completely onto the telephone footstand assembly. Insert the two self-tapping Phillips-head screws supplied with the MPDA or MCA into the mounting holes and tighten them with a #1 Phillips screwdriver.
- 13** Plug one end of an 8-conductor line cord supplied with a TELADAPT adapter in the jack J1 of the MPDA or MCA (latch tab facing down) and plug the other end of the line cord into the data jack in the base of the telephone. Make certain the latch tab of each cable end is firmly snapped into place.
- 14** Carefully route the excess cable so that it will not become pinched between the footstand and base.
- 15** Reassemble the base and footstand assembly sections, ensuring that the footstand is firmly seated on the base.

16 Tighten the screws

- Reconnect all cords, connect the new 24v AC transformer to the set.
- Plug in the new transformer into the 110v AC commercial electrical outlet.
- Place the telephone in the normal operating position.

Note 1: Place the label supplied with the MPDA or MCA on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.

Note 2: If an ADM3, ADM5, or ADM11 terminal is used in conjunction with the DB-25 connector-C interface connector in the Asynchronous Programmable Data Adapter, pin 22 in the DB-25 connector cable must be disconnected. These ADM terminals will go into test mode if this pin is not disconnected.

End of Procedure

Procedure 69

Connecting the data terminal

- 1 Connect the DB-25 connector-C interface connector from the data terminal to the matching header connector in the back of the telephone.
- 2 Insert the two captive screws in the connector body into the threaded holes in the header connector and secure tightly to prevent accidental disconnection during data terminal operation.

End of Procedure

Power Supply Board (NTZK models)

Use the following procedures to add a Power Supply Board to the telephone for connection to a transformer or closet power supply. Use Procedure 70 on [page 393](#) for the M2006 and M2008. Use Procedure 71 on [page 397](#) for the M2616 and M2216ACD.

Procedure 70
Installing and removing the M2006/M2008
Power Supply Board on NTZK sets



CAUTION

Damage to Equipment

Connect the optional Power Supply to the Meridian Modular Telephones only. Equipment damage may result from incorrect connections. Both the closet power supply and the transformer are for use with the Meridian Modular Telephones only.



CAUTION WITH ESDS DEVICES

Before handling internal telephone components, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

- 1 Remove the handset and place the telephone upside down on top of a level, solid work surface (such as a desktop) covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the two screws from the footstand assembly and unsnap the footstand assembly by pressing inward at the back of the footstand where it meets the base and pulling upward.
- 4 If the telephone is equipped with a Meridian Programmable Data Adapter (MPDA) or Meridian Communications Adapter (MCA), unplug the data cable from telephone's base jack.
- 5 Remove the four screws securing the base of the telephone to the top cover. Remove the base and set it aside.
- 6 If the telephone is equipped with a display, disconnect the display ribbon cable from the display board and move it out of the way.
- 7 If the telephone is not equipped with the power supply board, remove the jumpers from P1 connector pins on the main board. Go to step 9.
If the telephone is equipped with a power supply board, go to step 8.

- 8 The power supply board is located on the left side of the telephone. Remove two small screws from the power supply board (near the top) and set them aside. Grasp the board firmly on each side. Work the board loose from the connector by slowly applying upward pressure to alternate sides until released.

If the power supply board is not being replaced, place the jumpers (A0288529) connecting the bottom two sets of pins on the P1 connector.

- 9 Place the power supply board so that the alignment pin on the telephone fits into Slot A on the board. See Figure 71 on [page 395](#) and Figure 72 on [page 396](#). Align the mounting holes in the board (near the top) over the mounting holes in the telephone and carefully press down so that the H1 connector on the board slides onto the P1 pins.
- 10 Take the self-tapping Phillips-head screws supplied with the power supply board and install them into the mounting holes. Tighten firmly with a #1 Phillips screwdriver.
- 11 If the telephone has a display, reconnect the display ribbon cable, routing the cable as described in Procedure 73 on [page 405](#).

Note: Do not allow R5 on the power supply board to become bent during this procedure.

- 12 Replace the base. If the telephone is equipped with an MPDA or MCA, reconnect the data cable to the base telephone jack and replace the footstand (ensuring that the MPDA or MCA cable does not get pinched between the base and footstand). Make sure the footstand is firmly seated to the base.

Note: Place the label supplied with the power supply board on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.

- 13 Tighten all screws, reconnect the line cord, and place the telephone in the normal operating position.

Figure 71
M2006/M2008 telephone and option boards





Figure 72
M2616/M2216ACD telephone and option boards



Procedure 71**Installing and removing the M2616/M2216ACD
Power Supply Board on NTZK sets****CAUTION WITH ESDS DEVICES**

Before handling internal telephone components, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

- 1 Remove the handset and place the telephone upside down on top of a level, solid work surface (such as a desktop) covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the two screws from the footstand assembly and unsnap the footstand assembly by pressing inward at the back of the footstand where it meets the base and pulling upward.
- 4 If the telephone is equipped with an MPDA or MCA, unplug the data cable from the base telephone jack.
- 5 Remove the four or five screws securing the base to the top cover. Remove the base and set it aside.
- 6 If the telephone is equipped with display, disconnect the Display ribbon cable from the display board and move it out of the way.
- 7 If the telephone is not equipped with a power supply board, remove jumpers from the P1 connector pins on the main board. Go to step 9.
If the telephone is equipped with a power supply board, go to step 8.
- 8 The power supply board is located on the left side of the telephone. Remove two small screws from the power supply board (near the top) and set them aside. Grasp the board firmly on each side. Work the board loose slowly until it is released.
If not replacing the power supply board, place the jumpers (A0288529) connecting the bottom two sets of the pins on the P1 connector.
- 9 Place the power supply board so that Slot B fits into the alignment pin on the telephone. See Figure 70 on [page 391](#). Align the mounting holes in the board (near the top) over mounting holes in the telephone and carefully press down so that the H1 connector on the board slides onto the pins of the header (P1 on the M2616 or J2 on the M2006/M2008).

- 10 Take the self-tapping Phillips-head screws supplied with the power supply board and install them into the mounting holes. Tighten firmly with a #1 Phillips screwdriver.
- 11 If the telephone has a display, reconnect the display ribbon cable, routing the cable as described in Procedure 73 on [page 405](#).
Note: Do not allow R5 on the power supply board to become bent during this procedure.
- 12 Replace the base. If the telephone is equipped with an MPDA or MCA, reconnect the data cable to the base telephone jack and replace the footstand (ensuring the MPDA or MCA cable does not get pinched between the base and footstand). Make sure the footstand is firmly seated to the base.
Note: Place the label supplied with the power supply board on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.
- 13 Connect the telephone to a local transformer (see Figure 73 on [page 399](#)) or closet power supply (see Figure 74 on [page 400](#)). Refer to “Power requirements” on [page 345](#) for requirements.

End of Procedure

Figure 73
Configuration of a local plug-in transformer





Figure 74
Closet power supply configuration



Power Supply Board (NT2K models)

Follow the steps in Procedure 72 to add a Power Supply Board to the telephone for connection to a transformer or closet power supply. This procedure applies to the M2006, M2008/M2008HF, M2216ACD and M2616 Meridian Modular telephones, NT2K models.



CAUTION

Damage to Equipment

Connect the optional Power Supply to the Meridian Modular Telephones only. Equipment damage may result from incorrect connections. Both the closet power supply and the transformer are for use with the Meridian Modular Telephones2000 Series Meridian Digital Telephone only.

Procedure 72

Installing and removing the M2006 or M2008

Power Supply Board on NT2K sets



CAUTION WITH ESDS DEVICES

Before handling internal components of telephones, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

Opening the Telephone

- 1 Disconnect and remove all cords (including the handset) from the telephone.
- 2 Place the telephone, upside-down, on a padded, level surface.
- 3 If the telephone does not have an MCA or MPDA adapter, go to step 7.
- 4 Using a #1 Phillips screwdriver, remove both screws from the footstand.
- 5 Remove the footstand from the base by pressing in the back of the footstand as it is lifted from the base.
- 6 Unplug the MCA or MPDA from the data line jack on the base, and set the footstand aside.
- 7 Remove all screws on the base of the telephone.

- 8 Remove the base from the telephone.

Attaching the Power Module

- 9 Lay the Power Module assembly into position on the left side of the telephone. Be careful not to bend R5 (the big disk) on the Power Module during installation.
- 10 If you are adding a Power Module to the set for the first time (not replacing an existing Power Module), the connector (J2 on the M2006 and M2008/M2008HF, P1 on the M2616) on the main board should have jumpers which must be removed at this point.
- 11 Connect the Power Module to the main board with the ribbon cable, keeping the red edge of the ribbon cable from the front of the telephone as show in Figure 75.




CAUTION **Damage to Equipment**

This is a polarity-sensitive connection. The cable and the connector on the main board (J2 on the M2006 and M2008/M2008HF, and P1 on the M2616) are keyed.

- 12 Screw the Power Module into position on the left side of the telephone.

Figure 75
Ribbon cable placement



Reattaching the Base

- 13 Make sure that all ribbon cables are lying flat and not caught on any posts on the telephone cover or base.



CAUTION

For the M2616 and M2008HF, make sure that the microphone has not been moved from its black rubber holder. The holder should be seated in the main board near the ribbon cable that was just attached.

- 14 Replace the base.
- 15 Insert all screws and tighten them.
- 16 If the telephone has an MCA or MPDA, plug its cable into the jack on the telephone base.
- 17 Install the footstand, and secure it with two screws.
- 18 Reconnect all cords, including the handset.

Note: Place the label supplied with the power supply board on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.

End of Procedure

Installing displays

The following procedures cover installation of the various displays on the various sets.

- Procedure 73: “Installing and removing the M2616/M2216ACD Display on NTZK sets” on [page 405](#)
- Procedure 74: “Installing and removing the M2616 Display on NT2K sets” on [page 408](#)
- Procedure 75: “Installing NT2K28AA displays on NTZK or NT2K sets” on [page 411](#)

Procedure 73**Installing and removing the M2616/M2216ACD****Display on NTZK sets****CAUTION WITH ESDS DEVICES**

Before handling internal components of telephones, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

- 1 Remove the handset and place the telephone upside down on top of a level, solid work surface covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the two screws from the footstand assembly and unsnap the footstand assembly by pressing inward at the back of the footstand where it meets the base and pulling upward.
- 4 If the telephone is equipped with an MPDA or MCA, unplug the data cable from the base telephone jack. Remove the five screws securing the base to the telephone. Remove the base and set it aside.
- 5 If the telephone is not equipped with a display, go to step 9. If the telephone is equipped with a display, go to step 6.

Removing the display board

- 6 The display board is located at the left center of the telephone. Disconnect the display ribbon cable from the display board. Remove the small mounting screw from the board. Grasp the board firmly on each end and pull upward to remove it. To replace it, go to step 9.

Removing the display

- 7 The power supply board is located on the left side of the telephone. Remove the two small screws from the power supply board (near the top) and set them aside. Grasp the board firmly on each side. Carefully work the board loose until released.
- 8 Remove the two or three screws from the display Module. Remove the display from the telephone. To install the display, go to step 11.

Installing the display board

- 9 Place the J1 connector of the display board over the P2 pins of the telephone (see Figure 76 on [page 407](#)). Press down slowly until J1 slides onto the P2 pins and is firmly seated.

Note: If the center screw is included, do not perform step 10.

- 10 Insert the self-tapping Phillips-head screw supplied with the display into the mounting hole (near the top). Tighten firmly with a #1 Phillips screwdriver.

Installing the display

- 11 Place the display face-down near the top of the telephone and align the two mounting holes of the display with the mounting holes in the telephone.
- 12 Insert two self-tapping Phillips-head screws from the faceplate into the mounting holes; tighten them firmly with a #1 Phillips screwdriver.
- 13 Install the power supply board (see Procedure 71 on [page 397](#)). This step is not necessary on M2616 unless there are other hardware options.
- 14 Fold the ribbon cable near the connector to align it with the J2 pins on the display board, ensuring that the notch on the ribbon cable is facing toward the display board. Carefully work the ribbon cable connector onto the J2 pins until firmly seated. Route the cable flat beside the power supply board, gathering excess cable under the display. Be careful not to press the cable beneath the alignment posts or studs of the base. See Figure 76 on [page 407](#).


Note: Do not allow R5 on the power supply board to become bent during this procedure.

- 15 Replace the base. If the telephone is equipped with an MPDA or MCA, reconnect the data cable to the base telephone jack and replace the footstand (ensuring that the MPDA or MCA cable does not get pinched between the base and the footstand). Make sure the footstand is firmly seated in the base.

Note: Place the label supplied with the display on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.

- 16 Tighten all screws, reconnect all cords, and place the telephone in the normal operating position.

Figure 76
Display cable routing



- 17 Perform the self-test (see Procedure 62 on [page 358](#)) and acceptance test procedures. See LD 31 in the *Software Input/Output: Administration* (553-3001-311).

End of Procedure

Procedure 74
Installing and removing the M2616 Display
on NT2K sets



CAUTION WITH ESDS DEVICES

Before handling internal components of telephones, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

- 1 Remove the handset and place the telephone upside down on top of a level, solid work surface covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the two screws from the footstand assembly and unsnap the footstand assembly by pressing inward at the back of the footstand where it meets the base and pulling upward.
- 4 If the telephone is equipped with an MPDA or MCA, unplug the data cable from the base telephone jack. Remove the five screws securing the base to the telephone. Remove the base and set it aside.
- 5 If the telephone is not equipped with a display, go to step 9. If the telephone is equipped with a display, go to step 6.

Removing the display board

- 6 The display board is located at the left center of the telephone. Disconnect the display ribbon cable from the display board. Remove the small mounting screw from the board. Grasp the board firmly on each end and pull upward to remove it. To replace it, go to step 9.


Removing the display

- 7 The power supply board is located on the left side of the telephone. Remove the two small screws from the power supply board (near the top) and set them aside. Grasp the board firmly on each side. Carefully work the board loose until released.
- 8 Remove the two or three screws from the display Module. Remove the display from the telephone. To install the display, go to step 11.

Installing the display board

- 9 Place the J1 connector of the display board over the P4 pins of the telephone (see Figure 77 on [page 409](#)). Press down slowly until J1 slides onto the P4 pins and is firmly seated.

Figure 77
Connecting the cable to the display board



- 10 Insert the self-tapping Phillips-head screw supplied with the display into the mounting hole (near the top). Tighten firmly with a #1 Phillips screwdriver.

Installing the display

- 11 Place the display face-down near the top of the telephone and align the two mounting holes of the display with the mounting holes in the telephone.
- 12 Insert two self-tapping Phillips-head screws from the faceplate into the mounting holes; tighten them firmly with a #1 Phillips screwdriver.
- 13 Install the power supply board (see Procedure 71 on [page 397](#)). This step is not necessary on the M2616 unless there are other hardware options.
- 14 Fold the ribbon cable near the connector to align it with the J2 pins on the display board, ensuring that the notch on the ribbon cable is facing toward the display board. Carefully work the ribbon cable connector onto the J2 pins until firmly seated. Route the cable flat beside the power supply board, gathering excess cable under the display. Be careful not to press the cable beneath the alignment posts or studs of the base. See Figure 77 on [page 409](#).

Note: Do not allow R5 on the power supply board to become bent during this procedure.

- 15 Replace the base. If the telephone is equipped with an MPDA or MCA, reconnect the data cable to the base telephone jack and replace the footstand (ensuring that the MPDA or MCA cable does not get pinched between the base and the footstand). Make sure the footstand is firmly seated in the base.

Note: Place the label supplied with the display on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.

- 16 Tighten all screws, reconnect all cords, and place the telephone in the normal operating position.
- 17 Perform the self-test (see) and acceptance test procedures. See LD 31 in the *Software Input/Output: Administration* (553-3001-311).

End of Procedure

Procedure 75
Installing NT2K28AA displays on
NTZK or NT2K sets

Follow this procedure to add an NT2K28xx display to M2008 and M2616 telephones.

**CAUTION WITH ESDS DEVICES**

Before handling internal components of telephones, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

Opening the Telephone

- 1 Disconnect and remove all cords (including the handset) from the telephone.
- 2 Place the telephone, upside-down, on a padded, level surface.
- 3 Using a #1 Phillips screwdriver, remove the two screws from the footstand.
- 4 Carefully remove the footstand from the base. Press inward at the back of the footstand where it meets the base and pull upward.
- 5 If the telephone has a Meridian Communications Adapter, unplug its cable from the base telephone jack.
- 6 Loosen all screws on the base of the telephone.
- 7 Remove the base from the telephone.


Removing the Fillerplate

- 8 Loosen the screws that hold the fillerplate.
- 9 Remove the fillerplate, being careful not to touch the foam in the speaker housing.

Attaching the Display Module

- 10 Position the Display Module as shown in Figure 78 on [page 412](#).
- 11 Lower the Display Module into place.

Figure 78
Positioning the display module



12 Insert the fillerplate screws in the Display Module screw holes


13 Tighten the fillerplate screws.

Note: Place the label supplied with the display on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.

Connecting the Display Module Ribbon Cable


- 14 If installed, remove and discard the NT2K0013 daughterboard.
- 15 **NTZK models:** Make sure that the ribbon cable is folded as shown in Figure 79.

Figure 79
Connecting the Display Module Ribbon Cable, NTZK model



- 16 **NT2K models:** Make sure that the ribbon cable is folded as shown in Figure 80 on [page 414](#).

Figure 80
Connecting the Display Module Ribbon Cable, NT2K model



- 17 Make sure the red line on the ribbon cable lines up with the white dot beside the connector pins (P2 on an NT2K M2008, J3 on an NT2K M2008, and P4 on an M2616) on the motherboard.

- 18 Slide the ribbon cable connector onto the connector pins (P2 on an NTZK M2008, J3 on an NT2K M2008, and P4 on an M2616) on the mother board.



CAUTION

This connection is polarity sensitive.

- 19 Ensure that the pins line up with the connector correctly and carefully work the connector on until it is firmly seated.

Reattaching the Base

- 20 Make sure the ribbon cable is lying flat and not caught over or under any alignment posts or studs on the telephone base. (For the M2616, allow it to cover the screw post and do not replace the screw on re-assembly.)
- 21 Replace the base.
- 22 Insert all screws (except the center screw on the M2616) and tighten them.

Reattaching the Footstand

- 23 If the telephone has a Meridian Programmable Data Adapter (MPDA) or Meridian Communications Adapter (MCA), plug its cable into the jack on the telephone base.
- 24 Replace the footstand, positioning it firmly on the base.
- 25 Insert and tighten all screws.

Note: Place the label supplied with the display on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.

Reconnecting the Telephone

- 26 Reconnect all cords.

- 27 Turn the telephone right-side-up and place it in a normal operating position.
- 28 Reconnect the handset.

End of Procedure

External Alerter Board

Use Procedure 76 on [page 416](#) to add an External Alerter Board to the M2006, M2008, M2216ACD, or M2616 telephone. See Figure 81 on [page 418](#) for information on hooking up the third-party External Alerter device.

Procedure 76 **Installing and removing the** **External Alerter Board**



CAUTION WITH ESDS DEVICES

Before handling internal components of telephones, discharge static electricity from hands and tools by touching any grounded metal surface or conductor.

- 1 Remove the handset and place the telephone upside down on a level, solid work surface covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the two screws from the footstand assembly and unsnap the footstand assembly by pressing inward at the back of the footstand where it meets the base and pulling upward.
- 4 If the telephone is equipped with an MPDA or MCA, unplug the data cable from the base telephone jack.
- 5 Remove the four screws securing the base of the telephone to the top cover. Remove the base and set aside.
- 6 If the telephone is not equipped with an External Alerter Board, go to step 8. If replacing an existing External Alerter Board, go to step 7.

Removing the External Alerter Board

- 7 The External Alerter Board is located at the right center of the telephone. Remove the screws from the board. Grasp the board firmly on each end and pull upward to remove.

Installing the External Alerter Board

- 8 Place the H1 connector of the External Alerter Board over the P3 pins of the telephone (see Figure 71 on [page 395](#) for M2006/M2008; see Figure 72 on [page 396](#) for M2616/M2216ACD). Align the mounting hole over the mounting post. Carefully work H1 onto the P3 pins until firmly seated. Place the self-tapping Phillips-head screw supplied with the External Alerter Board into the mounting hole and tighten it with a #1 Phillips screwdriver.
- 9 To signal the External Alerter when the telephone's handset or speaker is active, place the jumpers (AO288529) connecting the two right-most pins on the alerter board.

To signal the External Alerter when the telephone is ringing or buzzing, place the jumpers connecting the two left-most pins on the External Alerter Board.


- 10 If the telephone is not yet equipped with the power supply board, install it (see Procedure 70 on [page 393](#) for M2006/M2008; see Procedure 71 on [page 397](#) for M2616/M2016S/M2216ACD).

Note: Do not allow R5 on the power supply board to become bent during this procedure.

- 11 Replace the base. If the telephone is equipped with an MPDA or MCA, reconnect the data cable to the base telephone jack and replace the footstand (ensuring that the MPDA or MCA cable does not get pinched between the base and the footstand). Make sure the footstand is firmly seated in the base.
- 12 Tighten all screws, reconnect the line cord, and place the telephone in the normal operating position.
Note: Place the label supplied with the External Alerter on the outside of the bottom cover of the telephone. This allows proper identification and tracking of the option level of the set.
- 13 For the connecting block configuration, see Figure 81.

- 14 Perform the self-test (see Procedure 62 on [page 358](#)) and acceptance test procedures. See LD 31 in the *Software Input/Output: Administration* (553-3001-311).

Figure 81
External Alerter connecting block configuration



————— **End of Procedure** —————

Key Expansion Modules

Follow the steps in Procedure 77 to add one (single) or two (double) Key Expansion Modules to the M2616 or M2216ACD telephones.

Note 1: Have the associated footstand on hand before installing the Key Expansion Modules.

Note 2: Adding a Key Expansion Module to a telephone requires a power supply board along with an additional power source (see Procedure 70 on [page 393](#) for the M2006/M2008; see Procedure 71 on [page 397](#) for the M2616/M2216ACD).

Procedure 77

Installing and removing Key Expansion Module(s) on the M2616 and M2216ACD telephones

- 1 Remove the handset and place the telephone upside down on top of a level, solid work surface covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the two screws from the footstand assembly and unsnap the footstand assembly from the telephone by pressing inward at the back of the footstand where it meets the base and pulling upward.

Note: If the M2616/M2216ACD is equipped with a Meridian Programmable Data Adapter (MPDA) or Meridian Communications Adapter (MCA), it must be removed and installed into the Key Expansion Module footstand. Use Procedure 68 on [page 389](#).

- 4 If the telephone is not equipped with a Key Expansion Module(s), go to step 7. If replacing the Key Expansion Module(s), go to step 5.

Removing the Key Expansion Module(s)

- 5 Remove the screws from the footstand assembly (where it meets the Key Expansion Module), and unsnap the footstand assembly from the Key Expansion Module and telephone by pressing inward at the back of the footstand where it meets the base and pulling upward.

- 6 Remove the interface cable from the telephone by pressing down on the locking tab. If equipped, remove the interface cable from the first Key Expansion Module (closest to the telephone).

Installing the Key Expansion Module(s)

- 7 If the telephone is not yet equipped with the power supply board, install the Power Board (see Procedure 71 on [page 397](#)).
- 8 Align the bottom of the Key Expansion Module(s) to the bottom of the telephone (see Figure 82 on [page 422](#)).
- 9 Snap the ribbon cable connector into the bottom interface jack on the Key Expansion Module.

Note: Use the cable supplied with the module. This is a special cable required for EMI compliance.

Snap the other end of the ribbon cable into the interface jack in the telephone (left side). Gather the excess cable in the base of the Key Expansion Module.

- 10 To add a second Key Expansion Module, snap a second ribbon cable connector into the bottom interface jack on the second Key Expansion Module. Snap the other end of the ribbon cable into the top interface jack on the first Key Expansion Module (see Figure 82 on [page 422](#)). Gather the excess cable in the base of the second Key Expansion Module.
- 11 If the telephone is equipped with an MPDA or MCA, reconnect the data cable to the base telephone jack. Make sure the MPDA or MCA cable (and interface cable) do not get pinched between the base and footstand.
- 12 Secure the footstand to the Key Expansion Module(s) and telephone by placing the tabs of the footstand into the slots provided on the base of the Key Expansion Module and telephone and pressing down. Make sure the footstand is firmly seated on the base.

Note: Use the cable supplied with the module. This is a special cable required for EMI compliance. Newer versions of the Key Expansion Module use a longer modified cable than was used on earlier versions.


Ensure that the ribbon cable(s) are not pinched between the footstand and mounting posts.

- 13 Insert the three (four if there are two modules) self-tapping, Phillips-head screws supplied with the Key Expansion Module into the mounting holes in the bottom of the footstand. Tighten firmly with a #1 Phillips screwdriver.

Note: Place the label supplied with the Key Expansion Module(s) on the outside of the bottom cover or footstand of the telephone. This allows proper identification and tracking of the option level of the set.

- 14 Perform the self-test (see Procedure 62 on [page 358](#)) and acceptance test procedures. See LD 31 in the *Software Input/Output: Administration* (553-3001-311).

Figure 82
Key Expansion Module connections (bottom view)



————— End of Procedure —————

Asynchronous Data Option

The Meridian Modular Telephones can be equipped with an Asynchronous Data Option (ADO) to enable a data call to be made using keyboard dialing from an attached terminal or personal computer. Voice and data communications can be conducted simultaneously without causing any mutual interference.

Functional description

The ADO is mounted in the telephone and works in conjunction with the Digital Interface Chip to provide asynchronous communication up to 19.2 kbps from an ASCII data terminal or a personal computer to the private Integrated Services Network. The ADO appears as Data Communications Equipment (DCE) in the terminal and connects to the Data Terminal Equipment (DTE) through an RS-232-C connector mounted on the ADO printed circuit board.

The Asynchronous Data Option supports the following:

- Hayes dialing
- Automatic data rate detection at all rates up to 19.2 kbps
- ASCII keyboard dialing (originating data calls to local and remote hosts or DTE by using the terminal keyboard)
- Call origination to local and remote hosts
- Call termination
- Ring Again Capability
- Auto Dial
- Speed Call
- Automatic or Manual answering of incoming data calls
- Manual Modem pooling
- Remote loopback
- Break detection and generation

ADO operating parameters

Table 68 shows the operating parameters for the ADO.

Table 68
ADO operating parameters

Data type	ASCII
Synchronization	Asynchronous, Start-Stop
Number of bits	8 bits
Parity	none (unchecked)
Data rate	300, 1200, 2400, 4800, 9600, 19200 bits per second (autobaud)
Stop bits	2 bits for 110 bits per second; 1 bit for all other speeds
Transmission	Full duplex

The ADO supports asynchronous ASCII operation. A data byte is received from the terminal or PC, a control byte is added, and the two bytes are transferred to the associated line card. In the other direction, two data bytes are received from the line card, the control byte is deleted, and the data byte is delivered to the terminal in a bit serial format, at the terminal's bit rate.

ADO external power supply

The ADO requires an external power supply in addition to the power from the line. See Table 69 on [page 425](#). A 110 V AC 60 Hz, 100 V AC 50/60 Hz, or a 220 V AC 50 Hz multi-output power supply unit provides nominal voltages of +5 V, +12 V, and -12 V DC. The power supply connects to the back of the telephone through a 5-pin Molex power connector.

If the AC power supply fails, data calls cannot be processed. All external power supplies are equipped with short circuit and thermal shutdown protection.


Table 69 lists the input and output requirements for the ADO external power supply.

Table 69
I/O requirements for ADO external power supply

North American version	
NPS50220-03L5	Multi-output external power supply (A0336823), UL listed and CSA approved
Input:	57–63 Hz 115–132 V AC
Output:	+5 V DC, 1.0 A (pin 3 for supply, pin 2 for return) +12 V DC, 200 mA (pin 6 for supply, pin 1 for return) –12 V DC, 200 mA (pin 4 for supply, pin 1 for return)
Japanese version	
NPS50220-03L8	Multi-output external power supply (A0336891), Japan Standard (“T” Mark)
Input:	47–63 Hz 85–115 V AC
Output:	+5 V DC, 1.0 A (pin 3 for supply, pin 2 for return) +12 V DC, 200 mA (pin 6 for supply, pin 1 for return) –12 V DC, 200 mA (pin 4 for supply, pin 1 for return)
European version	
NPS50220-03L5	Multi-output external power supply (A0336166), conforming to NPS50561 general requirements and UL1012
Input:	57–63 Hz 200–240 V AC
Output:	+5 V DC, 1.0 A (pin 3 for supply, pin 2 for return) +12 V DC, 200 mA (pin 6 for supply, pin 1 for return) –12 V DC, 200 mA (pin 4 for supply, pin 1 for return)

Figure 83 shows a block diagram of the ADO and an M2317 telephone.

Figure 83
Block diagram of ADO and M2317 telephone



See the *Asynchronous Data User Guide* and the *M2317 Quick Reference Card*, for more information on ADO operation.

M2317 Data Option

If an existing digital telephone was not originally equipped with the Data Option, or if the existing Data Option has become defective, that option can

be added or replaced. Procedure 78 explains how to install the Data Option for the M2317 telephone.

**CAUTION WITH ESDS DEVICES**

CMOS devices inside the telephone can be damaged by electrostatic discharge. Before opening any M2317 telephone, discharge your hands and tools by touching any grounded metal surface or conductor.

Procedure 78
Installing the M2317 data option

- 1 Remove the handset, and place the telephone upside down on a level workplace (a desktop, for example).
- 2 Disconnect all cords from the telephone.
- 3 Loosen and remove five screws in the base of the telephone, lifting the base upward.
- 4 If the telephone is not equipped with the ADO, proceed with step 5.

If the telephone is equipped with a defective ADO, carefully disconnect the ribbon cable connector from the header connector in the digital printed circuit board. Loosen and remove the two self-tapping screws that fasten the ADO to the telephone base and remove the defective ADO. Proceed with step 6. See Figure 84 on [page 429](#).
- 5 Remove the breakout section in the rear of the telephone base by tapping it with the handle of a small screwdriver.
- 6 Place the black plastic connector shroud over the RS-232-C interface connector.

Note: It is not possible to install the shroud after the board has been inserted in the telephone base.
- 7 Tip the circuit board up and insert it, connector end first, under the tabs in the base. Position it over the molded locating pins; then lower the board completely into position in the telephone base. Use the three slotted, self-tapping screws supplied with the board and install them through the mounting holes. Tighten the screws.
- 8 Plug the ribbon cable connector into the header connector, located on the existing circuit board of the telephone (mounted on the faceplate assembly). Only one such connector is located on the telephone's circuit board. Make sure the connector is snug.

- 9 Reassemble the telephone by placing the base section on the faceplate section. Reinstall the five screws.
- 10 Tighten the screws, reconnect all cords, and place the telephone in its former position.
- 11 Refer to Procedure 79 to connect the power supply and data terminal to the ADO.

End of Procedure

Procedure 79
Installing the M2317 data terminal

- 1 Connect the RS-232-C interface connector from the data terminal to the matching header connector in the back of the telephone. See Figure 84 on [page 429](#).
- 2 Insert the two captive screws in the connector body into the threaded holes in the header connector. Secure them tightly to prevent accidental disconnection during data terminal operation.
- 3 Insert the keyed power supply plug securely into the 5-pin power connector located to the right of the RS-232-C connector.
- 4 Plug the wall transformer into the nearest AC outlet. The data terminal is now operational.

Note 1: If an ADM3, ADM5, or ADM11 terminal is used in conjunction with the RS-232-C connector in the Asynchronous Data Option, pin 22 in the RS-232-C cable must be disconnected. These ADM terminals will go into test mode if this pin is not disconnected.

Note 2: A special 9-pin connector is required to connect the Apple Macintosh to the RS-232-C connector in the Meridian Modular Telephone Asynchronous Data Option. The connections are shown in Table 70 on [page 429](#).

End of Procedure

Figure 84
M2317 data terminal and Data Option power supply connection




Table 70
Connections for the Apple Macintosh to the M2317
Asynchronous Data Option (ADO)

9-pin connector (from terminal)		25-pin (RS-232-C) connector (at ADO port)
Pin 3	to	Pin 7
Pin 5	to	Pin 2
Pin 9	to	Pin 3
Note: Strap pins 4 and 5 and pins 6, 8, and 20 together.		

Table 71
RS-232-C signals and associated pin numbers for M2317 telephones

Circuit designation			Pin number	Signal source		
EIA	Common	CCITT		DTE	DCE	Name
AA		101	1		X	Frame ground
BA	TXD	103	2	X		Transmit data
BB	RXD	104	3		X	Receive data
CA	RTS	105	4	X		Request to send
CB	CTS	106	5		X	Clear to send
CC	DSR	107	6		X	Data set ready
AB	GND	102	7	X		Signal ground
CD	DTR	108.2	20	X		Data terminal ready
CE	RI	125	22		X	Ring indicator

Meridian Communications Unit

The Meridian Communications Unit (MCU) provides a stand-alone version of the Meridian Communications Adapter (MCA).

Functional description

The Meridian Communications Unit (MCU) enables data to be transmitted and received using PSDS, over either the public network or a private network.

The MCU, which replaced the QMT21C, is designed for domestic and international use, with transmission speeds up to 19.2 kbps asynch and 64 kbps synch, integrated display, and self diagnostics.

The MCU supports autodialing, ring again, and speed calling, as well as autobauding and automatic parity detection. The MCU can be used for the following:

- Video conferencing

- LAN bridging
- Bulk data/PC file transfer
- Dial back-up
- Host connectivity

The MCU fully complies with RS-232C and can be configured as DCE or DTE to connect to a terminal, printer, or fax machine.

Unlike the MCA, the MCU provides a dedicated call key and call progress tones. The MCU also enables smart modem pooling.

The MCU supports the DM-DM, T-Link, V.25 bis, and PSDS interfaces as well as the RS-232C, CCITT V.35, CCITT V.24, and RS570/RS3449 (with different cables) interfaces. It complies with V.28 for European approval.

Refer to *Meridian Communications Unit and Meridian Communications Adapter: Description, Installation, Administration, Operation* (553-2731-109) or *Meridian Communications Unit User Guide and Meridian Communications Adapter Reference Guide* for detailed information on this feature.

Wall mounting

The M2006, M2008, M2616, and M2016S telephones are equipped with a reversible footstand that allows for wall mounting. The wall-mount clip should be purchased and inserted in the handset well to hold the handset securely in place on wall-mounted telephones. Meridian Modular Telephones can be hung on the wall with an installed display or Key Expansion Module.

Note: The footstand cannot be reversed when the Meridian Programmable Data Adapter or Meridian Communications Adapter is equipped, so telephones with data cannot be wall mounted. Additionally, some wall plates are too deep to allow for wall mounting on top of the plate. In these cases, mount the telephone on the wall next to the plate.

An additional clip is provided for wall mounting the telephone. This clip is attached to the switchhook rest to prevent the handset from slipping when mounted on the wall.

Procedure 80

Wall mounting instructions for Meridian Modular Telephones

- 1 Remove the handset and place the telephone upside down on top of a level, solid work surface covered with soft material or paper to prevent damage to movable keys and the telephone face.
- 2 Disconnect all cords from the telephone.
- 3 Remove the two screws from the footstand assembly and unsnap the footstand assembly by pressing inward at the back of footstand where it meets the base, and pulling upward.
- 4 Rotate the footstand 180° and snap the footstand back into place on the telephone bottom cover. Make sure the footstand is firmly seated on the base of the telephone.
- 5 Tighten all screws and replace all cords.
- 6 Insert the wall-mounting clip in the switchhook rest.
- 7 Mount the telephone on the wall using the wall-mount holes provided on the bottom of the footstand.

End of Procedure

Troubleshooting

Use Table 72 to check problems encountered when installing Meridian Modular Telephones and their options.

Table 72
Troubleshooting Meridian Modular Telephones (Part 1 of 5)

Symptom	Solution	
Telephone does not work.	1	Unplug the line cord from the telephone and plug it back in.
	2	If the telephone uses external power, make sure the transformer or closet power supply is properly connected and that the power supply board is properly installed.
		If the telephone does not use external power, make sure that jumpers are placed connecting the bottom two sets of pins on the P1 connector on the main circuit board.
All LCDs flash and telephone does not function.	1	Press the Release (Rls) key.
	2	Unplug the line cord from the telephone and plug it back in.
Telephone wobbles.	1	Ensure that all cords are properly routed through channels in the footstand.
	2	Check that the footstand is firmly seated on the telephone.
	3	Ensure that all feet are firmly seated in the footstand.
Display does not work.	1	Unplug the line cord from the telephone and plug it in again.
	2	Ensure that the transformer is plugged in or the closet power is connected (M2008 only).

Table 72
Troubleshooting Meridian Modular Telephones (Part 2 of 5)

Symptom	Solution
	3 Ensure that the power supply board is installed properly (M2008 only).
Display does not work. (cont.)	4 Check that the display ribbon cable is properly connected to the display board and has not been pinched.
	5 Ensure that the display board is installed correctly and held securely with a mounting screw.
	6 M2006, M2008, M2616 – ensure that ADD Class of Service is configured in LD 11. See the <i>Software Input/Output: Administration</i> (553-3001-311).
There is no response when you type <CR> or AT at the terminal.	1 Press the P key and dial 28 to make sure you are in terminal mode.
	2 Make sure the PC or terminal's has power and is online.
	3 If the equipment connected to the MCA is not configured as Data Terminal Equipment, it is necessary to connect using a null modem cable.
	4 Make sure the MCA is receiving external power. Check to see that the power cables are connected properly and the external power supply is running.
	5 If there is a display on the telephone, press the P key and dial 63 to get into EIA Monitor mode. Be sure the MCA is receiving signals from the terminal by watching the display while entering carriage returns on the keyboard. If the indicator flashes, the connection is correct. If not, check the cable to make sure it is the standard RS-232 and is properly connected.

Table 72
Troubleshooting Meridian Modular Telephones (Part 3 of 5)

Symptom	Solution
	6 Press the P key and dial 62 to ensure that the MCA is in the asynchronous mode. Press the P key and dial 20 to change to the asynchronous mode.
	7 Press the P key and dial * to ensure that the MCA is in the idle mode.
The prompt CALL CONNECTED. SESSION STARTS is followed by RELEASE.	Check the configuration parameters of the far end data device. If they do not match those of the MCA, the call will be dropped. Change the parameters of your MCA to match.
Garbled prompts are sent to your terminal when you type <CR>.	Enter a period (.) followed by <CR> to perform an autoparity.
You are connected to a host computer, but get no response when you try to log on.	First, release the call. Turn on Remote Loopback and make the call again. Type some characters at the terminal. If the characters echo back and appear on the terminal, the problem is with the far end data device. If the characters do not appear on the terminal, the problem is with the MCA. Contact the telephone system administrator.
You try to make a data call from the initial prompt (or Main menu) in keyboard dialing. You see the prompt CALLING.	First, hold down the break key(s) for two seconds, enter <CR>, and try again to make the data call. If the problem persists, the MCA is probably disabled. Contact the telephone system administrator.
MCA does not operate at all.	1 Check the LED in the back of the telephone to see if it is flashing. If the LED is steadily lit, the MCA needs to be configured in the system, or it may be bad. If the LED is not lit, the MCA requires external power.
	2 Make sure the cable from the terminal or PC is connected to the MCA.
	3 Check the data parameters for the display.


Table 72
Troubleshooting Meridian Modular Telephones (Part 4 of 5)

Symptom	Solution
	4 Be sure the transformer is plugged in, or the closet power is connected.
	5 Be sure the cable between the MCA and the telephone is connected and has not been pinched.
	6 Be sure the power card is installed correctly. Verify that the jumper settings are correct for either RS-232 or V.35 (whichever you are using).
Key Expansion Module does not work.	1 Unplug and plug in the line cord.
	2 Ensure that the transformer is plugged in or that the closet power supply is connected.
	3 Ensure that the power supply board is installed properly.
	4 Make sure that the ribbon cable connecting the telephone and the Key Expansion Module is routed properly and is not pinched.
External Alerter does not work.	1 Ensure that the External Alerter Board is installed properly.
	2 Check that connections between the alerting device and the telephone connecting block are correct.
	3 Make sure that the jumpers are placed on the pins on the External Alerter Board as described in Procedure 76 on page 416 .
	4 Ensure that the transformer is plugged in or the closet power is connected.

Table 72
Troubleshooting Meridian Modular Telephones (Part 5 of 5)

Symptom	Solution
	5 Ensure that the power supply board is installed properly.
<p>Note 1: If the pseudorandom pattern 511 data is idle, the telephone keypad dialing is inoperative. Use the release key to clear this condition.</p> <p>Note 2: If using an RS-232 cable to connect the MCA to an ADM3/5 terminal, be sure that pin 22 is disconnected.</p> <p>Note 3: Change the baud rate before changing the mode from synchronous to asynchronous.</p> <p>Note 4: Some terminals may drop DTR with the break. If this happens, RELEASE is not displayed.</p>	

Figure 85
Flowchart for troubleshooting MCA



Appendix D: M2317 telephone

Contents

This section contains information on the following topics:

Introduction	439
Feature description	441
Firmware features	441
Software features	441
Physical description.	442
Housing.	442
Keys	443
Software requirements	452
Specifications	453
Safety considerations	453
Environmental considerations	453
Dimensions and weight	454
Line engineering.	454
Power requirements	454
Data communication.	458
Data characteristics.	458

Note: This section is for reference only. The M2317 telephone is manufacture discontinued and no longer available.

Introduction

The M2317 Telephone can provide simultaneous voice and data communications. It connects to the system using digital transmission. The


M2317 Telephone is intended for professionals and managers, and secretaries in group answer positions. It interfaces with the system through the Digital Line Card (DLC). It is connected to the switching equipment through a two-wire loop carrying two independent 64 kb/s Time Compressed Multiplex (TCM) channels with associated signaling channels. One of the two TCM channels is dedicated to voice, and the other to data traffic.

The M2317 telephone has the following features:

- A built-in, two-line (40 characters per line) Liquid Crystal Display (LCD) screen and integrated Handsfree.
- A telephone line cord and the handset cord equipped with standard modular connectors at each end, that enables quick replacement when required.

The M2317 Telephone is equipped with a microphone and speaker to permit Handsfree operation. Figure 86 shows the M2317 Telephone.

Figure 86
M2317 Telephone



Feature description

Firmware features

Firmware is chip-dependent and cannot be changed or altered on site. As a general rule, all firmware is on ROM microchips. Firmware is built into the M2317 telephone and the CS 1000 and Meridian 1 systems.

Firmware functions

The following functions are performed by firmware in the M2317 Telephone:

- Predial
- Last Number Redial
- Saved Number
- Redial Saved Number
- Timer
- Time and Date
- Call Processing

Software features

Downloading

All information related to the programmable keys must be downloaded into the M2317 RAM memory through the DLC.

Soft keys are automatically defined for the telephone based on COS, data base or package restrictions. Soft keys work only in conjunction with the LCD display screen.

Table 73
M2317 data features

Data features	M2317	DTE Keyboard
Ring Again	X	X
Speed Call	X	X
System Speed Call	X	X
Display		X
Call Forward	X	
Call Transfer (Note)		X
Autodial	X	X
Last Number Redial	X	
Save Number	X	
Redial Saved Number	X	
Manual modem pooling using keyboard dialing requires only call transfer to be defined.		
The Data DN must always be assigned to feature key 10.		

Physical description

The M2317 Telephone is fully modular. The telephone line cord and the handset cord are both equipped with TELADAPT connectors at each end, which permits quick replacement when required.

Housing

The housing of the M2317 digital telephone consists of a molded plastic base and faceplate. The display module and the main circuit board are fastened to

the underside of the faceplate. The Asynchronous Data Option (ADO) circuit board, if equipped, is mounted inside the base.

Keys

The M2317 Telephone is equipped with 32 keys that are arranged as follows:

Fixed keys

These are 16 keys to which a fixed function is assigned. They consist of:

- 12 dial pad keys
- 1 Release key
- 1 Hold key
- 1 Volume control key (with 2 toggle positions)
- 1 Handsfree/Mute key (with associated LCD indicator)

Feature keys

There are 11 programmable line/feature keys on the telephone faceplate. Each has an associated LCD indicator. Lines and features are assigned to these keys by service changes in the system software. A maximum of ten voice Directory Numbers and specific features such as, Auto Answerback, Call Waiting, Dial Intercom, and Display can be assigned.

Soft keys

The M2317 telephone has five LCD-labeled soft keys located immediately beneath the display screen. Each softkey has a seven-character-wide label on the display screen immediately above the key. The labels change as the available features change. For example, a softkey could access one feature in the idle state and a different feature in the active state.

The fifth softkey “**more...**” is used to scroll to a second layer feature menu when there are more softkey-assigned features available for the active telephone state. Pressing the “**more...**” key brings up the labels for the remaining functions. Softkey label positions on the display screen are fixed by the M2317 telephone firmware and cannot be changed by the user.

Alphanumeric display screen

The M2317 telephone is equipped with a two-line (40 characters per line capacity) LCD screen. The 155 x 15 mm (6 x 0.6 in) LCD screen has a capacity of 80 characters (two lines of 40 characters each). The first line displays date and time during the idle state, incoming call identification, feature icons, user prompts, and messages. The second line displays the labels for the soft keys (seven characters per key).

Handsfree key

When Handsfree is on, a user can talk to another party without lifting the handset. Handsfree can be activated by pressing the Handsfree/Mute key, or by pressing a DN key without lifting the handset. The Handsfree/Mute LCD indicator shows the status of the Handsfree. Once Handsfree is activated, it can be deactivated by picking up the handset or by pressing the Release (RLS) key.

Handsfree operates as if an off-hook operation had been performed. For example, when the telephone is idle, pressing the Handsfree/Mute key turns on the Handsfree and selects a DN (depending on line selection as assigned through COS), enabling the user to make a call. When a call comes into an M2317 and the set is ringing, pressing the Handsfree/Mute key turns on the Handsfree and enables the user to answer the incoming (ringing) call (depending on COS-assigned line selection) without picking up the handset.

The M2317 provides independent volume adjustments for Handsfree, handset, and alerting tone volumes (on-hook dialing and buzz). For detailed information on adjusting the volume, refer to the *M2317 Quick Reference Card*.

LCD indicators

LCD indicators support the following four key/LCD states:

Function	LCD state
idle	off
active	on (steady)

Function	LCD state
ringing (or “feature pending”)	flash (60 Hz)
hold	fast flash (120 Hz)

The following figures show the M2317 key layout and the different telephone states that can be displayed on the M2317 screen.

Figure 87
M2317 telephone – key identification




Figure 88
M2317 screen display – available idle state features

Displays Month, Day, Hour, Minutes

MMM DD HH : MM				
SAVED #	LAST #	CANCL	--->>	more...
HELD #	FORWARD	CHECK	TIMER	more...
RLSDATA	DATA	SPEED	FRENCH	more...

Note 1: Only one row of softkey labels is displayed at a time. Additional rows are accessed by operating the "more..." softkey. The five softkeys are located beneath the screen display in line with each displayed label.

Note 2: The HELD # softkey label is displayed on the screen only when there is a held conference/transfer call.

Note 3: The CANCL softkey label is displayed on the screen only when the "Ring Again" feature has been activated.

Note 4: The FORWARD and CHECK (Check Call Forward) labels are mutually exclusive; the FORWARD key label changes to CHECK when calls are forwarded.

Note 5: The RLSDATA label is displayed only when there is an active data call.

Note 6: The - - ->> key is only offered when CPND is used.

553-AAA0731

Figure 89
M2317 screen display – dialing state




Figure 90
M2317 screen display – ringback state




Figure 91
M2317 screen display – available established state features

Elapsed Timer (Hours: Minutes : Seconds)

3021				H : MM : SS
CONFER	TRANSFR	TIMER	SAVE #	more...
--->>	PARK	PRIVREL	CHARGE	more...
VMSG				more...

Note: Only one row of softkey labels is displayed at a time. Additional rows are accessed by operating the "more..." softkey. The five softkeys are located beneath the screen display in line with each designation.

553-AAA0735

Not all the features listed in Table 74 are provided for each customer. Check only those features that are enabled in accordance with the work order.

The - - ->> symbol display is associated with the Call Party Name Display (CPND) feature. CPND must be enabled before it can be accessed.

Table 74
M2317 states and associated soft keys (Part 1 of 3)




Screen state	State	Softkey display
Idle	On-hook, voice or data	Saved#, LAST#, CANCL  --->, more..., HELD#, FORWARD, CHECK  TIMER, more..., RLSDATA, DATA, SPEED
Dialtone	Ready to transmit dialed digits (voice)	Saved#, LAST#, CALL  SPEED#, more..., MESSAGE, PICKUP, ACCOUNT, more...
Intercom dialtone	Ready to transmit dialed digits for an intercom call (voice)	PICKUP
Dialing	Transmitting dialed digits	no soft keys shown
Private Line dialing	Transmitting dialed digits on a private line (voice)	SAVED#, LAST#
Busy	Called party off-hook (voice)	RINGAGN, SAVE#
Reorder	Called party is unavailable (voice)	no soft keys shown
Ringback	Called party is ringing (voice)	SAVE#
ERWT call back	Initial set of ESN routes not available. Set gets Expensive Route Warning Tone (voice).	RINGAGN, SAVE#

Table 74
M2317 states and associated soft keys (Part 2 of 3)



Screen state	State	Softkey display
Established	Voice connection made	CONFER, TRANSFR, TIMER, SAVE#, more..., —>>, PARK, PRIVREL, CHARGE, more..., MESSAGE, more...
Intercom established	Connection made with an intercom group (voice)	CONFER, TRANSFR, TIMER
Private Line established	Connection made with a private line (voice)	CONFER, TRANSFR, TIMER
Voice Call/Group Call established	Connection made using a voice key or group call key (voice)	no soft keys shown
Conference/Transfer dialtone	Special dialtone (voice)	SAVED#, LAST#, CALL  SPEED, ACCOUNT
Conference/Transfer dialing	After special dialtone is heard, dialing the call (voice)	no soft keys shown
Conference/Transfer busy	After special dialtone is received, called party is off-hook (voice)	RINGAGN, SAVE#
Conference/Transfer reorder	After special dialtone is received, called party is unavailable (voice)	no soft keys shown
Transfer ringback	Used xfer feature, and the called party is ringing (voice)	CONNECT, SAVE#
Conference ringback	Used conf feature, and the called party is ringing (voice)	SAVE#
Consultation	The third party (consulting party called by xfer/conf feature) has answered the call (voice)	CONNECT, SWAP
Consultation Hold	The user is talking to the original party and the consulting party is on hold (voice)	CONNECT, SWAP

Table 74
M2317 states and associated soft keys (Part 3 of 3)

Screen state	State	Softkey display
Established Hold	Call held by other party (voice)	no soft keys shown
User status	Leave telset msg for set's status (voice)	no soft keys shown
Display	The user has operated the feature key "DSP" to display the speed/system speed call numbers (voice or data)	SPEED#, EXIT
Program	The user has operated a feature key that requires user-input such as Auto Dial or Controlled Class of Service (COS)	no soft keys shown
Data call initiation	The user pressed data DN key to make a data call (data)	CALL  , SPEED#, SAVED#, LAST#
Data call dialing	Transmitting dialed digits (data)	no soft keys shown
Data call busy	Called party off-hook (data)	RINGAGN, SAVE#
Data call reorder	Called party is unavailable (data)	no soft keys shown
Data call ringback	Called party is ringing (data)	SAVE#
Data call ERWT call back	Initial set of routes not available. Set gets Expensive Route Warning Tone (ERWT).	RINGAGN, SAVE#
Data call established	Connection made (data)	SAVE#

Asynchronous Data Option

See "Asynchronous Data Option" on [page 423](#) for more information on ADO requirements.

Software requirements

All information related to the programmable keys must be downloaded into the M2317 RAM memory through the DLC or ISDLC. Downloading to the telephone is performed when the system is loaded or when a telephone is enabled.

Soft keys are automatically defined for the telephone based on Class of Service (CLS), database, or package restrictions. Soft keys work only in conjunction with the LCD display screen.

Table 75 lists the data features supported by the M2317 firmware.

Table 75
M2317 data features

Data features	M2317	DTE Keyboard
Ring Again	X	X
Speed Call	X	X
System Speed Call	X	X
Display		X
Call Forward	X	
Call Transfer (Note 1)		X
Autodial	X	X
Last Number Redial	X	
Save Number	X	
Redial Saved Number	X	
<p>Note 1: Manual modem pooling using keyboard dialing requires only call transfer to be defined.</p> <p>Note 2: The Data DN must always be assigned to feature key 10.</p>		

Specifications

The following specifications govern the safety and performance of the Meridian M2317 Telephone, and outline the environmental conditions under which this performance is achieved.

Safety considerations

Shock and fire hazards

For protection against electrical shock, energy hazards, or fire hazards, the telephone meets the following specifications:

CSA, C22.2 No. 0.7 – M1985

UL 1459, relevant sections

Overvoltage protection

The M2317 telephone meets the specifications detailed by CSA, C22.2 No.7, paragraph 6.9.3.

Environmental considerations

Temperature and humidity

Operating state:

Temperature range	0° to 50° C (32° to 122°F) 0° to 40° C (32° to 104°F) with Data Option
Relative humidity	5% to 95% from 4° to 29°C (39° to 84° F) noncondensing 5% to 34% from 29.5° to 49°C (85° to 120°F) noncondensing

Storage:

Temperature range	-20° to 70° C (-4° to 158° F)
Relative humidity	5% to 95% from -20° to 29°C (-4° to 84°F) noncondensing 5% to 15% from 29.5°C to 66°C (85° to 150°F)

Dimensions and weight

The M2317 digital telephone has the following dimensions:

depth	226.5 mm (9 in)
width	272.0 mm (10.1 in)
height (front)	27.5 mm (1.1 in)
height (rear)	73.5 mm (2.9 in)

Excluding the power supply and the NT1F09AC Asynchronous Data Option board, the M2317 weighs approximately 1.4 Kg (3 lb). With the Data Option installed, the telephone, excluding power supply and data cable, weighs approximately 1.56 Kg (3.5 lb).

Line engineering

The M2317 digital telephones operate to their full potential through twisted pair wiring on transmission lines selected by the rules given in “Digital telephones line engineering” on [page 289](#) &c. The maximum permissible loop length is 1067 m (3500 ft.) of 22 or 24 AWG or 760 m (2500 ft.) of 26 AWG standard twisted wire with no bridge taps or load coils.

The 1067 m (3500 ft.) loop length requires the use of a Digital Line Card (DLC) or an Integrated Services Digital Line Card (ISDLC) NT8D02, or later.

Power requirements

The M2317 digital telephone uses loop power for all circuits requiring +10 V. To satisfy the power requirements for those circuits on a maximum loop, as defined in “Digital telephones line engineering” on [page 289](#), 60mA of 13.5 V DC must be available at the telephone. The line card must have compatible voltage and source resistance to meet these requirements.

Logic and other circuitry requiring +5 V is powered from an external, regulated +5 V DC supply when the data option is not installed. The external power supply must meet the following specifications:

Input:	95–129 V AC, 60 Hz
Output:	+5 V DC, + or –5%, 300 mA 10 mV maximum RMS ripple
Cord:	2.5 m (8 ft.) of 20 AWG wire mating to a Switchcraft 722A connector
Case:	Wall-mounted, CSA and UL approved. Operational within 0°C (32°F) and 50°C (122°F) temperature limits
Impedance:	Greater than 10 M $\frac{3}{4}$ to ground

The external power supply, in all cases where no Asynchronous Data Option is installed, is connected to the mating connector mounted in the rear of the M2317 telephone. It covers the area where the RS-232-C interface connector would be located.


Note: If the Asynchronous Data Option is installed, an external, multi-output data power supply is required. Refer to NPS50220-03L5. See “Asynchronous Data Option” on [page 423](#) for more information on ADO requirements.

The data option power supply connector plugs into the back of the telephone next to the RS-232-C interface connector. Data option installation requires the removal of the telephone power supply connector.

The NPS50220-03L5 power supply meets the following specifications:

- AC input voltage: 105 - 132 V AC
- Input line frequency: 57 - 63 Hz
- Operating temperature: 0° to 50°C (32° to 122°F)
- Operating humidity: 5% to 95% non-condensing
- Storage temperature: -40° to 70°C(-40° to 158°F)

Figure 92
M2317 telephone cross-connections




- Output voltages:
 - +5 V DC at 1.0 A
 - 12 V DC at 200 mA
 - +12 V DC at 200 mA
- Case dimensions: 178 x 102 x 76 mm (7 x 4 x 3 in.)

The NPS50220-03L5 is equipped with an internal thermal and short circuit protection.

Whenever the external power supply fails (due to failure of the power utility), the M2317 Telephone assumes Plain Ordinary Telephone Service (POTS) status. At this time the telephone is capable of receiving and originating calls

on the prime DN, and of giving the usual alerting tones (ringing). It will not support the Display screen, soft keys, feature keys, Handsfree, or data facilities while in POTS status.

Figure 93
Block diagram of M2317



Data communication

The M2317 can be equipped with an Asynchronous Data Option which will permit the use of either the telephone's dial pad or the feature keys to place and terminate data calls in the asynchronous mode. The Data Option also supports keyboard dialing from the data terminal when that terminal operates in the asynchronous mode.

The Asynchronous Data Option is equipped with a dialing feature which enables the user to originate data calls to local and remote Data Terminal Equipment (DTE) directly from a data terminal keyboard or personal computer. The dialing feature, in conjunction with the communications firmware provided with the Data Option, supports most of the HAYES Smartmodem dialing features. Terminal emulation packages can also be used with the dialing feature.

Data characteristics

The M2317 Asynchronous Data Option communicates with Data Terminal Equipment (DTE) having characteristics as follows:

Data type	ASCII
Synchronization	Asynchronous, Start-Stop
Number of Bits	8 bits
Parity	none (unchecked)
Data rate	300, 1200, 2400, 4800, 9600, 19200 bits per second (autobaud)
Stop bits	2 bits for 110 bits per second; 1 bit for all other speeds
Transmission	Full duplex

Appendix E: M3110, M3310, and M3820 telephones

Contents

This section contains information on the following topics:

Feature description	460
M3110.	460
M3310.	463
M3820.	464
Meridian digital telephones used with a headset	466
Physical description.	466
Fixed keys (same for all three models).	468
Additional feature keys.	471
Programmable Feature keys	471
Software requirements	472
Terminal options	472
Meridian External Alerter and Recording Interface.	473
Brandline Insert	473
Key Expansion Module	474
Meridian Communications Adapter.	474
Configuration and installation.	474
Configuration	474
Installation	480
Installing hardware options	480
Specifications	486
Environmental and safety considerations.	486

Line engineering	487
Local alerting tones	487
Power requirements	488

Note: This section is for reference only. The M3110, M3310, and M3820 sets are manufacture discontinued and no longer available.

Feature description

The Meridian European Digital telephones series of telephones, which is only available in Europe, consists of the following telephones:

- M3110
- M3310
- M3820

Meridian digital telephones are designed to provide cost-effective integrated voice and data communication. These telephones communicate with the CS 1000 and Meridian 1 systems by using digital transmission over standard twisted-pair wiring. They interface with the system using the Integrated Services Digital Line Card (ISDLC) or the eXtended Digital Line Card (XDLC).

Meridian digital telephones are connected to the system through a two-wire loop carrying two independent 64 kbs PCM channels with associated signaling channels. One of the two PCM channels is dedicated to voice while the other is dedicated to data traffic.


The telephone interfaces with the Digital Line Card (XDLC) or ISDLC in the Intelligent Peripheral Equipment shelf of the system. The XDLC supports 16 voice and 16 data ports. The ISDLC supports eight voice and eight data ports. A TN is assigned to each port in the system software.

M3110

The M3110 Meridian digital telephone supports the following features:

- On-Hook Dialing and Group Listening
- Dedicated release and hold keys

Figure 94
M3110 Meridian digital telephone



- Message Waiting and Mute Indicators
- 10 Feature System Programmable keys including:
 - 8 system programmable keys
 - Mute key
 - Speaker key
- Volume control for:
 - Handset
 - Ringing Tone
 - Buzz Tone
 - On-Hook Dialing and Group Listening

Figure 95
M3310 Meridian digital telephone





Figure 96
M3820 Meridian digital telephone



- Support for the following terminal options:

- MCA data option to provide integrated voice and data
- External Alerter for high ambient noise environments
- Wall-mount ability
- Brand line insert to provide for special company logos

M3310

The M3310 Meridian digital telephone supports the following features:

- Handsfree, On-Hook Dialing and Group Listening
- Dedicated Release and Hold keys
- Message Waiting and Speaker/Mute Indicators
- Headset Socket
- 2 x 24 character display
- 10 Feature keys including:
 - Program key
 - 7 system programmable keys
 - Speaker key
 - Mute key
 - Volume control for:
 - Handset/Headset
 - Ringing Tone
 - Buzz Tone
 - On-Hook Dialing and Group Listening
 - Handsfree
- Support for the following set options:
 - MCA data option to provide integrated voice and data

- External Alerter for high ambient noise environments
- Wall-mount ability
- Brand line insert to provide for special company logos

M3820

The M3820 Meridian digital telephone supports the following features:

- Handsfree, On-Hook Dialing and Group Listening
- Dedicated Release and Hold keys
- Message Waiting and Speaker/Mute Indicators
- Headset Socket
- 2 x 24 character display
- 20 Feature keys including:
 - Store/program key
 - 13 system programmable keys
 - Handsfree/speaker key
 - Mute key
 - Directory key
 - Caller's List key
 - Edit key
 - Delete key
- Volume control for:
 - Handset/Headset
 - Ringing Tone
 - Buzz Tone
 - On-Hook Dialing and Group Listening
 - Handsfree

- Directory/Caller's List with 9 dedicated keys namely:
 - Directory, Callers, Edit, Delete, 4 cursor and Dial
- Support for the following terminal options:
 - MCA data option to provide integrated voice and data
 - External Alerter for high ambient noise environments
 - Wall-mount ability
 - Add-on Key Expansion Modules (2 maximum)
- Brand line insert to provide for special company logos

Meridian digital telephones used with a headset

You can use an electret headset in the headset port of the digital telephones (M3310 and M3820 only). Alternatively, choose an amplified headset that draws power from a battery or AC transformer; power is not provided by the telephone. The amplifier must draw less than 400 micro amps from the telephone jack.

The headset should be designed to work with a telephone jack with these characteristics:

Transmit interface: +5 V through 10K DC bias resistance with maximum current of 500 micro amps. The differential input impedance is 10K ohms. Connects to pins 2 and 5 of the headset jack.

Receive interface: single ended output with output impedance of 180 ohms. Connects to pins 3 and 4 of the headset jack.

Physical description

Meridian digital telephones support many general features as illustrated in Table 76.

Table 76
Meridian digital telephone general features (Part 1 of 2)

Feature	M3820	M3310	M3110
Handsfree, On-Hook Dialing, and Group Listening	yes	yes	yes
Dedicated Release and Hold keys	yes	yes	yes
Message Waiting and Speaker/Mute Indicators	yes	yes	yes
Headset Socket	yes	yes	no
2 x 24 character display	yes	yes	no
Feature keys including:	20	10	10
• Store/program key	yes	yes	no
• system programmable keys	13	7	8

Table 76
Meridian digital telephone general features (Part 2 of 2)

Feature	M3820	M3310	M3110
• Handsfree/speaker key	yes	yes	yes
• Mute key	yes	yes	yes
• Directory key	yes	no	no
• Caller's List key	yes	no	no
• Edit key	yes	no	no
• Delete key	yes	no	no
Volume control for:			
• Handset/Headset, Ringing Tone, Buzz Tone, On-Hook Dialing and Group Listening	yes	yes	yes
• Handsfree	yes	yes	no
Directory/Caller's List with dedicated keys for Directory, Callers, Edit, Delete, 4 cursor and Dial	yes	no	no
Terminal options:			
• MCA data option to provide integrated voice and data, External Alerter for high ambient noise environments, Wall-mount ability	yes	yes	yes
• Add-on Key Expansion Modules (2 maximum)	yes	no	no
Brand line insert to provide for special company logos	yes	yes	yes
Note: The location of the buttons used to activate and interact with these features is shown in Figure 97 on page 469 .			

Fixed keys (same for all three models)

Hold

By pressing the hold key, you can put an active call on hold. Return to the caller by pressing the extension key beside the flashing LCD indicator.

Release (RIs)

You can terminate an active call by pressing the RIs key or by hanging up the handset. The release key is especially useful for disconnecting handsfree and headset calls.

Volume control

The volume key controls the volume of the handset, the speaker and the ringer. Raise the volume by pressing the right side of the bar. Lower it by pressing the left side.


Mute

When engaged in a call, you can press the mute key. The party(ies) to whom you are speaking cannot hear you. This is especially useful when on a conference call and you are only listening. When you wish to return to the two-way conversation, you must push the mute key again. The mute key applies to handsfree, handset and headset microphones.

Speaker/Handsfree

The speaker key allows you to activate handsfree and group listening features. Handsfree is only available on the M3310 and M3820 models and is enabled by the system administrator. If handsfree is not configured at the switch, the telephone can only be used to listen.

Figure 97
The location and function of buttons on the Meridian digital telephone



The table below indicates the mode the terminal is in when the speaker key is operated under the various switch and set operations.

Table 77
Speaker Key Function

MODEL	Handsfree not selected at the switch	Handsfree selected at the switch - Group listening off	Handsfree selected at the switch - Group listening On
M3820	CPM and primary DN key-Speaker LED is not illuminated	HF and Primary DN key - speaker LED is on when in Handsfree mode	HF, Group listening and Primary DN key - speaker LED is on when in HF or Group Listening mode
M3310	CPM and Primary DN key-Speaker LED is not illuminated	HF and Primary DN key - Speaker LED is on when in HF mode	HF, Group Listening and Primary DN key - Speaker LED is on when in HF or group listening
M3110	CPM and Primary DN key- Speaker LED is not illuminated	N/A	Group listening and Primary DN key - speaker LED is on when in Group listening mode.

Note 3: CPM is Call Process Monitor which enables the user to hear, for example, the dial tone in the speaker. Group listening enables the user to speak through the handset/headset microphone and one or more parties can listen through the speaker, thus hearing both sides of the conversation. In Handsfree mode, the user (or group of users) uses both the handsfree microphone and speaker.

Note 4: Group listening is switched on or off under the program key option *1. (M3820 and M3310 only)

Additional feature keys

Message Waiting lamp key

Each telephone has a red message waiting LED just above the hold and Rls keys that lights to indicate a message is waiting. This LED is the primary message waiting indicator and lets you know that a message is waiting, regardless of whether the telephone has a message waiting key/lamp pair. You must have Message Waiting allowed Class of Service. See LD 11, *Software Input/Output: Administration (553-3001-311)* and *Software Input/Output: Maintenance (553-3001-511)*.

If you do assign a message waiting key/lamp pair, there will be two indications of a message waiting:

- the red Message Waiting LED lights
- the LCD associated with the Message Waiting key blinks

Autodial key

You can assign an Autodial Key that dials the message center (or voice mail system) to avoid the double indication or have no key/lamp pair assigned to the message center.

Programmable Feature keys

Each Meridian digital telephone has a number of programmable keys with LCD indicators that can be assigned to any combination of directory numbers and features. The M3820 has 13 fully programmable feature keys; the M3310 has seven, and the M3110 has eight. The lower right-hand key (key 0) is reserved for the Primary DN.

LCD indicators support four key/LCD states:

Function	LCD state
idle	off
active	on (steady)
ringing	flash (60 Hz)
hold	fast flash (120 Hz)

Note: An indicator fast flashes when you have pressed a feature key but have not completed the procedure necessary to activate the feature.

Software requirements

Meridian digital telephones are supported by software. The package number for the Meridian digital telephones is (170.) The mnemonic is ARIE. The DSET package (88) and the TSET package (89) are required.

Terminal options

This section describes the options available for Meridian european digital telephones. Table 78 lists the features and optional hardware available for each telephone.

Table 78
Hardware features and options

	M3820	M3310	M3110
Programmable Feature keys	13	7	8
Handsfree microphone	x	x	
Optional hardware available:			
Key Expansion Module	x		
Note: In this table, x indicates available features for the telephone type listed in the top row.			

Table 78
Hardware features and options

	M3820	M3310	M3110
Meridian Communications Adapter (MCA)	x	x	x
External alerter interface	x	x	x
Brandline insert	x	x	x
Note: In this table, x indicates available features for the telephone type listed in the top row.			

Meridian External Alerter and Recording Interface

The External Alerter Board provides an interface to standard remote ringing devices, such as a ringing unit, installed in a location separate from the telephone. The Meridian External Alerter and Recording Interface (MEARI) is not the remote ringer itself, but provides access to standard, off-the-shelf remote ringing devices. The Alerter Board requires additional power. See “Power requirements” on [page 488](#).

You can program the MEARI interface to activate a ringer (or light) when the telephone rings or when the telephone is in use (off-hook). A call to any DN configured on the telephone triggers the alerter. The MEARI alerts to one active call at a time; if the telephone is already active on a call, a second call will not activate MEARI.

For information on installing and setting up the External Alerter, see “Add-on modules” in “External Alerter Board” on [page 416](#).

Brandline Insert

The telephone contains a removable insert designed to accommodate custom labeling. You can order blank Brandline Inserts and have a printer silkscreen your company logo on them.

Key Expansion Module

A 22-key unit module can be attached to any M3820 terminal. The extra keys can be assigned to any combination of lines and features. You can add up to two expansion modules to a terminal. You will need a separate footstand for the module(s), one for a single module, one for a double.

Meridian Communications Adapter

The Meridian Communications Adapter (MCA) lets you connect your telephone to a personal computer or terminal. You can then use your telephone to exchange data between your computer and other computers. The MCA can be used with all three models.

Configuration and installation

Configuration

Use LD 11 (Meridian Digital Telephone Administration) to configure the telephones. All prompts are defaulted (or set as required) except for those noted in the tables following:

LD 11 - M3110 Configuration (Part 1 of 2)

Prompt	Response	Description
REQ	NEW	
TYPE	2616	M2616 set model used
DES	M3110	Enter appropriate set identifier
CLS	HFA (HFD)	Group Listening Allowed (Denied)
	NDD	No digit display

LD 11 - M3110 Configuration (Part 2 of 2)

Prompt	Response	Description
KEY 08	NUL 09 NUL 10 NUL 11 NUL 12 NUL 13 NUL 14 NUL	Keys 8-14 programmed as NUL. If Group Listening is denied (CLS HFD), Key 15 is also programmed as NUL.
If Group Listening is denied (CLS HFD), Key 15 is also programmed as NUL.		

Figure 98
M3110 Key Designation




Table 79
M3310 Configuration

Prompt	Response	Description
REQ	NEW	
TYPE	2616	M2616 set model used
DES	M3310	Enter appropriate set identifier
CLS	HFA (HFD)	Handsfree Allowed (Denied)
KEY	08 NUL	Keys 8-14 programmed as NUL. If Handsfree is denied (CLS HFD), Key 15 is also programmed as NUL.
	09 NUL	
	10 NUL	
	11 NUL	
	12 NUL	
	13 NUL	
	14 NUL	

Figure 99
M3310 Key Designations





Table 80
M3820 Configuration

Prompt	Response	Description
REQ	NEW	
TYPE	2616	M2616 set model used.
DES	M3820	Enter appropriate set identifier.
CLS	HFA (HFD)	Handsfree Allowed (Denied)
	AHA	Automatic Hold Allowed
	DNDD	Dialed Name Display Denied
	CNDA	Call Party Name Display Allowed
	CNIA	Call Number Information Allowed
	LNA	Last Number Redial Allowed
KEY	01 NUL	Keys 01 programmed as NUL. If Handsfree is denied (CLS HFD), Key 15 is also programmed as NUL. Note: If short hunt is configured, then Key 01 must be configured as an SCR key with the same DN as key 0. For MARP to operate with short hunt configured, Key 01 must be configured as the MARP key.

Figure 100
M3820 Key Designations



LD 20 – Print Routine

Prompt	Response	Description
REQ	PRT	
TYPE	2616	M2616 set model used.
DES	M3110	Enter appropriate set identifier Or M3+ to get a list of all three set types.
	M3310	
	M3820	
	M3+	

Installation

Procedure 81 **Installing Meridian European digital telephones**

Follow this procedure to install the Meridian European digital telephones:

- 1 Complete the wiring and cross-connections (loop power) before connecting the telephone to the connecting block.
- 2 Place the telephone on the desk in the normal operating position.
- 3 Place the RIs and Hold key caps on their positions just above the dialpad, with the Hold key closest to the handset.
- 4 Print the directory number on the designation card. Remove the number lens from its position underneath the handset, insert the designation card and snap the lens into place.
- 5 Print the feature keys on the label strip. Remove the label lens (beside the feature keys), insert the label strip and snap the lens into place.
- 6 Plug the line cord connector into the connecting block.
- 7 Perform the self test and acceptance procedures for Meridian Modular telephones (see “Meridian Modular Telephones self-test” on [page 358](#)).
- 8 Supply the user with a quick reference card.

End of Procedure

Installing hardware options

This section describes procedures for installing the following options:

- Power Board on all models.
- Headset on M3310 and M3820 telephones.
- Wallmount/Desktop Position change.

For installation of other options (MCA data option, external alerter and key expansion modules) see the section on Add-on modules for Meridian Modular Telephones (NT2K models) in Appendix C: “Meridian Modular Telephones add-on modules installation” on [page 371](#).


Procedure 82
Installing the Power Board

- 1 Open the Telephone.
 - a. Place the telephone, upside-down, on a padded, level surface.
 - b. Using a #1 Phillips screwdriver, remove the two screws holding the footstand (if fitted).
 - c. Disconnect and remove all cords including the handset and headset if fitted, from the telephone.
 - d. Use a #1 Phillips screwdriver and remove the four screws holding the base of the telephone.
- 2 Install the Power Board.
 - a. Remove the cable from the power board including the right angle header.
 - b. Disconnect the display cable from P4 on the main PCB. Note the orientation of this connector.
 - c. Place the power board to the left of the main PCB with the widest section of the power board nearest the display. Make sure that the display cable comes over the power board.
 - d. Clip the power board in place, by inserting the right hand side of the board under the clip, then push down on the left hand side adjacent to the clips provided.
 - e. Use a #1 Phillips screwdriver and the screw supplied to fasten the power board to the front cover of the telephone.
 - f. Remove and discard the two links on J8 on the telephone's main PCB.
 - g. Connect the power board cable (B0247405) to J8.
 - h. Note the key to prevent misconnection.
 - i. Connect the cable to the header at H1 on the power board as shown in the figure below).
 - j. Reconnect the display cable to P4.

Note: Do NOT twist the cable.

- 3 Reassemble the Telephone.
 - a. Replace the base cover and make sure that the cables lie flat.
 - b. Insert the four screws to secure the base.
 - c. Assemble the MCA to the footstand using the two screws provided.
 - d. Connect the cable to the 8 way jack on the base of the telephone.
 - e. Reconnect all cords to the telephone.
 - f. Replace the footstand with the two screws (if previously fitted).
 - g. Place the power board label on the footstand for tracking purposes.

End of Procedure

Figure 101
Power Board Installation**Procedure 83**
Adding a Headset (M3310 and M3820 only)

Use the following procedure to add a headset to a Meridian telephone:

- 1 Unplug the line cord from the connecting block.
- 2 Remove the handset and place the telephone upside down on top of a level, solid work surface covered with soft material or paper to prevent damage to moveable keys and the telephone face.
- 3 Remove the 2 screws from the telephone footstand (if fitted) to separate the footstand from the telephone.

- 4 Plug the headset TELADAPT connector into the socket on the base of the telephone marked with a headset icon.
- 5 Route the headset cord through the channels at the side of the telephone.
- 6 Replace the footstand in the same position and tighten both screws (if previously fitted).
- 7 Place the telephone back on the desk in the normal operating position.
- 8 Plug the line cord connector back into the connecting block.

End of Procedure

Telephone Positions

Your Meridian telephone can be installed in three different positions - two desktop positions and a wall-mount position. The two desktop positions provide two different angles for the telephone on the desktop. The telephone is supplied in the steeper of the two positions. Follow Procedure 84 for adjustment to the shallow-angle position, and Procedure 85 on [page 485](#) for wall mounting.

Procedure 84 Adjusting the telephone to the desktop shallow-angle position

The procedure to change to the more shallow angle is as follows:

- 1 Unplug the line cord from the connecting block.
- 2 Remove the handset and place the telephone upside down on top of a level, solid work surface covered with soft material or paper to prevent damage to moveable keys and the telephone face.
- 3 Remove the 2 screws from the telephone footstand (if fitted) to separate the footstand from the telephone.
- 4 Snap the footstand back into place using the alternate slots located closer to the back of the set and tighten the screws (if previously fitted).
- 5 Place the telephone back on the desk in the normal operating position.
- 6 Plug the line cord connector back into the connecting block.

End of Procedure

Procedure 85
Wall mounting the telephone

The procedure to wall mount the telephone by reversing the footstand is as follows:

- 1 Unplug the line cord from the connecting block.
- 2 Remove the handset and place the telephone upside down on top of a level, solid work surface covered with soft material or paper to prevent damage to moveable keys and the telephone face.
- 3 Remove the 2 screws from the telephone footstand (if fitted) to separate the footstand from the telephone.
- 4 Remove the wall-mount clip located inside the footstand and insert the clip in the switchhook rest using the holes provided.
- 5 Rotate the footstand 180 degrees, snap the footstand back into place and tighten the screws. Note that the footstand must be screwed to the base for wall mounting.
- 6 Mount the telephone on the wall using the wall-mount holes provided on the bottom of the footstand.
- 7 Plug the line cord connector back into the connecting block.

Note 1: The footstand cannot be reversed when the MCA data option or key expansion module is equipped so such telephones cannot be wall mounted.

Note 2: An additional clip is provided for wall mounting the telephone. This clip is attached to the switchhook rest to prevent the handset from slipping when mounted on the wall.

End of Procedure

Specifications

This section lists the specifications required for Meridian digital telephones.

Environmental and safety considerations

All Meridian digital telephones are designed to comply with:

EN 60950:1992 - Safety of Information Technology Equipment including Electrical Business Equipment.

EN 41003:1993 - Particular Safety Requirements for Equipment to be connected to Telecommunication Network.

Temperature and humidity

Operating state:

Temperature range	0° to 50°C (32° to 104°F)
Relative humidity	5% to 95% (noncondensing). At temperatures above 34°C (93°F) relative humidity is limited to 53 mbar of water vapor pressure.

Storage:

Temperature range	-50° to 70°C (-58° to 158°F)
Relative humidity	5% to 95% (noncondensing). At temperatures above 34°C (93°F) relative humidity is limited to 53 mbar of water vapor pressure.

Electromagnetic interference

All the digital telephones are designed to comply with:

EN 50082-1:1992 - Electromagnetic Compatibility - Generic immunity standard Part 1: Residential, commercial and light industry.

EN 50081-1:1992 - Electromagnetic Compatibility - Generic emissions standard. Generic standard class: Residential, commercial and light industry.

Line engineering

Meridian digital telephones use twisted pair wiring on transmission lines selected by the rules given in “Digital telephones line engineering” on [page 289](#). The maximum permissible loop length is 3500 ft. (1067 m), assuming 24 AWG (0.5 mm) standard twisted wire with no bridge taps. A 15.5 dB loss at 256 kHz defines the loop length limit. (Longer lengths are possible, depending on the wire’s gauge and insulation.) Table 81 gives detailed information on loop lengths.

Table 81
Loop lengths for Meridian digital telephones

	QPC578 A and B	QPC578 C +	NT8D02
PVC insulated cable (polyvinyl chloride)			
22 or 24 AWG	100–3000 ft. (30.5–915 m)	0–3500 ft. (0–1067 m)	0–3500 ft. (0–1067 m)
26 AWG	100–2100 ft. (30.5–640 m)	0–2600 ft. (0–945 m)	0–2600 ft. (0–793 m)
Note 1: No bridge taps or loading coils are allowed.			
Note 2: Effect of line protector at MDF reduces loop length by 500 ft.			

Note: Use only the line cord provided with the telephone. Using a cord designed for another telephone could result in damage to the cord.

Local alerting tones

Each telephone provides four alerting tones and a buzz sound. The system controls the ringing cadence by sending tone-ON and tone-OFF messages to the telephone. The alerting tone cadences cannot be changed from the telephone but can be altered for individual terminals by software controlled adjustments in the system. See *Software Input/Output: Administration* (553-3001-311). All other telephone tones, such as dial tone or overflow, are provided by the CS 1000 and Meridian 1 systems from a Tone and Digit Switch.

Alerting tone characteristics

The tone frequency combinations are as follows:

Tone	Frequencies	Warble Rate (Hz)
1	667 Hz, 500 Hz	5.2
2	667 Hz, 500 Hz	2.6
:		
3	1600 Hz, 2000 Hz	5.2
4	1600 Hz, 2000 Hz	2.6
:		
3	333 Hz, 250 Hz	5.2
4	333 Hz, 250 Hz	2.6

A 500 Hz buzz signal is provided for incoming call notification while the receiver is off-hook.

Power requirements

The Meridian digital telephones are loop powered. Loop power, originating in the ISDLC or the DLC, consists of a 30 V DC power source and assumes a 3500 ft. (1219 m) maximum loop length of 24 AWG (0.5 mm) wire and a minimum 15.5 V DC at the telephone terminals.

Note: The loop length limit is defined by a 15.5 dB loss at 256 KHz. Longer lengths can be determined using the wire’s gauge and insulation.

Some configurations of telephones and options need more than basic loop power to operate. Table 82 lists the types of Meridian digital telephones and shows when additional power is needed to operate the telephone or its optional hardware. Power Supply Boards come installed in factory-assembled configurations that require additional power.

Note: If a power failure occurs, configurations that require loop power will continue to work only if the system has battery backup. Only those options that require additional power will cease to function.

Table 82
Power requirements, Meridian digital telephones

Telephone type	Loop power	Additional power (Power Supply Board)
M3820	Terminal, handsfree, headset, key expansion	MCA, External Alerter Interface
M3310	Terminal, headset, handsfree	MCA, External Alerter Interface
M3110	Terminal	MCA, External Alerter Interface

Power supply board

The power supply option consists of a power supply board that mounts inside the telephone, coupled with an external wall-mount transformer or closet power supply that provides power to the power supply board. The power supply board receives its power through pins 1 and 6 of the line cord.

The power supply board connects to the telephone through a 14-pin bottom entry connector.

Local plug-in transformer


A single winding transformer equipped with a 10 ft. (3 m) cord of 22 AWG two-conductor stranded and twisted wire with a modular RJ-11 duplex adapter can provide the additional power needed to operate the telephone and its options.



WARNING

Do not plug any equipment other than the terminal into the RJ-11 transformer adapter, as damage to equipment can result.

Figure 102
Configuration of local plug-in transformer



120 V transformer The following minimum specifications must be met by this transformer:

Input voltage	120 V AC/60 Hz
No load output voltage	29 V AC maximum
Voltage at rated current	26.7 V AC minimum
Rated load current	700 mA

240 V transformer The following minimum specifications have to be met by this transformer:

Input voltage	240 V AC/50 Hz
No load output voltage	29 V AC maximum
Voltage at rated current	26.7 V AC minimum
Rated load current	700 mA

Note 1: You cannot wall mount the telephone over the wall jack when using a transformer because of the size of the RJ-11 adapter. Hang it above or to the side of the jack and run the line and power cords to it.

Note 2: The above-mentioned transformers can also be used with outlets identified as 110V or 220V.

Closet Power Supply

Closet power can be obtained from an AC transformer for loops of 100 ft. (30 m) or less, or a DC transformer for loop lengths of 650 ft. (198 m) or less. An equivalent power source can be used but must be UL listed to provide isolation of outputs to the terminal. See Figure 103.



WARNING


When using closet power, do not plug the TELADAPT connector into any equipment other than the Meridian digital telephone, as damage to equipment may result.

Note 1: All terminals must be isolated from the input winding and each terminal must be isolated from all other terminal windings. A separate winding is required for each terminal, and grounds must not be connected.

Note 2: The QUT1 closet power supply source is not compatible with Meridian digital telephones.

The AC source must be rated at 29 V AC, 700 mA isolated. The DC source must be rated at 42 V DC, 300 mA isolated, with current limiting output of 1 amp.

Figure 103
Closet Power Supply configuration



Index

Numerics

- 16/25-pair cables
 - attendant console connections, 59
 - terminal connections, 59
- 500/2500 telephones
 - connecting, 312
 - cross-connecting, 313, 315, 316
 - designating, 311
 - installing, 310
 - removing, 310
 - wiring, 313

A

- A0288529 jumpers, 397
- A0300752 cable, 386
- A0300753 cable, 386
- A0346862 line cords, 373
- A0367601 transformers, 44
- A0408927 cable, 386
- A0408928 cable, 386
- A connectors (IPE), 316
- ACPND (Attendant Call Party Name Display)
 - feature, 92
- Active Call Failover, 126
- active state
 - M3820, M3310, M3110, 472
 - Meridian Modular Telephones, 106, 330
- Active status message, 55

add-on modules

- BLF/CGM, 33
- Data Options, 426
- External Alerter Boards, 416
- Key Expansion Modules, 420
- key/lamp, 373
- packing and unpacking, 372
- power supply boards, 392, 401
- troubleshooting, 433
- wall mounting, 432

ADM terminals, 428

ADO (Asynchronous Data Option)

- Apple Macintosh connections, 429
- described, 423, 426
- external power supply, 424
- for M2317, 443, 455
- operating parameters, 424
- power supply connections, 429
- RS-232-C connectors, 428, 430

AK keystrip, 77

Alarm indicators, 95

Alerter

- adjusting speaker volume, 52, 80
- menu, 86
- testing pitch/volume levels, 84

alerting tones

- M3820, M3310, and M3110 telephones, 487

Amphenol connectors, 57

Analog Terminal Adapter (ATA), 150, 377

- description, 375

Apple Macintosh computers, 428, 429

ASIP

- Audio and System Interface Printed circuit card, 83

ASIP card

- control gate, 86
- hard reset, 87
- testing installed firmware, 85

ASM (Attendant Supervisory Module) add-ons, 44

- Data Options, 426
- installing, 44
- standoffs, 46, 47

ATA (Analog Terminal Adapter), 375

- installing and removing, 377

Attendant Administration feature, 96

Attendant Call Party Name Display (ACPND) feature, 92

attendant consoles

- BLF/CGM, 33, 35
- covers, 62, 63
- cross-connecting, 69
- designating, 64
- installing, 60
- key/lamp modules, 373
- local controls, 56
- loopback tests, 64
- packing and unpacking, 59
- removing, 61
- static discharge ground connections, 60
- wiring, 69

Attendant End to End Signaling, 95

Attendant Forward No Answer, 99

Attendant Intercept display, 92

Attendant Monitor, 98

Attendant Supervisory Module (NT7G10AA), 90

attenuation, cable, 305

Autodial feature, 452

Automatic Logout for Virtual Office, 175

auxiliary tone channel test, 84

B

background noise, 302

Barge-In feature, 95, 99

batteries

- BLF/CGM, 33
- for headsets, 466

B connectors (IPE), 317

BK keystrip, 77

BLF/CGM (Busy Lamp Field/Console Graphics Module), 33

- batteries, 33
- CGM/Mode keys, 53
- connecting, 40
- covers, 38, 41, 42
- described, 32
- fastening screws, 36
- installing, 34
- knockout tabs, 39
- removing, 43
- support spacers, 38
- testing functionality of, 42, 84
- volume slider position, 36
- with attendant consoles, 72

Brandline Inserts, 473

Busy Verify feature, 95, 99

C

cable attenuation, 305

cable lengths, maximum, 299

cable markers, 57

cable pairs, engineering requirements, 290

cablings, under-carpet

- allowable loop length, 299
- attenuation, 306
- characteristic impedance, 290
- requirements, 290

calculating

- DC loop resistance, 299
- expected pulse loss, 302

- Call Forward, 93, 452
 - calls
 - camped-on, 93
 - setting maximum number of waiting, 95
 - Call Waiting indicator, 95
 - Call Waiting status message, 55
 - capacitance unbalance, testing, 301
 - cards
 - DLC (Digital Line Card), 460
 - ISDLC (Integrated Services Digital Line Card), 460
 - CAS (Centralized Attendant Service), 51
 - CAS/History File status message, 55
 - CCB (Collect Call Blocking), 96
 - C connectors (IPE), 318
 - characteristic impedance
 - and junction loss, 307
 - under-carpet cabling, 290
 - CI/CK key/lamp strips, 93
 - CIS (Commonwealth of Independent States), 97
 - Clearing the Callers List and Redial List for Virtual Office, 175
 - Clearing the Directory Services Password for Virtual Office, 174
 - clock/calendar, real-time, 57
 - closet power supplies, 489, 491
 - conference bridge analog control gates, 86
 - Conference key, 94
 - conferencing feature, 450
 - configurations, 77
 - connecting blocks, 418
 - connections, console, 56
 - connectors
 - attendant consoles, 60, 61
 - IPE, 316
 - M2317 telephones, 361
 - Meridian Modular Telephones, 114, 356
 - continuity, testing DC, 301
 - Contrast menu, 80
 - control gates, conference bridge analog, 86
 - control procedure, 86
 - cords
 - Meridian Modular Telephones, 373
 - and TELADAPT snap-in connectors, 491
 - covers
 - attendant consoles, 62, 63
 - BLF/CGM, 38, 41, 42
 - cross-connections
 - attendant consoles, 69
 - M2317 telephone, 363
 - Meridian Modular Telephones, 121
 - custom labeling (logos) with Brandline Inserts, 473
- ## D
- data calls capability, 451
 - data channels, 460
 - data communication failures
 - M2317 telephone, 365
 - Data Options, 426
 - data parameters, MCA, 386
 - data port, 83
 - Dataport option, 64
 - data terminals
 - connections, 392, 429
 - installing, 428
 - RS-232-C connectors, 430
 - DC loop resistance
 - calculating, 299
 - maximum, 299
 - measuring, 306
 - dead telephones, troubleshooting, 433
 - designations
 - attendant consoles, 64
 - telephones, 119, 311, 367

- Diagnostics menu, 64
 - exiting from, 79
 - password-protection, 52, 80
 - selecting, 52, 80
- Diagnostics mode, 81
- diagnostic tests, loop, 300
- Dial 0 display, 92
- dialing failures
 - M2317 telephones, 367
- digital line cards, 56
- digital lines, enabling, 363
- digital telephones
 - cross-connections, 363
 - installing, 361
 - packing and unpacking, 355
 - self-tests, 363
 - trouble-locating procedures, 365
- Displays
 - cable routing, 407
 - for wall mounting, 432
 - installing and removing, 405, 408, 411, 416
 - troubleshooting, 433, 434
- DLC (Digital Line Card), 460
- DN (directory number) designation window, 65
- DTI (Digital Trunk Interface), 97
- DTMF (dual tone multifrequency) tones, 95

E

- E connectors (IPE), 316
- EI (Executive Intrusion), 98
- electret headsets, 466
- electromagnetic interference specifications
 - M3820, M3310, and M3110 telephones, 486
- Emergency status message, 55
- Emergency Transfer, 96
- engineering codes, 29

- engineering telephone lines
 - flowchart, 291
 - procedure, 289
- environmental and safety considerations
 - M2016S telephone, 109
 - M2317 telephone, 453
 - M3820, M3310, and M3110 telephones, 486
 - M3900 telephones, 185
 - Meridian Modular Telephones, 342
- Exclude Destination key, 94
- Exclude Source key, 94
- expected pulse loss, calculating, 302
- External Alerter Boards, 416
 - connecting block configuration, 418
 - troubleshooting, 436
- External Alerter interface, 473

F

- fastening screws, BLF/CGM, 36
- F connectors (IPE), 317
- feature keys, 94
 - modes, 79
- features
 - assigning to keys, 94
 - M2250 attendant console, 31, 89
 - modifying, 96
 - permanently assigned to keys, 93
- FI keystrip, 93
- finger wheels, 311
- FK keystrip
 - assignable features, 94
 - permanently assigned features, 93
- flashing LCDs, troubleshooting, 433
- footstands, 420, 421
- Foreign Exchange display, 92
- Fully Restricted Station indication, 92
- function keys, 51

G

garbled prompts, troubleshooting, 435

G connectors (IPE), 318

H

handsets

interfaces, 202

jack, 53, 56

options, 155, 202

volume control, 53

handsfree operation

M2317 telephone, 444

M3820, M3310, and M3110 telephones, 472

Meridian Modular Telephones, 332

headsets

electret, 466

interfaces, 156, 466

jack, 53, 56

volume control, 53

Hold key, 94

hold state

M3820, M3310, M3110, 472

Meridian Modular Telephones, 106, 330

I

ICI (Incoming Call Indicator) keys, 90

assignments, 92

QMT mode enabled/disabled, 78

selecting calls, 93

ICS procedure, 83

idle state

M2016S telephone, 106

M2317 telephone, 446, 447

M3820, M3310, M3110 telephones, 472

Meridian Modular Telephones, 330

Idle status message, 55

impedance, cable characteristic

under-carpet cabling, 290

vs. junction loss, 307

impulse noise

measuring, 302

vs. loop loss, 303

incoming calls

answering, 92, 93

indication, 78

queuing, 93

installation

ATA (Analog Terminal Adapter), 377

insulation resistance, testing, 301

Integrated Alarm Management, 97

Intelligent Peripheral Equipment (IPE)

cross-connections, 313, 315, 316

shelf, 460

Intercom, 450

ISDLC (Integrated Services Digital Line Card), 56,

460

ISDLC failures

M2317 telephones, 366

J

jacks

for headsets, 466

and TELADAPT snap-in connectors, 491

jumpers, 397

junction loss

determining, 304

vs. cable characteristic impedance, 307

K

K connectors (IPE), 316

Key-based Accessory module, 154

keyboard

layout, 51

testing key functionality, 82

key clicks, adjusting, 57

key designations, 64

- Key Expansion Modules, 420
 - connections, 422
 - for wall mounting, 432
 - installing and removing, 420
 - troubleshooting, 436
- key/lamp add-on modules, 373
- key/lamp strips
 - functions, 93
 - program mode, 96
- key location codes, 82
- keys
 - stuck (M2250 console), 87, 88
- knockout tabs, BLF/CGM, 39

L

- Lamp Field test procedures, 42, 84
- lamp tests, 83
- languages, 56
- LCD display screen
 - contrast, 56
 - description, 31
 - languages available, 56
 - messages, 55
 - softkey alternate functions, 80
 - softkey functions, 51
 - testing alphanumeric functionality, 85
- LCD indicators, 54
 - M2317, 444
 - M3820, M3310, M3110, 472
- LCDs, flashing, troubleshooting, 433
- L connectors (IPE), 317
- LD 12 program, 63
- LD 32 program, 362
- LD 12 program, 54
- LD 15 program, 77
- LD 31 (verification testing), 85
- Level 1 mode, accessing, 79

- line circuit card terminations, 119, 314, 368
 - attendant consoles, 68, 72
- line cord requirements, 440
- line cords
 - Meridian Modular Telephones, 373
- Listed Directory Numbers display, 92
- logos with Brandline Inserts, 473
- loopback tests, 64, 83
- Loop Keys/Lamps
 - described, 93
 - LCD indicators, 54
- loop length
 - M2250 attendant console, 59
- loop power failures, 365
- loops
 - diagnostic tests, 300
 - distances vs. AWG, 290
 - requirements, 299
 - selecting, 299
- loss, loop
 - maximum allowable, 299
 - vs. impulse noise counts, 303

M

- M2006 Meridian Modular Telephones, 325, 373
 - External Alerter Boards, 416
 - installing, 114, 356
 - Power Supply Boards, 393, 401
 - wall mounting, 432
- M2008 Meridian Modular Telephones, 325, 373
 - displays, 411
 - External Alerter Boards, 416
 - installing, 114, 356
 - Power Supply Boards, 393, 401
 - wall mounting, 432

- M2016S Meridian Modular Telephones, 373
 - diagram, 374
 - displays, 405, 408, 416
 - installing, 114, 356
 - Power Supply Boards, 395
 - wall mounting, 432
- M2216ACD Meridian Modular Telephones, 325, 373
 - diagram, 374
 - displays, 405, 408, 416
 - installing, 114, 356
 - Key Expansion Modules, 420
 - Power Supply Boards, 395
 - power supply boards, 397
- M2250 attendant console
 - BLF/CGM, 35
 - covers, 62, 63
 - cross-connecting, 71, 72, 73, 75
 - displaying number of waiting calls, 95
 - failure codes, 87
 - features, 31
 - installing, 60
 - key designations, 65
 - loopback tests, 64
 - loop length, 59
 - rear/left side/bottom views, 50
 - removing, 61
 - static discharge ground connections, 60
 - top view, 49
- M2317 data terminals
 - installing, 428
 - power supply connections, 429
 - RS-232-C connectors, 430
- M2317 telephone
 - cross-connections, 363
 - description and illustration, 439, 445
 - dimensions, 454
 - environmental and safety considerations, 453
 - installing, 361
 - line engineering, 454
 - power requirements, 454
 - screens and softkeys, 444
 - self-tests, 363
 - software requirements, 452
 - trouble-locating procedures, 365
- M2616 Meridian Modular Telephones, 325, 373
 - diagram, 374
 - displays, 405, 408, 411, 416
 - External Alert Boards, 416
 - handsfree, 332
 - installing, 114, 356
 - Key Expansion Modules, 420
 - Power Supply Boards, 395
 - power supply boards, 397
 - wall mounting, 432
- M3820, M3310, and M3110 telephones, 471
 - environmental and safety considerations, 486
 - fixed keys, 468
 - functions, connections, and interfaces, 460
 - hardware features and options, 472
 - line engineering, 188, 487
 - local alerting tones, 487
 - positions, 190
- M3900 telephones
 - add-ons, 147
 - description, 127
 - environmental and safety considerations, 185
 - features, 137
 - handset interface, 202
 - headset interface, 156
 - installing, 189
 - key descriptions, 159
 - line engineering, 188
 - wall mounting, 191
- Macintosh computers, 428, 429

major alarm indication/status message, 55, 95

MCA (Meridian Communications Adapter)
installing, 389
Key Expansion Modules, 420
troubleshooting, 435, 438
V.35 interface, 385, 387

M connectors (IPE), 318

measuring
background noise, 302
DC loop resistance, 306
impulse noise, 302

Meridian External Alerter and Recording Interface,
153

Meridian Modular Telephone add-ons
External Alerter Boards, 416
power supply boards, 401
troubleshooting, 433

Meridian Modular Telephones, 323–353
cross-connections, 121
designating, 119, 368
display module, 108, 335
exploded view, 374
installing, 114, 356
Key Expansion Module, 337
relocating, 340

Meridian Programmable Data Adapter, 335

messages, LCD display screen, 55

message waiting feature, 471

microphone
on M3820, M3310, M3110 telephones, 472

minor alarm indication/status message, 55, 95

modem pooling with MCA, 386

MPDA (Meridian Programmable Data Adapter)
installing, 389
Key Expansion Modules, 420

N

NE-284-74-5001 adapters
500/2500 connections, 313
terminal connections, 59

NE-47QA
500/2500 connections, 313
terminal connections, 59

NE-625F TELADAPT plugs and jacks
500/2500 connections, 313
terminal connections, 59

Night Service key, 94

Night Service mode
entering, 90
softkey, 51
status message, 55

noise measurements
background, 302
impulse noise, 302

no response, troubleshooting, 434, 435

normal call processing mode
accessing, 79
exiting Position Busy mode to, 90

normal operating ranges, wiring, 59

NT7G10AA (Attendant Supervisory Module), 90

NT8D02 cards, 72

O

operating keys, 93

Operating parameters for Virtual Office, 176

operating procedures, 77

operating ranges, wiring, 59

Options menu
Contrast option, 56
exiting from, 79
selecting, 51, 80

ordering information
codes, 29

P

- packing and unpacking
 - add-on modules, 372
 - attendant consoles, 59
 - telephones, 355
- parameters, MCA, 386
- PC-based Console application, 28
- peripherals testing, 83
- PFT (Power Fail Transfer) switch, 53, 55
- plugs and jacks
 - 500/2500 connections, 313
 - terminal connections, 59
- Position Busy key, 93
- Position Busy mode
 - entering, 90
 - and fault conditions, 101
 - indication, 89
 - softkey, 51
 - status message, 55
- Power Fail Transfer (PFT) switch, 53
- power failures, resets after, 101
- power requirements
 - for ADO (Asynchronous Data Option), 424
 - for headsets, 466, 488
 - for recording devices, 156, 202, 466
 - M2317 telephone, 453, 454
 - M3820, M3310, M3110 telephones, 488
- power supplies and power units
 - BLF/CGM, 33
 - data terminals, 429
 - Key Expansion Modules, 420
 - MCA and MPDA, 347, 384
 - Meridian Modular Telephones, 392, 401
- Power Supply Boards
 - closet configuration, 400
 - installing, 393, 395, 397, 401
 - Key Expansion Modules, 420
 - MCA and MPDA, 347, 384
 - removing, 393, 401
 - transformers, 399

- Power supply boards, 392, 401
- programmable keys
 - M2317 telephones, 443
 - M3820, M3310, M3110, 471
- PVC cable, 343, 487

Q

- QBB1B
 - 500/2500 connections, 313
 - terminal connections, 59
- QMT2 DIP switch, 85
- QMT2 mode
 - configuring attendant consoles for, 77
 - enabling/disabling, 78
 - LCD indicators, 54
- queues
 - Call Waiting indicator, 95
 - removing calls from, 92

R

- ranges
 - wiring, 59
- R connectors (IPE), 316
- Recall display, 93
- Release Destination key, 94
- Release key, 93
- RELEASE prompts, troubleshooting, 435
- Release Source key, 94
- relocation of Meridian Modular Telephones, 340
- remote ringers, 153, 473
- resetting attendant consoles
 - described, 101
 - hard reset procedure, 87
- ringing state
 - on M2006/2008/2616/2016S/2216ACD
 - Digital telephones, 106, 330
 - on M3820, M3310, M3110, 472

RLS key
Meridian Modular Telephones, 116, 358

RS-232-C connectors, 428, 430

S

S connectors (IPE), 317

screens
on M2317, 440, 444

scrolling LCD display screen, 52, 80

security codes with relocations, 341

selecting loops, 299

self-tests
M2317 telephone, 363

Semi-Automatic Camp-On, 99

Series Call, 100

Shift key purpose/location, 53

Signal Destination key, 53, 94

Signal Source key, 53, 94

softkeys
alternate functions, 80
definitions/functions, 51
M2317 telephones, 447

Speed Call feature, 95

Speed Call for Virtual Office, 176

Speed Calling
with M2317 telephones, 452

S status message, 55

standoffs, 46, 47

static discharge ground connections, 60

status messages, 55

submenus, 79

support spacers, BLF/CGM, 38

T

T connectors (IPE), 318

TELADAPT connectors
500/2500 connections, 313
M2317 telephones, 361
Meridian Modular Telephones, 114, 356
terminal connections, 59

TELADAPT snap-in connectors, 491

telephone failures
M2317 telephones, 367

telephone lines, engineering, 289

telephones
Asynchronous Data Options, 426
connecting, 312
cross-connecting, 119, 121, 313, 363, 368
designating, 119, 311, 367
exploded view, 374
installing, 114, 356, 361
key/lamp modules, 373
packing and unpacking, 355
power supplies, 392, 395, 397, 401
removing, 310
self-tests, 363
trouble-locating procedures, 365
wall mounting, 432
wiring, 313

temperature, cable
and cable attenuation, 305
correcting for, 304

temperature and humidity ranges for operations
M2317 telephone, 453
Meridian digital telephones, 185, 486

terminal connections, 59

testing
capacitance unbalance, 301
DC continuity, 301
insulation resistance, 301

tests, loop diagnostic, 300

TGB (Trunk Group Busy) indicators, 89

TGB (Trunk Group Busy) keys
accessing, 79
QMT2 mode enabled/disabled, 78

Tie Trunk display, 93
time/date feature, 89
TN (Terminal Number) and relocations, 340
tones, generating, 86
transformers
 BLF/CGM, 44
 for headsets (AC), 466
 local plug-in, 489
 Power Supply Boards, 399
trouble-locating procedures
 M2317 telephones, 365
troubleshooting Meridian Modular Telephones, 433
trunks
 busy indication, 78
 incoming calls on tie, 93
 status indications, 89

U

User interface printed circuit card (UIP)
 hard reset, 87
 installed firmware test, 85
 testing peripherals connected to, 83

V

V.35 interface, 385, 387
verification testing (LD 31), 85
Virtual Office (non-networked), 173
Virtual Office feature implementation, 177
voice channels/ports, 460
voice failures
 M2317 telephones, 367
volume control
 M3820, M3310, M3110, 471
volume slider position, BLF/CGM, 36

W

wall mount clips, 432
Wide Area Telephone Service display, 93

wiring
 displays, 407
 installing, 57
 MCA, 385
 operating ranges, 59
 telephones and attendant consoles, 69
 terminal connections, 59
 zone cabling and conduit, 57, 58
wiring and loop lengths
 M2006/2008/2616/2016S/2216ACD Digital
 telephones, 343
 M2317 telephone, 454
 M3820, M3310, M3110, 491
 M3820, M3310, M3110 telephones, 487, 488
wobbling, troubleshooting, 433

Z

zone cabling and conduit, 58
Z wiring
 500/2500 telephones, 313
 attendant consoles, 69
 cross-connections, 119, 120, 314, 319, 368,
 369
 terminal connections, 59

Nortel Communication Server 1000
Telephones and Consoles
Description, Installation, and Operation

Copyright © Nortel Networks Limited 2005
All Rights Reserved

Information is subject to change without notice.
Nortel Networks reserves the right to make changes in design
or components as progress in engineering and manufacturing
may warrant.

Nortel, Nortel (Logo), the Globemark, This is the Way, This is
Nortel (Design mark), SL-1, Meridian 1, and Succession are
trademarks of Nortel Networks.

Publication number: 553-3001-367
Document release: Standard 3.00
Date: August 2005
Produced in Canada



>THIS IS **THE WAY**

>THIS IS **NORTEL™**

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>