SnapNType PDA Keyboard for Palm[™] Handhelds User Guide



P73991

F8P3500

Introduction

Congratulations on your purchase of the SnapNType PDA Keyboard for your Palm handheld. The SnapNType is easy to install and use. With its compact design, you can start writing your e-mails and notes anywhere you go.

Setting Up Your SnapNType Keyboard

Installing the SnapNType Keyboard Software

Before installing the SnapNType software, please make sure that:

- 1) You have disabled all other keyboard software installed in your Palm handheld
- 2) You have performed a HotSync[®] function to backup all data.
- 3) Your Palm handheld has at least 10KB of free memory.

Follow these instructions to install SnapNType software on your Palm handheld

- 1) Insert the SnapNType floppy disk into your computer's floppy drive.
- Double-click the "My Computer" icon on the Windows desktop and double-click the "3.5" Floppy" icon. Then double-click on "SnapNType.prc". This will launch the Palm desktop installation tool.
- 3) Click once on the "SnapNType.prc" driver.
- 4) Click "Done".
- 5) Perform a HotSync function to transfer the SnapNType software onto your Palm handheld.



Setting Up Your SnapNType Keyboard (continued)

Attaching the SnapNType Keyboard to Your Palm Handheld

- 1) Press the two side buttons simultaneously to release the keyboard lock.
- 2) While still pressing the side buttons, flip the keypad backward.
- Slowly slide in your Palm handheld until the connector on the SnapNType keyboard latches the HotSync port securely. (See Fig. 1)
- You will hear a "beep" sound from your Palm handheld to indicate proper connection of the keyboard and activation of the SnapNType driver.
- 5) Fold the keypad onto your Palm handheld until the keyboard lock latches securely. (See Fig. 2)
- 6) The SnapNType keyboard is now ready for use.



Fig. 1



Fig. 2





Setting Up Your SnapNType Keyboard (continued)

Detaching the SnapNType Keyboard from Your Palm Handheld

- 1) Press the two side buttons simultaneously to release the keyboard lock.
- 2) While still pressing the side button, flip the keypad backward until it opens completely. (See Fig. 3)
- In an action similar to removing your Palm handheld from the HotSync cradle, slightly push your Palm handheld toward the keypad and remove it from the keyboard connector. (See Fig. 4)
- You will hear a "beep" sound to indicate deactivation of the SnapNType driver.



Fig. 3: Press the release button to release the connector lock.



Fig. 4: Slide the Palm handheld away from the keyboard.

Using Your SnapNType Keyboard

The SnapNType software driver has an advanced automatic enable/disable function. The driver will enable itself once you connect the SnapNType keyboard to your Palm handheld. When you disconnect the SnapNType keyboard, the driver will automatically disable itself. There is no need to manually turn on or off the SnapNType driver.

Typing Lowercase Letters

To enter lowercase letters with your SnapNType keyboard, simply type them as you would on a standard computer keyboard.

Typing Uppercase Letters

To capitalize one letter: Press $_{\fbox}$ once and the next letter you enter will be capitalized.

To capitalize a block of letters: Press and hold and all other letters you enter while holding will be capitalized.

To turn on "Caps Lock": Press 🗢 and then press 💮 . For as long as 💮 is turned on, all characters will be entered in uppercase.

To release "Caps Lock": Press 🚥 and then press 📻 .



- \ominus

Using Your SnapNType Keyboard (continued)

Typing Numbers and Symbols

To type one number or symbol: press once. The next key you press will register as the number or symbol printed in orange on the top of the key.

To type a block of numbers or symbols: press and hold . All other keys you press while holding will register the number or symbol.

To turn on "Symbol Lock": press twice to enter the "Symbol Lock" mode. All keys pressed during "Symbol Lock" mode will register as numbers or symbols.

To release "Symbol Lock": while in "Symbol Lock" mode, pressing one more time will release "Symbol Lock".



Using Your SnapNType Keyboard (continued)

Navigation Keys

The navigation keys enable you to quickly relocate the cursor on your Palm handheld. The following table lists available navigation key commands.

\leftarrow	

Keystroke	Action	
(Page Up	
()	Page Down	
📼 K)	Cursor Left	
	Cursor Right	
•••• (i)	Cursor Up	
•••• Q	Cursor Down	
(TAE)	Space	
CONTRACTOR CONTRACTOR	Tab	
BACK	Back Space / Delete	
Ð	Return	





Using Your SnapNType Keyboard (continued)

Application Keys

There are four application buttons on the bottom of the SnapNType keyboard. They will replace the buttons on your Palm that were covered by the keyboard. There are four different functions assigned to each button, you can activate different function by:

- 1. Tapping press and release the button
- 2. Press and hold the button

3. Press the 🗢 key and then the button

4. Press the \bigcirc key and then the button

The following table list the default functions associated with each button.

	Press and Release	Press and Hold	9+	œ +
6	Date Book	SnapNType	Applications	Done
0	Address Book	Clock	Pull Down Menu	OK
Ð	To Do List	Mail	Calculator	Details
Ø	Memo Pad	Preferences	Search	Delete





Using Your SnapNType Keyboard (continued)

Using the FaceBoard

Pressing the "Faceboard" button will pop up a window containing various less frequently used symbols and punctuation marks. There are also popular "smiley" patterns for your e-mails. Simply tap the on-screen buttons or the corresponding key on your SnapNType keyboard to select the symbol you want to enter.





Configuring the SnapNType Software

You can customize various features of the SnapNType program to best suit your application. To start the SnapNType configuration program, tap the "SnapNType" icon on your Palm handheld.

General Configuration



Enable—this will allow the SnapNType to accept key input.

Disable—this will turn off the SnapNType.

Repeat Rate—this will determine the repeat frequency of a key when you hold it down continuously.

Delay Until Repeat—this will determine the delay from your holding down a key to the key repeating.

Click Sound—you can enable or disable "key click". For this function to work properly, you need to first turn on "System Sound" in your Palm handheld. Please consult your Palm manual on how to turn on "System Sound".

Test Area—you can test your SnapNType by typing in this area.





Configuring the SnapNType Software (continued)

Programmable Buttons

You can program the four application buttons to launch your favorite applications or emulate different soft buttons. After launching the SnapNType configuration program, press and then to start the menu options. Tap on "Preferences" and the following screen will appear:



You can program the application launcher from the right side of your "Preference" screen.





Download from Www.Somanuals.com. All Manuals Search And Download.



Configuring the SnapNType Software (continued)



You can program the application launcher from the right side of your "Preference" screen.



You can program the soft-key emulation setting from the left side of your "Preference" screen.



 $-\phi$

Frequently Asked Questions (FAQs)

Do I need to disable the SnapNType driver before performing HotSync functions?

The SnapNType driver is fully compatible with the Palm HotSync function. The driver will not interfere with this function.

Do I need to disable the SnapNType driver every time I remove the device?

No, the SnapNType driver will disable itself every time you remove the device.

Why can't I hear a "beep" sound when connecting or disconnecting the SnapNType keyboard?

Please make sure your system's sound option is turned on.





5/23/02 P73991-F8P3500-PKG.QXD 1:31 PM Page 14

Information

FCC Statement

DECLARATION OF CONFORMITY WITH FCC RULES FOR ELECTROMAGNETIC COMPATIBILITY

We, Belkin Components, of 501 West Walnut Street, Compton, CA 90220, declare under our sole responsibility that the product: F8P3500

to which this declaration relates: Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE Declaration of Conformity

We, Belkin Components, declare under our sole responsibility that the F8P3500, to which this declaration relates, is in conformity with Generic Emissions Standard EN50081-1 and with Generic Immunity Standard EN50082-1 1992.

ICES Statement

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Belkin Components Limited 3-Year Product Warranty

Belkin Components warrants this product against defects in materials and workmanship for its lifetime. If a defect is discovered, Belkin will, at its option, repair or replace the product at no charge provided it is returned during the warranty period, with transportation charges prepaid, to the authorized Belkin dealer from whom you purchased the product. Proof of purchase may be required.

This warranty does not apply if the product has been damaged by accident, abuse, misuse, or misapplication; if the product has been modified without the written permission of Belkin; or if any Belkin serial number has been removed or defaced.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN, EXPRESSED OR IMPLIED. BELKIN SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

No Belkin dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

BELKIN IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH BELKIN PRODUCTS.

Some states do not allow the exclusion or limitation of incidental or consequential damages or exclusions of implied warranties, so the above limitations of exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.



Belkin Components 501 West Walnut Street Compton • CA • 90220 • USA Tel: 310.898.1100 Fax: 310.898.1111

Belkin Components, Ltd. Express Business Park Shipton Way • Rushden • NN10 6GL United Kingdom Tel: +44 (0) 1933 35 2000 Fax: +44 (0) 1933 31 2000

Belkin Components, Ltd. Express Business Park Shipton Way • Rushden • NN10 6GL United Kingdom Tel: +44 (0) 1933 35 2000 Fax: +44 (0) 1933 31 2000

Belkin Components, Ltd. 7 Bowen Cresent • West Gosford NSW 2250 • Australia Tel: +61 (2) 4372 8600 Fax: +61 (2) 4325 4277

© 2002 Belkin Components. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.



Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com