Panasonic

Operating Instructions

Air Conditioner



Model No.

Indoor Unit	Outdoor Unit
CS-C12PKF-3	CU-C12PKF-3
CS-C18PKF-3	CU-C18PKF-3
CS-C24PKF-3	CU-C24PKF-3



Operating Instructions Air Conditioner

Thank you for purchasing Panasonic Air Conditioner. Installation instructions attached. Before operating the unit, read these operating instructions thoroughly and keep them for future reference.

Provide electricity protection solution, maximum comfort, clean air and optimise energy saving

ECONAVI and AUTO COMFORT

Equipped with the human activity sensor, the air conditioner ensures to deliver cool air to you, and keeps the room consistently comfortable with minimum energy consumption.

Furthermore, the sunlight sensor detects the sunlight intensity and helps control cooling temperatures to provide optimum comfort.

See "To learn more..." for details.

nanoe-G


Deactivates harmful micro-organisms such as viruses, bacteria, etc. to keep air clean. It also deactivates viruses and bacteria on the filter to keep inside of the unit clean.

Automatic Voltage Switcher (AVS)

Monitors voltage level and protects air conditioner from unstable power supply.




Quick guide




Inserting the batteries

- 1 Pull out the back cover of remote control
- (can be used ~ 1 year)
- 3 Close the cover




Clock setting

- 1 Press CLOCK
- (2) Set the time
- (3) Confirm



Basic operation

Select the desired mode




(2) Start/stop the operation



- Please note that the OFF indication OFF is on to start.
- (3) Select the desired temperature
 - Selection range: 16 °C ~ 30 °C.
 - Operating the unit within the recommended temperature may save energy.

COOL: 26 °C ~ 28 °C.

DRY : 1 °C ~ 2 °C lower than room temperature.



- To dim or restore the unit's indicator brightness, press and hold for 5 seconds.
 - Use remote control within 8 m from the remote control receiver of the indoor unit.

The illustrations in this manual are for explanation purposes only and may differ from the actual unit. They are subject to change without notice for future improvement.

Table of contents

Safety precautio	ns 4-5
How to use	6-7
To learn more	8-9
Cleaning instruc	tions10
Troubleshooting	11
Information	Back cover

Accessories

- · Remote control
- AAA or R03 batteries × 2
- · Remote control holder
- Screws for remote control holder × 2

Safety precautions

To prevent personal injury, injury to others or property damage, please comply with the following:

Incorrect operation due to failure to follow instructions below may cause harm or damage, the seriousness of which is classified as below:



This sign warns of death or serious injury.



CAUTION

This sign warns of injury or damage to property.

The instructions to be followed are classified by the following symbols:




This symbol denotes an action that is PROHIBITED.







These symbols denote actions COMPULSORY.





WARNING

Indoor unit and outdoor unit



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Please consult authorised dealer or specialist to clean the internal parts, repair, install, remove and reinstall the unit. Improper installation and handling will cause leakage, electric shock or fire.

Confirm with authorised dealer or specialist on usage of any specified refrigerant type.
Using refrigerant type other than the specified may cause product damage, burst and injury etc.



Do not install the unit in a potentially explosive or flammable atmosphere. Failure to do so could result in fire.

Do not insert your fingers or other objects into the air conditioner indoor or outdoor unit, rotating parts may cause injury.



Do not touch the outdoor unit during lightning, it may cause electric shock.

Do not expose yourself directly to cold air for a long period to avoid excess cooling.

Do not sit or step on the unit, you may fall down accidentally.



Remote control



Do not allow infants and small children to play with the remote control to prevent them from accidentally swallowing the batteries.

Power supply



Do not use a modified cord, joint cord, extension cord or unspecified cord to prevent overheating and fire.






To prevent overheating, fire or electric shock:

- Do not share the same power outlet with other equipment.
- · Do not operate with wet hands.
- Do not over bend the power supply cord.
- Do not operate or stop the unit by inserting or pulling out the power plug.



Use complete power supply cord without joining. In unavoidable circumstances that complete power supply cord without joining is impossible, use an approved connection means (for example: socket and plug).



If the supply cord is damaged, it must be replaced by the manufacturer, service agent or similarly qualified persons in order to avoid a hazard

It is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD) to prevent electric shock or fire.

To prevent overheating, fire or electric shock:

- Insert the power plug properly.
- Dust on the power plug should be periodically wiped with a dry cloth.

Stop using the product if any abnormality/ failure occurs and disconnect the power plug or turn off the power switch and breaker. (Risk of smoke/fire/electric shock) Examples of abnormality/failure

- The ELCB trips frequently.
- Burning smell is observed.
- Abnormal noise or vibration of the unit is observed
- Water leaks from the indoor unit.
- · Power cord or plug becomes abnormally hot.
- Fan speed cannot be controlled.
- The unit stops running immediately even if it is switched on for operation.
- The fan does not stop even if the operation is stopped.

Contact your local dealer immediately for maintenance/repair.



This equipment must be earthed to prevent electrical shock or fire.



Prevent electric shock by switching off the power supply and unplug: - Before cleaning or servicing,



- When extended non-use, or
- During abnormally strong lightning activity.





CAUTION

Indoor unit and outdoor unit



Do not wash the indoor unit with water. benzine, thinner or scouring powder to avoid damage or corrosion at the unit.

Do not use for preservation of precise equipment, food, animals, plants, artwork or other objects. This may cause quality deterioration, etc.

Do not use any combustible equipment in front of the airflow outlet to avoid fire propagation.

Do not expose plants or pet directly to airflow to avoid injury, etc.

Do not touch the sharp aluminium fin, sharp parts may cause injury.



Do not switch ON the indoor unit when waxing the floor. After waxing, aerate the room properly before operating the unit.

Do not install the unit in oily and smoky areas to prevent damage to the unit.

Do not dismantle the unit for cleaning purpose to avoid injury.

Do not step onto an unstable bench when cleaning the unit to avoid injury.

Do not place a vase or water container on the unit. Water may enter the unit and degrade the insulation. This may cause an electric shock.

Do not open window or door for long time during COOL/DRY mode operation.



Prevent water leakage by ensuring drainage pipe is:

- Connected properly.
- Kept clear of gutters and containers, or
- Not immersed in water

After a long period of use or use with any combustible equipment, aerate the room regularly.

After a long period of use, make sure the installation rack does not deteriorate to prevent the unit from falling down.

Remote control



Do not use rechargeable (Ni-Cd) batteries. It may damage the remote control.



To prevent malfunction or damage of the remote control:

- Remove the batteries if the unit is not going to be used for a long period of time.
- · New batteries of the same type must be inserted following the polarity stated.

Power supply



Do not disconnect the plug by pulling the cord to prevent electric shock.

How to use

To optimise energy saving

MODE

To select operation mode

AUTO - For your convenience

- Unit selects the operation mode according to the room temperature.
- Once AUTO mode is selected, the unit will operate at the standard setting temperature.

Room temperature	Operation mode	Standard setting temperature
23°C & above	COOL	25°C
Below 23°C	DRY	22°C


• Press △ for "HI" to +2°C or ▽ for "LO" to -2°C to the standard setting temperature.

COOL - To enjoy cool air

 To reduce power consumption during COOL mode, use curtains to screen off sunlight and outdoor heat.

DRY - To dehumidify the environment

 Unit operates at low fan speed to give a gentle cooling operation.




→ POWERFUL → QUIET → NORMAL ¬

POWERFUL: To reach temperature quickly ○○POWERFUL

This operation will stop automatically after 15 minutes.

QUIET: To enjoy quiet operation :○:QUIET

This operation reduces airflow noise.





 For AUTO, the indoor fan speed is automatically adjusted according to the operation mode.

Auto OFF/ON button



Use when remote control is misplaced or a malfunction occurs. Raise the front panel:

- To use in AUTO mode, press the button once.
- To use in COOL mode, press and hold the button until 1 beep is heard, then release.
- · Press the button again to turn off.

AUTO COMFORT

To maximise comfort

-O-AUTO COMFORT

NANOE-G

To purify the air

:⊚:NANOE-G

- nanoe-G starts automatically when the unit is turned on with OFF/OND.
- Can be activated even when the unit is turned off. In this condition, the unit will operate as a fan with AUTO fan speed and louver swing.

To deactivate viruses/bacteria on the filter

- €0€NANOE-G POWER
- After the unit is turned off, the nanoe-G in-filter deactivation may activate up to 150 minutes.
 Turning on the unit cancels this operation.
- To disable this operation in the future, press and hold intil a short beep sound is heard. This will not disable the nanoe-G to purify the air.
- To restore the nanoe-G in-filter deactivation, press and hold in until a long beep sound is heard.



To adjust airflow direction


(Remote control display)



- Keeps the room ventilated.
- In COOL/DRY mode, if AUTO is set, the louver swings left/right and up/down automatically.
- · Do not adjust the louver by hand.

To set the timer

To turn ON or OFF the unit at a preset time.



1 Select ON or OFF timer





2 Set the time



③ Confirm



- To cancel ON or OFF timer, press $\stackrel{\text{ON}}{=}$ or $\stackrel{\text{OFF}}{=}$ then press $\stackrel{\text{CANCE}}{=}$.
- If timer is cancelled manually or due to power failure, you can restore the previous setting (once power is resumed) by pressing
- When ON Timer is set, the unit may start earlier (up to 15 minutes) before the actual set time in order to achieve the desired temperature on time.
- Timer operation is based on the clock set in the remote control and repeats daily once set.
 For clock setting, please refer to Quick guide.

Note



 Can be activated in all modes and can be cancelled by pressing the respective button again.



Cannot be selected at the same time.

To learn more...

Operation mode

COOL: Use curtains to screen off sunlight and outdoor heat to reduce power consumption during COOL mode.

DRY: Unit operates at low fan speed to give a gentle cooling operation.

nanoe-G in-filter deactivation

Depending on the unit's accumulated operation time, nanoe-G in-filter deactivation may activate only once a day after the unit turned off.

To remove the moisture left in the internal parts, the fan will operate for 30 minutes with louver opened slightly. This process only applicable when the unit is operated in COOL/DRY mode before turned off. Then, nanoe-G deactivates viruses/bacteria on the filter for 2 hours with fan stopped and louver closed.


Do not turn off the power supply during this operation. After power failure, this operation will not resume.

ECONAVI and AUTO COMFORT





The unit will start to initialise (for approximately 1 minute)





Note




When manual AIR SWING is selected, the ECONAVI and AUTO COMFORT operations will be cancelled.

Human activity sensor operation






AUTO COMFORT; Detecting human presence and activity, the unit controls room temperature to keep human comfortable consistently.



- * During low activity, fan speed 1 tap up for first 15 minutes or until set temperature is reached.
- ** During human absence, maximum fan speed for COOL/DRY mode is medium fan.

The human activity sensor will also scan for area of heat source and movement in a room.




The unit judges human activity area for a few seconds before indicator updates. Based on area activeness horizontal airflow direction louver will adjust either fix at predetermined position or swing left/right periodically.

- The human activity sensor performance is influenced by indoor unit location, movement speed, temperature range, etc.
- The human activity sensor may:
 - mistakenly detect an object with heat source & movement similar to human, such as pets, etc.
- mistakenly detect as non-heat source & movement if a human stays motionless for certain period of time.
- Do not place large objects near the sensor and keep away heating units or humidifier from the sensor's detection area. They may cause sensor malfunction.

Sunlight Sensor operation

ECONAVI; Detecting sunlight intensity, the unit adjust temperature to save energy.



ECONAVI is activated, the unit maintains set temperature until a high sunlight intensity is detected. The sunlight sensor detects sunlight intensity during weather or day/night changes, and the unit adjusts temperature.

In a room without window or with thick curtain, the sunlight sensor will judge as cloudy/night.

Automatic Voltage Switcher (AVS)

When power supply is unstable, where the AC voltage supplied is below 185 V or above 260 V, AVS will switch off the outdoor unit to protect the compressor. During this condition, the AVS indicator will turn on.

	Indicator	Indoor unit	Outdoor unit
POWER/AVS	Green	ON	ON
	Orange	ON	OFF

Note: Room temperature may rise during AVS ON.

Operation conditions

Use this air conditioner under the following temperature range.


DBT: Dry bulb temperature WBT: Wet bulb temperature

Temperature (°C)		Indoor		Outdoor	
remperature	(0)	DBT	WBT	DBT	WBT
0001	Max.	32	23	55	31
COOL	Min.	16	11	16	11

Cleaning instructions

To ensure optimal performance of the unit, cleaning has to be carried out at regular intervals. Please consult authorised dealer.

- Switch off the power supply and unplug before cleaning.
- Do not touch the aluminium fin, sharp parts may cause injury.
- Do not use benzine, thinner or scouring powder.
- Do not use water hotter than 40 °C.



Indoor unit

Wipe the unit gently with a soft, dry cloth.




Human activity sensor

Do not hit or violently press or poke it with a sharp object. This can lead to damage and malfunction.


Front panel

Wash gently and dry.

Remove the front panel



Close it securely



- (2) Close down
- 4 For CS-C18PKF-3, CS-C24PKF-3: Press at center of the front panel.

nanoe-G Generator

Every 6 months

- Clean with dry cotton bud.
- Do not touch during operation.



Air filters


Every 2 weeks

- Wash/rinse the filters gently with water to avoid damage to the filter surface.
- Dry the filters thoroughly under shade, away from fire or direct sunlight.
- Replace any damaged filters.

Remove air filter



Attach air filter



Insert into the unit

For seasonal inspection after extended non-use

- · Checking of remote control batteries.
- No obstruction at air inlet and air outlet vents.
- After 15 minutes of operation, it is normal to have the following temperature difference between air inlet and air outlet vents:

COOL: ≥8 °C

For extended non-use

- Activate nanoe-G operation for 2~3 hours as an alternative to remove moisture left in the internal parts thoroughly to prevent mould growth.
- Turn off the power supply and unplug.
- Remove the remote control batteries.

Troubleshooting

The following symptoms do not indicate malfunction.

Symptom	Cause
Mist emerges from indoor unit.	Condensation effect due to cooling process.
Water flowing sound during operation.	Refrigerant flow inside the unit.
The room has a peculiar odour.	• This may be due to damp smell emitted by the wall, carpet, furniture or clothing.
Indoor fan stops occasionally during automatic fan speed setting.	This helps to remove the surrounding odour.
Operation is delayed a few minutes after restarting.	• The delay is a protection to the unit's compressor.
Outdoor unit emits water/steam.	Condensation or evaporation occurs on pipes.
TIMER indicator is always on.	The timer setting repeats daily once set.
Cracking sound during operation.	Changes of temperature caused the expansion/ contraction of the unit.
2 or more human activity indicator turns on simultaneously.	Judgement of heat source and movement area in progress.

Check the following before calling for servicing.

Symptom	Check
Operation in COOL mode is not working efficiently.	Set the temperature correctly. Close all doors and windows. Clean or replace the filters. Clear any obstruction at the air inlet and air outlet vents.
Noisy during operation.	Check if the unit has been installed at an incline. Close the front panel properly.
Remote control does not work. (Display is dim or transmission signal is weak.)	Insert the batteries correctly. Replace weak batteries.
The unit does not work.	Check if the circuit breaker is tripped. Check if timers have been set.
The unit does not receive the signal from the remote control.	Make sure the receiver is not obstructed. Certain fluorescent lights may interfere with signal transmitter. Please consult authorised dealer.

NON SERVICEABLE CRITERIAS

TURN OFF POWER SUPPLY AND UNPLUG then please consult authorised dealer under the following conditions:

- · Abnormal noise during operation.
- Water/foreign particles have entered the remote control.
- · Water leaks from Indoor unit.

- · Circuit breaker switches off frequently.
- · Power cord becomes unnaturally warm.
- · Switches or buttons are not functioning properly.

Information

English

Information for Users on Collection and Disposal of Old Equipment and used Batteries



[Information on Disposal in other Countries outside the European Union]

These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.



Note for the battery symbol (bottom two symbol examples):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.



Pb

Panasonic Corporation Website: http://panasonic.net/

© Panasonic Corporation 2012

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com