

Register your product and get support at
www.philips.com/welcome

User Manual



PHILIPS

1

4


5

6

1

2

3



10

11


12

13

7

8

9



17



18

19

14


15

16



6 x R20 · UM-1 · D-CELLS

2



6





3



7



4



5



Congratulations on your purchase and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Supplied Accessories

– AC power cord

Top/front panels (See 1)

- ① **DBB** – turns the bass enhancement on/off
- ② **TUNING +/-** – tunes to radio stations
- ③ **PUSH TO OPEN** – opens/closes the CD door
- ④ **Source selector: CD/USB, FM, MW, OFF**
– selects CD, USB or radio (FM/MW) source
– switches off the set
- ⑤ **VOLUME** – adjusts volume level
- ⑥ **Display** – shows the CD/USB functions.
- ⑦ **CD/USB** – enters disc or USB mode
- ⑧ **MODE** – selects different play modes: e.g. REPEAT or SHUFFLE (random order).
- ⑨ **USB port** – connects an external USB device.
- ⑩ **▶ ||** – starts or pause CD/USB playback
◀ ▶ – selects the next/previous track
– searches forwards/backwards (press and hold the button) within the current track
■ – stops disc/USB playback;
– erases a program
- ⑪ **USB REC** – copies music to an external USB device.
- ⑫ **ALB +/-** – *For MP3-CD/USB only:* select albums.
- ⑬ **PROG** – programs tracks and reviews the program

Back/bottom panel (See 1)

- ⑭ **MP3 LINK** – inlet for external audio source.
- ⑮ **AC MAINS~** - inlet for power cord.
- ⑯ **Voltage selector** - adjusts to match the local voltage: 110-127V or 220-240V.
- ⑰ **Telescopic antenna** - improves FM reception.
- ⑱ **🎧** - 3.5 mm stereo headphone socket

Helpful hints: The speakers will be muted when headphones are connected to the set.

- ⑲ **Battery door** – Press on the arrow and push to insert 6 x 1.5V **R-20/ UM-1/ D-cells**.

CAUTION

- **Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.**
- **(Invisible) Laser Radiation when open. DO NOT STARE INTO BEAM.**
- **High voltage! Do not open. You run the risk of getting an electric shock. The machine does not contain any user-serviceable parts.**
- **Modification of the product could result in hazardous radiation of EMC or other unsafe operation.**

Power Supply

Whenever convenient, use the power supply cord if you want to conserve battery life.

Make sure you remove the plug from the set and wall outlet before inserting batteries.

Batteries (not included)

- 1 Open the battery door and insert 6 batteries, type **R-20, UM-1** or **D-cells**, (preferably alkaline) with the correct polarity as indicated by the "+" and "-" symbols inside the compartment.
- 2 Close the battery door, making sure the batteries are firmly and correctly in place. The set is now ready to operate.

Batteries contain chemical substances, so they should be disposed of properly.

- *Incorrect use of batteries can cause electrolyte leakage and will corrode the compartment or cause the batteries to burst:*
- *Do not mix battery types: e.g. alkaline with carbon zinc. Only use batteries of the same type for the set.*
- *When inserting new batteries, do not try to mix old batteries with the new ones.*
- *Remove the batteries if the set is not to be used for a long time.*

Using AC power

WARNING: Always check you have completely switched off the set, before you change or disconnect power supply.

- 1 Check if the power voltage, **as shown on the type plate located on the bottom of the set**, corresponds to your local power supply. If it does not, consult your dealer or service center.
- 2 Connect the power cord to the **AC MAINS~** inlet and the wall socket. The set is now connected and ready for use.
- 3 To switch the set off completely, withdraw the power cord from the wall socket.
- 4 Install the unit near the AC outlet and where the AC power plug can be easily reached.

- Disconnect the power cord from the wall socket to protect your set during heavy thunderstorms. Children could seriously injure

themselves as the free end of the cable may still be live if only the connector is removed from the MAINS socket at the back of the unit.

The type plate is located on the bottom of the set.

Helpful hints:

- To avoid unnecessary energy consumption, always adjust the **Source selector** to **OFF** after using the set.

General operation

Switching on and off and selecting the function

- 1 To select your sound source, adjust the **Source selector** to: **CD/USB, FM** or **MW**.
- 2 To switch off the set, adjust the **Source selector** to **OFF** position.
- 3 To switch to **MP3 LINK** mode, connect an external audio source to the **MP3 LINK** inlet.

Helpful hints:

- The set switches to **MP3 LINK** mode automatically when an external audio source is connected, no matter the set is in **CD/USB, FM** or **MW** mode.
- The **MP3 LINK** inlet is not for earphones.

Adjusting volume and sound

Adjust the sound with the **VOLUME** and **DBB** controls.

Radio reception

- 1 Adjust the **Source selector** to **FM** or **MW**.
- 2 Turn **TUNING** to tune to a station.

To improve radio reception

- For FM, extend, incline and turn the telescopic antenna for best reception. Reduce its length if the signal is too strong.
- For MW, the set uses a built-in antenna. Direct this antenna for best reception by turning the whole set.

About MP3

The music compression technology MP3 (MPEG1 Audio Layer 3) significantly reduce the digital data of an audio CD while maintaining CD quality sound.

- **Getting MP3 files:** you can either download legal music files from the internet to your computer hard disc, or create such files by converting audio CD files in your computer through appropriate encoder software. (128kbps bit rate or higher is recommended for MP3 files.)
- **Creating an MP3 CD:** burn the music files from your computer hard disc on a CDR or CDRW using your CD burner.

Helpful Hints:

- Make sure that the file names of the MP3 files end with **.mp3**.
- Total number of music files and albums: around 400 (with a typical file name length of 20 characters)
- The length of file names affects the number of tracks for playback. With shorter file names, more files can be burned on a disc.

Playing a disc

- This CD player plays Audio Discs including CD-Recordables (CD-R), CD-Rewritables (CD-RW) and MP3/WMA CD.
- CD-ROM, CD-I, CDV, VCD, DVD or computer CDs are not possible for playback.

IMPORTANT!

- CDs encoded with **copyright protection technologies** by some record companies may be unplayable by this product.
- DRM-protected WMA disc is not support.

1 Adjust the **Source selector** to **CD/USB**.

2 Press **CD/USB** once or more to enter the CD mode.

3 Open the CD door, and insert a CD with the printed side facing up, then press the CD door gently to close.

→ Play starts automatically.

4 To pause playback, press **▶II**.

→ Display: **▶** flashes. (See [3](#))

5 To resume, press **▶II** again.

6 To stop playback, press **■**.

Helpful hints:

CD play will also stop when:

- you open the CD door;
- you select **USB, FM, MW** or **OFF**;
- the CD has reached the end.

MP3/WMA/CD Player

Selecting a different track

- Press **◀/▶** once or repeatedly until the desired track number appears in the display.
For MP3/WMA-CD: First press **ALB +/-** once or more to select your album.
- In the pause/stop position, press **▶/II** to start playback.

Finding a passage within a track

- 1 During playback, press and hold **◀◀** or **▶▶**.
→ The CD is played at high speed and with reduced volume.
- 2 When you recognize the passage you want, release **◀◀** or **▶▶** to resume normal playback.

Helpful hints:

- When your searching reaches the end of the last track, the CD goes to stop mode.

Programming track numbers

You may store up to 40 tracks in the desired sequence. If you like, store any track more than once.

- 1 In the stop position, press **PROG** to activate programming.
→ Display: **PROG** and **PO 1** flash. (See **4**)
- 2 Press **◀◀** or **▶▶** to select your desired track number.
For MP3/WMA-CD: first press **ALB +/-** once or more to select your album.
- 3 Press **PROG** to store the desired track number.
→ Display: **PROG** and **PO 2** flash for you to program the next track.
- 4 Repeat steps **2** to **3** to select and store all desired tracks in this way.
→ If you attempt to store more than 40 tracks, no track can be selected and the display shows **FUL**.
- 5 To play your program, press **▶/II**

Helpful hints :

- When playback of your program comes to the stop position, your set will return to normal playback. To re-enter program mode, press **PROG** in the stop position.

Reviewing the program

In the stop position, press **PROG** to see the total number of stored tracks.

Erasing a program

You can erase the contents of the memory by:

- pressing **■** twice.
- selecting **USB, FM, MW** or **OFF**;
- opening the CD door;

Different play modes: REPEAT and SHUFFLE (See **5**, **6**)

You can select and change the various play modes before or during playback, and combine REPEAT modes with **PROG** (PROGRAM).

↻ – plays the current track continuously.

For MP3:

↻ **ALB** – plays all tracks of current album repeatedly.

↻ **ALL** – repeats the entire CD/program.



∞ – plays all tracks in random order.

∞ ↻ **ALL** – plays all tracks repeatedly in random order.





- 1 To select play mode, press **MODE** once or more.
→ The display shows the related icon.
- 2 Press **▶/II** to start playback if in the stop/pause position.
→ Playback will automatically start if you select **SHUFFLE** mode.
- 3 To return to normal playback, press **MODE** repeatedly until the modes are no longer displayed.
– You can also press **■** to cancel your play mode.

CD Ripping

This function enables you to record music to a connected USB device from the CD sound source without interrupting your enjoyment of the music.

- 1 Insert a USB device with sufficient free space to the set's USB port marked  .
- 2 Select the CD source and then load a CD onto the set.
- 3 Select a track where ripping will start.
- 4 Press **USB REC** to start ripping.
→ "ONE" appears and **•REC** flashes.
 - In the CD mode, to record all tracks starting from the one you selected, press **USB REC** again.
→ "ALL" appears and **•REC ALL** flashes.
- 5 At any moment, simply press  to stop ripping.

To delete a track from your USB device

- 1 Adjust the **source selector** to **CD/USB**
- 2 Press **CD/USB** once or more to enter the USB mode
- 3 Plug in the USB device.
- 4 (In the STOP position) Press  or  to select the track to be deleted.
- 5 Press and hold  on the system for more than 2 seconds.
→ "DEL" starts flashing on the display panel.
- 6 Press  to confirm the deletion.

Using USB connectivity

- AZ1845 is fitted with a USB port in the front panel, offering a plug and play feature which allows you to play, from your AZ1845, digital music and spoken contents stored on a USB mass storage device.
- Using a USB mass storage device, you can also enjoy all the features offered by AZ1845 which are explained and instructed in the sections of disc operation.

Compatible USB mass storage devices

With the AZ1845, you can use

- USB flash memory (USB 2.0 or USB 1.1)
- USB flash player (USB 2.0 or USB 1.1)
- USB device which requires driver installation under Windows XP is not supported.

Note:

In some USB flash players (or memory devices), the stored contents are recorded using copyright protection technology. Such protected contents will be unplayable on any other devices (such as AZ1845 device).

Supported formats:


- USB or memory file format FAT12, FAT16, FAT32 (sector size: 512 - 65,536 bytes)
- MP3 bit rate (data rate): 32-320 kbps and variable bit rate
- WMA v9 or earlier
- Directory nesting up to a maximum of 8 levels
- Number of albums: maximum 99
- Number of tracks: maximum 999
- ID3 tag v2.0 or later
- File name in Uicode UTF8 (maximum length: 128 bytes)

USB Connection

The system will not play or support the following:

- Empty albums: an empty album is an album that does not contain MP3/WMA files, and will not be shown in the display.
- Non-supported file formats are skipped. This means that e.g.: Word documents .doc or MP3 files with extension. dlf are ignored and will not be played.
- AAC, WAV, PCM. NTFS audio files
- DRM protected WMA files
- WMA files in Lossless format

Playing a USB mass storage device

- 1 Make sure that your AZ1845 is being powered by AC mains or specified batteries.
 - 2 Adjust the **source selector** to **CD/USB**.
 - 3 Press **CD/USB** once or more to enter the USB mode.
 - 4 Plug a compatible USB mass storage device to AZ1845's USB port marked . If needed, use a suitable USB cable to connect between the device and AZ1845's USB port.
 - The device will automatically power on.
- If the device is not powered on, turn on the power manually, then re-connect it.
 - AZ1845's display shows USB and then the total number of playable audio files (Max. displayed track number is 999) stored on the device.
 - Play starts automatically.

Helpful hints:

- Up to 999 playable audio files stored on a USB mass storage device can be played on AZ1845.
- Up to 99 playable albums stored on a USB mass storage device can be selected and displayed on AZ1845.
- Make sure that file names of MP3 files end with .mp3. and the file names of WMA files end with .wma.
- For DRM protected WMA files, use Windows Media Player 10 (or later) for conversion. Visit www.microsoft.com for details about Windows Media Player and WM DRM (Windows Media Digital Rights Management).
- For USB device playing, if the display shows "OL", it means that the USB device is electrically overloading AZ1845. You need to change a USB device.

CD player and CD handling

- If the CD player cannot read CDs correctly, use a cleaning CD to clean the lens before taking the set to repair.
- The lens of the CD player should never be touched!
- Sudden changes in the surrounding temperature can cause condensation on the lens of your CD player. Playing a CD is then not possible. Do not attempt to clean the lens but leave the set in a warm environment until the moisture evaporates.
- Always close the CD door to avoid dust on the lens.
- To clean the CD, wipe in a straight line from the center towards the edge using a soft, lint-free cloth. Do not use cleaning agents as they may damage the disc.
- Never write on a CD or attach any stickers to it.

Safety information

- Place the set on a flat, hard and stable surface so that the system does not tilt.
- Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Do not expose the set, batteries, CDs to humidity, rain, sand or excessive heat caused by heating equipment or direct sunlight.
- The apparatus shall not be exposed to dripping or splashing.
- Adequate ventilation with a minimum gap of 15cm (6 inches) between the ventilation holes and surrounding surfaces is necessary to prevent heat build-up.
- Do not cover the ventilation openings with items such as newspapers, table-cloths, curtains, etc.
- No objects filled with liquids, such as vases, shall be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.
- To clean the set, use a dry cloth. Do not use any cleaning agents containing alcohol, ammonia, benzene or abrasives as these may harm the housing.
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Troubleshooting

If a fault occurs, first check the points listed below before taking the set for repair.

If you are unable to remedy a problem by following these hints, consult your dealer or service centre.

WARNING: *Do not open the set as there is a risk of electric shock. Under no circumstances should you try to repair the set yourself, as this will invalidate the guarantee.*

Problem

- Possible cause
- Remedy

No sound /power

- Volume not adjusted
- Adjust the VOLUME
- Power cord not securely connected
- Connect the AC power cord properly
- Batteries dead/ incorrectly inserted
- Insert (fresh) batteries correctly
- CD contains non-audio files
- Press ◀▶, ▶▶ once or more to skip to a CD audio track, instead of the data file.

Display does not function properly / No reaction to operation of any of the controls

- Electrostatic discharge
- Switch off and unplug the set. Reconnect after a few seconds

---, Er or no indication

- No CD inserted
- Insert a CD
- CD badly scratched or dirty
- Replace/ clean CD, see **Maintenance**
- Laser lens steamed up
- Wait until lens has cleared
- CD-R/CD-RW is blank or not finalized
- Use a finalized CD-R/CD-RW or suitable CD Audio disc only

Note:

Make sure the CD is not encoded with copy-right protection technologies, as some do not conform to the Compact Disc standard.

The CD skips tracks

- CD damaged or dirty
- Replace or clean CD
- Program/shuffle is active
- Quit program/shuffle mode

Note: A CD badly scratch or dirty may result in improper operation.

Sound skips during MP3 playback

- MP3 file made at compression level exceeding 320kbps
- Use a lower compression level to record CD tracks into MP3 format
- Disc damaged or dirty
- Replace or clean disc

The USB device doesn't play on my AZ1845

- It is not set in the USB mode.
- Select the **USB** mode.
- The device is not securely connected to AZ1845's USB port.
- Re-connect the device, and make sure that the device is powered on.
- The device is not supported by AZ1845, or the audio file format stored on the device is not supported by AZ1845.
- Use a compatible device/ playable audio file format.

INFORMATION REGARDING USB DIRECT:

1. Compatibility of the USB connection on this product:
 - a) This product supports most USB Mass storage devices (MSD) that these devices are compliant to the USB MSD standards.
 - i) Most common Mass storage class devices are flash drives, memory sticks, jump drives and etc.
 - ii) If you see a "Disc Drive" showing up on your computer after you have plugged the mass storage device into your computer, most likely it is MSD compliant and it will work with this product.
 - b) If your Mass storage device requires a battery/power source, please make sure you have a fresh battery in it or charge the USB device first and then plug it into this product again.
2. Supported Music type:
 - a) This device only supports unprotected music with file extension: .mp3 .wma
 - b) Music bought from on-line music stores are not supported because they are secured by Digital Rights Management protection (DRM).
 - c) File name extensions that ended with the following are not supported: .wav; .m4a; .m4p; .mp4; .aac and etc.
3. No Direct connection can be made from a Computer USB port to this product even you have either or both mp3 or wma file in your computer.

Environmental information

All unnecessary packaging material has been omitted. The packaging can be easily separated into three materials: cardboard, polystyrene and plastic.

Your set consists of materials which can be recycled if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging, dead batteries and old equipment.

Specifications

Power consumption.....	15W
Total output power.....	2 x 1W RMS
Dimensions (L x W x H).....	420 x 240 x 168 (mm)
Weight.....	2.8 kg

Hearing Safety

Listen at a moderate volume:

- Using headphones at a high volume can impair your hearing. This product can produce sounds in decibel ranges that may cause hearing loss for a normal person, even for exposure less than a minute. The higher decibel ranges are offered for those that may have already experienced some hearing loss.
- Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So after prolonged listening, what sounds "normal" can actually be loud and harmful to your hearing. To guard against this, set your volume to a safe level before your hearing adapts and leave it there.

To establish a safe volume level:

- Set your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

Listen for reasonable periods of time:

- Prolonged exposure to sound, even at normally "safe" levels, can also cause hearing loss.
- Be sure to use your equipment reasonably and take appropriate breaks.

Be sure to observe the following guidelines when using your headphones:

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations.
- Do not use headphones while operating a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>