#### **FCC STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

At Playskool, we want to do all we can to help ensure that children thrive developmentally. That's why we have partnered with the National Campaign for Hearing Health to provide you with this Hearing Checklist for babies.

### Your Baby's Hearing Checkli

Provided by National Campaign for Hearing Health 1050 17th Street NW, Suite 701

Birth to 3 Months

Washington, DC 20036

YES



Talk to your doctor if you answer NO to any of these questions:

		Reacts to loud sounds Is soothed by your voice Turns head to you when you speak Seems to know your voice and quiets down if cryi
YES	NO	3 to 6 Months
		Looks upward or turns toward a new sound
		Responds to "no" and changes in tone of voice
		Enjoys rattles and other toys that make sounds
		Becomes scared by a loud voice

The National Campaign for Hearing Health is sponsored by the Deafness Research Foundation. It is a public outreach, professional education and government relations initiative whose goal is to educate the public about hearing health.

Call the National Campaign for Hearing Health at 1.800.535.3323 or visit www.hearinghealth.net for more information.

Based on NIDCD/NIH infant hearing checklist.









# Busy™ Ball Popper

Thank you for buying this PLAYSKOOL product!

Requires 4 x I.5V "D"/LR20 alkaline batteries. Phillips/cross head screwdriver (not included) required for battery installation.

**Adult Assembly Required.** 



© 2003 Hasbro. All Rights Reserved. ® denotes Reg. U.S. Pat. & TM Office. 06104 P/N 6174170100

# TO ASSEMBLE I. Snap track onto base. 2. Snap bowl onto tube (tab into slot). BOWL TRACK BASE


# TO PLAY

# The BUSY Ball Popper toy features air-powered poppin', droppin' fun!

- I. Slide ON/OFF switch on rear side of toy to ON. Press the plunger to start the music and air power. Drop the balls on the track or down the tube and watch as they pop out of the top, roll down the track, then pop out all over again! Sometimes the balls spill over for even more put-and-take play.
- 2. Each time you press the plunger the toy activates for approximately 30 seconds, and a different song plays!
  - 8 lively songs!
  - Fun sound effects!
  - Includes 5 colorful balls to the start the ball-droppin' fun!




Note: When storing toy, turn the ON/OFF switch to OFF to prevent accidental activation.



## TO INSTALL BATTERIES

Use a Phillips/cross head screwdriver to loosen screw in battery compartment door (screw remains attached to door). Slide door to the right and remove. Insert 4 fresh "D"/LR20 (I.5V) alkaline batteries. Fit door onto unit (tabs into notches), then slide door to the left. Tighten screw.



# CAUTION: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- 3) Always remove weak or dead batteries from the product.

# IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.

# **CAUTION:**

- 1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and polarity markings.
- 2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
- 3. Remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is not to be played with for a long time.
- 5. Do not short circuit the supply terminals.
- Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- 7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com