

FCC Information

English

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

In accordance with FCC requirements, changes or modifications not expressly approved by Thomson Inc. could void the user's authority to operate this product.

This device generates and uses radio frequency (RF) energy, and if not installed and used properly, this equipment may cause interference to radio and television reception. If this equipment does cause interference to radio or television reception (which you can determine by turning the equipment off and on), try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna (that is, the antenna for the radio or television that is "receiving" the interference).
- Move the unit away from the equipment that is receiving interference.
- Plug the unit into a different wall outlet so that the unit and the equipment receiving interference are on different branch circuits.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions.

Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, DC 20402. Please specify stock number 004-000-00345-4 when ordering copies.

This product complies with DHH5 Rules 21 CFR Subchapter J. Applicable at the date of manufacture.

For Your Safety

The AC power plug is polarized (one blade is wider than the other) and only fits into AC power outlets one way. If the plug won't go into the outlet completely, turn the plug over and try to insert it the other way. If it still won't fit, contact a qualified electrician to change the outlet, or use a different one. **Do not attempt to bypass this safety feature.**

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

Safety Information

Technical Information

Product: Portable CD Radio
Brand: RCA
Model: RCD039

Electrical Consumption

Power Supply: 120V - 60Hz
Power Consumption: 15 Watts

IMPORTER
Comercializadora Thomson de México, S.A. de C.V.
Álvaro Obregón No. 151, Piso 13.
Col. Roma, Delegación Cuauhtémoc
C.P. 06700, México, D.F.
Telefono: 52-55-11-020360
RFC: CTM-980723-K55

For Your Records

In the event that service should be required, you may need the model number. In the space below, record the date and place of purchase:

Model No.
Date of Purchase
Place of Purchase

Service Information

This product should be serviced only by those specially trained in appropriate servicing techniques. For instructions on how to obtain service, refer to the warranty included in this Guide.




WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

Important Information

Safety Precautions

- Never open the cabinet under any circumstances. Any repairs or internal adjustments should be made only by a trained technician.
- Never operate this product with the cabinet removed.
- Do not use your System immediately after transporting it from a cold place to a warm place, as condensation may cause the system to malfunction.
- Keep your unit away from humid areas and abnormally hot places.
- Do not touch the player with wet hands. If any liquid enters the player cabinet, take the player to a trained technician for inspection.
- This compact disc player uses a laser to read the music on the disc. The laser mechanism corresponds to the cartridge and stylus of a record player. Although this product incorporates a laser pick-up lens, it is completely safe when operated according to directions.

Minimum distances around the apparatus for sufficient ventilation.



- The ventilation should not be impeded by covering the ventilation opening with items, such as newspaper, table-cloths, curtains, etc.
- The rating plate is located at the bottom cabinet of apparatus.

Headset Safety

- Do not play your headset at high volume. Hearing experts warn against extended high-volume play.
- If you experience ringing in your ears, reduce volume or discontinue use.
- You should use with extreme caution or temporarily discontinue use in potentially hazardous situations.
- Even if your headset is an open-air designed to let you to hear outside sounds, do not turn up the volume so high that you are unable to hear what is around you.

Don't Infringe


- This product should only be used for the purposes for which it is sold, that is, entertainment, violating no copyright law. Any attempts to use this product for unintended purposes are unlawful and therefore not condoned by Thomson.

IMPORTADOR
Comercializadora Thomson de México, S.A. de C.V.
Álvaro Obregón No. 151, Piso 13.
Col. Roma, Delegación Cuauhtémoc
C.P. 06700, México, D.F.
Telefono: 52-55-11-020360
RFC: CTM-980723-K55

EXPORTER
Thomson Inc.
P.O. Box 1976
Indianapolis, IN 46206 - 1976
©2006 Thomson Inc.
Trademark(s) © Registered
Marque(s) © Déposé(s)
www.rca.com
Printed in China / Impreso en China
5643 1940 (EN/F/E)

user manual
guide de l'utilisateur
manual de usuario

RCD039



EN/F/E
It is important to read this instruction book prior to using your new product for the first time. Nous vous recommandons de lire ce manuel d'instructions avant d'utiliser votre nouveau produit pour la première fois. Es importante leer este manual antes de usar por vez primera su equipo.

Before You Begin

Useful Advice

- Do not use your system immediately after transporting it from a cold place to a warm place, as condensation may cause the system to malfunction. If moisture forms inside this system, it may not operate properly. To correct the problem, turn off the power and wait about 30 minutes for moisture to evaporate.
- This system is fitted with a laser. To avoid accidents, it is to be opened by qualified technicians only.
- Never leave the tray open as dust could cover the laser lens and/or the tray could be bumped into accidentally.
- Do not place the system near wet areas such as bathrooms and pool side. Avoid storing the system at humid places or near abnormally heated areas.
- Power is continuously supplied to the system. To disconnect power completely, unplug the power cord from the power outlet.
- Ensure minimum distance around the apparatus for sufficient ventilation. The ventilation should not be impeded by covering the ventilation openings with items, such as newspaper, etc.
- No naked flame source, such as lighted candles, should be placed on the apparatus.
- Attention should be paid to environmental aspects of battery disposal.

AC Power

Plug the power supply cord into the AC power jack on the back of the unit, and into an AC power supply outlet that accepts the plug supplied with your unit.

Battery Power

You can insert 6 C-sized alkaline batteries (not supplied) and you can take your stereo just about anywhere.

- Open the battery compartment door on the bottom of the unit by pressing down on the tab and pulling out the cover.
- Before inserting the batteries, observe the polarities (that is, + and -) of the battery, then relate the polarities to the engraved diagram located on the battery compartment door. Insert batteries in the battery compartment.

Note that the AC line cord must be unplugged from the jack on the back of the unit to operate on batteries.

Important Battery Information

- Remove the batteries to avoid leakage if you do not use your system for more than one month.
- Discard leaky batteries immediately as leaking batteries may cause skin burns or other personal injuries. Dispose of batteries in the proper manner, according to provincial and local regulations.
- Any battery may leak electrolyte under the following circumstances:
 - if mixed with a different battery type,
 - if inserted incorrectly,
 - if all batteries are not replaced at the same time,
 - if disposed of in fire, or
 - if an attempt is made to charge a battery not intended to be recharged
- Be sure to remove batteries when storing the set for more than 30 days. Leaky batteries can badly damage the system. Be sure to dispose of leaky, weak or dead batteries properly according to federal, state, and local regulations. To prevent injury or damage, do not reverse batteries and do not mix battery type.

General Controls

Top View

BAND AM/FM - Selects AM or FM band.

TUNING - Selects radio frequency.

SELECTION () / CD / RADIO / OFF - Selects operation mode. To switch off the unit, select **OFF**.


PROGRAM - Enters CD program mode.

MODE - Selects playback modes.

BASS - Turns bass boost on and off.

VOL. - Adjusts volume.

PUSH TO OPEN - Push to open the mp3 device storage compartment door. Push the door to close it.



Front View

◀▶ - In CD mode - goes back to the previous track or searches backward.

▶▶ - Starts and pauses playback.

▶▶▶ - In CD modes - goes to the next track or searches forward.

□ - In CD modes - stops playback.

PUSH TO OPEN - Opens disc tray. Push the disc tray to close it.


Back View

AC - IN - Insert the power cord here.


Antenna - Extend the antenna for better radio reception.

Bottom View

OPEN - Push and slide to lift up the battery compartment door.



Display



- Program mode is activated.
- Repeat mode is activated.
- Shuffle mode is activated.
- Playback in progress.
- Displays CD track information.
- AUX mode is selected for connecting with mp3 player.

Sound Feature

Bass Boost System

Press **BASS** to turn the digital bass boost system on and off.

Cleaning the exterior

- Disconnect the system from AC power before cleaning the exterior of the unit with a soft dust cloth.
- Clean the exterior with a soft clean cloth or slightly moistened chamois leather. DO NOT use solvents as it may cause damage to the unit.

Handling CDs

- Do not touch the signal surfaces. Hold CDs by the edges, or by one edge and the hole.
- Do not affix labels or adhesive tapes to the label surfaces. Do not scratch or damage the label.
- CDs rotate at high speeds inside the player. Do not use damaged (cracked or warped) CDs.
- Make sure CDs are stored in their original case after use. Keep them away from damp, humid or abnormally heated places.

Cleaning CDs

- Dirty CDs can cause poor sound quality. Always keep CDs clean by wiping them gently with a soft cloth from the inner edge toward the outer perimeter.

The descriptions and characteristics in this owner's manual are for the purpose of general reference only and not as a guarantee. In order to provide you with the highest quality product, we may make changes or modifications without prior notice. The English version serves as the final reference on all product and operational details should any discrepancies arise in other languages.

CD Playback

Creating Programs

The unit can program up to 20 normal audio CD tracks.

In program mode, **RANDOM** playback cannot be selected.

Deleting Programs

Press **□** in CD stop mode to delete all the stored tracks.

Opening the CD compartment door or switching mode will delete all the stored tracks.

The unit remains in program mode once programming track is done.

Displaying and Editing Programs

- Press **PROGRAM** repeatedly to recall and display program. Program position shows first, followed by track number.
- While track number is displayed, press **◀▶** or **▶▶** to edit track number. Press **PROGRAM** to store newly selected track.

Deleting Programs

Press **□** in CD stop mode to delete all the stored tracks.

Opening the CD compartment door or switching mode will delete all the stored tracks.

The unit remains in program mode once programming track is done.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>