

TECHNICAL & SERVICE MANUAL



KS3082 + C3082
KS3682 + C3682

FILE NO.


Destination: North America

DC INVERTER SPLIT SYSTEM AIR CONDITIONER

| Indoor Model No. | Product Code No. |
|------------------|------------------|
| KS3082 | 1 852 354 30 |
| KS3682 | 1 852 354 31 |


| Outdoor Model No. | Product Code No. |
|-------------------|------------------|
| C3082 | 1 852 354 34 |
| C3682 | 1 852 354 35 |

Indoor Unit



KS3082
KS3682

Outdoor Unit



C3082
C3682

IMPORTANT









These air conditioners employ new refrigerant R410A.















Pay special attention when servicing the unit.









R410A

REFERENCE NO. SM700859

SAFETY PRECAUTIONS

- Before doing repair work, please read the " SAFETY PRECAUTIONS" carefully and fully understand them.
- The precautionary items here are divided into " Warning" and " Caution" items.
Items in particular which may cause death or serious injury to the service personnel if the work is not performed correctly, are included in the " Warning" table.
However, even precautionary items identified as " Caution" also have the potential for serious consequences if not performed correctly.
Important safety precautions are described for all items in both categories. Be sure to carefully follow all of them.
- Symbol Indication
 -  : This symbol indicates items to which we need to pay attention.
In this triangle, a definite precautionary item is described.
 -  : This symbol indicates the item to be prohibited.
In or close to this circle, a prohibited item is described.
 -  : This symbol indicates the items requiring special attention or instruction.
In or close to this circle, a prohibited item is described.
- After doing repair work, perform a test run to confirm that there are no abnormalities.
At the same time, explain the precautions in use to the user.

|  Warning | |
|--|---|
| Before performing an overhaul, disconnect the power plug or power cable from the unit. Performing the work with the power supplied to the unit, may cause an electric shock. |  |
| When repair work or circuit inspection that requires power supply for the air conditioner, is to be performed, do not touch the charging section. Doing so may cause an electric shock. |  Prohibit |
| For the step-up capacitor attached to the electric section, perform the repair work after sufficiently discharging it. Insufficient capacitor discharge may cause an electric shock. |  |
| Do not perform repair work on the electric sections with wet hands. Doing so may cause an electric shock. |  Prohibit |
| Do not start or stop the air conditioner by means of connecting or disconnecting the power plug. Doing so may cause an electric shock or fire. |  Prohibit |
| When conducting repair work only use components included in the parts list for the corresponding unit and perform the work with the appropriate tools. Incorrect or poor repair work may cause an electric shock or fire. |  |
| Never modify the unit. Doing so may cause an electric shock or fire. |  Prohibit |
| Perform all electric work according to local applicable regulations related to electrical equipment or interior wiring regulation and make sure to use the exclusive circuit. Insufficient capacity to the electric circuit or defective arrangement results may cause an electric shock or fire. |  |
| Make sure to replace any power cable or lead wire showing any signs of scratch or deterioration. Failure to do so may cause an electric shock, overheating or fire. |  |
| Make sure that there is no dust on or slack in the power plug and insert fully into the socket. Dust or incomplete connections may cause an electric shock or fire. |  |
| Do not damage or process the power cord, as it may cause an electric shock or fire. |  Prohibit |
| For the wiring between the indoor unit and outdoor unit, securely fix the specified cable onto the terminal plate. Poorly fixed wiring may cause a heat or fire. |  |
| After connecting the wiring between the indoor unit and outdoor unit, attach the terminal cover securely. Incomplete attachment of the terminal cover may cause overheating or fire. |  |

|  Warning | |
|--|---|
| If refrigerant gas blows off during the work, do not touch the refrigerant gas as it may cause frostbite. |  Prohibit |
| If refrigerant gas leaks during the work, ventilate the room. If refrigerant gas catches fire, harmful gas may be generated. |  |
| Do not mix any gas other than the specified refrigerant gas in the refrigerating cycle. If air or other contaminants mix with the gas, pressure will become extremely high in the refrigerating cycle, which may cause a unit breakdown." |  Prohibit |
| When the welded section of the compressor intake or discharge pipe is to be disconnected, perform it in a well-ventilated place after sufficiently recovering the refrigerant gas. Any residue gas may jet out refrigerant or refrigerating machine oil, which may cause an injury. |  |
| When the work is to be performed in a high place (About 2 meters or more), make sure to wear a safety helmet, gloves and safety belt. Insufficient safety gear may cause a serious injury in case of a fall. |  |
| When the unit is to be relocated, confirm that the new installation location has sufficient strength for the weight of the unit. Insufficient strength of the installation location and incomplete installation work may cause an injury due to the unit falling. |  |
| When the remote controller batteries are replaced, dispose of the old batteries out of the reach of children. If a child swallows a battery, make sure that the child gets immediate medical attention. |  |













|  Caution | |
|--|---|
| Do not wash the air conditioner with water, as this may cause an electric shock or fire. |  Prohibit |
| For the repair work in places with high humidity or moisture, make sure to ground the unit. Failure to do so may cause an electric shock. |  |
| Confirm that the component attachment position, wiring condition, soldering condition and connector connection are normal. If not, it may cause overheating or fire. |  |
| Confirm that the temperature around the compressor is not too high, and then perform the repair work. Failure to do so may cause a burn. |  |
| Perform welding work in a place with good ventilation. If the work is performed in a poorly ventilated area, it might cause a lack of oxygen. |  |
| If the installation plate or attachment frame has deteriorated due to corrosion, etc., replace it. Failure to do so may cause an injury due to the unit falling. |  |
| When the cleaning is to be performed, make sure to turn off the power and pull out the plug. Touching the fan that is rotating at high speed may result in an injury. |  |
| When the indoor unit is to be removed, do not place it on an incline. Doing so may cause wet furniture because water left inside may trickle down. |  Prohibit |
| Do not hold the sharp end of the unit or the aluminum fins, as it may cause an injury to your hand or finger. |  Prohibit |
| After repairs, make sure to measure the insulation resistance and confirm that the value is 1 Mohm or more. Any insulation error may cause an electric shock. |  |
| After repairs, make sure to check the drainage of the indoor unit. Inappropriate drainage may cause wet furniture and floors due to water leakage. |  |

Table of Contents

| | Page |
|---|------|
| ⚠ SAFETY PRECAUTIONS | 2 |
| TABLE OF CONTENTS | 4 |
| 1. OPERATING RANGE | 6 |
| 2. SPECIFICATIONS | |
| 2-1. Unit Specifications | 7 |
| 2-2. Major Component Specifications | 11 |
| 2-3. Other Component Specifications | 15 |
| 3. DIMENSIONAL DATA | 16 |
| 4. REFRIGERANT FLOW DIAGRAM | |
| 4-1. Refrigerant Flow Diagram | 18 |
| 5. PERFORMANCE DATA | |
| 5-1. Temperature Charts | 19 |
| 5-2. Cooling Capacity | 21 |
| 5-3. Air Throw Distance Charts | 25 |
| 6. ELECTRICAL DATA | |
| 6-1. Electrical Characteristics | 27 |
| 6-2. Electric Wiring Diagrams | 29 |
| 7. FUNCTIONS | |
| 7-1. Operation Functions | 31 |
| 7-2. Protective Functions | 35 |
| 8. TROUBLESHOOTING | |
| 8-1. Precautions before Performing Inspection or Repair | 36 |
| 8-2. Method of Self-Diagnostics | 36 |
| 8-3. Checking the Indoor and Outdoor Units | 39 |
| 8-4. Trouble Diagnosis of Fan Motor | 43 |
| 8-5. Noise Malfunction and Electromagnetic Interference | 45 |

9. CHECKING ELECTRICAL COMPONENTS

| | |
|---|----|
| 9-1. Measurement of Insulation Resistance | 46 |
| 9-2. Checking Continuity of Fuse on PCB Ass'y | 47 |

10. REFRIGERANT R410A:

SPECIAL PRECAUTIONS WHEN SERVICING UNIT

| | |
|--|----|
| 10-1. Characteristics of New Refrigerant R410A | 48 |
| 10-2. Checklist before Servicing | 49 |
| 10-3. Tools Specifically for R410A | 50 |
| 10-4. Tubing Installation Procedures | 50 |
| 10-5. In Case of Compressor Malfunction | 51 |
| 10-6. In Case Refrigerant is Leaking | 53 |
| 10-7. Charging Additional Refrigerant | 54 |
| 10-8. Retro-Fitting Existing Systems | 54 |

| | |
|--|-----|
| APPENDIX A INSTRUCTION MANUAL | A-1 |
|--|-----|

| | |
|--|-----|
| APPENDIX B INSTALLAION INSTRUCTIONS | A-2 |
|--|-----|

1. OPERATING RANGE

| | Temperature | Indoor Air Intake Temp. | Outdoor Air Intake Temp. |
|---------|--------------------|--------------------------------|---------------------------------|
| Cooling | Maximum | 95 °F D.B. / 71 °F W.B. | 115 °F D.B. |
| | Minimum | 67 °F D.B. / 57 °F W.B. | 0 °F D.B. |

2. SPECIFICATIONS

2-1. Unit Specifications

Indoor Unit **KS3082**

Outdoor Unit **C3082**

< 230V >

| Voltage Rating | | 230V Single-Phase 60Hz | |
|------------------------------------|--|--|---|
| Performance | | | Cooling |
| | Total Capacity | BTU/h | 30,600 (10,900 to 30,600) |
| | | kW | 9.0 (3.2 to 9.0) |
| | Sensible Capacity | BTU/h | 18,600 |
| | Latent Capacity | BTU/h | 12,000 |
| | Air Circulation (High) | ft ³ /min (m ³ /h) | 630 (1,070) |
| | Moisture Removal (High) | Pints/h | 9.57 |
| Electrical Rating | Available Voltage Range | V | 187 to 253 |
| | Running Amperes | A | 16.5 (5.0 to 16.5) |
| | Power Input | W | 3,290 (1,000 to 3,290) |
| | Power Factor | % | 87 |
| | EER | BTU/h/W | 9.30 |
| | SEER | BTU/Wh | 16.0 |
| | Compressor Locked Rotor Amperes | A | 31.0 |
| | Fuse or Circuit Breaker Capacity | A | 35 |
| Features | Controls / Temperature Control | | Microprocessor / I.C. Thermister |
| | Control Unit | | Wireless Remote Control Unit |
| | Timer | | 24-Hour ON or OFF Timer, 1-Hour OFF Timer |
| | Fan Speeds | Indoor / Outdoor | Auto and 3 steps / Auto (Hi, Me, Lo) |
| | Airflow Direction (Indoor) | Horizontal | Manual |
| | | Vertical | Auto |
| | Air Filter | | Washable, Anti-Mold |
| | Compressor | | DC Twin Rotary (Inverter) |
| | Refrigerant / Amount charged at shipment | lbs (g) | R410A / 6.5 (2,950) |
| | Refrigerant Control | | Electric Expansion Valve |
| | Operation Sound | Indoor : Hi/Me/Lo/Qt* dB-A | 49 / 44 / 39 / 32 |
| | (*Qt = Quiet mode) | Outdoor : Hi dB-A | 55 |
| | Refrigerant Tubing Connections | | Flare Type |
| | Max. allowable tubing length at shipment | ft (m) | 164 (50) |
| Refrigerant | Narrow tube inch (mm) | 3/8 (9.52) | |
| Tube Diameter | Wide tube inch (mm) | 5/8 (15.88) | |
| Refrigerant Tube Kit / Accessories | | Optional / Air Clean Filter | |
| Dimensions & Weight | | | Indoor Unit |
| | | | Outdoor Unit |
| | Unit Dimensions | inch | 11-13/16 × 41-15/16 × 9-1/16 |
| | Height × Width × Depth | (mm) | (300 × 1,065 × 230) |
| | Package Dimensions | inch | 12-7/32 × 44-7/8 × 14-31/32 |
| | Height × Width × Depth | (mm) | (310 × 1,140 × 380) |
| Weight | Net | lbs (kg) | 32.0 (14.5) |
| | Shipping | lbs (kg) | 39.7 (18.0) |
| Shipping Volume | | cu.ft (m ³) | 4.59 (0.13) |
| | | | 15.88 (0.45) |

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are:

Cooling: Indoor air temperature 80°F D.B. / 67°F W.B.

Outdoor air temperature 95°F D.B. / 75°F W.B.

Indoor Unit **KS3082**
 Outdoor Unit **C3082**

< 208V >

| Voltage Rating | | 208V Single-Phase 60Hz | |
|------------------------------------|--|--|---|
| Performance | | | Cooling |
| | Total Capacity | BTU/h | 30,600 (10,900 to 30,600) |
| | | kW | 9.0 (3.2 to 9.0) |
| | Sensible Capacity | BTU/h | 18,600 |
| | Latent Capacity | BTU/h | 12,000 |
| | Air Circulation (High) | ft ³ /min (m ³ /h) | 630 (1,070) |
| | Moisture Removal (High) | Pints/h | 9.57 |
| Electrical Rating | Available Voltage Range | V | 187 to 253 |
| | Running Amperes | A | 18.0 (5.0 to 18.0) |
| | Power Input | W | 3,290 (1,000 to 3,290) |
| | Power Factor | % | 88 |
| | EER | BTU/h/W | 9.30 |
| | SEER | BTU/Wh | 16.0 |
| | Compressor Locked Rotor Amperes | A | 31.0 |
| | Fuse or Circuit Breaker Capacity | A | 35 |
| Features | Controls / Temperature Control | | Microprocessor / I.C. Thermister |
| | Control Unit | | Wireless Remote Control Unit |
| | Timer | | 24-Hour ON or OFF Timer, 1-Hour OFF Timer |
| | Fan Speeds | Indoor / Outdoor | Auto and 3 steps / Auto (Hi, Me, Lo) |
| | Airflow Direction (Indoor) | Horizontal | Manual |
| | | Vertical | Auto |
| | Air Filter | | Washable, Anti-Mold |
| | Compressor | | DC Twin Rotary (Inverter) |
| | Refrigerant / Amount charged at shipment | lbs (g) | R410A / 6.5 (2,950) |
| | Refrigerant Control | | Electric Expansion Valve |
| | Operation Sound | Indoor : Hi/Me/Lo/Qt* dB-A | 49 / 44 / 39 / 32 |
| | (*Qt = Quiet mode) | Outdoor : Hi dB-A | 55 |
| | Refrigerant Tubing Connections | | Flare Type |
| | Max. allowable tubing length at shipment | ft (m) | 164 (50) |
| | Refrigerant | Narrow tube inch (mm) | 3/8 (9.52) |
| Tube Diameter | Wide tube inch (mm) | 5/8 (15.88) | |
| Refrigerant Tube Kit / Accessories | | Optional / Air Clean Filter | |
| Dimensions & Weight | | | Indoor Unit |
| | | | Outdoor Unit |
| | Unit Dimensions | inch | 11-13/16 × 41-15/16 × 9-1/16 |
| | Height × Width × Depth | (mm) | (300 × 1,065 × 230) |
| | Package Dimensions | inch | 12-7/32 × 44-7/8 × 14-31/32 |
| | Height × Width × Depth | (mm) | (310 × 1,140 × 380) |
| Weight | Net | lbs (kg) | 32.0 (14.5) |
| | Shipping | lbs (kg) | 39.7 (18.0) |
| Shipping Volume | | cu.ft (m ³) | 4.59 (0.13) |
| | | | 15.88 (0.45) |

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are:

Cooling: Indoor air temperature 80°F D.B. / 67°F W.B.

Outdoor air temperature 95°F D.B. / 75°F W.B.

Indoor Unit **KS3682**
 Outdoor Unit **C3682**

< 230V >

| Voltage Rating | | 230V Single-Phase 60Hz | |
|------------------------------------|--|--|---|
| Performance | | | Cooling |
| | Total Capacity | BTU/h | 34,000 (10,900 to 34,000) |
| | | kW | 10.0 (3.2 to 10.0) |
| | Sensible Capacity | BTU/h | 20,700 |
| | Latent Capacity | BTU/h | 13,300 |
| | Air Circulation (High) | ft ³ /min (m ³ /h) | 630 (1,070) |
| | Moisture Removal (High) | Pints/h | 10.64 |
| Electrical Rating | Available Voltage Range | V | 187 to 253 |
| | Running Amperes | A | 20.0 (5.0 to 20.0) |
| | Power Input | W | 4,000 (1,000 to 4,000) |
| | Power Factor | % | 87 |
| | EER | BTU/h/W | 8.50 |
| | SEER | BTU/Wh | 16.0 |
| | Compressor Locked Rotor Amperes | A | 31.0 |
| | Fuse or Circuit Breaker Capacity | A | 45 |
| Features | Controls / Temperature Control | | Microprocessor / I.C. Thermister |
| | Control Unit | | Wireless Remote Control Unit |
| | Timer | | 24-Hour ON or OFF Timer, 1-Hour OFF Timer |
| | Fan Speeds | Indoor / Outdoor | Auto and 3 steps / Auto (Hi, Me, Lo) |
| | Airflow Direction (Indoor) | Horizontal | Manual |
| | | Vertical | Auto |
| | Air Filter | | Washable, Anti-Mold |
| | Compressor | | DC Twin Rotary (Inverter) |
| | Refrigerant / Amount charged at shipment | lbs (g) | R410A / 6.5 (2,950) |
| | Refrigerant Control | | Electric Expansion Valve |
| | Operation Sound | Indoor : Hi/Me/Lo/Qt* dB-A | 49 / 44 / 39 / 32 |
| | (*Qt = Quiet mode) | Outdoor : Hi dB-A | 55 |
| | Refrigerant Tubing Connections | | Flare Type |
| | Max. allowable tubing length at shipment | ft (m) | 164 (50) |
| Refrigerant | Narrow tube inch (mm) | 3/8 (9.52) | |
| Tube Diameter | Wide tube inch (mm) | 5/8 (15.88) | |
| Refrigerant Tube Kit / Accessories | | Optional / Air Clean Filter | |
| Dimensions & Weight | | | Indoor Unit |
| | | | Outdoor Unit |
| | Unit Dimensions | inch | 11-13/16 × 41-15/16 × 9-1/16 |
| | Height × Width × Depth | (mm) | (300 × 1,065 × 230) |
| | Package Dimensions | inch | 12-7/32 × 44-7/8 × 14-31/32 |
| | Height × Width × Depth | (mm) | (310 × 1,140 × 380) |
| Weight | Net | lbs (kg) | 32.0 (14.5) |
| | Shipping | lbs (kg) | 39.7 (18.0) |
| Shipping Volume | | cu.ft (m ³) | 4.59 (0.13) |
| | | | 15.88 (0.45) |

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are:

Cooling: Indoor air temperature 80°F D.B. / 67°F W.B.

Outdoor air temperature 95°F D.B. / 75°F W.B.

Indoor Unit **KS3682**
 Outdoor Unit **C3682**

< 208V >

| Voltage Rating | | 208V Single-Phase 60Hz | |
|------------------------------------|--|--|---|
| Performance | | | Cooling |
| | Total Capacity | BTU/h | 34,000 (10,900 to 34,000) |
| | | kW | 10.0 (3.2 to 10.0) |
| | Sensible Capacity | BTU/h | 20,700 |
| | Latent Capacity | BTU/h | 13,300 |
| | Air Circulation (High) | ft ³ /min (m ³ /h) | 630 (1,070) |
| | Moisture Removal (High) | Pints/h | 10.64 |
| Electrical Rating | Available Voltage Range | V | 187 to 253 |
| | Running Amperes | A | 21.9 (5.0 to 21.9) |
| | Power Input | W | 4,000 (1,000 to 4,000) |
| | Power Factor | % | 88 |
| | EER | BTU/h/W | 8.50 |
| | SEER | BTU/Wh | 16.0 |
| | Compressor Locked Rotor Amperes | A | 31.0 |
| | Fuse or Circuit Breaker Capacity | A | 45 |
| Features | Controls / Temperature Control | | Microprocessor / I.C. Thermister |
| | Control Unit | | Wireless Remote Control Unit |
| | Timer | | 24-Hour ON or OFF Timer, 1-Hour OFF Timer |
| | Fan Speeds | Indoor / Outdoor | Auto and 3 steps / Auto (Hi, Me, Lo) |
| | Airflow Direction (Indoor) | Horizontal | Manual |
| | | Vertical | Auto |
| | Air Filter | | Washable, Anti-Mold |
| | Compressor | | DC Twin Rotary (Inverter) |
| | Refrigerant / Amount charged at shipment | lbs (g) | R410A / 6.5 (2,950) |
| | Refrigerant Control | | Electric Expansion Valve |
| | Operation Sound | Indoor : Hi/Me/Lo/Qt* dB-A | 49 / 44 / 39 / 32 |
| | (*Qt = Quiet mode) | Outdoor : Hi dB-A | 55 |
| | Refrigerant Tubing Connections | | Flare Type |
| | Max. allowable tubing length at shipment | ft (m) | 164 (50) |
| Refrigerant | Narrow tube inch (mm) | 3/8 (9.52) | |
| Tube Diameter | Wide tube inch (mm) | 5/8 (15.88) | |
| Refrigerant Tube Kit / Accessories | | Optional / Air Clean Filter | |
| Dimensions & Weight | | | Indoor Unit |
| | | | Outdoor Unit |
| | Unit Dimensions | inch | 11-13/16 × 41-15/16 × 9-1/16 |
| | Height × Width × Depth | (mm) | (300 × 1,065 × 230) |
| | Package Dimensions | inch | 12-7/32 × 44-7/8 × 14-31/32 |
| | Height × Width × Depth | (mm) | (310 × 1,140 × 380) |
| Weight | Net | lbs (kg) | 32.0 (14.5) |
| | Shipping | lbs (kg) | 39.7 (18.0) |
| Shipping Volume | | cu.ft (m ³) | 4.59 (0.13) |
| | | | 15.88 (0.45) |

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are:

Cooling: Indoor air temperature 80°F D.B. / 67°F W.B.

Outdoor air temperature 95°F D.B. / 75°F W.B.

2-2. Major Component Specifications

2-2-1. Indoor Unit

Indoor Unit **KS3082**

| Control PCB | | |
|--|-----------------------------------|------------------------------------|
| Part No. | | CB-KS3082 |
| Controls | | Microprocessor |
| Control Circuit Fuse | | 250V 3A |
| Remote Control Unit | | RCS-8VPULS4U |
| Fan | | |
| Type | | Cross-Flow |
| Q'ty ... Dia. and Length | inch (mm) | 1 ... D3-15/16 / L32-1 (D100/L838) |
| Fan Motor | | |
| Type | | DC Motor |
| Model ... Q'ty | | SIC-39CVL-D847-10 ... 1 |
| No. of Poles | | 8 |
| Rough Measure RPM (Cool) | | 1,370 |
| Nominal Output | W | 47 |
| Coil Resistance (Ambient Temp. 68 °F (20 °C)) | Ohm | - |
| Safety Device | | |
| Type | | Internal Controller |
| Over-Current Protection | | Yes |
| Over-Heat Protection | | Yes |
| Run Capacitor | Micro F | - |
| | VAC | - |
| Flap Motor | | |
| Type | | Stepping Motor |
| Model | | 24BYJ48-1256 |
| Rating | | DC 12V |
| Coil Resistance (Ambient Temp. 77 °F (25 °C)) | Ohm | Each Pair of Terminal : 200 +/- 7% |
| Heat Exchanger Coil | | |
| Coil | | Aluminum Plate Fin / Copper Tube |
| Rows | | 1 and 2 |
| Fins Per inch | | 19.5 |
| Face Area | ft ² (m ²) | 4.55 (0.423) |

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Indoor Unit **KS3682**

| Control PCB | | |
|--|-----------------------------------|------------------------------------|
| Part No. | | CB-KS3682 |
| Controls | | Microprocessor |
| Control Circuit Fuse | | 250V 3A |
| Remote Control Unit | | RCS-8VPULS4U |
| Fan | | |
| Type | | Cross-Flow |
| Q'ty ... Dia. and Length | inch (mm) | 1 ... D3-15/16 / L32-1 (D100/L838) |
| Fan Motor | | |
| Type | | DC Motor |
| Model ... Q'ty | | SIC-39CVL-D847-10 ... 1 |
| No. of Poles | | 8 |
| Rough Measure RPM (Cool) | | 1,370 |
| Nominal Output | W | 47 |
| Coil Resistance (Ambient Temp. 68 °F (20 °C)) | Ohm | - |
| Safety Device | | |
| Type | | Internal Controller |
| Over-Current Protection | | Yes |
| Over-Heat Protection | | Yes |
| Run Capacitor | Micro F | - |
| | VAC | - |
| Flap Motor | | |
| Type | | Stepping Motor |
| Model | | 24BYJ48-1256 |
| Rating | | DC 12V |
| Coil Resistance (Ambient Temp. 77 °F (25 °C)) | Ohm | Each Pair of Terminal : 200 +/- 7% |
| Heat Exchanger Coil | | |
| Coil | | Aluminum Plate Fin / Copper Tube |
| Rows | | 1 and 2 |
| Fins Per inch | | 19.5 |
| Face Area | ft ² (m ²) | 4.55 (0.423) |

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

2-2-2. Outdoor Unit

Outdoor Unit **C3082**

| P.C.Board | | Control P.C.B | Noise Filer P.C.B | H.I.C.Board |
|--------------|--|----------------|-------------------|----------------|
| Part No. | | CR-C3082-F | POW-CH3082-B1 | HIC-CH3072R-C1 |
| Controls | | Microprocessor | - | - |
| Circuit Fuse | | 400V 3.5A | 250V 25A | - |

| Compressor | |
|---|--|
| Type | DC Twin Rotary (Hermetic) |
| Compressor Model / Nominal Output | C-9RVN273H0H / 2,250W |
| Compressor Oil ... Amount | Pints (cc) FV68S ... 2.98 (1,400) |
| Coil Resistance (Ambient Temp. 77 °F (25 °C)) | Ohm T - R : 0.169 T - S : 0.169 R - S : 0.169 |
| Safety Device | |
| CT (Peak current cut-off control) | Yes |
| Compressor Discharge Temp. Control | Yes |
| Operation cut-off control in abnormal ambient Temp. | Yes |
| Overload Relay | Model CS-7L110 |
| | Operation Temp. Open : 230 °F (110 °C), Close : 203 °F (95 °C) |
| Run Capacitor | Micro F - |
| | VAC - |
| Crankcase Heater | 230V 30W |

| Fan | |
|---------------|---------------------------------|
| Type | Propeller |
| Q'ty ... Dia. | inch (mm) 1 ... D19-9/32 (D490) |

| Fan Motor | |
|-------------------------------|-------------------------|
| Type | DC Motor |
| Model ... Q'ty | SIC-71FW-D8120-4A ... 1 |
| No. of Poles | 8 |
| Rough Measure RPM (Cool) | 750 |
| Nominal Output | W 142 |
| Coil Resistance | Ohm - |
| (Ambient Temp. 68 °F (20 °C)) | |
| Safety Device | |
| Type | Internal Controller |
| Over- Current Protection | Yes |
| Over- Heat Protection | Yes |
| Run Capacitor | Micro F - |
| | VAC - |

| Heat Exchanger Coil | |
|---------------------|--|
| Coil | Aluminum Plate Fin / Copper Tube |
| Rows | 2 |
| Fins per inch | 21.2 |
| Face Area | ft ² (m ²) 8.05 (0.748) |

| | |
|-----------------|--------------------------------|
| External Finish | Acrylic baked-on enamel finish |
|-----------------|--------------------------------|

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Outdoor Unit **C3682**

| | | | |
|------------------|----------------|-------------------|----------------|
| P.C.Board | Control P.C.B | Noise Filer P.C.B | H.I.C.Board |
| Part No. | CR-C3682-F | POW-CH3082-B1 | HIC-CH3072R-C1 |
| Controls | Microprocessor | - | - |
| Circuit Fuse | 400V 3.5A | 250V 25A | - |

| | |
|---|--|
| Compressor | |
| Type | DC Twin Rotary (Hermetic) |
| Compressor Model / Nominal Output | C-9RVN273H0H / 2,500W |
| Compressor Oil ... Amount | Pints (cc) FV68S ... 2.98 (1,400) |
| Coil Resistance (Ambient Temp. 77 °F (25 °C)) | Ohm T - R : 0.169 T - S : 0.169 R - S : 0.169 |
| Safety Device | |
| CT (Peak current cut-off control) | Yes |
| Compressor Discharge Temp. Control | Yes |
| Operation cut-off control in abnormal ambient Temp. | Yes |
| Overload Relay | Model CS-7L110 |
| | Operation Temp. Open : 230 °F (110 °C), Close : 203 °F (95 °C) |
| Run Capacitor | Micro F - |
| | VAC - |
| Crankcase Heater | 230V 30W |

| | |
|---------------|---------------------------------|
| Fan | |
| Type | Propeller |
| Q'ty ... Dia. | inch (mm) 1 ... D19-9/32 (D490) |

| | |
|-------------------------------|-------------------------|
| Fan Motor | |
| Type | DC Motor |
| Model ... Q'ty | SIC-71FW-D8120-4A ... 1 |
| No. of Poles | 8 |
| Rough Measure RPM (Cool) | 750 |
| Nominal Output | W 142 |
| Coil Resistance | Ohm - |
| (Ambient Temp. 68 °F (20 °C)) | |
| Safety Device | |
| Type | Internal Controller |
| Over- Current Protection | Yes |
| Over- Heat Protection | Yes |
| Run Capacitor | Micro F - |
| | VAC - |

| | |
|----------------------------|--|
| Heat Exchanger Coil | |
| Coil | Aluminum Plate Fin / Copper Tube |
| Rows | 2 |
| Fins per inch | 21.2 |
| Face Area | ft ² (m ²) 8.05 (0.748) |

| | |
|------------------------|--------------------------------|
| External Finish | Acrylic baked-on enamel finish |
|------------------------|--------------------------------|


DATA SUBJECT TO CHANGE WITHOUT NOTICE.

2-3. Other Component Specifications


Indoor Unit **KS3082**
KS3682

Outdoor Unit **C3082**
C3682


- **Indoor air temp sensor**
(Model:KTEC-35-S121-1)



- **Indoor heat exchanger sensor**
(Model:PTM-D51H-S6-1)
- **Compressor temp sensor**
(Model:TKS335B)




- **Outdoor air temp sensor**
(Model:TKS295B)
- **Outdoor heat exchanger sensor**
(Model:TKS334B)
- **Heat sink temp sensor (HIC Board)**
(Model:TKS316B)





3. DIMENSIONAL DATA

Indoor Unit **KS3082**
KS3682



Unit: inch(mm)
(852-0-0010-19600-0)

Outdoor Unit **C3082**
C3682




Unit: inch(mm)
(852-0-0010-19400-1)

4. REFRIGERANT FLOW DIAGRAM

4-1. Refrigerant Flow Diagram

Indoor Unit **KS3082**
 KS3682

Outdoor Unit **C3082**
 C3682



5. PERFORMANCE DATA


5-1. Temperature Charts

Indoor Unit **KS3082**


Outdoor Unit **C3082**

■ Cooling Characteristics (RH : 46%, Indoor fan speed : High fan) (60Hz, 230V)


(1) Low pressure performance chart



(2) Operating current performance chart



(3) Indoor discharge air performance chart



NOTE


• Check each performance value in test-run mode. Electrical performance values represent a combined indoor/outdoor value.

Indoor Unit **KS3682**


Outdoor Unit **C3682**

■ Cooling Characteristics (RH : 46%, Indoor fan speed : High fan) (60Hz, 230V)


(1) Low pressure performance chart



(2) Operating current performance chart



(3) Indoor discharge air performance chart



NOTE

• Check each performance value in test-run mode. Electrical performance values represent a combined indoor/outdoor value.

5-2. Cooling Capacity

Indoor Unit : **KS3082**

Outdoor Unit : **C3082**

Power Supply : 230V Single Phase 60Hz

< Cooling Capacity (Low Ambient) >

| RATING CAPACITY: | | 30,600 BTU/h | | AIR FLOW RATE: | | | | | 630 CFM | |
|--------------------|-----------|-----------------------|--------------|----------------|--------------|--------------|-------------|-------------|--------------|--|
| INDOOR | | OUTDOOR | | | | | | | | |
| ENT. TEMP. °F (°C) | | AMBIENT TEMP. °F (°C) | | | | | | | | |
| W.B. | D.B. | | 0 (-17.8) | 5 (-15.0) | 15 (-9.4) | 25 (-3.9) | 35 (1.7) | 45 (7.2) | 55 (12.8) | |
| 59 (15.0) | | TC | 30,120 | 30,060 | 29,930 | 29,780 | 29,590 | 29,330 | 29,070 | |
| | 72 (22.2) | SHC | 21,150 | 21,150 | 21,020 | 20,900 | 20,780 | 20,660 | 20,530 | |
| | 76 (24.4) | SHC | 23,470 | 23,470 | 23,350 | 23,230 | 23,230 | 22,980 | 22,860 | |
| | 80 (26.7) | SHC | 25,920 | 25,920 | 25,790 | 25,790 | 25,670 | 25,430 | 25,300 | |
| | 84 (28.9) | SHC | 28,240 | 28,240 | 28,120 | 28,120 | 27,990 | 27,870 | 27,630 | |
| | 88 (31.1) | SHC | 30,120 | 30,060 | 29,930 | 29,780 | 29,590 | 29,330 | 29,070 | |
| 63 (17.2) | | TC | 30,390 | 30,360 | 30,270 | 30,170 | 30,040 | 29,820 | 29,610 | |
| | 72 (22.2) | SHC | 17,720 | 17,720 | 17,600 | 17,600 | 17,480 | 17,360 | 17,360 | |
| | 76 (24.4) | SHC | 20,050 | 20,050 | 19,920 | 19,920 | 19,800 | 19,800 | 19,680 | |
| | 80 (26.7) | SHC | 22,490 | 22,490 | 22,370 | 22,370 | 22,370 | 22,250 | 22,120 | |
| | 84 (28.9) | SHC | 24,820 | 24,820 | 24,820 | 24,690 | 24,690 | 24,570 | 24,450 | |
| | 88 (31.1) | SHC | 27,140 | 27,140 | 27,140 | 27,020 | 27,020 | 26,890 | 26,770 | |
| 67 (19.4) | | TC | 30,490 | 30,480 | 30,450 | 30,400 | 30,330 | 30,160 | 30,020 | |
| | 72 (22.2) | SHC | 14,180 | 14,180 | 14,180 | 14,180 | 14,180 | 14,050 | 14,050 | |
| | 76 (24.4) | SHC | 16,500 | 16,500 | 16,500 | 16,500 | 16,500 | 16,380 | 16,380 | |
| | 80 (26.7) | SHC | 19,070 | 18,940 | 18,940 | 18,940 | 18,940 | 18,820 | 18,820 | |
| | 84 (28.9) | SHC | 21,390 | 21,390 | 21,390 | 21,270 | 21,270 | 21,150 | 21,150 | |
| | 88 (31.1) | SHC | 23,710 | 23,710 | 23,710 | 23,710 | 23,590 | 23,590 | 23,470 | |
| 71 (21.7) | | TC | 30,370 | 30,380 | 30,410 | 30,430 | 30,420 | 30,310 | 30,250 | |
| | 72 (22.2) | SHC | 10,510 | 10,510 | 10,510 | 10,630 | 10,630 | 10,510 | 10,510 | |
| | 76 (24.4) | SHC | 12,950 | 12,950 | 12,950 | 12,950 | 12,950 | 12,830 | 12,830 | |
| | 80 (26.7) | SHC | 15,400 | 15,400 | 15,400 | 15,400 | 15,400 | 15,280 | 15,280 | |
| | 84 (28.9) | SHC | 17,720 | 17,720 | 17,720 | 17,720 | 17,720 | 17,720 | 17,600 | |
| | 88 (31.1) | SHC | 20,050 | 20,050 | 20,050 | 20,050 | 20,050 | 20,050 | 20,050 | |
| 75 (23.9) | | TC | 30,030 | 30,080 | 30,170 | 30,240 | 30,310 | 30,250 | 30,270 | |
| | 76 (24.4) | SHC | 9,410 | 9,410 | 9,410 | 9,530 | 9,530 | 9,530 | 9,530 | |
| | 80 (26.7) | SHC | 11,850 | 11,850 | 11,850 | 11,970 | 11,970 | 11,970 | 11,970 | |
| | 84 (28.9) | SHC | 14,180 | 14,180 | 14,300 | 14,300 | 14,300 | 14,300 | 14,300 | |
| | 88 (31.1) | SHC | 16,500 | 16,620 | 16,620 | 16,620 | 16,620 | 16,620 | 16,620 | |

TC : Total Cooling Capacity (BTU/h) SHC : Sensible Heat Capacity (BTU/h)

NOTE

- Above data does not take Freeze Prevention Protection during cooling operation into account. For this reason, the value may vary from the actual cooling characteristics.
- Above data represents the value when the operation frequency of a compressor is fixed.

< Cooling Capacity >

| RATING CAPACITY: | | 30,600 BTU/h | | AIR FLOW RATE: | | 630 CFM | | |
|--------------------|-----------|-----------------------|--------------|----------------|--------------|--------------|---------------|---------------|
| INDOOR | | OUTDOOR | | | | | | |
| ENT. TEMP. °F (°C) | | AMBIENT TEMP. °F (°C) | | | | | | |
| W.B. | D.B. | | 65 (18.3) | 75 (23.9) | 85 (29.4) | 95 (35.0) | 105 (40.6) | 115 (46.1) |
| 59 (15.0) | | TC | 30,650 | 29,970 | 29,190 | 28,600 | 24,890 | 17,310 |
| | 72 (22.2) | SHC | 21,390 | 21,020 | 20,660 | 20,290 | 18,330 | 14,660 |
| | 76 (24.4) | SHC | 23,710 | 23,350 | 22,980 | 22,610 | 20,660 | 16,990 |
| | 80 (26.7) | SHC | 26,280 | 25,790 | 25,430 | 25,060 | 23,100 | 17,310 |
| | 84 (28.9) | SHC | 28,610 | 28,240 | 27,750 | 27,380 | 24,890 | 17,310 |
| | 88 (31.1) | SHC | 30,650 | 29,970 | 29,190 | 28,600 | 24,890 | 17,310 |
| 63 (17.2) | | TC | 31,580 | 30,910 | 30,160 | 29,630 | 25,270 | 17,560 |
| | 72 (22.2) | SHC | 18,330 | 17,970 | 17,600 | 17,360 | 15,150 | 11,730 |
| | 76 (24.4) | SHC | 20,660 | 20,290 | 19,920 | 19,680 | 17,480 | 14,050 |
| | 80 (26.7) | SHC | 23,100 | 22,740 | 22,370 | 22,120 | 20,050 | 16,500 |
| | 84 (28.9) | SHC | 25,430 | 25,060 | 24,690 | 24,450 | 22,370 | 17,560 |
| | 88 (31.1) | SHC | 27,750 | 27,510 | 27,020 | 26,770 | 24,690 | 17,560 |
| 67 (19.4) | | TC | 32,420 | 31,780 | 31,050 | # 30,600 | 25,550 | 17,760 |
| | 72 (22.2) | SHC | 15,150 | 14,790 | 14,420 | 14,300 | 12,100 | 8,920 |
| | 76 (24.4) | SHC | 17,480 | 17,110 | 16,870 | 16,620 | 14,420 | 11,240 |
| | 80 (26.7) | SHC | 19,920 | 19,560 | 19,310 | 19,070 | 16,870 | 13,690 |
| | 84 (28.9) | SHC | 22,250 | 22,000 | 21,640 | 21,390 | 19,190 | 16,010 |
| | 88 (31.1) | SHC | 24,570 | 24,330 | 23,960 | 23,710 | 21,510 | 17,760 |
| 71 (21.7) | | TC | 33,130 | 32,540 | 31,840 | 31,490 | 25,710 | 17,880 |
| | 72 (22.2) | SHC | 11,730 | 11,480 | 11,120 | 11,000 | 8,670 | 5,860 |
| | 76 (24.4) | SHC | 14,050 | 13,810 | 13,440 | 13,320 | 11,120 | 8,310 |
| | 80 (26.7) | SHC | 16,500 | 16,250 | 15,890 | 15,770 | 13,560 | 10,750 |
| | 84 (28.9) | SHC | 18,820 | 18,580 | 18,330 | 18,210 | 15,890 | 13,070 |
| | 88 (31.1) | SHC | 21,150 | 20,900 | 20,660 | 20,530 | 18,210 | 15,400 |
| 75 (23.9) | | TC | 33,630 | 33,090 | 32,430 | 32,190 | 25,730 | 17,900 |
| | 76 (24.4) | SHC | 10,750 | 10,510 | 10,260 | 10,140 | 7,940 | 5,370 |
| | 80 (26.7) | SHC | 13,200 | 12,950 | 12,710 | 12,590 | 10,380 | 7,820 |
| | 84 (28.9) | SHC | 15,520 | 15,280 | 15,030 | 15,030 | 12,710 | 10,140 |
| | 88 (31.1) | SHC | 17,840 | 17,720 | 17,480 | 17,360 | 15,030 | 12,590 |

TC : Total Cooling Capacity (BTU/h) SHC : Sensible Heat Capacity (BTU/h)

NOTE

1. Rating conditions (#) : Indoor Unit Entering Air Temp. 80 °F (26.7 °C) D.B. / 67 °F (19.4 °C) W.B.
: Outdoor Ambient Temp. 95 °F (35 °C) D.B.
2. Above data does not take Freeze Prevention Protection during cooling operation into account.
For this reason, the value may vary from the actual cooling characteristics.
3. Above data represents the value when the operation frequency of a compressor is fixed.

Indoor Unit : **KS3682**

Outdoor Unit : **C3682**

Power Supply : 230V Single Phase 60Hz

< Cooling Capacity (Low Ambient) >

| RATING CAPACITY: | | 34,000 BTU/h | | AIR FLOW RATE: | | 630 CFM | | | |
|--------------------|-----------|-----------------------|--------------|----------------|--------------|--------------|-------------|-------------|--------------|
| INDOOR | | OUTDOOR | | | | | | | |
| ENT. TEMP. °F (°C) | | AMBIENT TEMP. °F (°C) | | | | | | | |
| W.B. | D.B. | | 0 (-17.8) | 5 (-15.0) | 15 (-9.4) | 25 (-3.9) | 35 (1.7) | 45 (7.2) | 55 (12.8) |
| 59 (15.0) | | TC | 30,900 | 30,870 | 30,800 | 30,710 | 30,590 | 30,400 | 30,210 |
| | 72 (22.2) | SHC | 21,510 | 21,510 | 21,510 | 21,510 | 21,390 | 21,270 | 21,150 |
| | 76 (24.4) | SHC | 23,960 | 23,840 | 23,840 | 23,840 | 23,710 | 23,590 | 23,470 |
| | 80 (26.7) | SHC | 26,400 | 26,400 | 26,280 | 26,280 | 26,160 | 26,040 | 25,920 |
| | 84 (28.9) | SHC | 28,730 | 28,730 | 28,610 | 28,610 | 28,480 | 28,480 | 28,360 |
| | 88 (31.1) | SHC | 30,900 | 30,870 | 30,800 | 30,710 | 30,590 | 30,400 | 30,210 |
| 63 (17.2) | | TC | 31,010 | 31,010 | 30,990 | 30,950 | 30,890 | 30,750 | 30,620 |
| | 72 (22.2) | SHC | 17,970 | 17,970 | 17,970 | 17,970 | 17,970 | 17,840 | 17,840 |
| | 76 (24.4) | SHC | 20,410 | 20,410 | 20,290 | 20,290 | 20,290 | 20,170 | 20,170 |
| | 80 (26.7) | SHC | 22,860 | 22,860 | 22,740 | 22,740 | 22,740 | 22,610 | 22,610 |
| | 84 (28.9) | SHC | 25,180 | 25,180 | 25,180 | 25,060 | 25,060 | 25,060 | 24,940 |
| | 88 (31.1) | SHC | 27,510 | 27,510 | 27,510 | 27,510 | 27,380 | 27,380 | 27,260 |
| 67 (19.4) | | TC | 30,910 | 30,940 | 30,980 | 31,000 | 31,010 | 30,930 | 30,880 |
| | 72 (22.2) | SHC | 14,420 | 14,420 | 14,420 | 14,420 | 14,420 | 14,420 | 14,420 |
| | 76 (24.4) | SHC | 16,740 | 16,740 | 16,740 | 16,740 | 16,740 | 16,740 | 16,740 |
| | 80 (26.7) | SHC | 19,190 | 19,190 | 19,190 | 19,190 | 19,190 | 19,190 | 19,190 |
| | 84 (28.9) | SHC | 21,510 | 21,510 | 21,640 | 21,640 | 21,640 | 21,510 | 21,510 |
| | 88 (31.1) | SHC | 23,840 | 23,960 | 23,960 | 23,960 | 23,960 | 23,960 | 23,840 |
| 71 (21.7) | | TC | 30,570 | 30,620 | 30,730 | 30,820 | 30,910 | 30,900 | 30,930 |
| | 72 (22.2) | SHC | 10,630 | 10,630 | 10,750 | 10,750 | 10,750 | 10,750 | 10,750 |
| | 76 (24.4) | SHC | 12,950 | 12,950 | 13,070 | 13,070 | 13,070 | 13,070 | 13,070 |
| | 80 (26.7) | SHC | 15,400 | 15,400 | 15,520 | 15,520 | 15,520 | 15,520 | 15,520 |
| | 84 (28.9) | SHC | 17,720 | 17,840 | 17,840 | 17,840 | 17,970 | 17,970 | 17,970 |
| | 88 (31.1) | SHC | 20,170 | 20,170 | 20,170 | 20,170 | 20,290 | 20,290 | 20,290 |
| 75 (23.9) | | TC | 30,010 | 30,090 | 30,260 | 30,430 | 30,590 | 30,650 | 30,770 |
| | 76 (24.4) | SHC | 9,410 | 9,410 | 9,530 | 9,530 | 9,650 | 9,650 | 9,650 |
| | 80 (26.7) | SHC | 11,850 | 11,850 | 11,970 | 11,970 | 12,100 | 12,100 | 12,100 |
| | 84 (28.9) | SHC | 14,180 | 14,180 | 14,300 | 14,300 | 14,420 | 14,420 | 14,420 |
| | 88 (31.1) | SHC | 16,500 | 16,620 | 16,620 | 16,740 | 16,740 | 16,740 | 16,870 |

TC : Total Cooling Capacity (BTU/h) SHC : Sensible Heat Capacity (BTU/h)

NOTE

1. Above data does not take Freeze Prevention Protection during cooling operation into account. For this reason, the value may vary from the actual cooling characteristics.
2. Above data represents the value when the operation frequency of a compressor is fixed.

Indoor Unit : **KS3682**

Outdoor Unit : **C3682**

Power Supply : 230V Single Phase 60Hz

< Cooling Capacity >

| RATING CAPACITY: | | 34,000 BTU/h | | AIR FLOW RATE: | | 630 CFM | | |
|--------------------|-----------|-----------------------|--------------|----------------|--------------|--------------|---------------|---------------|
| INDOOR | | OUTDOOR | | | | | | |
| ENT. TEMP. °F (°C) | | AMBIENT TEMP. °F (°C) | | | | | | |
| W.B. | D.B. | | 65 (18.3) | 75 (23.9) | 85 (29.4) | 95 (35.0) | 105 (40.6) | 115 (46.1) |
| 59 (15.0) | | TC | 34,170 | 33,480 | 32,690 | 32,110 | 24,650 | 16,770 |
| | 72 (22.2) | SHC | 23,470 | 23,100 | 22,610 | 22,250 | 18,210 | 14,420 |
| | 76 (24.4) | SHC | 25,790 | 25,430 | 24,940 | 24,570 | 20,530 | 16,740 |
| | 80 (26.7) | SHC | 28,240 | 27,870 | 27,380 | 27,020 | 22,980 | 16,770 |
| | 84 (28.9) | SHC | 30,560 | 30,200 | 29,710 | 29,460 | 24,650 | 16,770 |
| | 88 (31.1) | SHC | 33,010 | 32,520 | 32,030 | 31,790 | 24,650 | 16,770 |
| 63 (17.2) | | TC | 35,010 | 34,360 | 33,600 | 33,100 | 24,850 | 16,910 |
| | 72 (22.2) | SHC | 20,170 | 19,800 | 19,310 | 19,070 | 15,030 | 11,480 |
| | 76 (24.4) | SHC | 22,490 | 22,120 | 21,760 | 21,390 | 17,360 | 13,810 |
| | 80 (26.7) | SHC | 24,940 | 24,570 | 24,200 | 23,840 | 19,800 | 16,250 |
| | 84 (28.9) | SHC | 27,260 | 26,890 | 26,530 | 26,280 | 22,120 | 16,910 |
| | 88 (31.1) | SHC | 29,580 | 29,220 | 28,850 | 28,610 | 24,450 | 16,910 |
| 67 (19.4) | | TC | 35,720 | 35,120 | 34,400 | # 34,000 | 24,930 | 16,970 |
| | 72 (22.2) | SHC | 16,620 | 16,380 | 16,010 | 15,890 | 11,730 | 8,670 |
| | 76 (24.4) | SHC | 19,070 | 18,700 | 18,330 | 18,210 | 14,180 | 11,000 |
| | 80 (26.7) | SHC | 21,510 | 21,150 | 20,900 | 20,660 | 16,620 | 13,440 |
| | 84 (28.9) | SHC | 23,840 | 23,590 | 23,230 | 22,980 | 18,940 | 15,770 |
| | 88 (31.1) | SHC | 26,160 | 25,920 | 25,550 | 25,300 | 21,270 | 16,970 |
| 71 (21.7) | | TC | 36,270 | 35,710 | 35,040 | 34,780 | 24,870 | 16,950 |
| | 72 (22.2) | SHC | 13,070 | 12,830 | 12,460 | 12,340 | 8,430 | 5,610 |
| | 76 (24.4) | SHC | 15,400 | 15,150 | 14,790 | 14,790 | 10,750 | 7,940 |
| | 80 (26.7) | SHC | 17,840 | 17,600 | 17,360 | 17,230 | 13,200 | 10,380 |
| | 84 (28.9) | SHC | 20,170 | 19,920 | 19,680 | 19,560 | 15,520 | 12,710 |
| | 88 (31.1) | SHC | 22,490 | 22,250 | 22,000 | 21,880 | 17,840 | 15,030 |
| 75 (23.9) | | TC | 36,560 | 36,070 | 35,450 | 34,630 | 24,680 | 16,830 |
| | 76 (24.4) | SHC | 11,850 | 11,610 | 11,360 | 11,120 | 7,570 | 5,130 |
| | 80 (26.7) | SHC | 14,300 | 14,050 | 13,810 | 13,560 | 10,020 | 7,570 |
| | 84 (28.9) | SHC | 16,620 | 16,500 | 16,250 | 15,890 | 12,340 | 9,900 |
| | 88 (31.1) | SHC | 18,940 | 18,820 | 18,580 | 18,210 | 14,660 | 12,220 |

TC : Total Cooling Capacity (BTU/h) SHC : Sensible Heat Capacity (BTU/h)


NOTE

1. Rating conditions (#) : Indoor Unit Entering Air Temp. 80 °F (26.7 °C) D.B. / 67 °F (19.4 °C) W.B.
: Outdoor Ambient Temp. 95 °F (35 °C) D.B.
2. Above data does not take Freeze Prevention Protection during cooling operation into account.
For this reason, the value may vary from the actual cooling characteristics.
3. Above data represents the value when the operation frequency of a compressor is fixed.


5-3. Air Throw Distance Charts

Indoor Unit **KS3082**

Cooling Room air temp. : 80°F (26.7°C)
 Fan speed : High



Cooling Room air temp. : 80°F (26.7°C)
 Fan speed : High



6. ELECTRICAL DATA

6-1. Electrical Characteristics

Indoor Unit **KS3082**

Outdoor Unit **C3082**

(1) Voltage:230V

Cooling

< 230V >

| | | | Indoor Unit | Outdoor Unit | Complete Unit |
|-------------------|--------------|---|------------------------|------------------------|---------------|
| | | | Fan Motor | Fan Motor + Compressor | |
| Performance at | | | 230V Single-phase 60Hz | | |
| Rating conditions | Running amp. | A | 0.4 | 16.1 | 16.5 |
| | Power input | W | 39 | 3,251 | 3,290 |

Rating conditions: Indoor air temperature: 80°F (26.7°C) D.B. / 67°F (19.4°C) W.B.

Outdoor air temperature: 95°F (35°C) D.B.

(2) Voltage:208V

Cooling

< 208V >

| | | | Indoor Unit | Outdoor Unit | Complete Unit |
|-------------------|--------------|---|------------------------|------------------------|---------------|
| | | | Fan Motor | Fan Motor + Compressor | |
| Performance at | | | 208V Single-phase 60Hz | | |
| Rating conditions | Running amp. | A | 0.4 | 17.6 | 18.0 |
| | Power input | W | 39 | 3,251 | 3,290 |

Rating conditions: Indoor air temperature: 80°F (26.7°C) D.B. / 67°F (19.4°C) W.B.

Outdoor air temperature: 95°F (35°C) D.B.

Indoor Unit **KS3682**

Outdoor Unit **C3682**

(1) Voltage:230V

Cooling

< 230V >

| | | | Indoor Unit | Outdoor Unit | Complete Unit |
|-------------------|--------------|---|------------------------|------------------------|---------------|
| | | | Fan Motor | Fan Motor + Compressor | |
| Performance at | | | 230V Single-phase 60Hz | | |
| Rating conditions | Running amp. | A | 0.4 | 19.6 | 20.0 |
| | Power input | W | 39 | 3,961 | 4,000 |

Rating conditions: Indoor air temperature: 80°F (26.7°C) D.B. / 67°F (19.4°C) W.B.
Outdoor air temperature: 95°F (35°C) D.B.

(2) Voltage:208V

Cooling


< 208V >

| | | | Indoor Unit | Outdoor Unit | Complete Unit |
|-------------------|--------------|---|------------------------|------------------------|---------------|
| | | | Fan Motor | Fan Motor + Compressor | |
| Performance at | | | 208V Single-phase 60Hz | | |
| Rating conditions | Running amp. | A | 0.4 | 21.5 | 21.9 |
| | Power input | W | 39 | 3,961 | 4,000 |

Rating conditions: Indoor air temperature: 80°F (26.7°C) D.B. / 67°F (19.4°C) W.B.
Outdoor air temperature: 95°F (35°C) D.B.


6-2. Electric Wiring Diagrams

Indoor Unit **KS3082**
KS3682



8FA2-5250-70400-3

Outdoor Unit **C3082**
C3682



8FA2-5250-71800-1

7. FUNCTIONS

7-1. Operation Functions

■ Emergency operation

Emergency operation is available when the remote controller malfunctions, has been lost, or otherwise cannot be used.

To operate the system, press the OPERATION button, which is also used as the receiver, below the unit display. Each time this button is pressed, the OPERATION lamp changes color to indicate the type of operation. Select the desired type of operation.




- The set temperature is 4°F(2°C) below the detected room temperature in the case of cooling operation.

■ SENSOR DRY

During DRY operation, the system adjusts the room temperature and fan speed according to the conditions in the room, in order to maintain a comfortable room environment.

SENSOR DRY operation

- DRY operation is as shown in the figure below.



Conditions are monitored at all times when the room temperature is below 59°F(15°C).

DRY A

The compressor operation frequency varies.
The indoor fan operates with 1/f fluctuation.

DRY B

The compressor operates at a low operating frequency.
The indoor fan operates with 1/f fluctuation.

Monitor

- Monitoring operation takes place when the room temperature is below 59°F(15°C), or more than 5°F(3°C) below the set temperature.
- When the monitoring range is entered, the compressor stops, and the indoor fan operates with 1/f fluctuation.

NOTE

The Sensor Dry operation during the Low Ambient Cooling Mode (outside air temperature : 59°F(15°C) or lower) is as follows.

DRY A and DRY B

When room temperature rises above the set temperature, the compressor turns ON. When room temperature falls below the set temperature, the compressor turns OFF.


■ HIGH POWER

This function acts to raise the power but keeps the AC system in the same operating mode. This function is set with the HIGH POWER button on the remote controller.

(It can be set regardless of the temperature and fan speed settings.)

● HIGH POWER operation from remote controller

The unit operates at maximum output for 30 minutes, regardless of the desired temperature. The fan speed is 1 step above "High."



NOTE


- When HIGH POWER operation ends, the unit operates at low Hz for 5 minutes, regardless of the thermostat OFF conditions.
- When in DRY mode, operation is in the cooling zone.

■ NIGHT SETBACK

- When NIGHT SETBACK operation is set, the temperature and fan speed settings will be adjusted automatically to allow comfortable sleep.
- When NIGHT SETBACK operation is set, "☺ mark" appears on the remote controller. The main unit display lamp also becomes dimmer.

● COOL and DRY modes

When the night setback mode is selected, the air conditioner automatically raises the temperature setting $2^{\circ}\text{F}(1^{\circ}\text{C})$ when 30 minutes have passed after the selection was made, and then another $2^{\circ}\text{F}(1^{\circ}\text{C})$ after another 30 minutes have passed, regardless of the indoor temperature when night setback was selected. This enables you to save energy without sacrificing comfort. This function is convenient when gentle cooling is needed.



■ Lamp colors

OPERATION lamp

| | |
|----------------|--------|
| DRY operation | Orange |
| COOL operation | Green |
| FAN operation | Green |

TIMER lamp

Green

LED CLEAN lamp

Green

■ Timer backup

- Operation stops if there are no operator controls for 25 hours or longer after unit operation switched from OFF to ON by use of ON timer operation.

■ Noise Reducing Control (Outdoor Unit)


The noise reducing control is the function used for silent operation of the air conditioner by means of setting the dip switch on the outdoor unit P.C.Board to control the fan and compressor's motor speed.

NOTE When this function is used, the cooling ability is slightly degraded. Therefore, when this function is to be enabled, make sure to receive the approval of the client.

<Operation Sound>

| Specifications | Noise Reducing Control (Fan's motor speed : 500rpm) |
|----------------|--|
| Cooling | Cooling |
| 55 dB-A | 47 dB-A |

<In Cooling Operation>



- NOTE**
1. In the test operation, high-power operation, defrost operation or low ambient cooling operation (to be cancelled at the outside temperature of 14 °C or less, or 17 °C or more), the noise reducing control is not available.
 2. In the noise reducing operation, the fan's maximum motor speed is limited to 500rpm. Also, the maximum frequency (Hz) is controlled in the cooling (30Hz) or heating operation (30Hz).

<Switching Procedure to Noise Reducing Control>

- (1) Remove the 3 screws fixing the inspection panel and remove the inspection panel. (Fig. 2)
- (2) When the switch No. 1 of the dip switch (SW01) on the control P.C.Board is turned ON, the noise reducing control is enabled. (Fig. 3)




Fig.2 View from front





Fig.3 Control P.C.Board

Maximum Current Value Change Function

The maximum current value is changed to 14A (for C3082) or 17A (for C3682) to prevent power breaker tripping. (It is set to 24A when the unit is delivered from the factory.)

- NOTE**
- When the high load is given (Outside temperature is high in the cooling operation), the capacity is reduced.
When the maximum current value change function is to be enabled, make sure to receive the approval of the client.
 - The maximum capacity for cooling operation is about as much as the rated capacity.

Description of function



- Operates at the target frequency at Point A and below.
- Stops increases to the frequency between Points A and B.
- Reduces the frequency by 1 Hz per 0.5 seconds when Point B is exceeded.
- Stops operation, and restarts it approximately 5 minutes later, if Point C is exceeded.
(May operate when sudden voltage fluctuations occur. → Indicates trouble.)

< C3082 >

| | In cooling operation |
|------------------------------|----------------------|
| Current Value on the Point C | (25.0) |
| Current Value on the Point B | 22.0 |
| Current Value on the Point A | 21.6 |

< C3682 >

| | In cooling operation |
|------------------------------|----------------------|
| Current Value on the Point C | (25.0) |
| Current Value on the Point B | 24.0 |
| Current Value on the Point A | 23.6 |

<Maximum Current Value Change Procedure>

- Remove the inspection panel.
Refer to Fig. 2 in "Noise Reducing Control" for details.
- When the switch No.2 of the dip switch (SW01) on the control P.C.Board is turned ON, the maximum current value change. (Fig. 4)

| Dip Switch (SW01) Switch No.2 | Max. Current Value | |
|----------------------------------|--------------------|-------|
| | C3082 | C3682 |
| ON | 14.0A | 17.0A |
| OFF | 22.0A | 24.0A |





Fig.4 Control P.C.Board

7-2. Protective Functions

■ Freeze prevention

During COOL or DRY operation, freezing is detected and operation is stopped when the temperature of the indoor heat exchanger matches the conditions below.

- Freeze-prevention operation is engaged when the temperature of the indoor heat exchanger is below 41°F(5°C).
- Restart after freeze-prevention operation occurs when the temperature of the indoor heat exchanger reaches 46°F(8°C) or above.




- Area: Automatic capacity control
- When the temperature drops below Point A, the operation frequency is reduced by a certain proportion.
- Area: Frequency increase is prohibited.
- When the temperature reaches Point C or above, freezing prevention is ended and control is the same as in the a area.

* When the temperature drops to below 36°F(2°C) (continuously for 2 minutes or longer), the compressor stops. Once the freeze condition is detected, the air conditioner will work less than the maximum frequency until it is turned off.

■ Compressor discharge temperature control

This function controls the operation frequency to prevent the compressor discharge temperature from rising more than a specified temperature.

Compressor discharge temperature °F(°C)



- Area: Automatic capacity control.
- When the temperature rises above Point A, the operation frequency is reduced at a specified rate.
- Area: Further frequency increase is prohibited.
- When the temperature falls below Point B, prevention of a rise in frequency is released and the air conditioner operates as in a area.

* The compressor will stop if the temperature of the compressor discharge exceeds 248°F(120°C) due to shortage of gas or other reason.

■ CT (Peak current cut-off control)

- This function prevents the circuit breaker or fuse from operating to open the circuit. This function works when electrical current has increased due to an increase in the cooling load, or to a decrease in the power supply voltage. In these cases, operation frequency is reduced or operation is interrupted automatically to control the electrical current for operation.
- When the cause of the increase in electrical current is rectified, the system will resume operation in the original mode.

< KS3082 > (A)

| | |
|----------------------------|---------------|
| | Cooling • Dry |
| Peak current cut-off trips | 25.0 |
| Hz down | 22.0 |

< KS3682 > (A)

| | |
|----------------------------|---------------|
| | Cooling • Dry |
| Peak current cut-off trips | 25.0 |
| Hz down | 24.0 |

8. TROUBLESHOOTING

8-1. Precautions before Performing Inspection or Repair

- After checking the self-diagnostics monitor, turn the power OFF before starting inspection or repair.
 - High-capacity electrolytic capacitors are used inside the outdoor unit controller (inverter). They retain an electrical charge (charging voltage DC 310V) even after the power is turned OFF, and some time is required for the charge to dissipate. Be careful not to touch any electrified parts before the controller LED (red) turns OFF.
- If the outdoor controller is normal, approximately 30 seconds will be required for the charge to dissipate. However, allow at least 5 minutes for the charge to dissipate if there is thought to be any trouble with the outdoor controller.

8-2. Method of Self-Diagnostics

Follow the procedure below to perform detailed trouble diagnostics.

NOTE

- 1: If the operation lamp blinks every 0.5 seconds immediately when the power is turned ON, there is an external ROM (OTP data) failure on the indoor circuit board, or a ROM socket insertion problem, or the ROM has not been installed.
- 2: The failure mode is stored in memory even when the power is not ON. Follow the procedure below to perform diagnostics.

PROCEDURE

After turning on power to the air conditioner, use the remote controller and follow the steps below to execute self-diagnostics.


Step 1: Press and hold the remote controller QUIET button and 1 HR TIMER button. Then, press and hold the ACL (reset) button with a pointed object such as the tip of a pen. After 5 seconds, release ACL button first, then release QUIET and 1 HR TIMER buttons, "oP-1" (test run) appears, blinking in the remote controller clock display area.

Step 2: Next, press the 1 HR TIMER button twice to change the display from "oP-1" to "oP-2" and "oP-3" (self-diagnostics). (The display continues to blink.)


Step 3: Finally press the ON/OFF button to engage self-diagnostics mode.

- The self-diagnostics function utilizes the 3 indicator lamps on the main unit, in combinations of ON lamps, blinking lamps, and OFF lamps, to report the existence of sensor trouble or a protective operation. (The lamps blink or remain ON for 5 seconds, then turn OFF for 2 seconds.) Self-diagnostics is completed when the buzzer sounds 3 short beeps.
- A maximum of 3 self-diagnostics reports are displayed, for 5 seconds each, beginning with the most recent report. Following this display the lamps turn OFF. In order to view the self-diagnostics results again, press the ON/OFF button again.
- The 3 lamps remain OFF if no trouble has occurred.

<IMPORTANT> After self-diagnostics is completed, be sure to press the ACL (reset) button to return to normal mode. The air conditioner will not operate if this is not done.




(1) Self-diagnostics Lamps



*Since the indications cover various units, the corresponding parts listed below may not be present in some models.

| Indication on indoor unit | | | | | ✕ ... OFF | ☀ ... Blinking | ☀ ... ON (Illuminated) | | |
|---------------------------|---------------|-----------|---------------|------------|--|---|------------------------|--|--|
| Alarm Code | LED Clean (3) | Timer (2) | Operation (1) | Error Code | Diagnosis Contents | Possible Malfunction | | | |
| F10 | ✕ | ✕ | ☀ | S01 | Room temperature sensor failure | (1) Sensor open circuit or short circuit | | | |
| F02 | ✕ | ☀ | ✕ | S02 | Indoor heat exchanger sensor failure | (2) Contact failure at connector or open circuit at terminal crimping location (short-circuit detection only for the humidity sensor) | | | |
| F13 | ✕ | ☀ | ☀ | S03 | Humidity sensor failure | (3) Indoor/outdoor PCboard failure | | | |
| F04/F12 | ☀ | ✕ | ✕ | S04 | Compressor temperature sensor failure | (1) Sensor open circuit or short circuit | | | |
| F09/ F15 to F18 | ☀ | ✕ | ☀ | S05 | Outdoor heat exchanger sensor failure | (2) Contact failure at connector or open circuit at terminal crimping location | | | |
| F08/ F21 to F24 | ☀ | ☀ | ✕ | S06 | Outdoor air temperature sensor failure | (3) Outdoor PCboard failure | | | |
| F27 | ☀ | ☀ | ☀ | S07 | Outdoor electrical current detection failure | Outdoor PCboard failure | | | |
| E05 | ✕ | ✕ | ☀ | E01 | Indoor/outdoor communications failure (serial communications) | (1) Mis-wiring (2) AC power failure (3) Blown fuse (4) Power Relay failure (5) Indoor or outdoor PCboard failure (6) Outdoor Fan Motor failure (7) Reactor failure (8) High-Pressure Switch failure (9) Overload Relay failure (10) Magnetic Coil failure * See detailed flowchart in this section. | | | |
| P26 | ✕ | ☀ | ✕ | E02 | * HIC circuit failure * Power Tr (transistor) circuit failure | (1) HIC or power Tr failure (2) Outdoor fan does not turn. (3) Instantaneous power outage (4) Service valve not opened. (5) Outdoor fan blocked. (6) Continuous overload operation (7) Compressor failure (8) Outdoor PCboard failure | | | |
| F31 | ✕ | ☀ | ☀ | E03 | Outdoor unit external ROM (OTP data) failure | (1) External ROM data failure (2) Outdoor PCboard failure | | | |
| P16 | ☀ | ✕ | ✕ | E04 | Peak current cut-off | (1) Instantaneous power outage (2) HIC or power transistor failure (3) Outdoor PCboard failure | | | |
| P07 | ☀ | ✕ | ☀ | E05 | * PAM circuit failure * Active circuit failure | (1) Outdoor PCboard failure (2) Outdoor power supply voltage failure | | | |
| P03 | ☀ | ☀ | ✕ | E06 | Compressor discharge overheat prevention activated. | (1) Electric expansion valve failure (2) Capillaries choked (3) Shortage of refrigerant (4) Continuous overload operation (5) Outdoor fan does not rotate (6) Outdoor PCboard failure | | | |
| P01 | ☀ | ☀ | ☀ | E07 | Indoor fan operating failure | (1) Fan motor failure (2) Contact failure at connector (3) Indoor PCboard failure | | | |
| P19 | ☀ | ☀ | ☀ | E08 | * 4-way valve switching failure * Indoor zero-cross failure | (1) 4-way valve failure (heat pump model only) (2) Outdoor PCboard failure | | | |
| P15 | ☀ | ☀ | ☀ | E09 | No-refrigerant protection | (1) Service valve not opened. (2) Shortage of refrigerant | | | |
| P29 | ☀ | ☀ | ☀ | E10 | DC compressor drive circuit failure | (1) Open phase (2) Outdoor PCboard failure | | | |
| P22 | ☀ | ☀ | ☀ | E11 | Outdoor fan operating failure | (1) Fan motor failure (2) Contact failure at connector (3) Outdoor PCboard failure | | | |
| E07/P04/P05 P20/P27 | ☀ | ☀ | ☀ | E12 | * Outdoor system communications failure * OLR operation * Outdoor power supply open phase * Outdoor coil freezing | (1) Mis-wiring (2) Blown fuse (3) Power Relay failure (4) Outdoor PCboard failure (5) Compressor failure * See detailed flowchart in this section. | | | |
| P11 | ☀ | ☀ | ☀ | E13 | Freeze-prevention operation activated. | (1) Indoor fan system failure (2) Shortage of refrigerant (3) Low-temperature operation | | | |

(2) If the self-diagnostics function fails to operate



8-3. Checking the Indoor and Outdoor Units

(1) Checking the indoor unit

| No. | Control | Check items (unit operation) |
|-----|--|--|
| 1 | Use the remote controller to operate the unit in "TEST run" mode. To determine whether the mode is currently in "TEST run" mode, check the 4 indicator lamps on the unit. If all 4 are blinking, the current mode is "TEST run." | <ul style="list-style-type: none"> The rated voltage must be present between inter-unit wirings 1 and 2. Connect a 5 k ohm resistor between inter-unit wirings 2 and 3. When the voltage at both ends is measured, approximately 12 to 15V DC must be output and the multimeter pointer must bounce once every 8 seconds. Or instead of measuring the voltage, you can insert an LED jig and check that the LED flickers once every 8 seconds. |

- If there are no problems with the above, then check the outdoor unit.
- For the "Test run" procedure, refer to the Appendix B "Installation Instructions".


(2) Checking the outdoor unit

| No. | Control | Check items (unit operation) |
|-----|--|---|
| 1 | Apply the rated voltage between outdoor unit terminals L and N. | <ul style="list-style-type: none"> The control panel LED (red) must illuminate. |
| 2 | Short-circuit the outdoor unit COM terminal to the T-RUN terminal. | <ul style="list-style-type: none"> The compressor, fan motor and 4-way valve must all turn on. |

- If there are no problems with the above, then check the indoor unit.

● Using the TEST/T-RUN terminals

- T-RUN : Test run (compressor and fan motor turn ON).
 TEST/MV : Compresses time to 1/60th (accelerates operation by 60 times faster than normal).



(3) Serial Communication Error Identification Procedure

If the lamps on the main body show the following conditions after the completion of self-diagnostics, a communication error between the indoor unit and outdoor unit might be considered. In such a case, identify the breakdown section by using the following procedure.

NOTE Refer to "Method of Self-Diagnostics" for the self-diagnostics procedure.

| Alarm Code (Error Code) | Lamp (3) | LED Clean (2) | Timer (1) | Operation |
|----------------------------|-------------|------------------|--------------|-----------|
| E05 (E01) | × | × | ☀ | × |
| E07/P04/P05/P20/P27 (E12) | ☀ | ☀ | ☀ | ☀ |

× : Off
 ☀ : Blinking
 ☀ : Illuminated

< Before the Operation >



WARNING


For terminal strip short circuit work or inter-unit wiring removal, turn off the power to avoid an electric shock. Release the terminal strip short circuit after the completion of self-diagnostics.



CAUTION

Do not perform the short-circuit work between any other terminals except for specified ones on the specified terminal strip. If such work is performed between the incorrect terminals, the unit might be broken.

< Convenient Tool for Short-Circuit Work (for example) >




< Check Items before Troubleshooting Serial Communication Start >

After confirming that the following errors do not exist, start the "Troubleshooting Serial Communication" in "Alarm Code : E05 and E07/P04/P05/P20/P27".

- | | |
|---|--|
| 1. Mis -wiring (inter-unit cable, etc.) | 6. Reactor failure (defective insulation, etc.) |
| 2. AC power failure | 7. High-Pressure Switch failure |
| 3. Blown fuse | 8. Overload Relay failure |
| 4. Power Relay failure | 9. Magnetic Coil failure (defective insulation, short-circuit, etc.) |
| 5. Outdoor Fan Motor failure (defective insulation, etc.) | 10. Compressor failure (defective insulation, etc.) |

(3-1) Alarm Code : E05



(Continued from the previous page A.)

(Continued from the previous page B.)

A

B

Yes

No

Defect or connection error in the inter-unit cable

Defect in the indoor unit P.C. board

1. Turn OFF the power and wait until the power lamp (LED) of the outdoor unit controller is turned OFF.
 2. Short-circuit between the terminals 2 and 3 on the outdoor unit terminal strip. (Fig. 3)





Fig. 3

1. Turn ON the power and operate the system using the remote controller or the operation button on the indoor unit.
 2. Perform the self-diagnosis five seconds after the operation start.



Alarm Code : E05

1. Turn off the power and wait until the power lamp (LED) of the outdoor unit controller is turned OFF.
 2. Remove the short-circuit between the terminals 2 and 3 on the outdoor unit terminal strip.
 3. Disconnect the cable from the terminal 3 on the indoor unit terminal strip. (Fig. 4)




Fig. 4

Short-circuit between the terminals 2 and 3 on the indoor unit terminal board. (Fig. 5)





Fig. 5

1. Turn ON the power and operate the system using the remote controller or the operation button on the indoor unit.
 2. Perform the self-diagnosis five seconds after the operation start.



Alarm Code : E05


Defect in the indoor unit P.C. board

(3-2) Alarm Code : E07/P04/P05/P20/P27

Troubleshooting Serial Communication

1. Turn off the power and wait until the power lamp (LED) of the outdoor unit controller is turned OFF.
2. Disconnect the cable from the terminal 3 on the Outdoor unit terminal strip. (Fig. 6)

1. Turn ON the power and operate the system using the remote controller or the operation button on the indoor unit.
2. Perform the self-diagnosis five seconds after the operation start.




Alarm Code : E05

Defect in the outdoor unit P.C. board

Alarm Code : E07/P04/P05/P20/P27

1. Turn off the power and wait until the power lamp (LED) of the outdoor unit controller is turned OFF.
2. Disconnect the cable from the terminal 3 on the indoor unit terminal strip. (Fig. 7)

1. Turn ON the power and operate the system using the remote controller or the operation button on the indoor unit.
2. Perform the self-diagnosis five seconds after the operation start.



Alarm Code : E05

Defect in the inter-unit cable

Alarm Code : E07/P04/P05/P20/P27

Defect in the indoor unit P.C. board




Fig. 6




Fig. 7

8-4. Trouble Diagnosis of Fan Motor

8-4-1. Indoor Fan Motor

- This indoor DC fan motor contains an internal control PCB. Therefore, it is not possible to measure the coil resistance, and the following procedure should be used to check the motor.
- To perform diagnosis, operate the unit in cooling mode with indoor fan speed "High". Next, make sure that the indoor unit receive the signals from the remote controller when the ON/OFF operation button is pressed.

Important: (A) Turn OFF the power before connecting or disconnecting the motor connectors.
(B) When performing voltage measurement at the indoor controller connector for (3) in the table below, the DC motor will trip and voltage output will stop approximately 1 minute after operation is started. For this reason, to measure the voltage again, turn OFF the unit once using the remote controller, and then start the air conditioner again.

[Trouble symptom 1] The fan does not stop when the unit stops. → Indoor unit controller trouble.

[Trouble symptom 2] The fan motor does not rotate when the unit is operating.

(Diagnostic procedure)

* Disconnect the motor connectors and measure the voltage at the DC motor connectors on the indoor unit controller (3 locations).

| Measurement location | Normal value |
|--------------------------------------|---------------------------------------|
| (1) Vm-Gnd: Between pin 1 and pin 4 | DC 280 V +/-10% |
| (2) Vcc-Gnd: Between pin 5 and pin 4 | DC 15 V +/-10% |
| (3) Vs-Gnd: Between pin 6 and pin 4 | Fluctuation between DC 1.63 to 6.23 V |

(Diagnostic results)

All of the above measured values are normal. → Fan motor trouble (Replace the motor.)

Any one of the above measured values is not normal. → Indoor unit controller trouble (Replace the controller .)

(Reference) DC motor connector pin arrangement

- Pin 1: Vm (red)
- Pin 2: Not used
- Pin 3: Not used
- Pin 4: Gnd (black)
- Pin 5: Vcc (white)
- Pin 6: Vs (yellow)
- Pin 7: PG (blue)

[Trouble symptom 3] Motor rotates for some time (several seconds), but then quickly stops, when the indoor unit operates.

(There is trouble in the system that provides feedback of motor rotation speed from the motor to the indoor unit controller.)

[Trouble symptom 4] Fan motor rotation speed does not change during indoor unit operation.

[Trouble symptom 5] Fan motor rotation speed varies excessively during indoor unit operation.

(Remedy for symptom 3 to 5)

It is not possible to identify whether the trouble is indoor unit controller trouble or motor trouble. Therefore, first replace the indoor unit controller, then (if necessary) replace the DC motor.

8-4-2. Outdoor Fan Motor

- This outdoor DC fan motor contains an internal control PCB. Therefore, it is not possible to measure the coil resistance, and the following procedure should be used to check the motor.
- Perform the trouble diagnosis by Test Run mode described on Installation Instructions of indoor unit.

Important: (A) Turn OFF the power before connecting or disconnecting the motor connectors.

(B) When performing voltage measurement at the outdoor controller connector for (3) in the table below, the DC motor will trip and voltage output will stop approximately 10 seconds after operation is started. For this reason, to measure the voltage again, first turn OFF the outdoor unit power, then, measure the voltage in Test Run mode.

[Trouble symptom 1] The fan does not stop when the outdoor unit stops. → Outdoor unit controller trouble

[Trouble symptom 2] The fan motor does not rotate when the outdoor unit is operating.

(Diagnostic procedure)

* Disconnect the motor connectors and measure the voltage at the DC motor connectors on the outdoor unit controller (3 locations).

| Measurement location | Normal value |
|--|-------------------------------------|
| (1) Vm-Gnd : Between pin 1 and pin 3 of FM1 | DC 280V +/- 10% |
| (2) Vcc-Gnd : Between pin 1 of FM2 and pin3 of FM1 | DC 15V +/- 10% |
| (3) Vs-Gnd : Between pin 3 of FM2 and pin3 of FM1 | Fluctuation between DC 1.8V to 5.7V |

(Diagnostic results)

All of the above measured values are normal. → Fan motor trouble (Replace the motor.)

Any one of the above measured values is not normal. → Outdoor unit controller trouble
(Replace the controller .)

(Reference) DC motor connector pin arrangement

| Connector No. | Pin |
|---------------|---------------------|
| FM1 | Pin 1: Vm (red) |
| | Pin 2: Not used |
| | Pin 3: Gnd (blue) |
| FM2 | Pin 1: Vcc (brown) |
| | Pin 2: PG (white) |
| | Pin 3: Vsp (orange) |

[Trouble symptom 3] Motor rotates for some time (several seconds), but then quickly stops, when the outdoor unit operates.

(There is trouble in the system that provides feedback of motor rotation speed from the motor to the outdoor unit controller.)

[Trouble symptom 4] Fan motor rotation speed does not change during outdoor unit operation.

[Trouble symptom 5] Fan motor rotation speed varies excessively during outdoor unit operation.

(Remedy for symptom 3 to 5)

It is not possible to identify whether the trouble is outdoor unit controller trouble or motor trouble. Therefore, first replace the outdoor unit controller, then (if necessary) replace the DC motor.

8-5. Noise Malfunction and Electromagnetic Interference

An inverter A/C operates using pulse signal control and high frequencies. Therefore, it is susceptible to the effects of external noise, and is likely to cause electromagnetic interference with nearby wireless devices.

A noise filter is installed for ordinary use, preventing these problems. However, depending on the installation conditions, these effects may still occur. Please pay attention to the points listed below.

(1) Noise malfunction

This refers to the application of high-frequency noise to the signal wires, resulting in abnormal signal pulses and malfunction.

| Locations most susceptible to noise | Trouble | Correction |
|---|--|---|
| <ol style="list-style-type: none"> 1. Locations near broadcast stations where there are strong electromagnetic waves 2. Locations near amateur radio (short wave) stations 3. Locations near electronic sewing machines and arc-welding machines | <p>Either of the following trouble may occur.</p> <ol style="list-style-type: none"> 1. The unit may stop suddenly during operation. 2. Indicator lamps may flicker. | <p>(The fundamental concept is to make the system less susceptible to noise.)</p> <p>- Insulate for noise or distance from the noise source. -</p> <ol style="list-style-type: none"> 1. Use shielded wires. 2. Move unit away from the noise source. |

(2) Electromagnetic interference

This refers to noise generated by high-speed switching of the microcomputer and compressor. This noise radiates through space and returns to the electric wiring, affecting any wireless devices (televisions, radios, etc.) located nearby.

| Locations most susceptible to noise | Trouble | Correction |
|---|--|--|
| <ol style="list-style-type: none"> 1. A television or radio is located near the A/C and A/C wiring. 2. The antenna cable for a television or radio is located close to the A/C and A/C wiring. 3. Locations where television and radio signals are weak. | <ol style="list-style-type: none"> 1. Noise appears in the television picture, or the picture is distorted. 2. Static occurs in the radio sound. | <ol style="list-style-type: none"> 1. Select a separate power source. 2. Keep the A/C and A/C wiring at least 1 meter away from wireless devices and antenna cables. 3. Change the wireless device's antenna to a high-sensitivity antenna. 4. Change the antenna cable to a BS coaxial cable. 5. Use a noise filter (for the wireless device). 6. Use a signal booster. |

9. CHECKING ELECTRICAL COMPONENTS

9-1. Measurement of Insulation Resistance

- The insulation is in good condition if the resistance exceeds 1M ohm.

9-1-1. Power Supply Cord

Clamp the grounding wire of power cord with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on either of the two power wires. (Fig. 1)

Then also measure the resistance between the grounding and other power terminals. (Fig. 1)




Fig. 1

9-1-2. Indoor Unit

Clamp an aluminum plate fin or copper tube with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw on the terminal plate. (Fig. 2)

Note that the ground line terminal should be skipped for the check.




Fig. 2

9-1-3. Outdoor Unit

Clamp a metallic part of the unit with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw where power supply lines are connected on the terminal plate. (Fig. 2)




Fig. 3

9-1-4. Measurement of Insulation Resistance for Electrical Parts

Disconnect the lead wires of the desired electric part from terminal plate, capacitor, etc. Similarly disconnect the connector. Then measure the insulation resistance. (Figs. 3 and 4)

NOTE

Refer to Electric Wiring Diagram.

If the probe cannot enter the poles because the hole is too narrow then use a probe with a thinner pin.




Fig. 4

9-2. Checking Continuity of Fuse on PCB Ass'y

- Remove the PCB Ass'y from the electrical component box. Then pull out the fuse from the PCB Ass'y. (Fig. 5)
- Check for continuity using a multimeter as shown in Fig. 6.




Fig. 5




Fig. 6

10. REFRIGERANT R410A: SPECIAL PRECAUTIONS WHEN SERVICING UNIT

10-1. Characteristics of New Refrigerant R410A

10-1-1. What is New Refrigerant R410A?

R410A is a new refrigerant that contains two types of pseudo-non-azeotropic refrigerant mixture. Its refrigeration capacity and energy efficiency are about the same level as the conventional refrigerant, R22.

10-1-2. Components (mixing proportions)

HFC32 (50%) / HFC125 (50%)

10-1-3. Characteristics

- Less toxic, more chemically stable refrigerant
- The composition of refrigerant R410A changes whether it is in a gaseous phase or liquid phase. Thus, when there is a refrigerant leak the basic performance of the air conditioner may be degraded because of a change in composition of the remaining refrigerant. **Therefore, do not add new refrigerant.** Instead, recover the remaining refrigerant with the refrigerant recovery unit. Then, after evacuation, totally recharge the specified amount of refrigerant with the new refrigerant at its normal mixed composition state (in liquid phase).
- When refrigerant R410A is used, the composition will differ depending on whether it is in gaseous or liquid phase, and the basic performance of the air conditioner will be degraded if it is charged while the refrigerant is in gaseous state. **Thus, always charge the refrigerant while it is in liquid phase.**



CAUTION


Ether-type oil is used for compressor oil for R410A-type units, which is different from the mineral oil used for R22. Thus more attention to moisture prevention and faster replacement work compared with conventional models are required.

10-2. Checklist before Servicing

Use a clutch-type flare tool for R410A or the conventional flare tool. Note that sizes of the resultant flares differ between these two tools. Where a conventional flare tool is used, make sure to observe A Specification (amount of extrusion) by using the flare spacer.

| Diameter of tube D | Specification A | |
|----------------------|-------------------------------|-----------------------------------|
| | Flare tool for R410A | Conventional flare tool (for R22) |
| Dia. 1/4" (6.35 mm) | 0 to 0.0196" (0 to 0.5 mm) | 0.0472" (1.2 mm) |
| Dia. 3/8" (9.52 mm) | | |
| Dia. 1/2" (12.7 mm) | | |
| Dia. 5/8" (15.88 mm) | | |

● Size of flare



● Tubing precautions

- Refrigerant R410A is more easily affected by dust or moisture compared with R22, thus be sure to temporarily cover the ends of the tubing with caps or tape prior to installation.

Never use 0.0276" (0.7 mm)-thick copper tubing or tubing which is less than 0.0315" (0.8 mm) in thickness, since air conditioners with R410A are subject to higher pressure than those using R22 and R407C.

● No addition of compressor oil for R410A

No additional charge of compressor oil is permitted.

● No use of refrigerant other than R410A

Never use a refrigerant other than R410A.

● If refrigerant R410A is exposed to fire

Through welding, etc., toxic gas may be released when R410A refrigerant is exposed to fire. Therefore, be sure to provide ample ventilation during installation work.

● Caution in case of R410A leak

Check for possible leak points with the special leak detector for R410A. If a leak occurs inside the room, immediately provide thorough ventilation.

10-3. Tools Specifically for R410A

- For servicing, use the following tools for R410A

| Tool Distinction | Tool Name |
|--|---|
| Tools specifically for R410A | <ul style="list-style-type: none"> ● Gauge manifold ● Charging hose ● Gas leak detector ● Refrigerant cylinder ● Charging cylinder ● Refrigerant recovery unit ● Vacuum pump with anti-reverse flow (*1) (Solenoid valve-installed type, which prevents oil from flowing back into the unit when the power is off, is recommended.) ● Vacuum pump (*2)...can be used if the following adapter is attached. ● Vacuum pump adapter (reverse-flow prevention adapter) (*3). (Solenoid valve-installed adapter attached to a conventional vacuum pump.) ● Electronic scale for charging refrigerant ● Flare tool |
| Tools which can be commonly used for R22, R407C, and R410A | <ul style="list-style-type: none"> ● Bender ● Torque wrench ● Cutter, reamer ● Welding tool, nitrogen gas cylinder |



CAUTION

- The above tools specifically for R410A must not be used for R22 and R407C. Doing so will cause malfunction of the unit.
- For the above vacuum pump (*1, *2) and vacuum pump adapter (*3), those for R22-type units can be used for R410A-type. However, they must be used exclusively for R410A and never alternately with R22 and R407C.
- To prevent other refrigerants (R22, R407C) from being mistakenly charged to this unit, shape and external diameter of the service port screw has been altered.
 <External diameter of service port> R410A : 5/16"
 R22, R407C : 1/4"

10-4. Tubing Installation Procedures

When the tubes are connected, **always apply HAB oil on the flare portions to improve the sealing of tubing.**

The following is the **HAB oil** generally used:

Esso: ZERICE S32

NOTE For details on tubing installation procedures, refer to the installation manuals attached to the indoor unit and outdoor unit.

10-5. In Case of Compressor Malfunction



CAUTION

- Should the compressor malfunction, be sure to make the switch to a replacement compressor as quickly as possible.
- Use only the tools indicated exclusively for R410A. → See "10-3. Tools Specifically for R410A."

10-5-1. Procedure for Replacing Compressor

(1) Recovering refrigerant

- Any remaining refrigerant inside the unit should not be released to the atmosphere, but recovered using the refrigerant recovery unit for R410A.
- Do not reuse the recovered refrigerant, since it will contain impurities.

(2) Replacing Compressor


- Soon after removing seals of both discharge and suction tubes of the new compressor, replace it quickly.

(3) Checking for sealing

- Use nitrogen gas for the pressurized gas, and never use a refrigerant other than R410A. Also do not use oxygen or any flammable gas.

(4) Evacuation

- **Use a solenoid valve-installed vacuum pump** so that even if power is cut off in the middle of evacuation of air due to a power interruption, the valve will prevent the pump oil from flowing back.
- The equipment may be damaged if moisture remains in the tubing, thus carry out the evacuation thoroughly.
- When using a vacuum pump with exhaust air volume more than 0.883 cu.ft./min. and ultimate vacuum pressure rate of 50 micron Hg.



Standard time for evacuation

| Length of tubing | Less than 33 ft. (10 m) | More than 33 ft. (10 m) |
|------------------|-------------------------|-------------------------|
| Evacuation time | More than 10 minutes | More than 15 minutes |

(5) Recharging

- **Be sure to charge the specified amount of refrigerant in liquid state** using the service port of the wide tube service valve. The proper amount is listed on the unit's nameplate.

When the entire amount cannot be charged all at once, charge gradually while operating the unit in Cooling Operation.



CAUTION

Never charge a large amount of liquid refrigerant at once to the unit. This may cause damage to the compressor.

- When charging with a refrigerant cylinder, use an electronic scale for charging refrigerant. In this case, if the volume of refrigerant in the cylinder becomes less than 20% of the fully-charged amount, the composition of the refrigerant starts to change. Thus, **do not use the refrigerant if the amount in the charging cylinder is less than 20%.**

Also, charge the minimum necessary amount to the charging cylinder before using it to charge the air conditioning unit.

Example:

In case of charging refrigerant to a unit requiring 1.68 lb. (0.76 Kg) using a capacity of a 22 lb. (10 Kg) cylinder, the minimum necessary amount for the cylinder is:

$$1.68 + 22 \times 0.20 = 6.08 \text{ lb.}$$

$$(0.76 + 10 \times 0.20 = 2.76 \text{ Kg})$$

- **For the remaining refrigerant, refer to the instructions of the refrigerant manufacturer.**

If using a charging cylinder, transfer the specified amount of liquid refrigerant from the refrigerant cylinder to the charging cylinder.

Prepare an evacuated charging cylinder beforehand.




CAUTION

- **To prevent the composition of R410A from changing, never bleed the refrigerant gas into the atmosphere while transferring the refrigerant. (Fig. 3)**

Do not use the refrigerant if the amount in the charging cylinder is less than 20%.


Configuration and characteristics of cylinders



Single valve

Charge liquid refrigerant with cylinder in up-side-down position.

Fig. 1



Single valve (with siphon tube)

Charge with cylinder in normal position.

Fig. 2




Fig. 3

10-6. In Case Refrigerant is Leaking



CAUTION

Never attempt to charge additional refrigerant when refrigerant has been leaking from the unit. Follow the procedure described below to locate points of leaks and carry out repairs, then recharge the refrigerant.

(1) Detecting Leaks

- Use the detector for R410A to locate refrigerant leak points.

(2) Recovering refrigerant

- Never release the gas to the atmosphere; recover residual refrigerant using the refrigerant recovery unit for R410A, instead.
- Do not reuse the recovered refrigerant because its composition will have been altered.

(3) Welding leaking points

- Confirm again that no residual refrigerant exists in the unit before starting welding.
- Weld securely using flux and wax for R410A.
- Prevent oxide film from forming inside the tubes utilizing substitution with nitrogen (N₂) in the refrigerant circuit of the unit. Leave ends of tubes open during welding.

(4) Checking for sealing

- Use nitrogen gas for the pressurized gas, and never use a refrigerant other than R410A. Also do not use oxygen or any flammable gas.

(5) Evacuation


- **Use a solenoid valve-installed vacuum pump** so that even if power is cut off in the middle of evacuation of air due to a power interruption, the valve will prevent the pump oil from flowing back.
- The equipment may be damaged if moisture remains in the tubing, thus carry out the evacuation thoroughly.
- When using a vacuum pump with exhaust air volume more than 0.883 cu.ft./min. and ultimate vacuum pressure rate of 50 micron Hg.

Standard time for evacuation

| Length of tubing | Less than 33 ft. (10 m) | More than 33 ft. (10 m) |
|------------------|-------------------------|-------------------------|
| Evacuation time | More than 10 minutes | More than 15 minutes |

(6) Recharging

- Recharge unit in the same manner explained on the previous page "(5) Recharging."



10-7. Charging Additional Refrigerant

10-7-1. When Tubes are Extended

- Observe the proper amount of refrigerant as stated in this service manual or the installation manual that came with the indoor unit. **Charge additional refrigerant in liquid state only.**



CAUTION

Never charge additional refrigerant if refrigerant is leaking from the unit. Follow instructions given in "10-6. In Case Refrigerant is Leaking" and completely carry out repairs. Only then should you recharge the refrigerant.

10-8. Retro-Fitting Existing Systems

10-8-1. Use of Existing Units

- **Never use new refrigerant R410A for existing units which use R22.** This will cause the air conditioner to operate improperly and may result in a hazardous condition.

10-8-2. Use of Existing Tubing

- If replacing an older unit that used refrigerant R22 with a R410A unit, **do not use its existing tubing.** Instead, completely new tubing must be used.

APPENDIX A INSTRUCTION MANUAL

KS3082 + C3082

KS3682 + C3682

(OI-852-6-4181-150-00-0)

KS3082

KS3682

COOL/DRY Model

SANYO

INSTRUCTION MANUAL

Inverter-Controlled Split System Air Conditioner

EG

MODE D'EMPLOI

Climatiseur de type séparé contrôlé par inverseur

F

**This air conditioner uses
the new refrigerant R410A.**

**Save These Instructions!
Conserver ce mode d'emploi**

Pub. OI-85264181150000

© SANYO 2010

Download from Www.Somanuals.com. All Manuals Search And Download.

FEATURES

This air conditioner is an inverter type unit that automatically adjusts capability as appropriate. Details on these functions are provided below; refer to these descriptions when using the air conditioner.

- **Microprocessor Controlled Operation**
The interior compartment of the remote control unit contains several features to facilitate automatic operation, easy logically displayed for easy use.
- **Simple One-touch Wireless Remote Control**
The remote control unit has several features to facilitate automatic operation.
- **24-Hour ON or OFF Timer**
This timer can be set to automatically turn the unit on or off at any time within a 24 hour period.
- **1-Hour OFF Timer**
This timer can be set to automatically turn off the unit at any time after one hour.
- **Night Setback**
This function saves energy by controlling operation to provide a quieter operating sound than normal.
- **Automatic and 3-step Fan Speed**
Auto/High/Medium/Low
- **Air Sweep Control**
This function moves a flap up and down in the air outlet, directing air in a sweeping motion around the room and providing comfort in every corner.
- **Auto. Flap Control**
This automatically sets the flap to the optimum position during cooling and drying operation.
- **Automatic Restart Function for Power Failure**
Even when power failure occurs, preset programmed operation can be reactivated once power resumes.
- **High Power Operation**
The unit operates at maximum output for 30 minutes, regardless of the desired temperature. The fan speed is 1 step above "High".
- **Quiet Operation**
The fan rotates slower than the fan speed setting to provide a quieter operating sound.
- **LED Clean Operation**
During operation, the UV anti-bacteria unit is activated for 30 minutes and cleans the air blown from the air conditioner.
- **Anti-Mold Filter**
This unit is equipped with an anti-mold filter that inhibits the growth of mold and bacteria.
- **Air Clean Filter**
An air filter that eliminates unpleasant odors and cleans the air is available. Purchase a replacement filter at your local dealer. (model **STK-FDXB**)
- **Unoccupied**
This function prevents the room temperature from increasing too much when no one is in the room, and operate automatically to save energy.

CONTENTS

| | Page | | Page |
|--|------|---|------|
| FEATURES | 2 | SPECIAL REMARKS | 12 |
| PRODUCT INFORMATION | 3 | SETTING THE TIMER | 12 |
| ALERT SYMBOLS | 3 | USING THE 1-HOUR OFF TIMER | 14 |
| INSTALLATION LOCATION | 3 | TIPS FOR ENERGY SAVING | 14 |
| ELECTRICAL REQUIREMENTS | 3 | ADJUSTING THE AIRFLOW DIRECTION | 14 |
| SAFETY INSTRUCTIONS | 3 | OPERATION WITHOUT THE REMOTE CONTROL UNIT | 15 |
| NAMES OF PARTS | 4 | CARE AND CLEANING | 15 |
| USING THE REMOTE CONTROL UNIT | 8 | TROUBLESHOOTING | 17 |
| OPERATION WITH THE REMOTE CONTROL UNIT | 9 | OPERATING RANGE | 17 |
| 1. Operation | 9 | WIRED REMOTE CONTROLLER | 17 |
| 2. Adjusting the Fan Speed | 9 | | |
| 3. Fan Only | 9 | | |
| 4. Night Setback Mode | 10 | | |
| 5. QUIET Mode | 10 | | |
| 6. HIGH POWER Mode | 10 | | |
| 7. LED CLEAN Mode | 11 | | |
| 8. UNOCCUPIED Mode | 11 | | |

PRODUCT INFORMATION

If you have problems or questions concerning your Air Conditioner, you will need the following information. Model and serial numbers are on the nameplate on the bottom of the cabinet.

Model No. _____

Serial No. _____

Date of purchase _____

Dealer's address _____

Phone number _____

ALERT SYMBOLS

The following symbols used in this manual, alert you to potentially dangerous conditions to users, service personnel or the appliance:



WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

INSTALLATION LOCATION

- We recommend that this air conditioner be installed properly by qualified installation technicians in accordance with the Installation Instructions provided with the unit.
- Before installation, check that the voltage of the electric supply in your home or office is the same as the voltage shown on the nameplate.



WARNING

- Do not install this air conditioner where there are fumes or flammable gases, or in an extremely humid space such as a greenhouse.
- Do not install the air conditioner where excessively high heat-generating objects are placed.

Avoid:

To protect the air conditioner from heavy corrosion, avoid installing the outdoor unit where salty sea water can splash directly onto it or in sulphurous air near a spa.

ELECTRICAL REQUIREMENTS

1. All wiring must conform to the local electrical codes. Consult your dealer or a qualified electrician for details.
2. Each unit must be properly grounded with a ground (or earth) wire or through the supply wiring.
3. Wiring must be done by a qualified electrician.

SAFETY INSTRUCTIONS

- Read this Instruction Manual carefully before using this air conditioner. If you still have any difficulties or problems, consult your dealer for help.
- This air conditioner is designed to give you comfortable room conditions. Use this only for its intended purpose as described in this Instruction Manual.



WARNING

- Never use or store gasoline or other flammable vapor or liquid near the air conditioner — it is very dangerous.
- This air conditioner has no ventilator for intaking fresh air from outdoors. You must open doors or windows frequently when you use gas or oil heating appliances in the same room, which consume a lot of oxygen from the air. Otherwise there is a risk of suffocation in an extreme case.




CAUTION

- Do not turn the air conditioner on and off from the power mains switch. Use the ON/OFF operation button.
- Do not stick anything into the air outlet of the outdoor unit. This is dangerous because the fan is rotating at high speed.
- Do not let children play with the air conditioner.
- Do not cool the room too much if babies or invalids are present.

EG

NAMES OF PARTS




NOTE

This illustration is based on the external view of a standard model. Consequently, the shape may differ from that of the air conditioner which you have selected.

This air conditioner consists of an indoor unit and an outdoor unit. You can control the air conditioner with the remote control unit.

| | |
|----------------------------------|--|
| Air Intake | Air from the room is drawn into this section and passes through air filters which remove dust. |
| Air Outlet | Conditioned air is blown out of the air conditioner through the air outlet. |
| Remote Control Unit | The wireless remote control unit controls power ON/OFF, operation mode selection, temperature, fan speed, timer setting, and air sweeping. |
| Refrigerant Tubes | The indoor and outdoor units are connected by copper tubes through which refrigerant gas flows. |
| Drain Hose | Moisture in the room condenses and drains off through this hose. |
| Outdoor (Condensing) Unit | The outdoor unit contains the compressor, fan motor, heat exchanger coil, and other electrical components. |

UNIT DISPLAY AND OPERATION BUTTON



IMPORTANT

Avoid using radio equipment such as mobile phone near (within 4 ft. (1.2 m)) the remote control receiver. Some radio equipment may cause malfunction of the unit.


If the trouble happens, disconnect power and restart the air conditioner after a few minutes.

| | |
|--------------------------------|---|
| REMOTE CONTROL receiver | This section picks up infrared signals from the remote control unit (transmitter). |
| OPERATION button | When the remote control unit cannot be used, pressing this button enables cooling operation. Each time this button is pressed, the operation mode changes cyclically. Cooling operation → Stop ↑ |
| OPERATION lamp | This lamp lights when the system is in the continuous DRY (orange), COOL (green) and FAN (green) mode. |
| TIMER lamp | This lamp lights when the system is being controlled by the timer. |
| LED CLEAN lamp | This lamp lights during operation in the UV anti-bacterial mode. |

NOTE

The unit's display lamps are dimmed during operation in the NIGHT SETBACK mode.




REMOTE CONTROL UNIT (DISPLAY)







EG

Symbols


(1) Operation mode

- MILD DRY 
- COOL 
- FAN 





(2) Fan speed

- Automatic operation 
- HIGH 
- MEDIUM 
- LOW 

(3) Temperature setting

- 60 – 86 °F
- When set to 80 °F
- temperature indication 

(4) Timer

- 24-hour clock with ON/OFF program Timer 
- ON Timer. 
- OFF Timer. 
- 1-hour OFF Timer. 

(5) NIGHT SETBACK.....



(6) Confirmation of transmission.....



(7) Auto. flap indication.....



Flap angle indication.....



Sweep indication.....



(8) High power operation.....



(9) UNOCCUPIED



(10) Quiet operation




(11) LED CLEAN operation.....



REMOTE CONTROL UNIT

Transmitter

When you press the buttons on the remote control unit, the  mark appears in the display to transmit the setting changes to the receiver in the air conditioner.

Display

Information on the operating conditions is displayed while the remote control unit is switched on. If the unit is turned off, FLAP setting and FAN SPEED setting are not displayed.





LED CLEAN button

LED C: If this button is pressed during DRY, COOL or FAN operation, the UV anti-bacterial unit is activated for 30 minutes and cleans the air blown from the air conditioner.

QUIET button




QUIET: When you press this button, the fan rotates slower than the fan speed setting to provide a quieter operating sound.

FAN SPEED selector button

- : The air conditioner automatically decides the fan speeds.
- : High fan speed
- : Medium fan speed
- : Low fan speed


FLAP button

Press this button either to select the setting of the airflow direction to the auto. flap in each mode or one of the six possible positions manually or to select the sweep function which moves the flap up and down automatically.

- : Auto flap setting: If selected in a cooling or dry operation, the flap is set at position (7) in the following chart.
- : The airflow direction can be set manually. (six positions)
- : The flap moves up and down automatically.

NOTE

When you press the FLAP button, the air flow direction will be changed one by one as follows.




ON TIME/OFF TIME setting buttons




Advance button

Return button

No display: The timer does not operate.


: The air conditioner starts at the set time.

: The air conditioner stops at the set time.

  : The air conditioner stops and starts, or starts and stops, at the set times every day. For details, see "SETTING THE TIMER".

CANCEL button

SENSOR button


When you press this button (use a small-tipped object such as a ballpoint pen), the  mark will appear at the display. And the room temperature is detected by the sensor which is built into the indoor unit and the air conditioner is controlled accordingly.

NOTE

If the remote control unit is located near a heat source, such as a space heater or in direct sunlight, press the SENSOR button to switch to the sensor on the indoor unit.

ADDRESS switch

- The address switch changes to prevent mixing of signals from remote control units when two air conditioners are installed next to each other. Normally, the address switch is set to A. For more information, please contact the dealer where you made the purchase.
- Normally, the tabs on the remote control unit should not be bent.



Temperature display selector button

This switches the temperature display between °C and °F.

Sensor

A temperature sensor inside the remote control unit senses the room temperature.

ON/OFF operation button

This button is for turning the air conditioner on and off.

1 HR. TIMER button (1-HOUR OFF TIMER)

1H. : When you press this button, regardless of whether the unit is operating or stopping, the unit operates for one hour and then shuts down.

Temperature setting buttons (TEMP.)

Press the button to increase the set temperature.

Press the button to reduce the set temperature.

The temperature setting changes by 1 °C or 2 °F each time one of the TEMP. buttons is pressed.

MODE selector button

Use this button to select DRY, COOL or FAN mode.

(DRY) : The air conditioner reduces the humidity in the room.

(COOL) : The air conditioner makes the room cooler.

(FAN) : The air conditioner works only as a circulation fan.

NIGHT SETBACK button

For details, see “4. Night Setback Mode”. When you press this button in the DRY or COOL mode, the mark appears in the display, and the remote control unit will automatically adjust the set temperature to save energy.

HIGH POWER button

: If this button is pressed during DRY, COOL or FAN operation, the unit operates at maximum output for 30 minutes, regardless of the desired temperature. The fan speed is 1step above “HIGH”.


CLOCK button

UNOCCUPIED button

For details, see “8. UNOCCUPIED Mode”. When you press this button, the mark appears in the display. And the remote control unit will automatically prevent the room temperature from increasing too much when no one is in the room.

ACL button (ALL CLEAR)

Puts the remote control unit into pre-operation status. Always press this button after replacing the batteries.




(Cover closed)

NOTE

- The illustration above pictures the remote control unit after the cover has been opened.
- The remote control unit sends the temperature signal to the air conditioner regularly at five minute intervals. If the signal from the remote control unit stops for more than 15 minutes due to the loss of the remote control unit or other trouble, the air conditioner will switch to the temperature sensor which is built into the indoor unit and control the room temperature. In these cases, the temperature around the remote control unit may differ from the temperature detected at the air conditioner's position.
- The indoor fan runs continuously when the system is in normal operation. It does not turn off when the desired room temperature is reached. If Night Set Back mode is selected, the fan will turn off intermittently during cooling operation in order to control air flow.

USING THE REMOTE CONTROL UNIT

HOW TO INSTALL BATTERIES



1. Slide the cover in the direction indicated by the arrow and remove it.
2. Install two AAA alkaline batteries. Make sure the batteries point in the direction marked in the battery compartment.
3. Use a thin object such as the tip of a pen to press the ACL button.


NOTE

- The batteries last about six months, depending on how much you use the remote control unit. Replace the batteries when the remote control unit's display fails to light, or when the remote control unit cannot be used to change the air conditioner's settings.
- Use two fresh leak-proof type-AAA alkaline batteries.
- In replacing batteries, follow the instructions as mentioned in the sub-section "HOW TO INSTALL BATTERIES".
- If you do not use the remote control unit more than 1 month, take out the batteries.
- Dispose of the used batteries at the designated location in compliance with the applicable local ordinances.

HOW TO USE THE REMOTE CONTROL UNIT

When using the remote control unit, always point the unit's transmitter head directly at the air conditioner's receiver.

**Air conditioner
(Indoor unit)**



REMOTE CONTROL UNIT INSTALLATION POSITION


The remote control unit may be operated either from a non-fixed position or from a wall-mounted position. To ensure that the air conditioner operates correctly, DO NOT install the remote control unit in the following places:

DO NOT

- In direct sunlight
- Behind a curtain or other places where it is covered
- More than 26 ft. (8 m) away from the air conditioner
- In the path of the air conditioner's airstream
- Where it may become extremely hot or cold
- Where it may be subject to electrical or magnetic noise
- Where there is an obstacle between the remote control unit and air conditioner (since a check signal is sent from the remote control unit every 5 minutes)

MOUNTING THE REMOTE CONTROL UNIT

Before mounting the remote control unit, press the ON/OFF operation button at the mounting location to make sure that the air conditioner operates from that location. The indoor unit should make a beeping sound to indicate that it has received the signal.



- To prevent loss of the remote control unit, you can connect the remote control unit to the mount by passing a string through the remote control unit and attachment hole.


To take out the remote control unit, pull it forward.

WHEN HOLDING THE REMOTE CONTROL UNIT

- When using the remote control unit and during air conditioner operation, the transmitter on the remote control unit should be pointed towards the receiver on the indoor unit.
- Make sure that there are no objects between the remote control unit and receiver which could block the signal.




OPERATION WITH THE REMOTE CONTROL UNIT

1. Operation



NOTE Check that the circuit breaker on the power panel is turned on.

Press the setting buttons as described below and change the settings as desired.


| | |
|---------------|---|
| STEP 1 | Press the MODE selector button and select the desired mode. For dehumidifying operation →  For cooling operation →  For fan only operation →  |
| STEP 2 | To start the air conditioner, press the ON/OFF operation button. |
| STEP 3 | Press the TEMP. setting buttons to change the temperature setting to the desired temperature. Adjustable temperature range: 30 °C max. or 86 °F max. 16 °C min. 60 °F min. |
| STEP 4 | Set the FAN SPEED selector button to the setting you want. |
| STEP 5 | Press the FLAP button and set the airflow direction as desired. (Refer to "ADJUSTING THE AIRFLOW DIRECTION" on page 14.) |

To stop the air conditioner, press the ON/OFF operation button again.

- NOTE**
- Choose the best position in the room for the remote control unit, which also acts as the sensor for room comfort and transmits the operating instructions. Once you've found this best position, always keep the remote control unit there.
 - This appliance has a built-in 5-minute time delay circuit to ensure reliable operation. When the operation button is pressed, the compressor will start running within three minutes. In the event of power failure, the unit will stop.




2. Adjusting the Fan Speed

A. Automatic fan speed


Simply set the FAN SPEED selector button to the  position.

This automatically sets the best fan speed for the room temperature.





B. Manual fan speed

If you want to adjust fan speed manually during operation, just set the FAN SPEED selector button as desired. [, , or ]


3. Fan Only



If you want to circulate air without any temperature control, follow these steps:

| | |
|---------------|--|
| STEP 1 | Press the MODE selector button to switch to the fan mode  . |
| STEP 2 | Press the ON/OFF operation button. |
| STEP 3 | Press the FAN SPEED selector button to select the fan speed of your choice ( ,  , or ). |

4. Night Setback Mode



Night Setback Mode is used for saving energy.

Press the NIGHT SETBACK button while operation. (except FAN mode)
The ☺ mark appears in the display.


To release the night setback function, press the NIGHT SETBACK button again.

NOTE


Pressing the MODE selector button cancels Night Setback mode.

In Cooling and DRY Mode: (❄️ and 💧)

When the night setback mode is selected, the air conditioner automatically raises the temperature setting 2 °F when 30 minutes have passed after the selection was made, and then another 2 °F after another 30 minutes have passed, regardless of the indoor temperature when night setback was selected. This enables you to save energy without sacrificing comfort. This function is convenient when gentle cooling is needed.



5. QUIET Mode




QUIET Mode is used to reduce the fan sound of the indoor unit.

Press the QUIET button.
The **QUIET** mark appears in the display.

To cancel, press QUIET button again.

- In QUIET Mode, the fan rotates at a slower speed than the fan speed setting.
- If the unit is already operating with a very low airflow, the fan sound may not change even if the QUIET button is pressed.

6. HIGH POWER Mode



HIGH POWER mode can be used to increase the output of the indoor unit for all operation modes.

Press the HIGH POWER button while operation.
The mark appears in the display.


To cancel, press HIGH POWER button again.

- When the HIGH POWER button is pressed, the unit operates at maximum output for 30 minutes, regardless of the desired temperature. The fan speed is 1 step above "High".
- QUIET Mode and HIGH POWER Mode cannot be used at the same time.

NOTE

- Pressing the MODE selector button cancels HIGH POWER mode.
- Depending on the operating conditions, the fan speed may be increased by a small amount only.

7. LED CLEAN Mode



In LED CLEAN mode, a UV anti-bacterial unit (including a LED CLEAN lamp and anti-bacterial filter) in the indoor unit is used during DRY, COOL, or FAN operation to remove bacteria from air blown from the air conditioner.

Press the LED CLEAN button while operation.
The **LED C** mark appears in the display.



To cancel, press the LED CLEAN button again.

- When the LED CLEAN button is pressed, the UV anti-bacterial unit operates for one hour and cleans air blown from the air conditioner.


NOTE

- Pressing the MODE selector button cancels LED CLEAN mode.
- Do not open the front panel while the LED CLEAN lamp on the display is on.
- Depending on the room brightness, light from the LED CLEAN lamp may reflect inside the air conditioner and be visible. This is not a malfunction.

8. UNOCCUPIED Mode





Unoccupied mode is used to prevent the room temperature from increasing too much when no one is in the room, and operate automatically to save energy.

Press the UNOCCUPIED button.
The  mark appears in the display.

To release the unoccupied function, press the UNOCCUPIED button again.

Unoccupied Indication

| Unoccupied Function | Unoccupied Indication | Status |
|---------------------|---|--|
| OFF | no display | The unoccupied function is not set. |
| ON |  flashing | The unoccupied function is now being set, and under Cooling operation. |
| |  lighting | Although the unoccupied function is set, not under Cooling operation. |

NOTE


Even if Unoccupied Mode is ON, it will be disabled if the air conditioner is in operation.

- Unoccupied Function can be set and released through all operational modes, regardless of whether the air conditioner is operating or not.
- If the Unoccupied Function is ON and the remote control unit is used to turn the air conditioner OFF (including OFF TIMER), the air conditioner will turn off, but depending on the room temperature, Cooling Operation will automatically begin.
- When the Unoccupied Function is in operation and the ON/OFF operation button is pressed, operation will restart based on the settings input before the air conditioner was turned off.

In Cooling Mode: (※)

- (1) When the room temperature rises above 89°F, Cooling Operation will begin.
- (2) When the room temperature drops below 82°F, Cooling Operation will stop.

The above actions will repeat so that the room temperature is maintained at about 86°F.



- Unoccupied Mode triggers Cooling Operation in response to the room temperature, but when this happens, the remote control unit will continue to display the Operation mode set by the user.
- If the room temperature rapidly changes, the room temperature may get over the upper or lower limit when the unoccupied function is activated.

NOTE

- The remote control unit should be used in the location specified in "REMOTE CONTROL UNIT INSTALLATION POSITION" on page 8.
- The air conditioner's stop order (stated in (2) / above) is valid only when the unoccupied function is operated.

SPECIAL REMARKS

“DRY” () Operation

How it works?

- Once the room temperature reaches the level that was set, the unit's operation frequency is changed automatically.
- During DRY operation, the fan speed automatically runs at lower speed for providing a comfortable breeze.
- “DRY” operation is not possible if the indoor temperature is 59 °F or less.

Cooling () operation

- Sometimes the indoor unit may not get to the set fan speed such as LOW under cool operation at very low outdoor temperatures due to the indoor unit being protected from ice or frost.

Power failure during operation

- In the event of power failure, the unit will stop. When the power is resumed, the unit will restart automatically in approximately 5 minutes by the remote control unit. If the remote control unit is on and left in a location where the unit can receive a signal, then the unit will automatically restart in approximately 5 minutes of power being restored.

Clicking Sound


Clicking sound is heard from the air conditioner

- In cooling operation, any plastic parts may shrink due to a sudden temperature change. In this event, a clicking sound may occur. This is normal, and the sound will soon disappear.

Remote Control Unit

- The remote control unit sends the setting condition to the air conditioner regularly at five minute intervals.

SETTING THE TIMER





NOTE

In the descriptions below, the following settings are used for the temperature and time indicator selector button on the bottom front section of the remote control unit.

- Temperature: °F
- Time: AM, PM

1. How to set the present time


(Example) To set to 10:30 pm.



| Operation | Indication |
|---|--|
| 1. Press the CLOCK button once if the time indicator is not flashing. | The time indication alone flashes. |
| 2. Press the Advance, Return (▲, ▼) button until PM 10:30 is displayed. | The time can be set in 1-minute increments. Holding down the button advances the time rapidly in 10-minute increments. |
| 3. Press the CLOCK button again. | This completes the setting of the current time. |

2. How to set the OFF time


(Example) To stop the air conditioner at 11:00 am.



| Operation | Indication |
|--|--|
| 1. Press the OFF TIME setting button once. | The timer OFF indication is displayed, and the present OFF time is shown. |
| 2. Press the Advance, Return (▲ , ▼) button until AM 11:00 is displayed. | The timer OFF indication blinks. The time can be set in 10-minute increments. Holding down the button advances the time rapidly in 10-minute increments. |
| 3. Wait a few seconds, and then the setting is complete. | The timer OFF indication stops blinking and the present time is displayed. |

3. How to set the ON time


(Example) To start operation at 7:10 am.



| Operation | Indication |
|---|---|
| 1. Press the ON TIME setting button once. | The timer ON indication is displayed, and the present ON time is shown. |
| 2. Press the Advance, Return (▲ , ▼) button until AM 7:10 is displayed. | The timer ON indication blinks. The time can be set in 10-minute increments. Holding down the button advances the time rapidly in 10-minute increments. |
| 3. Wait a few seconds, and then the setting is complete. | The timer ON indication stops blinking and the present time is displayed. |

4. How to set daily ON/OFF repeat timer

(Example) To start operation at 7:10 am. and stop the air conditioner at 11:00 am.



| Operation | Indication |
|--|--|
| 1. Set the timer ON/OFF times as shown in 2-1, 2, 3 and 3-1, 2, 3. | The present time 10:30 pm. and ON OFF are displayed. |

NOTE

- The ON/OFF combination timer uses the current time as the reference, and it is activated starting from whichever set time comes first.
- With the ON/OFF combination timer, the settings are repeated every day.
- You can check the timer ON/OFF times after you have set them by pressing the ON TIME and OFF TIME setting buttons.

To cancel a timer program


- Press the CANCEL button.
- When either an ON or OFF timer is to be canceled, press the button corresponding to the timer whose program is to be canceled, and then press the CANCEL button.

NOTE

- The airflow direction, fan speed and temperature setting can be changed after a timer program has been set even when the unit is stopped. Even when operation is stopped during an ON timer program, the unit will start operating when the set time is reached provided that the program is not canceled.
- When the ON timer and OFF timer are set to the same time, the timer operates as if it is turned off.

USING THE 1-HOUR OFF TIMER

1. 1-Hour OFF Timer



This function causes the unit to operate for one hour and then stop, regardless of whether the unit is on or off when this button is pressed.

The **1H** indicator in the display indicates that this function is operating.

Setting procedure:

Regardless of whether the unit is operating or stopped, press the 1 HR. TIMER button.

1H appears in the display.

Cancellation procedure:

Press the ON/OFF operation button to turn the unit off, wait for the unit to stop operating, and then press the ON/OFF operation button again.

The 1-Hour Timer function is now cancelled and the unit operates normally.

NOTE

- If, while the 1-Hour Timer function is operating, the 1HR. TIMER button is pressed once to cancel the function and then again, the unit continues to operate for one hour from that point in time and then stops.
- It is not possible to use the OFF Timer and 1-Hour OFF Timer together. Whichever function is set last takes precedence. If the 1 HR. TIMER button is pressed while the TIMER OFF function operates, the OFF Timer is cancelled and the unit will stop operating one hour later.

2. Operation together with the daily ON/OFF repeat timer

The 1-Hour OFF Timer setting is given priority over the DAILY ON/OFF REPEAT setting.

TIPS FOR ENERGY SAVING

Do not

- **Block the air intake and outlet of the unit. If they are obstructed, the unit will not work well, and may be damaged.**
- Let direct sunlight into the room. Use sunshades, blinds or curtains. If the walls and ceiling of the room are warmed by the sun, it will take longer to cool the room.


Do

- Always try to keep the air filter clean. (Refer to "CARE AND CLEANING".) A clogged filter will impair the performance of the unit.
- To prevent conditioned air from escaping, keep windows, doors and any other openings closed.

ADJUSTING THE AIRFLOW DIRECTION

1. Horizontal

The horizontal airflow can be adjusted by moving the vertical vanes with your hands to the left or right.





CAUTION

When the humidity is high, the vertical vanes should be in the front position during the cooling or dehumidifying operation. If the vertical vanes are positioned all of the way to the right or left, condensation may begin to form around the air vent and drip down.

2. Vertical

The vertical airflow can be adjusted by moving the flap with the remote control unit. Do not move the flap with your hands. Confirm that the remote control unit has been turned on. Use the FLAP button to set either the sweep function or one of the six airflow direction settings.



A. Sweep function




The flap starts moving up and down to deliver air over the sweep range.

B. Setting the airflow manually



Referring to the above illustration, use the FLAP button to set the airflow direction within the range used during cooling or dehumidifying operation.



C. Auto flap function



The flap is set to the recommended position.


NOTE

- The flap automatically closes when the unit is off.

**CAUTION**

- Use the **FLAP** button on the remote control to adjust the position of the flap. If you move the flap by hand, the flap position according to the remote control and the actual flap position may no longer match. If this should happen, shut off the unit, wait for the flap to close, and then turn on the unit again; the flap position will now be normal again.
- Do not have the flap pointed down during cooling operation. Condensation may begin to form around the air vent and drip down.

OPERATION WITHOUT THE REMOTE CONTROL UNIT

INDOOR UNIT

If you have lost the remote control unit or it has trouble, follow the steps below.

When the air conditioner is not running

Each time the **OPERATION** button is pressed, the operation mode changes cyclically.

**NOTE**

The temperature is set to the room temperature minus 4°F during the cooling operation, and the fan speed and flap are set to Auto.

CARE AND CLEANING

**WARNING**

1. For safety, be sure to turn the air conditioner off and also to disconnect the power before cleaning.
2. Do not pour water on the indoor unit to clean it. This will damage the internal components and cause an electric shock hazard.

Casing and Grille (Indoor Unit)

Clean the casing and grille of the indoor unit with a vacuum cleaner brush, or wipe them with a clean, soft cloth.

If these parts are stained, use a clean cloth moistened with a mild liquid detergent. When cleaning the grille, be careful not to force the vanes out of place.

**CAUTION**


1. Never use solvents, or harsh chemicals when cleaning the indoor unit. Do not wipe the plastic casing using very hot water.
2. Some metal edges and the fins are sharp and may cause injury if handled improperly; be especially careful when you clean these parts.
3. The internal coil and other components of the outdoor unit must be cleaned every year. Consult your dealer or service center.

Anti-Mold Filter

The anti-mold filter behind the front panel should be checked and cleaned at least once every two weeks.

How to remove the anti-mold filter

1. Grasp both ends of the front panel and pull forward and up to open the front panel.




2. Lift the anti-mold filter up slightly to disengage it from the protrusions on the unit.
3. Pull downward to remove the filter from the unit.

Cleaning

Use a vacuum cleaner to remove light dust. If there is sticky dust on the filter, wash the filter in lukewarm, soapy water, rinse it in clean water, and dry it.

How to replace the anti-mold filter

1. Insert the top of the anti-mold filter, and then secure the bottom of the filter with the protrusions on the unit.
2. Close the front panel by pushing the center of the front panel and then pressing both edges until the panel clicks into place.

**Air Clean Filter**


The air clean filter removes dust and dirt from the air, and reduces odors and smoke from tobacco.

**WARNING**

This air clean filter cannot remove harmful gases or vapors nor ventilate air in the room. You must open doors or windows frequently when you use gas or oil heating appliances. Otherwise there is a risk of suffocation in extreme cases.

How to install the air clean filter

The air clean filter needs to be installed behind the anti-mold filter.



1. Open the front panel and remove the anti-mold filter.
2. Remove the air filter holder from the anti-mold filter.
3. Install the air clean filter in the air filter holder.
4. Install the air filter holder to the anti-mold filter, remount the anti-mold filter, and close the front panel.

How to clean the air clean filter

- In general, the filter should be sucked to remove dust in low fan speed of a vacuum cleaner once every three months.
- If there is heavily grime on the filter, soak the filter in lukewarm water with neutral detergent diluted 1:500 for 1 to 2 minutes then wash it.
- Rinse the filter in clean water, then let it dry on the towel in room temperature.

NOTE

- Do not bend nor give excessive force onto the air clean filter.
- If the filter surface is heavily blocked with dirt or damaged, replace it with new one. Purchase a replacement filter at your local dealer. (model **STK-FDXB**)

Cleaning the main unit and remote control unit


- Wipe clean using a soft, dry cloth.
- To remove stubborn dirt, moisten a cloth in warm water no hotter than 104 °F, wring thoroughly, and then wipe.
- The front panel can be removed in order to wash it with water.

Removing and remounting the front panel**Removing**

Open the front panel until it is nearly horizontal, grasp the sections near the front panel arms on both sides, and then remove the panel by pushing the arms towards the outside while pulling the panel towards you.

If the front panel is difficult to remove, grasp both ends of it and lift it up slightly.

Move it to the left and disengage the left arm, then move it to the right and disengage the right arm.

**Remounting**

Grasp the sections near the front panel arms on both sides, and hold the front panel so that it is nearly horizontal. Push the arm shafts towards the outside so that they come into contact with the top of the indentations on the right and left sides of the air conditioner. Then push firmly until the arm shafts click into place. After closing the front panel, press firmly on the parts indicated by the arrows to securely fasten the panel in place. Also refer to the figure that shows "How to replace the anti-mold filter".

**CAUTION**

When using a footstool or the like, be careful not to let it tip over.

Washing the front panel with water

- Clean the front panel gently using a soft sponge, or the like. Then wipe away any remaining moisture.
- Neutral detergent may be used to remove stubborn dirt. Then rinse thoroughly with water and wipe away any remaining moisture.

TROUBLESHOOTING

If your air conditioner does not work properly, first check the following points before requesting service. If it still does not work properly, contact your dealer or service center.

| Trouble | Possible Cause | Remedy |
|---|--|---|
| Air conditioner does not run at all. | <ol style="list-style-type: none"> 1. Power failure. 2. Leakage circuit breaker tripped. 3. Line voltage is too low. 4. Batteries in remote control unit have run down. | <ol style="list-style-type: none"> 1. Restore power. 2. Contact service center. 3. Consult your electrician or dealer. 4. Replace batteries. |
| OPERATION lamp blinks and air conditioner does not operate. | Trouble in system. | Contact service center. |
| Compressor runs but soon stops. | Obstruction in front of condenser coil. | Remove obstruction. |
| Poor cooling performance. | <ol style="list-style-type: none"> 1. Dirty or clogged air filter. 2. Heat source or many people in room. 3. Doors and/or windows are open. 4. Obstacle near air intake or air discharge port. 5. Thermostat is set too high for cooling. | <ol style="list-style-type: none"> 1. Clean air filter to improve airflow. 2. Eliminate heat source if possible. 3. Shut them to keep the heat out. 4. Remove it to ensure good airflow. 5. Set the temperature lower. |
| Clicking sound is heard from the air conditioner. | In cooling operation, any plastic parts may shrink due to a sudden temperature change. In this event, a clicking sound may occur. | This is normal, and the sound will soon disappear. |
| OPERATION lamp lights but outdoor unit will not run. | The use of cellular phones near the air conditioner may cause disturbance to its normal operation. | <ol style="list-style-type: none"> 1. Turn off the power then restart the air conditioner after a while. 2. Consult your dealer. |

OPERATING RANGE

The air conditioner is operable within the temperature ranges as listed below:

| | Temperature | Indoor air temperature | Outdoor air temperature |
|---------|-------------|------------------------|-------------------------|
| COOLING | Max. | 95 °F DB / 71 °F WB | 115 °F DB |
| | Min. | 67 °F DB / 57 °F WB | 0 °F DB |

WIRED REMOTE CONTROLLER

A separately sold wired remote controller (STK-RCS-7TWSUA) used with this air conditioner is also available. If you wish to use the wired remote control function, you will need to purchase both the optional wired remote controller and its connection kit (STK-KCW2).

EG

APPENDIX B INSTALLATION INSTRUCTIONS

KS3082 + C3082

KS3682 + C3682

(II-852-6-4190-499-00-0)

– Inverter Split System Air Conditioner –

COOL/DRY Model

This air conditioner uses the new refrigerant R410A.

NOTE Refrigerant service valve size = 5/16"

Contents

| | Page |
|---|-----------|
| IMPORTANT! | |
| Please Read Before Starting | 2 |
| 1. GENERAL | 3 |
| 1-1. Tools Required for Installation (not supplied) | |
| 1-2. Accessories Supplied with Unit | |
| 1-3. Optional Copper Tubing Kit | |
| 1-4. Type of Copper Tube and Insulation Material | |
| 1-5. Additional Materials Required for Installation | |
| 2. INSTALLATION SITE SELECTION | 4 |
| 2-1. Indoor Unit | |
| 2-2. Outdoor Unit | |
| 3. HOW TO INSTALL THE INDOOR UNIT | 12 |
| 3-1. Remove the Rear Panel from the Unit | |
| 3-2. Make a Hole | |
| 3-3. Install the Rear Panel on the Wall | |
| 3-4. Removing and Installing the Grille | |
| 3-5. Shape the Indoor Side Tubing | |
| 3-6. Wiring Instructions | |
| 3-7. Wire Size and Length | |
| 3-8. Wiring Instructions for Inter-unit Connections | |
| 3-9. Mounting | |
| 3-10. Frame Fastening Method | |
| 3-11. Drain Hose | |
| 4. HOW TO INSTALL THE OUTDOOR UNIT | 22 |
| 4-1. Wiring Instructions for the Outdoor Unit | |
| 4-2. Routing the Tubing and Wiring | |
| 5. REFRIGERANT TUBING | 23 |
| 5-1. Use of the Flaring Method | |
| 5-2. Flaring Procedure with a Flare Tool | |
| 5-3. Caution before Connecting Tubes Tightly | |
| 5-4. Connecting Tubing between Indoor and Outdoor Units | |
| 5-5. Insulation of Refrigerant Tubing | |
| 5-6. Taping the Tubes | |
| 5-7. Finishing the Installation | |
| 6. AIR PURGING | 25 |
| ■ Air Purging with a Vacuum Pump (for Test Run) | |
| ■ Basic Functions of the Service Valves | |
| ■ Pump Down | |
| ■ Service Valve Connections | |

Model Combinations

Combine indoor and outdoor units only as listed below.

| <u>Indoor Unit</u> | <u>Outdoor Unit</u> |
|--------------------|---------------------|
| KS3082 _____ | C3082 |
| KS3682 _____ | C3682 |

Power Source:
60 Hz, single-phase, 230/208 V

Be sure to read the yellow instruction sheet attached to the outdoor unit for models using the new refrigerant R410A.

| | |
|---|-----------|
| 7. REMOTE CONTROL UNIT INSTALLATION POSITION | 29 |
| 7-1. Mounting on a Wall | |
| 8. ADDRESS SWITCH | 30 |
| 8-1. Address Setting of the Remote Control Unit | |

NOTE

The illustrations are based on the typical appearance of a standard model. Consequently, the shape may differ from that of the air conditioner that you are installing.

SANYO North America Corporation
Commercial Solutions Division
2055 Sanyo Ave., San Diego
CA 92154, U.S.A.

In Canada
SANYO Canada Inc.
201 Creditview Road, Woodbridge
Ontario, L4L 9T1, Canada

IMPORTANT!

Please Read Before Starting

This air conditioning system meets strict safety and operating standards. As the installer or service person, it is an important part of your job to install or service the system so it operates safely and efficiently.

For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning.
- Follow each installation or repair step exactly as shown.
- Observe all local, state, and national electrical codes.
- Pay close attention to all warning and caution notices given in this manual.



WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If Necessary, Get Help

These instructions are all you need for most installation sites and maintenance conditions. If you require help for a special problem, contact our sales/service outlet or your certified dealer for additional instructions.

In Case of Improper Installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

SPECIAL PRECAUTIONS

WARNING

When Wiring



ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause **accidental injury or death**.
- **Ground the unit** following local electrical codes.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.

When Transporting

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminum fins on the air conditioner can cut your fingers.

When Installing...

...In a Ceiling or Wall

Make sure the ceiling/wall is strong enough to hold the unit's weight. It may be necessary to construct a strong wood or metal frame to provide added support.

...In a Room

Properly insulate any tubing run inside a room to prevent "sweating" that can cause dripping and water damage to walls and floors.

...In Moist or Uneven Locations

Use a raised concrete pad or concrete blocks to provide a solid, level foundation for the outdoor unit. This prevents water damage and abnormal vibration.

...In an Area with High Winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

...In a Snowy Area

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

When Connecting Refrigerant Tubing

- Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them, then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.

When Servicing

- Turn the power OFF at the main power box (mains) before opening the unit to check or repair electrical parts and wiring.
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after you finish, remembering to check that no metal scraps or bits of wiring have been left inside the unit being serviced.



CAUTION

Others

- Ventilate any enclosed areas when installing or testing the refrigeration system. Escaped refrigerant gas, on contact with fire or heat, can produce dangerously toxic gas.
- Confirm upon completing installation that no refrigerant gas is leaking. If escaped gas comes in contact with a stove, gas water heater, electric room heater or other heat source, it can produce dangerously toxic gas.

1. General

This booklet briefly outlines where and how to install the air conditioning system. Please read over the entire set of instructions for the indoor and outdoor units and make sure all accessory parts listed are with the system before beginning.










1-1. Tools Required for Installation (not supplied)

1. Standard screwdriver
2. Phillips head screwdriver
3. Knife or wire stripper
4. Tape measure
5. Carpenter's level

6. Sabre saw or key hole saw
7. Hacksaw
8. Core bits
9. Hammer
10. Drill
11. Tube cutter
12. Tube flaring tool
13. Torque wrench
14. Adjustable wrench
15. Reamer (for deburring)

1-2. Accessories Supplied with Unit

Table 1

| Parts | Figure | Q'ty | Parts | Figure | Q'ty | Parts | Figure | Q'ty |
|----------------------------|---|------|------------------|---|------|--------------------|---|------|
| Remote control unit |  | 1 | Air clean filter |  | 2 | Rawl plug |  | 8 |
| Remote control unit holder |  | 1 | Tapping screw |  Truss-head Phillips 5/32 x 5/8" (4x16 mm) | 10 | Drain hose adapter |  | 1 |
| AAA alkaline battery |  | 2 | Tapping screw |  Truss-head Phillips 5/32 x 13/32" (4x10 mm) | 2 | Flare insulation |  | 1 |

1-3. Optional Copper Tubing Kit

Copper tubing for connecting the outdoor unit to the indoor unit is available in kits which contain the narrow and wide tubing, fittings and insulation. Consult your nearest sales outlet or air conditioning workshop.

1-4. Type of Copper Tube and Insulation Material

If you wish to purchase these materials separately from a local source, you will need:

1. Deoxidized annealed copper tube for refrigerant tubing as detailed in Table 2.
Cut each tube to the appropriate lengths 1' to 1'4" (30 cm to 40 cm) to dampen vibration between units.

2. Foamed polyethylene insulation for the specified copper tubes as required to precise length of tubing. Wall thickness of the insulation should be not less than 5/16" (8 mm).
3. Use insulated copper wire for field wiring. Wire size varies with the total length of wiring. Refer to 3-6. Wiring Instructions for details.



CAUTION

Check local electrical codes and regulations before obtaining wire. Also, check any specified instructions or limitations.

Table 2

| Model | Narrow Tube | | Wide Tube | |
|--------|----------------|------------------|-----------------|------------------|
| | Outer Dia. | Thickness | Outer Dia. | Thickness |
| KS3082 | 3/8" (9.52 mm) | 0.0314" (0.8 mm) | 5/8" (15.88 mm) | 0.0393" (1.0 mm) |
| KS3682 | 3/8" (9.52 mm) | 0.0314" (0.8 mm) | 5/8" (15.88 mm) | 0.0393" (1.0 mm) |

1-5. Additional Materials Required for Installation

1. Refrigeration (armored) tape
2. Insulated staples or clamps for connecting wire
(See local codes.)
3. Putty
4. Refrigeration lubricant
5. Clamps or saddles to secure refrigerant tubing

2. Installation Site Selection

2-1. Indoor Unit



WARNING

To prevent abnormal heat generation and the possibility of fire, do not place obstacles, enclosures and grilles in front of or surrounding the air conditioner in a way that may block air flow.

AVOID:

- direct sunlight.
- nearby heat sources that may affect performance of the unit.
- areas where leakage of flammable gas may be expected.
- places where large amounts of oil mist exist.

DO:

- select an appropriate position from which every corner of the room can be uniformly cooled. (High on a wall is best.)
- select a location that will hold the weight of the unit.
- select a location where tubing and drain hose have the shortest run to the outside. (Fig. 1)
- allow room for operation and maintenance as well as unrestricted air flow around the unit. (Fig. 2)
- install the unit within the maximum elevation difference (H) above or below the outdoor unit and within the maximum tubing length (L) from the outdoor unit as detailed in Table 3 and Fig. 3a.
- install the indoor unit more than 3.3' (1 m) away from any antenna or power lines or connecting wires used for television, radio, telephone, security system, or intercom. Electrical noise from any of these sources may affect operation.





Fig. 1



Front View

Fig. 2




Fig. 3a



CAUTION

For stable operation of the air conditioner, do not install wall-mounted type indoor units less than 5' (1.5 m) from floor level.




Fig. 3b

Table 3

| Model | Charge-less Tubing Length (Actual Length) (ft.) | Maximum Tubing Length (L) (ft.) | Maximum Elevation Difference (H) (ft.) | | Required Amount of Additional Refrigerant (oz./ft.)* |
|------------------|---|---------------------------------|--|-----|--|
| KS3082 KS3682 | 10 to 100 | 165 | If the outdoor unit is higher | 100 | 0.43 |
| | | | If the outdoor unit is lower | 50 | |

* If total tubing length becomes 100 to 165 ft. (Max.), charge additional refrigerant (R410A) by 0.43 oz./ft.

No additional charge of compressor oil is necessary. For more detailed charging information, refer to the Technical & Service Manual.

2-2. Outdoor Unit

AVOID:

- heat sources, exhaust fans, etc. (Fig. 4)
- damp, humid or uneven locations.

DO:

- choose a place as cool as possible.
- choose a place that is well ventilated.
- install in a location where at least two sides are unobstructed, so that the flow of air at the intake port or exhaust port is not blocked, and so that sufficient space is ensured for maintenance to be carried out without trouble. In general the top also must be unobstructed. (Fig. 5a)
- provide a solid base (level concrete pad, concrete block, 6" x 1'4" (15 x 40 cm) beams or equal), a minimum of 6" (15 cm) above ground level to reduce humidity and protect the unit against possible water damage and decreased service life. (Figs. 5b and 5c)



CAUTION

A solid base must not cover the hole of the bottom plate.

- install cushion rubber under unit's feet to reduce vibration and noise. (Fig. 5d)
- use lug bolts or equal to bolt down unit, reducing vibration and noise.
- install in a location where no antenna of a television or radio exists within 10' (3 m).




Fig. 4




Fig. 5a



CAUTION

- Concerning air-intake side distance "A" (Fig. 5a) The minimum for distance "A" is 6" if there are no obstructions on the air-discharge side (wall *1 side) and *2 or *4 is not present. In all other cases, the minimum for distance "A" is 8".
- If wall *1 is on the air-discharge side (Fig. 5a), or if obstructions are present on all 3 sides *2, *3, and *4 (Fig. 5a), then the minimum distance for "B" and "C" is 39-3/8". Even if there is no wall on the air-discharge side, a minimum of 39-3/8" is required.




Fig. 5b




Fig. 5c




Fig. 5d

2-2-1. Installing the Unit in an Area with High Winds and in a Snowy Area

- In locations with high winds, a wind-proof duct should be fitted and direct exposure to the wind should be avoided as much as possible. (Fig. 5e)
- In regions with significant snowfall, the outdoor unit should be provided with a platform and snow-proof duct. (Fig. 5f)

■ Countermeasures against snow and wind

In regions with snow and strong wind, the following problems may occur when the outdoor unit is not provided with a platform and ducting:

- The outdoor fan may not run and damage to the unit may occur.
- There may be no air flow.
- The tubing may freeze and burst.
- The condenser pressure may drop because of strong wind, and the indoor unit may freeze.

2-2-2. Precautions for Installation in a Snowy Area

- (1) The platform should be higher than the maximum snow depth. (Fig. 5g)
- (2) The 2 anchoring feet of the outdoor unit should be used for the platform, and the platform should be installed beneath the air intake side of outdoor unit.
- (3) The platform foundation must be firm and the unit must be secured with anchor bolts.
- (4) In case of installation on a roof subject to strong wind, countermeasures must be taken to prevent the unit from being blown over.




Fig. 5e




Fig. 5f






Fig. 5g

2-2-3. Dimensions of Wind-proof Duct

Reference diagram for C3082/3682



Reference diagram for wind-proof duct (locally purchased): STK-DGV160E




Required space around the outdoor unit

If the wind-proof duct is used, the space shown below must be secured around the outdoor unit.

If the unit is used without the required space, a protective device may activate, preventing the unit from operating.

(1) Single-unit installation



Unit: inch




CAUTION

The top and both sides must remain open. If there are obstacles to the front and rear of the outdoor unit, the obstacle at either the front or rear must be no taller than the height of the outdoor unit.

(2) Multiple-unit installation

● Installation in lateral rows



Unit: inch




CAUTION

The front and top must remain open. The obstacles must be no taller than the height of the outdoor unit.

● Installation in front-rear rows

Installation with intakes facing intakes or outlets facing outlets

Installation with intakes facing outlets



Unit: inch









CAUTION

The front and both sides must remain open.

Reference diagram for snow-proof duct


Space requirements for setting
C3082/3682 with STK-BDV80E

| [Obstacle to the rear of unit] | [Obstacle to the front of unit] |
|---|---|
| <p>● Top is open:</p> <p>(1) Single-unit installation (2) Obstacles on both sides</p>  <p>(3) Multiple-unit installation (2 or more units)</p>  <p>Note: In cases 2 and 3 the height of the obstacle must be no taller than the height of the outdoor unit.</p> | <p>● Top is open:</p> <p>(1) Single-unit installation</p>  <p>(2) Multiple-unit installation (2 or more units)</p>  |
| <p>● Top is blocked by an obstacle:</p>  | <p>● Top is blocked by an obstacle:</p>  |

[Obstacles to the front and rear of unit]


- The top and both sides must remain open. Either the obstacle to the front or the obstacle to the rear must be no taller than the height of the outdoor unit.

(1) Single-unit installation




(2) Obstacles on both sides

Installation is possible with the maximum 3 outdoor units.



[Installation in front-rear rows]

- The top and both sides must remain open. Either the obstacle to the front or the obstacle to the rear must be no taller than the height of the outdoor unit.



Unit: inch

3. How to Install the Indoor Unit

3-1. Remove the Rear Panel from the Unit

- (1) Remove and discard the set screw on the rear panel. (Fig. 6)
- (2) Press the 2 Δ marks on the frame cover and disengage the stationary tabs from the frame. (Fig. 7a)
- (3) Remove the rear panel by grasping the sections shown in Fig. 7b and pulling it in the direction shown by the arrow.

NOTE

Tubing can be extended in 6 directions as shown in Fig. 8. Select the direction you need providing the shortest run to the outside unit.

- When left tubing is to be done, switch the drain hose and drain cap. (For details, refer to "Switching drain hose and drain cap" on page 20.)

3-2. Make a Hole

- (1) Place the rear panel from the indoor unit on the wall at the location selected. Make sure the panel is horizontal, using a carpenter's level or tape measure to measure down from the ceiling. Wait until after cutting the hole before attaching the rear panel to the wall.
- (2) Determine which side of the unit you should make the hole for tubing and wiring. (Fig. 9)

NOTE

In the case of left-rear tubing, use the measurement points 6-7/32" (158 mm) from the marked position on the rear panel for precise placement of the hose outlet. (Fig. 9)

- (3) Before making the hole, check carefully that no studs or pipes are directly run behind the spot to be cut.



CAUTION

Also avoid areas where electrical wiring or conduits are located.

The above precautions are also applicable if tubing goes through the wall in any other location.





Fig. 9



Set screw only for transportation

Fig. 6




Fig. 7a




Fig. 7b




Fig. 7c




Fig. 8

- (4) Using a sabre saw, key hole saw or hole-cutting drill attachment, cut a hole in the wall. See Table 4 and Fig. 10.

Table 4

| Hole Dia. |
|-----------------|
| 3-5/32" (80 mm) |

- (5) Measure the thickness of the wall from the inside edge to the outside edge and cut PVC pipe at a slight angle 1/4" (6 mm) shorter than the thickness of the wall. (Fig. 11)
- (6) Place the plastic cover over the end of the pipe (for indoor side only) and insert the pipe in the wall. (Fig. 12)

3-3. Install the Rear Panel on the Wall

Be sure to confirm that the wall is strong enough to suspend the unit.

There are a number of screw holes on the rear panel. Using the 8 screw holes with $\leftarrow \rightleftarrows$ mark is recommended to attach the rear panel securely to the wall.

See either Item a) or b) below depending on the wall type.

a) If Wooden Wall

- (1) Attach the rear panel to the wall with the 8 screws provided. (Fig. 13)

If you are not able to line up the holes in the rear panel with the beam locations marked on the wall, use rawl plugs or toggle bolts to go through the holes on the panel or drill 3/16" (5 mm) dia. holes in the panel over the stud locations and then mount the rear panel.

- (2) Double check with a carpenter's level or tape measure that the panel is level. This is important to install the unit properly. (Fig. 14)
- (3) Make sure the panel is flush against the wall. Any space between the wall and unit will cause noise and vibration.

b) If Block, Brick, Concrete or Similar Type Wall

Make 3/16" (4.8 mm) dia. holes in the wall. Insert rawl plugs for appropriate mounting screws. (Fig. 15)

NOTE

Hole should be made at a slight downward slant to the outdoor side.





Fig. 10

PVC pipe (Locally purchased)



Cut at slight angle

Fig. 11




Fig. 12




Fig. 13




Fig. 14




Fig. 15

3-4. Removing and Installing the Grille

Basically, these models can be installed and wired without removing the grille. If access to any internal part is needed, follow the steps as given below.

How to remove the grille

- (1) Open the front panel until it is nearly horizontal, grasp the sections near the front panel arms on both sides, and then remove the panel by pushing the arms towards the outside while pulling the panel towards you.

If the front panel is difficult to remove, grasp both ends of it and lift it up slightly. Move it to the left and disengage the left arm, then move it to the right and disengage the right arm. (Fig. 16)

- (2) Lift the anti-mold filter up slightly to disengage it from the protrusions on the unit, and then pull downward to remove the filter from the unit. (Fig. 16)
- (3) Remove the 3 screws from the front of the unit and remove the screw covers on the bottom surface. Then remove the 2 screws. (Fig. 17)
- (4) Remove the screw on the right side cover plate and remove the cover. (Fig. 17a)
- (5) Remove the lower flap by disengaging 4 pins of the lower flap in order. (Figs. 17b and 17c)
(The flap is so flexible that it can be easily removed.)
- (6) Lift up the grille in the direction shown by the arrow and pull the grille towards you to remove it. (Fig. 17d)

How to replace the grille

- (1) While aligning the top edge of the grille with the frame, move the grille horizontally and insert the top and bottom into the frame.
- (2) Press the grille firmly with your hand to ensure no gap exists between the frame and grille.
- (3) Tighten the 6 screws. And fix the removed covers in place.
- (4) Grasp the sections near the front panel arms on both sides, and hold the front panel so that it is nearly horizontal. Push the arm shafts towards the outside so that they come into contact with the top of the indentations on the right and left sides of the air conditioner. Then push firmly until the arm shafts click into place. (Fig. 18)
- (5) Remount the lower flap.
(In remounting the flap, it cannot be turned end for end because the right and left pins of the flap differ in form. (Fig. 17c))
- (6) Insert the top of the anti-mold filter, and then secure the bottom of the filter with the protrusions on the unit.
- (7) When closing the front panel, push the central part of the front panel first and then press the bottom right and left corners in place until you feel a click. (Fig. 19)

NOTE

Check that no gap exists between the frame and the grille.




Fig. 16




Fig. 17a




Fig. 17b




Fig. 17c




Fig. 17d




Fig. 18




Fig. 19

3-5. Shape the Indoor Side Tubing

(1) Arrangement of tubing by direction

a) Right or left tubing

Cut out the corner of the right/left frame with a hacksaw or the like. (Figs. 20 and 21)

b) Right-rear or left-rear tubing

In this case, the corner of the frame need not be cut.

(2) To mount the indoor unit on the rear panel:

Hang the 3 mounting slots of the unit on the upper tabs of the rear panel. (Fig. 22)

3-6. Wiring Instructions

General precautions on wiring

- (1) Before wiring, confirm the rated voltage of the unit as shown on its nameplate, then carry out the wiring closely following the wiring diagram.
- (2) Provide a power outlet to be used exclusively for each unit, with a power supply disconnect and circuit breaker for overcurrent protection provided in the exclusive line.
- (3) To prevent possible hazards due to insulation failure, the unit must be grounded.
- (4) Each wiring connection must be done tightly and in accordance with the wiring system diagram. Wrong wiring may cause the unit to misoperate or become damaged.
- (5) Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- (6) Unauthorized changes in the internal wiring can be very dangerous. The manufacturer will accept no responsibility for any damage or misoperation that occurs as a result of such unauthorized changes.




Fig. 20




Fig. 21




Fig. 22

3-7. Wire Size and Length

Regulations on wiring diameter differ from locality to locality. For field wiring requirements, please refer to your local electrical codes. Carefully observe these regulations when carrying out the installation.

NOTE

Refer to the wiring system diagram (Fig. 23) for the meaning of (A), (B), and (C) in Table 5.

Refer to your local codes or in the absence of local codes see the National Electric Code: ANSI/NFPA70.

Table 5

| Model | | (A) POWER SUPPLY WIRING | (B) POWER LINE | (C) CONTROL LINE |
|----------------|----------------------------------|--|-------------------------|------------------|
| C3082 C3682 | Wire Size | AWG12 (min.) or bigger (*1) for C3082 AWG10 (min.) or bigger (*1) for C3682 | AWG14 or bigger | AWG14 or bigger |
| | Length | It depends on wire specification and supply voltage level (*2) | 180 ft. (max.) | 180 ft. (max.) |
| | Fuse or Circuit Breaker Capacity | 35A for C3082 45A for C3682 | Disconnect switch (15A) | — |

(AWG: American Wire Gauge)

(*1) It depends on supply voltage level and wire specification. Consider temperature rating of wire, ambient temperature, and the number of wires inside the conduit.

(*2) Requirement of supply voltage level: AC187V to 253V (Measure voltage level at terminal plate inside the outdoor unit.)



WARNING

- Be sure to comply with local codes on running the wire from the indoor unit to the outdoor unit (size of wire and wiring method, etc.).
- Each wire must be firmly connected.
- No wire should be allowed to touch refrigerant tubing, the compressor, or any moving part.



WARNING

- To avoid the risk of electric shock, each air conditioner unit must be grounded.
- For the installation of a grounding device, please observe local electrical codes.
- Grounding is necessary, especially for units using inverter circuits, in order to release charged electricity and electrical noise caused by high tension. Otherwise, electrical shock may occur.
- Place a dedicated ground more than 7' (2 m) away from other grounds and do not have it shared with other electric appliances.



CAUTION

- Be sure to connect the power supply line to the outdoor unit as shown in the wiring diagram. The indoor unit draws its power from the outdoor unit.
- Do not run wiring for antenna, signal, or power lines of television, radio, stereo, telephone, security system, or intercom any closer than 3'4" (1 m) from the power cable and wires between the indoor and outdoor units. Electrical noise may affect the operation.

WIRING SYSTEM DIAGRAM




Fig. 23

* NOTE

Disconnect switch may be required by national or local codes.



CAUTION

Always comply with national and local code requirements.

3-8. Wiring Instructions for Inter-unit Connections

- (1) Insert the inter-unit wiring (according to local codes) into the through-the-wall PVC pipe. Run the wiring toward the indoor side allowing approx. 10" (25 cm) to extend from the wall face. (Fig. 24)
- (2) Grasp both ends of the front panel, push the arms towards the outside, and remove the front panel by opening it towards the front and pulling it towards you. If the front panel is difficult to remove, grasp both ends of it and lift it up slightly. Move it to the left and disengage the left arm, then move it to the right and disengage the right arm.
- (3) Remove the screw on the right side cover plate and open the cover. (Fig. 25)
- (4) Route the inter-unit wiring from the back of the indoor unit and pull it toward the front for connection. (Fig. 26a, 26b)
- (5) Connect the inter-unit wiring to the corresponding terminals on the terminal plate (Fig. 26a, 26b) while referring to the wiring diagram.
- (6) Be sure to secure the wiring with the provided clamp.

NOTE

When closing the front panel, push the central part of the front panel first and then press the bottom right and left corners in place until you feel a click. (Fig. 27)

Please refer to "How to replace the grille" on page 14 for installing the air intake grille.




Fig. 27




Fig. 24




Fig. 25




Fig. 26a




Fig. 26b


**WARNING**

Loose wiring may cause the terminal to overheat or result in unit malfunction. A fire hazard may also exist. Therefore, be sure all wiring is tightly connected.


When connecting each power wire to the corresponding terminal, follow the instructions “How to connect wiring to the terminal” and fasten the wire securely tight with the fixing screw of the terminal plate.

How to connect wiring to the terminal**a) For Indoor Unit**




- (1) Cut the wire end with a cutting pliers, then strip the insulation to expose the wire about 9/32" (7 mm). See the label (Fig. 28) near the terminal plate.
- (2) Using a screwdriver, loosen the terminal screw on the terminal plate.
- (3) Insert the wire and tighten the terminal screw completely using a screwdriver.

**Fig. 28****b) For Outdoor Unit****■ For solid core wiring (or F-cable)**

- (1) Cut the wire end with a cutting pliers, then strip the insulation to expose the solid wire about 15/16" (25 mm). (Fig. 29)
- (2) Using a screwdriver, remove the terminal screw(s) on the terminal plate.
- (3) Using the pliers, bend the solid wire to form a loop suitable for the terminal screw.
- (4) Shape the loop wire properly, place it on the terminal plate and fix it securely with the removed terminal screw using a screwdriver.

**Fig. 29****■ For stranded wiring**

- (1) Cut the wire end with a cutting pliers, then strip the insulation to expose the stranded wiring about 3/8" (10 mm) and tightly twist the wire ends. (Figs. 30 and 31)
- (2) Using a screwdriver, remove the terminal screw(s) on the terminal plate.
- (3) Using a ring connector fastener or pliers, securely clamp each stripped wire end with a ring connector. (Fig. 30)
- (4) Place the ring connector wire, and replace and tighten the removed terminal screw using a screwdriver. (Fig. 32)

**Fig. 30****Fig. 31****Fig. 32**

3-9. Mounting

- (1) To install the indoor unit, mount the indoor unit onto the 3 tabs on the upper part of the rear plate.
- (2) Hold down the air discharge outlet and press the lower part of the indoor unit until it clicks to securely fasten to the 2 tabs on the lower part of the rear plate. (Fig. 33)

NOTE

For tubing, choose either the right or left tubing direction and follow the steps below. Also, extend the support on the back of the indoor unit as a stand to make your work easier. (Fig. 34)

■ Right-side tubing

- (1) Shape the refrigerant tubing so that it can easily go into the wall hole. (Fig. 35)
- (2) Push the wiring, refrigerant tubing, and drain hose through the hole in the wall. Adjust the indoor unit so it is securely seated on the rear panel. (Fig. 36)
- (3) Carefully bend the tubing (if necessary) to run along the wall in the direction of the outdoor unit and then tape as far as the fittings. (See Caution on page 24.) The drain hose should come straight down the wall to a point where water runoff won't stain the wall.
- (4) Connect the refrigerant tubing to the outdoor unit. (After performing a leak test on the connecting part, insulate it with the tubing insulation. (Fig. 37a)) Also, refer to Section 5-4. Connecting Tubing between Indoor and Outdoor Units.
- (5) Assemble the refrigerant tubing, drain hose, and conduit (including inter-unit wiring) as shown in Fig. 37b.




Fig. 33




Fig. 34




Fig. 35




Fig. 37a




Fig. 37b




Fig. 36

■ Left-side tubing

- (1) Lead the tubing and drain hose through the wall, allowing sufficient length for connection. Then bend the tubing using a tube bender to make the attachment. (Fig. 38)
- (2) Switch the drain hose and drain cap.

Switching drain hose and drain cap

- (a) Locate the drain hose and the drain cap. (Fig. 39)
- (b) Remove the screw fastening the drain hose on the right side, and pull out the drain hose to remove it. (Fig. 39)
- (c) Apply moderate force to pull off the drain cap on the left side. (If you cannot pull it off by hand, use a long-nose pliers.)
- (d) Reattach the drain hose to the left side and the drain cap to the right side. (Fig. 40a)

Drain hose

Slide the drain hose fully onto the drain pan outlet. (It will be easy to slide when water is added.) Check that the screw holes in the drain bracket and the drain pan outlet are aligned and securely in contact, then fasten them with the screw. (After attaching the drain hose, check that it is attached securely.) (Fig. 40b)

Drain cap

Use a Phillips screwdriver to push the drain cap in firmly. (If it is difficult to push in, wet the cap with water first.)

- (3) Install the indoor unit on the rear panel.
- (4) Connect the tubing and wiring led inside from outdoors.
- (5) After completing a leak test, bundle the tubing together with armoring tape and store it inside the tubing storage area at the back of the indoor unit and hold it with clamps. (Figs. 40a and 41)




Fig. 38




Fig. 39




Fig. 40a




Fig. 40b




Fig. 41

To unmount indoor unit

Press the 2 \triangle marks on the lower part of the indoor unit and unlatch the tabs. Then lift the indoor unit and unmount. (Fig. 42)

3-10. Frame Fastening Method

- (1) Remove the screw cover on the bottom surface. (Fig. 43)
- (2) Fasten the frame to the rear panel using the 2 supplied tapping screws $5/32" \times 13/32"$ ($4 \times 10 \text{ mm}$). (Fig. 43)

NOTE

Under normal conditions, the installation design calls for a less than $3/32"$ (2 mm) gap between the air conditioner unit and the wall.

Confirm that the gap is appropriate (less than 2 mm).

3-11. Drain Hose

- a) The drain hose should be slanted downward to the outdoors. (Fig. 44)
- b) Never form a trap in the course of the hose.
- c) If the drain hose will run in the room, insulate the hose with insulation* so that chilled condensation will not damage furniture or floors. (Fig. 45)

* Foamed polyethylene or its equivalent is recommended.




Fig. 42






Fig. 43



WARNING Do not supply power to the unit or operate it until all tubing and wiring to the outside unit are completed.



Risk of Electric Shock




Fig. 44




Fig. 45


4. How to Install the Outdoor Unit

First refer to Section 2. Installation Site Selection.

4-1. Wiring Instructions for the Outdoor Unit


Regulations on wire size differ from locality to locality. For field wiring requirements, please refer to your local electrical codes. Make sure that the installation fully complies with all local and national regulations.

- (1) Remove the 3 screws from the inspection panel.
(Fig. 46a)
Remove the inspection panel by sliding it downward and pulling it toward you. (Fig. 46b)
- (2) Connect the inter-unit and power supply line according to the wiring system diagram on the inspection panel. (Fig. 46c)
- (3) When connections are completed, check that all connections are correct as shown in the wiring system diagram.
- (4) Be sure to ground the unit according to your local codes.




4-2. Routing the Tubing and Wiring

- The tubing and wiring can be extended out in 3 directions: front, rear, and right. Use a nipper or similar tool to cut out the knockout holes for the inter-unit control wiring outlet, power wiring outlet, and tubing outlet from the appropriate covers A and B. (Fig. 46d)



- **Route the tubing so that it does not contact the compressor, panel, or other parts inside the unit. Increased noise will result if the tubing contacts these parts.**
- **When routing the tubing, use a tube bender to bend the tubes.**



5. Refrigerant Tubing

5-1. Use of the Flaring Method

Many of the conventional split system air conditioners employ the flaring method to connect refrigerant tubes which run between indoor and outdoor units. In this method, the copper tubes are flared at each end and connected with flare nuts.

5-2. Flaring Procedure with a Flare Tool

- (1) Cut the copper tube to the required length with a tube cutter. It is recommended to cut approx. 12" to 20" (30 to 50 cm) longer than the tubing length you estimate.
- (2) Remove burrs at the end of the copper tube with a tube reamer or file. This process is important and should be done carefully to make a good flare. (Fig. 47)

NOTE

When reaming, hold the tube end downward and be sure that no copper scraps fall into the tube. (Fig. 48)

- (3) Remove the flare nut from the unit and be sure to mount it on the copper tube.
- (4) Make a flare at the end of copper tube with a flare tool.* (Figs. 49a and 49b)

(*Use "RIDGID" or equivalent.)

NOTE

A good flare should have the following characteristics:

- inside surface is glossy and smooth.
- edge is smooth.
- tapered sides are of uniform length.

5-3. Caution before Connecting Tubes Tightly

- Be sure to apply a sealing cap or water-proof tape to prevent dust or water from getting into the tubes before they are used.
- Be sure to apply refrigerant lubricant to the matching surfaces of the flare and union before connecting them together. This is effective for reducing gas leaks. (Fig. 50)
- For proper connection, align the union tube and flare tube straight with each other, then screw in the flare nut lightly at first to obtain a smooth match. (Fig. 51)




Fig. 47






Fig. 48

If the special R410A flare tool is used:



If the previous flare tool (clutch-type) is used:



Adjust so that the amount of tube protrusion is as shown in the figure.

Fig. 49a




Fig. 49b




Fig. 50




Fig. 51

5-4. Connecting Tubing between Indoor and Outdoor Units

- Tightly connect the indoor side refrigerant tubing extended from the wall with the outdoor side tubing. (Fig. 52)
- To fasten the flare nuts, apply specified torque as:

Table 6

| Tube Dia. | Nut | Tightening Torque |
|-----------------|-----------------|---|
| 1/4" (6.35 mm) | 21/32" (17 mm) | Approx. 120 – 160 lbs·in (140 – 180 kgf·cm) |
| 3/8" (9.52 mm) | 7/8" (22 mm) | Approx. 300 – 360 lbs·in (340 – 420 kgf·cm) |
| 1/2" (12.70 mm) | 1-1/32" (26 mm) | Approx. 430 – 540 lbs·in (490 – 610 kgf·cm) |
| 5/8" (15.88 mm) | 1-5/32" (29 mm) | Approx. 590 – 710 lbs·in (680 – 820 kgf·cm) |

5-5. Insulation of Refrigerant Tubing

IMPORTANT

To prevent heat loss and wet floors due to dripping of condensation, **both tubes must be well insulated with a proper insulation material.** (Fig. 53)

The thickness of the insulation should be a minimum 5/16" (8 mm). (Fig. 54)

5-6. Taping the Tubes



CAUTION

After a tube has been insulated, never try to bend it into a narrow curve, as this may cause the tube to break or crack.

- At this time, the 2 refrigerant tubes (and electrical wire if local codes permit) should be taped together with armoring tape. The drain hose may also be included and taped together as 1 bundle with the tubing.
- Wrap the armoring tape from the bottom of the outdoor unit to the top of the tubing where it enters the wall. As you wrap the tubing, overlap half of each previous tape turn. (Fig. 55)
- Clamp the tubing bundle to wall, using 1 clamp approx. every 47" (120 cm).

NOTE

Do not wind the armoring tape too tightly, since this will decrease the heat insulation effect. Also, be sure the condensation drain hose splits away from the bundle and drips clear of the unit and the tubing.

5-7. Finishing the Installation

After finishing insulating and taping over the tubing, use sealing putty to seal off the hole in the wall to prevent rain and draft from entering. (Fig. 56)




Fig. 52




Fig. 53




Fig. 54




Fig. 55




Fig. 56

6. Air Purging

Air and moisture remaining in the refrigerant system have undesirable effects as indicated below. Therefore, they must be purged completely.

- pressure in the system rises
- operating current rises
- cooling (or heating) efficiency drops
- moisture in the air may freeze and block capillary tubing
- water may lead to corrosion of parts in the refrigerant system

■ Air Purging with a Vacuum Pump (for Test Run)

- (1) Check that each tube (both narrow and wide tubes) between the indoor and outdoor units have been properly connected and all wiring for the test run has been completed. Note that both narrow and wide tube service valves on the outdoor unit are kept closed at this stage.
- (2) Using an adjustable wrench or box wrench, remove the valve caps from the service valve on both narrow and wide tubes.
- (3) Connect a vacuum pump and a manifold valve (with pressure gauges) to the service port on the wide tube service valve. (Fig. 57)



CAUTION

The service port on the wide tube service valve uses a Schrader core valve to access the refrigerant system. The valve core is similar to those used in automobile tires. Therefore, be sure to use a vacuum hose connector which has a push-pin inside.



CAUTION

Be sure to use a manifold valve for air purging. If it is not available, use a stop valve (field supply) for this purpose. The “Hi” knob of the manifold valve must always be kept closed.

- (4) With the “Lo” knob of the manifold valve open, run the vacuum pump. The operation time for the vacuum pump varies with tubing length and the capacity of the pump. The following table shows the amount of time for evacuation:

Table 7

| Required time for evacuation when 100 liter/h vacuum pump is used | |
|---|---|
| If tubing length is less than 33 ft. (10 m) | If tubing length is more than 33 ft. (10 m) |
| 10 min. or more | 15 min. or more |




Fig. 57

NOTE

To prevent other refrigerants from being mistakenly charged to units which use R410A, the size of the charge port on the service valve is different from the one for other refrigerant types. For servicing such as recharging, the specified charging hose, manifold and vacuum pump adapter (with reverse flow prevention) for R410A must be used.

NOTE

The required time in Table 7 is calculated based on the assumption that the ideal (or target) vacuum condition is around 10 mmHg abs.

- (5) With the vacuum pump still running, close the “Lo” knob of the manifold valve. Then stop the vacuum pump.
- (6) With the hex wrench, turn the valve stem on the narrow tube service valve counter-clockwise by 90 degrees (1/4 turn) for 10 seconds, and then turn the stem clockwise to close it again. (Fig. 58)



CAUTION

Be sure to completely insert the hex wrench before attempting to turn the valve.

- (7) Leak test all joints at the tubing (both indoor and outdoors) with soapy water. Bubbles indicate a leak. Tighten the joint more when leaks, then check if there is no leak. Be sure to wipe off the soap with a clean cloth.
- (8) With the hex wrench, turn the wide tube service valve stem counter-clockwise to fully open the valve.
- (9) Turn the narrow tube service valve stem counter-clockwise to fully open the valve.
- (10) Loosen the vacuum hose connected to the wide tube service port slightly to release the pressure. Then, remove the hose.



CAUTION

This may cause the refrigerant gas to leak. In order to avoid this, take off the hose quickly.

- (11) Fasten the valve cap on the wide tube service port securely with an adjustable wrench or box wrench. Next, mount the valve cap on the service valve and tighten it to 170 lbs·in (200 kgf·cm) with a torque wrench. This process is very important to prevent gas from leaking from the system.
- (12) Test run the air conditioner. (See next page.)
- (13) While the air conditioner is running, apply liquid soap to check for any gas leaks around the service valves or caps.
- (14) If there is no leakage, stop the air conditioner.
- (15) Wipe off the soap on the tubing.

This completes air purging with a vacuum pump and the air conditioner is ready for actual operation.




Fig. 58

How to Test Run the Air Conditioner

After turning on the power of the air conditioner, use the remote controller and follow the steps below to conduct the test run.

- (1) Set the remote controller in Test Run mode. (Fig. 59a)
 - a) Press and hold the QUIET button and the 1HR. TIMER button.
 - b) Then press and hold the ACL (Reset) button with a pointed object such as the tip of a pen. After 5 seconds, release the ACL button first.
 - c) Then release the QUIET and 1HR. TIMER buttons.
 - d) ✻ appears and "oP-1" blinks in the remote controller clock display area. (Fig. 59b)
- (2) Start Cooling mode test run by pressing the ON/OFF operation button of the remote controller. (Fig. 59a)
 - This starts the fan producing uncooled forced air with the 3 indicator lamps (OPERATION lamp, TIMER lamp, and LED CLEAN lamp) on the main unit blinking. (Fig. 59c)
 - After 3 minutes, the system shifts into cooling operation, and cool air will start to be felt. Cooling mode test run is unaffected by the room temperature.
- (3) Press the ON/OFF operation button of the remote controller again to stop the test run. (Fig. 59a)
- (4) Finally press the ACL (Reset) button of the remote controller to release it from Test Run mode to return to normal mode. (Fig. 59a)
 - "✻" and "oP-1" will disappear from the remote controller clock display area.

NOTE

Troubleshooting:

In the event that the green OPERATION lamp is blinking upon powering up the system, an error condition exists. In this case, refer to the self-diagnostics procedure on the inside of the front cover.

IMPORTANT

After the test run is completed, be sure to press the ACL (Reset) button to return to normal mode. The air conditioner will not operate correctly if this is not done.




Fig. 59a




Fig. 59b












Fig. 59c


■ Basic Functions of the Service Valves

The basic functions of the service valves are given in Table 8 below.

Table 8

| Action | Narrow Tube Service Valve (2-Way) | Wide Tube Service Valve (3-Way) |
|--|---|---|
| Shipping | CLOSED  | O-ring, Valve cap, Stem  |
| Operating and test running the air conditioner | Fully OPEN  |  |
| Measuring pressure and gas charging | Fully OPEN  | *  |
| Air purging with a vacuum pump | CLOSED  | *  |

* The service port on the wide tube service valve uses a Schrader core valve to access the refrigerant system. Therefore, be sure to use a hose connector which has a push-pin inside. (Fig. 60a)



CAUTION

When opening or closing the service valve stem, use the hex wrench. Be sure to fully seat the wrench before turning the valve.





Fig. 60b



NOTE

External diameter of service port R410A: 5/16"

Fig. 60a

■ Pump Down

Pump down means collecting all refrigerant gas in the system back into the outdoor unit without losing any of the gas. Pump down is used when the unit is to be moved or before servicing the refrigerant circuit.

Pump Down Procedure

Be sure to carry out pump down with the unit in cooling mode.

(1) Connect the Lo side charging hose of the manifold valve to the service port on the wide tube service valve.

- (2) Using a hex wrench, turn the narrow tube service valve clockwise all the way to close the service valve. (Be sure to confirm that the wide tube service valve is fully open.)
- (3) Press the operation button and start cooling operation.
- (4) When the low pressure gauge reading falls to 14.2 to 7.1 psi (1 to 0.5 kg/cm²), fully close the wide tube valve stem. Then quickly stop the unit.
- (5) Disconnect all gauges and hoses, and replace the valve caps as they were before.

■ Service Valve Connections

- Temporary connection:
Screw in 3 – 5 turns by hand. (Fig. 60c)
- To fasten the flare nuts, apply specified torque as Table 9 and Fig. 60d.




Table 9

| Tube Dia. | Nut | Tightening Torque |
|-----------------|-----------------|---|
| 1/4" (6.35 mm) | 21/32" (17 mm) | Approx. 120 – 160 lbs·in (140 – 180 kgf·cm) |
| 3/8" (9.52 mm) | 7/8" (22 mm) | Approx. 300 – 360 lbs·in (340 – 420 kgf·cm) |
| 1/2" (12.70 mm) | 1-1/32" (26 mm) | Approx. 430 – 540 lbs·in (490 – 610 kgf·cm) |
| 5/8" (15.88 mm) | 1-5/32" (29 mm) | Approx. 590 – 710 lbs·in (680 – 820 kgf·cm) |

Fig. 60c

Fig. 60d



CAUTION

Be sure to tighten the flare nut using the prescribed torque. If the nut is over-tightened, refrigerant leakage may occur.

7. Remote Control Unit Installation Position


The remote control unit can be operated from either a non-fixed position or a wall-mounted position.

To ensure that the air conditioner operates correctly, do not install the remote control unit in the following places:

- In direct sunlight
- Behind a curtain or other place where it is covered
- More than 26' (8 m) away from the air conditioner
- In the path of the air conditioner's airstream
- Where it may become extremely hot or cold
- Where it may be subject to electrical or magnetic interference
- Where there is an obstacle between the remote control unit and the air conditioner (since a check signal is sent from the remote control unit every 5 minutes)

7-1. Mounting on a Wall

Before mounting the remote control unit, press the ON/OFF operation button at the mounting location to make sure that the air conditioner operates from that location. The indoor unit should make a beeping sound to indicate that it has received the signal.



To take out the remote control unit, pull it forward.

Fig. 61

8. Address Switch


8-1. Address Setting of the Remote Control Unit

The address can be set in order to prevent interference between remote controllers when 2 indoor units are installed near each other. The address is normally set to "A." To set a different address, it is necessary to change the address on the second remote controller.

NOTE

Once changed, you cannot restore the original address setting of the air conditioner.

- (1) Switch on the power source.
- (2) Break the address-setting tab marked "A" on the second remote controller to change the address (Fig. 62). When the tab is removed, the address is automatically set to B (Fig. 63).
- (3) Press and hold the remote controller QUIET button and 1HR. TIMER button. Then press and hold the ACL (Reset) button with a pointed object such as the tip of a pen. After 5 seconds, release the ACL button first, then release the QUIET and 1HR. TIMER buttons. "oP-1" (Test Run) appears, blinking in the remote controller clock display area.
- (4) Each time the 1HR. TIMER button is pressed, the display changes as shown below. Press this button 3 times to change the display to "oP-7" (Address setting).



- (5) "oP-7" has now been selected for address setting.
- (6) Press the ON/OFF operation button on the remote controller. (Fig. 64) Check that the "beep" signal-received sound is heard from the second indoor unit (approximately 5 times). The sound you hear is the signal that the remote controller address has been changed.
- (7) Finally press the remote controller ACL (Reset) button to cancel the blinking "oP-7" display. (Fig. 64)

Changing of the second remote controller address is now completed.




Fig. 62




Fig. 63




Fig. 64

For Parts or Service Assistance please contact your local Sanyo HVAC Contractor or Distributor

United States: SCS, HVAC Solutions
Web: www.SanyoHVAC.com
Parts: hvac.parts@sna.sanyo.com
Service: hvac.service@sna.sanyo.com

Canada: Sanyo Canada Inc.
Web: www.SanyoHVAC.com
Parts/Service: hvac@sci.sanyo.com

3/10 Printed in Japan

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>