# 2112/24TSRB Photoelectronic Smoke Detector



3825 Ohio Avenue, St. Charles, Illinois 60174 1-800-SENSOR2, FAX: 630-377-6495

**Specifications** 

Diameter: 5.5 inches (140 mm)
Height (including mounting bracket): 1.7 inches (43 mm)
Weight: 5.3 oz. (150 g)

Operating Temperature Range: 32° to 100°F (0° to 39°C)

Operating Humidity Range: 10% to 93% relative rumidity, noncondensing Latching Alarm: Reset by momentary power interruption 135°F fixed temperature electronic thermistor

**Electrical Ratings** 

System Voltage nominal: 12 or 24 VDC

Minimum: 8.5 VDC Maximum: 35 VDC

Maximum Ripple Voltage: 30% of nom. voltage (peak to peak)

Standby Current: 15 mA maximum

Alarm Current:

at 12V: 38 mA maximum

at 24V: 45 mA maximum

Reset Voltage: 0.8 VDC minimum
Reset Time: 0.3 seconds maximum

Start-up Time: 30 seconds maximum (after 30 second reset)

Supervision and Alarm Initiation Contact Ratings Resistive or inductive load (60% power factor)

Form A: 0.5A @ 30 VAC/DC

## **Before Installing**

Please thoroughly read System Sensor manual I56-407, *Guide for Proper Use of System Smoke Detectors*, which provides detailed information on detector spacing, placement, zoning, wiring, and special applications. Copies of this manual are available at no charge from System Sensor.

**NOTICE:** This manual should be left with the owner/user of this equipment.

**IMPORTANT:** This detector must be tested and maintained following NFPA 72 requirements. The detector should be cleaned at least once a year.

## **General Description**

The Model 2112/24TSRB is a 4-wire photoelectronic smoke detector that uses a state-of-the-art optical sensing chamber. This detector is designed to provide open area protection. It features a restorable, built-in, fixed-temperature (135°F) thermal sensor.


Installation of this detector is simplified by the use of the

mounting bracket and plug-in screw terminal block that can be prewired to the system, allowing the detector to be easily installed or removed for cleaning. The detector's sensitivity can be tested in place using the MOD400R Test Module (available separately from System Sensor).

The 2112/24TSRB features a supervisory relay that supervises the power and the sensitivity of the detector. When the power to the detector is lost, the supervisory relay opens instantaneously. Where as, when the detector deviates from its sensitivity range indicating the need for maintenance, the supervisory relay opens after a maintenance condition has continuously existed for 30 to 35 minutes.

An LED on the detector provides a local visual indication of the detector's status. If power is applied to the detector, and it is functioning normally in standby, the status LED blinks every ten seconds. The LED latches on in alarm and quits flashing when the detector deviates from its sensitivity range.

Figure 1. Surface mounting of 2112/24TSRB smoke detector on 3<sup>1</sup>/<sub>2</sub>-inch and 4-inch octagonal box:



## **Mounting**

The 2112/24TSRB detector is supplied with a mounting bracket that permits the detector to be mounted:

- 1. To a single gang box, or
- 2. Directly to a 31/2-inch or 4 inch octagonal box, or
- 3. To a 4 inch square electrical box by using a plaster ring.

## **Tamper-resistant Feature**

This detector includes a tamper-resistant feature that prevents its removal from the bracket without the use of a tool. To make the detector tamper-resistant, remove the smaller tab by breaking it at the scribed line on the tamper resistant tab on the detector mounting bracket (see Figure 2), then install the detector. To remove the detector from the bracket once it has been made tamper resistant, use a small screwdriver to depress the tamper-resistant tab, located in the slot on the mounting bracket, and turn the detector counterclockwise.

#### **Wiring Installation Guidelines**

All wiring must be installed in compliance with the National Electrical Code, applicable local codes, and any special requirements of the local authority having jurisdiction. Proper wire gauges should be used. The conductors used to connect smoke detectors to control panels and accessory devices should be color-coded to reduce the likelihood of wiring errors. Improper connections can prevent a system from responding properly in the event of a fire.

The screw terminal block accepts 14 – 22 gauge wire. For best system performance, all wiring should be installed in separate grounded conduit. Do not mix fire system wiring in the same conduit as any other electrical wiring. Twisted pair may be used to provide additional protection against electrical interference.

Smoke detectors and alarm system control panels have specifications for allowable loop resistance. Consult the control panel specifications for the total loop resistance allowed for the control panel being used before wiring the detector loops.

Wire connections are made by stripping about 1/4 inch of insulation from the end of the feed wire, inserting the wire into the appropriate terminal, and tightening the screw to secure the wire in place.

NOTE: Trouble relay must be wired last in the circuit.


#### Installation

# **▲**WARNING

Remove power from the control unit or initiating device circuits before installing detectors.


- 1. Wire the plug-in screw terminal block per Figure 3 and plug the terminal block into the detector.
- 2. Align the arrows on the detector with the arrows on the mounting bracket.
- 3. Turn the detector clockwise in the mounting bracket until it clicks into place.
- 4. After all detectors have been installed, apply power to the control unit or initiating device circuits.
- 5. Test the detector as described in **TESTING**.
- 6. Reset the detector at the system control panel.
- 7. Notify the proper authorities the system is in operation.

Figure 2. Smoke detector mounting bracket:



D200-61-00 2 156-930-02

Figure 3. Wiring diagram for the 2112/24TSRB detector:



A78-2336-02

## **A**CAUTION

Dust covers are an effective way to limit the entry of dust into smoke detector sensing chambers. However, they may not completely prevent airborne dust particles from entering the detector. Therefore, System Sensor recommends the removal of detectors before beginning construction or other dust producing activity. Be sure to remove dust covers from any sensors that were left in place during construction as part of returning the system to service.

## **Testing**

**NOTE:** Before testing, notify the proper authorities that the smoke detector system is undergoing maintenance and will be temporarily out of service. Disable the zone or system undergoing maintenance to prevent unwanted alarms.

Detectors must be tested after installation and following periodic maintenance. Test the 2112/24TSRB as follows:

#### A. Test Switch

- 1. A recessed test switch is located on the detector housing (See Figure 4).
- 2. Press and hold the recessed test switch with a 0.1 inch maximum diameter tool such as an allen wrench or small screwdriver.
- 3. The detector's LED should light within 5 seconds.

- B. Test Module (System Sensor Model No. MOD400R). The MOD400R test module can be used with a DMM or analog voltmeter to check the detector sensitivity as described in the test module's manual.
- C. Smoke Entry Test

  Hold a smoldering punk stick or cotton wick at the side
  of the detector and gently blow smoke through the detector until the unit alarms.
- D. Direct Heat Method (Hair dryer of 1000-1500 watts).


  Direct the heat toward either of the side thermistors.

  Hold the heat source about 12 inches from the detector in order to avoid damage to the plastic. The detector will reset only after it has had sufficient time to cool and the power source has been momentarily interrupted.

Both smoke and heat detection testing are recommended for verifying system protection capability.

A detector that fails to activate with any of the above tests should first be cleaned as outlined in **MAINTENANCE**. If the detector still fails to activate, return it for repair. Notify the proper authorities the system is in operation.

Figure 4. Top and side views showing position of test switch:



D200-61-00 3 156-930-02

#### **Maintenance**


It is recommended that the detector be removed from its mounting base to facilitate cleaning. The detector is cleaned as follows:

**NOTE:** Before removing the detector, notify the proper authorities that the smoke detector system is undergoing maintenance and will be temporarily out of service. Disable the zone or system undergoing maintenance to prevent unwanted alarms.

- 1. Remove the detector cover by prying away the four side tabs with a small-bladed screwdriver, and then pulling the cover from the base.
- 2. Vacuum the screen carefully without removing it. If further cleaning is required continue with Step 3, otherwise skip to Step 8.
- 3. Remove the screen assembly by pulling it straight out (see Figure 5).
- 4. Remove the sensing chamber cover by pulling it straight out.
- 5. Clean the vaned chamber piece by vacuuming or blowing out dust and particles.
- 6. Replace the sensing chamber cover, aligning the arrow on the top with arrow on the printed circuit board.
- 7. To replace the screen, place it over the chamber assembly, turning it until it snaps into place.

- 8. Replace the cover using the test module socket and LEDs to align the cover and then gently pushing it until it locks into place.
- 9. Reinstall the detector.
- 10. Test the detector as described in TESTING.
- 11. Reconnect disabled circuits.
- 12. Notify the proper authorities that the system is back on line.

Figure 5. Removal of cover and screen for cleaning:



## **▲**WARNING

#### **The Limitations of Property Protection Smoke Detectors**

This smoke detector is designed to **activate and initiate** emergency action, but will do so only when it is used in conjunction with an authorized fire alarm system. This detector must be installed in accordance with NFPA standard 72.

**Smoke detectors will not work without power.** AC or DC powered smoke detectors will not work if the power supply is cut off.

Smoke detectors will not sense fires which start where smoke does not reach the detectors. Smoldering fires typically do not generate a lot of heat which is needed to drive the smoke up to the ceiling where the smoke detector is usually located. For this reason, there may be large delays in detecting a smoldering fire with either an ionization type detector or a photoelectric type detector. Either one of them may alarm only after flaming has initiated which will generate the heat needed to drive the smoke to the ceiling.

Smoke from fires in chimneys, in walls, on roofs or on the other side of a closed door(s) may not reach the smoke detector and alarm it. A detector cannot detect a fire developing on another level of a building quickly or at all. For these reasons, detectors **shall be located on every level and in every bedroom within a building.** 

**Smoke detectors have sensing limitations, too.** Ionization detectors and photoelectric detectors are required to pass fire tests of the flaming and smoldering type. This is to ensure that both can detect a wide range of

types of fires. Ionization detectors offer a broad range of fire sensing capability but they are somewhat better at detecting fast flaming fires than slow smoldering fires. Photoelectric detectors sense smoldering fires better than flaming fires which have little, if any, visible smoke. Because fires develop in different ways and are often unpredictable in their growth, neither type of detector is always best, and a given detector may not always provide early warning of a specific type of fire.

In general, detectors cannot be expected to provide warnings for fires resulting from inadequate fire protection practices, violent explosions, escaping gases which ignite, improper storage of flammable liquids like cleaning solvents which ignite, other similar safety hazards, arson, smoking in bed, children playing with matches or lighters, etc. Smoke detectors used in high air velocity conditions may have a delay in alarm due to dilution of smoke densities created by frequent and rapid air exchanges. Additionally, high air velocity environments may create increased dust contamination, demanding more frequent maintenance.

**Smoke detectors cannot last forever.** Smoke detectors contain electronic parts. Even though smoke detectors are made to last over 10 years, any part can fail at any time. Therefore, smoke detectors shall be replaced after being in service for 10 years. The smoke detector system that this detector is used in must be tested regularly per NFPA 72. This smoke detector should be cleaned regularly per NFPA 72 or at least once a year.

#### **Three-Year Limited Warranty**

System Sensor warrants its enclosed smoke detector to be free from defects in materials and workmanship under normal use and service for a period of three years from date of manufacture. System Sensor makes no other express warranty for this smoke detector. No agent, representative, dealer, or employee of the Company has the authority to increase or alter the obligations or limitations of this Warranty. The Company's obligation of this Warranty shall be limited to the repair or replacement of any part of the smoke detector which is found to be defective in materials or workmanship under normal use and service during the three year period commencing with the date of manufacture. After phoning System Sensor's toll free number 800-SENSOR2 (736-7672) for a Return Authorization number, send defective units postage prepaid to: System Sensor, Repair

Department, RA #\_\_\_\_\_\_, 3825 Ohio Avenue, St. Charles, IL 60174. Please include a note describing the malfunction and suspected cause of failure. The Company shall not be obligated to repair or replace units which are found to be defective because of damage, unreasonable use, modifications, or alterations occurring after the date of manufacture. In no case shall the Company be liable for any consequential or incidental damages for breach of this or any other Warranty, expressed or implied whatsoever, even if the loss or damage is caused by the Company's negligence or fault. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com