

Micro HI-FI Component System

Operating Instructions

DAB
Digital Audio Broadcasting

**COMPACT
disc
DIGITAL AUDIO**

CD R·D·S

CMT-GPX9DAB


WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To prevent fire, do not cover the ventilation of the apparatus with news papers, table-cloths, curtains, etc. And don't place lighted candles on the apparatus.

To prevent fire or shock hazard, do not place objects filled with liquids, such as vases, on the apparatus.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.



This appliance is classified as a CLASS 1 LASER product. This marking is located on the rear exterior.



Don't throw away the battery with general house waste, dispose of it correctly as chemical waste.

Table of Contents

How to use this manual.....	4
Overview of DAB	4
Playable discs.....	5

Getting Started

Hooking up the system.....	6
Setting the clock.....	9

CD – Play

Loading a disc	9
Playing a disc	10
— Normal Play/Shuffle Play	
Playing repeatedly.....	11
— Repeat Play	
Creating your own program	11
— Program Play	

Tuner

Scanning DAB stations	13
Presetting radio stations	13
Listening to the radio	15
— Preset Tuning	
— Manual Tuning (FM/AM bands only)	
Using the Radio Data System on FM stations (RDS).....	16
(European model only)	

Tape – Play

Loading a tape.....	17
Playing a tape.....	17

Tape – Recording

Recording your favorite CD tracks on a tape.....	17
— CD-TAPE Synchro Recording	
Recording on a tape manually.....	18
— Manual Recording	

Sound Adjustment

Adjusting the sound.....	20
--------------------------	----

Timer

Falling asleep to music	20
— Sleep Timer	
Waking up to music.....	21
— Play Timer	
Timer recording radio programs.....	22
— Rec Timer	

Display

Turning off the display	23
— Power Saving Mode	
Viewing information about the disc in the display	23
Viewing the tuner information in the display	24

Optional Components

Hooking up optional components.....	25
Listening to audio from a connected component	26
Recording audio from a connected component	26

Troubleshooting

Problems and remedies.....	27
Messages.....	30

Additional Information

Precautions.....	31
Specifications.....	32
List of button locations and reference pages.....	35

How to use this manual

This manual mainly explains operations using the remote, but the same operations can also be performed using the buttons on the unit having the same or similar names.

Overview of DAB


DAB (Digital Audio Broadcasting) is a new multimedia broadcasting system that replaces the current FM/AM broadcast to transmit audio programmes with a quality comparable to that of CDs*.

Each DAB multiplex radio station converts programmes (services) into an ensemble, which it then broadcasts. Each service contains one or more components. All services and components are identified by name, so you can access any of them without having to know their frequencies. Furthermore, additional information (called programme associated data) can be broadcast along with the services in the form of text.

With DAB digital radio, you can enjoy:

- CD sound quality without any hiss or crackle to spoil the sound*
- both music and data services from a single tuner (this tuner does not support data services)
- the same radio stations of the same frequency from anywhere in the country
- multiple programmes (services) from a single frequency

* Some service components may not match CD quality sound.








Notes

- The status of the DAB broadcast depends on your country or region. It may not be broadcast or may be in test phase.
- DAB programmes are broadcast in Band-III (174 to 240 MHz) and/or L-Band (1452 to 1491 MHz), with each band divided into channels. Each of these channels has its own channel label. For details on the channel labels and frequencies that this tuner supports, see the Frequency Table on page 33.
- This tuner does not support data services.

Playable discs

You can play back the following discs on this system. Other discs cannot be played back.

List of playable discs

Format of discs	Disc logo
Audio CDs	
CD-R/CD-RW (audio data)	   

Discs that this system cannot play

- CD-ROMs
- CD-Rs/CD-RWs other than those recorded in the music CD format.
- Discs with non-standard shapes (e.g., heart, square, star) cannot be played on this unit. Attempting to do so may damage the unit. Do not use such discs.
- A disc with paper or stickers on it.
- A disc that has the adhesive, cellophane tape, or a sticker still left on it.
- An 8 cm disc with an adaptor

Notes on CD-R and CD-RW

- Some CD-Rs or CD-RWs cannot be played on this system depending upon the recording quality or physical condition of the disc, or the characteristics of the recording device. Furthermore, the disc will not play if it has not been correctly finalized. For more information, see the operating instructions for the recording device.
- Discs recorded on CD-R/CD-RW drives may not be played back because of scratches, dirt, recording condition or the driver's characteristics.
- The following discs take a longer time to start playback.
 - a disc recorded with complicated tree structure.
 - a disc to which data can be added (non-finalized disc).


Music discs encoded with copyright protection technologies

This product is designed to playback discs that conform to the Compact Disc (CD) standard. Recently, various music discs encoded with copyright protection technologies are marketed by some record companies. Please be aware that among those discs, there are some that do not conform to the CD standard and may not be playable by this product.

Getting Started


Hooking up the system

Perform the following procedures **1** to **4** to hook up your system using the supplied cords and accessories.




1 Connect the speakers.

Connect the right and left speaker cords to the SPEAKER terminals as shown below.




2 Connect the FM and AM aerials.


Set up the AM loop aerial, then connect it.




Plug type (A)



Extend the FM lead aerial horizontally

Plug type ②

Extend the FM lead aerial horizontally

Plug type ③

North American models:
Connect using the white side
Other models:
Connect using the brown side

Note

To prevent noise pickup, keep the aerials away from the speaker cords.


Tip

You can use the same lead aerial for both DAB and FM connection. Use the white side connector for DAB connection and the brown side connector for FM connection.


3 Connect the DAB aerial.

With a DAB external aerial, you can obtain a higher DAB broadcast sound quality. We recommend that you use the supplied DAB/FM lead aerial only temporarily until you install a DAB external aerial.

Connect the supplied DAB/FM lead aerial to the DAB terminal on the back of this unit.



Connect a DAB external aerial (not supplied) to the DAB terminal on the back of this unit.

**Tip**

To install the DAB external aerial (not supplied), 75-ohm coaxial cable with F male type connector (not supplied) will be needed.


4 Connect the mains lead to mains.

If the plug does not fit the wall socket, detach the supplied plug adaptor (only for models equipped with an adaptor).

To turn on the system, press I/⏻.

continued

Inserting two R6 (size AA) batteries into the remote



Note

If you do not use the remote for a long period of time, remove the batteries to avoid possible damage from battery leakage and corrosion.

Tip

With normal use, the batteries should last for about six months. When the remote no longer operates the system, replace both batteries with new ones.

When carrying this system

Perform the following procedure to protect the CD mechanism.

Use buttons on the unit for the operation.

- 1** Press I/⏻ to turn on the system, then press FUNCTION repeatedly to switch the function to CD.
- 2** Make sure that no disc is loaded in the disc tray.
- 3** Hold down CD ■, and then press TUNING MODE and I/⏻ until “STANDBY” appears. After a few seconds later, “STANDBY” disappears and “LOCK” appears.
- 4** Unplug the mains lead.

Setting the clock

Use buttons on the remote for the operation.

- 1 Press **I/⏻** to turn on the unit.
- 2 Press **CLOCK/TIMER SET**.
- 3 Press **I◀◀** or **▶▶I** repeatedly to set the hour.
- 4 Press **ENTER**.
- 5 Press **I◀◀** or **▶▶I** repeatedly to set the minute.
- 6 Press **ENTER**.

The clock starts working.

To adjust the clock

- 1 Press **CLOCK/TIMER SET**.
- 2 Press **I◀◀** or **▶▶I** repeatedly to select "CLOCK SET", then press **ENTER**.
- 3 Do the same procedures as step 3 to 6 above.

Note


The clock is not displayed in Power Saving Mode (page 23).

CD – Play

Loading a disc

- 1 Press **CD** (or **FUNCTION** repeatedly on the unit) to switch the function to **CD**.
- 2 Insert a disc in the disc slot with the label side up.

When you play a disc, insert it with the label side up.




Notes

- When you turn on the system, the disc is not pulled into the disc slot until "NO DISC" appears in the display. Do not attempt to push in the disc until "NO DISC" appears.
- Do not use a disc with tape, seals or paste on it as this may cause malfunction.
- Do not load an 8 cm disc with an adaptor. Doing so may cause the system to malfunction.
- When you remove a disc, handle the disc by its edge and pull it straight out of the disc slot. Do not touch the surface.
- If you load a disc that is not playable by this system, it will be ejected automatically.

Playing a disc

— Normal Play/Shuffle Play

You can play audio CDs.



- 1 Press CD (or FUNCTION repeatedly) to switch the function to CD.**
- 2 Press PLAY MODE repeatedly in stop mode until the mode you want appears in the display.**

Select	To play
No display (Normal Play)	The tracks on the disc you have selected in original order.
SHUF (Shuffle Play)	All the tracks on the disc you have selected in random order.
PGM (Program Play)	The tracks on the disc in the order you want them to be played (see “Creating your own program” on page 11).

- 3 Press ► (or CD/►|| on the unit).**

Other operations

To	Do this
Stop play	Press ■ (CD stop).
Pause	Press (or CD/► on the unit). Press again to resume play.
Select a track	Press ◀◀ or ▶▶ repeatedly.
Find a point in a track	Keep pressing ◀◀ or ▶▶ during playback and release it at the desired point.
Remove a disc	Press CD ⇄ on the unit.

Notes

- You cannot change the play mode during playback.
- Some time may be needed to start playback of discs recorded in complex configurations such as many layers.

Tip

When disc access takes a long time, set “CD POWER” and “ON” by CD power manage function (page 14).

Playing repeatedly

— Repeat Play

You can play all the tracks or a single track on a disc repeatedly.

Press **REPEAT** repeatedly during playback until “REP” or “REP 1” appears.

REP: For all tracks up to five times.

REP 1: For a single track only.

To cancel Repeat Play

Press **REPEAT** repeatedly until both “REP” and “REP 1” disappear.

Note


When you select “REP 1”, that track is repeated endlessly until “REP 1” is canceled.

Creating your own program

— Program Play

You can make a program of up to 25 steps. You can synchro record the programmed tracks onto a cassette tape (page 17).

- 1** Press **CD** (or **FUNCTION** repeatedly) to switch the function to **CD**.
- 2** Press **PLAY MODE** repeatedly in stop mode until “**PGM**” appears.
- 3** Press **◀◀** or **▶▶** repeatedly until the desired track number appears.



- 4** Press **ENTER**.
The track is programmed.
The program step number appears, followed by the last programmed track number and total playing time.
- 5** To program additional tracks, repeat steps 3 and 4.
- 6** Press **▶** (or **CD/▶▶** on the unit).
Program Play starts.

continued

Other operations

To	Do this
Cancel Program Play	Press PLAY MODE repeatedly in stop mode until "PGM" disappears.
Erase the program	Press CLEAR in step 4. Each time you press the button, a track is cleared from the end of the program.
Add a track to the end of the program	Perform steps 3 and 4 in stop mode.

Note

You cannot erase program during playback.

Tips

- The program you made remains after Program Play finishes. To play the same program again, press CD (or FUNCTION repeatedly) to switch the function to CD, then press ► (or CD/►|| on the unit). However, the program is cleared when you eject the disc.
- "– – –" appears if the total program time exceeds 100 minutes, if you select a track whose number is 21 or over.
- If you select "AL" in step 3, you can select all tracks on the disc at once.

Scanning DAB stations

Before you can receive DAB, you must register the contents of broadcasts (service components) so that they can be received by the DAB tuner using the DAB Automatic Scan procedure.

DAB Automatic Scan

DAB Automatic Scan starts automatically only when you plug in the mains lead for the first time after you purchase the system.

If you want to use the DAB Automatic Scan again, perform the procedure below.

Press TAPE ■ and TUNING MODE simultaneously.

Scanning begins. Depending on the DAB services available in your area, this may take a few minutes.

When scanning is complete, available service component list is created.

Notes

- If your country or region does not support DAB broadcast, “NO SERV” appears.
- Do not press any button on the unit or supplied remote during DAB Automatic Scan. Scanning is interrupted and service component list may not be created properly. In this case, perform the DAB Automatic Scan again.
- If you move to another area, repeat this procedure to store the stations for your new area.
- This procedure clears all previously stored presets.
- This procedure does not create any presets.

Presetting radio stations

You can preset up to 20 DAB stations, 20 FM stations and 10 AM stations. You can then tune in any of those stations simply by selecting the corresponding preset number.

Automatic tuning preset

You can automatically tune in all of the service components or stations that can be received in your area and then store them.

- 1 Press TUNER BAND (or FUNCTION repeatedly) to switch the function to TUNER.**
- 2 Press TUNER BAND repeatedly to select “DAB”, “FM” or “AM”.**
You can also use the DAB button to select DAB directly.
- 3 Press TUNING MODE repeatedly until “AUTO” appears in the display.**
- 4 Press + or – (or TUNING + or – on the unit).**

Service component list is played downward (DAB) or the frequency changes as the system scans for a station (FM/AM). Scanning stops automatically when a station is tuned in. At that time, “TUNED” and “STEREO” (for stereo program only) appear.


If “TUNED” does not appear and the scanning does not stop

Set the frequency of the desired radio station as described in steps 3 and 4 of “Manual tuning preset” (page 14).

Manual tuning is not available for DAB.

- 5 Press TUNER MEMORY.**

A preset number flashes. Perform steps 6 and 7 while the preset number flashes.



continued

6 Press + or – (or TUNING + or – on the unit) repeatedly to select the desired preset number.

7 Press ENTER.

8 Repeat steps 4 through 7 to preset other stations.

Notes

- When tuning in a DAB station, it may take a few seconds before you hear any sound.
- Before you can receive DAB, you must complete the DAB Automatic Scan procedure (see “Scanning DAB stations” on page 13).
- You cannot preset the service component while “TUNED” is not displayed (DAB only).

Tip

Press TUNING MODE to stop scanning (FM/AM bands only).

Manual tuning preset (FM/AM bands only)

You can manually tune in and store the radio frequency of the desired stations.

1 Press TUNER BAND (or FUNCTION repeatedly) to switch the function to TUNER.

2 Press TUNER BAND repeatedly to select “FM” or “AM”.

3 Press TUNING MODE repeatedly until “AUTO” and “PRESET” disappear from the display.

4 Press + or – (or TUNING + or – on the unit) repeatedly to tune in the desired station.

5 Press TUNER MEMORY.

6 Press + or – (or TUNING + or – on the unit) repeatedly to select the desired preset number.

7 Press ENTER.

8 Repeat steps 4 through 7 to preset other stations.

Other Operations

To	Do this
Tune in a station with a weak signal	Follow the procedure described in “Manual tuning preset (FM/AM bands only)”.
Set another station to the existing preset number	After step 5, press + or – (or TUNING + or – on the unit) repeatedly to select the preset number of the station you want to store.

To change the AM tuning interval (Except for European model)

The AM tuning interval is factory-preset to 9 kHz (or 10 kHz for some areas). To change the AM tuning interval, tune into any AM station first, then turn off the system.

While holding TUNING +, press I/⏻ on the unit.

When you change the interval, all AM preset stations are erased. To reset the interval, repeat the same procedure.

Note

You cannot change the AM tuning interval in Power Saving Mode (page 23).

Tips

- The preset stations are retained for about half a day even if you disconnect the mains lead or if a power failure occurs.
- To improve broadcast reception, adjust the supplied aerials, or connect a commercially available external aerial.

To improve tuner reception

When tuner reception is poor, set CD player power off by the CD power manage function. CD power is factory set to on.

Use buttons on the unit for the operation.

1 Press FUNCTION repeatedly to switch the function to CD.

2 Press I/⏻ to turn off the system.

3 After “STANDBY” stops flashing, press I/⏻ while holding CD ■. “CD POWER” and “OFF” appear.

To set the CD power on

Repeat the procedure above and “CD POWER” and “ON” appear.

Notes

- When “CD POWER” and “OFF” are selected, disc access time is increased.
- You cannot change the setting in Power Saving Mode (page 23).

Listening to the radio

You can listen to a radio station either by selecting a preset station, or by manually tuning in the station.

Listening to a preset station

— *Preset Tuning*

Preset radio stations in the tuner’s memory first (see “Presetting radio stations” on page 13).

- 1** Press **TUNER BAND** (or **FUNCTION** repeatedly) to switch the function to **TUNER**.
- 2** Press **TUNER BAND** repeatedly to select “**DAB**”, “**FM**” or “**AM**”.
You can also use the DAB button to select DAB directly.
- 3** Press **TUNING MODE** repeatedly until “**PRESET**” appears in the display.
- 4** Press **+** or **-** (or **TUNING +** or **-** on the unit) repeatedly to select the desired preset station.

Note

If there is no stored preset station, “NO PRESET” appears (DAB only).

Listening to non-preset radio station

— *Manual Tuning (FM/AM bands only)*

- 1** Press **TUNER BAND** (or **FUNCTION** repeatedly) to switch the function to **TUNER**.
- 2** Press **TUNER BAND** repeatedly to select “**FM**” or “**AM**”.
- 3** Press **TUNING MODE** repeatedly until “**AUTO**” and “**PRESET**” disappear from the display.
- 4** Press **+** or **-** (or **TUNING +** or **-** on the unit) repeatedly to tune in the desired station.

continued

Note

When switching to CD function from tuner, a longer time may be required to access the disc. In this case, set "CD POWER" and "ON" by CD power manage function (page 14).

Tips

- To improve broadcast reception, adjust the supplied aerials, or connect a commercially available external aerial.
- When an FM stereo program has static noise, press FM MODE repeatedly until "MONO" appears. There will be no stereo effect, but the reception will improve.
- Press TUNING MODE repeatedly until "AUTO" appears in step 3 above, then press + or - (or TUNING + or - on the unit). The frequency indication changes and scanning stops when the system tunes in a station (Automatic Tuning).
- To record the radio programs, use manual recording (page 18).
- When receiving DAB station that carries DRC (Dynamic Range Control) data, "DRC" appears in the display.
- "SECONDARY" appears in the display when receiving secondary service (DAB only).
- Primary service is automatically received when secondary service ends.

Using the Radio Data System on FM stations (RDS)

(European model only)

What is the Radio Data System?

Radio Data System (RDS) is a broadcasting service that allows radio stations to send additional information along with the regular program signal. RDS is available only on FM stations.*

Note

RDS may not work properly if the station you are tuned in is not transmitting the RDS signal properly or if the signal is weak.

* Not all FM stations provide RDS service, nor do they provide the same types of services. If you are not familiar with the RDS system, check with your local radio stations for details on RDS services in your area.

Receiving RDS broadcasts

Simply select a station from the FM band.

When you tune in a station that provides RDS services, the station name appears in the display.

To check the RDS information

Each time you press DISPLAY the display changes cyclically as follows:


Station name* → Frequency → Clock display
→ Bass level → Treble level

* If the RDS broadcast is not properly received, the station name may not appear in the display.

Tape – Play

Loading a tape

- 1 Press \triangle PUSH EJECT on the unit.
- 2 Load a recorded/recordable tape into the cassette holder.



Playing a tape

You can use TYPE I (normal) tape.

- 1 Load a tape.
- 2 Press TAPE (or FUNCTION repeatedly) to switch the function to TAPE.
- 3 Press DIRECTION on the unit repeatedly to select “ \rightleftarrows ” to play one side of a tape, “ \leftrightarrow ” to play both sides, or “ \rightleftarrows ”* to play both sides repeatedly.
* The tape deck stops automatically after repeating the sequence five times.
- 4 Press \blacktriangleright (or TAPE/ $\blacktriangleleft\blacktriangleright$ on the unit).
The tape starts playing. Press the button again to play the reverse side.

Other operations

To	Do this
Stop play	Press \blacksquare (TAPE stop).
Pause	Press \blacksquare . Press again to resume play.
Fast-forward or rewind	Press \blacktriangleleft or \blacktriangleright .
Remove a tape	Press \triangle PUSH EJECT on the unit in stop mode.

Note

You cannot eject the tape during playback or recording.

Tape – Recording

Recording your favorite CD tracks on a tape

— CD-TAPE Synchro Recording

You can record a whole CD on a tape. You can use TYPE I (normal) tape. The recording level is adjusted automatically. Use buttons on the unit for the operation.

- 1 Load a recordable tape.
- 2 Press FUNCTION repeatedly to switch the function to CD and load a disc you want to record.
- 3 Press CD SYNCHRO on the unit. “SYNC”, “REC” and “ \blacktriangleright ” (or “ \blacktriangleleft ”) appear.
The tape deck stands by for recording and the CD player pauses for playback.
- 4 Press DIRECTION repeatedly to select “ \rightleftarrows ” to record on one side or “ \leftrightarrow ” (or “ \rightleftarrows ”) to record on both sides.
- 5 Press TAPE/ $\blacktriangleleft\blacktriangleright$ repeatedly to select the recording side.
If you select both sides recording or front side recording, press TAPE/ $\blacktriangleleft\blacktriangleright$ until “ \blacktriangleright ” appears. If you record on the reverse side, press TAPE/ $\blacktriangleleft\blacktriangleright$ again until “ \blacktriangleleft ” appears.
- 6 Press \bullet REC PAUSE/START.
Recording starts.
When the recording is completed, the CD player and the tape deck stop automatically.

To stop recording

Press \blacksquare .

To record a disc by specifying track order

You can record only your favorite CD tracks using Program Play. Between steps 2 and 3, perform steps 2 to 6 of “Creating your own program” (page 11).

Tip

If you select both sides recording and the tape reaches the end of the front side part-way through a track, the entire track is recorded again from the beginning of the reverse side.

Recording on a tape manually

— Manual Recording

You can record just the portions you like from a CD or radio program on a tape.

You can also record from connected components (see “Hooking up optional components” on page 25).

Use buttons on the unit for the operation.

- 1 Load a recordable tape.**
- 2 Press FUNCTION repeatedly to switch the function to TAPE.**
- 3 Press FUNCTION repeatedly to select the desired source to record.**
 - TUNER: To record from this system’s tuner.
 - CD: To record from this system’s CD player.
 - AUDIO IN: To record from the optional component connected to the AUDIO IN jacks.
- 4 Press ● REC PAUSE/START.**

“REC” flashes and “▶” (or “◀”) appears and the tape deck stands by for recording.
- 5 Press DIRECTION repeatedly to select “→” to record on one side or “↔” (or “↔”)** to record on both sides.
- 6 Press TAPE/◀▶ repeatedly to select the recording side.**

If you select both sides recording or front side recording, press TAPE/◀▶ until “▶” appears. If you record on the reverse side, press TAPE/◀▶ again until “◀” appears.
- 7 Press ● REC PAUSE/START, then start playing the desired source to record.**

Recording starts.

Other operations

To	Do this
Stop recording	Press ■ (TAPE stop).
Pause recording	Press ● REC PAUSE/START.

Notes

- When you record on both sides, be sure to start from the front side. If you start from the reverse side, recording stops at the end of the reverse side.
- You cannot listen to other sources while recording. Recording stops if you change the function to another one.

Tips

- For recording from a CD, you can press ◀◀ or ▶▶ to select tracks during recording pause mode (after step 4 and before step 6).
- For recording from the tuner:
If noise is heard while recording from the tuner, move the respective aerial to reduce the noise.

Sound Adjustment

Adjusting the sound

You can adjust the bass and treble to enjoy more powerful sound.

Generating a more dynamic sound (Dynamic Sound Generator X-tra)

Press **DSGX** on the unit.

Each time you press the button, the display changes as follows: DSGX ON* ↔ DSGX OFF

* The “DSGX ON” display appears.

Adjusting the bass and treble

You can adjust the bass and treble.

1 Press **EQ** repeatedly to select “**BASS**” or “**TREBLE**”.

Each time you press the button, the display changes as follows:

BASS ↔ TREBLE

2 Press **◀◀** or **▶▶** repeatedly to adjust the level while “**BASS**” or “**TREBLE**” appears.

To adjust the bass on the unit

Turn BASS control.

To adjust the treble on the unit

Turn TREBLE control.

To exit the bass and treble settings

Press any button other than EQ, **◀◀** or **▶▶**. Also if you do not perform any operations for a few seconds, the display automatically returns to the original display.

Timer

Falling asleep to music

— Sleep Timer

You can set the system to turn off after a certain time, so that you can fall asleep to music.

Press **SLEEP** repeatedly.

Each time you press the button, the minute display (the turn-off time) changes cyclically as follows:

AUTO* → 90MIN → 80MIN → ... → 10MIN → SLEEP OFF

* The system automatically turns off in 100 minutes or after the current disc or tape finishes playing.

Other operations

To	Press
Check the remaining time*	SLEEP once.
Change the time to turn off	SLEEP repeatedly to select the time you want.
Cancel the Sleep Timer function	SLEEP repeatedly until “SLEEP OFF” appears.

* You cannot check the remaining time if you select “AUTO”.

Tip

You can use Sleep Timer, even if you have not set the clock.

Waking up to music

— Play Timer

You can wake up to music at a preset time. Make sure you have set the clock (see “Setting the clock” on page 9).

Use buttons on the remote for the operation.

1 Prepare the sound source you want to play.

- CD: Load a disc. To start from a specific track, make a program (see “Creating your own program” on page 11).
- TAPE: Load a tape (see “Playing a tape” on page 17).
- TUNER: Tune in a preset radio station (see “Listening to the radio” on page 15).

2 Press VOLUME + or – to adjust the volume.

3 Press CLOCK/TIMER SET.

4 Press ◀◀ or ▶▶ repeatedly to select “PLAY SET”, then press ENTER.

“ON” appears and the hour indication flashes.

5 Set the time to start playing.

Press ◀◀ or ▶▶ repeatedly to set the hour, then press ENTER.


The minute indication flashes.

Press ◀◀ or ▶▶ repeatedly to set the minute, then press ENTER.

6 Set the time to stop playing following the same procedure as step 5.

7 Press ◀◀ or ▶▶ repeatedly until the desired sound source appears.

Each time you press the button the display changes cyclically as follows:



8 Press ENTER.

The start time, the stop time and the sound source appear in turn, then the original display returns.

9 Press I/⏻ to turn off the system.

Other operations

To	Do this
Activate the timer/ check the setting	<ol style="list-style-type: none"> 1 Press CLOCK/TIMER SELECT. 2 Press ◀◀ or ▶▶ repeatedly until “PLAY SEL” appears, then press ENTER.
Change the setting	Start over from step 1.
Cancel the timer	<ol style="list-style-type: none"> 1 Press CLOCK/TIMER SELECT. 2 Press ◀◀ or ▶▶ repeatedly until “TIMER OFF” appears, then press ENTER.

Notes

- If you use the Play Timer and the Sleep Timer at the same time, the Sleep Timer has priority.
- Do not operate the system from the time the system turns on until the play starts (about 15 seconds before the preset time).
- If the system is on about 15 seconds before the preset time, Play Timer will not be activated.
- You cannot use the optional component connected to the AUDIO IN jacks as sound sources for Play Timer.
- You cannot activate Play Timer and the Rec Timer at the same time.
- The Play Timer setting remains as long as the setting is not canceled manually.

Timer recording radio programs

— Rec Timer

You can record a preset radio station from a specified time.

To timer record, you must first preset the radio station (see “Presetting radio stations” on page 13) and set the clock (see “Setting the clock” on page 9).

- 1 Tune in the preset radio station (see “Listening to a preset station” on page 15).**
- 2 Press CLOCK/TIMER SET.**
- 3 Press \lll or \ggg repeatedly to select “REC SET”, then press ENTER.**
“ON” appears and the hour indication flashes.
- 4 Set the time to start recording.**
Press \lll or \ggg repeatedly to set the hour, then press ENTER.
The minute indication flashes.
Press \lll or \ggg repeatedly to set the minute, then press ENTER.
- 5 Set the time to stop recording following the same procedure as step 4.**
The start time, the stop time, and the preset radio station to be recorded (e.g., “FM 5”) appear in turn, before the original display returns.
- 6 Load a recordable tape.**
- 7 Press DIRECTION on the unit repeatedly to select “ \rightleftarrows ” to record on one side or “ \rightarrow ” (or “ \leftarrow ”) to record on both sides.**
- 8 Press \blacktriangleright (or TAPE/ \blacktriangleleft) on the unit) repeatedly to select the recording side.**
If you select both sides recording or front side recording, press \blacktriangleright (or TAPE/ \blacktriangleleft) on the unit) until “ \blacktriangleright ” appears. If you record on the reverse side, press \blacktriangleright (or TAPE/ \blacktriangleleft) on the unit) again until “ \blacktriangleleft ” appears.
- 9 Press I/⏻ to turn off the system.**

Other operations

To	Do this
Activate the timer/ check the setting	1 Press CLOCK/TIMER SELECT. 2 Press \lll or \ggg repeatedly until “REC SEL” appears, then press ENTER.
Change the setting	Start over from step 1.
Cancel the timer	1 Press CLOCK/TIMER SELECT. 2 Press \lll or \ggg repeatedly until “TIMER OFF” appears, then press ENTER.

Notes

- If you use the Rec Timer and the Sleep Timer at the same time, the Sleep Timer has priority.
- Do not operate the system from the time the system turns on until the recording starts (about 15 seconds before the preset time).
- If the system is on about 15 seconds before the preset time, Rec Timer will not be activated.
- The volume is reduced to minimum during recording.
- Note that if Rec Timer is set at the same time as Play Timer sound source is set to tape, Rec Timer sound may be recorded onto the tape.
- You cannot activate the Play Timer and the Rec Timer at the same time.
- The Rec Timer is canceled automatically after the Rec Timer has been activated.

Display

Turning off the display

— Power Saving Mode

The clock display can be turned off to minimize the amount of power consumed during standby (Power Saving Mode).

Press DISPLAY repeatedly while the system is off until the clock display disappears.

To cancel Power Saving Mode

Press DISPLAY while the system is off. Each time you press the button, the display switches cyclically as follows:

Clock display* ↔ No display (Power Saving Mode)

* The clock is displayed only if you set the clock.

Note

You cannot perform the following operations in Power Saving Mode.

- setting the clock
- switching the AUDIO IN function
- changing the CD power manage function
- changing the AM tuning interval (except for European model)

Tips

- STANDBY indicator lights up even in Power Saving Mode.
- The timer continues to operate in Power Saving Mode.

Viewing information about the disc in the display

You can check the playing time and remaining time of the current track or that of the disc.

Checking the remaining time

Press DISPLAY during Normal Play.

Each time you press the button, the display changes cyclically as follows:

Current track number and elapsed playing time → Current track number and remaining time → Remaining time of the disc¹⁾ → Clock display (for eight seconds) → Bass level (for eight seconds) → Treble level (for eight seconds)
¹⁾ “- - - -” appears in Program Play mode.

Note

When fast forward or fast reverse is performed, elapsed playing time and remaining time of the track may not be displayed accurately.

Checking the total playing time

Press DISPLAY repeatedly in stop mode.

Each time you press the button, the display changes cyclically as follows:

■ Normal Play mode

TOC display* → Clock display (for eight seconds) → Bass level (for eight seconds) → Treble level (for eight seconds)

* TOC = Table of Contents; displays total number of tracks on the disc, and total playing time of the disc

■ Program Play mode

The last track number of the program and the total playing time → Total track number of the program (for eight seconds) → Clock display (for eight seconds) → Bass level (for eight seconds) → Treble level (for eight seconds)

Viewing the tuner information in the display

Press DISPLAY while listening to the radio.

Each time you press the button, the display changes cyclically as follows:
Station name¹⁾ → Preset number²⁾ and frequency → Clock display (for eight seconds) → Bass level (for eight seconds) → Treble level (for eight seconds)

¹⁾European model only

²⁾Preset number is displayed only if you preset radio stations (page 13).

Checking the DAB station information

You can check the status of this tuner and the information about the program using the display.

Press DISPLAY repeatedly when tuning in a DAB station.

Each time you press the button, the display changes cyclically as follows:
Service component label → Preset number + Frequency (for two seconds)¹⁾ → Channel label + Frequency (for two seconds) → DLS (Dynamic Label Segment)²⁾ → Ensemble label (until scroll ends)³⁾ → Clock display (for eight seconds) → Bass level (for eight seconds) → Treble level (for eight seconds)

¹⁾Preset number is displayed only if you preset radio stations (page 13).

²⁾If there is no information in a service component, “NO TEXT” appears.

³⁾If an ensemble does not have a label, “NO LABEL” appears.


Note

When “STEREO” appears in the display, the current programme is broadcasted in the stereo/joint (intensity) stereo mode.

Optional Components

Hooking up optional components

To enhance your system, you can connect optional components. Refer to the operating instructions provided with each component.



A AUDIO IN jacks

Use audio cords (not supplied) to connect an optional analog component (MiniDisc player/recorder or VCR, etc.) to these jacks. You can then record or listen to the sound from the component through this system.

Notes

- Before connecting or disconnecting the audio cord (not supplied), press VOLUME – repeatedly (or turn the VOLUME control on the unit counterclockwise) to turn down the volume.
- Disconnect the audio cords when not using optional components.

Listening to audio from a connected component

- 1 Connect the audio cord.**
See “Hooking up optional components” on page 25.
- 2 Press FUNCTION repeatedly until “AUDIO IN” appears.**
- 3 Start playing the connected component.**

Recording audio from a connected component

- 1 Connect audio cord.**
See “Hooking up optional components” on page 25.
- 2 Start recording manually.**
See “Recording on a tape manually” on page 18.

Troubleshooting

Problems and remedies

Should you encounter a problem with your system, do the following:

- 1 Make sure the mains lead and speaker cords are correctly and firmly connected.
- 2 Find your problem in the troubleshooting checklist below and take the indicated corrective action.

If the problem persists after doing all of the above, consult your nearest Sony dealer.

When the I/⏻ indicator flashes

Immediately unplug the mains lead and check the following items.

- If your system has a voltage selector, is the voltage selector set to the correct voltage? Check the voltage for your region, then make sure the voltage selector is set correctly.
- Are the + and – speaker cords short-circuited?
- Are you using the supplied speakers?
- Is anything blocking the ventilation holes on the rear of the system?

Check all the above items and fix any problems found. After I/⏻ indicator stops flashing, reconnect the mains lead and turn on the system. If the indicator still flashes, or if the cause of the problem cannot be found even after checking all the above items, consult your nearest Sony dealer.

General

“-- --” appears in the display.

- A power interruption has occurred. Set the clock (page 9) and timer settings (pages 21 and 22) again.

The clock setting/radio presetting/timer is canceled.

- Redo the following:
 - “Setting the clock” (page 9)
 - “Presetting radio stations” (page 13)

- “Activate the timer/check the setting” (pages 21 and 22)
- “Timer recording radio programs” (page 22)

There is no sound.

- Press VOLUME + or turn VOLUME on the unit clockwise.
- Make sure the headphones are not connected.
- Check the speaker connections (page 6).
- There is no audio output during Rec Timer.
- Connect the aerials.
- The specified station has temporarily stopped broadcast.
- Perform the DAB Automatic Scan procedure (page 13).

Sound comes from one channel, or unbalanced left and right volume.

- Place the speakers as symmetrically as possible.
- Connect the supplied speakers.

There is severe hum or noise.

- Move the system away from the source of noise.
- Connect the system to a different mains.
- Install a noise filter (commercially available) to the mains lead.

The timer cannot be set.

- Set the clock again (page 9).

The timer does not function.

- Check the timer setting and set the correct time (pages 21 and 22).
- Cancel the Sleep Timer function (page 20).
- Make sure the clock is correctly set.

The color irregularity on a TV screen persists.

- Turn off the TV set once, then turn it on after 15 to 30 minutes. If the color irregularity still persists, place the speakers farther away from the TV set.

The remote does not function.

- Remove the obstacle.
- Move the remote closer to the system.
- Point the remote at the system's sensor.
- Replace the batteries (R6/size AA).
- Locate the system away from the fluorescent light.

The system can not be turned on even though you have pressed I/⏻.

- Make sure the mains lead is connected to mains.

CD player

“LOCKED” appears.

- Contact your Sony dealer or local authorized Sony service facility.

The disc does not eject.

- You cannot eject the disc during CD Synchro Recording. Press CD ■ on the unit to cancel the CD Synchro Recording, then press CD ≡ on the unit to eject the disc.
- Consult your nearest Sony dealer.

Play does not start.

- Check whether a disc is loaded.
- Wipe the disc clean (page 31).
- Replace the disc.
- Load the disc that this system can play (page 5).
- Load the disc correctly.
- Load the disc with the label side up.
- Remove the disc and wipe away the moisture on the disc, then leave the system turned on for a few hours until the moisture evaporates.
- Press ► (or CD/►|| on the unit) to start play.

Disc access takes a long time.

- Set “CD POWER” and “ON” by CD power manage function (page 14).

The sound skips.

- Wipe the disc clean (page 31).
- Replace the disc.
- Try moving the system to a place without vibration (e.g., on top of a stable stand).
- Try moving the speakers away from the system, or placing them on separate stands. When you listen to a track with bass sounds at high volume, the speaker vibration may cause the sound to skip.

Play does not start from the first track.

- Press PLAY MODE repeatedly until both “PGM” and “SHUF” disappear to return to Normal Play.

Tuner

Severe hum or noise/stations cannot be received.

- Set the proper band and frequency (page 13).
- Connect the aerial properly (pages 6 and 7).
- Find a place and an orientation that provide good reception, then set up the aerial again. If you cannot obtain good reception, we recommend you connect a commercially available external aerial.
- The supplied FM lead aerial receives signals along its entire length, so make sure you extend it fully.
- Connect an external aerial for DAB/FM broadcasts.
- Locate the aerials as far away from the speaker cords as possible.
- Consult your nearest Sony dealer if the supplied AM aerial has come off the plastic stand.
- Try turning off surrounding electrical equipment.
- Set “CD POWER” and “OFF” by CD power manage function (page 14).

A stereo FM program cannot be received in stereo.

- Press FM MODE until “STEREO” appears in the display.

RDS isn't working.

- Make sure that you tune in an FM station.
- Select a stronger FM station.

The appropriate display or information does not appear.

- Contact the radio station and find out whether or not they actually provide the service in question. The service may be temporarily out of order.

The tuner malfunctions.

- The microprocessor in the tuner has malfunctioned. Turn off the tuner, then turn it on again.

“TUNED” does not appear in the display (DAB only).

- Check all aerial connections, then press TAPE ■ and TUNING MODE on the unit simultaneously to perform the DAB Automatic Scan.
- The current DAB service is not available. Press + or – (or TUNING + or – on the unit) to select a different service.
- If you have moved to another area, some services/frequencies may have changed and you may not be able to tune into your usual broadcast. Perform the DAB Automatic Scan procedure to re-register the contents of broadcasts. (Performing this procedure clears all previously stored presets.)

“NO SERV” is displayed (DAB only).

- Check all aerial connections, then press TAPE ■ and TUNING MODE on the unit simultaneously to perform the DAB Automatic Scan.

“SCANNING” does not disappear.

- Depending on the DAB services available in your area, scanning may take a few minutes.

Tape deck

The tape does not record or play, or there is a decrease in sound level.

- The heads are dirty. Clean them (page 32).
- The record/playback heads are magnetized. Demagnetize them (page 32).

The tape does not erase completely.

- The record/playback heads are magnetized. Demagnetize them (page 32).

There is excessive wow or flutter, or the sound drops out.

- The capstans in the tape deck are dirty. Clean them (page 32).

Noise increases or the high frequencies are erased.

- The record/playback heads are magnetized. Demagnetize them (page 32).

The tape does not record.

- No cassette is loaded. Load a cassette.
 - The tab has been removed from the cassette. Cover the broken tab with adhesive tape (page 32).
 - The tape has wound to the end.
-

Optional components

There is no sound.

- Refer to General item “There is no sound.” (page 27) and check the condition of the system.
- Connect the component properly (page 25) while checking:
 - if the cords are connected properly.
 - if the cord plugs are firmly inserted all the way.
- Turn on the connected component.
- Refer to the operating instructions supplied with the connected component and start playing.

The sound is distorted.

- Set the volume of the connected component lower.
-

If the system still does not operate properly after performing the above measures, reset the system as follows:

Use buttons on the unit for the operation.

- 1 Disconnect the mains lead.
- 2 Reconnect the mains lead.
- 3 Press I/⏻ to turn on the system.
- 4 Press CD ■, DSGX and I/⏻.

The system is reset to the factory settings. You should set the settings you made, such as the preset stations, clock, and timer.

Messages

One of the following messages may appear or flash in the display during operation.

CD

NO DISC

There is no disc in the player.

NO STEP

All of the programed tracks have been erased.

CD OVER

You have reached the end of the disc while pressing
▶▶ during playback or pause.

STEP FULL

You tried to program 25 or more tracks (steps).

PUSH STOP

You pressed PLAY MODE during playback.

Tuner

COMPLETE

The preset operation ended normally.

NO SERV (DAB only)

There is no supported DAB broadcast in your country or region.

NO PRESET (DAB only)

There is no stored preset station.

Tape

NO TAB

You cannot record the tape because the tab has been removed from the cassette.

NO TAPE

There is no tape in the tape deck.

Timer

SET TIMER

You tried to select the timer when the Play Timer or Rec Timer are not set.

TIME NG

The Play Timer or Rec Timer start and end times are set to the same time.

PUSH SELECT

You tried to set the clock or timer during timer operation.

SET CLOCK

You tried to select the timer when the clock is not set.

Additional Information

Precautions

On operating voltage

- Before operating the system, check that the operating voltage of your system is identical with the voltage of your local power supply.

On safety

- The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.
- Unplug the system from the wall outlet (mains) if it is not to be used for an extended period of time. To disconnect the power cord (mains lead), pull it out by the plug. Never pull the cord itself.
- Should any solid object or liquid fall into the system, unplug the system and have it checked by qualified personnel before operating it any further.

On placement

- Do not place the system in an inclined position.
- Do not place the system in locations where it is;
 - Extremely hot or cold
 - Dusty or dirty
 - Very humid
 - Subject to vibrations
 - Subject to direct sunlight
- Use caution when placing the unit or speakers on surfaces that have been specially treated (with wax, oil, polish, etc.) as staining or discoloration of the surface may result.

On heat buildup

- Although the system heats up during operation, this is not a malfunction.
- Place the system in a location with adequate ventilation to prevent heat build-up in the system.
- If you continuously use this system at a high volume, the cabinet temperature of the top, side and bottom rises considerably. To avoid burning yourself, do not touch the cabinet.
- To prevent a malfunction, do not cover the ventilation hole.

On the speaker system

This speaker system is not magnetically shielded and the picture on TV sets may become magnetically distorted. In such a case, turn off the power of the TV set once, and after 15 to 30 minutes turn it on again.

If there seems to be no improvement, locate the speaker system further away from the TV set.

On operation

- If the system is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens inside the CD player. Should this occur, the system will not operate properly. Remove the disc and leave the system turned on for about an hour until the moisture evaporates.
- When you move the system, take out any disc.

If you have any questions or problems concerning your system, please consult your nearest Sony dealer.

Notes on discs


- Before playing, clean the disc with a cleaning cloth. Wipe the disc from the center out.
- Do not use solvents such as benzene, thinner, commercially available cleaners or anti-static spray intended for vinyl LPs.
- Do not expose the disc to direct sunlight or heat sources such as hot air ducts, nor leave it in a car parked in direct sunlight.
- Do not use discs encircled with a protection ring. This may cause a malfunction to the system.
- When using discs that have glue or similar tacky substance on the label side of the disc or that used a special ink when the label was printed, there is a chance that the disc or label may become attached to parts inside this unit. When this occurs, it may not be possible to remove the disc, and may also cause this unit to malfunction. Be sure to check that the label side of the disc is not sticky before using. The following types of disc should not be used:
 - Rental or used discs with attached seals where the glue extends beyond the seal. The perimeter of the seal on the disc is tacky.
 - Discs that have labels printed using a special ink that feels tacky when touched.
- Discs with non-standard shapes (e.g., heart, square, star) cannot be played on this unit. Attempting to do so may damage the unit. Do not use such discs.

Cleaning the cabinet

Clean the cabinet, panel and controls with a soft cloth slightly moistened with mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as thinner, benzene or alcohol.

To save a tape permanently

To prevent a tape from being accidentally recorded over, break off the cassette tab from side A or B as illustrated.



If you later want to reuse the tape for recording, cover the broken tab with adhesive tape.

Before placing a cassette in the tape deck

Take up any slack in the tape. Otherwise, the tape may get entangled in the parts of the tape deck and become damaged.

When using a tape longer than 90 minutes

The tape is very elastic. Do not change the tape operations such as play, stop, and fast-winding frequently. The tape may get entangled in the tape deck.

Cleaning the tape heads

Clean the tape heads after every 10 hours of use. Be sure to clean the tape heads before you start an important recording or after playing an old tape. Use a separately sold dry-type or wet-type cleaning cassette. For details, refer to the instructions of the cleaning cassette.

Demagnetizing the tape heads

Demagnetize the tape heads and the metal parts that have contact with the tape after every 20 to 30 hours of use with a separately sold demagnetizing cassette. For details, refer to the instructions of the demagnetizing cassette.

Specifications

AUDIO POWER SPECIFICATIONS

Main unit

Amplifier section

DIN power output (rated): 30 + 30 W
(6 ohms at 1 kHz, DIN)
Continuous RMS power output (reference):
35 + 35 W
(6 ohms at 1 kHz, 10% THD)
Music power output (reference):
60 + 60 W

Inputs

AUDIO IN: Sensitivity 250 mV,
impedance 47 kilohms

Outputs

PHONES: Accepts headphones with
an impedance of 8 ohms or
more

SPEAKER: Accepts impedance of 6 to
16 ohms.

CD player section

Laser Diode Properties

Emission Duration:
Continuous
Laser Output*:
Less than 44.6 μ W

* This output is the value measurement at a distance of 200 mm from the objective lens surface on the Optical Pick-up Block with 7 mm aperture.

Frequency response 20 Hz – 20 kHz
Wavelength 780 – 790 nm

Tape deck section

Recording system	4-track 2-channel, stereo
Frequency response	50 – 13,000 Hz (± 3 dB), using Sony TYPE I cassettes
Wow and flutter	$\pm 0.15\%$ W. Peak (IEC) 0.1% W. RMS (NAB) $\pm 0.2\%$ W. Peak (DIN)

Tuner section

DAB tuner section

Frequency range	
Band-III:	174.928 (5A) – 239.200 (13F) MHz
L-Band:	1452.960 MHz (L1) – 1490.624 MHz (L23) (L-Band is not available for the UK model.)

* For details, see “DAB frequency table” below.

Aerial terminal	75 Ω F female
FM stereo, FM/AM superheterodyne tuner	
FM tuner section	
Tuning range	87.5 – 108.0 MHz
Aerial	FM lead aerial
Aerial terminals	75 ohms unbalanced
Intermediate frequency	10.7 MHz
AM tuner section	
Tuning range	
European model:	531 – 1,602 kHz (with the tuning interval set at 9 kHz)
Other models:	530 – 1,710 kHz (with the tuning interval set at 10 kHz) 531 – 1,602 kHz (with the tuning interval set at 9 kHz)
Aerial	AM loop aerial, external aerial terminal
Intermediate frequency	450 kHz

DAB frequency table

Band-III

Frequency	Label	Frequency	Label
174.928 MHz	5A	209.936 MHz	10A
176.640 MHz	5B	211.648 MHz	10B
178.352 MHz	5C	213.360 MHz	10C
180.064 MHz	5D	215.072 MHz	10D
181.936 MHz	6A	216.928 MHz	11A
183.648 MHz	6B	218.640 MHz	11B
185.360 MHz	6C	220.352 MHz	11C
187.072 MHz	6D	222.064 MHz	11D
188.928 MHz	7A	223.936 MHz	12A
190.640 MHz	7B	225.648 MHz	12B
192.352 MHz	7C	227.360 MHz	12C
194.064 MHz	7D	229.072 MHz	12D
195.936 MHz	8A	230.784 MHz	13A
197.648 MHz	8B	232.496 MHz	13B
199.360 MHz	8C	234.208 MHz	13C
201.072 MHz	8D	235.776 MHz	13D
202.928 MHz	9A	237.488 MHz	13E
204.640 MHz	9B	239.200 MHz	13F
206.352 MHz	9C		
208.064 MHz	9D		

Note

Frequencies are displayed to two places of decimals on this system.

L-Band

Frequency	Label
1452.960 MHz	LA
1454.672 MHz	LB
1456.384 MHz	LC
1458.096 MHz	LD
1459.808 MHz	LE
1461.520 MHz	LF
1463.232 MHz	LG
1464.944 MHz	LH
1466.656 MHz	LI
1468.368 MHz	LJ
1470.080 MHz	LK
1471.792 MHz	LL
1473.504 MHz	LM
1475.216 MHz	LN
1476.928 MHz	LO
1478.640 MHz	LP
1480.352 MHz	LQ
1482.064 MHz	LR
1483.776 MHz	LS
1485.488 MHz	LT
1487.200 MHz	LU
1488.912 MHz	LV
1490.624 MHz	LW

Notes

- L-Band is not available for the UK model.
- Frequencies are displayed to two places of decimals on this system.

Speaker

SS-CGPX9

Speaker system	2-way, bass-reflex type
Speaker units	
Woofer:	12 cm dia., cone type
Tweeter:	4 cm dia., cone type
Nominal impedance	6 ohms
Dimensions (w/h/d)	Approx. 160 × 261.5 × 233 mm
Mass	Approx. 2.6 kg net per speaker

General

Power requirements	
European model:	230 V AC, 50/60 Hz
Australian model:	230 – 240 V AC, 50/60 Hz
Power consumption	85 W 0.25 W (in Power Saving Mode)
Dimensions (w/h/d)	Approx. 181.5 × 261.5 × 357.5 mm incl. projecting parts and controls
Mass	Approx. 5.8 kg
Supplied accessories	Remote Commander (1) R6 (size AA) batteries (2) AM loop aerial (1) DAB/FM lead aerial (2)

Design and specifications are subject to change without notice.



- Standby power consumption: 0.3 W
- Halogenated flame retardants are not used in the certain printed wiring boards.
- Lead-free solder is used for soldering certain parts.
- Halogenated flame retardants are not used in cabinets.

Remote control

ALPHABETICAL ORDER

A - O


CD **16** (9, 10, 11)
 CLEAR **13** (12)
 CLOCK/TIMER SELECT **2**
 (21, 22)
 CLOCK/TIMER SET **3** (9, 21,
 22)
 DAB **6** (13, 15)
 DISPLAY **19** (16, 23, 24)
 ENTER **9** (9, 11, 14, 21, 22)
 EQ **12** (20)
 FM MODE **4** (16)
 FUNCTION **10** (10, 11, 13, 15,
 17, 26)

P - Z

PLAY MODE **18** (10, 11)
 REPEAT **4** (11)
 SLEEP **20** (20)
 TAPE **15** (17)
 TUNER BAND **5** (13, 15)
 TUNER MEMORY **17** (13)
 TUNING MODE **18** (13, 15)
 VOLUME +/- **11** (21)

BUTTON DESCRIPTIONS

I/⏻ (power) **1** (7, 21)
 ◀◀/▶▶ (rewind/fast forward)
7 (10, 17)
 ◀◀/▶▶ (skip back/skip
 forward) **14** (9, 10, 19, 20, 21)
 ■ (stop) **8** (10, 13, 17, 19, 29)
 || (pause) **8** (10, 17)
 ▶ (play) **8** (10, 17, 22)
 +/- (tuning) **14** (13)



Printed on 100 % recycled
 paper using VOC (Volatile
 Organic Compound)-free
 vegetable oil based ink.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>