



1. **Please read the users guide before proceeding with your installations. Serious damage may occur if the procedure is not followed properly.**
2. This motherboard does not support CPUs with a Vcore higher than 1.6 volts. Please make sure the CPU you are using 1.6 volts or is below. Check the CPU specification before you insert it in the CPU socket.
3. AGP cards running at 3.3v are not supported. Only AGP cards running at 1.5v (most 4x or 8x AGP cards) are supported on this motherboard.
4. Please make sure that your memory modules are inserted correctly. They can go in only one way, and should fit completely in the socket without sticking out. Failure to do so will damage your motherboard and memory module.
5. An ATX12V power supply (Power supply for Pentium 4 system) is required for the system to operate normally. (Preferably 350 watts for minimal loading or 400 watts for fully loaded system).
6. If you have any problem getting your system to work, please follow the troubleshooting tips in your user manual.
7. On some motherboards, the actual chipset cooler may differ from the chipset cooler as shown on the picture or on the box. However, the chipset fan on the motherboard is of the same quality and will work just as well as the one shown in the picture. (The chipset cooler is as sufficient as the chipset fan based on a different design.)
8. For answers to Technical questions, please visit SOYO tech support link at <http://www.soyogroup.com/support> and <http://www.soyogroup.com/kb>.



# SY-P4I875P DRAGON 2 V1.0 Motherboard

\*\*\*\*\*

mPGA Socket 478 Processor supported

Intel 875P AGP/PCI

533/800 MHz Front Side Bus supported

ATX Form Factor

\*\*\*\*\*

## User's Manual

**Trademarks:**

SOYO is the registered trademark of SOYO Group Inc. All trademarks are the properties of their owners.

**Product Rights:**

All names of the product and corporate mentioned in this publication are used for identification purposes only. The registered trademarks and copyrights belong to their respective companies.

**Copyright Notice:**

All rights reserved. This manual has been copyrighted by SOYO Group Inc. No part of this manual may be reproduced, transmitted, transcribed, translated into any other language, or stored in a retrieval system, in any form or by any means, such as by electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without permission in writing from SOYO Group Inc.

**Disclaimer:**

SOYO Group Inc. makes no representations or warranties regarding the contents of this manual. We reserve the right to amend the manual or revise the specifications of the product described in it from time to time without obligation to notify any person of such revision or amend. The information contained in this manual is provided to our customers for general use. Customers should be aware that the personal computer field is subject to many patents. All of our customers should ensure that their use of our products does not infringe upon any patents. It is the policy of SOYO Group Inc. to respect the valid patent rights of third parties and not to infringe upon or to cause others to infringe upon such rights.

**Disclaimer:**

Please be advised that some SOYO motherboards are designed with overclocking features and may allow users to run the components beyond manufacturer's recommended specifications. Overclocking beyond manufacturer's specifications is not recommended nor endorsed by SOYO Group, Inc. and will void your manufacturer's warranty. Overclocking beyond manufacturer's specifications is not encouraged and should be assumed at the user's own risk. Unsafe overclocking can damage the user's system or cause serious personal injury. If the user is unsure or in doubt about overclocking, please seek professional advise. SOYO, Inc. is not responsible for any direct or indirect damage resulting from overclocking.

**Restricted Rights Legend:**

Use, duplication, or disclosure by the Government is subject to restrictions set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at 252.277-7013.

**About This Guide:**

This Quick Start Guide can help system manufacturers and end users in setting up and installing the Motherboard. Information in this guide has been carefully checked for reliability; however, to the correctness of the contents there is no guarantee given. The information in this document is subject to amend without notice.

For further information, please visit our **Web Site** on the Internet. The address is "<http://www.soyogroup.com>".

**Edition: February 2005****Version V1.1****P4I875P DRAGON 2 V1.0 Platinum Edition SERIES****FC** Tested To Comply  
With FCC Standards  
FOR HOME OR OFFICE USE**100%** POST CONSUMER  
RECYCLED PAPER

# Table of Contents

<b>CHAPTER 1 MOTHERBOARD DESCRIPTION.....</b>	<b>1</b>
1-1 INTRODUCTION .....	1
1-2 UNPACKING THE MOTHERBOARD.....	1
1-3 KEY FEATURES .....	3
1-4 HANDLING THE MOTHERBOARD.....	5
1-5 ELECTROSTATIC DISCHARGE PRECAUTIONS.....	5
1-6 SY-P4I875P DRAGON 2 V1.0 MOTHERBOARD LAYOUT.....	6
1-7 SY-P4I875P DRAGON 2 V1.0 MOTHERBOARD COMPONENTS ...	7
<b>CHAPTER 2 HARDWARE INSTALLATION .....</b>	<b>14</b>
2-1 PREPARATIONS.....	14
2-2 INSTALLATION GUIDE .....	15
<b>A. IDE Device Installation (HDD, CD-ROM) .....</b>	<b>22</b>
<b>B. Floppy Drive Installation .....</b>	<b>25</b>
<b>C. Front Panel Connections .....</b>	<b>26</b>
<b>D. Back Panel Connections .....</b>	<b>29</b>
<b>E. Other Connections .....</b>	<b>32</b>
<b>F. ATX12V Power Supply.....</b>	<b>39</b>
<b>G. Center &amp; Bass Select Connector (JP30) .....</b>	<b>41</b>
<b>H. CMOS Clear (JP5) .....</b>	<b>42</b>
2-3 QUICK BIOS SETUP .....	44
<b>CHAPTER 3 BIOS SETUP UTILITY .....</b>	<b>46</b>
3-1 SOYO COMBO FEATURE.....	49
3-2 STANDARD CMOS SETUP.....	60
3-3 ADVANCED BIOS FEATURES .....	63
3-4 ADVANCED CHIPSET FEATURES .....	68
3-5 INTEGRATED PERIPHERALS .....	70
3-6 POWER MANAGEMENT SETUP.....	76
3-7 PNP/PCI CONFIGURATION SETUP.....	80
3-8 PC HEALTH STATUS.....	83



3-9 LOAD FAIL-SAFE DEFAULTS ..... 84

3-10 LOAD OPTIMIZED DEFAULTS ..... 85

3-11 SUPERVISOR PASSWORD ..... 86

3-12 USER PASSWORD ..... 87

**CHAPTER 4 DRIVERS INSTALLATION ..... 89**

**CHAPTER 5 USB 2.0 DRIVER INSTALLATION ..... 97**

**CHAPTER 6 ALI M5281 DRIVER INSTALLATION ..... 98**

**CHAPTER 7 ALI M5281 SERIAL ATA DRIVER INSTALLATION ..... 101**

**CHAPTER 8 ICH5R (SATA1/SATA2) SETUP INFORMATION ..... 104**

**APPENDIX A ALI M5283 ..... 106**

**APPENDIX B FLASHING BIOS ROM ..... 114**

**APPENDIX C TROUBLESHOOTING ..... 118**

**APPENDIX D CONTACT INFORMATION ..... 127**

## Chapter 1

# MOTHERBOARD DESCRIPTION

### 1-1 INTRODUCTION

The **SY-P4I875P DRAGON 2 V1.0** AGP/PCI Motherboard is a high-performance Socket 478 processor, ATX form-factor system board. **SY-P4I875P DRAGON 2 V1.0** uses the Intel 875P Chipset technology. This Motherboard is fully compatible with industry standards and adds many technical enhancements.

### 1-2 UNPACKING THE MOTHERBOARD

When unpacking the Motherboard, check for the following items:

---

◆ The SY-P4I875P DRAGON 2 V1.0 Intel 875P AGP/PCI Motherboard

---



---

◆ The user manual

---



---

◆ The Installation CD-ROM

---



---

◆ SOYO Bonus Pack CD-ROM

---



---

◆ Three IDE Device ATA 100 Flat Cable

---



---

◆ One Floppy Disk Drive Flat Cable

---



---

◆ Four Serial ATA cables

---



- 
- ◆ One SPDIF Audio Connector Card (optional)



- 
- ◆ One Back panel



- 
- ◆ Σ BOX (optional)



---

**Warning:** Do not unpack the Motherboard from its anti-static packaging until you are ready to install it.

---

Like most electronic equipment, your Motherboard may be damaged by electrostatic discharge. To avoid permanent damage to components ground yourself while working by using a grounding strap. Otherwise, ground yourself frequently by touching the unpainted portion of the computer chassis to drain the static charges.

Handle the Motherboard carefully, holding it by the edges. You are now ready to start the installation.

### 1-3 KEY FEATURES

<b>CPU</b>	<p>Supports Intel® mPGA Socket 478 processors:</p> <ul style="list-style-type: none"> <li>➤ Pentium® 4 with and without Hyperthreading, Northwood, Prescott (533/800MHz FSB)</li> <li>➤ Pentium® 4 Celeron</li> <li>➤ SOYO COMBO Setup CMOS setup menu for complete and easy changing of your CPU settings in CMOS setup, making jumpers obsolete.</li> </ul> <p><b>Note:</b> CPU with higher than 1.6 volts are not supported.</p>
<b>Chipset</b>	Intel® 875P / ICH5R Chipset
<b>Memory</b>	<ul style="list-style-type: none"> <li>➤ The SY-P4I875P DRAGON 2 V1.0 supports PC2700 and PC3200 DDR (non-registered and ECC) memory modules.</li> <li>➤ SOYO COMBO Setup menu, to fully configure your memory settings.</li> </ul>
<b>AGP</b>	1x AGP master 4x/8x slot (1.5v only)
<b>PCI</b>	5x 32-bit bus master PCI slots
<b>Super I/O</b>	<p>ITE IT8712F-A Super I/O controller supporting :</p> <ul style="list-style-type: none"> <li>➤ Floppy disk controller</li> <li>➤ Parallel port (SPP, EPP and ECP compliant)</li> <li>➤ 2x 16550A compatible RS232 serial ports</li> <li>➤ IrDA compatible infrared port</li> <li>➤ PS/2 Keyboard and mouse</li> <li>➤ Hardware monitor for monitoring temperatures, voltages and fan speeds in the system.</li> <li>➤ PC/SC (Personal Computer Smart Card Working Group) Standard compliant smart card controller</li> </ul>



<b>Storage</b>	<ul style="list-style-type: none"> <li>➤ ICH5R integrated Serial ATA controller supporting up to 2x UDMA 150 hard disks in normal or RAID 0 mode</li> <li>➤ ALi M5281 Serial ATA RAID controller supporting up to 2x UDMA 150 hard disks in normal or RAID (0 or 1) mode.</li> <li>➤ ICH5R Integrated Parallel ATA controller supporting up to 4x UDMA 33/66/100 Parallel ATA devices.</li> <li>➤ ALi M5281 PCI to IDE RAID controller for support for up to 4x UDMA 33/66/100/133 parallel ATA hard disks in normal or RAID (0, 1 or 0+1) mode.</li> </ul>
<b>USB 2.0</b>	8x USB 2.0 compliant ports (4 on rear IO panel, 4x motherboard connectors).
<b>Sound</b>	Onboard CMedia CM8738 6 channel PCI Hardware Audio
<b>Network</b>	Onboard Intel 10/100 MBps 100Base-T and 1000BASE-T (Gigabit) Ethernet controller, supporting Wake-On-Lan (WOL)
<b>IEEE1394</b>	Onboard VIA VT6306 IEEE1394 Firewire controller with 1x rear IO panel connector and 2x motherboard connectors.
<b>BIOS</b>	<ul style="list-style-type: none"> <li>➤ Power Failure resume function to allow the system to turn on or off after a power failure, which is indispensable for server systems.</li> <li>➤ Wake On Ring and Power On by Alarm to allow your system to wake up from suspend or power on through the modem or RTC alarm.</li> <li>➤ Multiple boot, allowing your system to boot from for example CD-ROM</li> </ul>
<b>Software</b>	<ul style="list-style-type: none"> <li>➤ SOYO Hardware Doctor allowing you to fully monitor and control your system</li> <li>➤ SOYO Bonus Pack CD-ROM containing free bonus software.</li> </ul>
<b>Industry standards</b>	<p>This motherboard is compliant with the following industry standards :</p> <ul style="list-style-type: none"> <li>➤ Microsoft PC99</li> <li>➤ FCC</li> <li>➤ ACPI</li> </ul>

## 1-4 HANDLING THE MOTHERBOARD

To avoid damage to your Motherboard, follow these simple rules while unpacking:

- Before handling the Motherboard, ground yourself by grasping an unpainted portion of the system's metal chassis.
- Remove the Motherboard from its anti-static packaging. Hold the Motherboard by the edges and avoid touching its components.
- Check the Motherboard for damage. If any chip appears loose, contact your dealer or our tech support immediately.



**Warning:** Do not apply power if the Motherboard appears damaged. If the motherboard is damaged, contact your dealer immediately.

---


## 1-5 ELECTROSTATIC DISCHARGE PRECAUTIONS

Make sure to ground yourself before handling the Motherboard or other system components. Electrostatic discharge can easily damage the components. Note that you must take special precautions when handling the Motherboard in dry or air-conditioned environment.

To protect your equipment from electrostatic discharge, take the following precautions:


- Do not remove the anti-static packaging until you are ready to install.
- Ground yourself before removing any system component from its protective anti-static packaging. (To ground yourself, grasp the expansion slot covers or other unpainted portions of the computer chassis.)
- Frequently ground yourself while working or use a grounding strap.
- Handle the Motherboard by its edges and avoid touching its components.

## 1-6 SY-P4I875P DRAGON 2 V1.0 MOTHERBOARD LAYOUT



Back Panel SY-P4I875P DRAGON 2 V1.0 Platform

### 1-7 SY-P4I875P DRAGON 2 V1.0 MOTHERBOARD COMPONENTS



A	<p><b>Microphone and LAN Status LED Connector (J30)</b> This connector allows you to extend your microphone connector and LAN Status LED to your front panel. Check the <b>MIC &amp; LED Connector (J30)</b> paragraph on page 36 for a lay-out of this header.</p>
B	<p><b>+12V Power Connector</b> This is where the Power Supply's +12V ATX connector goes. For a lay-out of this connector please check the <b>F. ATX12V Power Supply</b> paragraph on page 39.</p>
C	<p><b>AGP Slot</b> This is the AGP expansion slot for your video card. Note that it can only work with 1.5v AGP cards. For more information, check the <b>Step 3 Installation of Expansion Cards</b> paragraph on page 19.</p>
D	<p><b>Socket 478 Connector</b> This is the Zif (Zero Insertion Force) socket for your Pentium 4 or Celeron CPU. For more information, check the <b>Step 1 Install the CPU</b> paragraph on page 15.</p>
E	<p><b>Intel 875P North Bridge Chip</b> The Intel® 875P chipset features support for an 800 MHz Front Side Bus (FSB) and implements Intel® Performance Acceleration Technology (PAT) with dual-channel <a href="#">DDR400</a> memory configurations to get incredible performance from the memory interface. Optimized to support the Intel® Pentium® 4 Processor with <a href="#">Hyper-Threading Technology</a><sup>†</sup>, the 875P chipset adds intelligence to help manage and prioritize multiple threads received from the microprocessor.</p>
F	<p><b>3V Lithium Battery</b> This battery supplies power to the CMOS RAM. As long as the battery supplies enough power, the contents of your CMOS RAM will be valid. CMOS RAM contents are configured by CMOS setup, and can be cleared by JP5. For more details on this check the <b>H. CMOS Clear (JP5)</b> paragraph on page 42.</p>
G	<p><b>CPU Cooling Fan (CPUFAN1, 2) connectors</b> With these connectors you can attach the CPU fan or fans to your motherboard. They supply power and (in the case of CPUFAN1) allow you to monitor the speed of the FAN via the SOYO Hardware Monitor software or via CMOS setup. For more details on the lay-out of these connectors, check the <b>2. Cooling Fan Installation</b> paragraph on page 33.</p>

H	<p><b>Chassis Cooling Fan (CHAFAN3) connectors</b> This connector is to connect your chassis fan to your motherboard. This motherboard supports up to 3 chassis fans. Please check the <b>(2) Chassis Cooling Fan (CHAFAN1, CHAFAN2, CHAFAN3)</b> paragraph on page 34 for more details.</p>
I	<p><b>DDR DIMM Banks</b> These 4, 184 pin memory slots are to install your system memory in. They support up to 4 GB of memory. For more details check the Step 2 Install Memory Module paragraph on page 18.</p>
J	<p><b>ITE IT8712F-A Super I/O Chip</b> The IT8712F-A is a Low Pin Count Interface-based highly integrated Super I/O. The IT8712F-A provides the most commonly used legacy Super I/O functionality plus the latest Environment Control initiatives, such as H/W Monitor, Fan Speed Controller, ITE's 'SmartGuardian' function and Smart Card Reader Interface. The device's LPC interface complies with Intel 'LPC Interface Specification Rev. 1.0'. The IT8712F-A meets the 'Microsoft® PC98 &amp; PC99 System Design Guide' requirements, and is ACPI &amp; LANDesk compliant.</p>
K	<p><b>Serial Infrared (IrDA) device header</b> This header allows you to connect an IrDA receiver to the motherboard. You can find the lay-out in the <b>1. Standard Infrared (SIRCON)</b> paragraph on page 32.</p>
L	<p><b>Smart Card Reader connector</b> This connector allows you to connect a smart card reader to the PC/SC, ISO 7816 compliant onboard smart card reader. The paragraph <b>3. Smart Card Reader</b> on page 35 contains more information on the lay-out of this header.</p>
M	<p><b>ATX Power Supply connector</b> This connector is to connect the ATX connector of your ATX12V compliant power supply to the motherboard. For more details on this connector, please check the <b>F. ATX12V Power Supply</b> paragraph on page 39.</p>
N	<p><b>Floppy Disk Drive (FDD) connector</b> This 34 pins connector is to connect your floppy drive to. Check for more details in the <b>B. Floppy Drive Installation</b> paragraph on page 25.</p>

O	<p><b>Chassis Cooling Fan (CHFAN2) connector</b> This connector is to connect your third chassis fan to your motherboard. This motherboard supports up to 3 chassis fans. Please check the <b>(2) Chassis Cooling Fan (CHAFAN1, CHAFAN2, CHAFAN3)</b> paragraph on page 34 for more details.</p>
P	<p><b>Flash BIOS</b> This chip contains the system BIOS firmware, and is software upgradable. It's size is 4Mbit. For updates of your Flash BIOS, please go to <a href="http://www.soyogroup.com/">http://www.soyogroup.com/</a>. For details on how to setup your BIOS, please go to the <b>BIOS SETUP UTILITY</b> chapter on page 46.</p>
Q	<p><b>Bus Mastering EIDE/ATAPI Ports</b> These connectors are to attach your IDE devices to. Each connector can support up to 2 IDE devices, 1 master and 1 slave. Please check the <b>IDE Device Installation (HDD, CD-ROM)</b> paragraph on page 22 for more details.</p>
R	<p><b>CMOS Clear Jumper (JP5)</b> This jumper allows you to clear your CMOS RAM contents in order to reset your system configuration. . For more details on this check the <b>H. CMOS Clear (JP5)</b> paragraph on page 42.</p>
S	<p><b>Front Panel connectors (J25)</b> This header allows you to connect the switches and LEDs on your front panel. Please check the <b>C. Front Panel Connections</b> chapter on page 26 for more details and lay-outs.</p>
T	<p><b>5V Stand-By Indicator LED</b> The ATX 12V power supply will always supply a 5V standby voltage to your motherboard so that it can power on via for example Wake On Lan technology. This LED shows that your ATX 12V power supply is supplying this standby voltage to your motherboard.</p>
U	<p><b>IDE RAID Ports</b> These IDE ports (IDE 3 and IDE 4) can be used as normal IDE port or in a RAID configuration and are controlled by the ALi M5281 chip. ATAPI devices will not work on these ports. For more details, please check the <b>IDE Device Installation (HDD, CD-ROM)</b> paragraph on page 22.</p>

V	<p><b>ALi M5281 Serial /Parallel ATA RAID chip</b> The M5281 provides personal computer systems with PCI device solution of the highest integration: It includes two Serial-ATA Host controllers for supporting a total of 2 ports, one fully Parallel-ATA Host controller for supporting two channels.</p>
W	<p><b>SATA Connectors</b> These connectors allow you to attach one UDMA 150 hard disk to each connector. Note that SATA 3 and 4 are controlled by the ALi M5281 chip, and can support RAID 0 and 1. For more information on these connectors check the <b>IDE Device Installation (HDD, CD-ROM)</b> paragraph on page 22.</p>
X	<p><b>USB 2.0 connectors</b> These connectors support 2 USB 2.0 ports per connector. For details on the lay-out, please check the <b>5. Universal Serial Bus (USB1/USB2, USB3/USB4, USB20_1/USB20_2)</b> paragraph on page 31.</p>
Y	<p><b>Chassis Cooling Fan (CHAFAN1) connector</b> This connector is to connect your chassis fan to your motherboard. This motherboard supports up to 3 chassis fans. It allows you to monitor the speed of CHAFAN1 in CMOS setup or by using the SOYO Hardware Monitor software. Please check the <b>(2) Chassis Cooling Fan (CHAFAN1, CHAFAN2, CHAFAN3)</b> paragraph on page 34 for more details.</p>
Z	<p><b>CD-IN connector</b> This connector is to attach your analog audio output channel from your CDROM or DVD drive to your motherboard. Please check the <b>4. CD Line-in (CDIN)</b> paragraph on page 35 for more details.</p>
AA	<p><b>GAMEPORT connector</b> This connector is to attach your gameport connector to. Gameports are used to connect for example joysticks to. For more details check the paragraph on page 31.</p>
AB	<p><b>SPK5 connector</b> This connector is to connect the speaker attached to your case to your motherboard. Please check the <b>7. SPK5</b> paragraph on page 37 for more details.</p>



AC	<p><b>IEEE1394 Firewire connector</b> These connectors allow you to attach IEEE 1394 connectors or devices to the motherboard. The lay-out can be found in the <b>8. IEEE 1394 (Firewire) Connector (FW1/FW2)</b> paragraph on page 38.</p>
AD	<p><b>VIA VT6306 IEEE1394 Firewire chip</b> The VT6306 IEEE 1394 OHCI Host Controller provides high performance serial connectivity. It implements the Link and Phy layers for IEEE 1394-1995 High Performance Serial Bus and 1394a Draft 4.0. It is compliant with 1394 Open HCI 1.0 and 1.1 with DMA engine support for high performance data transfer via a 32-bit bus master PCI host bus interface.</p>
AE	<p><b>Center &amp; Bass select connector (JP30)</b> Because some speaker manufacturers connect their center and bass speakers different, this jumper allows you to select how your center and bass speakers are connected. See the <b>G. Center &amp; Bass Select Connector (JP30)</b> paragraph on page 41 for more details.</p>
AF	<p><b>AUX-IN connector</b> This connector allows you to attach a second CDROM analog audio out output to your mainboard. Please check the <b>5. AUX-IN (AUXIN)</b> paragraph on page 36 for more details.</p>
AG	<p><b>CMedia CMI 8738 PCI 6 Channel hardware audio chip</b> The CMI 8738 chip is a 2/4/6 Channel PCI hardware audio chip, which uses the HRTF 3D positional audio technology. It is SB Pro compatible and supports SPDIF IN/OUT. It also has a DLS (Downloadable Sound) wave table music synthesizer which supports DirectMusic.</p>
AH	<p><b>32 bit PCI slots</b> These are the motherboard's 3.3v busmastering PCI slots, compliant to PCI specification v2.2.</p>
AI	<p><b>Intel 82801ER South Bridge chip</b> ICH5R platforms enable the next generation desktop storage interface with integration of Serial ATA (SATA). The ICH5R also supports eight, high-speed USB 2.0 ports and integrates an Alert Standard Format (ASF) System Management controller for network manageability. The ICH5R includes enhancements for ACPI 2.0 compliant power management logic. ICH5R supports RAID 0 function.</p>

AJ	<b>Intel 82547EI LAN chip</b> The Intel® 82547 family of controllers are highly integrated Platform LAN Connect devices combining 10BASE-T, 100BASE-TX and 1000BASE-T (Gigabit) physical layer capabilities, and providing a core ingredient of the enabling solution for the integrated networking connectivity in Intel® I/O Controller Hub based platforms. It supports a single interface fully compliant with the IEEE 802.3/802.3u/802.3 standard. The IEEE 802.3 standard for 1000BASE-TX defines networking over two pairs of Category 5 unshielded twisted pair cable.
AK	<b>AGP DET LED</b> This LED lights up when an AGP 3.3v card is inserted in the system. If this LED lights up, your system will not work, since AGP 3.3v cards are not supported.
AL	<b>Back panel connectors</b> These connectors allow you to attach the external devices to the back of your PC. Please check the <b>D. Back Panel Connections</b> paragraph on page 29 for more details.

## Chapter 2

### HARDWARE INSTALLATION

Congratulations on your purchase of **SY-P4I875P DRAGON 2 V1.0** Motherboard. You are about to install and connect your new Motherboard.



---

**Note:** Do not unpack the Motherboard from its protective anti-static packaging until you have made the following preparations.

---

#### 2-1 PREPARATIONS

Gather and prepare all the following hardware equipment to complete the installation successfully:

1. Socket mPGA478 processor with CPU cooling fan. (CPUs with a VCORE higher than 1.6 volts are not supported)
2. DDR memory module(s)
3. A computer case with an adequate power supply unit (350W for a minimally loaded system or 400W for a fully loaded system).
4. Monitor
5. Keyboard
6. Pointing Device (mouse)
7. Disk Drives: HDD, CD-ROM, Floppy drive...
8. External Peripherals: Printer and Modem (optional)
9. VGA Card (AGP or PCI)

**Note: This M/B only supports 1.5V AGP VGA cards! 3.3V AGP cards are not supported !**

## 2-2 INSTALLATION GUIDE

We will now begin the installation of the Motherboard. Please follow the step-by-step procedure designed to lead you to a complete and correct installation.

- Step1-** Install the Central Processing Unit (CPU).
- Step2-** Install memory modules.
- Step3-** Install expansion cards.
- Step4-** Connect cables, case wires, and power supply.
- Step5-** Power on and enter BIOS setup.
- Step6-** Install supporting software tools. See Chapter 4 for more info.



---

**Warning:** Turn off the power to the Motherboard, system chassis, and peripheral devices before performing any work on the Motherboard or system.


---

# BEGIN THE INSTALLATION


### Step 1 Install the CPU

**CPU Mount Procedure:** To mount the Pentium® 4 Socket mPGA478 processor that you have purchased separately, follow these instructions.


1. Lift the socket handle up to a vertical position.




2. Align the blunt edge of the CPU with the matching pinhole distinctive edge on the socket.



3. Seat the processor in the socket completely and without forcing.



4. Then close the socket handle to secure the CPU in place.



---

Remember to connect the CPU Cooling Fan to the appropriate power connector on the Motherboard. *The fan is a key component that will ensure system stability. The fan prevents overheating, therefore prolonging the life of your CPU.*

---

### CPU Fan Installation

Your Socket 478 processor kit comes with a cooling fan. Mount the fan on the processor according to the instructions provided by the manufacturer. The fan is a key component that will ensure system stability. The fan prevents overheating, therefore prolonging the life of your CPU.




---

**Note:** Remember to connect the fan to the appropriate power source.

---

## Step 2 Install Memory Module



This motherboard supports two Dual Channels to your memory. Note that you can use normal DDR memory for Dual Channel to work. Also note that for Dual Channel to work 2 or 4 modules of equal size and specifications have to be installed.

**The largest memory capacity possible is 4GB.** On this motherboard, DRAM speed can be set independent from the CPU front side bus speed. Note that when installing 4GB of memory, your total memory will be less than 4GB. The reason for this is that the BIOS, PCI and AGP cards claim part of your CPUs address space.

### ***Memory Configuration Table***

If you want to use the Dual Channel feature, please follow the memory configuration table below:

DDR Slots Performance	DDR_A1	DDR_A2	DDR_B1	DDR_B2
128 bit	Present		Present	
128 bit		Present		Present
128 bit	Present	Present	Present	Present

Installing your memory in a combination different from the table above will still allow your system to work. The Dual Channel feature will not work then however. This motherboard also supports ECC (error correcting code) memory DDR modules.

### **Memory frequency Table**

Depending on the front side bus (FSB) frequency of the CPU, you can run memory of different speeds. Please look at the table below for details:

CPU FSB (MHz)	Memory Frequency (MHz)	DDR DIMM Type
400	266	PC2100
533	266 or 333	PC2100 or PC2700
800	400 or 320*	PC3200 or PC2700


\* When using a 800 MHz FSB CPU and PC2700 DDR DIMMs, the memory frequency runs at 320 MHz (instead of 333 MHz) due to chipset limitations.

### **Step 3 Installation of Expansion Cards**


The motherboard has 1 AGP slot and 5 PCI slots.

1. Read the related expansion card's instruction document before inserting the expansion card into the computer.
2. Press the expansion card firmly into the expansion slot on the motherboard.
3. Make sure the metal contacts on the card are seated in the slot.
4. Replace the screw to secure the slot bracket of the expansion card.
5. Install required driver for the operating system you use.



**AGP Slot**

**This motherboard only support 1.5V AGP cards (4X/8X cards). If 3.3V AGP card is used, the system will not power-on and the AGPDET LED will lit.**




**PCI Slots***PCI IRQ Assignment*

The following table shows which PCI IRQs are used by which onboard device.

	A	B	C	D	E	F	G
AGP	•						
ALi M5281						•	
CMedia 8738 PCI Audio							•
VIA VT6306 IEEE1394				•			
Intel 82547EI 10/100/1G Ethernet			•				
PCI Slot 1	•						
PCI Slot 2		•					
PCI Slot 3			•				
PCI Slot 4				•			
PCI Slot 5		•					
Intel 82801ER (ICH5R) USB 2.0					•		

**Step 4 Connect cables, case wire and power supply**

**A. IDE Device Installation (HDD, CD-ROM)**



This Motherboard offers two primary (IDE1, IDE3) IDE device connectors, 2 secondary IDE device connectors (IDE2, IDE4) and 4 tertiary serial ATA ports. IDE1 and IDE2 can support up to four high-speed Ultra DMA 33/66/100 HDD or CD-ROM. IDE3 and IDE4 can support up to 4 high speed Ultra DMA 33/66/100/133 HDD. SATA1~4 can support up to 4 ATA 150 SATA hard disks.

IDE1,2 are controlled by the 82801ER (ICH5R), IDE3,4 are controlled by the ALi M5281, SATA1,2 are controlled by the 82801ER (ICH5R) and SATA3,4 are controlled by the ALi M5281 controller.

There are 8 parallel ATA HDD connectors (IDE1, IDE2, IDE3, IDE4) and 4 serial ATA connectors on the motherboard. IDE3 and IDE4 are provided for IDE RAID or standard IDE function. SATA1, SATA2, SATA 3 and SATA4 are provided for SATA RAID or standard SATA function. This Motherboard can support up to 12 HDDs.




---

**Note:** IDE2 and SATA2 are not bootable, SATA1, SATA3, SATA4 and IDE1, IDE3 and IDE4 are bootable.

---




---

**Note1:** SATA1 and SATA2 can only support RAID 0  
**Note2:** RAID 0 function of ICH5R can only work under Windows XP, other operating system is not supported.

---




---

**Note:** Only Windows XP can use SATA1, SATA2, IDE1 and IDE2 at the same time. All other operating systems can use any combination from the following table:


---

	Enabled devices		
1	SATA1	SATA2	IDE1
2	SATA1	SATA2	IDE2
3	IDE1	IDE2	
4	SATA1	SATA2	


These devices can be enabled in your CMOS setup menu. Please check the OnChip IDE Device paragraph on page 55 for more details.

**Parallel ATA connectors**


Connect the black end of the ATA66/100 flat cable to the IDE device (HDD or CD-ROM) and plug the blue end to the primary (IDE1, IDE3) or secondary (IDE2, IDE4) directionally keyed IDE connector on the Motherboard. The ATA66/100 cable is backward compatible with ATA33 HDDs.

**Serial ATA connectors**

You can also plug the serial ATA cable into the serial ATA connector of the motherboard. The other end of the SATA cable goes into your SATA device.




## B. Floppy Drive Installation




The system supports 5 possible floppy drive types: 720 KB, 1.2 MB, 1.44 MB, 2.88 MB. In addition, this Motherboard supports a 3-mode (720KB/1.2MB/1.44MB) floppy commonly used in Japan.

Connect one side of the 34-pin flat cable to the floppy drive and plug the other end to the floppy drive connector in the Motherboard. The end of the cable that goes into the motherboard is not twisted. The twisted end of the cable goes into the floppy drive.

This Motherboard can support only one floppy drive.




### C. Front Panel Connections



Plug the computer case's front panel devices to the corresponding headers on the Motherboard.


#### 1. Power LED

Please install according to the following pin assignment: pin 1,3 are for Power LED.




## 2. Reset

Plug the Reset push-button cable into the 2-pin Reset header on the motherboard. Pushing the Reset button on the front panel will cause the system to restart the boot-up sequence.




## 3. Speaker

Attach the 4-pin PC speaker cable from the case to the Speaker header on the Motherboard.



## 4. ACPI LED


Connecting the 2-pin ACPI LED cable to the corresponding ACPI LED header will cause the LED to light whenever the system is in ACPI mode. The manufacturer has permanently set this Motherboard in ACPI mode because of PC99 specification requirements.






### 5. IDE LED

Attach the 2-pin IDE device LED cable to the corresponding IDE LED header on the Motherboard. This will cause the LED to light when an IDE1 or IDE2 (HDD, CD-ROM) device is active.



### 6. ATX Power On/Off Switch

Attach the 2-pin momentary type switch to the PWRBT header for turning On or Off your ATX power supply. Note that 5VSB will always have power, so the 5V standby LED will always be lit.




## D. Back Panel Connections

All external devices such as the PS/2 keyboard, PS/2 mouse, printer, modem, USB can be plugged directly into the Motherboard back panel.

Only after you have fixed and locked the Motherboard to the computer case can you start connecting the external peripheral devices.

When connecting an external device, use the following figure to locate and identify which back panel connector to plug the device to.



### 1. Onboard Serial Ports COMA/COMB

External peripherals that use serial transmission scheme include:

- serial (RS232) mice
- modem

Plug the serial device cables directly into the COMA/COMB 9-pin male connectors located at the rear panel of the Motherboard.


### 2. Parallel Port PRT

This parallel port is used to connect the printer or other parallel devices.

Plug the parallel device cable into the 25-pin female connector located at the rear panel of the Motherboard.


### 3. PS/2 Keyboard

Plug the keyboard jack directly into the 6-pin female PS/2 keyboard connector located at the rear panel of the Motherboard.



### 4. PS/2 Mouse


Similarly, plug the mouse jack directly into the 6-pin female PS/2 mouse connector.



### 5. Universal Serial Bus (USB1/USB2, USB3/USB4, USB20\_1/USB20\_2)

This Motherboard provides 8 USB2.0 ports for your additional devices. Plug the USB device jack into the available USB connector USB1, USB2, USB3 and USB4.

USB20\_1 and USB20\_2 are available. To make use of these USB ports, purchase a USB cable from your dealer. The lay-out of USB20\_1/USB20\_2 connector is as follows:




USB20\_1 and USB20\_2 support USB2.0 devices.

### 6. Onboard Game port/audio (Audio Speakers connections)


When using 2-channel speaker, connect the speaker cable to Line-out.

If you're using 4 channel speaker, connect the front L/R speakers to Line-out and rear L/R speakers to Line-in. Make sure that the audio software is set for 4 channel speaker system.

Use the SPDIF Card to use 6 channel speaker.



The Gameport has the following lay-out :



## E. Other Connections


### 1. Standard Infrared (SIRCON)

Plug the 5-pin infrared device cable to the SIRCON header.




This will enable the infrared transfer function. This Motherboard meets both the ASKIR and HPSIR specifications.

Please install according to the following pin assignment:




## 2. Cooling Fan Installation



### (1) CPU Cooling Fan (CPUFAN1, CPUFAN2)


After you have seated the CPU properly on the processor, attach the 3-pin fan cable to the CPUFAN connector on the Motherboard.

To avoid damage to the system, install according to the following pin assignment:



**(2) Chassis Cooling Fan (CHAFAN1, CHAFAN2, CHAFAN3)**


Some chassis also feature a cooling fan. This Motherboard features a CHAFAN connector to provide 12V power to the chassis fan. Connect the cable from the chassis fan to the CHAFAN 3-pin connector. Install according to the following pin assignment:



**Note:** CPU cooling fan must be installed to prevent the CPU from overheating and ensure system stability. Chassis cooling fan is optional, depending on whether there is cooling fan in your chassis.

### 3. Smart Card Reader


The smart card reader conforms to the PC/SC Working group standard, and has the following lay-out:



### 4. CD Line-in (CDIN)

This Motherboard provides one CD Line-in connector. Please connect the 4-pin audio cable from your CD-ROM or DVD ROM drive to CDIN.


Please install according to the following pin assignment:






### 5. AUX-IN (AUXIN)

This Motherboard provides one AUX-IN connector. Please connect the 4-pin audio cable from your second CD-ROM or DVD ROM drive to AUX-IN. Please install according to the following pin assignment:



### 6. MIC & LED Connector (J30)



You can connect the Line-out /MIC in/LAN LED to the front panel of your PC case (If this option is available in your PC case). This connector has the following pin assignment:



## 7. SPK5

Connect the end of the SPDIF Audio connector card cable to the SPK5 connector on the motherboard.

Please refer to C-Media sound solution for more information on the AUDIO function.




**Note:** Some 5.1 speakers have different center/base assignment. Please use the C-media Multi-Channel Audio demo software to check if sounds coming from the center/base speaker are correct. Adjust JP30 accordingly if not.

### 8. IEEE 1394 (Firewire) Connector (FW1/FW2)

This motherboard provides 3 IEEE 1394 ports for your Firewire devices. Standard drivers are supplied with the operating system for commonly used Firewire devices.

FW1 and FW2 are available. You can connect them to a 1394 bracket or  $\Sigma$  BOX to use them. The layout out of the FW1 and FW2 Firewire connector is as follows:




## F. ATX12V Power Supply

The power supply connector is the last connection to be made when installing a motherboard. This motherboard requires an ATX 12V power supply. AT or ATX power supplies cannot be used. We recommend a power supply of at least 350W, or 400W under full loading.

### Steps:

1. Connect the 20 pin connector to the ATX power connector. See FIG. 1.
2. Connect the 4 pin connector to the +12V power connector. See FIG. 2.



---

**Note 1:** The presence of the +12V power connector indicates that a power supply is ATX12V; the absence of the +12V power connector indicates that a supply is ATX.

---



**Note 2:** When using the Power-On by Keyboard function, please make sure the ATX 12V power supply is able to provide at least 1220mA on the 5V Standby lead (5VSB).




**Note 3:** The minimum recommended wattage is 400W for a fully loaded system or 350W for a minimally loaded system, the system might become unstable if power supply is not enough




**Note 4:** The 4 pin ATX 12V must be connected to the motherboard. Without this connector, the system cannot boot.

Please install the ATX 12V power according to the following pin assignment:




**FIG. 1**





**FIG. 2**


**G. Center & Bass Select Connector (JP30)**



The 4 pin block jumper can be set to 1,2,3,4 or 3,4,5,6. The position this jumper block should be set to depends on your speakers. If during usage you find that your center and base channels are swapped set this jumper to the other position.



Center & Bass select	Normal	Reverse (Default)
<b>JP30 Setting</b>	Short pin 1-3/2-4  	Short pin 3-5/4-6  

## H. CMOS Clear (JP5)




In some cases the CMOS memory may contain wrong data, follow the steps below to clear the CMOS memory.

1. Clear the CMOS memory by momentarily shorting pin 2-3 on jumper JP5.  
This jumper can be easily identified by its white colored cap.
2. Then put the jumper back to 1-2 to allow writing of new data into the CMOS memory.

CMOS Clearing	Clear CMOS Data	Retain CMOS Data
<b>JP5 Setting</b>	Short pin 2-3 for at least 5 seconds to clear the CMOS 	Short pin 1-2 to retain new settings 
<i>Note: You must unplug the power cable from your power supply connector when performing the CMOS Clear operation.</i>		


## Onboard LAN LED Definition

When this LED is lit (**green sign**), this means the LAN is running at 100 mbps, if it is not lit, the Onboard LAN is working at 10 mbps.



This is the LAN activity LED. It will blink when it is active.

When this LED is lit (**red sign**), this means the LAN is running at 1 Gbps, if it is not lit, the Onboard LAN is working at 10 mbps.



This is the LAN activity LED. It will blink when it is active.

**Step 5 Power On**

You have now completed the hardware installation of your Motherboard successfully.

1. Turn the power on
2. To enter the BIOS Setup Utility, press the <DEL> key while the system is performing the diagnostic checks,



---


**Note:** If you have failed to enter the BIOS Setup utility, wait until the boot up sequence is completed. Then push the RESET button and press <DEL> key again at the beginning of boot-up, during diagnostic checks.

---



Repeat this operation until you get the following screen.

3. The BIOS Setup screen appears:



### 2-3 QUICK BIOS SETUP

This Motherboard does not use any hardware jumpers to set the CPU frequency. Instead, CPU settings are software configurable with the BIOS [SOYO COMBO FEATURE]. The [SOYO COMBO FEATURE] combines the main parameters that you need to configure, all in one menu, for a quick setup of the BIOS.

After the hardware installation is complete, turn the power switch on, then press the <DEL> key during the system diagnostic checks to enter the Award BIOS Setup program. The CMOS SETUP UTILITY will be shown on the screen. Then, follow these steps to configure the CPU settings.



**Step 1.** Select [STANDARD CMOS SETUP]

Set [Date/Time] and [Floppy drive type], then set [Hard Disk Type] to "Auto".

**Step 2.** Select [LOAD OPTIMIZED DEFAULTS]

Select the "LOAD OPTIMIZED DEFAULTS" menu and type "Y" at the prompt to load the BIOS optimal setup.

**Step 3.** Select [SOYO COMBO FEATURE]

Set the [CPU Frequency Select] field to "Manual", to be able to change the CPU frequency 1 MHz stepping.

**Step 4.** Select [SAVE & EXIT SETUP]

Press <Enter> to save the new configuration to the CMOS memory, and continue the boot sequence.

You are now ready to configure your system with the BIOS setup program.

Go to **Chapter 3: BIOS SETUP**


## Chapter 3

### BIOS SETUP UTILITY

This Motherboard's BIOS setup program uses the ROM PCI BIOS program from Award Software Inc.

To enter the Award BIOS program's Main Menu:

1. Turn on or reboot the system.
2. After the diagnostic checks, press the [Del] key to enter the Award BIOS Setup Utility.



#### Selecting items

- Use the arrow keys to move between items and select fields.
- From the Main Menu press arrow keys to enter the selected submenu.

#### Modifying selected items


- Use the [Up]/[Down] keys to modify values within the selected fields. Some fields let you enter values directly, others will let you press Enter then select the value.

**Hot Keys:** Function keys give you access to a group of commands throughout the BIOS utility.

Function	Command	Description
<b>F1</b>	General Help	Gives the list of options available for each item.
<b>F5</b>	Previous Values	Restore the old values. These are the values that the user started the current session with.
<b>F6</b>	Load Fail-Safe Defaults	Loads all items with the most conservative values.
<b>F7</b>	Load Optimized Defaults	Loads all options with the optimize values.
<b>F10</b>	Save	Saves your changes and reboots the system.
<b>[Esc]</b>	Exit	Return to the previous menu.
<b>[Enter]</b>	Select	Will display a overlapping window with all options for the current item.
<b>[+/-/PU/PD]</b>	Value	Using the +, -, Page Up and Page Down keys the user can toggle the value of the current item.

## SAVE AND EXIT SETUP


Select the [SAVE & EXIT SETUP] option from the Main Menu to save data to CMOS and exit the setup utility. This option saves all your changes and causes the system to reboot.



Type [Y] to save the changes and exit or [N] to return to the Main Menu and keep current values.

## EXIT WITHOUT SAVING

Selecting the [EXIT WITHOUT SAVING] option allows you to abandon all changes and exit setup.



Type [Y] to abandon changes and exit or [N] to return to the Main Menu and keep current values.

### 3-1 SOYO COMBO FEATURE

This motherboard does not use any hardware jumpers to set the CPU frequency. Instead, CPU settings are software configurable with the BIOS [SOYO COMBO Feature].

After the hardware installation is complete, turn the power switch on, then press the <DEL> key during the system diagnostic checks to enter the Award BIOS Setup program. The CMOS SETUP UTILITY will display on screen. Then, select the [SOYO COMBO Feature] option from the main menu and press the <Enter> key.

Phoenix – Award BIOS CMOS Setup Utility		
SOYO COMBO Feature		
System Performance	Normal	Item Help
CPU Clock Ratio	13X	
CPU Frequency Select	Auto	Menu Level ▶
x Frequency 1MHz Stepping	100MHz	
Async AGP/PCI CLK	Disabled	
DRAM:CPU Ratio	Auto	
DRAM Frequency	333 MHz	
Quick Power On Self Test	Enabled	
C.I.H. 4-WAY Protection	Disabled	
CPU Vcore Select	Default	
DDR Voltage Select	Default	
AGP Voltage Select	Default	
▶ Advanced DRAM Control	Press Enter	
▶ Onboard Device	Press Enter	
▶ OnChip IDE Device	Press Enter	
▶ Boot Device Order	Press Enter	
↑↓→ Move    Enter:Select    +/-/PU/PD:Value    F10:Save    ESC:Exit    F1:General Help F5:Previous Values    F6:Fail-Safe Defaults    F7: Optimized Defaults		

The [SOYO COMBO Feature] menu combines the main parameters that you need to configure, all in one menu, for a quick setup in BIOS.

**System Performance**

	Setting	Description	Note
<b>System Performance</b>	Normal	Adjust your computer's performance.	Default
	Fast		
	Turbo		

**SOYO COMBO Feature**

	Setting	Description	Note
<b>CPU Clock Ratio</b>	8X~ 50X	The available CPU ratio you can select will depends on your CPU ID.	
<b>CPU Frequency Select</b>	Manual	Choose the pre-defined CPU frequency setting or auto for auto detecting your CPU frequency. For experienced overclocker, set the field to "Manual" and use the CPU Freq. by 1 MHz stepping manual to overclock the CPU. Don't forget to set the correct CPU to PCI divider.	Default
	Auto		
<b>Frequency 1MHz Stepping</b>	100 ~ 511	Press "Page Up" / "Page Down" key to overclock the CPU Front Side Bus in 1MHz increment or Press "Enter" key, then type the desired CPU Front Side Bus.	
<b>Async AGP/PCI CLK</b>	Disabled	Allows you to set your AGP/PCI clock regardless of what your FSB and memory are.	Default
	66/33 MHz		
	73/36 MHz		
	80/40 MHz		
<b>DRAM:CPU Ratio</b>	Auto	Choose the pre-defined DRAM frequency setting or auto for experienced overclocker, set the field to "x1.33" or "x1.25" DRAM frequency.	Default
	x1.33		
	x1.25		
<b>DRAM Frequency</b>		This item shows you the DRAM frequency.	

**SOYO COMBO Feature (Continue)**

	Setting	Description	Note
<b>Quick Power On Self Test</b>	Disabled		
	Enabled	Provides a fast POST at boot-up.	Default
<b>C.I.H. 4-WAY Protection</b>	Enabled	This item allows you write-protect your BIOS chip. If you want to flash your BIOS, set this option to disabled. Write protecting your BIOS protects you against some viruses.	Default
	Disabled		

**Voltage Select**

	Setting	Description	Note
<b>CPU Vcore Select</b>	Default	This function allows you to adjust the CPU voltage.	Default
	1.600		
	1.550		
	1.500		
	1.450		
	1.400		
	1.350		
	1.300		
<b>DDR Voltage Select</b>	Default	This function allows you to adjust the DDR voltage.	Default
	2.9V		
	2.8V		
	2.7V		
<b>AGP Voltage Select</b>	Default	This function allows you to adjust the AGP voltage.	Default
	1.8V		
	1.7V		
	1.6V		



### 3-1.1 Advanced DRAM Control



**Caution:** Change these settings only if you are already familiar with DRAM timing parameters.

The [Advanced DRAM Control] option changes the values of the chipset registers. These registers control the timings of your memory.

Phoenix – Award BIOS CMOS Setup Utility  
 Advanced DRAM Control

DRAM Timing Selectable	By SPD	Item Help
x CAS Latency Time	2.5	Menu Level ▶
x Active to Precharge Delay	7	
x DRAM RAS# to CAS# Delay	4	
x DRAM RAS# Precharge	4	
Refresh Mode Select	Auto	

↑↓→:Move    Enter:Select    +/-/PU/PD:Value    F10:Save    ESC:Exit    F1:General Help  
 F5:Previous Values    F6:Fail-Safe Defaults    F7: Optimized Defaults

After you have completed the changes, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.

#### CHIPSET FEATURES SETUP


	Setting	Description	Note
<b>DRAM Timing Selectable</b>	By SPD	If enable the DRAM will auto detect the DRAM timing.	Default
	Manual		
<b>CAS Latency Time</b>	1.5	This item allows you to control the DRAM CAS Latency time.	
	2		
	2.5		Default
	3		
<b>Active to Precharge Delay</b>	5	This item allows you to control the DRAM Percharge Delay time.	
	6		
	7		Default
	8		

**CHIPSET FEATURES SETUP (Continue)**

	Setting	Description	Note
<b>DRAM RAS# to CAS# Delay</b>	2	This item allows you to control DRAM RAS to CAS delay time.	
	3		
	4		Default
<b>DRAM RAS# Precharge</b>	2	This item allow you to control DRAM RAS percharge time.	
	3		
	4		Default
<b>Refresh Mode Select</b>	7.8 us	This item allows you to set the interval between consecutive refresh cycles.	
	15.6 us		
	64 us		
	Auto		Default

### 3-1.2 Onboard Device

The [Onboard Device] option allows you to select which devices you want to enable and which you want to disable in your computer.



After you have completed the changes, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.

#### Onboard Settings

	Setting	Description	Note
<b>LAN Chip</b>	Enabled	This setting allows you to enabled or disabled onboard LAN.	Default
	Disabled		
<b>6 Channel H/W Audio</b>	Enabled	This setting allows you to enabled or disabled onboard 6Ch H/W Audio.	Default
	Disabled		
<b>RAID IDE 3,4/SATA3,4</b>	Enabled	This setting allows you to enabled or disabled onboard IDE 3,4/SATA3,4.	Default
	Disabled		
<b>IEEE 1394</b>	Enabled	This setting allows you to enabled or disabled onboard IEEE1394.	Default
	Disabled		

### 3-1.3 OnChip IDE Device



**Caution:** Change these settings only if you are already familiar with the IDE settings.

The [OnChip IDE Device] option changes the settings of the 82801ER (ICH5R) IDE controller. These settings do not influence the ALi M5281 controllers.

The following screen shows setup default settings.

Phoenix – Award BIOS CMOS Setup Utility		
OnChip IDE Device		
		Item Help
IDE 1,2 /SATA 1,2	IDE only	
IDE HDD Block Mode	Enabled	
IDE DMA transfer access	Enabled	
On-Chip Primary PCI IDE	Enabled	
IDE Primary Master PIO	Auto	
IDE Primary Slave PIO	Auto	
IDE Primary Master UDMA	Auto	
IDE Primary Slave UDMA	Auto	
On-Chip Secondary PCI IDE	Enabled	
IDE Secondary Master PIO	Auto	
IDE Secondary Slave PIO	Auto	
IDE Secondary Master UDMA	Auto	
IDE Secondary Slave UDMA	Auto	
*** On-Chip Serial ATA Setting ***		
SATA Mode	IDE	
On-Chip Serial ATA	Disabled	
x Serial ATA Port0 Mode	Primary Master	
x Serial ATA Port1 Mode	Primary Slave	
		Menu Level ▶
		[Disabled]: Disabled SATA Controller.
		[Auto]: Auto arrange by BIOS.
		[Combined Mode]: PATA and SATA are combined. Max. of 2 IDE drives in each channel.
		[Enhanced Mode]: Enable both SATA and PATA. Max. of 6 IDE drives are supported.
		[SATA Only]: SATA is operating in legacy mode.
↑↓→:Move    Enter:Select    +/-/PU/PD:Value    F10:Save    ESC:Exit    F1:General Help F5:Previous Values    F6:Fail-Safe Defaults    F7: Optimized Defaults		

After you have completed the changes, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.

**CHIPSET FEATURES SETUP**

	Setting	Description	Note
<b>IDE 1,2 /SATA 1,2</b>	IDE only	Only enabled IDE1,2. SATA1,2 are disabled	Default
	Pri IDE+SATA	IDE1 and SATA1,2 are enabled. IDE2 is disabled.	
	SATA+Sec IDE	IDE2 and SATA 1,2 are enable. IDE1 is disabled.	
	SATA only	Only enable SATA1,2. IDE1,2 are disabled.	
	IDE + SATA	IDE1,2 AND sata1,2 are all enabled.	
<b>IDE HDD Block Mode</b>	Disabled		
	Enabled	Invokes multi-sector transfer instead of one sector per transfer. Not all HDDs support this function.	Default
<b>IDE DMA transfer access</b>	Enabled	This option allows the 82801ER (ICH5R)'s IDE controller to directly transfer data to memory without intervention or the CPU if enabled.	Default
	Disabled		

**IDE Device Controls**

	Setting	Description	Note
<b>On-Chip PCI IDE</b> ➤ Primary ➤ Secondary	Disabled	Turn off the on-board IDE	
	Enabled	Use the on-board IDE	Default
<b>IDE</b> ➤ Primary Master PIO ➤ Primary Slave PIO ➤ Secondary Master PIO ➤ Secondary Slave PIO	mode 0-4	0 is the slowest speed 4 is the fastest speed	
	Auto	For better performance and stability, we suggest you use the Auto setting to set the HDD control timing.	Default
<b>IDE</b> ➤Primary Master UDMA ➤Primary Slave UDMA ➤Secondary Master UDMA ➤Secondary Slave UDMA	Disabled		
	Auto	Select auto to autodetect UDMA support, or disabled to use DMA/PIO.	Default

### 3-1.4 Boot Device Order

The [Boot Device Order] option allows you to change the order in which your system scans for devices to boot from.

**Note:** That SATA 1 and SATA 2 are not bootable.

Phoenix – Award BIOS CMOS Setup Utility		
Boot Device Order		
First Boot Device	Floppy	Item Help
Second Boot Device	HDD-0	Menu Level ▶  Allows the system to skip certain tests while booting. This will decrease the time needed to boot the system.
Third Boot Device	LS120	
Boot Other Device	Enabled	
Other Device Boot Order	IDE3/IDE4,SCSI	
↑↓→:Move    Enter:Select    +/-/PU/PD:Value    F10:Save    ESC:Exit    F1:General Help F5:Previous Values    F6:Fail-Safe Defaults    F7: Optimized Defaults		

After you have completed the changes, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.


**System Boot Control Settings**

	Setting	Description	Note
<b>First /Second/Third Boot Device</b>	Floppy	Selects the order in which your system scans for devices to boot from (First the first boot device, then the second, etc...). For booting from ALi M5281 controller, set this option to other device).	
	LS120		
	IDE1/SATA1		
	CDROM		
	ZIP100		
	Other Device		
	Disabled		
<b>Boot Other Device</b>	Disabled	Selects if the system should try to find any other bootable devices if the first, second and third boot device cannot be booted from.	
	Enabled		Default
<b>Other Device Boot Order</b>	IDE3/IDE4,SCSI	Selects whether your system should first try to boot from any PCI SCSI or ATA controllers (SCSI) or first from the on booted SATA/ATA controllers.	Default
	SCSI,IDE3/IDE4		
	SATA3/SATA4,SCSI		



### 3-2 STANDARD CMOS SETUP

Select the [STANDARD CMOS SETUP] option from the Main Menu and press [Enter] key.



This screen allows you to modify the basic CMOS settings.

After you have completed the changes, press [Esc] key to return to the Main Menu.

#### Date & Time

	Display	Setting	Please Note
<b>Date</b>	mm/dd/yyyy	Type the current date	You can also the PUp/PDn keys to toggle
<b>Time</b>	hh:mm:ss	Type the current time	24-hour clock format 3:15 PM is displayed as 15:15:00

## Hard Disks Type & Mode

Choose the type and mode for the hard disks that you have already installed.

	Setting	Description	Note
<b>IDE HDD Auto-Detection</b>	Press Enter	To auto-detect the HDD's cylinders, head, sectors and size on this channel	
<b>IDE Primary Slave (User Type)</b>	Auto	BIOS detects hard disk type automatically.	Default
	User	User defines the type of hard disk.	
	None		
<b>Access Mode</b>	Auto	BIOS detects hard disk mode automatically.	Default
	CHS	Normal IDE hard disk	<528MB
	LBA	Enhanced IDE hard disk	>528MB
	Large	Large IDE hard disk (for certain hard disks)	



**Note:** If you have any questions on your hard disk type or mode, ask your hard disk provider or previous user for details.

## Floppy Drives

	Setting	Description	Note
<b>Drives A</b>	360KB, 5.25 in.		
	1.2MB, 5.25 in.		
	720KB, 3.5 in.		
	1.44MB, 3.5 in.		Default
	2.88MB, 3.5 in.		
	None	Not installed	
<b>Floppy 3-Mode Support</b>	Disabled		Default
	Drive A	Supports 3-mode floppy diskette: 740KB/1.2MB/1.44MB on selected disk drive.	Special disk drive commonly used in Japan

**Others Optional**

	<b>Setting</b>	<b>Description</b>	<b>Note</b>
<b>Video</b>	EGA/VGA	Select the video mode, supported by your VGA Card and memory.	Default
	CGA 40		
	CGA 80		
	MONO (Monochrome)		
<b>Halt On</b>	ALL Errors	When the BIOS detects system errors, this function will stop the system. Select which type of error will cause the system halt.	Default
	No Errors		
	All, But Keyboard		
	All, But Diskette		
	All, But Disk/Key		

### 3-3 ADVANCED BIOS FEATURES

Select the [Advanced BIOS Features] option from the Main Menu and press [Enter] key.

Phoenix – Award BIOS CMOS Setup Utility		
Advanced BIOS Features		
Virus Warning	Disabled	Item Help
CPU L1 & L2 Cache	Enabled	
CPU L2 Cache ECC Checking	Enabled	Menu Level ▶  Allows you to choose the VIRUS warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep.
Boot Up Floppy Seek	Enabled	
Boot Up NumLock Status	On	
Gate A20 Option	Fast	
Typematic Rate Setting	Disabled	
x Typematic Rate (Chars/Sec)	6	
x Typematic Delay (Msec)	250	
Security Option	Setup	
APIC Mode	Enabled	
MPS Version Control For OS	1.1	
OS Select For DRAM > 64MB	Non-OS2	
HDD S.M.A.R.T. Capability	Disabled	
Report No FDD For WIN 95	No	
Full Screen LOGO Show	Enabled	
EPA LOGO SELECT	LOGO-0	
Small Logo (EPA) Show	Enabled	
↑↓→ Move    Enter : Select    + / - / PU / PD : Value    F10 : Save    ESC : Exit    F1 : General Help F5 : Previous Values    F6 : Fail - Safe Defaults    F7 : Optimized Defaults		

After you have completed the changes, press [Esc] key and follow the instructions on your screen to save your settings or exit without saving.

**Virus Warning**

	Setting	Description	Note
<b>Virus Warning</b>	Disabled	Allows you to choose the VIRUS warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep. Sound a warning beep.	Default
	Enabled		

**Cache Memory Options**

	Setting	Description	Note
<b>CPU L1 &amp; L2 Cache</b>	Disabled	Because the CPU is faster than memory, the CPU after has to wait to complete memory access. By enabling L2 caching you will let the CPU write or read first from a very fast internal memory (the CPU cache) before accessing main memory, thereby increasing the speed of your system. The CPU will automatically update main memories from the cache.	Default
	Enabled		
<b>CPU L2 Cache ECC Checking</b>	Enabled	Allows your CPU to check for ECC when transferring data from to the L2 cache some performance.	Default
	Disabled		

**Boot Up Floppy Seek**

	Setting	Description	Note
<b>Boot Up Floppy Seek</b>	Disabled	Seeks disk drives during boot up. Disabling speeds boot up.	
	Enabled		Default

**Boot Up Num Lock Status**

	Setting	Description	Note
<b>Boot Up Num Lock Status</b>	On	Numeric keypad in numeric mode at boot-up.	Default
	Off	Puts numeric keypad in arrow key mode at boot-up.	

**Gate A20 Options**

	Setting	Description	Note
<b>Gate A20 Options</b>	Normal	A pin in the keyboard controller controls GateA20.	
	Fast	Lets the chipset control GateA20.	Default

**Typematic Settings**

	Setting	Description	Note
<b>Typematic Rate Setting</b>	Disabled	Keystrokes repeat at a rate determined by the keyboard.	Default
	Enabled	When enabled , the typematic rate and typematic delay can be selected.	
The following [Typematic Rate] and [Typematic Delay] fields are active only if [Typematic Rate Setting] is set to [Enabled]			
<b>Typematic Rate</b>	6 (Char/sec)	Choose the rate at which a character is repeated when holding down a key.	Default
	8 (Char/sec)		
	10 (Char/sec)		
	12 (Char/sec)		
	15 (Char/sec)		
	20 (Char/sec)		
	24 (Char/sec)		
30 (Char/sec)			
<b>Typematic Delay</b>	250 (msec)	Choose how long after you press a key down the character begins repeating.	Default
	500 (msec)		
	750 (msec)		
	1000 (msec)		

**Security Option**

Use this feature to prevent unauthorized system boot-up or use of BIOS Setup. The following table describes the security settings.

	Setting	Description	Note
<b>Security Option</b>	Setup	If a password is set, the password prompt only appears when you attempt to enter the BIOS Setup program.	Default
	System	If a password is set, prompt appears both when entering CMOS setup and during system POST.	
<b>APIC Mode</b>	Disabled	Enabled the Advanced Programmable Interrupt Controller (APIC) mode. On operating systems that support it you will have more IRQs available when enabled.	Default
	Enabled		
<b>MPS Version Control for OS</b>	1.1	Allows you to choose the Multi Processor Specification (MPS) version.	Default
	1.4		

**Other Control Options**

	Setting	Description	Note
<b>OS Select for DRAM&gt;64MB</b>	OS2	When using an OS2 operating system.	
	Non-OS2	When using another, non-OS2 operating system.	Default
<b>HDD S.M.A.R.T. Capability</b>	Enabled	Enabled this field when your HDD supports the S.M.A.R.T. function. Consult your HDD provider for details.	Default
	Disabled		
<b>Report No FDD For WIN 95</b>	Yes	Windows will release IRQ line 6 (normally used by the Floppy Disk Drive) after you disable your on-board FDD and set this field to [Yes].	
	No	Windows will reserve INT 6 for your FDD, whether it is disabled or not.	Default

**LOGO Show**

	Setting	Description	Note
<b>Full Screen LOGO Show</b>	Disabled	Set Enabled to Show Logo (DRAGON).	
	Enabled		Default
<b>EPA LOGO SELECT</b>	LOG0	Allows user to display SOYO logo or own logo. Logo-0 shows SOYO logo, Logo-1 shows user logo.	Default
	LOG1		
<b>Small Logo(EPA) Show</b>	Disabled	Set Enabled to Show Logo(EPA).	
	Enabled		Default



### 3-4 ADVANCED CHIPSET FEATURES



**Caution:** Change these settings only if you are already familiar with the Chipset.

The [Advanced Chipset Features] option changes the values of the chipset registers. These registers control the system options in the computer.

Phoenix – Award BIOS CMOS Setup Utility		
Advanced Chipset Features		
System BIOS Cacheable	Disabled	Item Help Menu Level ▶
Video BIOS Cacheable	Disabled	
Delay Prior to Thermal	16 Min	
AGP Aperture Size (MB)	64	
Init Display First	AGP	
DRAM Data Integrity Mode	Non-ECC	
↑↓→ Move    Enter : Select    + / - / PU / PD : Value    F10 : Save    ESC : Exit    F1 : General Help F5 : Previous Values    F6 : Fail - Safe Defaults    F7 : Optimized Defaults		

After you have completed the changes, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.

The following table describes each field in the Advanced Chipset Features Menu and how to configure each parameter.

**CHIPSET FEATURES SETUP**


	Setting	Description	Note
<b>System BIOS Cacheable</b>	Disabled		Default
	Enabled	The ROM area F0000H-FFFFFFH is cacheable.	
<b>Video BIOS Cacheable</b>	Disabled		Default
	Enabled	The video BIOS area at C0000H-C7FFFH is cacheable.	
<b>Delay Prior to Thermal</b>	4Min	Set the time for the system to decrease performance to avoid reaching maximum thermal temp. Ex. If you set it to 16 minutes the system will start decreasing the performance 16 minutes before reaching max thermal temp.	
	8Min		
	16Min		Default
	32Min		
<b>AGP Aperture Size (MB)</b>	256M	Select the size of Accelerated Graphics Port (AGP) aperture. The aperture is a portion of the system memory address range dedicated for graphics memory address space. (for when your VGA card runs out of memory) Host cycles that hit the aperture range are forwarded to the memory without any translation.	
	128M		
	64M		Default
	32M		
<b>Init Display First</b>	PCI Slot	Choose which card – AGP Display card or PCI VGA card – to initialize first.	
	AGP		Default
<b>DRAM Data Integrity Mode</b>		Auto-Detect whether your DDR RAM is ECC or not.	

### 3-5 INTEGRATED PERIPHERALS



**Caution:** Change these settings only if you are already familiar with the Chipset.

The [INTEGRATED PERIPHERALS] option changes the values of the chipset registers. These registers control the system options in the computer. The following screen shows setup default settings.




The following tables describe each field in the [INTEGRATED PERIPHERALS] Menu and provide instructions on how to configure the IDE controls, FDC controls, and the onboard serial and parallel ports.

### 3-5.1 Onboard USB Device

The [Onboard USB Device] option changes the values of the onboard USB controller.

The following screen shows setup default settings.



After you have completed the changes, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.

#### Keyboard Controls

	Setting	Description	Note
<b>USB Controller</b>	Disabled		
	Enabled	Select <i>Enabled</i> if you want to use your onboard Universal Serial Bus (USB) controller and you have USB peripherals.	Default
<b>USB 2.0 Controller</b>	Disabled	Select Enabled if you have USB	
	Enabled	2.0 peripherals.	Default
<b>USB Keyboard Support</b>	Disabled	Select Enabled if you want to use	Default
	Enabled	USB Keyboard in DOS.	
<b>USB Mouse Support</b>	Disabled	Select Enabled if you want to use	Default
	Enabled	USB Mouse in DOS.	

### 3-5.2 SuperIO Device



**Caution:** Change these settings only if you are already familiar with the Chipset.

The [SuperIO Device] option changes the values of the Super I/O controller. The following screen shows setup default settings.

Phoenix – Award BIOS CMOS Setup Utility		
SuperIO Device		
POWER ON Function	BUTTON ONLY	Item Help
x KB Power ON Password	Enter	
x Hot Key Power ON	Ctrl-F1	
Onboard FDC Controller	Enabled	Menu Level ▶
Onboard Serial Port 1	3F8/IRQ4	
Onboard Serial Port 2	2F8/IRQ3	
UART Mode Select	Normal	
x UR2 Duplex Mode	Half	
Onboard Parallel Port	378/IRQ7	
Parallel Port Mode	SPP	
x ECP Mode Use DMA	3	
PWRON After PWR-Fail	OFF	

↑↓→:Move    Enter:Select    +/-/PU/PD:Value    F10:Save    ESC:Exit    F1:General Help  
 F5:Previous Values    F6:Fail-Safe Defaults    F7: Optimized Defaults

After you have completed the changes, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.

**Others Optional**

	Setting	Description	Note
<b>POWER ON Function</b>	Password	Enables you to wake-up the system by entering a password on the keyboard.	
	HotKEY	You can wake-up the system by pressing the key combination of your choice (Ctrl-F1~F12).	
	Mouse Move	Enables waking up the system by pressing either the right or left mouse button.	
	Mouse Click		
	Any KEY		
	BUTTON-ONLY	Disables the Wake-Up by Keyboard function.	Default
Keyboard98	Allows you to power on a system using this type or keyboard.		
If [POWER ON Function] is set to [Password]			
<b>KB Power ON Password</b>	Enter (your password)	Set the password that will wake-up your system.	
If [POWER ON Function] is set to [Hot Key]			
<b>Hot Key Power ON</b>	Ctrl-F1~F12	Choose the key combination that will wake-up the system. [Ctrl-F1 to Ctrl-F12]	

**Onboard FDC controller**

	Setting	Description	Note
<b>Onboard FDC controller</b>	Disabled	Turn off the on-board floppy controller	
	Enabled	Use the on-board floppy controller	Default

**Onboard Serial Ports**

	Setting	Description	Note
<b>Onboard Serial Port 1 / Serial Port 2</b>	Disabled		
	3F8/IRQ4	Choose serial port 1 & 2's I/O address.	Default (port 1)
	2F8/IRQ3	Do not set port 1 & 2 to the same setting except for Disabled or Auto.	Default (port 2)
	3E8/IRQ4		
	2E8/IRQ3		
	Auto		

**Onboard Serial Ports**

	Setting	Description	Note
<b>UART Mode Select</b>	Normal	The second serial port offers several special modes. It can either work as an infrared device (IrDA, ASKIR) or as a Smart Card reader (SCR), or as a normal serial port.	Default
	IrDA		
	ASKIR		
	SCR		
If [UART Mode Select] is set to [IrDA]/[ASKIR]			
<b>UR2 Duplex Mode</b>	Half	Choose [Half] or [Duplex] to set UR2 in half duplex mode or full duplex mode respectively. Refer to your IR device specifications to select the suitable mode.	Default
	Full		

**Onboard Parallel Ports**

	Setting	Description	Note
<b>Onboard Parallel Port</b>	Disabled	Choose the printer I/O address.	Default
	378/IRQ7		
	3BC/IRQ7		
	278/IRQ5		
<b>Parallel Port Mode</b>	SPP	The mode depends on your external device that connects to this port.	Default
	EPP		
	ECP		
	ECP+EPP		
If [Parallel Port Mode] is set to [ECP] mode			
<b>ECP Mode use DMA</b>	3	Choose DMA3	Default
	1	Choose DMA1	


**Others Optional**

	<b>Setting</b>	<b>Description</b>	<b>Note</b>
<b>PWRON After PWR-Fail</b>	On	The system will switch on when power comes back after a power failure.	
	Off	The system will remain off when power comes back after a power failure.	Default
	Former-Sts	The system will return to the state it was in before the power failure when power returns. (i.e. If the system was on, it will switch on again, if it was off, it will remain off)	



### 3-6 POWER MANAGEMENT SETUP

The [POWER MANAGEMENT SETUP] sets the system's power saving functions.



After you have completed the Power Management Setup, press [Esc] to return to the Main Menu.

**Power Management Controls**

	Setting	Description	Note			
<b>ACPI Suspend Type</b>	S1(POS)	This item allows you select suspend mode.	Default			
	S3(STR)					
	S1 & S3					
<b>Run VGABIOS if S3 Resume</b>	Auto	Some OS (win xp/2k) require to load VGABIOS after resume from S3.	Default			
	Yes					
	No					
<b>Power Management</b>	User Define	Lets you define the HDD and system power down times.	Default			
		Doze timer		Standby timer	Suspend timer	HDD power down
	Min Saving	1 Hour		1 Hour	1 Hour	15 Min
	Max Saving	1 Min		1 Min	1 Min	1 Min
<b>Video Off Method</b>	V/H Sync+Blank	Selects the method by which the monitor is blanked.	Default			
	Blank screen					
	DPMS					
<b>Video Off In Suspend</b>	Yes	If the CPU goes into suspend mode, should the monitor also be turned off.	Default			
	No					
<b>Suspend Type</b>	Stop Grant	The system can wake up through external events.	Default			
	PwrOn Suspend	The system can only wake up through the Power-Button.				
<b>MODEM Use IRQ</b>	3	Selects which IRQ the modem uses to wake up from.	Default			
	3-11, NA					
<b>Suspend Mode</b>	Disabled	When the set time has elapsed, BIOS sends a command to the system to enter suspend Mode.	Default			
	1Min-1Hour					

**Power Management Controls (Continue)**

	Setting	Description	Note
<b>HDD Power Down</b>	Disabled		Default
	1-15Min	When the set time has elapsed, BIOS sends a command to the HDD to power down. This turns off the HDD motor.	Some older model HDDs may not support this advanced function.
<b>Soft-Off by PWR-BTTN</b>	Instant-off	Turns off the system power instant after pushing the power button.	Default
	Delay 4 Sec.	Turns off the system power 4 seconds after pushing the power button.	
<b>Wake-Up by PCI card</b>	Disabled	If enabled any PCI card using the PINE signal will wake the system up.	Default
	Enabled		
<b>Power On by Ring</b>	Disabled		Default
	Enabled	The system will self-power on when the modem is ringing.	
<b>USB KB Wake Up From S3</b>	Disabled	When Enabled, this feature allows the USB KB to wake the system up from the S3 (suspend to RAM) state.	Default
	Enabled		
<b>Resume by Alarm</b>	Disabled	The system ignores the alarm.	Default
	Enabled	Set alarm to power on the system by the date (1-31) or time (hh:mm:ss). If the date is set to [0], the system will self-power on by alarm everyday at the set time.	

**Reload Global Timer Events**

	Setting	Description	Note
<b>IDE0, IDE1</b> ➤ Primary ➤ Secondary	Disabled		Default
	Enabled	In effect, the system remains alert for anything which occurs to a device which is configured as <i>Enabled</i> .	
<b>FDD, COM, LPT Port</b>	Disabled		Default
	Enabled	In effect, the system remains alert for anything which occurs to a device which is configured as <i>Enabled</i> .	
<b>PCI PIRQ [A-D]#</b>	Disabled		Default
	Enabled	The system monitors these elements for activity. The system will resume if [IRQ activity] is detected.	

### 3-7 PNP/PCI CONFIGURATION SETUP

This option sets the Motherboard's PCI configuration..

Phoenix – Award BIOS CMOS Setup Utility		
PnP/PCI Configurations		
Reset Configuration Data	Disabled	Item Help
Resources Controlled By x IRQ Resources	Auto (ESCD) Press Enter	Menu Level ▶
PCI/VGA Palette Snoop	Disabled	Default is Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the OS cannot boot.
Assign IRQ For VGA	Enabled	
Assign IRQ For USB	Enabled	
INT Pin 1 Assignment	Auto	
INT Pin 2 Assignment	Auto	
INT Pin 3 Assignment	Auto	
INT Pin 4 Assignment	Auto	
INT Pin 5 Assignment	Auto	
INT Pin 6 Assignment	Auto	
INT Pin 7 Assignment	Auto	
INT Pin 8 Assignment	Auto	
↑↓→ Move    Enter:Select    +/-/PU/PD:Value    F10:Save    ESC:Exit    F1:General Help F5:Previous Values    F6:Fail-Safe Defaults    F7: Optimized Defaults		



**Note:** Starred (\*) items will disappear when the [Resources Controlled By] option is set to [Auto].

After you have completed the PCI Slot Configuration, press [Esc] and follow the instructions on your screen to save your settings or exit without saving.

**PNP/PCI Configuration Controls**

	Setting	Description	Note
<b>Reset Configuration Data</b>	Disabled	Retain PnP configuration data in BIOS.	Default
	Enabled	Reset PnP configuration data in BIOS.	
<b>Resources Controlled By</b>	Manual	BIOS does not manage PCI/ISA PnP card IRQ assignment. Required to assign IRQ-# and DMA-# to PCI or ISA PnP manually. IRQ-3,4,5,7,9,10,11,12,14,15 assigned to: _ DMA-0,1,3,5,6,7 assigned to: _	
	Auto (ESCD)	The Plug-and-Play BIOS auto manages PCI/ISA PnP card IRQ assignment automatically.	Default
	If [Resources Controlled By] is set to [Manual]		
<b>IRQ-# assigned to:</b>	PCI device	Choose IRQ# assigned to PCI/ISA PnP card.	Default
	Reserved	Reserved IRQ for Legacy cards.	
<p>Under this item the user can assign an IRQ to a PCI slot. However, there under some conditions the IRQ will not be assigned as selected under this item:</p> <ol style="list-style-type: none"> <li>1. IRQs 0, 1, 2, 6, 8, 13 can NOT be assigned, because they are fixed.</li> <li>2. IRQs 5, 9, 10, 11 are available</li> <li>3. IRQs 3,4,7,12,14 and 15 will only be assigned if they are free. See the table below on how to free them:</li> </ol>			

**PNP/PCI Configuration Setup (Continue)**

	Setting	Description	Note
Interrupt Line	How to set the BIOS to release the IRQ to the PnP Interrupt pool:		
	PnP / PCI configuration	Integrated Peripherals	
IRQ 15	IRQ 15: <b>PCI / ISA PnP</b>	On-Chip Secondary PCI IDE: <b>disabled</b>	
IRQ 14	IRQ 14: <b>PCI / ISA PnP</b>	On-Chip Primary PCI IDE: <b>disabled</b>	
IRQ 12	IRQ 12: <b>PCI / ISA PnP</b>	<i>Interrupt 12 will be released by the PnP BIOS automatically if the PS/2 Mouse Port is not used.</i>	
IRQ 7	IRQ 7: <b>PCI / ISA PnP</b>	Onboard parallel port: <b>disabled</b>	
IRQ 4	IRQ 4: <b>PCI / ISA PnP</b>	Onboard Serial port 1: <b>disabled</b>	
IRQ 3	IRQ 3: <b>PCI / ISA PnP</b>	Onboard Serial port 2: <b>disabled</b>	
4. Your OS may reassign another interrupt to a PCI slot after BIOS passes control to the OS, especially if you use Windows 95, 98, NT, XP or 2k.			
<b>Assign IRQ For VGA/USB</b>	Enabled	BIOS will assign IRQ for VGA/USB port.	Default
	Disabled	BIOS won't assign IRQ for VGA/USB port.	
5. Your OS may reassign another interrupt to a PCI slot after BIOS passes control to the OS, especially if you use Windows 95, 98, NT, 2k or XP.			
<b>INT Pin 1~8 Assignment</b>	Auto	Set to Auto the BIOS will using IRQs Automatically.	Default

**MULTI I/O ADDRESSES**

Default settings for multi-I/O addresses are as follows:

Port	I/O Address	IRQ	Status
<b>LPT1</b>	378H	7	ECP/EPP
<b>COM1</b>	3F8H	4	
<b>COM2</b>	2F8H	3	



**Warning:** If a default I/O address conflicts with other I/O cards such as sound card, you must change one of the I/O addresses to remedy to this address conflict. (I/O addresses can be adjusted from the BIOS Setup Utility)

### 3-8 PC HEALTH STATUS

This option shows the Motherboard's PC Health Status.

Phoenix – Award BIOS CMOS Setup Utility		
PC Health Status		
CPU Vcore	1.45V	Item Help Menu Level ▶
+ 3.3V	3.34V	
+ 5V	5.13V	
+ 12V	11.90V	
DRAM Voltage	2.59 V	
AGP Voltage	1.53 V	
CPU Temperature	46°C / 114°F	
CHA Temperature	28°C / 82°F	
CPUFAN1 Speed	0 RPM	
CHAFAN1 Speed	0 RPM	
↑↓→ Move    Enter:Select    +/-PU/PD:Value    F10:Save    ESC:Exit    F1:General Help F5:Previous Values    F6:Fail-Safe Defaults    F7: Optimized Defaults		


#### CPU Device Monitoring

	Setting	Description	Note
<b>CPU Vcore, +3.3V, +5V, +12V, DRAM Voltage, AGP Voltage</b>	V	Show the current voltage status.	
<b>CPU Temperature</b>	°C/°F	Show the current status of the CPU temperature.	
<b>CHA Temperature</b>	°C/°F	Show the current status of system temperature.	
<b>CPUFAN1 Speed</b>	RPM	Show you the current CPUFAN operating speed.	
<b>CHAFAN1 Speed</b>	RPM	Show you the current CHAFAN operating speed.	



### 3-9 LOAD FAIL-SAFE DEFAULTS

Select the [Load Fail-Safe Defaults] option from the Main Menu to load a pre-defined safe bios settings. This option is recommended if you have instability issues.



Type [Y] to use the Setup Defaults followed by [Enter] or otherwise [N] to return to the Main Menu and keep current values.



### 3-11 SUPERVISOR PASSWORD

Based on the setting you have made in the [Security Option] of the [Advanced BIOS Feature] section, the password prevents access to the system or the setup program by unauthorized users. Follow this procedure to set a new password or disable the password:

1. Choose [Advanced BIOS Feature] in the Main Menu and press [Enter].  
Select the [Security Options] item and set the field to:
  - a. [System]: The password is required every time the system is booted. This means only a person who knows the password can use this computer.
  - b. [Setup]: The password is required only when you attempt to enter the BIOS Setup program.
2. Choose [SUPERVISOR PASSWORD] from the Main Menu and press [Enter]. The following prompt appear:

Enter Password:



---

**Warning:** If you forget or lose the password, the only way to access the system is to set jumper JP5 to clear the CMOS RAM. All setup information is lost and you must run the BIOS setup program again.

---



---

**Note:** If you do not wish to use the password function, press [Enter] directly and the following message appears:

Password Disabled!!


---

3. Enter your new password and press [Enter]. The following message appears, prompting to confirm the new password:

Confirm Password:

4. Re-enter your password and then press [Enter] to exit to the Main Menu.

This diagram outlines the password selection procedure:



### 3-12 USER PASSWORD

When the user password option is on, you are not allowed to change any setting in the [CMOS SETUP UTILITY] except for changing the user's password. Only the supervisor's password will allow you to make changes in CMOS setup.

The password setting procedure is similar to that for the [SUPERVISOR PASSWORD] (Refer to section 3-11).

## Boot Menu

Boot Menu enables user to boot-up on different boot device without going into the BIOS setup.

*To enable boot Menu, press “ESC” after memory and option ROM (like the HighPoint 372N BIOS) initialization, the user will see a device menu, in which he or she can choose from which device they wish to boot.*



## Chapter 4

### DRIVERS INSTALLATION



**The SOYO-CD will Auto Run only in Windows Based Operating Systems.**

Your SY-P4I875P DRAGON 2 V1.0 Motherboard comes with a CD-ROM labeled “SOYO CD”. The SOYO CD contains

- a. The user’s manual for your new motherboard in PDF format
- b. The driver software needed for installation
- c. A database in HTML format with information on SOYO motherboards and other products.

**Step 1.** Insert the SOYO CD into the CD-ROM drive

If you use Windows NT, 2000 or XP, the SOYO-CD will not detect your motherboard type. In that case the following dialog will pop up, please choose your motherboard and press OK. Now the SOYO-CD Start Up Menu will be shown.



**(SOYO CD Start Up Program Menu)**



The user's manual files included on the SOYO CD are in PDF (Postscript Document Format). In order to read a PDF file, the appropriate Acrobat Reader software must be installed on your system.

**Note:** The Start Up program automatically detects if the Acrobat Reader utility is already present on your system, and otherwise prompts you on whether or not you want to install it. You must install the Acrobat Reader utility to be able to read the user's manual file. Follow the instructions on your screen during installation, then once the installation is completed, restart your system and re-run the SOYO CD.

**Step 2.** Install Drivers and Utilities

Highlight the driver you want to install and then click ok. The Start Up program displays the drivers available for the particular model of Motherboard you own. We recommend that you only install those drivers . Click the **Install Drivers** button to display the list of driver software that can be installed with your Motherboard. The Start Up program displays the drivers available for the particular model of Motherboard you own. We recommend that you only install those drivers.

**(Driver Installation Menu)**

A short description of all available drivers follows:

➤ **Intel Chipset Software Installation Utility for Win 98SE/ME /2000/XP**

Windows operating systems will not recognize the new INTEL 875P chipset properly. To update the necessary .inf files that will help Windows recognize the 875P chipset, please run this utility.

➤ **Intel Application Accelerator RAID Edition for Win 2K/XP**

This installs the ICH5R RAID driver in your system (for XP only).



➤ **Intel USB2.0 Driver for Win 98SE/ME**

This program will install the USB 2.0 driver for Windows 98SE and Windows ME.

➤ **Intel 10/100/1G Lan Driver for Win 98SE/ME/2000/XP**

This program will install Lan driver on your computer.

➤ **C-MEDIA 6-channel Audio Driver for Win 98SE/ME/2000/XP**

This driver supports 2/4/6 speakers 3D positional audio for the onboard C-Media 8738 audio chip.

➤ **ALi M5281 RAID Driver/Utility for Win 98Se/ME/2000/XP**

This utility will allow you to select which RAID mode you want to use for your configuration. It will only change the RAID configuration for the ALi M5281 controller (IDE3, IDE4, SATA3 and SATA4 IDE ports), not for any of the other IDE controllers.

➤ **P4I875P DRAGON 2 V1.0 Hardware Monitor for Win 98SE/ME /2000/XP**

Your motherboard comes with a hardware monitoring IC. By installing this utility Temperature, Fan speed and Voltages can be monitored.

➤ **ITE SIM Card Reader Driver/Utility for Win 98SE/ME/2000/XP**

Driver to support the smart card reader. You need to install this if you use the SCR.

Select which driver you want to install and click **OK**, or click **Cancel** to abort the driver installation and return to the main menu.


**Note:** Once you have selected a driver, the system will automatically exit the SOYO CD to begin the driver installation program. When the installation is complete, most drivers require a restart of your system before they become active.




**Step 3.** Check the Latest Releases

Click the 'Check the latest Releases' button to go the SOYO Website to automatically find the latest BIOS, manual and driver releases for your motherboard. This button will only work if your computer is connected to the internet through a network or modem connection. Make sure that your internet connection is up before clicking this button.

After Windows XP installation, your device manager should look like this:




After driver installation, your Windows XP device manager should look like this:



Note: To install the USB 2.0 driver, please update to Windows XP service pack 1, check chapter 5 for more info.

Drivers directory list in the CD driver



## Chapter 5

### USB 2.0 DRIVER INSTALLATION

#### *USB2.0 Driver Installation for Windows XP*


USB 2.0 drivers are available for download using Windows Update for Windows XP.

For additional information regarding USB 2.0 support in Windows XP, please visit:

<http://www.microsoft.com/windowsxp/pro/downloads/servicepacks/sp1/default.asp>

**(Windows XP Service Pack1 Include USB2.0 Driver)**

After installing service pack1, please do the following:

- 1) Go into the device manager.
- 2) Remove "  Universal Serial Bus (USB) Controller "
- 3) Restart your system.

Next time Windows XP starts up a new USB 2.0 controller will be found.

#### *USB2.0 Driver Installation for Windows 2000*

USB 2.0 drivers are available for download using Windows Update for Windows 2000.

For additional information regarding USB 2.0 support in Windows 2000, please visit:

<http://www.microsoft.com/windows2000/downloads/servicepacks/sp4/default.asp>

**(Windows 2000 Service Pack 4 Include USB2.0 Driver)**

## Chapter 6

### ALi M5281 Driver Installation

**You can use your IDE 3/ IDE4 as**

1. Normal IDE function.
2. RAID function. (RAID0, 1, 0+1)

**To use IDE3 and IDE4 as normal IDE, please do the following steps**

1. Go to the CMOS setup → SOYO COMBO Feature → Onboard Device → and set the “RAID IDE 3,4/ SATA3,4” to “Enable”.
2. Install the ALi M5281 driver, see driver installation instruction below.

**To use IDE3 and IDE4 as RAID controller, please do the following steps**

1. Connect 2 hard disk on IDE3/4, set them both as master.
2. Go to the CMOS setup → SOYO COMBO Feature → Onboard Device → and set the “RAID IDE 3,4/ SATA3,4” to “Enable”.
3. Go to the CMOS setup → SOYO COMBO Feature → and set the “First Boot Device” to “Other Device”.
4. Set the “Other Device Boot Order” to “IDE3/IDE4,SCSI”.
5. Press “Ctrl+A” when the ALi M5281 BIOS summary screen appears.
6. Create a disk array, check appendix A for create instructions.
7. Install the ALi M5281 driver. See driver installation instruction below.

**To boot from the ALi M5281 controller, (IDE 3 or IDE 4)**

1. Go to the CMOS setup → SOYO COMBO Feature → and set the First Boot Device to “Other Device”.
2. Set the “Other Device boot order” to “IDE3/IDE4,SCSI”.

For more information on the ALi M5281 Utility Software, please check the ALi M5281 manual located in “d:\doc” folder in the Soyo driver CD.

## ***Installing ALi M5281 during OS Installation***

### **Install driver during Windows XP installation**

1. Go to “d:\raid\m5281\floppy” directory, (assuming that your CD-ROM is drive d) copy all the files and directory to a floppy disk.
2. Windows XP will start to inspect your hardware configuration
3. Press “F6” when the message “Press F6 if you need to install a third party SCSI or RAID driver...” Appear. Below the screen
4. Press **S** key to specify additional devices when the **Windows XP Setup** window appears.
5. Insert the floppy disk of driver, then press **Enter** to continue
6. In the follow-on window of device type, please select “**M5281 SATA RAID Controller (Windows XP)**” to continue
7. The follow-on interface will list the devices to be installed, in which “**M5281 SATA RAID Controller (Windows XP)**” item should be included.
8. Press **S** key to specify additional devices
9. In the follow-on window of device type, please select “**M5228 ATA RAID Controller (Windows XP)**” to continue
10. The follow-on interface will list the devices to be installed, in which “**M5228 SATA RAID Controller (Windows XP)**” item should be included. (If users want to install other devices, press “S” at this time.) Press **ENTER** to continue Windows XP setup



## Install driver during Windows 2000 installation

1. Go to “d:\raid\m5281\floppy \” directory, (assuming that your CD-ROM is drive d) copy all the files and directory to a floppy disk.
2. Windows 2000 will start to inspect your hardware configuration
3. Press “F6” when the message “Press F6 if you need to install a third party SCSI or RAID driver....” Appear.
4. Press **S** key to specify additional devices when the **Windows 2000 Setup** window appears.
5. Insert the floppy disk of driver, then press **Enter** to continue
6. In the follow-on window of device type, please select “**M5281 SATA RAID Controller (Win 2000)**” to continue
7. The follow-on interface will list the devices to be installed, in which “**M5281 SATA RAID Controller (Win 2000)**” item should be included.
8. Press **S** key to specify additional devices
9. In the follow-on window of device type, please select “**M5228 ATA RAID Controller (Win 2000)**” to continue
10. The follow-on interface will list the devices to be installed, in which “**M5228 SATA RAID Controller (Win 2000)**” item should be included. (If users want to install other devices, press “S” at this time.) Press ENTER to continue Windows 2000 setup

## Chapter 7

### ALi M5281 Serial ATA Driver Installation

#### You can use your SATA3/SATA4 as

1. Normal IDE function.
2. RAID function. (RAID0, 1)

#### To use SATA3 and SATA4 as normal IDE, please do the following steps

1. Go to the CMOS setup → SOYO COMBO Feature → Onboard Device → and set the “RAID IDE3,4/ SATA3,4” to enable.
2. Install the ALi M5281 driver. See driver installation instruction below.

#### To use SATA3 and SATA4 as RAID controller, please do the following steps

1. Go to the CMOS setup → SOYO COMBO Feature → Onboard Device → and set the “RAID IDE3,4/ SATA3,4” to “Enable”.
2. Go to the CMOS setup → SOYO COMBO Feature → and set the “First Boot Device” to “Other Device”.
3. Set the “Other Device Boot Order” to “SATA3/SATA4, SCSI”.
4. Press “Ctrl+A” when the ALi M5281 BIOS summary screen appears..
5. Create RAID set, check appendix A for more info on creating RAID set.

#### To boot from the ALi M5281 controller, (SATA3 or SATA4)

1. Go to the CMOS setup → SOYO COMBO Feature → and set the First Boot Device to “Other Device”.
2. Set the “Other Device Boot Order” to “SATA3/SATA4, SCSI”.

For more information on the ALi M5281 Utility Software, please check the ALi M5281 manual located in “d:\doc” folder in the Soyo driver CD.

## ***Installing ALi M5281 during OS Installation***

### **Install driver during Windows XP installation**

1. Go to “d:\raid\m5281\floppy” directory, (assuming that your CD-ROM is drive d) copy all the files and directory to a floppy disk.
2. Windows XP will start to inspect your hardware configuration
3. Press “F6” when the message “Press F6 if you need to install a third party SCSI or RAID driver...” Appear. Below the screen
4. Press **S** key to specify additional devices when the **Windows XP Setup** window appears.
5. Insert the floppy disk of driver, then press **Enter** to continue
6. In the follow-on window of device type, please select “**M5281 SATA RAID Controller (Windows XP)**” to continue
7. The follow-on interface will list the devices to be installed, in which “**M5281 SATA RAID Controller (Windows XP)**” item should be included.
8. Press **S** key to specify additional devices
9. In the follow-on window of device type, please select “**M5228 ATA RAID Controller (Windows XP)**” to continue
10. The follow-on interface will list the devices to be installed, in which “**M5228 SATA RAID Controller (Windows XP)**” item should be included. (If users want to install other devices, press “S” at this time.) Press **ENTER** to continue Windows XP setup



## Install driver during Windows 2000 installation

1. Go to “d:\raid\m5281\floppy \” directory, (assuming that your CD-ROM is drive d) copy all the files and directory to a floppy disk.
2. Windows 2000 will start to inspect your hardware configuration
3. Press “F6” when the message “Press F6 if you need to install a third party SCSI or RAID driver...” Appear.
4. Press **S** key to specify additional devices when the **Windows 2000 Setup** window appears.
5. Insert the floppy disk of driver, then press **Enter** to continue
6. In the follow-on window of device type, please select “**M5281 SATA RAID Controller (Win 2000)**” to continue
7. The follow-on interface will list the devices to be installed, in which “**M5281 SATA RAID Controller (Win 2000)**” item should be included.
8. Press **S** key to specify additional devices
9. In the follow-on window of device type, please select “**M5228 ATA RAID Controller (Win 2000)**” to continue
10. The follow-on interface will list the devices to be installed, in which “**M5228 SATA RAID Controller (Win 2000)**” item should be included. (If users want to install other devices, press “S” at this time.) Press **ENTER** to continue Windows 2000 setup

## Chapter 8

### ICH5R (SATA1/SATA2) Setup Information

#### You can use your ICH5R as

1. Normal IDE function.
2. RAID 0 function (Striping).

#### To use SATA1 and SATA2 as normal IDE, please do the following steps

1. Go to the CMOS setup → Soyo combo Feature → onchip device → and set the “IDE1, 2/SATA1, 2” to “SATA only ” or “IDE + SATA” (depending on your system configuration.)
2. Set “SATA Mode” to “IDE “
3. Then start installing Windows operating system. No driver is needed.

#### To use SATA1 and SATA2 as RAID 0 function, please do the following steps

1. Go to the CMOS setup → Soyo combo Feature → onchip device → and set the “IDE1,2/SATA1,2” to “SATA only ” or “IDE + SATA” (depending on your system configuration.)
2. Set “SATA Mode” to “RAID0“
3. Press “Ctrl + I” when the ICH5RBIOS summary screen appears.
4. Create a disk array,
5. Install ICH5R driver, see driver installation instruction below



---

**Note:** Only Windows XP can use “Enhance Mode” (SATA1, SATA2, IDE1 and IDE2 at the same time.)

---

## ***Installing ICH5R during OS Installation***

### **Install driver during Windows XP installation**

1. Set the folder options to “show hidden files and folders”, check Microsoft help for more info on how to set this option.
2. **Go to “d:\drivers\Intel\_iaa\floppy” directory, (assuming that your CD-ROM is drive d) copy all the files to a floppy disk.**
3. Windows XP will start to inspect your hardware configuration
4. Press “F6” when the message “Press F6 if you need to install a third party SCSI or RAID driver...” Appear. Below the screen
5. Press **S** key to specify additional devices when the **Windows XP Setup** window appears.
6. Insert the floppy disk of driver, then press **Enter** to continue
7. In the follow-on window of device type, please select **“Intel ® 82801ER SATA RAID Controller”** to continue installation
8. The follow-on interface will list the devices to be installed, in which **“Intel ® 82801ER SATA RAID Controller”** item should be included. (If users want to install other devices, press “S” at this time.) Press ENTER to continue Windows XP setup.

## ***Installing Driver on an Existing System***

### **For windows XP**

1. Place the driver CD into the CD-ROM drive
2. Choose the model P4I875P DRAGON 2 V1.0
3. Highlight the **“Intel Application Accelerator RAID Edition for Win XP”** and then click install



**Note:** RAID 0 can only work under Windows XP, other operating system is not supported.

---

***APPENDIX A***

**ALi M5283**

# Introduction

## 1.1 What is ALi M5283 controller

ALi M5281/M5283 is a high integration IDE controller that supports both Parallel-ATA and Serial-ATA interfaces. It supports PATA UDMA mode transfer up to mode 6 and SATA 1.0 drives.

M5281/M5283 also provides a cost-effective solution of RAID functions for the performance and reliability.

### Main Features & Benefits

- Support RAID 0, 1, & JBOD
- Allowed maximum 2 disks connection to every controller (Does not support ATAPI devices)
- Support independent use of hard disk
- Support Operating Systems: Windows 98/Me, Windows 2000, Windows XP.
- Windows-based software for RAID management(compatible with BIOS)

## 2. ALi RAID BIOS

After the system BIOS detects ALi RAID BIOS, the RAID BIOS version and drive information shows up on the screen.

The following is an example of BIOS version and drives information when using M5281:

*ALi RAID BIOS V1.00*

*(c) ALi Corporation 2003, All Rights Reserved.*

*Identifying IDE driver .o.o.x.x.o.o*

*Channel 1 Master: Maxtor 4A160J0*

*Channel 1 Slave : Maxtor 6L040J2*




Channel 2 Master: WDC WD360GD-00F

Channel 3 Master: Maxtor 6Y200M0

Press Ctrl-A to enter ALi RAID BIOS setup utility

When RAID BIOS is waiting after identifying drives, press 'Ctrl' and 'A' simultaneously to enter the setup menu:


## 2.1 RAID BIOS Setup Menu



There are three major areas in the RAID BIOS setup screen: Main Menu, Drive Select Menu and RAID Array List:

## 2.2 Main Menu

In **Main Menu**, the user has several options to operate RAID:



### 2.2.1 Create RAID 0 Striping for Performance

1. Press 'Enter' key to activate this item. An 'S' flash cursor appears at the **Drive Select Menu** for the user to choose the first drive for RAID 0.
2. Use 'Space' key to choose the desired drive for RAID 0. Then the flash cursor changes to an 's' flash cursor for the user to choose the second drive for RAID 0.
3. The prompt 'Create RAID 0(Y/N)' appears after two drives are properly assigned.
4. Press 'Y', and then some necessary information will be written to the drives, which may destroy the original data in the drives.

**Warning:** Make sure the data in drives is no longer in use before creating RAID Array.

5. Next, the Array Name input line appears for the user to key in a name for the newly created array. The effective characters for an array name is '0'-'9', 'A'-'Z', 'a'-'z', space and underscore.
6. After the RAID array has been created successfully, its information shows up at **RAID Array List**.

**Note:** RAID 0 cannot be used for parallel ATA drives connected at the same channel. RAID 0 cannot be used for mixed parallel and serial ATA drives.

### 2.2.2 Create RAID 1 Mirroring for Reliability

1. Press 'Enter' key to activate this item. An 'M' flash cursor appears at the 'Drive Select Menu' for the user to choose the first drive for RAID 1.
2. Use 'Space' key to choose the desired drive for RAID 1. Then flash cursor changes to an 'm' flash cursor for the user to choose the second drive for RAID 1.
3. The prompt 'Create RAID 1(Y/N)' appears after two drives are properly assigned.
4. Press 'Y', and then some necessary information will be written to drives, which maybe destroy the original data in the drives.

**Warning:** Make sure the data in drives is no longer in use before creating RAID Array.

5. Next, the Array Name input line appears for the user to key in a name for the newly created array. The effective characters for an array name is '0'-'9', 'A'-'Z', 'a'-'z', space and underscore.
6. After the RAID array has been created successfully, its information shows up at **RAID Array List**.

7. Lastly a prompt message asks whether to do drive copy. The source and destination drives are the ones indicated as 'M' and 'm' in 'Drive Select Menu' respectively.

*Note: RAID 1 cannot be used for parallel ATA drives connected at the same channel. RAID 1 cannot be used for mixed parallel and serial ATA drives.*

### 2.2.3 Create JBOD for integrated Capacity

1. Press 'Enter' key to activate this item. A 'J' flash cursor appears at the 'Drive Select Menu' for the user to choose the first drive for JBOD.
2. Use 'Space' key to choose the desired drive for JBOD array. Use 'Enter' key to finish JBOD drive selection. The maximum number of drives for JBOD array is four and the minimum is two.
3. The prompt 'Create JBOD (Y/N)' appears.
4. Press 'Y' key and then some necessary information will be written to drives, which maybe destroy the original data in the drives

*Warning: Make sure the data in drives is no longer in use before creating RAID Array.*

5. Next the Array Name input line appears for the user to key in a name for the newly created array. The effective characters for an array name is '0'-'9', 'A'-'Z', 'a'-'z', space and underscore.

### 2.2.4 Stripe Size

This item is effective for RAID 0. The user can choose a stripe size from 64K (default), 32K, 16K, 8K and 4K. If the user uses RAID 0 for most A/V editing application or files, 64K is recommended.

1. Press 'Enter' key to activate this item. Then 64K, 32K, 16K, 8K, 4K items appears at bottom of **Main Menu**.
2. Use '↑' '↓' to choose the stripe size.

### 2.2.5 Delete RAID Setting & Partition

1. Press 'Enter' key to activate this item. An '**E**' flash cursor appears at the '**Drive Select Menu**' for the user to choose defined array drive to be deleted.
2. 'Data on RAID drives will be erased (Y/N)?' prompt message shows up to confirm the user's selection.
3. Press 'Y' key, and then the data in drivers is destroyed.

***Warning:** Make sure the data in drives is no longer in use before deleting RAID Array.*

4. '**RAID array List**' automatically updates itself.

### 2.2.6 Delete All RAID Setting & Partition

1. Press 'Enter' key to activate this item.
2. 'Data on RAID drives will be erased (Y/N)?' prompt message shows up to confirm the user's selection.
3. Press 'Y' key, and then the data in drivers is destroyed.

***Warning:** Make sure the data in drives is no longer in use before deleting RAID Array.*

4. '**RAID array List**' automatically updates itself.

### 2.2.7 Rebuild RAID Array

When a drive is replaced or BIOS detects a bad drive, use **Rebuild RAID Array** to keep data coherency for RAID 1 and 0+1.

1. Press 'Enter' key to activate this item. An '**R**' flash cursor appears at the '**Drive Select Menu**' for the user to choose the array to rebuild.
2. BIOS shows the source and destination drives and waits for confirmation to rebuild. Press 'Y' to start rebuild process.
3. Process status bar shows up during the rebuild process.


## 2.2.8 Select Boot Drive

1. Press 'Enter' key to activate this item. A 'B' flash cursor appears at the 'Drive Select Menu' for the user to choose the boot drive.
2. Press 'Enter' or 'Space' Key to finish selection.

**Note:** The boot drive affects how the operation system treats the order of other drives. Take the above BIOS screen as an example, if Channel 3 is the boot drive, the operation system will use the order of Channel 3 Master, Channel 1 Master, Channel 1 Slave, Channel 4 Master consecutively.

## 2.3 Drive Select Menu

There are three bars in this menu: two RAID Drive Selection Bar and one Boot Drive Selection Bar.



## ***APPENDIX B***

# **Flashing BIOS ROM**

## How to flash your motherboard's system BIOS:

To flash your system BIOS to a different version, follow the following steps:

1. Download the BIOS for your motherboard from our website
2. Copy the BIOS .BIN file onto a clean, formatted floppydisk
3. Insert the floppydisk into your system.
4. Restart your system until you see the Dragon Logo. Press TAB immediately. You should see the following :





5. Press ALT+F2 to start up AWDFLASH. You should see the following screen :



6. AWARD flash will now automatically flash your BIOS and reset when it is done.



# **Troubleshooting**

## Troubleshooting at First Start

### Boot-up Issues

**The system does not power-up, no beeping sound heard and the CPU fan does not turn on.**

1. Check if the power cord is plugged in the power source.
2. Check if the power is connected to the M/B. (both the ATX 12V and the ATX connector)
3. Check if the cable of the case power button is connected to the M/B power button connector (see connectors and plug-ins in this manual for more info).
4. Make sure the power supply is not defective. Change the power supply. The minimum should be 350 watts for a minimally loaded system or 400 watt for a fully loaded system.
5. Remove the M/B from the case and test the system. The M/B might be shorted to the case.

**The system powers up, no video, no beeping sound heard, but the CPU fan is turning.**

1. Clear the CMOS RAM. (JP5 connector, see the manual for more info on how to clear the CMOS).
2. Check all the jumper settings on the M/B.
3. Check if the CPU is ok by using another CPU (check the manual for CPU supported on this M/B).
4. Check if the power supply is ok. The minimum should be 350 watts for a minimally loaded system or 400 watt for a fully loaded system.
5. Make sure the CPU fan is connected to CPUFAN1 connector.
6. Remove the M/B from the case and test the system. The M/B might be shorted to the case.
7. Change the VGA card. If you have used a 3.3V AGP card, the AGP DET LED will also lit.

**The system powers up, no video, but beeping is heard.**

1. Clear the CMOS ram. (JP5 connector, see the manual for more info on how to clear the CMOS).
2. Check if the memory module and the VGA card are inserted properly in the M/B.
3. If yes, change the memory module, it might be defective. Make sure the memory specification is supported by the M/B. (for more info on this, check our FAQ on our website).
4. Change the VGA card. Make sure the AGP card is 1.5v, not 3.3v.

**The system turns on for some seconds then shut down by itself.**

1. Check if the CPU fan is connected to the CPUFAN1 connector.
2. The CPU might be overheating. Check the CPU FAN if it is defective or see if the CPU fan is in contact with the CPU.
3. Clear the CMOS ram. (JP5 connector, see the manual for more info on how to clear the CMOS).
4. Make sure the power supply you have in your system supports the M/B specification. Example. If you have a P4 M/B, you need to use a P4 power supply. (ATX 12V compliant)
5. If you already checked the power supply specification, change the power supply. It might be defective or too low for your configuration. The minimum is 350 watts for a minimally loaded system or 400 watt for a fully loaded system.

**When I boot up my system, everything works fine, it sees my CPU and memory, detects my hard drive, floppy drive and CD-ROM but locks up at "Verify DMI pool data..."it doesn't go any further. What should I do?**

1. Clear the CMOS ram. (JP5 connector, see the manual for more info on how to clear the CMOS).
2. If it still has the problem, remove all other add-on cards except the video card see if it boots further. Then put peripherals in one by one to identify which one causes the lockup.
3. Change the CPU.

**During Boot-up, my computer says CMOS memory Checksum error.**

**What is the problem? This error occurs if you:**

1. Clear CMOS memory.
2. Redo your CMOS setup settings. If your battery is empty the error will occur more frequently. You will need to replace the battery in this case. If the problem persists, re-flash the BIOS. If all fails your BIOS chip is failing and needs to be replaced.
3. Change the CMOS battery.
4. Re-flash BIOS.
5. The BIOS chip might be failing.

**Stability Issues**

**My system intermittently locks up, very unstable.**

1. Check the CPU Temp, it might be overheating. Change the CPU FAN. (Check in the health monitor setup menu what your CPU temperature is)
2. Do not overclock your CPU
3. Check the specification of the memory module; maybe the M/B does not support it.
4. Go to BIOS setup and load fail-safe settings. Please check if the system performance in the BIOS setup is set to Turbo/Maximum. Set it to normal if so.
5. Check the website for latest BIOS update.
6. Check the website for FAQ's regarding instability issues.
7. Change the memory module or CPU, they might be defective.
8. The power supply might not have enough wattage to support all the peripherals. If your system has other peripherals connected, like CD-RW, extra HDD, etc. disconnect them. And see if the problem is gone then.
9. Install Intel Inf driver.
10. Check if your mainboard is shorting out against the case.
11. Check if your memory module timings set in CMOS setup are supported by your memory module.

### **My system intermittently locks up, during Windows installation.**

1. Go to BIOS and load the optimized defaults.
2. Check our website for any BIOS updates.
3. If it still has the problem, remove all other add-on cards except CPU (and CPU Fan)/ Memory/ Video card/Hard disk. See if you can finish Windows installation. Then put peripherals in one by one to identify which one causes the lockup.

### **BIOS Issue**

#### **Where can I find the BIOS revision of my mainboard?**

It will be displayed on the upper-left corner of the screen during boot-up. It will show as your board type followed by the revision number, such as kvxa\_2BA1 (meaning BIOS revision 2BA1 for the SY-K7V Dragon plus! board) or 6BA+ IV\_2AA2 which means SY-6BA+ IV motherboard with the 2AA2 BIOS.

#### **Where can I find the latest BIOS of my motherboard?**

Please go to the technical support page of one of the SOYO websites (Taiwan: [www.soyo.com.tw](http://www.soyo.com.tw); USA: <http://www.soyogroup.com/>), and look up your motherboard to find the latest BIOS revision.

#### **How can I flash the BIOS?**

You can:

1. Download the BIOS from our support website.
2. Make a bootable floppy disk with out any memory manager loaded (i.e. himem, emm386, etc...).
3. Copy the BIOS file and awdf flash utility to the diskette.
4. Type "awdf flash biosname.bin /sn /py".
5. Then reboot.

Or:

1. Download the BIOS from our support website.
2. Copy the BIOS to an empty floppy disk. (no other files on the disk!)
3. Press <ALT> <F2> after memory initialization.
4. The system will now automatically flash and reboot.

**Note:** That flashing from the BIOS is only possible if you use a normal floppy drive. It can't flash from any other device.

**After flashing the BIOS, my system will not boot-up.**

1. Try clearing the CMOS ram.
2. The BIOS chip is defective due to an unsuccessful flash, contact your nearest SOYO branch for re-flashing.

**Is there a way to reprogram my BIOS after an unsuccessful flash?**

No other way, you need to send back the BIOS ROM to your nearest SOYO branch for re-flashing.

**I'm using a 400 or 533 MHz FSB CPU, I cannot find the DDR 200MHz option in the BIOS, why?**

An 800 MHz CPU should be used if you want your memory to run at DDR 400 (PC3200).

## **VGA Issue**

**I cannot set my VGA to go higher than 16 color (640x 480).**

1. Make sure that you have installed the Intel Inf driver.
2. Install/ re-install the VGA driver.

**After wake-up from Suspend to RAM or Standby mode, the screen has no display but I can hear the hard disk operating**

Check the VGA card manufacturer for a driver update and VGA BIOS update, make sure the VGA card supports the Suspend to Ram function.

## **Audio Issue**

**How can I disable the on-board Audio?**

Go to the SOYO Combo Feature menu in the BIOS setup, then set the "onboard audio" to disable.



**I cannot get the sound working on my system.**

1. Check if the speaker wire is connected to the line out connector on the M/B. Make sure the SPDIF card cable isn't connected the wrong way around.
2. Check if your speakers are powered on.
3. Install the audio driver supplied on our driver disc.
4. Check BIOS setup if "onboard audio" is enabled.
5. If sound is already installed, check our website for an audio driver update.

**The sound is working in my system, but when I play CD music from the CD-ROM, I do not get any sound. What is wrong?**

This is because the 4-wire audio cable from the CD-ROM to the on-board CDIN connector or AUX connector on the M/B is not connected. See manual for location of CDIN.

**The sound and everything else works fine except that the line-in and/or microphone doesn't work. What is wrong?**

1. Please go to sound properties and check if the line-in and/or microphone are enabled.
2. Check if the Microphone/line-in device is ok.
3. If you use the 4-channel option and you are connection your PC (not via the SPDIF card), line-in will be disabled. Line-in works normally when using the SPDIF card for speaker connections in 4-channel mode.

**Added PCI Audio Card does not work on this motherboard.**

1. Go to SOYO COMBO Setup and Disable "onboard audio".
2. Go to integrated peripherals and Disable "Game port address" and "Midi port address"

**Hard disk/FDD/ CD-ROM issues****My Western digital HDD is not detected during boot-up**

Change the jumper settings to cable select or single.

**Sometimes the system finds my CD-ROM, sometimes not**

1. Check CD-ROM if it is working properly.
2. The power supply might not have enough wattage to support all the peripherals. If your system has other peripherals connected, like CD-RW, extra HDD, etc. disconnect them.

**When I boot up my new computer I get "floppy boot failure" and the LED on the floppy stays on**

1. Make sure the red wire of floppy ribbon cable goes to Pin1 on the floppy drive side (don't trust the "key lock" or "notch") and use the end-connector of the cable (don't use middle one).
2. Some floppy drivers have their own jumper to make the same twist as the twist on the cable. Make sure this jumper is set not to "twist" the cable while the floppy drive is connected to the twisted end of the cable.

**RAID issue****Windows does not detect the on-board RAID.**

1. Enable the on-board RAID function in the BIOS.
2. Install the RAID driver, see chapter 6 for more info.

**Can I use my CD-ROM or other IDE device (except HDD) on IDE 3 & 4, SATA 1-4?**

No, the IDE3,4 and all SATA ports only support Hard disks.

**Can I use IDE 3 & 4 and / or SATA 3-4 as a normal IDE channel?**

Yes, no need to change any settings in the BIOS. Just make sure to install the driver, check Chapter 6 for more info.

**I cannot get the HDD to boot from IDE 3 or IDE 4, why?**

Make sure that the 1st boot device in the BIOS is set to "other device" and then set the "other device boot order" to "IDE3,4/SCSI".

**Boot-up from my IDE3/4, I get blue screen upon entering Windows system**

Make sure the raid option in the BIOS is enabled.

## LAN Issues

### **I have problem installing Novell NetWare v.50**

Disable the APIC option in the BIOS.

For updated FAQs, please check <http://www.soyogroup.com/support/>

## **Contact Information**

## How to contact us:

- If you are interested in our products, please contact the SOYO sales department in the region you live.
- If you require Technical Assistance, please contact our Technical Support in the region you live.

SOYO prefers Email as a communication medium, remember to *always add to the email the country that you live in.*

### **TAIWAN**

SOYO ENTERPRISE LTD

---

1st F., No. 38, Lane 15, Sec. 6, Minquan  
East Road, Neihu District, Taipei City  
11494, Taiwan, R.O.C..

---

TEL: 886-2-2791-5688

FAX: 886-2-2791-8599

<http://www.soyo.com.tw/>

Email: [info@mail.soyo.com.tw](mailto:info@mail.soyo.com.tw)

### **USA**

SOYO GROUP INC.

---

1420 S. Vintage Ave. Ontario, CA  
91761, USA

---

TEL: 909-292-2500

FAX: 909-937-0783

<http://www.soyogroup.com>

<http://www.soyogroup.com/kb>

For technical support

<http://www.soyogroup.com/support/>

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>