

STERLCO TEMPERATURE CONTROL UNIT  
SERVICE AND INSTRUCTION MANUAL

MODEL S-8613

Engineered and Manufactured by INDUSTRIAL CONTROL DIVISION  
STERLING, INC.

5200 West Clinton Avenue, P.O. Box 23435, Milwaukee, WISCONSIN 53223-0435  
Manufacturers of Temperature Control Equipment Since 1916

## Please note that our address and phone information has changed. Please reference this page for updated contact information.



These manuals are obsolete and are provided only for their technical information, data and capacities. Portions of these manuals detailing procedures or precautions in the operation, inspection, maintenance and repair of the products may be inadequate, inaccurate, and/or incomplete and shouldn't be relied upon. Please contact the ACS Group for more current information about these manuals and their warnings and precautions.

### Parts and Service Department

The ACS Customer Service Group will provide your company with genuine OEM quality parts manufactured to engineering design specifications, which will maximize your equipment's performance and efficiency. To assist in expediting your phone or fax order, please have the model and serial number of your unit when you contact us. A customer replacement parts list is included in this manual for your convenience. ACS welcomes inquiries on all your parts needs and is dedicated to providing excellent customer service.

#### For immediate assistance, please contact:

- North, Central and South America, 8am – 5pm CST +1 (800) 483-3919 for drying, conveying, heating and cooling and automation. For size reduction: +1 (800) 229-2919.  
North America, emergencies after 5pm CST (847) 439-5855  
**North America email: [acsuscanadacustserv@corpemail.com](mailto:acsuscanadacustserv@corpemail.com)**
- Mexico, Central & South America  
**Email: [acslatinamericacustserv@corpemail.com](mailto:acslatinamericacustserv@corpemail.com)**
- Europe, Middle East & Africa +48 22 390 9720  
**Email: [acseuropecustserv@corpemail.com](mailto:acseuropecustserv@corpemail.com)**
- India +91 21 35329112  
**Email: [acsindiacustserv@corpemail.com](mailto:acsindiacustserv@corpemail.com)**
- Asia/Australia +86 512 8717 1919  
**Email: [acsasiacustserv@corpemail.com](mailto:acsasiacustserv@corpemail.com)**

### Sales and Contracting Department

Our products are sold by a worldwide network of independent sales representatives. Contact our Sales Department for the name of the sales representative nearest you.

Let us install your system. The Contract Department offers any or all of these services: project planning; system packages including drawings; equipment, labor, and construction materials; and union or non-union installations.

#### For assistance with your sales or system contracting needs please Call:

North, Central and South America +1 (262) 641-8600 or +1 (847) 273-7700 Monday–Friday, 8am–5pm CST

Europe/Middle East/Africa +48 22 390 9720

India +91 21 35329112

Asia/Australia +86 512 8717 1919

#### Facilities:

ACS offers facilities around the world to service you no matter where you are located. For more information, please visit us at [www.acscorporate.com](http://www.acscorporate.com)

United States:

#### ACS Schaumburg – Corporate Offices

1100 E. Woodfield Road  
Suite 588  
Schaumburg, IL 60173  
Phone: + 1 847 273 7700  
Fax: + 1 847 273 7804

#### ACS New Berlin – Manufacturing Facility

2900 S. 160<sup>th</sup> Street  
New Berlin, WI 53151  
Phone : +1 262 641 8600  
Fax: + 1 262 641 8653

Asia/Australia:

#### ACS Suzhou

109 Xingpu Road SIP  
Suzhou, China 215126  
Phone: + 86 8717 1919  
Fax: +86 512 8717 1916

Europe/Middle East/Africa:

#### ACS Warsaw

Ul. Działkowa 115  
02-234 Warszawa  
Phone: + 48 22 390 9720  
Fax: +48 22 390 9724

India

#### ACS India

Gat No. 191/1, Sandbhor Complex  
Mhalunge, Chakan, Tal Khed,  
Dist. Pune 410501, India  
Phone: +91 21 35329112  
Fax: + 91 20 40147576

MODEL: S-8613 SERIES

	<u>PAGE</u>
INTRODUCTION . . . . .	1
INSTALLATION AND CIRCULATION . . . . .	2 - 4
Flow Diagram	
Elementary Diagram	
OPERATION . . . . .	5
PREVENTATIVE MAINTENANCE . . . . .	6
TROUBLESHOOTING (UNIT) . . . . .	(1) - (4)
STERLCO PUMP & MOTOR . . . . .	
SOLENOID VALVE . . . . .	
HEATER ELEMENT . . . . .	
MOTOR STARTER . . . . .	
CONTACTOR . . . . .	
PARTS LIST . . . . .	

STERLCO TEMPERATURE CONTROL UNIT  
SERVICE AND INSTRUCTION MANUAL

MODEL S-8613

Engineered and Manufactured by INDUSTRIAL CONTROL DIVISION  
STERLING, INC.

5200 West Clinton Avenue, P.O. Box 23435, Milwaukee, WISCONSIN 53223-0435  
Manufacturers of Temperature Control Equipment Since 1916

## MODEL: S-8613 SERIES

### INTRODUCTION

The Model S-8613 single zone temperature control unit is designed to continuously circulate water to an open tank or a process requiring very low pressure while automatically maintaining the temperature which the operator has selected. It is designed for use through a temperature range from tap water temperature up to approximately 180° F.

The Sterl-Tronic High Temperature Control Unit; designed and tested over a period of many years, represents one of the most significant advances ever in its field. These self-contained units are used for a variety of applications such as circulating temperature controlled water through molds, rolls or jackets of processing equipment.

The Sterl-Tronic temperature control unit is designed to circulate water through your process and to precisely, automatically, and reliably maintain this water at the selected temperature. The unit is well suited for use with a city water supply, water from portable or central chillers, towers, or with well water.

Many new improved designed features have been incorporated into the Sterl-Tronic. Among them are: solid-state electronic thermostat, automatic mechanical proportioning of heating and cooling, and dual electronic sensing probes.

The relatively small amount of water, rapidly recirculated by the Sterl-Tronic, provides a close and uniform temperature relationship between the delivery and return lines of the unit. This assures uniform and stable temperature control as well as a very even temperature throughout the work area. Also, the high rate of recirculation combined with the large immersion heater and high cooling rate, gives the unit exceptionally fast response in bringing the process up to temperature and in making changes of settings when necessary.

These standard units may have many variations of optional features added to them, relative to the customer's application of specific desires.

The unit is warranted against defects in materials and workmanship for one year from date of shipment.

Any Sterlco unit which has been used contrary to specific operation instructions or materially altered, will not be covered by this warranty. Final determination of defects must be made at Sterling, Inc.

The units can easily be moved from one location to another, simply by removing the circulating connection lines.

By following the instructions in the manual and treating your equipment with care and respect due any precision equipment, you will be rewarded with years of uninterrupted, trouble free service.

MODEL: S-8613 SERIES

INSTALLATION AND CIRCULATION

SYSTEM TEMPERATURES

The system temperatures are easily read on the meter which is part of the thermostat. Its long thin needle with close calibration permits the detection of small temperature variations.

ELECTRICAL

The pump motor and immersion heater operate on three phase, full line voltage with the control circuit operating at 115 V. single phase. The control circuit voltage is provided by a single phase transformer wired across two legs of the three phase power supply. Magnetic motor starters with overload and high/low voltage protection are used for the pump motors. The 115 V. control circuit is fused. These units are supplied for three phase operation for a selected voltage. Caution must be taken to provide a correctly sized power supply to the unit. Refer to unit nameplate for proper voltage and amperage requirements. These units must be securely grounded. Electrical connections and service should only be made with the power disconnected, and only by a qualified electrician.

NOTE:

ALL PUMP MOTORS ARE THREE (3) PHASE AND PUMP ROTATION MUST BE CHECKED TO INSURE PROPER OPERATION OF YOUR UNIT.

DELIVERY AND RETURN CONNECTIONS

Since the delivery and return hoses create resistance to flow, we suggest that the hoses be as short in length and as large in diameter as possible. Even though the passages in the process may be small, it is necessary to use large hoses and fittings to minimize the total restriction to flow.

MODEL: S-8613 SERIES

Installation and Circulation - Continued

PUMP

The pump is a straight centrifugal type, bronze-fitted. It has a high output capacity with good discharge pressure and is well suited for the conditions under which the unit is designed to operate. The circulating capacity available to the user, outside the unit, is as stated below.

NOTE:

ALL PUMP MOTORS ARE THREE (3) PHASE AND PUMP ROTATION MUST BE CHECKED TO INSURE PROPER OPERATION OF YOUR UNIT.

A special seal-flush system in the pump, helps keep the seal clean, thereby extending seal life. The seal itself is the finest type available for this type of service and provides an excellent combination of long wearability, high abrasion resistance and heat resistance. The following table is a listing of true unit capacities.

1/2 H.P.	15 GPM @ 20 PSI
3/4 H.P.	20 GPM @ 20 PSI
1 H.P.	30 GPM @ 25 PSI
1-1/2 H.P.	40 GPM @ 30 PSI
2 H.P.	50 GPM @ 30 PSI
3 H.P.	45 GPM @ 40 PSI
5 H.P.	60 GPM @ 50 PSI

COOLING

Cooling is accomplished by the direct mixing of plant cooling water into the circulating system. Naturally the plant water supply temperature will govern the minimum operating temperature of the unit.

MODEL: S-8613 SERIES

Installation and Circulation - Continued

WATER SUPPLY

It is very important that the water supply to the unit meets certain requirements. We recommend a full sized hose, equal to the pipe size of our water supply connection and without restrictive fittings.

The water supply line should be open to the unit whenever the unit is running. While a certain minimum supply pressure (10 p.s.i., 0.70 kg/cm<sup>2</sup>) is necessary, supply pressures over 75 p.s.i. (5.27 kg/cm<sup>2</sup>) while serving no useful purpose may indeed cause damage to the unit and shorten its life. If your water pressure is excessively high, it is recommended that a pressure regulator be installed in the supply line with a relief valve downstream from the regulator and set slightly higher than the regulator. Hard or corrosive water can be damaging to the unit and your equipment, especially since the temperatures at which the system operates tend to accelerate deposits or corrosion. Also, bad water can build layers of scale or lime on inside surfaces, slowing down water flow and causing control problems and eventual damage to the equipment. Since the corrective maintenance and downtime often caused by bad water are costly, it is well worthwhile to treat the supply water. In general, we have found that customers using good water seldom buy parts. Industrial water treatment to neutralize these conditions is relatively inexpensive and in many cases is truly a wise investment.

PROCESS CONNECTIONS:

Connection lines and connectors between the Temperature Control Unit and the process should be selected by the customer to suit the needs and requirements of the application.

These connection lines and connectors should be inspected frequently to ensure that the original service rating has not been reduced by age and/or deterioration.



MODEL: S-8613 SERIES

OPERATION

"ON-OFF" SWITCH

"ON" Position

When the switch is in the "ON" position, the fill solenoid is opened and supplies raw water to the system. Once the water in the tank reaches the correct level, the float switch closes. The fill solenoid is closed automatically and the motor starter is energized. The starter then supplies power to the motor and temperature controller and the controller begins to regulate "Heating" or "Cooling".

If the water level in the tank becomes too low, the float switch opens causing the fill solenoid to open. Raw water is again supplied to the system. The motor starter de-energizes, cutting power to the motor and temperature controller.

"OFF" Position

When the switch is pressed to the "Off" position and the float switch is closed, the motor starter is de-energized cutting power to the motor and temperature controller.

When the switch is pressed to the "Off" position and the float switch is open, the fill solenoid closes.

TEMPERATURE SELECTION

Position the "SET-POINT" on the temperature controller to the desired temperature.

Select Lo or Hi heat with the HEAT SELECTOR SWITCH.

As the unit operates in the heating cycle, the HEAT pilot light will illuminate. When the temperature of the water increases beyond the set point, the unit will automatically switch to the cooling cycle and the COOL pilot light will illuminate.

A small neutral band is provided in the thermostat between heat-on and cooling-on so that at times the unit will maintain continuous circulation without heating or cooling.

MODEL: S-8613 SERIES

SHUTDOWN

Prior to shutdown, the water supply to the unit should be shut off.

Water supply and drain lines, delivery and return lines, and the power supply may then be disconnected.

DRAINING

If your Steri-Tronic is to be taken out of service for a long time, or if it will be exposed to freezing, it should be thoroughly drained. Drain plugs are provided at the base of the heater tank, and water supply and drain lines. Open the blow-off valve to drain the tank.

OPERATION OF ONE ZONE ONLY ON A DUAL OR TRIPLE ZONE UNIT

When one zone of a dual or triple zone unit is to be operated while the other remains idle, it is necessary to run a by-pass line from the delivery to the return line of the idle zone.

PREVENTATIVE MAINTENANCE

EVERY SIX (6) MONTHS - DISCONNECT ALL POWER PRIOR TO SERVICING

Inspect all electrical connections for secure attachment and for safe and secure ground connections. Inspect the power cable, especially at entrance point to the unit. This inspection should be made by a qualified electrician!

MODEL: S-8613 SERIES

TROUBLESHOOTING

TEMPERATURE FLUCTUATIONS Alternate Overheating and Overcooling.

While the user might be inclined to believe the trouble is with the controller, this fluctuation can most always be traced to poor water flow, resulting from one or more of the following conditions.

1. Small connectors or restricted water passages. Decreased water flow will create a long reaction time which causes overheating and overcooling.
2. Very long connecting lines or long serpentine flow of water in and out of the process in series rather than in parallel. Refer to the page on installation.
3. Blocked water line in the process. New molds sometimes contain metal chips or other foreign particles inside the water lines. Old molds sometimes contain lime or rust accumulations.
4. Quick disconnect fitting with check valves. (A source of very serious obstruction.) The check valves should be removed.
5. Lime buildup in the piping or fittings.

NOTE: The unit can be checked for normal control by the use of a short line of 3/4" or 1/2" hose connected directly from the delivery to the return line. This will provide a condition of very good flow and will establish whether the blockage is in the unit or the external piping.

RAPID CYCLING FROM HEAT TO COOL

This condition is traceable to the same causes as the temperature fluctuations indicated above.

UNABLE TO HEAT PROPERLY

When the temperature will not rise above a certain temperature, the cause will generally be traced to continuous loss of water from the system (allowing cooling water to enter). This can be checked by observing the drain. Under some conditions it is possible to have the solenoid valve close on a particle of grit which, of course, will allow the valve to continuously leak. This solenoid valve can be flushed out easily by having the operator adjust the "set point" up and down scale several times to open and close the solenoid. If it continues to leak, the unit should be stopped and the electric power and water turned off and the solenoid valve should be taken apart and cleaned or replaced, as required.

Another cause would be traceable to a leaking hose or fitting somewhere in the system. It is also possible that the immersion heater might be inoperative or defective. Most any qualified electrician can check this. Heater terminals are readily accessible for inspection.

NO HEAT AT ALL

Check to be sure that the contactor moves "in" and "out" in response to signals from the controller. This can be done by positioning the thermostat above and below the temperature set point. The contactors should move "in" and "out" as the needle passes the set point. If it does not function, the controller may be faulty and the section of this manual dealing with controller diagnosis should be studied and followed. If the contactor does function, but no heat is produced, then the problem may be within the heater, assuming that the steps listed under "Unable to Properly Heat" have been followed first. The heater can be quickly checked by using an ammeter. If all 3 legs draw equal current, the heater is okay.

UNABLE TO COOL

In order to cool, the unit must pass water to the drain directly, or through the heat exchanger if the unit has a heat exchanger. Therefore, if your unit does not provide cooling; the following steps should be taken to help locate the cause.

1. Check to see that the water supply is open at all times while the unit is in operation.
2. Check to see if water flows to the drain when the unit calls for cooling.
3. Check the solenoid valve for proper operation - observe the drain. Water should flow to drain in response to solenoid action. If the drain cannot be seen, a simple method of check is by "feel" of the drain piping at the unit, with the solenoid alternately open and closed.
4. If the solenoid valve is operating properly, a "no flow" condition could be the result of a plugged heat exchanger, which could reduce or stop the cooling water flow on those units which contain heat exchangers.
5. High back pressure from the drain could easily cause a limited ability to cool, since the unit depends upon the pressure differential between the water supply and drain for the amount of cooling available.

## MODEL: S-8613 SERIES

### HEATER BURN OUT

A direct visual indication of heater burn out is the presence of scorched or discolored paint on the heater tank. In most cases, the water level inside the tank at the time of burn out can be determined because the paint on the exterior of the tank below the water level will not be scorched. Causes of heater burn out are generally traceable to:

1. The unit not being filled with water and purged of air prior to start-up.
2. A faulty heater (tank discoloration not always present).
3. A plugged system or badly obstructed flow.

### PUMPS AND SEALS

Before leaving our factory, each unit is operated for a considerable period of time and calibrated. After this test, the unit is drained and blown out with air to remove most of the water from the piping systems. If the unit is allowed to stand idle for a long time before being installed in your factory, the housing gasket on the pump can dry out and possibly leak when the unit is started. In many cases these gaskets will swell and form a tight seal, while in other cases it may be necessary to tighten the pump screws to avoid a leaking condition.

The pump seal surface may separate slightly because of rough handling or considerable vibration during transit from our plant to yours. This will cause leakage at the pump seal when the pump is started, but in most cases the surface will mate again after the pump is allowed to run for short periods of time. If they do not mate, it will be necessary to open the pump and free the seal by hand. It is seldom necessary to install a replacement seal in a new unit unless the seal has been damaged because the unit has been started without water.

Our pump seals should give a long service life. There are conditions which tend to shorten the seal life - such as presence of grit, operation of the unit without water, sustained high water temperatures or the presence of certain chemicals in the water. Our pump seal assembly has been developed to resist abrasive particles which we find present in many water systems. It is also fitted with high temperature flexible components for a maximum amount of heat resistance. These same components remain flexible even at low temperatures. Thus, the standard seal has a fine combination of heat and wear resistance.

MODEL: S-8613 SERIES

After the unit has been in service for a period of years where abrasive conditions are present, you may find that the pump casting, which is designated as our "bracket", can be eroded away in the area around the seat of the rotary seal. This area should provide a straight, smooth surface against which the O-ring of the seal seat should bear. Should your casting show signs of erosion in this area, we would strongly recommend that the casting be replaced, since the replacement cost of the casting is a very modest investment when compared with downtime and maintenance cost for replacing a seal which has been installed in a worn out pump. A small puddle underneath the unit is a sign of rotary seal wear, and if your investigation confirms the pump as the source of the leak we would recommend that the seal be replaced as soon as practical. If allowed to leak, the water will eventually find its way to the lower motor bearing and cause further damage. The water slinger is intended to provide temporary protection against this possibility, but a continued and substantial leak will, undoubtedly, ruin the motor bearing.

Even though your maintenance people may have had many years of experience in dealing with pumps in general, we would strongly suggest that they follow our Form I-4100-E1 when overhauling the pumps. Careful attention to these instructions will help assure a proper installation and minimum downtime.

Under some conditions, users find that the pump will not start. After turning off the power supply it would be well to check the motor shaft to be certain that it is free to turn. By removing the drip cover atop the motor, access is provided to the end of the shaft, which has been slotted so that it might be turned with a screwdriver. If the shaft is found free to turn, we would suggest that the power supply to the unit be checked on all legs to be certain that the power is available to the motor. If these two items have been checked, we would then recommend that a competent electrician be called upon to check the motor and its circuit.

NOTE:

IF THE PUMP MOTOR IS UNWIRED FOR REMOVAL FROM THE UNIT, IT IS VERY IMPORTANT THAT YOU CHECK THE ACTUAL DIRECTION OF ROTATION WHEN THE MOTOR IS REWIRED INTO THE UNIT.

**MODEL: S8613**

<b><u>PART NO.</u></b>	<b><u>DESCRIPTION</u></b>
729.00084.00	Contactor 30 amp
601.00479.01	Controller, S3 (250 degree)
601.00479.02	Controller, S3 (300 degree)
601.00479.03	Controller, S3 (180 degree)
725.00600.00	Fuse, Control #FNM 1.6 amp @ 250V
722.00126.01	Immersion Heater 9KW @ 480V
722.00126.02	Immersion Heater 9KW @ 240V
542.00007.08	Heater Gasket
715.10037.00	Pilot Light (Red - "Power-On")
715.10036.00	Pilot Light (Amber - "Pump-Run")
692.07369.03	Probe, Sensing (Heat & Cool)
732.00024.00	Solenoid Valve 1/4" 115v coil 5/32" orifice
162.00001.18	Solenoid Coil only 115v coil
732.00072.00	Solenoid Valve 1/2" 115v coil 5/8" orifice
162.00001.06	Solenoid Coil only 115v coil
726.00005.02	Starter, Motor Size "00"
726.00007.02	Starter, Motor Size "0"
632.02858.01	Switch, Pressure
732.00007.00	Solenoid Valve 1/4" 115v coil 9/32" Orifice
717.10027.00	Switch, Selector (ON-OFF)
717.10029.00	Switch, Selector, (COOL)
724.00206.00	Thermostat, Safety (250 degrees)
724.00221.00	Thermostat, Safety (100-600 degrees)
704.00052.00	Transformer 150VA (230-460v)
044.00138.00	Valve, Safety Relief 3/4"
044.00014.00	Valve, Check 3/4"
044.00034.00	Valve, Check 3/4"
701.00066.00	Relay, Rotation Sensor
734.00018.00	Switch, Float
572.00169.01	Tank, Galvanized
672.07324.00	Tank, Heater Brass

STERLING, INC.  
PARTS LIST A & C  
STERLCO PUMP 1/2HP & 3/4HP

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
C	542.10404.00	Water Slinger
E	615.13341.01	Bracket
E	615.13341.03	Bracket, Brass
H	081.00024.02	Rotary Seal Assembly
I	695.18409.00	Impeller, Standard Brass, 1/2HP
I	695.18409.03	Impeller, Standard Brass, 3/4HP
J	001.06850.00	Impeller Screw
K	545.00001.00	Housing Gasket
LA	615.14921.00	Volute
LB	614.14951.00	Housing
B	720.09170.00	Motor 1/2HP 3/60/230-460v TEFC
B	720.09167.00	Motor 1/2HP 3/60/230-460v Open
B	720.09168.00	Motor 3/4HP 3/60/230-460v Open
B	720.09190.00	Motor 3/4HP 3/60/230-460v TEFC

**MOTOR, IMPELLER, SEAL ASSEMBLY**

695.00007.03	1/2HP 3/60/230-460v Open
695.00007.24	1/2HP 3/60/230-460v TEFC
695.00030.03	3/4HP 3/60/230-460v Open
695.00030.10	3/4HP 3/60/230-460v TEFC
695.00019.04	1/2HP 3/60/230-460v BRASS

STERLING part numbers apply to non-special motors.

STERLING, INC. 5200 West Clinton Avenue, Milwaukee, Wisconsin 53223-0435  
Phone 414-354-0970 or 800-783-7835



STERLING, INC.  
PARTS LIST D - G  
STERLCO PUMP 1HP & 3HP

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
O	001.05915.00	Motor Screw, (4) required
P	542.10404.00	Water Slinger
Q	615.00001.00	Bracket (obsolete - see attached)
S		Impeller-specify part number and diagram (see pump nameplate)
T	525.00001.00	Lock Washer
U	535.00001.00	Impeller Nut
V	545.00002.00	Housing Gasket
W-A	615.00003.00	Threaded Inlet Casting
W-B	615.00002.00	Tank Inlet Casting
X-A	001.05915.00	Pump Screw for pump w/threaded suction (8) required
X-B	001.05915.00	Pump Screw for pump w/tank suction (6) required
X-B	001.05923.00	Pump Screw for pump w/tank suction (2) required

ABOVE PARTS ILLUSTRATED ON FORM MP-1

M	160.00005.00	Motor Drip Cover (**)
N	720.09003.00	Motor 1HP 3/60/230-460v Open (#)
N	720.09009.00	Motor 1HP 3/60/230-460v TEFC (#-*)
N	720.09004.00	Motor 1-1/2HP 3/60/230-460v Open (#)
N	720.09010.00	Motor 1-1/2HP 3/60/230-460v TEFC (#-*)
N	720.09005.00	Motor 2HP 3/60/230-460v Open (#)
N	720.09011.00	Motor 2HP 3/60/230-460v TEFC (#-*)
N	720.09006.00	Motor 3HP 3/60/230-460v Open (#)
N	720.09012.00	Motor 3HP 3/60/230-460v TEFC (#-*)

\*\* Used only on drip proof motors

# State Motor Manufacturer if preferred

\* State Special Specification (i.e. 7EQ-Spec, 7E-Spec, etc)

STERLING part number apply to non-special motors  
STERLING, INC. 5200 West Clinton Avenue, Milwaukee, Wisconsin 53223-0435  
Phone 414-354-0970 or 800-783-7835

**STERLING, INC.  
PARTS LIST D - G  
STERLCO PUMP 1HP & 3HP**

**COMPLETE PUMP & MOTOR ASSEMBLY**

**Open Drip Proof 3450 RPM, 3/60/230-460v**

<b>605.00083.11</b>	<b>1 HP</b>
<b>605.00084.07</b>	<b>1-1/2 HP</b>
<b>605.00065.03</b>	<b>2 HP</b>
<b>605.00086.01</b>	<b>3 HP</b>

**TEFC 3450 RPM, 3/60/230-460v**

<b>605.00083.11</b>	<b>1 HP</b>
<b>605.00084.02</b>	<b>1-1/2 HP</b>
<b>605.00065.01</b>	<b>2 HP</b>
<b>605.00086.03</b>	<b>3 HP</b>

**7EQ and Explosion Proof Not Included**

**STERLING part numbers apply to non-special motors.  
STERLING, INC. 5200 West Clinton Avenue, Milwaukee, Wisconsin 53223-0435  
Phone 414-354-0970 or 800-783-7835**

# Installation & Maintenance Instructions

2-WAY DIRECT-ACTING SOLENOID VALVES

NORMALLY OPEN OR NORMALLY CLOSED OPERATION

BRASS OR STAINLESS STEEL CONSTRUCTION - 1/8", 1/4", OR 3/8" NPT

SERIES

8262

8263

Form No. V5256R8

**IMPORTANT:** See separate solenoid installation and maintenance instructions for information on: Wiring, Solenoid Temperature, Causes of Improper Operation, and Coil or Solenoid Replacement.

## DESCRIPTION

Series 8262 and 8263 valves are 2-way direct-acting general service solenoid valves. Valves bodies are of rugged brass or stainless steel. Series 8262 or 8263 valves may be provided with a general purpose or explosionproof solenoid enclosure. Series 8262 and 8263 valves with suffix "P" in the catalog number are designed for dry inert gas and non-lubricated air service.

## OPERATION

**Normally Open:** Valve is open when solenoid is de-energized; closed when is energized.

**Normally Closed:** Valve is closed when solenoid is de-energized; open when energized.

**IMPORTANT:** No minimum operating pressure required.

### Manual Operation

Manual operator allows manual operation when desired or during an electrical power outage. Depending upon basic valve construction, three types of manual operators are available:

#### Push Type Manual Operator

To engage push type manual operator, push stem at base of valve body upward as far as possible. Valve will now be in the same position as when the solenoid is energized. To disengage manual operator, release stem. Manual operator will return to original position.

#### Screw Type Manual Operator

To engage screw type manual operator, rotate stem at base of the valve body clockwise until it hits a stop. Valve will now be in the same position as when the solenoid is energized. To disengage, rotate stem counterclockwise until it hits a stop.

**CAUTION:** For valve to operate electrically, manual operator stem must be fully rotated counterclockwise.

#### Stem/Lever Type Manual Operator

To engage manual operator, turn stem/lever clockwise until it hits a stop. Valve will now be in the same position as when the solenoid is energized. To disengage manual operator, turn stem/lever counterclockwise until it hits a stop.

**CAUTION:** For valve to operate electrically, manual operator stem/lever must be fully rotated counterclockwise.

### Flow Metering Devices

Valves with suffix "M" in catalog number are provided with a metering device for flow control. Turn stem to right to reduce flow; left to increase flow.

## INSTALLATION

Check nameplate for correct catalog number, pressure, voltage, frequency, and service. Never apply incompatible fluids or exceed pressure rating of the valve. Installation and valve maintenance to be performed by qualified personnel.

Note: Inlet port will either be marked "I" or "IN". Outlet port will be marked "2" or "OUT".

### Future Service Considerations.

Provision should be made for performing seat leakage, external leakage, and operational tests on the valve with a nonhazardous, noncombustible fluid after disassembly and reassembly.

### Temperature Limitations

For maximum valve ambient and fluid temperatures, refer to charts below. Check catalog number, coil prefix, suffix, and watt rating on nameplate to determine the maximum temperatures.

Wattage	Catalog Number Coil Prefix	Coil Class	Max. Ambient Temp. °F	Max. Fluid Temp. °F
6, 10.5, 12.4	none, DA or S	A	77	180
6, 10.5 12.4	DF, FT or SF	F	125	180
6, 10.5, 12.4	HT	H	140	180
9, 10.7	none, DP or SP	F	77	180
9.7	none, FT or HT	A, F or H	77	120
11.2	none, FT or HT	A, F or H	77	150
16.7	none, DP or SP	F	77	200
17.1	none, KP SP or SD	F	125	180
17.1	HB, KB SS or SV	H	140	180

Catalog Nos. 8262B200 and 8262 C200 AC construction only and Catalog Nos. 8262B214 and 8262 D200 AC and DC construction are limited to 140°F fluid temperature.

Valves with Suffix V or W that are designed for AC service and normally closed operation are for use with No. 2 and 4 fuel oil service. These valves have the same maximum temperatures per the above table except Suffix W valves are limited to a maximum fluid temperature of 140°F.

Listed below are valves with Suffix V in the catalog number that are acceptable for higher temperatures.

Catalog Number Coil Prefix	Max. Ambient Temp. °F	Max. Fluid Temp. °F
FT8262, HB8262 FT8263, HB8263 8262G, 8263G	125	250*
HT or HB 8262G HT or HB 8263G	140	250

\*The only exception is the 8262G and 8263G series (Class F coil) at 50 Hz rated 11.1 and 17.1 watts are limited to 210°F fluid temperature.

### Positioning

This valve is designed to perform properly when mounted in any position. However, for optimum life and performance, the solenoid should be mounted vertically and upright to reduce the possibility of foreign matter accumulating in the solenoid base sub-assembly area.

Valves with suffix "P" in the catalog number must be mounted with the solenoid vertical and upright.

### Mounting

Refer to Figure 2 for mounting dimensions.

### Piping

Connect piping or tubing to valve according to markings on valve body. Inlet port will either be marked "I" or "IN". Outlet port will be marked "O" or "OUT". Wipe the pipe threads clean of cutting oils. Apply pipe compound sparingly to male pipe threads only. If applied to valve threads, the compound may enter the valve and cause operational difficulty. Avoid pipe strain by properly supporting and aligning piping. When tightening the pipe, do not use valve or solenoid as a lever. Locate wrenches applied to valve body or piping as close as possible to connection point.

**IMPORTANT:** To protect the solenoid valve, install a strainer or filter suitable for the service involved, in the inlet side as close to the valve as possible. Clean periodically depending on service conditions. See ASCO Series 8600, 8601 and 8602 for strainers.

## MAINTENANCE

**▲ WARNING:** To prevent the possibility of personal injury or property damage, turn off electrical power, depressurize valve, and vent fluid to a safe area before servicing the valve.

**NOTE:** It is not necessary to remove the valve from the pipeline for repairs.

### Cleaning

All solenoid valves should be cleaned periodically. The time between cleanings will vary depending on the medium and service conditions. In general, if the voltage to the coil is correct, sluggish valve operation, excessive noise or leakage will indicate that cleaning is required. In the extreme case, faulty valve operation will occur and the valve may fail to open or close. Clean strainer or filter when cleaning the valve.

### Preventive Maintenance

- Keep the medium flowing through the valve as free from dirt and foreign material as possible.
- While in service, the valve should be operated at least once a month to insure proper opening and closing.
- Depending on the medium and service conditions, periodic inspection of internal valve parts for damage or excessive wear is recommended. Thoroughly clean all parts. If parts are worn or damaged, install a complete ASCO Rebuild Kit.

### Causes of Improper Operation

- **Incorrect Pressure:** Check valve pressure. Pressure to valve must be within range specified on nameplate.
- **Excessive Leakage:** Disassemble valve (see Maintenance) and clean all parts. If parts are worn or damaged, install a complete ASCO Rebuild Kit.

### Valve Disassembly

1. Disassemble valve using exploded views for identification of parts.
2. Remove solenoid, see separate instructions.
3. Unscrew solenoid base sub-assembly or valve bonnet with special wrench adapter supplied in ASCO Rebuild Kit. For wrench adapter only, order No. K218948. Remove core assembly, core spring, and solenoid base gasket from valve body. For normal maintenance on Series 8263 valves it is not necessary to remove valve seat. See Figure 1 for metering or manual operator constructions.
4. For normally open construction (Figure 3) remove end cap, or manual operator, (not shown) end cap gasket, disc holder spring, and disc holder assembly.
5. All parts are now accessible to clean or replace. If parts are worn or damaged, install a complete ASCO Rebuild Kit.

### Valve Reassembly

1. Use exploded views for identification, orientation and placement of parts.
2. Lubricate all gaskets with DOW CORNING® 111 Compound lubricant or an equivalent high-grade silicone grease.
3. For normally open construction (Figure 3), install disc holder assembly, disc holder spring, end cap gasket and end cap or manual operator. For valves with 1/8" NPT, torque end cap or manual operator to  $90 \pm 10$  in-lbs [ $10.2 \pm 1.1$  Nm]. For all other valves torque end cap or manual operator to  $175 \pm 25$  in-lbs [ $19.8 \pm 2.8$  Nm].
4. For Series 8263 apply a small amount of LOCTITE® PST® pipe sealant to threads of valve seat (if removed). Follow manufacturers instructions for application of pipe sealant. Then install valve seat and torque to  $75 \pm 10$  in-lbs [ $8.5 \pm 1.1$  Nm].
5. Replace solenoid base gasket, core assembly with core spring and solenoid base sub-assembly or plugnut/core tube sub-assembly and valve bonnet. Note: For core assemblies with internal type core springs, install wide end of core spring in core assembly first, closed end of core spring protrudes from top of core assembly.
6. For 1/8" NPT valve constructions, Torque valve bonnet to  $90 \pm 10$  in-lbs [ $10.2 \pm 1.1$  Nm]. Torque solenoid base sub-assembly to  $175 \pm 25$  in-lbs [ $19.8 \pm 2.8$  Nm].
7. Install solenoid, see separate solenoid instructions. Then make electrical hookup to solenoid.

**▲ WARNING:** To prevent the possibility of personal injury or property damage, check valve for proper operation before returning to service. Also perform internal seat and external leakage tests with a nonhazardous, noncombustible fluid.

8. Restore line pressure and electrical power supply to valve.
9. After maintenance is completed, operate the valve a few times to be sure of proper operation. A metallic *click* signifies the solenoid is operating.

## ORDERING INFORMATION FOR ASCO REBUILD KITS

Parts marked with an asterisk (\*) in the exploded view are supplied in Rebuild Kits. When Ordering Rebuild Kits for ASCO valves, order the Rebuild Kit number stamped on the valve nameplate. If the number of the kit is not visible, order by indicating the number of kits required, and the Catalog Number and Serial Number of the valve(s) for which they are intended.








Figure 1. Metering and manual operator constructions.

\* Bonnet wrench supplied in ASCO Rebuild Kits.  
For bonnet wrench only order No. K218948.


Torque Chart		
Part Name	Torque value Inch-Pounds	Torque value Newton-Meters
solenoid base sub-assembly	175±25	19,8±2,8
valve bonnet	90±10	10,2±1,1
valve seat	75±10	8,5±1,1




### Series 8262





\* Indicates Parts Supplied in ASCO Rebuild Kits.



2 MOUNTING HOLES  
190-24UNC-2B THREAD  
1/4 [6,4] MIN. FULL THREAD  
3/8 [9,5] DEEP



(1/8" NPT brass)



### Series 8263

Note:  
Wide end of core spring in core first,  
closed end protrudes from top of core.

Figure 2. Series 8262 and 8263, normally closed construction.

## Disassembly and Reassembly of Stem/Lever Type Manual Operator (Refer to Figure 3)

NOTE: There are two stem/lever manual operator constructions. They are identified by the location of the core spring as *internal* or *external* spring construction.

1. Unscrew solenoid base sub-assembly from manual operator body.
2. Unscrew manual operator body from valve body. Then remove body gasket and stem retainer.
3. Slip stem/spacer sub-assembly with stem gasket from manual operator body. Remove core assembly with core spring from center of manual operator body.
4. All parts are now accessible for cleaning or replacement. Lubricate gaskets per *Valve Reassembly* step 2.

5. Position core assembly with core spring into base of manual operator body. Then install stem/spacer sub-assembly into manual operator body to engage with core assembly.
  6. Reinstall stem retainer on body and stem/spacer sub-assembly.
- IMPORTANT:** The spacer on the stem/spacer sub-assembly must be *inside* of the stem retainer for *internal* spring construction and *outside* the stem retainer for *external* spring construction.
7. Replace body gasket and install manual operator assembly in valve body. Torque manual operator body to  $175 \pm 25$  in-lbs [ $19,8 \pm 2,8$  Nm].
  8. Replace solenoid base gasket and solenoid base sub-assembly. Torque solenoid base sub-assembly to  $175 \pm 25$  in-lbs [ $19,8 \pm 2,8$  Nm].
  9. Check manual operator for proper operation. Turn stem clockwise and counterclockwise; stem should turn freely without binding.




Figure 3. Stem/lever type manual operators

Figure 4. Series 8262, normally open construction.

# Installation & Maintenance Instructions



OPEN-FRAME, GENERAL PURPOSE, WATERTIGHT/EXPLOSIONPROOF SOLENOIDS

SERIES

8003G  
8202G

Form No.V6584R4

## SERVICE NOTICE

ASCO® solenoid valves with design change letter "G" in the catalog number (example: 8210G 1) have an epoxy encapsulated ASCO® Red-Hat II® solenoid. This solenoid replaces some of the solenoids with metal enclosures and open-frame constructions. Follow these installation and maintenance instructions if your valve or operator uses this solenoid.

## DESCRIPTION

Catalog numbers 8003G and 8202G are epoxy encapsulated pull-type solenoids. The green solenoid with lead wires and 1/2" conduit connection is designed to meet Enclosure Type 1—General Purpose, Type 2—Dripproof, Types 3 and 3S—Raintight, and Types 4 and 4X—Watertight. The black solenoid on catalog numbers prefixed "EF" is designed to meet Enclosure Types 3 and 3S—Raintight, Types 4 and 4X—Watertight, Types 6 and 6P—Submersible, Type 7 (A, B, C, & D) Explosionproof Class I, Division 1 Groups A, B, C, & D and Type 9 (E, F, & G)—Dust—Ignitionproof Class II, Division 1 Groups E, F, & G. The Class II, Groups F & G Dust Locations designation is not applicable for solenoids or solenoid valves used for steam service or when a class "H" solenoid is used. See *Temperature Limitations* section for solenoid identification and nameplate/retainer for service. When installed just as a solenoid and not attached to an ASCO valve, the core has a 0.250—28 UNF—2B tapped hole, 0.38 or 0.63 minimum full thread.

Catalog numbers 8202G1, 8202G3, 8202G5 and 8202G7 are epoxy encapsulated push-type, reverse-acting solenoids having the same enclosure types as previously stated for Catalog numbers 8003G1 and 8003G2.

### Series 8003G and 8202G solenoids are available in:

- **Open-Frame Construction:** The green solenoid may be supplied with 1/4" spade, screw, or DIN terminals. (Refer to Figure 4)
- **Panel Mounted Construction:** These solenoids are specifically designed to be panel mounted by the customer through a panel having a .062 to .093 maximum wall thickness. Refer to Figure 1 and section on *Installation of Panel Mounted Solenoid*.

### Optional Features For Type 1 — General Purpose Construction Only

- **Junction Box:** This junction box construction meets Enclosure Types 2,3,3S,4, and 4X. Only solenoids with 1/4" spade or screw terminals may have a junction box. The junction box provides a 1/2" conduit connection, grounding and spade or screw terminal connections within the junction box (See Figure 5).
- **DIN Plug Connector Kit No.K236—034:** Use this kit only for solenoids with DIN terminals. The DIN plug connector kit provides a two pole with grounding contact DIN Type 43650 construction (See Figure 6).

## OPERATION

Series 8003G — When the solenoid is energized, the core is drawn into the solenoid base sub-assembly. **IMPORTANT:** When the solenoid is de-energized, the initial return force for the core, whether developed by spring, pressure, or weight, must exert a minimum force to overcome residual magnetism created by the solenoid. Minimum return force for AC Construction is 11 ounces, and 5 ounces for DC construction.

Series 8202G — When the solenoid is energized, the disc holder assembly seats against the orifice. When the solenoid is de-energized, the disc holder assembly returns. **IMPORTANT:** Initial return force for the disc or disc holder assembly, whether developed by spring, pressure, or weight, must exert a minimum force to overcome residual magnetism created by the solenoid. Minimum return force is 1 pound, 5 ounces.

## INSTALLATION

Check nameplate for correct catalog number, service, and wattage. Check front of solenoid for voltage and frequency.

**▲ WARNING:** To prevent the possibility of electrical shock from the accessibility of live parts, install the open-frame solenoid in an enclosure.

### FOR BLACK ENCLOSURE TYPES 7 AND 9 ONLY

**▲ CAUTION:** To prevent fire or explosion, do not install solenoid and/or valve where ignition temperature of hazardous atmosphere is less than 165° C. On valves used for steam service or when a class "H" solenoid is used, do not install in hazardous atmosphere where ignition temperature is less than 180° C. See nameplate/retainer for service.

**NOTE:** These solenoids have an internal non-resettable thermal fuse to limit solenoid temperature in the event that extraordinary conditions occur which could cause excessive temperatures. These conditions include high input voltage, a jammed core, excessive ambient temperature or a shorted solenoid, etc. This unique feature is a standard feature only in solenoids with black explosionproof/dust-ignitionproof enclosures (Types 7 & 9).

**IMPORTANT:** To protect the solenoid valve or operator, install a strainer or filter, suitable for the service involved in the inlet side as close to the valve or operator as possible. Clean periodically depending on service conditions. See ASCO Series 8600, 8601, and 8602 for strainers.

### Temperature Limitations

For maximum valve ambient temperatures, refer to chart. The temperature limitations listed, only indicate maximum application temperatures for field wiring rated at 90°C. Check catalog number prefix and watt rating on nameplate to determine maximum ambient temperature. See valve installation and maintenance instructions for maximum fluid temperature. **NOTE:** For steam service, refer to *Wiring* section, *Junction Box* for temperature rating of supply wires.

Temperature Limitations For Series 8003G or 8202G Solenoids for use on Valves Rated at 10.1, 11.6, 17.1, or 22.6 Watts			
Watt Rating	Catalog Number Coil Prefix	Class of Insulation	Maximum † Ambient Temp. ° F
10.1 & 17.1	None, FB, KF, KP, SC, SD, SF, & SP	F	125
10.1 & 17.1	HB, HT, KB, KH, SS, ST, SU,	H	140
11.6 & 22.6	None, FB, KF, KP, SC, SD, SF, & SP	F	104
11.6 & 22.6	HP, HT, KB, KH, SS, ST, SU, & SV	H	104

† Minimum ambient temperature —40° F (—40° C).

### Positioning

This solenoid is designed to perform properly when mounted in any position. However, for optimum life and performance, the solenoid should be mounted vertically and upright to reduce the possibility of foreign matter accumulating in the solenoid base sub-assembly area.

### Wiring

Wiring must comply with local codes and the National Electrical Code. All solenoids supplied with lead wires are provided with a grounding wire which is green or green with yellow stripes and a 1/2" conduit connection. To facilitate wiring, the solenoid may be rotated 360°. For the watertight and

explosionproof solenoid, electrical fittings must be approved for use in the approved hazardous locations.

### Additional Wiring Instructions For Optional Features:

#### • Open-Frame solenoid with 1/4" spade terminals.

For solenoids supplied with screw terminal connections use #12-18 AWG stranded copper wire rated at 90°C or greater. Torque terminal block screws to 10 ± 2 in-lbs [1,0 ± 1,2 Nm]. A tapped hole is provided in the solenoid for grounding, use a #10-32 machine screw. Torque grounding screw to 15 - 20 in-lbs [1,7 - 2,3 Nm]. On solenoids with screw terminals, the socket head screw holding the terminal block to the solenoid is the grounding screw. Torque the screw to 15 - 20 in-lbs [1,7 - 2,3 Nm] with a 5/32" hex key wrench.

#### • Junction Box

The junction box is used with spade or screw terminal solenoids only and is provided with a grounding screw and a 1/2" conduit connection. Connect #12-18 AWG standard copper wire only to the screw terminals. Within the junction box use field wire that is rated 90°C or greater for connections. For steam service use 105°C rated wire up to 50 psi or use 125°C rated wire above 50 psi. After electrical hookup, replace cover gasket, cover, and screws. Tighten screws evenly in a crisscross manner.

#### • DIN Plug Connector Kit No.K236-034

1. The open-frame solenoid is provided with DIN terminals to accommodate the plug connector kit.
2. Remove center screw from plug connector. Using a small screwdriver, pry terminal block from connector cover.
3. Use #12-18 AWG stranded copper wire rated at 90°C or greater for connections. Strip wire leads back approximately 1/4" for installation in socket terminals. The use of wire-end sleeves is also recommended for these socket terminals. Maximum length of wire-end sleeves to be approximately 1/4". Tinning of the ends of the lead wires is not recommended.
4. Thread wire through gland nut, gland gasket, washer, and connector cover.

NOTE: Connector housing may be rotated in 90° increments from position shown for alternate positioning of cable entry.

5. Check DIN connector terminal block for electrical markings. Then make electrical hookup to terminal block according to markings on it. Snap terminal block into connector cover and install center screw.
6. Position connector gasket on solenoid and install plug connector. Torque center screw to 5 ± 1 in-lbs [0,6 ± 1,1 Nm].

NOTE: Alternating current (AC) and direct current (DC) solenoids are built differently. To convert from one to the other, it may be necessary to change the complete solenoid including the core and solenoid base sub-assembly, not just the solenoid. Consult ASCO.

### Installation of Solenoid

Solenoids may be assembled as a complete unit. Tightening is accomplished by means of a hex flange at the base of the solenoid.

### Installation of Panel Mounted Solenoid (See Figure 1)

1. Disassemble solenoid following instruction under *Solenoid Replacement* then proceed.
2. Install solenoid base sub-assembly through customer panel.
3. Position spring washer on opposite side of panel over solenoid base sub-assembly.
4. Replace solenoid, nameplate/retainer and red cap.
5. Make electrical hookup, see *Wiring* section.

### Solenoid Temperature

Standard solenoids are designed for continuous duty service. When the solenoid is energized for a long period, the solenoid becomes hot and can be touched by hand only for an instant. This is a safe operating temperature.

## MAINTENANCE

**▲ WARNING:** To prevent the possibility of personal injury or property damage, turn off electrical power, depressurize solenoid operator and/or valve, and vent fluid to a safe area before servicing.

### Cleaning

All solenoid operators and valves should be cleaned periodically. The time between cleaning will vary depending on medium and service conditions. In general, if the voltage to the solenoid is correct, sluggish valve operation, excessive noise or leakage will indicate that cleaning is required. Clean strainer or filter when cleaning the valve.

### Preventive Maintenance

- Keep the medium flowing through the solenoid operator or valve as free from dirt and foreign material as possible.
- While in service, the solenoid operator or valve should be operated at least once a month to insure proper opening and closing.
- Depending on the medium and service conditions, periodic inspection of internal valve parts for damage or excessive wear is recommended. Thoroughly clean all parts. Replace any worn or damaged parts.

### Causes of Improper Operation

- **Faulty Control Circuit:** Check the electrical system by energizing the solenoid. A metallic *click* signifies that the solenoid is operating. Absence of the *click* indicates loss of power supply. Check for loose or blown fuses, open-circuited or grounded solenoid, broken lead wires or splice connections.
- **Burned-Out Solenoid:** Check for open-circuited solenoid. Replace if necessary. Check supply voltage; it must be the same as specified on nameplate/retainer and marked on the solenoid. Check ambient temperature and check that the core is not jammed.
- **Low Voltage:** Check voltage across the solenoid leads. Voltage must be at least 85% of rated voltage.

### Solenoid Replacement

1. Disconnect conduit, coil leads, and grounding wire.  
NOTE: Any optional parts attached to the old solenoid must be reinstalled on the new solenoid. For 3-way construction, piping or tubing must be removed from pipe adapter.
2. Disassemble solenoids with optional features as follows:

- **Spade or Screw Terminals**  
Remove terminal connections, grounding screw, grounding wire, and terminal block (screw terminal type only).

NOTE: For screw terminals, the socket head screw holding the terminal block serves as a grounding screw.

- **Junction Box**

Remove conduit and socket head screw (use 5/32" hex key wrench) from center of junction box. Disconnect junction box from solenoid.

- **DIN Plug Connector**

Remove center screw from DIN plug connector. Disconnect DIN plug connector from adapter. Remove socket head screw (use 5/32" hex key wrench), DIN terminal adapter, and gasket from solenoid.

3. Snap off red cap from top of solenoid base sub-assembly. For 3-way construction with pipe adapter (Figure 3), remove pipe adapter, nameplate and solenoid. Omit steps 4 and 5.
4. Push down on solenoid. Then using a suitable screwdriver, insert blade between solenoid and nameplate/retainer. Pry up slightly and push to remove.

NOTE: Series 8202G solenoids have a spacer between the nameplate/retainer and solenoid.

5. Remove solenoid from solenoid base sub-assembly.
6. Reassemble in reverse order of disassembly. Use exploded views for identification and placement of parts.
7. Torque pipe adapter to 90 inch-pounds maximum [10,2 Nm maximum]. Then make up piping or tubing to pipe adapter on solenoid.

### Disassembly and Reassembly of Solenoids

1. Remove solenoid, see *Solenoid Replacement*.
2. Remove spring washer from solenoid base sub-assembly. For 3-way construction, remove plugnut gasket.
3. Unscrew solenoid base sub-assembly from valve body.
4. Remove internal solenoid parts for cleaning or replacement. Use exploded views for identification and placement of parts.
5. If the solenoid is part of a valve, refer to basic valve installation and maintenance instructions for further disassembly.
6. Torque solenoid base sub-assembly and adapter to 175 ± 25 in-lbs [19,8 ± 2,8 Nm].

### ORDERING INFORMATION FOR ASCO SOLENOIDS

When Ordering Solenoids for ASCO Solenoid Operators or Valves, order the number stamped on the solenoid. Also specify voltage and frequency.



## Torque Chart

Part Name	Torque Value in Inch-Pounds	Torque Value in Newton-Meters
solenoid base sub-assembly/adapt- pipe adapter	175 ± 25	19,8 ± 2,8
pipe adapter	90 maximum	10,2 maximum




Figure 1. Series 8003G solenoids




Figure 2. Series 8202G solenoids




Figure 3. 3-Way Construction

## Torque Chart

Part Name	Torque Value In Inch-Pounds	Torque Value In Newton-Meters
terminal block screws	10 ± 2	1,1 ± 0,2
socket head screw	15 - 20	1,7 - 2,3
center screw	5 ± 1	0,6 ± 0,1




Figure 4. Open-frame solenoids




Figure 5. Junction box (optional feature)




Figure 6. DIN plug connector kit No. K236-034 (optional feature)

**GENERAL ELECTRIC  
OVERLOAD HEATERS**

**MAGNETIC STARTERS**

**NEMA SIZES 00, 0 AND 1**

Max. Motor Full-Load Amps	Heater Catalog Number
0.45	CR123C0.54A
0.49	CR123C0.60A
0.53	CR123C0.66A
0.59	CR123C0.71A
0.65	CR123C0.78A
0.76	CR123C0.87A
0.84	CR123C0.97A
0.93	CR123C1.09A
1.04	CR123C1.18A
1.15	CR123C1.31A
1.27	CR123C1.48A
1.39	CR123C1.63A
1.55	CR123C1.84A
1.73	CR123C1.96A
1.89	CR123C2.20A
2.05	CR123C2.39A
2.28	CR123C2.68A
2.47	CR123C3.07A
2.79	CR123C3.26A
3.31	CR123C3.56A
3.70	CR123C3.79A
4.05	CR123C4.19A
4.47	CR123C4.66A
4.95	CR123C5.26A
5.49	CR123C5.92A
5.91	CR123C6.30A
6.47	CR123C6.95A
7.20	CR123C7.78A
8.22	CR123C8.67A
8.72	CR123C9.55A
9.67	CR123C10.48
10.4	CR123C11.38
11.0	CR123C12.58
12.4	CR123C13.78
13.2	CR123C15.18
15.4	CR123C16.58
17.1	CR123C18.08
18.1	CR123C19.88
20.0	CR123C21.48
21.5	CR123C22.88
22.5	CR123C25.08
23.9	CR123C27.38
26.3	CR123C30.38
27.0	CR123C33.08

**CAUTION NOTE! MAKE SELECTION THIS TABLE ONLY!**  

$$\frac{\text{LTRA N.P. AMPS} + 1 \text{ AMP}}{\text{AMPS}} = \text{FULL LOAD}$$

**MANUAL STARTERS**

Maximum Motors Full-load Amp	Heater Cat. No. CR123
.48	H0.55A
.53	H0.61A
.58	H0.67A
.65	H0.74A
.71	H0.82A
.78	H0.90A
.86	H0.99A
.95	H1.08A
1.04	H1.20A
1.14	H1.32A
1.25	H1.44A
1.37	H1.58A
1.49	H1.72A
1.63	H1.86A
1.78	H2.05A
1.95	H2.24A
2.13	H2.45A
2.32	H2.67A
2.53	H2.91A
2.76	H3.17A
3.01	H3.46A
3.27	H3.77A
3.56	H4.10A
3.88	H4.46A
4.22	H4.86A
4.60	H5.29A
5.00	H5.75A
5.43	H6.25A
5.90	H6.80A
6.41	H7.39A
6.96	H8.02A
7.60	H8.73A
8.25	H9.50A
8.95	H10.38
9.75	H11.28
10.6	H12.28
11.4	H13.28
12.5	H14.48
13.6	H15.78
14.8	H17.18
16.0	H18.68

"MOTOR STARTER HEATER ELEMENT (COVER LOAD) SELECTION CHART"

7/12/12 11:22:00 AM

**NEMA SIZE 2**

Max. Motor Full-Load Amps	Heater Catalog Number
5.85	CR123C6.30A
6.47	CR123C6.95A
7.35	CR123C7.78A
8.06	CR123C8.67A
9.03	CR123C9.55A
9.61	CR123C10.48
10.5	CR123C11.38
11.6	CR123C12.58
12.5	CR123C13.78
13.6	CR123C15.18
16.7	CR123C16.38

12/20/18  
 10:50 CAUTION NOTE!  
 1/21/20  
 10:50 PLS S  
 5/19/18

- NOTE:**
- MOTOR W/SERVICE FACTOR HIGHER THAN 1.0:  
 If the full load current value shown on the motor nameplate is between the listed "Full Load Amps." select the "Heater Type No." with the higher value.
  - MOTORS W/1.0 SERVICE FACTOR:  
 Select the "Heater Type No." on



# GE Instructions

## NEMA Size 00, 0, & 1 — CR305, CR306, CR309 Magnetic Contactors, Starters, & Reversers

**Caution:** Before installing in a nuclear application, determine that the product is intended for such use.

**Warning:** Disconnect power before installing or servicing.

### Description

GE 300-Line full-voltage motor starters include a magnetic contactor and a three-leg block overload relay, providing motor protection against running and stalled motor overloads. The overload relay is provided with a yellow trip indicator located to the right of the reset arm, and is visible when the overload relay is tripped.




Figure 1. Typical 300-Line magnetic starter.

### Rated—600 V Maximum

Starter Maximum Current Rating	Contactor Maximum Current Rating	AC Volts	Maximum Hp For AC Motors	
			Single-phase	Poly-phase

#### Size 00

9 ampere (open and enclosed)	10 ampere (open) 9 ampere (enclosed)	115 200 230 460-575	1/2 — 1 —	— 1 1/2 1 1/2 2
------------------------------	---	------------------------------	--------------------	--------------------------

#### Size 0

18 ampere (open and enclosed)	20 ampere (open) 18 ampere (enclosed)	115 200 230 460-575	1 — 2 —	— 3 3 5
-------------------------------	--	------------------------------	------------------	------------------

#### Size 1

27 ampere (open and enclosed)	30 ampere (open) 27 ampere (enclosed)	115 200 230 460-575	2 — 3 —	— 7 1/2 7 1/2 10
-------------------------------	--	------------------------------	------------------	---------------------------

Motor branch circuit and control circuit overcurrent protection should be supplied in accordance with the National Electrical Code. CR305 contactors are suitable for use on a circuit capable of delivering not more than 5,000 RMS symmetrical amperes, 600 volts maximum when protected by H, J, K1, K5, RK1, RK5 class fuses, or a circuit breaker having an interrupting rating not less than 5,000 RMS symmetrical amperes.

### Installation

Before connecting controller to power supply:

1. Remove all packing.
2. Clean magnet mating surfaces of any dirt or foreign matter.
3. Select and install heaters in accordance with heater table.
4. Operate movable magnet and operating arm by pressing on the nameplate to assure free movement.
5. Mount on a sturdy vertical support.
6. Make the electrical connections

7. The starter overload relay may be reset manually by depressing and releasing the reset arm.

### Coil Replacement

1. Remove power from device.
2. Press against coil while putting up slightly on coil retainers (A-Figure 1) and move retainers away from coil.
3. Withdraw magnet assembly, coil, molded cover, and movable arm from device.
4. Withdraw spring clip (B-Figure 1) and remove armature from movable arm.
5. Remove coil from magnet.
6. Replace coil.
7. Reassemble device by reversing procedure.

### Contact Replacement

1. Perform steps 1 through 5 under *Coil Replacement*.
2. Remove magnet from molded cover and movable arm.
3. Remove return spring from center of movable arm.
4. Remove molded cover from movable arm.
5. Depress and slide movable contact and spring from movable arm.
6. Remove screws holding stationary contacts in place and remove stationary contacts.
7. Reassemble device by reversing procedure.

**Note:** For starters with one or more normally closed contacts, perform steps 1 and 2 shown under *Coil Replacement*. Withdraw spring clip (B-Figure 1) and remove armature, coil, and magnet from device. Remove return spring from center of movable arm. Remove molded cover and stationary contacts before lifting movable arm from device.




Figure 2.

### Normally Closed Contacts

The contacts may be converted from normally open to normally closed with no additional parts. Perform steps 1 through 4 shown under *Coil Replacement*. Lift coil and magnet from movable arm. Remove return spring from center of movable arm. Depress movable contact spring and spring seat against movable contact and rotate these parts 1/2 turn without removing them from window. Remove the stationary contacts. Install the movable arm in the device. Install the stationary contacts so that their silver pads face the movable contact silver pads.

Reassemble the device. To change contacts from normally closed to normally open position, reverse the above procedure.

### Check For Welded Contacts In Overload Relay

With power disconnected, disconnect the control wiring from the relay terminals. Place a bell set or resistance measuring instrument across the

Instructions For  
25, 30, 40, 50, & 60  
Full-load Ampere Forms



# Magnetic Contactors

## Definite Purpose CR353AB, AC, AD, FE, & FF Series

**Caution:** Before installing in a nuclear application, determine that the product is intended for such use.

**Warning:** Disconnect power before installing or servicing.

### Features

- Designed to control air conditioning and resistance heating loads.
- Universal mounting base allows easy replacement of other manufacturers devices.
- Molded, enclosed coil structures.
- UL recognized and CSA certified.

### Installation

1. Disconnect power from source.
2. Remove all packing material from the contactor.
3. If a control transformer is used, determine that the coil VA listed in the coil data table is compatible with the capacity of the control transformer.
4. Verify that the power pole ratings equal or exceed those of the contactor being replaced.
5. Assemble coil terminal tabs if needed (See Figure 2), 50 and 60 ampere forms only.
6. Mount the contactor on a vertical panel.
7. Make all electrical connections.

### Power Pole Ratings

Base Catalog Number Product Family	Volts AC	1-Phase, 2-Pole or 3-Phase, 3-Pole		Resistive Amperes Per Pole
		Full-load Amperes	Locked Rotor Amperes	
CR353AB—	240 480 600	25	150 125 100	35
CR353AC—	240 480 600	30	180 150 120	40
CR353AD—	240 480 600	40	240 200 160	50
CR353FE—	240 480 600	50	300 250 200	62
CR353FF—	240 480 600	60	360 300 240	75

### Coil Data; 25, 30, & 40 Full-load Amperes

Contactor	Coil Cat. No.	Volts	Hertz	Nominal Inrush VA.	Nominal Sealed VA.
CR353AB, AC, AD	SS-B20A	110/120	60	77	10
		50	87	12.5	
	SS-B20B	208/240	60	77	10
		50	87	12.5	
	SS-B20C	416/480	60	77	10
		50	87	12.5	
SS-B20F	277	60	77	10	
		50	87	12.5	
SS-B20H	24⓪	60	77	10	
		50	87	12.5	
SS-B19H	24⓪	60	60	7	
		50	68	7.4	

⓪ 4- or 5-pole forms only.

⓪ 2- or 3-pole forms only.

### Coil Data; 50 & 60 Full-load Amperes

Contactor	Coil Cat. No.	Volts	Hertz	Nominal Inrush VA.	Nominal Sealed VA.
CR353FE, FF	SS-B23A	110/120	60	100	11
		50	119	14	
	SS-B23B	208/240	60	100	11
		50	119	14	
	SS-B23C	416/480	60	100	11
		380/416	50	119	14
SS-B23F	277	60	100	11	
		50	90	11	
SS-B23H	24	60	90	11	
		50	107	14	

AUXILIARY CONTACT KIT INSTALLED





Figure 1. Typical CR353AD 40 FL ampere contactor.

COIL TERMINAL TABS INSTALLED



AUXILIARY CONTACT KIT INSTALLED

Figure 2. Typical CR353FE 50 FL ampere contactor

**UPDATED PARTS LIST FOR STERLCO PUMP**

**1 HP -- 3HP MOTORS**

**Please review the following information before ordering spare parts for your STERLCO pump and motor assembly. Please feel free to call Customer Service, at the number below, if you have any questions. Thank you.**

**Customer Service  
800-783-7835**

# REPLACING ROTARY SEAL ASSEMBLY ON STERLCO PUMP: 1 HP AND LARGER

## PARTS


M. Drip Cover  
N. Motor  
O. Motor Screws (4)  
P. Water Slinger  
Q. Bracket

R. Rotary Seal Assembly  
S. Impeller  
T. Lock Washer  
U. Impeller Nut  
V. Housing Gasket

W-A. Threaded Inlet  
W-B. Tank Inlet  
X-A. Pump Screws (8)  
X-B. Pump Screws-  
two long, six short

## TOOLS NEEDED:

Large Screwdriver  
3/8" Wrench or Socket  
5/8" Wrench or Socket  
1" Socket  
Detergent (household)



Parts List -- MP

STERLING, INC.  
PARTS LIST D - G  
STERLCO PUMP 1HP & 3HP

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
O	001.05915.00	Motor Screw, (4) required
P	542.10404.00	Water Slinger
Q	615.00001.00	Bracket ( <i>obsolete</i> - see attached)
S		Impeller-specify part number and diagram (see pump nameplate)
T	525.00001.00	Lock Washer
U	535.00001.00	Impeller Nut
V	545.00002.00	Housing Gasket
W-A	615.00003.00	Threaded Inlet Casting
W-B	615.00002.00	Tank Inlet Casting
X-A	001.05915.00	Pump Screw for pump w/threaded suction (8) required
X-B	001.05915.00	Pump Screw for pump w/tank suction (6) required
X-B	001.05923.00	Pump Screw for pump w/tank suction (2) required
N	720.09003.00	Motor 1HP 3/60/230-460v Open
N	720.09009.00	Motor 1HP 3/60/230-460v TEFC
N	720.09004.00	Motor 1-1/2HP 3/60/230-460v Open
N	720.09010.00	Motor 1-1/2HP 3/60/230-460v TEFC
N	720.09005.00	Motor 2HP 3/60/230-460v Open
N	720.09011.00	Motor 2HP 3/60/230-460v TEFC
N	720.09006.00	Motor 3HP 3/60/230-460v Open
N	720.09012.00	Motor 3HP 3/60/230-460v TEFC

M. Drip Cover

N. Motor

O. Motor Screws (4)

P. Water Slinger

Q. Bracket

R. Rotary Seal Assembly

S. Impeller

T. Lock Washer

U. Impeller Nut

V. Housing Gasket


W-A. Threaded Inlet

W-B. Tank Inlet


X-A. Pump Screws (8)

X-B. Pump Screws  
two long, six short

OLD



NEW



Item	Description	Old Part Number	New Part Number
O	Motor Screws	001.23358.00	001.23358.00
Q	Bracket	615.00001.00	615.00195.00
W-A	Threaded Inlet	615.00003.00	615.00210.00
X-A	Pump Screws	001.05914.00	001.05914.00
V	Housing Gasket	545.00002.00	545.00002.00

**Retrofit Kit for 7/8 MP/MJ Pumps:**

Part Number 682.84617.00 includes items: Q, W-A, X-A, and V (New Part Numbers)

MOTOR, IMPELLAR, SEAL ASSEMBLIES

695-00204-01	1/2	HP	3/60/208,230,460V	\$395.00
695-00215-01	3/4	HP	3/60/208,230,460V	441.00
695-00212-01	1	HP	3/60/208,230,460V	523.00
695-00213-01	1½	HP	3/60/208,230,460V	581.00
695-00211-01	2	HP	3/60/208,230,460V	600.00
695-00214-01	3	HP	3/60/208,230,460V	665.00

When ordering pump and motor complete, the above items are needed plus:

- (1) 615-00210-00 \$100.00 each
- (1) 545-00002-00 2.30 each
- (8) 001-05914-00 .75 each

Part Number 682-84617-00 Kit (\$188.00) Includes:

- (1) 615-00195.00 Bracket
- (1) 615-00210-00 Volute
- (1) 545-00002-00 Gasket
- (8) 001-05914-00 Pump Screws



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>