Cleaning

- Use a soft, dry, clean cloth. Regularly dust the vents at the back or sides.
- Using solvents, abrasive or alcohol-based products risks damaging the appliance
- If an object or liquid enters inside the appliance, unplug it immediately and have it checked by an authorised engineer

Handling and caring for discs



- Handle your discs with care. Hold the disc with your fingers at the edges or through the hole.
- Insert the disc with the label facing up (for a single-sided disc).
- Place the disc properly into the tray in the allotted holder.
- Use a soft cloth to clean discs if necessary, always wiping from the centre to the edge
- Always put discs back in their cases after use and store in a vertical position.
- Do not close the tray with two discs in it or with a disc not sitting correctly in the holder.
- Do not play cracked, chipped or warped discs nor try to repair them with adhesive tape
- Do not write on a disc
- Do not move the player when a disc is being played.
- Do not scratch discs or store them in places exposed to direct sunlight, high humidity or high temperatures.
- Do not use aerosol cleaners, benzene, anti-static liquids or any other solvent for cleaning discs. When cleaning, wipe gently with a soft damp (water only) cloth from the centre to the edge, avoiding circular motions, which could cause scratches and interference during playback.

Guarantee

- The type and production number of your appliance are printed on the guarantee certificate supplied with your appliance. Keep this certificate as well as the invoice. These documents are required in the event of claiming your guarantee rights.
- All repairs during the guarantee period must be carried out by an authorised engineer for our brand. If this condition is not met, your rights will no longer be valid.
- Never open the appliance yourself, since this may put you at risk or damage the equipment.THOMSON does not accept any liability if the appliance is used in any way other than in accordance with this manual.

DISCLAIMER OF WARRANTIES: TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, DECLARATIONS AND WARRANTIES OF NON-INFRINGEMENT OF COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHTS RESULTING FROM THE USE OF THE PRODUCT IN CONDITIONS OTHER THAN THOSE SPECIFIED ABOVE ARE HEREBY DISCLAIMED.

In spite of progress made to ensure playability of all discs types, it is not possible to guarantee playback of discs which are not in conformity with DVD, CD, VCD or SVCD standards. This unit may not play some recordings or files on CD-R, CD-RW, DVD-R, DVD-RW, DVD+R, DVD+RW due to differences in recording formats, software used and disc types.



DVD-Video

Digital video discs - 12 cm and 8 cm, single or double sided, single or dual layer. DVDs are nigh-density optical discs on which high quality picture and audio are recorded by means of digital signals



Most DVD-R and DVD+R (one recording only), DVD-RW and DVD+RW discs (rewritable). Depending on the DVD writer and discs used. Recordings using DVD-R and DVD-RW discs must be made in Video DVD mode. Recordings using DVD+RW discs must be made in accordance with the specifications for DVD+RW discs with a 4.7 GB capacity.



VCD - Video Compact Disc

SVCD - Super Video Compact Disc

DVD-R, DVD-RW, DVD+R, DVD+RW

CD on which you can record up to 74 min. of VHS-quality video associated with still images, udio tracks and interactive menus.

Most SVCDs comply with the IEC62107 standard. SVCDs can be used to record up to 70 minutes

of digital sound and images in accordance with MPEG-2 standards for video and MPEG-I



standards for audio.

Audio CDs Audio CDs (8 and 12 cm)



CD-R, CD-RW

Most CD-R (one recording only) and CD-RW discs (rewritable).

This player can play most CD-R discs. CD-Rs written during a multisession recording can also be played, provided that the session has ended before the disc is played (depending on the write software). However, depending on the condition of the CD-writer, computer and the disc used, you may find that not all discs will play successfully. When playing a CD-R disc, it is completely normal for the unit to take up to 20 seconds to recognise the disc before starting to play. If the disc is not recognised after a period of 20 seconds, remove the disc, and then insert it again. • Irrespective of the actual recording capacity of the CD-R, do not use its full capacity. • CD-Rs should be preferably used instead of CD-RWs (rewritable CDs) as, in certain cases, CD-RW playback may be faulty. • Use reliable, good-quality CD write software. • Close all other applications on the computer to ensure reliable CD-R disc recording.





DivX is the name of a revolutionary new video codec which is based on the new MPEG - 4 compression standard for video. Whether DivX files play correctly on your player or not depends on the preparation and production of the audio and video files, the codecs and the type of recording equipment used, as well as on your computer's parameters. It is therefore possible that you cannot play a DivX file or that part or all of it is defective. It also sometimes happens that you can play the images (video) but not the sound (audio). DivX disc compatibility with this play er is limited as follows: The maximum resolution of the DivX file is below 720x576 (W x H) pixels • DivX filenames should not exceed 56 characters. • If the video and audio structure of the recorded file is not interleaved, either video or audio is outputted. • If the file is recorded with GMC, the unit supports only I-point GMC. GMC is the acronym for Global Motion Compensation. It is an encoding tool specified in the MPEG4 standard. Some MPEG4 encoders, like DivX or XviD, have this option. There are different levels of GMC encoding, usually called I - point, 2 - point, or 3 - point GMC. • DivX files with subtitles in . SRT, $% \left(1\right) =\left(1\right) +\left(1\right) +\left$ of all languages may not be possible as some characters may be missing.



CD-R and CD-RW discs containing audio files in mp3 format. With regard to CD-R mp3 discs, please follow all the recommendations for CD-R above, along with the comments below:

• Your mp3 files should be ISO 9660 or IOLIET format, ISO 9660 format and Joliet mp3 files are compatible with Microsoft DOS and Windows, as well as with Apple Mac. These two formats are the most widely used. • mp3 filenames should not exceed 8 characters and should end with the ".mp3" extension. General name format: Title.mp3. When composing your title ensure that you use 8 characters or less, have no spaces in the name, and avoid the use of special characters including (.../...) = .+). • The total number of files on a disc should be less than 999. The total number of folders should be less than 499 • Use a decompression transfer rate of at least 128. kB/sec (kilobytes/second) when recording mp3 files. Sound quality with mp3 files basically depends on the rate of compression/ decompression you choose. Obtaining audio CD quality sound requires an analogue/digital sampling rate, that is conversion to mp3 format, of at least 128 kB/sec and up to 160 kB/sec. Choosing higher rates, such as 192 kB/sec or more, only rarely produces even better sound quality. Conversely, files with sampling rates below 128 kB/sec will not play properly. • Do not try recording copyright-protected mp3 files. "Securized" files are encrypted and code-protected to prevent illegal copying. You must not copy such files.



WMA (Windows Media Audio) files

CD-R with WMA files

• WMA filenames should not exceed 8 characters, and should end with the ".wma" extension. General name format: Title.wma. When composing your title ensure that you use 8 characters or less, have no spaces in the name, and avoid the use of special characters including (,,/,,=,+). •The total number of files

Windows Media and the Windows logo are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Important:The above recommendations cannot be taken as a guarantee that the DVD player will play mp3 or WMA recordings, or as an assurance of sound quality. You should note that certain technologies ar methods for mp3 file recording on CD-Rs prevent optimal playback of these files on your DVD player (i.e. degraded sound quality and even in some cases, inability of the blaver to read the file)

DVD copy protection

In accordance with the DVD standard, your DVD player is equipped with a Copy Protection system, which can be switched on and off by the DVD disc itself, in order to make any recording of the relevant DVD disc onto a videotape of very poor picture quality, or even impossible. "This product incorporates copyright protectio technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home use only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Note on DivX files

Before playing DivX or mpeg4 files, please be sure of their origin and that you have legally purchased or rented the contents. Pirate copying is illegal and may result in sanctions. Private copies of your own material for your own use may be legal in some countries. Make sure you are aware of any applicable laws.

Technical data

Power requirements: AC 220-240V, 50/60Hz

Power consumption: I5W Operating temperature:

5°C to 35°C (41°F to 95°F)


5 % to 90 % (no condensation)

Operating humidity:

THOMSON Multimedia Sales Europe 46, quai A. Le Gallo 92648 Boulogne Cedex

> 322 019 464 RCS NANTERRE http://www.thomson-europe.com


(€ 🛞 35905170 ©Copyright THOMSON 2005



Some points to check before you connect your TV set

- Ensure that the mains supply in your house complies with that indicated on the identification sticker located on the back of your appliance.
- Install your appliance horizontally, away from any source of heat (fireplace) or appliances generating strong magnetic or electric fields. The components of this appliance are sensitive to heat.The maximum ambient temperature should not exceed 35° Celsius.
- Leave sufficient space around the appliance to allow adequate ventilation: 10 cm on either side and at the back, as well as 7 cm above it are ideal.
- The humidity of the room should not exceed 75%. If you have to use the appliance outdoors, do not expose it to rain or splashing water. The appliance should not be exposed to dripping or splashing and no objects filled with liquids, such as vases, should not be placed on top of it.
- Moving it from a cold environment to a warm one is likely to cause condensation on some components inside the appliance. Let the condensation disappear of its own accord before turning the appliance on again.
- Before moving the player, make sure the disc tray is empty.

The remote control



Inserting batteries in the remote control

Insert two R03 or AAA batteries in the remote control.

- Do not mix different types of batteries or new and old batteries. Do not use rechargeable batteries
- In order to avoid any risk of explosion, observe the polarities indicated inside the battery compartment.
 Replace only with the type of batteries specified above. Do not dispose of them in a fire or recharge them
- If you are not using the remote control for a long period of time, remove the batteries.

Please respect the environment and prevailing regulations. Before you dispose of batteries or accumulators, ask your dealer whether they are subject to special recycling and if they will accept them for disposal.



In accordance with the rating plate of the unit, this unit complies with current standards concerning electrical safety and electromagnetic compatibility.



CAUTIONRISK OF ELECTRIC SHOCK - DO

NOT OPEN

FN CAUTION

- LASER RADIATION WHEN OPEN DO NOT STARF INTO BEAM.





CAUTION: TO REDUCE THE RISK OF THE LIGHTNING FLASH AND CTRIC SHOCK, DO NOT REMOVE THE ARROWHEAD WITHIN THE TRIANGLE COVER (OR BACK). NO USER-SERVICEABLE IS A WARNING SIGN ALERTING YOU VICE PERSONNEL OF A DANGEROUS VOLTAGE INSIDE



THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN PARTS INSIDE, REFER SERVICING TO QUALIFIED | ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE

SEE MARKING ON BOTTOM / BACK OF PRODUCT



THE PRODUCT.

This THOMSON product is designed and manufactured with high quality materials and components which can be recycled and reused. This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste.



Please, dispose of this equipment at your local community waste collection/recycling centre.

In the European Union there are separate collection systems for used electrical and electronic product.

Please, help us to conserve the environment we live in

Front panel controls



STANDBY/ON - To switch the appliance on and off.

OPEN/CLOSE - To open and close the disc tray

STOP - To stop disc playback. PLAY - To start playing a disc.

I◄◄/▶►ISKIP BACKWARD/FORWARD - To skip for a chapter or track.

VOL1,2 (MIC LEVEL) - To adjust the mic sound.

Basic connections (DVD player + TV + video recorder)

- 1. Connect the DVD player Scart socket (TV AUDIO VIDEO OUT) to the television set's Scart socket (AVI, EXTI, AUXI) using a Scart lead (not provided).
- 1. If your television set does not have two Scart sockets, connect the DVD player to the video recorder's AV2 socket using a Scart lead (not provided). If you have a satellite or cable receiver you can also connect the DVD player to the receiver's second Scart socket. Note: If your video recorder only has one Scart socket, but has a modulator, use the aerial cable to connect the video recorder to the television set, adjust the video recorder's modulator, then connect the DVD player to the video recorder's Scart socket.
- 2. Connect the video recorder (or satellite receiver) to the television set as shown in the video recorder's (or satellite receiver's) user guide.
- 3. Connect the DVD player to the mains socket using the mains lead
- 4. Switch on the devices.

Note: If one of the devices is not working, check that all the cables have been inserted properly into the sockets which they should be connected to.

Other connection options

VIDEO OUT socket

This socket (yellow) is also known as a composite video socket. The video cable (not supplied) usually comes with two audio cables (white and red). The picture quality obtained using a video connection is poorer compared to that obtained using a Scart connection.

AUDIO L (left) and AUDIO R (right) sockets

These are analogue audio output sockets. The AUDIO L socket and cable are white, while the AUDIO R socket and cable are red. Connect the DVD player's AUDIO L and R sockets to the television set's AUDIO L and R sockets using audio cables (not supplied).

Note: If your television set only has one audio socket connect it to the DVD player's left socket (white).

If the TV set is equipped with S-Video, connecting this signal will provide a better picture than Video (composite)

FRANCE

Component output (Y. Pr. Pb. / Y. Cr. Cb)

YPrPb sockets deliver an optimum image quality due to the separation of the video signal into three separate components (comparable with RGB separation in a Scart-Peritel cable). Note: the video signal available from these 3 sockets depends on the choice made in the Video Out menu

In order to obtain the best possible image quality, always use very high quality cables for the connections. Your dealer can provide Y, Pr, Pb cables that are sold together and come in the standard colour codes (red, green and blue) used for these types of sockets and cables.

Note: do not forget to also connect the audio cables, because Component cables only transmit images, and not sound.

Optical and coaxial Out sockets

The digital sound from a Video DVD in playback is permanently available at the optical and coaxial sockets on your player. Use one of these sockets by connecting it to a decoder or a DTS or Dolby Digital amplifier. Some of these appliances are equipped with a coaxial In socket (COAXIAL) or an optical In socket (OPTICAL), while others are equipped with both sockets. Choose one of the two connections.

Note: In most cases these two types of connection give similar results; the only difference lies in the type of cable used and the cost of these cables, the coaxial cable being the least expensive one to buy. However it sometimes happens that some coaxial cables are parasitised by high frequency interference caused by household electrical appliances, high voltage electric cables or radio transmitters.

Note: when connecting the obtical audio digital cable:

Remove the protection cap from the connector and connect it firmly as shown on the drawing.
 Keep the protection cap and always reattach the cap when the connector is not in use, to keep it dustfree.

Basic Playback Operations

Regional coding

Your DVD player has been designed to process regional management information that is stored on DVD discs. DVD discs that have different regional codes to that of your player cannot be played. The regional code for your player is 2 (Europe, the Middle East, South Africa, Japan). ALL means all regions. When you buy a disc check that it bears the correct logo.

Operating the DVD player

- Switch on your TV set.
- 2. Press the (1) button on the remote control or the STANDBY/ON button located on the DVD player's front panel.

Playback

- 1. Press the OPEN/CLOSE button on the front of the appliance or on the remote control to open the disc tray
- 2. Put the disc in with the printed side upwards (in the case of a single-sided disc).
- 3. Press OPEN/CLOSE button again to close the disc tray. Play starts automatically, If a menu appears, one of its options can be selected to start playing the disc. Select it and press **ENTER**
- **4.** Press **STOP** button to stop playback.

Notes: The player stores the point where playback was interrupted. If you press PLAY button again, playback resumes from this point. To stop playback completely or to start again from the beginning, press **STOP** button twice. If the player is left in STOP mode for more than one minute without any user inter action, a screen saver is activated.

Accelerated play

While the disc is playing, press the **REV** or **FWD** button one or more times to vary the speed and direction of the accelerated play.

Still image

While the disc is playing, press PAUSE/STEP once for freeze frame.

Note: After five minutes in PAUSE with no user interaction, the player goes into screen saver mode.

Frame advance (DVD and VCD only)

- I. While the disc is playing, press PAUSE/STEP once.
- 2. Press the PAUSE/STEP button a number of times to advance forward image by image. 3. Press PLAY button to resume normal playback

Variable slow motion (DVD and VCD only)

- I. While the disc is playing, press **SLOW** button.
- 2. Press the **SLOW** button repeatly to change slow speed.
- 3. Press PLAY button to resume normal playback.

Changing chapter/track

While the disc is playing, press the **SKIP** \Longrightarrow or **SKIP** \Longrightarrow button to go immediately to the next or previous chapter, or to the next or previous track.

Or enter the track number with the number buttons.

Zoom (DVD, VCD and JPEG)

- 1. While a disc is playing, press the **ZOOM** button until you reach the zoom size you require.
- **2.** Move from one area to another using the \blacktriangleleft , \blacktriangleright , \blacktriangle and \blacktriangledown buttons.

Note: Under Zoom function for JPEG file, press ZOOM button goes to Zoom x I mode, then Press the REV or FWD button a number of times to vary the Zoom steps which you want, then press ZOOM to quit Zoom mode

Play modes

Repeat playback

While the disc is playing, press the **REPEAT** button repeatedly to select a play mode. DVD: Repeat Chapter, Repeat Title, Repeat Off;

VCD and audio CD: Repeat Track, Repeat All, Repeat Off;

A-B repeat

2

To repeat a sequence between two points A and B, press the **A-B** button at the beginning of the sequence you want to repeat. Then press the A-B button again at the end of the sequence-Then the sequence is played repeatedly until you press A-B to resume normal playback

Programme playback (DVD, VCD and audio CD)

With this option, you choose and programme the playback order. You can store up to 20 tracks. I. Insert a disc

- 2. In playing and stop mode, press the PROGRAM button. The Program menu appears.
- 3. Use the number buttons to enter the title number and then the chapter number (for DVD) or the track number (for VCD and Audio CD).

- 4. Use CURSOR button moving to the next input. Repeat step 3 until programming is
- 5. Highlight the "Start" icon, press ENTER button to start the program play
- 6. Press the STOP button to stop the programme playback. Press the OPEN/CLOSE button to cancel the programme playback.

SHUFFLE playback

You can play all the tracks on the disc in a shuffle order (chosen by the player).

L. Insert a disc

- 2. Press the SHUFFLE button during playback."SHUFFLE" appears. Once all tracks have been played, the player automatically stops playback.
- 3. Press the SHUFFLE button again to stop random playback.

Advanced functions

Audio (DVD, VCD and audio CD)

Some discs have several audio tracks used for different languages or different audio formats. To change the language or audio format during play, press the $\boldsymbol{\mathsf{AUDIO}}$ button one or more times to select one of the available audio formats or languages.

Note: This option is only available if the disc offers a number of dialogue languages or audio formats.

Status menu

Press the **OSD** button, a number of times during playback to show in turn:

DVD:Title elapsed time, Title remaining time, number of title, number of Chapter, Chapter elapsed time and Chapter remaining time.

VCD and audio **CD**: Single elapsed time, Single remaining time, Total elapsed time and Total remaining time.

PBC (VCD)

The PlayBack Control function offers scenes and information which can be selected interactively via a menu. It can also be used to display high-resolution pictures, if the disc contains any.

Press the TITLE button to access the PBC menu and the MENU button to turn the PBC function on and off

GOTO a desired section

Press the GOTO button to play ata desired title, chapter or time

DVD disc

I. Press the GOTO button to select GOTO mode.

2. Press the **DOWN** button highlight desired item and then press ENTER button.

TITLE: Input title number

CHAPTER: Input chapter number

AUDIO: select audio channel SUBTITLE: select subtitle

ANGLE : select angel

CHTIME: input chapter time

REPEAT: select repeat mode

TIME DISP.: select time display mode.

TTTIME: Input time h:mm:ss

3. Press ENTER button.

CD disc

I. Press the GOTO button repeatedly to enter different GOTO modes.

Disc Go To :--:-- Input desired time of the disc

Track Go To :--:- Input desired time of the track

Select Track :-- Input desired track number 2 Press ENTER button

Playback of mp3,WMA, JPEG and DivX files

mp3 is an audio file format which compresses recorded music. It was developed in collaboration with **THOMSON**. The main advantage of the mp3 format is that it means CDquality music tracks can be stored on a personal computer in user-friendly compressed files. Your player is an Official DivX Certified[™] product that plays DivX[®] 5, DivX[®] 4, DivX[®] 3, and DivX® VOD video content, in compliance with DivX Certified™ technical requirements.

Playing mp3, WMA or DivX files

Before inserting a disc, check that it is compatible with the player.

- I. Open the tray by pressing the OPEN/CLOSE buttor
- 2. Place the disc with the printed side facing up and close the tray. The disc's contents are displayed.
- 3. Select a folder using the ▲ and ▼ buttons on the remote control, then press ENTER button to see the folder's contents.
- 4. Press the STOP button to stop playback.
- 5. To go back to the folder list, press the ◀ button in stop mode.

Note: During playback you can use the SKIP ■ or SKIP ▶ button to go back to the previous file or go on Repeat playback

While the disc is playing, press the **REPEAT** button repeatedly to select a play mode: $\mbox{\bf mp3}$ and $\mbox{\bf WMA}$: Repeat One, Repeat Folder, Folder (=Off).

Karaoke connection

Complete the video and audio connections referring to this manual.

NOTE Karaoke do NOT function through Digital Audio outputs. Connect the L,R or 5.1 channel decoded output for karaoke.

- Connect microphones to the MIC jack I and/or 2 on the front panel.
- Turn the MIC LEVEL switch I and 2 anti-clockwise to the lowest level.
- Power on the unit and play a Karaoke disc.
- Switch on the microphone

- Turn the MIC LEVEL switches I and/or 2 clockwise, slowly to a suitable level.
- Press AUDIO button to select the disc Karaoke channel (depends on disc design)


NOTE

- Do not hold the microphones too close nor direction toward the loud speakers. otherwise, howling may occur.
- If howling still occurs, turn the MIC LEVEL anti-clockwise

Player menus

Using the player's menus

Press the **SET UP** button to display the player's main menu. Select a menu icon (



the \blacktriangle and \blacktriangledown buttons. Press the \blacktriangleright button to access the submenu and use the \blacktriangle and \blacktriangledown buttons to select an option Then press ENTER button, to confirm your selection Return to a previous menu using the **d** button. To exit from the player menus, press the **SET UP**

The General Setup menu

TV Display

Depending on the format of the DVD disc, you can choose the picture format best suited to the format of your TV screen

Select a format using the ▲ and ▼ buttons and press ENTER button to confirm:

Normal/PS: reproduces a 4:3 picture without distortion, Normal/LB: gives best reproduction of pictures recorded in this format (i.e. with horizontal bands at the top and bottom of the screen) or in 16:9.

reproduces 16:9 format films in full on a 16:9 screen.

Widescreen: Menu Language

To change the language of the player menus, choose the language using the ▲ and ▼ buttons and press **ENTER** button to confirm.

When the player is stopped during DVD/VCD playback, the player will memorize the last scene of the playback. When the disc is loaded again, playback will continue from the last scene.

ON: Activate the last memory function

OFF: Deactivate the last memory function. Note:This function will not be activated if the playback is stopped by pressing STOP button twice

To rent (purchase) DivX® VOD files

DivX VOD files are downloaded after paying a rental from certain commercial websites. Prior to downloading a VOD you need to input the registration number of your DVD player on the purchase form on the site.

Follow the instructions below to find the registration number of your player: insert a disc and press the SET UP button and then the ZOOM button. Write down this VOD 8-character registration number so that you can fill in the form on the website you purchase your DivX

Note: If you cannot play a DivXVOD file recorded on a CD-R disc after downloading it, the rental period allocated during purchasing from the website may have expired. It is also possible that the recorded file is not compatible with your player because of different versions or incorrect download parameters. The parameters used when copying to CD-R may be another reason for this. Since it is not possible here to supply all the information, parameters and advice relating to the use of DivX VOD files, we recommend that you visit specialist websites such as www.divx.com/vod.

The Audio Setup menu



Note: Dolby and the double-D symbol are trademarks of Dolby Laboratories. Manufactured under license from Dolby Laboratories.

You can use this function to control the different sound levels via dynamic compression. It improves the quality of the sound track at a low volume and quietens the loudest sounds. Select an option using the ▲ and ▼ buttons, and press **ENTER** button to confirm.

Note:This function is available only on DVD discs recorded in Dolby Digital.

available whatever selection has been made

The Video Setup menu

Choose the type of video signal that the TV or monitor connected to the back of your player will accept

RGB: this gives the best quality picture output from the TV AUDIO VIDEO OUT SCART socket.

YUV Interlace: used when a YCrCb monitor is connected to the 3 component video sockets. YUV Progress.: used when a YPrPb monitor is connected to the 3 component video sockets. Note: the composite (CVBS) video signal output from the TV AUDIO VIDEO OUT SCART socket remains

The Preferences Setup menu

Note:The Preferences Setup menu is only available at stop mode.

TV Type

In addition to PAL DVDs and VCDs, you can enjoy NTSC films as well (a 50Hz or 60Hz PAL compatible TV set is required). If the pictures from the DVD being played appear in black and white on your screen, try changing the colour standard

Set the function to PAL or NTSC and press ENTER button to confirm.

To change the dialogue language, choose the language using the $\, extstyle \, extstyle \,$ and $\, extstyle \,$ buttons and press ENTER button to confirm

To change the subtitle language, choose the language using the ▲ and ▼ buttons and press **ENTER** button to confirm

To change the language of the disc menus, choose the language using the ▲ and ▼ buttons and press ENTER button to confirm

Playback of some DVDs can be limited according to pre-determined level

(KID SAFE/G/PG/PG 13/PGR/R/NC 17/ADULT).

I. In the Preference Setup menu, highlight the PARENTAL selection and press ENTER button. 2. Highlight the desired settings and press **ENTER** button to confirm.

3. Enter the 4- digits password and press ENTER button to confirm.

4 Press SETUP button to save the setting and quit

The Password Setup Menu

This option allows you to set or change the password.

I Press ENTER to enter the Change Password menu

2.To change the password, enter the current four-digit password in the "Old Password" box. Then enter the new password in the "New Password" box. You are then prompte to enter it again in the "Confirm Password" box to confirm and press OK.

• Press the U button on the remote control or the **STANDBY/ON** button on the front

Additional Information

Troubleshooting

The appliance does not switch on. Make sure it is plugged into a mains socket.

It is impossible to read the disc.

• Insert the disc with the printed side facing up. • Check that the disc can actually be played by this device (see below). • Check that the disc's regional code matches the player's regional code. This player's

regional code is 2.

Clean the disc (see below).

of the appliance.

There is no picture.
• Check you have switched on the TV set.

• Check the connections.

• Select the AV input assigned to the player on the TV.

• Check the connection

There is no sound or the sound is of poor quality. • Check the connections.

The picture is of poor quality (with snow or lines).

Turn on the audio equipment connected to the player, if any.

The remote control does not work or works only intermittently.

 Check that batteries are inserted or change them. • Aim the remote control at the appliance. The infrared beam must not be blocked or

The subtitles do not appear.

• Check that the DVD disc provides subtitles.

• Refer to the section on how to display subtitles The disc menu language is not the correct one. • The disc menu language has not been set up.

• If you forget your own password, enter "9999" to reset.

• The language of your choice is not available on the disc. Forget Password

• If your appliance has been stored in a cool place for any length of time, during a journey

for example, wait for about 2 hours before using it. • The openings located on the top and bottom are for ventilation and must not be obstructed.

• During thunderstorms, we recommend that you isolate the appliance from the electrical supply so that it is not damaged by electrical or electromagnetic surges. • This appliance is designed for continuous use. Switching off the DVD player to stand-by mode

plug from the mains socket as some components remain connected to the electrical supply. • If you notice any burning or smoke, disconnect the appliance immediately to avoid any risk

does not disconnect it from the mains supply. To completely isolate the equipment, remove the

• Do not attempt to look inside the appliance through the disk tray opening or any other opening. You may be electrocuted or exposed to laser radiation

• This appliance is for domestic use only and must not be used for industrial purposes.

• Total or partial copying of recordings protected by copyright legislation, without the explicit permission of the holder of the rights, contravenes current legislation. Copying or downloading music files for sale or any other business purpose constitutes or could constitute a violation of copyright law.

3

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com