
- The openings located on the top and bottom are for ventilation and must not be obstructed.
- · During thunderstorms, we recommend that you isolate the appliance from the electrical supply so that it is not damaged by electrical or electromagnetic surges.
- This appliance is designed for continuous use. Switching off the DVD player to stand-by mode does not disconnect it from the mains supply. To completely isolate the equipment, remove the
- plug from the mains socket as some components remain connected to the electrical supply. • If you notice any burning or smoke, disconnect the appliance immediately to avoid any risk
- of electrocution. • Do not attempt to look inside the appliance through the disk tray opening or any other
- opening. You may be electrocuted or exposed to laser radiation This appliance is for domestic use only and must not be used for industrial purposes.
- Total or partial copying of recordings protected by copyright legislation, without the explicit permission of the holder of the rights, contravenes current legislation. Copying or downloading music files for sale or any other business purpose constitutes or could constitute a violation of copyright law.

Cleaning

- Use a soft, dry, clean cloth. Regularly dust the vents at the back or sides.
- Using solvents, abrasive or alcohol-based products risks damaging the appliance. • If an object or liquid enters inside the appliance, unplug it immediately and have it checked
- by an authorised engineer.

Handling and caring for discs



- Handle your discs with care. Hold the disc with your fingers at the edges or through the hole.
- Insert the disc with the label facing up (for a single-sided disc).
- Place the disc properly into the tray in the allotted holder.
- Use a soft cloth to clean discs if necessary always wiping from the centre to the edge.
- · Always put discs back in their cases after use and store in a vertical position
- · Do not close the tray with two discs in it or with a disc not sitting correctly in the holder.
- · Do not play cracked, chipped or warped discs nor try to repair them with adhesive tape or glue.
- Do not write on a disc.
- Do not move the player when a disc is being played.
- Do not scratch discs or store them in places exposed to direct sunlight, high humidity or high temperatures.
- · Do not use aerosol cleaners, benzene, anti-static liquids or any other solvent for cleaning discs. When cleaning, wipe gently with a soft damp (water only) cloth from the centre to the edge, avoiding circular motions, which could cause scratches and interference during playback.

Guarantee

- · The type and production number of your appliance are printed on the guarantee certificate supplied with your appliance. Keep this certificate as well as the invoice. These documents are required in the event of claiming your guarantee rights.
- · All repairs during the guarantee period must be carried out by an authorised engineer for our brand. If this condition is not met, your rights will no longer be valid.
- · Never open the appliance yourself, since this may put you at risk or damage the equipment. THOMSON does not accept any liability if the appliance is used in any way other than in accordance with this manual.

DISCLAIMER OF WARRANTIES: TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, DECLARATIONS AND WARRANTIES OF NON-INFRINGEMENT OF COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHTS RESULTING FROM THE USE OF THE PRODUCT IN CONDITIONS OTHER THAN THOSE SPECIFIED ABOVE ARE HEREBY DISCLAIMED.

Discs you can play

In spite of progress made to ensure playability of all discs types, it is not possible to guarantee playback of discs which are not in conformity with DVD, CD, VCD or SVCD standards. This unit may not play some recordings or files on CD-R, CD-RW, DVD-R, DVD-RW, DVD+R, DVD+RW due to differences in recording formats, software used and disc types.

DVD-Video

สม

Digital video discs - 12 cm and 8 cm, single or double sided, single or dual layer: DVDs are highdensity optical discs on which high quality picture and audio are recorded by means of digital signals.

DVD-R. DVD-RW. DVD+R. DVD+RW DVD

Most DVD-R and DVD+R (one recording only), DVD-RW and DVD+RW discs (rewritable). Depending on the DVD writer and discs used. Recordings using DVD-R and DVD-RW discs must be made in Video DVD mode. Recordings using DVD+RW discs must be made in accordance with the specifications for DVD+RW discs with a 4.7 GB capacity.

VCD - Video Compact Disc <u>/</u> VIDEO CD

CD on which you can record up to 74 min. of VHS-quality video associated with still images, audio tracks and interactive menus

SVCD - Super Video Compact Disc

Most SVCDs comply with the IEC62107 standard. SVCDs can be used to record up to 70 minutes of digital sound and images in accordance with MPEG-2 standards for video and MPEG-1 standards for audio.



CD-R. CD-RW Most CD-R (one recording only) and CD-RW discs (rewritable).

This player can play most CD-R discs. CD-Rs written during a multisession recording can also be played, provided that the session has ended before the disc is played (depending on the write software). However, depending on the condition of the CD-writer, computer and the disc used, you may find that not all discs will play successfully. When playing a CD-R disc, it is completely normal for the unit to take up to 20 seconds to recognise the disc before starting to play. If the disc is not recognised after a period of 20 seconds, remove the disc, and then insert it again.

· Irrespective of the actual recording capacity of the CD-R, do not use its full capacity. • CD-Rs should be preferably used instead of CD-RWs (rewritable CDs) as, in certain cases, CD-RW

playback may be faulty. • Use reliable, good-quality CD write software, • Close all other applications on the computer to ensure reliable CD-R disc recording.

DivX DivX files

DivX is the name of a revolutionary new video codec which is based on the new MPEG-4 compression standard for video. Whether DivX files play correctly on your player or not

depends on the preparation and production of the audio and video files, the codecs and the type of recording equipment used, as well as on your computer's parameters. It is therefore possible that you cannot play a DivX file or that part or all of it is defective. It also sometimes happens that you can play the images (video) but not the sound (audio). DivX disc compatibility with this player is limited as follows: • The maximum resolution of the DivX file is below 720x576 (W x H) pixels. • DivX filenames should not exceed 56 characters. . If the video and audio structure of the recorded file is not interleaved, either video or audio is outputted. • If the file is recorded with GMC, the unit supports only 1-point GMC. GMC is the acronym for Global Motion Compensation. It is an encoding tool specified in the MPEG4 standard. Some MPEG4 encoders, like DivX or XviD, have this option. There are different levels of GMC encoding, usually called 1-point, 2-point, or 3-point GMC. • DivX files with subtitles in .SRT, SUB and .SMI formats can be played. Correct playback of all

languages may not be possible as some characters may be missing.

mp3 mp3 files

CD-R and CD-RW discs containing audio files in mp3 format. With regard to CD-R mp3 discs, please follow all the recommendations for CD-R above, along with the comments below: • Your mp3 files should be ISO 9660 or [OLIET format. ISO 9660 format and Joliet mp3 files are compatible with Microsoft DOS and Windows, as well as with Apple Mac. These two formats are the most widely used. • mp3 filenames should not exceed 8 characters and should end with the ".mp3" extension. General name format: Title.mp3. When composing your title ensure that you use 8 characters or less, have no spaces in the name, and avoid the use of special characters including (, , / , \ , = ,+). \bullet The total number of files on a disc should be less than 999. The total number of folders should be less than 499. • Use a decompression transfer rate of at least 128 kB/sec (kilobytes/second) when recording mp3 files. Sound quality with mp3 files basically depends on the rate of compression/ decompression you choose. Obtaining audio CD quality sound requires an analogue/digital sampling rate, that is conversion to mp3 format, of at least 128 kB/sec and up to 160 kB/sec. Choosing higher rates, such as 192 kB/sec or more, only rarely produces even better sound quality. Conversely, files with sampling rates below 128 kB/sec will not play properly. • Do not try recording copyright-protected mp3 files. "Securized" files are encrypted and code-protected to prevent illegal copying. You must not copy such files.

WMA (Windows Media Audio) files Plays 💦

CD-R with WMA files. Windows Media™

 WMA filenames should not exceed 8 characters, and should end with the ".wma" extension. General name format: Title.wma. When composing your title ensure that you use 8 characters or less, have no spaces in the name, and avoid the use of special characters including (., /, \, =, +). The total number of files on a disc should be less than 999.

Important: The above recommendations cannot be taken as a guarantee that the DVD player will play mp3 or WMA recordings, or as an assurance of sound quality. You should note that certain tec and methods for mp3 file recording on CD-Rs prevent optimal playback of these files on your DVD player (i.e. degraded sound quality and even, in some cases, inability of the player to read the file).

PIGITAL JPEG files

• CD-R and CD-RW with JPEG files. Certain JPEG files, including progressive JPEG files, cannot be read by this player

Kodak Kodak Picture CDs

DVD copy protection

In accordance with the DVD standard, your DVD player is equipped with a Copy Protection system, which can be switched on and off by the DVD disc itself, in order to make any recording of the relevant DVD disc onto a videotape of very poor picture quality, or even impossible. "This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright technology unit is protected by our patients and other microscop popular, and is intended for home and other protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited."

Note on DivX files

Before playing DivX or mpeg4 files, please be sure of their origin and that you have legally purchased or rented the contents. Pirate copying is illegal and may result in sanctions. Private copies of your own material for your own use may be legal in some countries. Make sure you are aware of any applicable laws.

Technical data

Power requirements: AC 230V, 50 Hz -Power consumption: I5W -Operating temperature: $5^{\circ}C$ to $35^{\circ}C$ ($41^{\circ}F$ to $95^{\circ}F$) -Operating humidity: 5 % to 90 % (no condensation).

THOMSON Multimedia Sales Europe


46, quai A. Le Gallo 92648 Boulogne Cedex

FRANCE

322 019 464 RCS NANTERRE

http://www.thomson-europe.com

- Insert two LR06 or AA batteries in the remote control.
- · Do not mix different types of batteries or new and old batteries. Do not use rechargeable batteries.
- In order to avoid any risk of explosion, observe the polarities indicated inside the battery compartment
- Replace only with the type of batteries specified above. Do not dispose of them in a fire or recharge them. • If you are not using the remote control for a long period of time, remove the batteries.



Connections and Setup

Some points to check before you connect your TV set

- · Ensure that the mains supply in your house complies with that indicated on the identification sticker located on the back of your appliance.
- Install your appliance horizontally, away from any source of heat (fireplace) or appliances generating strong magnetic or electric fields. The components of this appliance are sensitive to heat. The maximum ambient temperature should not exceed 35° Celsius.
- · Leave sufficient space around the appliance to allow adequate ventilation: 10 cm on either side and at the back, as well as 7 cm above it are ideal.
- The humidity of the room should not exceed 75%. If you have to use the appliance outdoors, do not expose it to rain or splashing water. The appliance should not be exposed to dripping or splashing and no objects filled with liquids, such as vases, should be placed on top of it.
- · Moving it from a cold environment to a warm one is likely to cause condensation on some components inside the appliance. Let the condensation disappear of its own accord before turning the appliance on again.

To access the Zoom function

· Before moving the player, make sure the disc tray is empty.


700M

The remote control

	ZOOM	To access the Zoom function.				
	ANGLE	To access the Camera angle function.				
	OPEN ·CLOSE	To open and close the disc tray.				
	ڻ ا	To switch the appliance on and off.				
ZOOM ANGLE CLOSE	PROGRAM	To access the Program menu.				
ZOOM ANGLE CLOSE	RANDOM	To access the Random playback function.				
PROGRAM RANDOM REPEAT A-B	REPEAT	To access the Repeat playback function.				
REV FWD SKIP	A-B	To access the A-B repeat playback function.				
AUSE PLAY STOP	REV	To start reverse accelerated play and reverse slow motion.				
	FWD	To start forward accelerated play and forward slow motion.				
	SKIP ≪/≫	To start a reverse or forward search for a chapter or track.				
	PAUSE	To activate freeze frame, frame advance, slow motion.				
REVIEW SET UP	PLAY	To start playing a disc.				
	STOP	To stop play.				
1 2 3 DISPLAY	CLEAR	To clear entered items in a menu.				
4 5 6 AUDIO	DISC MENU	To call the disc menu (if there is one).				
7 8 9 SUBTITLE		To access the PBC menu.				
	<>××	To navigate through the menus.				
C BOOKMARK TITLE	OK	To confirm a selection.				
	PREVIEW	To access the Digest or the Introscan function.				
	SET UP	To access the player's menu.				
	0 - 9	Number entry.				
	DISPLAY	To display the Status menu.				
THOMSON	AUDIO	To change the dialogue language or audio format.				
RCT195DA1	SUBTITLE	To select a subtitle language and turn the subtitle menu on and off.				
	₩.	To mute and restore the sound.				
	BOOKMARK	To access the Bookmark function.				
	TITLE MENU	To access the title menu of the disc (if there is one). To turn the PBC function on and off.				
erting batteries in the re	emote control					

(E 2 35985440 © Copyright THOMSON 2005







This THOMSON product is designed and manufactured with high quality materials and components which can be recycled and reused. This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste.

Please, dispose of this equipment at your local community waste collection/recycling centre

In the European Union there are separate collection systems for used electrical and electronic product. Please, help us to conserve the environment we live in!



www.thomson-europe.com

₽ • Please respect the environment and prevailing regulations. Before you dispose of batteries or accept the company of the company of

Front panel controls

THOMSON			•RBCek	Bert		249	(1993) (1997)	100	
	DVD / COMPACT DISC PLAYER	ĴŎ	≣i ≉ 888:88	88≊	0				
<u></u>					_	=			P
		Ó				0	6)	0

1 SENSOR - Remote sensor. Point the remote control here.

OPEN/CLOSE - To open and close the disc tray.

③ STOP/STANDBY - To stop disc playback. To switch the appliance on and off.

PLAY - To start playing a disc.

Basic connections (DVD player + TV + video recorder)


I. Connect the DVD player Scart socket (TV AUDIO VIDEO OUT) to the television set's Scart socket (AVI, EXTI, AUXI) using a Scart lead (not provided). - OR -

- I. If your television set does not have two Scart sockets, connect the DVD player to the video recorder's AV2 socket using a Scart lead (not provided). If you have a satellite or cable receiver you can also connect the DVD player to the receiver's second Scart socket.
- Note: If your video recorder only has one Scart socket, but has a modulator, use the aerial cable to connect the video recorder to the television set, adjust the video recorder's modulator, then connect the DVD player to the video recorder's Scart socket.
- 2. Connect the video recorder (or satellite receiver) to the television set as shown in the video recorder's (or satellite receiver's) user guide
- 3. Connect the DVD player to the mains socket using the mains lead.
- 4. Switch on the devices.

Note: If one of the devices is not working, check that all the cables have been inserted properly into the sockets which they should be connected to

Other connection options





Coaxial cable

Coaxial digital audio output

VIDEO OUT socket

This socket (yellow) is also known as a composite video socket. The video cable (not supplied) usually comes with two audio cables (white and red). The picture quality obtained using a video connection is poorer compared to that obtained using a Scart connection.

AUDIO L (left) and AUDIO R (right) sockets

These are analogue audio output sockets. The AUDIO L socket and cable are white, while the AUDIO R socket and cable are red. Connect the DVD player's AUDIO L and R sockets to the television set's AUDIO L and R sockets using audio cables (not supplied).

Note: If your television set only has one audio socket connect it to the DVD player's left socket (white

Coaxial digital audio output (COAXIAL)

This socket offers a higher level of sound quality compared to that provided using an analogue audio connection. For 6-channel multichannel sound. connect the audio/video amplifier or receiver to this socket using a coaxial cable (not supplied).

Basic Playback Operations

Regional coding

Your DVD player has been designed to process regional management information that is stored on DVD discs. DVD discs that have different regional codes to that of your player cannot be played. The regional code for your player is 2 (Europe, the Middle East, South Africa, Japan). ALL means all regions. When you buy a disc check that it bears the correct logo.

Operating the DVD player

I. Switch on your TV set.

2. Press the \bigcirc button on the remote control or the STOP/STANDBY button located on the DVD player's front panel.

Playback

- Press the OPEN/CLOSE button on the front of the appliance or on the remote control to open the disc tray.
- 2. Put the disc in with the printed side upwards (in the case of a single-sided disc).
- Press OPEN/CLOSE again to close the disc tray. Play starts automatically. If a menu appears, one of its options can be selected to start playing the disc. Select it and press OK.

4. Press **STOP** to stop playback.

Notes: The player stores the point where playback was interrupted. If you press **PLAY** again, playback resumes from this point. To stop playback completely or to start again from the beginning, press **STOP** twice. If the player is left in STOP mode for more than five minutes without any user interaction, a screen saver is activated.

Accelerated play

While the disc is playing, press the **REV** or **FWD** button one or more times to vary the speed and direction of the accelerated play.

Still image

While the disc is playing, press **PAUSE** once for freeze frame. Note:After five minutes in PAUSE with no user interaction, the player goes into screen saver mode

Frame advance (all discs except audio CD, mp3, WMA and DivX)

- 1. While the disc is playing, press **PAUSE** once.
- 2. Press the PAUSE button a number of times to advance forward image by image.

3. Press PLAY to resume normal playback.

Variable slow motion (DVD and VCD only)

I. While the disc is playing, press **PAUSE** once.

2. Press the **REV** or **FWD** button a number of times to vary the speed and direction of the slow motion.

3. Press PLAY to resume normal playback.

Note: Reverse slow motion is not possible with a Video CD.

Changing chapter/track

While the disc is playing, press the **SKIP** H or **SKIP** H button to go immediately to the next or previous chapter, or to the next or previous track. For audio CD and VCD only: enter the track number with the number buttons and then

press **OK**.

Zoom (DVD,VCD and DivX only)

I. While a disc is playing, press the **ZOOM** button until you reach the zoom size you require.

2. Move from one area to another using the \checkmark , \succ , \bigstar and \checkmark buttons.

Play modes

Repeat playback

While the disc is playing, press the **REPEAT** button repeatedly to select a play mode: **DVD**: Repeat Chapter, Repeat Title, Repeat Off:

VCD and audio CD: Repeat Track, Repeat All, Repeat Off;

A-B repeat

2

To repeat a sequence between two points A and B, press the **A-B** button at the beginning of the sequence you want to repeat. Then press the **A-B** button again at the end of the sequence. Then the sequence is played repeatedly until you press **A-B** to resume normal playback.

Programme playback (DVD,VCD and audio CD)

With this option, you choose and programme the playback order. You can store up to 20 tracks. I. Insert a disc.

- 2. In Stop mode, press the **PROGRAM** button. The **Program** menu appears.
- Use the number buttons to enter the title number and then the chapter number (for DVD) or the track number (for VCD and Audio CD). Repeat Step 3 as often as necessary.
- 4. Use the ≺, ≻, ∧ and ∨ buttons to select Start and press OK to start playback. Tracks are played in the order of the playback list. Playback stops once all tracks have been played.
- Press the STOP button to stop the programme playback. Press the STOP button twice or the OPEN/CLOSE button to cancel the programme playback.

Random playback (all discs except DVD)

You can play all the tracks on the disc in a random order (chosen by the player). I. Insert a disc.

- 2. Press the **RANDOM** button during playback. "**Random**" appears. Once all tracks have been randomly played, the player automatically stops playback.
- 3. Press the RANDOM button again to stop random playback. "Off" appears on the TV screen.

Advanced functions

Audio (DVD, VCD and audio CD)

Some discs have several audio tracks used for different languages or different audio formats. To change the language or audio format during play, press the **AUDIO** button one or more times to select one of the available audio formats or languages.

Note: This option is only available if the disc offers a number of dialogue languages or audio formats. Bookmarks

BOOKIIIAIK

The player can store up to 12 disc locations as long as the disc remains in the player and the unit remains switched on.

- I. Press the BOOKMARK button during play. A menu is displayed.
- 2. To create a bookmark, select a free bookmark using the < and > buttons and press the PLAY button.
- **3.** Repeat Step 2 as often as necessary.
- To start playback from a bookmark, press the BOOKMARK button, select the bookmark using the

 and → buttons and then press the PLAY button.
- 5. To delete a bookmark, press the BOOKMARK button, select the bookmark using the ≺ and ➤ buttons and then press the CLEAR button.
- To exit the bookmark function, press the **BOOKMARK** button again.

Status menu

- Press the **DISPLAY** button a number of times during playback to show in turn:
- **DVD**:Title elapsed time,Title remaining time, Chapter elapsed time, Chapter remaining time, Display Off.
- VCD and audio CD: Single elapsed time, Single remaining time, Total elapsed time, Total remaining time, Display Off.
- mp3 and DivX: Single elapsed time, Single remaining time.

PBC (VCD)

The PlayBack Control function offers scenes and information which can be selected interactively via a menu. It can also be used to display high-resolution pictures, if the disc contains any. Press the **DISC MENU** button to access the PBC menu and the **TITLE MENU** button to turn the PBC function on and off.

Preview (DVD and VCD)

 Press the PREVIEW button during playback to display the Digest menu. It includes various options depending on the type of disc:

DVD:Title Digest, Chapter Digest, Title Interval, Chapter Interval and Bookmark Digest; VCD:Track Digest, Disc Interval and Track Interval.

- 2. Select one of the digest types:
- Title Digest/Chapter Digest/Track digest: shows a digest of all titles/chapters/ tracks available on the disc.
- Title/Chapter/Disc/Track Interval: shows a digest of the current title/chapter/disc/ track in 10 minutes interval.
- Bookmark Digest: shows a digest of all bookmarks created on the disc.
- 3. To display the next page, press the ➡I button or select Next in the menu and press OK. To start playback from a particular title, chapter, track, interval or bookmark, select it using the ≺, ≻, ∧ and ∨ buttons and press OK, or input the corresponding number in the Select box and press OK.
- To return to the digest menu, select the **Menu** button, and press **OK**.
- To leave the digest menu, select the \mathbf{Exit} button and press \mathbf{OK} or press the $\mathbf{PREVIEW}$ button again.

IntroScan (audio CD)

This option plays the first five seconds of each track.

Press **PLAY** to start playback, then the **DISPLAY** button to display the Single elapsed time and then the **PREVIEW** button to start the IntroScan. Press **PLAY** to continue playing the current track.

Playback of mp3,WMA, JPEG and DivX files

mp3 is an audio file format which compresses recorded music. It was developed in collaboration with **THOMSON**. The main advantage of the mp3 format is that it means CD-quality music tracks can be stored on a personal computer in user-friendly compressed files. WMA (Windows Media Audio) is another audio file format developed by Microsoft. JPEG files are image files. Make sure that they have a resolution of less than 5 megapixels. Your player is an Official DivX CertifiedTM product that plays DivX[®] 5, DivX[®] 4, DivX[®] 3, and DixX[®] VOD video content, in compliance with DivX CertifiedTM technical requirements.

Displaying JPEG files or playing mp3 or WMA or DivX files

- Before inserting a disc, check that it is compatible with the player.
- I. Open the tray by pressing the OPEN/CLOSE button.
- Place the disc with the printed side facing up and close the tray. The disc's contents are displayed.
 Select a folder using the ▲ and ¥ buttons on the remote control, then press OK to
- see the folder's contents.
- **4.** Select a file using the \land and \lor buttons on the remote control, then press **OK** to start playback.
- 5. Press the STOP button to stop playback.

to the next or

6. To go back to the folder list, press the ≺ button in stop mode. Note: During playback you can use the SKIP I or SKIP >> button to go back to the previous file or go on

Playing JPEG and mp3 music files at the same time

- You can display JPEG files while listening to mp3 music files recorded on the same disc.
- 2. Select an mp3 music file using the ▲ and ➤ buttons, then press OK to confirm your selection.

- 3. Then select a JPEG image file using the ▲ and ¥ buttons, then press OK to confirm your selection.
- Note: To delete your selection, press the CLEAR button

4. Press OK to start playing the two files at the same time.

5. Press the STOP button to stop playback.

specialist websites such as www.divx.com/vod

DivX: Repeat One, Repeat All, Repeat Off.

Programme playback (mp3 and WMA)

Repeat playback

I. Insert a disc.

have been played.

Player menus

TV Display

Normal/PS:

Normal/LB[.]

Widescreen:

Menu Language

buttons and press OK to confirm.

Refer to "To rent (or purchase) DivXVOD files".

The Dolby Digital Setup menu

om Dolby Laborator

TV Type

VOD

Download from Www.Somanuals.com. All Manuals Search And Download.

Using the player's menus

The General Setup menu

the format of your TV screen.

To rent (or purchase) DivX[®]VOD files

DivX VOD files are downloaded after paying a rental from certain commercial websites. Prior to downloading a VOD you need to input the registration number of your DVD player on the purchase form on the site.

Follow the instructions below to find the registration number of your player: press the **SET UP** button. Select the **VOD** option from the **General Setup Menu** and press **OK**. Write down this VOD 8-character registration number so that you can fill in the form on the website you purchase your DivX VOD files from.

Note: If you cannot play a DivX VOD file recorded on a CD-R disc after downloading it, the rental period

used when copying to CD-R may be another reason for this. Since it is not possible here to supply all the

information, parameters and advice relating to the use of DivX VOD files, we recommend that you visit

While the disc is playing, press the **REPEAT** button repeatedly to select a play mode:

2. Use the \checkmark , \succ , \bigstar and \checkmark buttons to select the file you want to add to the playback list

playback. Files are played in the order of the playback list. Playback stops once all files

Press the SET UP button to display the player's main menu. Select a menu icon using the <

and \succ buttons. Then select one of the available options using the \land and \checkmark buttons. Press

the \blacktriangleright button to access the submenu and use the \land and \checkmark buttons to select an option. Then

DOLBY

Depending on the format of the DVD disc, you can choose the picture format best suited to

reproduces 16:9 format films in full on a 16:9 screen.

In addition to PAL DVDs and VCDs, you can enjoy NTSC films as well (a 50Hz or 60Hz PAL

- Dolby Digital Setup -

District Dolby and the double-D symbol I are trademarks of Dolby Laboratories. Manufactured under

D

compatible TV set is required). If the pictures from the DVD being played appear in black

To change the language of the player menus, choose the language using the \bigstar and \checkmark

D

Normal/PS

ENG DivX(R) VOD

gives best reproduction of pictures recorded in this format (i.e. with

horizontal bands at the top and bottom of the screen) or in 16:9,

press **OK** to confirm your selection. Return to a previous menu using the **〈** button.

General Setup Menu

To delete a file from the list, press the **PROGRAM** button, use the \wedge and \vee buttons to

and press the BOOKMARK button. Repeat this step as often as necessary.

select the file from the playback list and press **BOOKMARK** to delete it.

4. Press the OPEN/CLOSE button to delete the playback list.

To exit from the player menus, press the **SET UP** button again.

Д

TV Display

Select a format using the \wedge and \vee buttons and press **OK** to confirm:

and white on your screen, try changing the colour standard.

Set the function to PAL or NTSC and press OK to confirm.

Dynamic

reproduces a 4:3 picture without distortion,

TV Type Menu Language VOD

3. Press the PROGRAM button to display the playback list and press PLAY to start

IPEG, mp3 and WMA: Repeat One, Repeat Folder, Folder (=Off),

allocated during purchasing from the website may have expired. It is also possible that the recorded file is not compatible with your player because of different versions or incorrect download parameters. The parameters

Dynamic

You can use this function to control the different sound levels via dynamic compression. It improves the quality of the sound track at a low volume and quietens the loudest sounds. Select an option using the \wedge and \checkmark buttons, and press **OK** to confirm.

Note: This function is available only on DVD discs recorded in Dolby Digital.

The Preferences Setup menu

	DOLBY				
Preferences Setup					
Audio Subtitle Disc menu Ratings Password	ENG ENG ENG				

Note: The Preferences Setup menu is not available when there is a disc in the player

To change the dialogue language, choose the language using the \blacktriangle and \forall buttons and press **OK** to confirm.

Subtitle

To change the subtitle language, choose the language using the \blacktriangle and \checkmark buttons and press \mathbf{OK} to confirm.

Disc menu

To change the language of the disc menus, choose the language using the \blacktriangle and \checkmark buttons and press **OK** to confirm.

Ratings

You can control access to the player and the type of discs your family can watch with the rating function. There are eight levels of parental control.

- Note: The disc publisher is responsible for coding scenes according to the rating limits. In Europe, very few discs have coded scenes.
- I. Select the rating level using the \checkmark and \checkmark buttons.
- 2. Press OK to enter the Password Setup menu.
- Note: To access the Ratings submenu, you must input a four-digit password. If you have not chosen one yet, you are prompted to do so when you try to access it (see option **Password**).
- Enter your four-digit password and press OK. If you have not chosen one yet, the factory preset password is 1369.

Password

This option allows you to set or change the password.

- I. Press OK to enter the Change Password menu.
- 2. To change the password, enter the current four-digit password in the "Old Password" box. Then enter the new password in the "New Password" box. You are then prompted to enter it again in the "Confirm Password" box to confirm and press OK.

Additional Information

Troubleshooting

- The appliance does not switch on.
- Make sure it is plugged into a mains socket.
- Press the \bigcup button on the remote control or the ${\bf STOP/STANDBY}$ button on the front of the appliance.

It is impossible to read the disc.

- Insert the disc with the printed side facing up.
- Check that the disc can actually be played by this device (see below).
- Check that the disc's regional code matches the player's regional code. This player's regional code is 2.
- · Clean the disc (see below).

There is no picture.

- Check you have switched on the TV set.
- · Check the connections.
- Select the AV input assigned to the player on the TV.
- The picture is of poor quality (with snow or lines).

Check the connections.

- There is no sound or the sound is of poor quality.
- Check the connections.
- Turn on the audio equipment connected to the player, if any.
- The remote control does not work or works only intermittently.
- · Check that batteries are inserted or change them.
- Aim the remote control at the appliance. The infrared beam must not be blocked or interrupted.

The subtitles do not appear.

- Check that the DVD disc provides subtitles.
- Refer to the section on how to display subtitles
- The disc menu language is not the correct one.
- The disc menu language has not been set up.
- The language of your choice is not available on the disc.
- You have forgotten your password (Parental control).
- Open the disc tray, press CLEAR and then enter 00001 with the numeric buttons. Turn off the player and then turn it on again.

Precautions

Use

• If your appliance has been stored in a cool place for any length of time, during a journey for example, wait for about 2 hours before using it.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com