


WINEGARD®

ENTERTAINMENT SELECT


MODEL VS-0503/VS-5312

Model shown has five inputs, three outputs.



FEATURES:

- Simple push button controls allow you to send signals from any one of 5 different inputs to 2 TVs and VCR.
- 5 Inputs are Satellite Receiver, TV Antenna, VCR, Cable TV & Auxiliary.
- 3 Outputs: Main TV, TV 2, VCR.
- Built-in +12 VDC TV antenna power supply eliminates need for separate wall mounted TV antenna power supply.
- Self-resetting fuses used in antenna power supply prevent failure caused by shorted connections.
- Video switch allows for independent viewing of signals at different TVs, with a record option from VCR.
- Low profile housing blends nicely with other electronic components; fits easily in overhead cabinets.
- Shielded circuitry for high isolation and low signal loss.
- Oversize, easy-to-read graphics for proper function selection when mounted in out of the way locations.



COAX CABLE CONNECTIONS

STEP 1. Connect the coax cable from the output on the switch box marked "To Main TV" to the antenna input connection on the back of the main TV.

STEP 2. Connect the coax cable from the output on the switch box marked "To TV 2" to the antenna input connection on the back of the second TV.

STEP 3. Connect the coax cable from the output on the switch box marked "To VCR" to the input connection on the back of the VCR.

STEP 4. Connect the coax cable from the output of the VCR to the coax connection on the back of the switch box marked "From VCR."

STEP 5. Connect the coax cable from the exterior Cable TV input plate to the to the coax connection on the switch box marked "From Cable TV."

STEP 6. The output of the auxiliary device (TV game, camcorder, etc.) can be connected to the input connection marked "FROM AUX."

STEP 7. Connect the coax cable from the output of the satellite receiver marked "TO TV" to the input connection on the back of the switch box marked "From Sat."

NOTE: The coax cable from the satellite antenna must go directly to the input of the satellite receiver marked "Satellite In."

STEP 8. Connect the coax cable from the TV antenna to the coax connection on the back of the switch box marked "From TV Ant."

POWER CONNECTIONS

NOTE: When hooking up an amplified TV antenna, see Figures A and B. When hooking up a non-amplified antenna see Figure C. If you are unsure whether your antenna is amplified or non-amplified, contact the manufacturer of the antenna or your dealer. If using VS-0503 as shown in Fig. A, use the wires and connector supplied and connect +12 VDC per Note to the right of Fig. A.




Figure A. (BYPASSING THE WALL MOUNTED POWER SUPPLY)

When using Winegard or another brand of VHF/UHF "Amplified Antenna", you must hook up the +12 VDC power to the back of the control box. The Power Indicator LED will only light when the Power button is on.

Figure B. (USING THE ANTENNA'S WALL MOUNTED POWER SUPPLY)

When using Winegard or another brand of VHF/UHF "Amplified Antenna" with power supply, you don't need to hook up the +12 VDC to the control box if you are using the antenna's separate wall mounted power supply. The TV Antenna Power Button is only used when wired for an amplified antenna. The Power Indicator LED will only light when the switch box is wired per Fig. A.

Figure C. When using Winegard or another brand "Non-Amplified Antenna," the +12 VDC should NOT be used. The TV Antenna Power Button is only used when wired for an amplified antenna. The Power Indicator LED will only light when the switch box is wired per Fig. A.

OPERATION

Once all the connections have been properly made to the control box, you are ready to watch your favorite programming.

USING THE BUTTONS ON THE FRONT OF THE CONTROL BOX

VIEWING

STEP 1. To view signals from an amplified TV Antenna, first press the TV Antenna POWER button to the ON position. This provides +12 volt power to the TV antenna amplifier located inside the antenna housing. To view the TV antenna signal on the main TV, simply press the TV ANT button located above the area marked "MAIN TV." Follow the same procedure for TV 2.

NOTE: The picture quality from your outdoor TV antenna varies depending on the location of the TV station in relationship to your location. If picture quality is degraded and you are *not* using an external power supply, try turning the TV Antenna Power button on your control box Off and On. If your TV antenna is powered by an *external* wall mounted power supply, try turning it Off and On.

STEP 2. To view Satellite signals on your main TV, press the SAT button above the area marked "Main TV." Follow the same procedure for TV 2.

STEP 3. To view Cable TV signals on your main TV, press the Cable TV button above the area marked "Main TV." Follow the same procedure for TV 2.

NOTE: To view Cable TV signals, you must be connected to a Cable TV input on the outside of your vehicle. Cable TV inputs are available at many of today's campgrounds.

STEP 4. To view VCR signals on your main TV, press the VCR button above the area marked "Main TV." Follow the same procedure for TV 2.

STEP 5. To view Auxiliary signals, such as games, camcorder, etc., on your main TV, press the AUX button above the area marked "Main TV." Follow the same procedure for TV 2.

RECORDING

STEP 6. To record programming from the Antenna, Satellite Antenna, Cable TV or Auxiliary, simply press the appropriate button above the section marked VCR.

To record programming from the TV antenna to your VCR, press the TV ANT button above the VCR section on the switch box.

To record programming from the Satellite antenna to your VCR, press the SAT button above the VCR section on the switch box.

To record programming from an Auxiliary device to your VCR, press the AUX button above the VCR section.

To record programming from Cable TV to your VCR, press the Cable TV button above the VCR section on the switch box.

NOTE: To record Cable TV signals, you must be connected to a Cable TV input on the outside of your vehicle. Cable TV inputs are available at many campgrounds.

NOTE: With Winegard's control box, you can watch different programming on each of your two TV sets while recording another program on your VCR. If your vehicle is equipped with an exterior patio TV set, you may choose the programming source desired for the patio TV by using the buttons above the TV 2 section on the control box. The programming source is the same for the patio (exterior) TV and TV 2. When viewing signals on the patio TV, you cannot view different signals on TV 2. You could watch different signals on the main TV.

TROUBLESHOOTING


If the unit doesn't switch properly between inputs, (TVs, VCR, SAT, CABLE, etc.), be sure the coax is connected to the proper jacks on the back of the control box. Make sure the center conductors of the coax cables are not bent and are making good contact. See "Installing Coax Connectors" below.

If you are using the +12 VDC and light does not turn ON when pushing the power button, go through the following steps.

1. Be sure the unit is wired into a +12 VDC source and that this source is supplying power to the plug going to the control box. Check to make sure all connections are correct.
2. If power is being supplied to the control box and the light still does not go on when pushing the TV Antenna Power Button, disconnect the coax from the jack labeled "From Antenna" on the back of the control box. If the light now comes on, there is a short in your coax cable going to the outside antenna, or the amplifier in your antenna is bad.
3. Reattach the coax cable to back of the control box. Disconnect it at the TV antenna. If the light comes on, the coax cable is connected properly and the problem is in the antenna. If the light does not come on, the problem is in the coax cable.

NOTE: The picture quality from your outdoor TV antenna varies depending on the location of the TV station in relationship to your location. If picture quality is degraded and you are *not* using an external power supply, try turning the TV Antenna Power button on your control box Off and On. If your TV antenna is powered by an *external* wall mounted power supply, try turning it Off and On.

INSTALLING COAX CONNECTORS



1. Strip outer cover back 1/2" from end of cable. Fray braid back as far as outer cover will allow.
2. Trim braid close to outer cover and remove 1/4" of inner insulation. **Be careful not to nick center conductor and make sure no foil or braid can touch center conductor.**
3. Slide connector tip between braid and inner insulation (braid and foil, on foil shield cable), and push connector on cable as far as it will go. Crimp built-in ferrule with appropriate crimping tool. **Do not crush cable out-of-round.** (If you are installing in very hot weather, increase these dimensions 1/8").

WINEGARD MOBILE PRODUCTS LIMITED WARRANTY (2 YEARS PARTS; 1 YEAR LABOR)

Winegard Company warrants this Winegard product against defects in materials or workmanship for a period of two (2) years from date of original purchase. During year one (1) of such warranty, Winegard Company will also pay authorized labor costs to an authorized Winegard dealer to repair or replace defective products. No warranty claim will be honored unless at the time the claim is made, Customer presents proof of purchase to an authorized Winegard dealer, (to locate the nearest authorized Winegard dealer, contact Winegard Company, 3000 Kirkwood Street, Burlington, IA 52601, Telephone 319-754-0600 or visit www.winegard.com. Customer must provide proof of purchase with a dated sales receipt for the Winegard product to verify the product is under warranty. If the date of purchase cannot be verified, the warranty period shall be considered to begin thirty (30) days after the date of manufacture.

If a defect in material or workmanship is discovered, Customer may take the product to an authorized Winegard dealer for service. Customer must provide proof of purchase to verify the product is under warranty. If the product is brought to an authorized Winegard dealer for service prior to expiration of year one (1) of the warranty period and a defect in material or workmanship is verified by Winegard Technical Services, Winegard Company will cover the Winegard dealer's labor charges for warranty service. The Winegard dealer must contact Winegard Technical Services in advance for pre-approval of the service. Approval of the service is at the sole discretion of Winegard Company.

Alternatively, Customer may ship the product prepaid to Winegard Technical Services (located at 3000 Kirkwood Street, Burlington, Iowa 52601, Telephone 319-754-0660). Customer must return the product along with a brief description of the problem and provide Winegard Technical Services with Customer's name, address, and phone number. Customer must also provide proof of purchase to verify the product is under warranty. If the product is returned before the expiration of the warranty period, Winegard Company will (at its option) either repair or replace the product.

This Limited Warranty does not apply if the product has been damaged, deteriorates, malfunctions or fails from: improper installation, misuse, abuse, neglect, accident, tampering, modification of the product as originally manufactured by Winegard in any manner whatsoever, removing or defacing any serial number, usage not in accordance with product instructions or acts of nature such as damage caused by wind, lightning, ice or corrosive environments such as salt spray and acid rain.

RETURN AUTHORIZATION POLICY

A Return Material Authorization (RMA) is required prior to returning any product to Winegard Company or Winegard Warranty Services under this warranty policy. Please call our Technical Services Department at (800) 788-4417 or send an email to warranty@winegard.com to obtain the RMA number. Please furnish the date of purchase when requesting an RMA number. Enclose the product in a prepaid package and write the RMA number in large, clear letters on the outside of the package. To avoid confusion or misunderstanding, a shipment(s) without an RMA number(s) or an unauthorized return(s) will be refused and returned to Customer freight collect.

WINEGARD COMPANY DOES NOT ASSUME ANY LIABILITIES FOR ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, MADE BY ANY OTHER PERSON.

ALL OTHER WARRANTIES WHETHER EXPRESS, IMPLIED OR STATUTORY INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY ARE LIMITED TO THE TWO YEAR PERIOD OF THIS WARRANTY.

In states that do not allow limitations on implied warranties, or the exclusion of limitation of incidental or consequential damages, the above limitations or exclusions do not apply.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion of limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This warranty gives Customer specific legal rights. Customer may also have other rights that may vary from state to state.

SATELLITE RECEIVER WARRANTY
See manufacturer's limited warranty policy.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>