





Cat. No. 21-1822

Owner's Manual

FRS 2-Way Radio

sports

- Water- and Shock-Resistant
 - 14 Channels
- 300 mW Output Power
- 2-Digit Channel Display
 - 19 Quiet Codes
- Rubberized Case
 - Call Button
 - Channel Lock
- 30-Hour Battery Life
 - Headset Jacks
- Low Battery Indicator
 - Built-in Charger



RadioShack®






INTRODUCTION




RadioShack welcomes you to the next generation of personal communication — the Family Radio Service (FRS). FRS is a new license-free, two-way, short-range voice radio service that lets families and groups keep in touch with each other on specific reserved channels.

Your RadioShack Sports FRS 2-Way Radio is a lightweight, palm-sized radio that you can carry almost anywhere and use to talk with another person who has an FRS radio set to the same frequency as your radio. Your radio's quiet code feature is like having a sub-channel within a channel, giving you greater communication flexibility.



Your radio has 14 channels and 19 different quiet codes. If someone else is using the channel you selected and you do not want to hear that person, select another channel or use the quiet feature (see "Using Quiet Codes" on Page 9). You can talk with other FRS radio users whose radios are tuned to the same channel and quiet code as yours.



Your radio has *auto-squelch*, which means you will not hear anything on a channel unless someone is transmitting nearby on the same channel. You can turn off auto-squelch to hear weaker, distant transmissions (see "Auto-Squelch" on Page 11).



PREPARATION

Note: Your radio's display is protected during shipment by a piece of film. Peel off this film before you use the radio.

INSTALLING BATTERIES

Your radio requires three AAA batteries (not supplied) for power. For the best performance and longest life, we recommend alkaline batteries, or you can use nickel-cadmium (Ni-Cd) or nickel-metal hydride (Ni-MH) rechargeable batteries and charge them in the radio with an optional AC adapter. Both types of batteries are available from your local RadioShack store.


Before using the radio with rechargeable batteries, you must charge the batteries for a minimum of 12-16 hours, using an adapter (not supplied). See "Charging Rechargeable Batteries" on Page 4.

Warning: Dispose of old batteries promptly and properly. Do not burn or bury them.

Cautions:

- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- If you do not plan to use the radio for a month or longer, remove the batteries. Batteries can leak chemicals that can destroy electronic parts.





1. Rotate  **OFF** toward **OFF** until it clicks to turn off the radio, then pull down the latch on the bottom of the radio to remove the battery compartment cover.

2. Use a pointed object such as a pen to set **AL/NI** inside the compartment to **AL** (for alkaline batteries) or **NI** (for rechargeable batteries).

Warning: Never set **AL/NI** to **NI** if you use non-rechargeable batteries. Non-rechargeable batteries can get hot or explode if you try to recharge them.

3. Install the batteries inside the battery compartment, matching the polarity symbols (+ and -) marked inside the compartment. Then replace the battery compartment cover.




The radio's range decreases as battery power decreases. To ensure maximum range, keep fresh batteries in the radio.

If TX/BATT lights when you are not holding down PTT, replace or recharge the batteries.

Charging Rechargeable Batteries

You can charge rechargeable batteries in the radio using either a 9V, 300 mA AC adapter or a DC cigarette-lighter adapter and a size H Adaptaplug[®] adapter (not supplied). All are available at your local RadioShack store.

It takes between 12 and 16 hours to recharge rechargeable batteries that are fully discharged. It takes about 14 hours to fully



charge 550mAH Ni-MH batteries in your radio. For best battery life, do not overcharge.

Warning: Do not charge non-rechargeable batteries in the radio. Non-rechargeable batteries can get hot and explode if you try to recharge them.


Cautions:



You must use a Class 2 power source that supplies 9V DC and delivers 300 mA. Its center tip must be set to positive and its plug must fit the radio's **CHG** jack. Using an adapter that does not meet these specifications could damage the radio or the adapter.

- Always connect the adapter to the radio before you connect it to an external power source (such as an AC outlet or a vehicle cigarette-lighter socket). When you finish, disconnect the adapter from the external power source before you disconnect it from the radio.
- Do not charge rechargeable batteries longer than 12 to 16 hours.

Note: Ni-CD batteries and other batteries of lower capacity will fully charge faster, but provide less operating time

1. Rotate  **OFF** toward **OFF** until it clicks to turn off the radio, then pull down the latch on the bottom of the radio to remove the battery compartment cover.
2. Use a pointed object such as a pen to set **AL/NI** to **NI**.

3. Install the rechargeable batteries inside the battery compartment, matching the polarity symbols (+ and -) marked inside the compartment. Then replace the battery compartment cover.
4. Attach the Adaptaplug adapter to the adapter so the tip reads positive (+).
5. Connect the other end of the adapter to a standard AC outlet or, if you are using a DC adapter, attach the other end to a vehicle's cigarette-lighter socket.

Important: This radio can use Ni-Cd rechargeable batteries. At the end of a Ni-Cd battery's useful life, it must be recycled or disposed of properly. Contact your local, county, or state hazardous waste management authorities for information on recycling or disposal programs in your area or call 1-800-843-7422. Some options that might be available are: municipal curbside collection, drop-off boxes at retailers such as your local RadioShack store, recycling collection centers, and mail-back programs.



CONNECTING AN OPTIONAL MICROPHONE/ SPEAKER


To use the radio privately, connect an optional headset with microphone or a microphone and earphone communication headset (available at your local RadioShack store) to the **SPK** and **MIC** jacks.

This connection automatically disconnects the internal speaker and the **PTT** (push to talk) button.

Or, you can connect a mono earphone (available at your local RadioShack store) into the **SPK** jack and use the **PTT** button as usual.


USING THE BELT CLIP

To use the supplied belt clip, slide it down onto the tab at the back of the radio until it clicks. To remove the clip, pull up on the middle tab of the clip and slide the clip upward.



USING A HAND STRAP


To attach an optional hand strap to the radio, thread the hand strap's small loop through the holes next to **PTT**. You might need to use a small screwdriver or a straightened paper clip to do this. Then pull the strap's large loop through the small loop.



To attach an optional pager chain to the radio, simply snap the chain's small loop into one of the holes next to **PTT**.

OPERATION

CONTROLS



VOLUME — turn away from **OFF** to turn the radio on and adjust the volume. To turn the radio off, turn **VOLUME** toward **OFF** until it clicks.

PTT (push to talk) — to talk, hold down for about 1 second, then speak into the microphone. TX lights. Release **PTT** when you finish speaking.

CALL — hold down to send a paging tone or quiet code to all radios tuned to the same frequency.

Important: Do not hold down **CALL** for more than 10 seconds. The FCC does not allow you to send a continuous tone for more than 10 seconds at a time on FRS frequencies.


MON (monitor) — hold down to turn off auto-squelch (see “Auto-Squelch” on Page 11). To turn auto-squelch back on, release **MON**.

MODE — hold down then turn on the radio to set the quiet code, press to turn on or off the quiet feature (see “Using Quiet Codes” on Page 9), and hold down until **L** appears to lock **▲** and **▼** to prevent accidental operation.

Hold down **MODE** until **L** disappears to unlock **▲** and **▼**.

▲ and **▼** — selects the channel number.

DISPLAY AND INDICATORS



1-19 — indicates the selected channel (1-14) or quiet code (1-19).

TX/BATT — lights when you transmit a message, press **CALL**, or when the batteries are low.

L — appears when you lock **▲** and **▼**.

QUIET — lights when the quiet mode (CTCSS) is set and flashes while you are selecting the quiet (CTCSS) code.


USING QUIET CODES

You can set the radio with a Continuous Tone Coded Squelch System (CTCSS) quiet code and screen out unwanted conversations, even from someone transmitting nearby on the same channel. When a quiet code is set, the radio sends the code every time **PTT** or

CALL is pressed and the radio only responds to signals that have the same code. Radios you plan to use together must be set to the same code. This radio has these quiet (CTCSS) codes.

Channel	Frequency (Hz)	Channel	Frequency (Hz)
1	67.0	11	97.4
2	71.9	12	100.0
3	74.4	13	103.5
4	77.0	14	107.2
5	79.7	15	110.9
6	82.5	16	114.8
7	85.4	17	118.8
8	88.5	18	123.0
9	91.5	19	127.3
10	94.8		

To set the radio to use the quiet feature and set a quiet code:

1. Hold down **MODE** then rotate  **OFF** away from **OFF** to turn on the radio. The QUIET indicator flashes.
2. While the QUIET indicator flashes, repeatedly press **▲** or **▼** to select the quiet code, then press **MODE** again. The QUIET indicator stays lit and the quiet (CTCSS) code is set.

To turn on or off the quiet feature, press **MODE**. The QUIET indicator turns on or off.




AUTO-SQUELCH


Your radio has auto-squelch, which means you will not hear anything on a channel unless someone is transmitting nearby on the same channel. Or, if you use the quiet feature, you might not hear a transmission on the current frequency.

To turn off auto-squelch (so you can hear weaker, distant transmissions), hold down **MON**. Release **MON** to turn auto-squelch back on.

AUTO POWER SAVE




The automatic power save feature extends battery life by reducing the power the radio uses until the radio receives a signal or you press a key. When the radio sets itself to automatic power save mode, the radio's display turns off, then the channel number flashes intermittently.



Because the receiving radio might be in this mode, wait about 1 second after pressing **PTT** to allow the receiving radio to come to full power before you begin speaking.

TALK CONFIRMATION

You can set the radio so a confirmation tone sounds when you release **PTT**. The tone alerts another person you are talking to that you have finished talking. To turn on or off this feature, hold down **PTT** while turning on the radio.







TURNING THE KEY TONE ON AND OFF

The radio is preset to sound a beep each time you press a key. To turn the beep on or off, hold down **CALL** then turn on the radio.

CARE

To enjoy your RadioShack Sports FRS 2-Way Radio for a long time:

- Keep the radio dry. If it gets wet, wipe it dry immediately.
- Use and store the radio only in normal temperature environments.
- Handle the radio gently and carefully. Don't drop it.
- Keep the radio away from dust and dirt.
- Wipe the radio with a damp cloth occasionally to keep it looking new.



Modifying or tampering with the radio's internal components can cause a malfunction and might invalidate its warranty and void your FCC authorization to operate it. If your radio is not performing as it should, take it to your local RadioShack store for assistance.







FCC INFORMATION



Important: Do not open your radio to make any internal adjustments. Your radio is set to transmit a regulated signal on an assigned frequency. It is against the law to alter or adjust the settings inside the radio to exceed those limitations. Any adjustments made to your radio must be made by a qualified technician using the proper test equipment. To be safe and sure:

- Never open your radio's case.
- Never change or replace anything in your radio except the batteries.

Your radio might cause TV or radio interference even when it is operating properly. To determine whether your radio is causing the interference, turn it off. If the interference goes away, your radio is causing it.




Try to eliminate the interference by:

- moving your radio away from the receiver
- calling your local RadioShack store for help

Using your radio as described in this manual exposes you to RF energy well below the FCC's recommended limits.

This device complies with Part 15 of the *FCC Rules*. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



SPECIFICATIONS

RF Output Power 300 mW

Number of Channels 14

Frequencies:

Channel	Frequency (MHz)	Channel	Frequency (MHz)
1	462.5625	8	467.5625
2	462.5875	9	467.5875
3	462.6125	10	467.6125
4	462.6375	11	467.6375
5	462.6625	12	467.6625
6	462.6875	13	467.6875
7	462.7125	14	467.7125

Temperature Range -4° to 122°F
(-20° to 50°C)

Minimum Battery Life (alkaline):

Standby 85 Hours

Transmitting 4 Hours

Battery Type 3 AAA Alkaline
or Rechargeable

External Jacks **SPK, MIC, CHG**

Microphone Impedance 1 kOhm

Speaker Impedance..... 8 Ohms







Dimensions (HWD) 3.3 x 2.2 x 1.1 Inches
(85 x 56 x 28 mm)

Weight (with batteries) 0.275 lbs
(125 g)

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.



NOTES



Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor,
Fort Worth, TX 76102

We Service What We Sell

12/99

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

03A00

9WM014
Printed in China

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>