

Enjoy Softened Water Throughout Your Home



In the bathroom . . .




In the kitchen . . .



In the laundry . . .

Economical Water Conditioning System <u>SAVES You Money!</u>


- Eliminate Soap Scum
- Save on Cleaning Products
- Clothes Wash Up Cleaner
- Soft, Lustrous Hair
- Water Using Appliances Last Longer
- Increases Water Heater Efficiency



• Meter Demand

• Utilizes 100% of Available Capacity


• Easily Adjustable Regeneration Cycles







WaterMate-3 Water Conditioning System



- Meter Demand
- Soft Water 24-Hours Per Day
- 110-Volt Operation
- Utilizes 100% of available capacity, no wasted reserve.
- No time clock to set.
- Easily adjustable regeneration settings.
- Time controlled brine refill for efficient salt usage.
- Soft water regeneration increases efficiencies and keeps your salt tank cleaner.
- Uses less than \$2.00 of electricity per year.
- Optional 24 Volt Solid State Controller

How Does A Water Softener Work?

- . Hard water enters your water softener (1) and passes down through the ion exchange resin, which are charged with sodium ions. The hard water ions (calcium and magnesium) are attracted to the ion exchange resin and an equal amount of sodium ions are bumped off into the water supply. When the water reaches the bottom of the tank, it is softened and ready to be used in your home and business.
- 2. When the ion exchange resin for the tank in service is saturated with calcium and magnesium (hard water ions) it must be recharged. The controller automatically places the "stand-by unit" tank into service and switches the tank that is in need of recharging into regeneration. (2) A strong brine solution enters the tank and flushes the calcium and magnesium ions off the ion exchange resin and attaches itself.
- A final rinse process ensures that any unused brine is rinsed from the system. This tank is now fully recharged and placed on stand-by, ready to provide you with soft water when the other tank becomes exhausted.

Specifications

DEMAND MODEL NAME	MINERAL CU.FT.	LOW SALT GRAINS/LBS	CAPACITY MED. SALT GRAINS/LBS	HIGH SALT GRAINS/LBS	SERVICE FLOW RATING GPM/PSI	MINERAL TANK (INCHES)	BRINE TANK SIZE (INCHES)	SALT STORAGE (POUNDS)	FLOOR SPACE (WxHxD)	MODEL NAME
WM3-16	0.50	10,400/3.0	13,600/5.0	16,400/7.5	6.1/5.3	7 x 44	18 x 33	300	36x48x19	WM3-16
WM3-24	0.75	15,500/4.5	20,400/7.5	24,600/11.3	8.4/7.5	8 x 44	18 x 33	300	38x52x19	WM3-24
WM3-32	1.00	20,700/6.0	27,200/10.0	32,800/15.0	10.0/8.8	9 x 48	18 x 33	300	40x56x19	WM3-32
WM3-48	1.50	31,100/9.0	40,800/15.0	49,200/22.5	9.7/8.4	10 x 54	18 x 33	375	42x62x19	WM3-48
WM3-64	2.00	41,400/12.0	54,400/20.0	65,600/30.0	12.0/9.9	13 x 54	18 x 40	375	46x56x19	WM3-64
WM3-96	3.00	62,100/18.0	81,600/30.0	98,400/45.0	12.0/9.2	14 x 65	18 x 40	375	50x73x19	WM3-96

- These conditioners are designed for hardness removal and limited amounts of "ferrous bicarbonate" iron.
- 2. See owners manual for specific operating details.
- 3. These conditioners will not purify or make your water safe to drink.
- 4. Product improvements and design changes subject to change without notice.

HELLENBRAND WARRANTY

Ask your WaterMate Series Dealer for full details.

Dealer Information:



Hellenbrand, Inc.

404 Moravian Valley Road Waunakee, WI 53597 www.hellenbrand.com Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com