Notice to Installers

The servicing instructions in this notice are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions, unless you are qualified to do so.

Note to System Installer

For this apparatus, the coaxial cable shield/screen shall be grounded as close as practical to the point of entry of the cable into the building. For products sold in the US and Canada, this reminder is provided to call the system installer's attention to Article 820-93 and Article 820-100 of the NEC (or Canadian Electrical Code Part 1), which provides guidelines for proper grounding of the coaxial cable shield.



This symbol is intended to alert you that uninsulated voltage within this product may have sufficient magnitude to cause electric shock Therefore, it is dangerous to make any kind of contact with any inside part of this product.

Ce symbole a pour but d'alerter toute personne qu'un contact avec une pièce interne de ce produit, sous tension et non isolée, pourrait être suffisant pour provoquer un choc électrique. Il est donc dangereux d'être en contact avec toute pièce interne de ce produit



CAUTION: To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.

WARNING TO PREVENT FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE



This symbol is intended to alert you of the presence of important operating and maintenance (servicing) instructions in the literature accompanying this product.

Ce symbole a pour but de vous avertir qu'une documentation importante sur le fonctionnement et l'entretien accompagne ce produit.

20070131 SysInstaller 820 US/Canada/Intl

Verify the Power Source from the On/Off Power Light

When the on/off power light is not illuminated, the apparatus may still be connected to the power source. The light goes out when the apparatus is turned off, regardless of whether it is still plugged into an AC power source.

Eliminate AC Mains Overloads





Prevent Power Cord Damage

Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where the cord exits from the apparatus

Provide Ventilation and Select a Location

- · Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- · Do not place this apparatus on a bed, sofa, rug, or similar surface.
- · Do not place this apparatus on an unstable surface
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat
- · Do not install this apparatus in an enclosure, such as a bookcase or rack, unless the installation provides proper ventilation
- · Do not place entertainment devices (such as VCRs or DVDs), lamps, books, vases with liquids, or other objects on top of this product.

Protect from Exposure to Moisture and Foreign Objects Do not use this apparatus near water

WARNING: Avoid electric shock and fire hazard! Do not expose this product to liquids, rain, or moisture

WARNING: Avoid electric shock and fire hazard! Unplug this product before cleaning. Clean only with a dry cloth. Do not use a liquid cleaner or an aerosol cleaner. Do not use a magnetic/static cleaning device (dust remover) to clean this product.

WARNING: Avoid electric shock and fire hazard! Never push objects through the openings in this product. Foreign objects can cause electrical shorts that can result in electric shock or fire.

WARNING: Avoid electric shock and fire hazard! Only use attachments/accessories specified by your service provider or the manufacture

Service Warnings



WARNING: Avoid electric shock! Do not open the cover of this product. Opening or removing the cover may expose you to dangerous voltages. If you open the cover, your warranty will be void. This product contains no user-serviceable parts. Refer all servicing to qualified service perso

Servicing is required when the apparatus has been damaged in any way, such as a power-supply cord or plug is damaged liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture,

Check Product Safety

Upon completion of any service or repairs to this product, the service technician must perform safety checks to determine that this product is in proper operating condition

......... **CISCO**

Cisco Explorer 4540HDC and 4550HDC Set-Top with Multi-Stream CableCARD Interface



Protect the Product when Moving It

Always disconnect the power source when moving the apparatus or connecting or disconnecting cables



WARNING: Avoid personal injury and damage to this product! Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.

20070802 Set-Top Cable US & Canada

the FCC Rules. These limits are designed to provide reasonable protection against such interference in a residentia installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures.

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the cable company or an experienced radio/television technician for help

Any changes or modifications not expressly approved by Scientific-Atlanta, Inc., could void the user's authority to operate the equipment

The information shown in the FCC Declaration of Conformity paragraph below is a requirement of the FCC and is intended to supply you with information regarding the FCC approval of this device. The phone numbers listed are for FCC-related questions only and not intended for questions regarding the connection or operation for this device. Please contact your cable service provider for any questions you may have regarding the operation or installation of this device.



This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: 1) the device may not cause harmful interference, and 2) the device must accept any interference received, including interference that may cause undesired operation.

> Explorer 4540HDC and 4550HDC Models: 4540HDC and 4550HDC Manufactured by: Scientific-Atlanta, Inc 5030 Sugarloaf Parkway Lawrenceville Georgia 30044 USA Telephone: 770-236-1077

Canada EMI Regulation

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la class B est conforme à la norme NMB-003 du Canada

Download from Www.Somanuals.com, All Manuals Search And Download

Accessories Warnings

does not operate normally, or has been dropped.

protection against voltage surges and built-up static charges. **Outdoor Grounding System** If this product connects to an outdoor antenna or cable system, be sure the antenna or cable system is grounded (earthed).

nt of the

This provides some protection against voltage surges and built-up static charges

If this product connects to coaxial cable wiring, be sure the cable system is grounded (earthed). Grounding provides some

outlet with the voltage and frequency indicated on the product label. If you are uncertain of the type of power supply to

WARNING: Avoid electric shock and fire hazard! Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the

Article 810 of the National Electric Code (NEC) ANSI/NFPA No. 70-1990, provides the following information

- Grounding of the mast and supporting structure
- · Grounding the lead-in wire to an antenna discharge unit

IMPORTANT SAFETY INSTRUCTIONS

your home or business, consult your service provider or your local power company.

ded plug does not fit into your outlet, consult an electrician for rep

The AC inlet on the unit must remain accessible and operable at all times

Read These Instructions

Keep These Instructions

Follow All Instructions

Power Source Warning


Ground the Product

Heed All Warnings

- · Size of the grounding conductors
- · Location of the antenna-discharge unit
- · Connection to arounding electrodes

· Requirements for the grounding electrodes (see the following antenna grounding diagram as recommended by NEC ANSI/NEPA 70)

WARNING: Avoid electric shock and fire hazard! Do not locate an outside antenna system in the ricinity of overhead power lines or power circuits. Touching power lines or circuits might be fai



Protect the Product from Lightning

For added protection, unplug this apparatus during lightning storms or when unused for long periods of time. In addition to disconnecting the AC power from the wall outlet, disconnect the signal inputs.

United States FCC Compliance

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of



Disclaimer

Cisco Systems, Inc. assumes no responsibility for errors or omissions that may appear in this guide. We reserve the right to change this guide at any time without notice



AVC VIDEO LICENSE

With respect to each AVC/MPEG-4/H.264 product, we are obligated to provide the following notice:

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://WWW.MPEGLA.COM.

Accordingly, please be advised that service providers, content providers, and broadcasters are required to obtain a separate use license from MPEG LA prior to any use of AVC/MPEG-4/H.264 encoders and/or decoders.



Scientific Atlanta, A Cisco Company 5030 Sugarloaf Parkway, Box 46544 Lawrenceville, GA 30042

770.236.500

www.scientificatlanta.com

Cisco, Cisco Systems, the Cisco logo, the Cisco Systems logo, Scientific Atlanta, and Explorer are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

CableCARD and M-Card are trademarks of Cable Television Laboratories. Inc.

HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC All other trademarks mentioned in this document are the property of their respective owners.

Product and service availability is subject to change without notice © 2007, 2008 Cisco Systems, Inc. All rights rese

March 2008

Welcome

The Cisco Explorer 4540HDC (digital-only tuning) and 4550HDC (analog and digital tuning) set-tops deliver high-definition programming with exceptional picture and audio quality. Through the 4540HDC and 4550HDC you can also access interactive services, such as video-ondemand and pay-per-view programs. Contact your service provider for information about these and other available services. Use the instructions in this guide to install the 4540HDC or the 4550HDC and to access your program services.

The consumer support website provides news and information about this product. For more information, please refer to www.scientificatlanta.com/products/consumers/new_cableboxes.htm

Safetv First

Before using this set-top, read the IMPORTANT SAFETY INSTRUCTIONS section of this guide

Watch TV

Press the following remote control keys to access services and programs:

- · Guide-Display the on-screen program guide
- · Arrows-Highlight a program in the schedule
- · Info-Display program description
- · Select-Watch a specific program in the guide

Avoid Screen Burn-In

Images such as letterbox bars or side bars, bright closed-captioning backgrounds, station logos, or any other stationary images may cause the HDTV screen to age unevenly and cause damage to your HDTV. Refer to the user's guide that came with your HDTV for more information about screen burn-in.

Automatic Software Updates

A message appears on the TV screen when the set-top and the Multi-Stream CableCARD™ (M-Card™) module are receiving software updates. In addition, download information also appears on the front panel of the set-top during these updates. Wait for the current time to display on the front panel before continuing. When the time appears, the update is complete.

Performance Tips

If the set-top does not perform as expected, the following tips may help.

No picture

- · Verify that the M-Card module is installed
- · Verify that the power to your TV is turned on.
- · If the set-top is plugged into a wall switch, verify the switch is in the ON position. (Avoid plugging into an outlet that is controlled by a wall switch.)
- · Verify that all cables are properly connected.
- The current channel may not be available in your service package. Try selecting another channel to see if a picture appears.

No color

- · Verify that the HDTV is in HD mode. If necessary, re-run the HDTV Setup Wizard to select HD mode.
- · Verify the current TV program is broadcast in color.
- · Adjust the TV color controls.

No sound

- If your setup includes a VCR or stereo, verify that you have properly connected them to the set-top.
- · Verify the volume is turned up.
- · Verify the mute function is not on.

Front Panel Features

3 Select

5 Guide

6 Info

7 Exit

8 Settings

10 Power

9 IR Sensor

11 USB Port

3 Cable Out

4 Audio Out

8 IR

(Left, Right)

9 S-Video Out

10 Optical Audio

Output


12 Ethernet

13 USB

11 HDMI


Video/Audio Out)

4 LED Display



- 2 CH+, CH -
 - Scrolls up and down through the channels
 - Provides access to your on-screen selection
 - Displays the selected channel number and time of day. The LED also displays the following:
 - Message (= _) HDTV
 - Power (())
 - Output Resolution (1080i, 720p, 480p, or 480i)
 - · AUTO Automatically outputs native scan rates that your TV can accept
 - Accesses on-screen services, such as the on-screen guide, video-on-demand, or pay-per-view
 - Displays a description of the selected program. This button is available from the on-screen guide and while viewing a program
 - Exits menus, the on-screen guide, and program information
 - Provides access to the Settings menu
 - Receives the infrared signal from the remote control
 - Turns the set-top on and off
 - Connects to external equipment, such as a keyboard or mouse (reserved for future use)

Back Panel Connections



- Slot for M-Card module, which decrypts subscription digital channels. This set-top will not operate correctly without
- 2 Cable In

 - These signals are standard-definition TV (SDTV) video and stereo audio
 - Connects to RCA cables that send analog audio signals (left and right) to the stereo inputs on a TV
- 6 Digital Audio Out Connects to an RCA cable that sends a digital audio signal to a surround-sound receiver or other digital audio device
- 7 Out 2 (Secondary Connects to either a VCR or to another set of inputs (composite) on your TV

 - Connects to an S-Video cable that sends an S-Video signal to your TV or VCR. This signal is standard definition, but higher quality than other SDTV connections
 - May be used to connect to a DVI interface using an HDMI-to-DVI adaptor for video and separate audio connections. Any of the following audio connections may be used: Audio Out: Left, Right (4); Digital Audio Out (6); or Optical Audio Output (10)
 - Connects to an Ethernet network
 - Connects to external USB devices such as a keyboard or a mouse
- 14 1394 Firewire Connects to display devices that are equipped with a 1394 input
- 15 AC Power Input Connects to the power cord to deliver power to the set-top
- 16 AC Outlet Connects to the AC power cord from another device, such as a TV

Connecting to an HDTV with Component Input (YPbPr)

Use the connection diagram and follow these steps to connect the set-top to an HDTV that has a component video connector (YPbPr) and an audio left/right connector.

- 1. Insert the M-Card module if not already installed.
- 2. Connect the set-top to the coaxial cable coming from the wall
- connector on the HDTV to the right audio (red) connector on the set-top.
- 5. Plug the set-top and the HDTV into an AC power source. lightning storms and power outages, by plugging the set-top into a surge protector.
- displays on the front panel of the set-top, that indicates that the update is complete: Current time
 Four dashes (----)

Explorer 4540HDC and 4550HDC

Safety and Performance Tips • Keep the top of the set-top free of

- all objects and electronic devices, including your TV.
- Always set the set-top on its feet, never on its side

Note: This illustration may vary from the actual product.

WARNING Electric shock hazard! Unplug all electronic devices before connecting or disconnecting any device cables to the set-top.

Cable Input

U.S. Patents

4,498,169; 4,692,919; 4,748,667; 4,829,569; 4,866,770; 4,885,775; 4,888,799; 4,890,319; 4,922,456; 4,922,532; 4,924,498; 4,965,534; 4,991,011; 5,003,384; 5,012,510; 5,029,207; 4,848,109; 4,940,100; 4 5,255,086; 5,257,403; 5,267,071; 5,270,809; 5,271,041; 5,272,752; 5,282,028; 5,285,497; 5,287,351; 5,301,028; 5,309,514; 5,317,391; 5,319,709; 5,341,425; 5,347,388; 5,347,389; 5,387,389; 5,387,389; 5,380; 5,387,389; 5,387,389; 5,387,389; 5,387,389; 5,387,389; 5,387 5,357,276; 5,359,601; 5,361,156; 5,367,571; 5,379,141; 5,379,145; 5,381,481; 5,390,337; 5,400,401; 5,406,558; 5,418,782; 5,420,866; 5,420,923; 5,425,101; 5,428,404; 5,430,568; 5,420,401; 5,400,401; 5,400,558; 5,418,782; 5,420,866; 5,420,923; 5,425,101; 5,428,404; 5,430,568; 5,420,401; 5,400,400; 5,400,400; 5,400,400; 5,400,400; 5,40 5,434,610; 5,436,749; 5,438,370; 5,440,632; 5,442,472; 5,455,570; 5,457,701; 5,471,492; 5,477,199; 5,477,262; 5,477,282; 5,477,370; 5,481,389; 5,481,542; 5,485,221; 5,493,339; 5,497,187; 5,500,758; 5,502,499; 5,506,904; 5,519,780; 5,539,822; 5,550,825; 5,579,055; 5,579,057; 5,583,562; 5,592,551; 5,596,606; 5,600,378; 5,602,933; 5,640,388; 5,657,414; 5,602,933; 5,640,388; 5,657,414; 5,640,388; 5,660,388; 5 5,675,575; 5,684,876; 5,715,515; 5,724,525; 5,734,822; 5,740,300; 5,742,677; 5,754,940; 5,757,416; 5,771,064; 5,774,859; 5,825,829; 5,826,167; 5,850,305; 5,854,703; 5,870,474; 5,757,416; 5,771,064; 5,774,859; 5,825,829; 5,826,167; 5,850,305; 5,854,703; 5,870,474; 5,757,416; 5,771,064; 5,774,859; 5,825,829; 5,826,167; 5,850,305; 5,854,703; 5,870,474; 5,757,416; 5,771,064; 5,774,859; 5,825,829; 5,826,167; 5,850,305; 5,854,703; 5,870,474; 5,870,474; 5,870,474; 5,870,474; 5,870,476; 5,870,470; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870; 5,870 5.892.607; 5.920.626; 5.923.755; 5.930.024; 5.930.515; 5.937.067; 5.963.352; 5.966.163; 5.982.424; 5.991.139; 5.999.207; 6.005.631; 6.005.938; 6.016.163; 6.028.941; 6.029.046; 6 052 384: 6 055 244: 6 072 532: 6 105 134: 6 148 039: 6 157 719: 6 188 729: 6 195 389: 6 212 278: 6 215 530: 6 219 358: 6 240 103: 6 243 145: 6 246 767: 6 252 964: 6 272 226: 6.292.081: 6.292.568: 6.320.131: 6.374.275: 6.405.239: 6.411.602: 6.417.949: 6.424.714: 6.424.717: 6.433.906: 6.438.139: 6.463.586: 6.467.091: 6.476.878: 6.493.876: 6.510.519: 6,516,002; 6,516,412; 6,526,508; 6,538,595; 6,546,013; 6,560,340; 6,567,118; 6,570,888; 6,622,308; 6,629,227; 6,664,984; 6,667,994; 6,671,879; 6,674,967; 6,678,891; 6,714,598; 6,674,967; 6,678,912; 6,674,912; 6,744; 6,744,912; 6,744,912; 6,744,912; 6,744,912; 6,744,912; 6,744 6.721.352; 6.721.956; 6.725.459; 6.738.982; 6.744.892; 6.744.967; 6.751.271; 6.760.918; 6.795.972; 6.802.077; 6.804.708; 6.811.447; 6.817.028; 6.822.972; 6.823.385; 6.832.386; 6.845,106; 6.868,473; 6.874,075; 6.889,191; 6.909,471; 6.917,622; 6.917,628; 6.922,412; 6.927,806; 6.928,656; 6.931,058; 6.937,729; 6.969,279; 6.971,008; 6.971,121; 6.978,310; 6,986,156; 6,988,900; 6,996,838; 7,010,801; 7,053,960; 7,065,213; 7,069,578; 7,069572; D348065; D354959; D359737; D363932; D390217; D434753; D507240; D507535; D513407; D516518; RE36368; RE36988

1 Multi-Stream CableCARD an M-Card module. Obtain an M-Card module from your service provider

- Connects to a coaxial cable that delivers the signal from your service provider Connects to a coaxial cable that sends analog audio and video signals to a TV or VCR.
- 5 HDTV (PrPbY/V) Connects to the component video input (YPbPr) on the HDTV, when in HD mode

 - Connector reserved for future use
 - - Connects to an optical cable that sends a digital audio signal to a surround-sound receiver or other digital audio device
 - Connects an HDMI[™] cable to the HDMI input of an HDTV. HDMI supports both digital audio and video.

3. Connect the Y (green) connector on the HDTV to the Y (green) connector on the set-top; connect the Pb (blue) connector on the HDTV to the Pb (blue) connector on the set-top; and connect the Pr (red) connector on the HDTV to the Pr (red) connector on the set-top.


4. Connect the left audio (white) connector on the HDTV to the left audio (white) connector on the set-top, and connect the right audio (red)

Important: To potentially protect the set-top from power surge damage, ground (earth) your cable product to provide some protection against voltage surges and built-up static charges. You may be able to reduce the risk of damage from voltage surges, which can be caused by

6. Wait several minutes for the set-top to receive the latest software, programming, and service information. When you see one of the following

Note: If four dashes are displayed, you must call your service provider to get the set-top authorized.

7. To begin watching TV, turn on the HDTV and press Power on the front panel of the set-top, or press Power on the remote control.



T13037

A patent notice is affixed to this product. In addition, the product may also be covered by one or more of the following patents:

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com