



Cisco 12000/10700 v3.1.1 Router Manager User Guide

Software Release 3.1.1

Corporate Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Text Part Number: OL-4455-01



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCIP, CCSP, the Cisco Arrow logo, the Cisco *Powered* Network mark, Cisco Unity, Follow Me Browsing, FormShare, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherSwitch, Fast Step, GigaStack, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, MGX, MICA, the Networkers logo, Networking Academy, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, RateMUX, Registrar, ScriptShare, SlideCast, SMARTnet, StrataView Plus, Stratm, SwitchProbe, TeleRouter, The Fastest Way to Increase Your Internet Quotient, TransPath, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries.

All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0304R)

Cisco 12000/10700 v3.1.1 Router Manager User Guide
Copyright © 2003 Cisco Systems, Inc. All rights reserved.



About This Guide	xxv
Document Audience	xxv
Document Organization	xxvi
Conventions	xxviii
Command Conventions	xxviii
Example Conventions	xxviii
Document Conventions	xxix
Obtaining Documentation	xxix
Cisco.com	xxix
Documentation CD-ROM	xxx
Ordering Documentation	xxx
Documentation Feedback	xxx
Obtaining Technical Assistance	xxxi
Cisco.com	xxxi
Technical Assistance Center	xxxi
Cisco TAC Website	xxxii
Cisco TAC Escalation Center	xxxii
Obtaining Additional Publications and Information	xxxii

CHAPTER 1

Overview	1-1
Cisco Element Manager Framework (Cisco EMF) Software	1-2
Cisco 12000/10720 Router Manager Software	1-2
Key Features of the Cisco 12000/10720 Router Manager Software	1-2
Accessing Online Help	1-4

CHAPTER 2

Concepts	2-1
Cisco 12000/10720 Router Manager Objects and Interfaces	2-1
Physical Objects	2-2
Cisco 12000/10720 Router Chassis	2-3
Supporting Modules	2-5
Linecards	2-5
Physical Interfaces and Technologies	2-5
Logical Objects	2-6
Use of Telecom Graphics Objects	2-7

- OSI Mappings 2-10
- Views 2-11
 - Component Managed View 2-11
 - Layer 3 QoS View 2-12
 - Network View 2-12
 - Physical View 2-12
 - VLAN View 2-12
- Cisco 12000/10720 Router Manager Object States 2-13
 - Decommissioned State 2-14
 - Normal State 2-14
 - Errored 2-14
 - Performance Logging On 2-14
 - Lost Comms 2-15
 - Discovery Lost Comms 2-15
 - Mismatched 2-15
 - Transient Object States 2-15

CHAPTER 3

Getting Started 3-1

- Cisco 12000/10720 Router Manager Workflow 3-1
- Starting Cisco EMF and Cisco 12000/10720 Router Manager 3-3
 - Starting a Cisco EMF User Session 3-3
 - Launchpad 3-5
 - Launching an Application 3-5
 - Map Viewer (Viewer) 3-6
 - Groups 3-6
 - Access 3-6
 - Event Browser (Events) 3-6
 - Discovery 3-6
 - Notification Profiles 3-7
 - Thresholding Regimes 3-7
 - Event Groups 3-7
 - PreFilter 3-8
 - Quitting a Cisco EMF User Session 3-8
- Deployment 3-8
 - Deployment Process Outline 3-9
 - Manually Deploying a Generic Site Object 3-10
 - IP Auto Discovery of the Cisco Chassis 3-19
 - Manually Deploying a Cisco 12000/10720 Chassis 3-20
 - Commissioning and Subchassis Discovery 3-26

Commissioning a Chassis	3-27
Decommissioning a Chassis	3-30
Object States	3-30
Manually Deploying Modules	3-30
User Named vs. Auto Named Module Deployment	3-31
Manually Deploying a GRP Card	3-31
Manually Deploying Line Cards	3-38
Manually Deploying Supporting Modules	3-50
Pre-deployment	3-58
Performing Pre-deployment	3-59

CHAPTER 4

Managing Chassis 4-1

Launching the Chassis Management Windows	4-2
Management Information	4-3
Viewing the Management Information Window	4-3
System Configuration	4-4
Entering or Changing IOS CLI Username and Passwords	4-5
Management Information Window—Detailed Description	4-6
Configuration Tab	4-6
IOS/Command Line Security Tab	4-6
Chassis Configuration	4-7
Viewing the Chassis Configuration Window	4-7
Commissioning a Chassis	4-8
Decommissioning a Chassis	4-8
Starting Global Performance Logging	4-9
Stopping Global Performance Logging	4-10
Entering Additional Descriptions for a Selected Chassis	4-11
Device Management Tab in Configuration Window	4-12
Chassis Configuration Window—Detailed Description	4-13
Configuration Tab	4-13
Additional Descriptions Tab	4-14
Device Management Tab	4-14
SNMP Management	4-14
Viewing the SNMP Management Window	4-15
Modifying SNMP Community Names or Version	4-15
Enabling or Disabling Trap Generation	4-16
SNMP Management Window—Detailed Description	4-16
Community Names	4-16
Version	4-17

- Trap Generation 4-17
- Chassis Inventory 4-17
 - Viewing the Chassis Inventory Window 4-17
 - Chassis Inventory Window—Detailed Description 4-18
 - General Tab 4-18
 - Asset Tracking Tab 4-19
- Chassis Fault Management 4-20
 - Viewing the Chassis Fault Management Window 4-20
 - Changing Column Width 4-24
 - Chassis Fault Management Window—Detailed Description 4-25
 - General Tab 4-25
 - Power Supply Tab 4-25
 - Temperature Tab 4-26
 - Fan Tab 4-26
- Command Log 4-27
 - Viewing the Command Log Window 4-27
 - Command Log Window—Detailed Description 4-28
 - Command Log Details Tab 4-28
- System Log 4-29
 - Viewing the SysLog Messages Window 4-29
 - System Log Window—Detailed Description 4-30
 - SysLog Message Tab 4-30
- Using RME for Chassis Management Tasks 4-31
 - Configuration Backup/Restore Using RME 4-32
 - IOS Image Download Using RME 4-32
- APS Status 4-32
 - Viewing the APS Status Window 4-32
 - APS Status Window—Detailed Description 4-34
 - APS Circuits Area 4-34
- Initiating a Telnet Service 4-34
- Launching the Web Console 4-35
- Configuration Editor 4-35
 - Viewing the Configuration Editor Window 4-35
 - Downloading, Opening, or Editing the Running Configuration from a Selected Chassis 4-36
 - Searching in the Configuration Editor 4-37
 - Downloading the Edited Configuration File to a Selected Chassis 4-37
 - Configuration Editor Window—Detailed Description 4-37
 - Configuration Editor Tab 4-37
- RPR Configuration 4-38

Viewing the RPR Configuration Window	4-38
RPR Configuration Window—Detailed Description	4-39
Configuration Tab	4-39
Switch Over Tab	4-40
RPR Status	4-40
Viewing the RPR Status Window	4-40
RPR Status Window—Detailed Description	4-41
RP Status	4-41
LC Status	4-42
IP Routing Status	4-42
Viewing the IP Routing Status window	4-42
IP Routing Status Window—Detailed Description	4-43
Classless Inter-Domain Routing Tab	4-43
TCP Status	4-44
Viewing the TCP Status Window	4-45
TCP Status Window—Detailed Description	4-46
TCP Status Tab	4-46
TCP Connections Tab	4-47
UDP Status	4-48
Viewing the UDP Status Window	4-48
UDP Status Window—Detailed Description	4-49
Status	4-49
CHAPTER 5	
Managing Modules	5-1
Cisco 12000/10720 Router Manager Module Names	5-1
Launching the Module Management Windows	5-2
Module Configuration	5-3
Viewing the Configuration Window	5-3
Commissioning a Selected Module	5-4
Decommissioning a Selected Module	5-5
Module Configuration Window—Detailed Description	5-7
Configuration Tab	5-7
Module Fault Management	5-7
Viewing the Module Fault Management Window	5-7
Module Fault Management Window—Detailed Description	5-8
Module Availability	5-8
Cisco Contact Details	5-9
Module Performance	5-9
Viewing the Module Performance Window	5-10

- Starting or Stopping Performance Logging 5-10
- Module Performance Window—Detailed Description 5-11
 - CPU Usage 5-11
 - Performance Logging 5-11
- Module Inventory 5-12
 - Viewing the Module Inventory Window 5-12
 - Module Inventory Window—Detailed Description 5-13
 - General 5-13
 - Asset Tracking 5-14

CHAPTER 6

Managing Interfaces 6-1

- Cisco 12000/10720 Router Manager Interface Naming Conventions 6-1

CHAPTER 7

Interface Profiles 7-1

- Interface Profile Types 7-2
- Launching the Interface Profile Windows 7-2
- Creating an ATM Interface Profile 7-3
 - Editing an Existing ATM Interface Profile 7-6
 - Deleting an Existing ATM Interface Profile 7-6
 - ATM Interface Configuration Profile Window—Detailed Description 7-7
 - Configuration (1) Tab 7-7
 - Configuration (2) Tab 7-8
- Creating an HSRP Profile 7-9
 - Editing an Existing HSRP Interface Profile 7-10
 - Deleting an Existing HSRP Interface Profile 7-11
 - HSRP Profile Window—Detailed Description 7-11
 - HSRP Profile Parameters Area 7-11
 - Actions 7-12
- Creating a POS Interface Profile 7-12
 - Editing an Existing POS Interface Profile 7-14
 - Deleting an Existing POS Interface Profile 7-15
 - POS Profile Window—Detailed Description 7-15
 - POS Config Tab 7-15
- Creating a SRP Side Profile 7-17
 - Editing an Existing SRP Side Profile 7-19
 - Deleting an Existing SRP Side Profile 7-19
 - SRP Side Profile Window—Detailed Description 7-20
 - General Tab 7-20
 - Alarms Tab 7-21

Interface Configuration 8-1

Interfaces and Related Technology-Specific Windows	8-1
Launching the Interface Configuration Windows	8-2
Generic Interface Configuration	8-3
Viewing the Generic Interface Configuration Window	8-4
Configuring and Commissioning a Generic Interface	8-4
Decommissioning an Interface	8-5
Generic Interface Configuration Window—Detailed Description	8-5
Configuration Tab	8-5
ATM Interface Configuration	8-6
Viewing the ATM Interface Configuration Window	8-6
Configuring an ATM Interface	8-7
ATM Interface Configuration Window—Detailed Description	8-8
Configuration (1) Tab	8-8
Configuration (2) Tab	8-9
Ethernet Interface Configuration	8-9
Viewing the Ethernet Interface Configuration Window	8-10
Configuring an Ethernet Interface	8-11
Ethernet Interface Configuration Window—Detailed Description	8-12
Configuration Tab	8-12
HSRP Parameters Tab	8-12
IP Configuration	8-13
Viewing the IP Configuration Window	8-14
Configuring an IP Interface	8-14
IP Configuration Window—Detailed Description	8-15
Generic Parameters Tab	8-15
POS Interface Configuration	8-15
Viewing the POS Interface Configuration Window	8-15
Configuring a POS Interface	8-16
POS Interface Configuration Window—Detailed Description	8-17
POS Config Tab	8-17
APS Interface Configuration	8-18
Viewing the APS Configuration Window	8-19
Adding a Working Interface	8-20
Removing a Working Interface	8-20
Adding a Protected Interface	8-20
Removing a Protected Interface	8-20
APS Configuration Window—Detailed Description	8-21
APS Tab	8-21

- APS Interface 8-21
 - SRP Interface Configuration 8-22
 - Viewing the SRP Interface Configuration Attributes 8-22
 - Configuring a SRP Interface 8-23
 - SRP Interface Configuration Window—Detailed Description 8-23
 - General 8-23
 - IPS 8-23
 - SRP Interface Side Configuration 8-24
 - Viewing the SRP Interface Side Configuration Attributes 8-24
 - Configuring a SRP Side 8-25
 - SRP Interface Side Configuration Window—Detailed Description 8-26
 - General Tab 8-26
 - Alarms Tab 8-27

CHAPTER 9

Interface Status 9-1

- Interfaces and Related Technology-Specific Windows 9-1
- Launching the Interface Status Windows 9-2
- Generic Interface Status 9-3
 - Viewing the Generic Interface Status Window 9-3
 - Generic Interface Status Window—Detailed Description 9-4
 - Interface Details 9-4
 - Last Change Details 9-4
 - Transmission Details 9-4
- ATM Interface Status 9-5
 - Viewing the ATM Interface Status Window 9-5
 - ATM Interface Status Window—Detailed Description 9-6
 - ATM Transmit Status 9-6
 - ATM Receive Status 9-7
 - Physical Layer Status 9-7
 - ATM Port Status 9-7
 - Action 9-7
- ATM Interface Faults 9-8
 - Viewing the ATM Interface Faults Window 9-8
 - ATM Interface Faults Window—Detailed Description 9-9
 - Fault Tab 9-9
- DS3/E3 Interface Status 9-9
 - Viewing the DS3/E3 Interface Status Window 9-9
 - DS3/E3 Interface Status Window—Detailed Description 9-10
 - Status Tab 9-10

SONET Interface Status	9-12
Viewing the SONET Interface Status Window	9-12
SONET Status Window—Detailed Description	9-16
Medium	9-16
Section	9-16
Line	9-16
Path	9-16
Virtual Tributary	9-17
SRP Interface Status	9-17
Viewing the SRP Interface Status Attributes	9-17
SRP Interface Status Window—Detailed Description	9-18
Interface Tab	9-18
Side A Frame	9-18
Side B Frame	9-18
SRP Side IPS Status	9-19
Viewing the IPS Status Attributes	9-19
IPS Status Window—Detailed Description	9-20
IPS Status	9-20
Remote Node	9-20
SRP Topology Map	9-20
Viewing the SRP Topology Map	9-20
SRP Topology Map—Detailed Description	9-21
Topology Map	9-21
CHAPTER 10	
Interface Performance	10-1
Interfaces and Related Technology-Specific Windows	10-1
Launching the Interface Performance Windows	10-2
Generic Interface Performance	10-3
Viewing the Generic Interface Performance Window	10-3
Starting Performance Logging for a Selected Interface	10-5
Stopping Performance Logging for a Selected Interface	10-7
Generic Interface Performance Window—Detailed Description	10-8
Performance (1) Tab	10-8
Performance (2) Tab	10-9
Performance (3) Tab	10-10
SONET Interface Performance	10-10
Viewing the SONET Interface Performance Window	10-10
SONET Performance Window—Detailed Description	10-14
Section Tab	10-14

- Line Tab 10-14
- Path Tab 10-15
- Virtual Tributary Tab 10-15
- DS3/E3 Interface Performance 10-15
 - Viewing the DS3/E3 Interface Performance Window 10-15
 - DS3/E3 Interface Performance Window—Detailed Description 10-17
 - DS3 Performance Tab 10-17
 - E3 Performance Tab 10-18
- Ethernet Interface Performance 10-19
 - Viewing the Ethernet Interface Performance Window 10-19
 - Ethernet Interface Performance Window—Detailed Description 10-20
 - General Statistics 10-20
 - Collision Statistics 10-20
- SRP Performance 10-21
 - Viewing the SRP Performance Window 10-21
 - SRP Performance Window—Detailed Description 10-24
 - Interface Tab 10-25
 - Outer Ring Tab 10-26
 - Inner Ring Tab 10-27
 - Side Tab 10-28
- SRP Side Performance 10-28
 - Viewing the SRP Side Performance Window 10-29
 - SRP Side Performance Window—Detailed Description 10-31
 - Ring Tab 10-31
 - Host Tab 10-32
 - Errors Tab 10-33

CHAPTER 11

Layer 3 QoS 11-1

- Launching the Layer 3 QoS Windows 11-1
- CAR and WRED Overview 11-3
 - Access Lists 11-3
 - Committed Access Rate (CAR) 11-3
 - Weighted Random Early Detection (WRED) 11-3
 - Towards the Fabric (ToFab) 11-4
 - MDRR Overview 11-4
 - MDRR in Cisco 12000/10720 Router Manager 11-4
 - Implications of Engine Type 11-5
 - CAR and WRED in Cisco 12000/10720 Router Manager 11-5
- The Workflow for CAR 11-6

CAR Policy Configuration	11-6
Per Interface Rate Control (PIRC) Support	11-6
Limited Support for Engine 4	11-7
Creating a CAR Policy	11-7
Applying an Access List to a CAR Policy	11-8
CAR Policy Configuration Window—Detailed Description	11-9
CAR Policy Configuration Tab	11-9
Exceed Action	11-10
Access List Configuration	11-10
Creating Access Lists	11-10
Access List Configuration Window—Detailed Description	11-12
General Tab	11-12
IP Standard Tab	11-13
IP Precedence Tab	11-14
MAC	11-15
IP Extended Tab	11-16
CAR Policy Apply	11-18
Applying a CAR Policy to an Interface	11-18
Removing a CAR Policy from an Interface	11-19
Editing or Deleting a CAR Policy	11-19
CAR Policy Apply Window—Detailed Description	11-20
CAR Policy Apply Tab	11-20
CAR Policy Status	11-21
Viewing the CAR Policy Status Window	11-21
The Workflow for WRED/DRR	11-22
Engine Type Support for WRED	11-22
CoS Queue Group Configuration	11-23
Creating a CoS Queue Group Under WRED	11-23
Editing an Existing CoS Queue Group	11-24
Deleting an Existing CoS Queue Group	11-24
CoS Queue Group Configuration Window—Detailed Description	11-25
CoS Queue Group Tab	11-25
DRR Tab	11-27
WRED Tx Configuration	11-28
Applying a CoS Queue Group to an Interface	11-28
Removing a CoS Queue Group from an Interface	11-30
Changing the Association of a CoS Queue Group	11-30
WRED Tx Configuration Window—Detailed Description	11-31
Tx Config Tab	11-31

- WRED ToFab Configuration 11-32
 - Creating a ToFab Policy 11-32
 - Editing an Existing ToFab policy 11-33
 - Deleting an Existing ToFab policy 11-34
 - WRED ToFab Policy Configuration Window—Detailed Description 11-35
 - ToFab Policy Configuration tab 11-35
 - Slot Table Parameters 11-35
 - Actions 11-35
 - Slot-CosQ Groups 11-35
- WRED Rx Configuration 11-36
 - Associating a ToFab Policy to a Line card 11-36
 - Disassociating a ToFab Policy from a Line card 11-37
 - Changing the Association of a ToFab Policy 11-37
 - WRED Rx Configuration Window—Detailed Description 11-38
 - Rx Configuration Tab 11-38
 - Actions 11-38
 - Associated slot—Table Info 11-38
 - Apply Status 11-38

CHAPTER 12

Managing ATM Connections 12-1

- ATM Connections Supported by Cisco 12000/10720 Router Manager 12-2
 - PVC Connections 12-2
 - Terminating PVC Connections 12-2
 - SVC Connections 12-3
- Launching the ATM Connections Windows 12-4
- ATM Connection Synchronization 12-4
 - Device_is_Master (default policy) 12-5
 - Normal Policy 12-6
 - CEMF_is_Master_After_First_Sync 12-6
- Creating ATM Connections 12-7
- Uploading Existing ATM Connections and QoS Profiles 12-7
 - Naming Convention for the Uploaded Connection Objects 12-8
 - Configuring the Management Password Information 12-8
 - Without configuring the Management Password Information 12-8
 - Viewing the ATM Connection Upload Window 12-9
 - Uploading Existing ATM Connections and ATM QoS Profiles 12-10
 - ATM Connection Upload Window—Detailed Description 12-11
 - Connection Upload Tab 12-11
- Managing ATM QoS Profiles 12-12

Creating ATM QoS Profiles	12-12
Editing an ATM QoS Profile	12-14
Deleting an ATM QoS Profile	12-15
ATM QoS Profiles Configuration Window—Detailed Description	12-17
Profile Tab	12-17
RxTx Parameters Tab	12-17
Deploying ATM Connection Objects	12-18
Deploying a PVC Object	12-18
Deploying an SVC Object	12-22
Applying an ATM QoS Profile to an ATM Connection	12-28
ATM PVC Configuration	12-30
Viewing the ATM VCL Configuration Window	12-30
Connecting or Disconnecting a PVC	12-31
Decommissioning or Re-Commissioning a PVC	12-32
ATM OAM Ping	12-32
ATM VCL Configuration Window—Detailed Description	12-34
Configuration Tab	12-34
Layer 3 Configuration Tab	12-35
OAM Ping Tab	12-36
SVC Configuration	12-37
Viewing the SVC Configuration Window	12-37
Connecting or Disconnecting an SVC	12-38
Decommissioning or Recommissioning an SVC	12-38
SVC Configuration Window—Detailed Description	12-38
Configuration	12-38
PVC Status	12-40
ATM VCL Status Window—Detailed Description	12-41
Status tab	12-41
OAM tab	12-42

CHAPTER 13

Managing VLANs 13-1

Launching the VLAN Windows	13-1
VLAN Synchronization	13-2
Deploying VLAN objects	13-4
Deploying a Domain	13-4
Deploying a VLAN and a Sub-Interface Object Under an Existing Domain	13-7
VLAN Configuration	13-14
Viewing the VLAN Configuration Window	13-14
Commissioning a VLAN	13-15

- Decommissioning a VLAN 13-16
- Start Performance Logging 13-17
- Stop Performance Logging 13-18
- VLAN Configuration Window—Detailed Description 13-19
 - Configuration Tab 13-19
- VLAN Performance 13-19
 - Viewing the VLAN Performance Window 13-20
 - VLAN Performance Window—Detailed Description 13-21
- Reparenting VLANs and VLAN Sub-Interfaces 13-21
- Deleting VLAN Objects 13-22

CHAPTER 14

Routing 14-1

- Launching the Routing Windows 14-1
- BGP Management 14-2
- BGP Configuration 14-3
 - Viewing the BGP Details Tab on the BGP Configuration Window 14-3
 - BGP Details Tab—Detailed Description 14-4
 - BGP General 14-4
 - BGP Information 14-5
 - Enabling BGP on a Chassis 14-5
 - Enable BGP Window—Detailed Description 14-6
 - Action 14-6
 - Modifying BGP on a Chassis 14-7
 - BGP Modify Window—Detailed Description 14-8
 - Disabling BGP on a Chassis 14-8
 - Viewing the Network Tab on the BGP Configuration Window 14-9
 - Network Tab—Detailed Description 14-10
 - BGP Network Information 14-10
 - BGP Network Configuration 14-11
 - BGP Network Configuration Window—Detailed Description 14-11
 - Action 14-12
 - Viewing the Neighbor Tab on the BGP Configuration Window 14-12
 - Neighbor Tab—Detailed Description 14-13
 - BGP Neighbor Information 14-13
 - BGP Neighbor Configuration 14-13
 - BGP Neighbor Configuration Window—Detailed Description 14-14
 - Action 14-15
 - Viewing the Redistribution Tab on the BGP Configuration Window 14-15
 - Redistribution Tab—Detailed Description 14-16

BGP Redistribution Information	14-16
BGP Redistribute Configuration	14-16
BGP Redistribute Configuration—Detailed Description	14-17
Action	14-17
BGP Status	14-18
Viewing the BGP Status Window	14-18
BGP Status Window—Detailed Description	14-21
BGP-Details	14-21
Network	14-22
Neighbor	14-22
Redistribution	14-23
BGP Address-Family Synchronization	14-23
BGP Address-Family Synchronization—Detailed Description	14-26
Synchronization Tab	14-26
BGP Address Family Configuration	14-26
Viewing the AF-General Tab on the BGP Address-Family Configuration Window	14-27
AF-General Tab—Detailed Description	14-28
BGP General	14-28
BGP Address Family Information	14-28
Configuring Address Family	14-28
Configure Address Family—Detailed Description	14-29
Add Address Family	14-29
Modifying BGP Address Family	14-30
BGP Address Family-Modify Address Family Parameters—Detailed Description	14-31
Modify Address Family Parameters	14-31
Viewing the AF-Network Tab on the BGP Address-Family Configuration Window	14-32
AF-Network Tab—Detailed Description	14-33
Network Information	14-33
BGP Address Family—Network Configuration	14-33
BGP Address Family-Network Configuration—Detailed Description	14-34
Add/Remove Network	14-34
Viewing the AF-Neighbor Tab on the BGP Address-Family Configuration Window	14-35
AF-Neighbor Tab—Detailed Description	14-36
Neighbor Information	14-36
BGP Address Family—Neighbor Configuration	14-36
BGP Address Family-Neighbor Configuration—Detailed Description	14-37
Add/Remove Neighbor	14-37
Viewing the AF-Redistribute Tab on the BGP Address-Family Configuration Window	14-38
AF-Redistribute Tab—Detailed Description	14-39

- Redistribute Information 14-39
 - BGP Address Family—Redistribute Configuration 14-40
 - BGP Address Family-Configure Redistribute Protocol—Detailed Description 14-41
 - Add/Remove Redistribution Information 14-41
 - BGP Address-Family Status 14-41
 - Viewing the BGP Address-Family Status window 14-41
 - BGP Address-Family Status Window—Detailed Description 14-45
 - AF-General 14-45
 - AF-Network 14-46
 - AF-Neighbor 14-46
 - AF-Redistribute 14-46
- OSPF Management 14-47
- OSPF Configuration 14-47
 - Viewing the OSPF Configuration Window 14-47
 - Config Tab—Detailed Description 14-48
 - Config 14-48
 - Adding an OSPF Process 14-49
 - Removing an OSPF Process 14-50
 - Viewing the Network Tab on the OSPF Configuration Window 14-51
 - Network Tab—Detailed Description 14-51
 - Ospf Network 14-51
 - Configuring a Network 14-52
 - Configure Network—Detailed Description 14-54
 - Configure Network 14-54
- OSPF Status 14-54
 - Viewing the OSPF Status Window 14-54
 - OSPF Status—Detailed Description 14-61
 - General Group 14-61
 - Process Information 14-62
 - Area 14-62
 - Interface 14-63
 - Neighbor 14-65
 - Link State 14-66
 - Host 14-66

CHAPTER 15

MPLS Management 15-1

- Introduction 15-1
- MPLS Management Workflow 15-2
- Launching the MPLS Management Windows 15-3

MPLS Forwarding Information	15-4
Viewing the MPLS Forwarding Information Window	15-4
MPLS Forwarding Information Window—Detailed Description	15-5
MPLS Forwarding Information Tab	15-5
Fault Management for MPLS LSR Interfaces	15-6
MPLS Interface Status	15-6
Viewing the MPLS Interface Status Window	15-6
MPLS Interface Status Window—Detailed Description	15-7
MPLS Interface Information	15-8
Viewing the MPLS Interface Information Window	15-8
MPLS Interface Information Window—Detailed Description	15-9
Performance Management for MPLS LSR Interfaces	15-14
MPLS Interface Performance	15-14
Viewing the MPLS Interface Performance Window	15-14
MPLS Interface Performance Window—Detailed Description	15-15
Fault Management for MPLS LDP	15-18
MPLS LDP Entity Status Window	15-18
Viewing the MPLS LDP Entity Status Window	15-18
MPLS LDP Entity Status Window—Detailed Description	15-19
MPLS LDP Hello Adjacencies	15-26
Viewing the MPLS LDP Hello Adjacencies Window	15-26
MPLS LDP Hello Adjacencies Window—Detailed Description	15-27
MPLS LDP Peer Status	15-28
Viewing the MPLS LDP Peer Status Window	15-28
MPLS LDP Peer Status Window—Detailed Description	15-29
Fault Management for MPLS Traffic Engineering	15-33
MPLS Tunnel Information	15-33
Viewing the MPLS Tunnel Information Window	15-33
MPLS Tunnel Information Window—Detailed Description	15-34

CHAPTER 16

MPLS VRF Management 16-1

Introduction to VRF Management	16-1
VRF Management Workflows	16-2
Launching the MPLS VRF Management Windows	16-2
Creating VRF Objects in the EM	16-3
Deploying VRF Objects	16-3
Creating and Configuring the VRF Policy on a Device	16-8
Configuring and Creating a VRF Policy on a Selected Chassis	16-8
Removing a VRF Policy from a Selected Chassis	16-10

Adding a Routing Target to a Selected Chassis	16-10
Deleting a Routing Target from a Selected Chassis	16-10
VRF Configuration Window—Detailed Description	16-11
VRF Configuration Tab	16-11
Associating a VRF Policy with an Interface	16-12
Associating VRF Policies	16-13
Removing a VRF Policy from a Selected Interface	16-14
VRF Association Window—Detailed Description	16-14
VRF Tab	16-14
VRF Fault Management	16-15
VRF Status	16-15
Viewing the VRF Status Window	16-15
VRF Status Window—Detailed Description	16-16
General Tab	16-16
Performance and Security Tab	16-17
Interface VRF Status	16-19
Viewing the Interface VRF Status Window	16-19
Interface VRF Status Window—Detailed Description	16-20
Interface VRF Association Tab	16-20
VPN Status	16-20
Viewing the VPN Status Window	16-20
VPN Status Window—Detailed Description	16-21
General Tab	16-21
Routes Tab	16-22
Route Targets Tab	16-23
BGP Neighbor Tab	16-25
VRF Object Status	16-26
Viewing the VRF Object Status Window	16-26
VRF Object Status Window—Detailed Description	16-27
General Tab	16-27
Routes Tab	16-28
Route Targets Tab	16-29
Interface Association Tab	16-31
Performance Tab	16-32

CHAPTER 17

MPLS Trap Management	17-1
MPLS Traps Supported by the C12000/10720 Router Manager	17-1
Enabling/Disabling Traps on the Device	17-3
MPLS Trap Configuration Window—Detailed Description	17-4
Traps Tab	17-4
MPLS CLI Troubleshooting Services	17-5
Launching the MPLS CLI Troubleshooting Services Windows	17-5
Verify Routing Protocols	17-6
Verify Routing Tables	17-7
Verify CEF Switching	17-8
Verify CEF Switching Summary	17-9
Verify MPLS Interfaces	17-10
Verify Label Distribution	17-11
Verify Label Bindings	17-12
Verify Interface CEF Switching	17-13

CHAPTER 18

Fault Management	18-1
Cisco 12000/10720 Router Manager Alarms	18-1
Viewing Alarms	18-2
Cisco 12000/10720 Router Trap Support	18-2
Chassis Alarms	18-3
Interface Alarms	18-5
Syslog Traps	18-5
Configuration Management Traps	18-6
Heartbeat Polling	18-7
Connectivity Management	18-7
Operational Status Polling	18-7
Disabling Heartbeat Polling	18-7
Performance Logging	18-8

CHAPTER 19

Change Management	19-1
Inserting a Line Card	19-2
Mismatched State	19-2
Removing a Line Card	19-4

CHAPTER 20

Performance Management and Historical Data	20-1
Performance Information Available Using Cisco 12000/10720 Router Manager	20-2
Viewing the Performance Manager Window	20-2

- Viewing Performance Statistics 20-4
- Viewing a Chart 20-5
- Printing a Performance File 20-6
- Saving Performance Data to a File 20-6
- Archiving 20-6
- Exporting A Performance File 20-7
- Performance Manager Window—Detailed Description 20-7
 - Monitored Attributes 20-7
 - Time Period 20-8
 - Summary 20-8
 - Refresh 20-9
 - Line Chart Tab 20-9
 - Table Display Tab 20-9

CHAPTER 21

Troubleshooting and FAQs 21-1

- Administration 21-1
 - What Version is the Software? 21-1
 - What Dialogs Use the IOS CLI Instead of SNMP? 21-2
- Configuration 21-3
 - Verifying SNMP, Log, and Trap Settings 21-3
 - BGP Configuration 21-5
 - ATM Sub-Interface Configuration 21-5
 - ATM IP Configuration GUI Display ERROR Settings 21-5
 - Viewing ATM Physical Port Configurations? 21-6

APPENDIX A

SONET/SDH Conversion Chart A-1

APPENDIX B

GUI Synchronization Details B-1

- GUIs that Synchronize with the Device when Launched B-1
- GUIs that do not Synchronize with the Device when Launched B-2

APPENDIX C

Investigating LSP Black Holes Using Cisco 12000 Series Router Manager C-1

- Network Diagram C-1
- Setup C-1
 - Problem C-2
 - Analysis of Problem C-2
 - Solution C-3

Running Configs	C-4
CE1	C-4
PE1	C-5
P	C-7
PE2	C-11
CE2	C-12

INDEX



About This Guide

This guide provides information on using the Cisco 12000/10720 Router Manager application. The Cisco 12000/10720 Router Manager uses the Cisco Element Management Framework (Cisco EMF), which provides element management to simplify the day-to-day tasks of an operator. These tasks can include equipment provisioning, fault monitoring, interface configuration, and gathering and displaying interface performance statistics.

This chapter contains the following sections:

- [Document Audience](#)
- [Document Organization](#)
- [Conventions](#)
- [Obtaining Documentation](#)
- [Obtaining Technical Assistance](#)

Document Audience

This user guide is written as a technical resource for network managers, system administrators, network analysts, and system operators, with the following qualifications:

- Basic understanding of network design, operation, and terminology
- Familiarity with your own network configurations
- Basic familiarity with UNIX
- Familiarity with the *Cisco Element Management Framework Installation and Administration Guide* and *Cisco Element Management Framework User Guide*.

Document Organization

This guide is organized as follows:

Table 1 Document Organization

Chapter Number	Chapter Title	Content
Chapter 1	Overview	This chapter provides a basic overview of the Cisco 12000/10720 Routers and the Cisco 12000/10720 Router Manager application.
Chapter 2	Concepts	This chapter describes Cisco 12000/10720 Router Manager basic concepts.
Chapter 3	Getting Started	This chapter describes the typical tasks you should complete to get started using the Cisco 12000/10720 Router Manager application.
Chapter 4	Managing Chassis	This chapter describes the various management tasks that can be performed on the chassis to be managed using the Cisco 12000/10720 Router Manager application.
Chapter 5	Managing Modules	This chapter describes the management functions available on Gigabit Route Processors (GRPs), line cards, and supporting modules.
Chapter 6	Managing Interfaces	This chapter describes the various management tasks that can be performed on the interfaces of the Cisco devices being managed using the Cisco 12000/10720 Router Manager application.
Chapter 7	Interface Profiles	This chapter describes how to create interface profiles using the Cisco 12000/10720 Router Manager application.
Chapter 8	Interface Configuration	This chapter describes how to configure or set up interfaces associated with each line card.
Chapter 9	Interface Status	This chapter describes how to view appropriate status information for each of the interfaces on the Cisco 12000/10720 Routers you are managing.
Chapter 10	Interface Performance	This chapter describes how to view appropriate performance information for each of the interfaces on the Cisco 12000/10720 Routers you are managing.
Chapter 11	Layer 3 QoS	This chapter describes how to create and configure Layer 3 QoS (Quality of Service) Committed Access Rate (CAR), Weighted Random Early Detection (WRED) policies and To-Fabric (ToFab) policies.
Chapter 12	Managing ATM Connections	This chapter describes the different types of ATM connections supported by the Cisco 12000/10720 Router Manager application and then describes how to create, set up and manage ATM connections. Cisco 10720 routers do not support ATM connections.

Table 1 Document Organization (continued)

Chapter Number	Chapter Title	Content
Chapter 13	Managing VLANs	This chapter describes the VLAN functionality supported by the Cisco 12000/10720 Router Manager application and guides you through the process of creating and configuring VLAN objects.
Chapter 14	Routing	This chapter describes the Border Gateway Protocol (BGP) and the Open Shortest Path First Routing Protocol (OSPF).
Chapter 15	MPLS Management	This chapter describes the Multi Protocol Label Switching (MPLS) management tasks that can be performed using the Cisco 12000/10720 Router Manager application.
Chapter 16	MPLS VRF Management	This chapter describes the various MPLS VRF Management tasks that can be performed using the Cisco 12000/10720 Manager (C12k/10720M) application.
Chapter 17	MPLS Trap Management	This chapter describes MPLS traps that can be configured using the Cisco 12000/10720 Router Manager application using the MPLS Trap Configuration window.
Chapter 18	Fault Management	This chapter describes how to view appropriate fault information on the Cisco 12000/10720 Routers you are managing.
Chapter 19	Change Management	This chapter describes how to manage the insertion and removal of linecards from the Cisco 12000/10720 Routers being managed.
Chapter 20	Performance Management and Historical Data	This chapter describes the Performance Manager application. Performance Manager displays historical data as well as current data in the form of a line chart, bar chart, or table. Performance logging can be enabled on multiple or individual object basis.
Chapter 21	Troubleshooting and FAQs	Details answers to some commonly asked questions or problems.
Appendix A	SONET/SDH Conversion Chart	This appendix details Synchronous Optical Network (SONET) and Synchronous Digital Hierarchy (SDH) conversion information.
Appendix B	GUI Synchronization Details	List the GUIs that synchronize with the device when launched, and those GUIs that do not synchronize with the device when launched.
Appendix C	Investigating LSP Black Holes Using Cisco 12000 Series Router Manager	Gives an example of a problem, and details the solution.

Conventions

Conventions are presented in the following sections:

- [Command Conventions](#)
- [Example Conventions](#)
- [Document Conventions](#)

Command Conventions

Commands use these conventions:

Table 2 *Command Conventions*

Format	Description	Example
Boldface font	Commands, keywords, and user entries in text	/usr/bin
<i>Italic font</i>	Arguments for which users supply values	<i>CEMF_ROOT</i>
Square brackets ([])	Optional keywords or arguments	[?]
Braces ({ })	Alternative but required keywords	{yes no}
Vertical bar ()	Separator between alternative but required keywords	{yes no}
Angle brackets (<>)	Non-printing user entries (such as passwords)	<rootpassword>

Example Conventions

Examples use these conventions:

Table 3 *Example Conventions*

Format	Description	Example
Plain screen font	Onscreen displays, examples, and scripts	C12000/C10700 EM
Bold screen font	User entries in examples and scripts	./cemf install
<i>Italic screen font</i>	User entry variables	<i>remote-host</i>
Square brackets ([])	Default responses	[tftp idle]

Document Conventions

This guide uses these conventions:

Table 4 Document Conventions

Format	Description	Example
Boldface font	Menu options, button names, and names of keys on keyboards	Exit
<i>Italic</i> font	Directories, filenames, and titles	<i>Cisco Element Management Framework User Guide Release 3.2 (78-12536-01)</i>

Notes and cautionary statements use these conventions:



Note

Means reader take note. Notes contain helpful suggestions or references to materials not contained in this manual.



Caution

Means reader be careful. You are capable of doing something that might result in equipment damage or loss of data.

Obtaining Documentation

Cisco provides several ways to obtain documentation, technical assistance, and other technical resources. These sections explain how to obtain technical information from Cisco Systems.

Cisco.com

You can access the most current Cisco documentation on the World Wide Web at this URL:

<http://www.cisco.com/univercd/home/home.htm>

You can access the Cisco website at this URL:

<http://www.cisco.com>

International Cisco websites can be accessed from this URL:

http://www.cisco.com/public/countries_languages.shtml

Documentation CD-ROM

Cisco documentation and additional literature are available in a Cisco Documentation CD-ROM package, which may have shipped with your product. The Documentation CD-ROM is updated regularly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual or quarterly subscription.

Registered Cisco.com users can order a single Documentation CD-ROM (product number DOC-CONDOCCD=) through the Cisco Ordering tool:

http://www.cisco.com/en/US/partner/ordering/ordering_place_order_ordering_tool_launch.html

All users can order monthly or quarterly subscriptions through the online Subscription Store:

<http://www.cisco.com/go/subscription>

Ordering Documentation

You can find instructions for ordering documentation at this URL:

http://www.cisco.com/univercd/cc/td/doc/es_inpk/pdi.htm

You can order Cisco documentation in these ways:

- Registered Cisco.com users (Cisco direct customers) can order Cisco product documentation from the Networking Products MarketPlace:

<http://www.cisco.com/en/US/partner/ordering/index.shtml>

- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco Systems Corporate Headquarters (California, U.S.A.) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

Documentation Feedback

You can submit comments electronically on Cisco.com. On the Cisco Documentation home page, click **Feedback** at the top of the page.

You can e-mail your comments to bug-doc@cisco.com.

You can submit comments by using the response card (if present) behind the front cover of your document or by writing to the following address:

Cisco Systems
Attn: Customer Document Ordering
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides Cisco.com, which includes the Cisco Technical Assistance Center (TAC) website, as a starting point for all technical assistance. Customers and partners can obtain online documentation, troubleshooting tips, and sample configurations from the Cisco TAC website. Cisco.com registered users have complete access to the technical support resources on the Cisco TAC website, including TAC tools and utilities.

Cisco.com

Cisco.com offers a suite of interactive, networked services that let you access Cisco information, networking solutions, services, programs, and resources at any time, from anywhere in the world.

Cisco.com provides a broad range of features and services to help you with these tasks:

- Streamline business processes and improve productivity
- Resolve technical issues with online support
- Download and test software packages
- Order Cisco learning materials and merchandise
- Register for online skill assessment, training, and certification programs

To obtain customized information and service, you can self-register on Cisco.com at this URL:

<http://tools.cisco.com/RPF/register/register.do>

Technical Assistance Center

The Cisco TAC is available to all customers who need technical assistance with a Cisco product, technology, or solution. Two types of support are available: the Cisco TAC website and the Cisco TAC Escalation Center. The type of support that you choose depends on the priority of the problem and the conditions stated in service contracts, when applicable.

We categorize Cisco TAC inquiries according to urgency:

- Priority level 4 (P4)—You need information or assistance concerning Cisco product capabilities, product installation, or basic product configuration. There is little or no impact to your business operations.
- Priority level 3 (P3)—Operational performance of the network is impaired, but most business operations remain functional. You and Cisco are willing to commit resources during normal business hours to restore service to satisfactory levels.
- Priority level 2 (P2)—Operation of an existing network is severely degraded, or significant aspects of your business operations are negatively impacted by inadequate performance of Cisco products. You and Cisco will commit full-time resources during normal business hours to resolve the situation.
- Priority level 1 (P1)—An existing network is “down,” or there is a critical impact to your business operations. You and Cisco will commit all necessary resources around the clock to resolve the situation.

Cisco TAC Website

The Cisco TAC website provides online documents and tools to help troubleshoot and resolve technical issues with Cisco products and technologies. To access the Cisco TAC website, go to this URL:

<http://www.cisco.com/tac>

All customers, partners, and resellers who have a valid Cisco service contract have complete access to the technical support resources on the Cisco TAC website. Some services on the Cisco TAC website require a Cisco.com login ID and password. If you have a valid service contract but do not have a login ID or password, go to this URL to register:

<http://tools.cisco.com/RPF/register/register.do>

If you are a Cisco.com registered user, and you cannot resolve your technical issues by using the Cisco TAC website, you can open a case online at this URL:

<http://www.cisco.com/tac/caseopen>

If you have Internet access, we recommend that you open P3 and P4 cases online so that you can fully describe the situation and attach any necessary files.

Cisco TAC Escalation Center

The Cisco TAC Escalation Center addresses priority level 1 or priority level 2 issues. These classifications are assigned when severe network degradation significantly impacts business operations. When you contact the TAC Escalation Center with a P1 or P2 problem, a Cisco TAC engineer automatically opens a case.

To obtain a directory of toll-free Cisco TAC telephone numbers for your country, go to this URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Before calling, please check with your network operations center to determine the Cisco support services to which your company is entitled: for example, SMARTnet, SMARTnet Onsite, or Network Supported Accounts (NSA). When you call the center, please have available your service agreement number and your product serial number.

Obtaining Additional Publications and Information

Information about Cisco products, technologies, and network solutions is available from various online and printed sources.

- The *Cisco Product Catalog* describes the networking products offered by Cisco Systems, as well as ordering and customer support services. Access the *Cisco Product Catalog* at this URL:

http://www.cisco.com/en/US/products/products_catalog_links_launch.html

- Cisco Press publishes a wide range of networking publications. Cisco suggests these titles for new and experienced users: *Internetworking Terms and Acronyms Dictionary*, *Internetworking Technology Handbook*, *Internetworking Troubleshooting Guide*, and the *Internetworking Design Guide*. For current Cisco Press titles and other information, go to Cisco Press online at this URL:

<http://www.ciscopress.com>

- *Packet* magazine is the Cisco quarterly publication that provides the latest networking trends, technology breakthroughs, and Cisco products and solutions to help industry professionals get the most from their networking investment. Included are networking deployment and troubleshooting tips, configuration examples, customer case studies, tutorials and training, certification information, and links to numerous in-depth online resources. You can access *Packet* magazine at this URL:

<http://www.cisco.com/go/packet>

- iQ Magazine is the Cisco bimonthly publication that delivers the latest information about Internet business strategies for executives. You can access iQ Magazine at this URL:

<http://www.cisco.com/go/iqmagazine>

- Internet Protocol Journal is a quarterly journal published by Cisco Systems for engineering professionals involved in designing, developing, and operating public and private internets and intranets. You can access the Internet Protocol Journal at this URL:

http://www.cisco.com/en/US/about/ac123/ac147/about_cisco_the_internet_protocol_journal.html

- Training—Cisco offers world-class networking training. Current offerings in network training are listed at this URL:

http://www.cisco.com/en/US/learning/le31/learning_recommended_training_list.html



Overview


This chapter provides an overview of the Cisco 12000/10720 Routers and the Cisco 12000/10720 Router Manager application.

The Cisco 12000 Series Routers are part of Cisco’s premier routing product family and play an integral part in the network architecture. The Cisco 12000 Series Routers were designed and developed for the core of service provider and enterprise IP backbones.

The Cisco 10720 Router provides IP services to users at optical speeds at the edge of their networks. The Cisco 10720 Router provides network access using Ethernet and Dynamic Packet Transport (DPT) technology for optical connectivity. Each router is equipped with one uplink card and one Ethernet access card.

Figure 1-1 shows a typical Cisco 12000 Series Routers deployment. The Cisco 12000/10720 Router Manager application supports the entire range of the Cisco 12000 Series Routers like: Cisco 12008, Cisco 12012, Cisco 12016, Cisco 12404, Cisco 12406, Cisco 12410, Cisco 12416 and the Cisco 10720 Router.

Figure 1-1 Typical Cisco 12000 Series Router Deployment



The Cisco 12000/10720 Router Manager application works in conjunction with the Cisco Element Management Framework (Cisco EMF) application to provide element management for the Cisco 12000 Series and Cisco 10720 Routers. The Element Manager includes FCAP management.

This chapter describes the following information:

- [Cisco Element Manager Framework \(Cisco EMF\) Software](#)
- [Cisco 12000/10720 Router Manager Software](#)
- [Key Features of the Cisco 12000/10720 Router Manager Software](#)
- [Accessing Online Help](#)

Cisco Element Manager Framework (Cisco EMF) Software

Cisco EMF is an open carrier class management system, designed to integrate with third party products and proprietary operational support systems.

Many different management protocols, both standards-based and proprietary, are supported by Cisco EMF in a transparent manner. New network devices are managed instantly and new management applications can be quickly developed to meet new requirements.

Cisco EMF systems architecture provides a distributed network management solution designed to manage large-scale networks. Cisco EMF provides the performance required within the logical and physical architecture and provides user interfaces that support the need to perform mass operations to large domains within the overall network. In addition, due to the distributed nature of Cisco EMF, administration tools are provided to “manage” the management system. Refer to the *Cisco Element Management Framework User Guide Release 3.2 (78-12536-01)* for further details.

Map Viewer is the primary entry point into the Cisco 12000/10720 Router Manager software. When Map Viewer is launched, the application is displayed corresponding to the highlighted map icon in the hierarchy pane. You can easily monitor the status of all network elements or abstractions of elements contained within the network and you can launch any additional applications available. See “[Map Viewer \(Viewer\)](#)” section on page 3-6 for further details.

Cisco 12000/10720 Router Manager Software

The Cisco 12000/10720 Router Manager application is a carrier class Element Manager (EM) that allows you to manage Cisco 12000/10720 Routers. Cisco 12000/10720 Router Manager adds custom windows and modeling behavior to the standard Cisco EMF to allow the management of the Cisco 12000 Series and Cisco 10720 Routers.



Note

This Guide describes the concepts and operating instructions for the Cisco 12000/10720 Router Manager. Refer to the *Cisco Element Management Framework User Guide Release 3.2 (78-12536-01)* for further details on Cisco EMF.

Key Features of the Cisco 12000/10720 Router Manager Software

Cisco 12000/10720 Router Manager features include the following:

- Maps for Chassis representation of Cisco 12000/10720 Router objects
- Cisco 12000/10720 Router Manager windows and wizards—Eliminate the need for operators to have detailed Cisco IOS software and SNMP-based knowledge for individual interface or system parameter commands

- Cisco 12000/10720 Router Manager deployment—Eases deployment of large networks by enabling template-based element configuration, operations, administration, and maintenance
 - Pre-deployment of chassis, GRP and line cards
 - AutoDiscovery—Automatically discovers existing Cisco 12000/10720 routers
- Comprehensive fault management system—For chassis, line cards and interfaces
- Configuration Backup/Restore using RME—Uses Resource Manager Essentials to back up and save the running configuration of a device and its modules so that if a hardware failure occurs, you can restore configuration
- Configuration Editor—Uploads and saves the running configuration on a device after editing
- Configuration operations—Performs in bulk to numerous Cisco 12000/10720 routers
- Cisco 12000/10720 Router Manager Management—Fault, Configuration, Accounting and Performance (FCAP) Element Management of Cisco 12000 Series Routers using Cisco EMF windows
- Interface profiles—Enables you to apply the same parameters to a large number of objects at one time
- Layer 3 QoS support—Includes Committed Access Rate (CAR), Weighted Random Early Detection (WRED), WRED ToFab and Modified Deficit Round Robin (MDRR)
- Line cards and interfaces—Supports various line cards and interfaces, such as packet-over-SONET (POS), Asynchronous Transfer Mode (ATM), Digital Signal 3 (DS3), Dynamic Packet Transport (DPT), Spatial Reuse Protocol (SRP) and Gigabit and Fast Ethernet
- Cisco IOS releases—Easily downloads new software releases from Cisco 12000/10720 Router Manager onto devices using RME
- ATM Connections Management—Uploads existing PVCs and associated QoS profiles from any device into the Cisco 12000/10720 Router Manager and also manual deployment and management of PVCs and SVCs
- Subchassis discovery—Determines the physical chassis contents, such as line cards and interfaces
- Rediscover Line Cards after online insertion or removal (OIR)
- BGP and OSPF Protocols Management—Configuration and Fault Management for BGP and OSPF routing protocols and uploading BGP Address Family configurations
- Route Processor Redundancy (GRP and PRP) support for chassis management
- Complete support for IP Routing, TCP and UDP Status Management
- MPLS Management—Fault Management and Performance Management for MPLS Interfaces and Sub-Interfaces, Fault Management for LDP Entities and MPLS Tunnels, Configuring MPLS and VRF Traps
- VRF Management—Configuration of VRFs in the EM. Creation of VRFs in the device through EM and Association of VRFs to Interfaces. Fault Management for VRFs
- VLAN Management—Configuration and performance monitoring of the VLAN sub-interfaces
- VLAN Synchronization—Uploads the existing VLAN information from the network into Cisco 12000/10720 Router Manager

Accessing Online Help

Each window has the option to click the Help icon, or to select **Help** from the menu bar. A list of help topics is displayed.



Concepts

This chapter describes Cisco 12000/10720 Router Manager concepts and covers the following information:

- [Cisco 12000/10720 Router Manager Objects and Interfaces](#)
- [Views](#)
- [Cisco 12000/10720 Router Manager Object States](#)

Cisco 12000/10720 Router Manager Objects and Interfaces

Cisco 12000/10720 Router Manager manages both physical and logical objects, as follows:

- **Physical**—Represents tangible components and devices such as the chassis (hardware frame), line cards, and interfaces
- **Logical**—Represents intangible, more abstract features, such as ATM connections, Layer 3 Quality of Service (QoS) objects and VLAN sub-interfaces

Fault, Configuration, Accounting and Performance (FCAP) windows are accessible on both physical and logical EM objects, in the form of FCAP menu options that appear when you right-click on any object in Cisco 12000/10720 Router Manager. FCAP functionality provides a complete management interface to the features of the Cisco 12000/10720 Router.

This section covers the following areas:

- [Physical Objects](#)
- [Cisco 12000/10720 Router Chassis](#)
- [Supporting Modules](#)
- [Physical Interfaces and Technologies](#)
- [Logical Objects](#)

Physical Objects

[Table 2-1](#) lists all physical objects created in Cisco 12000/10720 Router Manager and the management functions that can be performed on each object.

Table 2-1 Physical Objects and Management Functions

Cisco 12000/10720 Router Manager Physical Object	Management Functions
Chassis—The hardware frame of the Cisco 12000/10720 Router, which houses all subchassis objects (modules).	Command Log Configuration Configuration Backup/Restore Configuration Editor Fault Management Initiate Telnet Service Inventory IOS Image Download Launch Web Console Management Information SNMP Management System Log APS Status RPR Configuration RPR Status
GRP (Gigabit Route Processor)—There can be up to two GRPs in a chassis. The primary GRP is the CPU or “brains” of the router. The secondary GRP is redundant.	Configuration Fault Management Inventory Performance
Line Cards—There are various types of line cards within a chassis (for example, ATM, Ethernet, SRP, POS, E3, DS3 and Modular Ethernet). Each of these line cards holds a given number of physical interfaces (ports).	Configuration Fault Management Inventory
Physical Interfaces—Each line card has at least one, if not multiple, physical interfaces (ports). The type of physical interface is equivalent to the type of line card the interface resides on. Each physical interface can support multiple technologies (for details, see “Physical Interfaces and Technologies” section on page 2-5) The line card type determines what specific technologies are supported by an interface.	Profile Configuration Fault Management Performance Status
Supporting Modules—Additional subchassis cards and modules: the switch fabric card (SFC), clock scheduler card (CSC), AC or DC power supply module, blower module, and fan tray module.	Configuration Fault Management Inventory



Note

The Cisco 10720 chassis does not support the Configuration Editor.

The physical objects and interfaces displayed in [Table 2-1](#) are traced as follows:

- The chassis contains the GRPs, supporting modules, and all line cards
- The line cards contain the physical interfaces.

See the [“Views” section on page 2-11](#) for further details on hierarchies within Cisco EMF and Cisco 12000/10720 Router Manager.



Tip


Physical objects contained within a chassis are often referred to as subchassis objects or modules.

Cisco 12000/10720 Router Chassis

The Cisco 12000/10720 Router Manager application supports the entire range of Cisco 12000 Series Router chassis like: Cisco 12008, Cisco 12012, Cisco 12016, Cisco 12404, Cisco 12406, Cisco 12410, Cisco 12416 and the Cisco 10720 Router chassis.

[Figure 2-1](#) displays a Cisco 12016 Router chassis as an example, and identifies the modules and sub-modules that you would find.

Figure 2-1 Cisco 12016 Chassis



The Cisco 12016 chassis supports the following components:

- Power shelf and power supplies—Contains either 3 AC (shown) or 4 DC power modules
- Upper and lower blower modules
- Upper and lower cable management brackets
- Upper card cage, which contains the following:
 - 1 Non-configurable alarm card in far left slot
 - 1 GRP in far right slot
 - Up to 7 line cards
- Air filter door—Behind it is the switch fabric card cage, which contains the following:
 - 2 CSCs (one is optional for redundancy)
 - 3 SFCs

- Lower card cage, which contains the following:
 - 1 Non-configurable alarm card in far right slot
 - 1 Optional GRP in far left slot
 - Up to 8 line cards

Supporting Modules

Cisco 12000/10720 Router Manager supports five types of supporting modules within a Cisco 12000 Series Router chassis. Some modules only apply to certain chassis types.

- CSC (Clock Scheduler Card)—CSCs handle requests from line cards, issue grants to access the switch fabric cards, and provide a reference clock to all the cards in the system to synchronize data transfer across the crossbar. Each chassis must have at least one CSC.
- SFC (Switch Fabric Card)—SFCs receive the scheduling information and clocking reference from the CSC cards and perform the switching functions.
- AC or DC Power Supply Module—Chassis can be ordered with either AC or DC power supply modules, having anywhere from one to four AC or DC-input power supplies, depending upon the specific chassis.
- Blower Module—The Cisco 12012 and 12016 Routers contain two blower modules, which circulate cooling air through the card cages in the chassis.
- Fan Tray—The Cisco 12008 Router contains a fan tray, which circulates cooling air through the card cage in the chassis.

Linecards

Refer “[Manually Deploying Line Cards](#)” section on page 3-38 for details of all the supported technology specific linecards.

Physical Interfaces and Technologies

Physical interfaces are modeled as objects below the parent line card. Some generic properties are supported by all the interfaces. As mentioned before, the type of line card characterizes the type of physical interface; for example, an ATM line card will only support ATM interfaces. However, there can be multiple technologies supported on that physical interface. For example, ATM physical interfaces can support the following:

- Internet Protocol (IP)
- ATM
- SONET



Note

Cisco 12000/10720 Router Manager handles both SDH and SONET in the same manner. The Cisco 12000/10720 Routers support both SDH and SONET. For a comparison chart of SONET and SDH speeds, see [Appendix A, “SONET/SDH Conversion Chart.”](#)



Tip

The technologies supported by an interface are exposed within FCAP-based management windows. It is important to understand the relationship of physical interfaces to technologies in order to properly manage an interface.

[Table 2-2](#) outlines each physical interface and the technologies it supports. Also included are the different FCAP-based windows that are applicable to each physical interface and technology. For example, if you want to configure an ATM interface, look in the table under ATM, and you will notice that four technologies apply: Generic, ATM, SONET, and IP. This means that you should open the configuration windows for these four technologies and configure the fields within, in order to completely configure an ATM interface.

Table 2-2 *Physical Interfaces, Related Technologies and Windows*

Physical Interfaces	Technologies Supported and Related Windows
DS-3	Generic—Configuration, Status, Performance DS-3—Status, Performance IP—Configuration
POS	Generic—Configuration, Status, Performance SONET—Status, Performance POS—Configuration, Profile, APS Configuration, APS Status IP—Configuration
ATM	Generic—Configuration, Status, Performance ATM—Status, Configuration, Profile, Fault SONET—Status, Performance IP—Configuration
Ethernet	Generic—Configuration, Status, Performance Ethernet—Performance, Configuration, HSRP Configuration, HSRP Profile IP—Configuration
SRP	Generic—Configuration, Status, Performance SRP—Configuration, Status, Topology, Performance SRP Side—Profile, Configuration, IPS Status, Performance IP—Configuration

Logical Objects

Cisco 12000/10720 Router Manager supports three logical object types:

- Layer 3 QoS—Weighted Random Early Detection (WRED) or Committed Access Rate (CAR) objects, such as Class of Service (CoS) Queue Groups, WRED ToFab policies, CAR policies, and CAR access lists.



Note

The Cisco 10720 Router does not support Layer 3 QoS objects.

- ATM connections—Permanent Virtual Circuits (PVCs) or Switched Virtual Circuits (SVCs) can be applied to ATM interfaces. The Cisco 10720 Router does not support ATM connections.

- VLAN—Domain, VLAN, sub-interface objects. VLAN sub-interfaces can be configured on Ethernet interfaces.

Table 2-3 describes the management functions for Layer 3 QoS logical configurations.

Table 2-3 Layer 3 QoS Logical Objects

Logical Object	Management Functions
WRED: CoS queue groups ToFab Policies	Create, configure, apply, modify, delete and remove CosQ groups, WRED ToFab and CAR objects.
CAR: CAR policies CAR access lists	
Software: VRF Policies	Create, configure, apply(to an interface) and remove(from device and interface) VRF Policies

Table 2-4 describes the management functions for ATM logical objects.

Table 2-4 ATM Logical Objects

Logical Object	Management Functions You Can Perform
PVC SVC	Upload, sync, create, configure, manage, and delete/connect/disconnect on main or sub-interfaces. Status information can be collected and displayed for PVC objects only.

Table 2-5 describes the management functions for VLAN objects.

Table 2-5 VLAN Objects


Logical Object	Management Functions You Can Perform
Domain, VLAN VLAN sub-interfaces	Create and delete on Domain objects. Create, configure, manage, and delete on VLAN and sub-interfaces.

Use of Telecom Graphics Objects

Cisco EMF uses Telecom Graphics Objects (TGO) in the Map Viewer application. TGO is a TeleManagement Forum (TMF) sponsored initiative to provide standard graphical representations for network topology maps.

A TGO displays additional information icons on top of the existing object icons displayed in Map Viewer. The additional icons indicate a variety of information (for example, information on the state of the object or event status information). Figure 2-2 provides an example of a TGO.

Figure 2-2 Sample Telecom Graphical Object




An object is a representation of a network element. For example, the object could be a node or a link. Each object shown in the right window provides pictorial cues which provide information about its associated network element. The information can be structural information; for example, a network element name or state and event information such as “out of service.”

Each object can display the following information about its associated network element:

- Object name—Name that the user gives to the object
- Object class—Class indicates a different kind of element
- Object state—(ANSI T1-232):
 - Event unacknowledged count
 - Event unacknowledged state
 - Event outstanding state

Figure 2-3 shows an example of a Cisco 12000 chassis map displaying a few of the TGO icons that could appear.

Figure 2-3 Sample Cisco 12000 Chassis Showing Telecom Graphical Objects







Refer to the *Cisco Element Management Framework User Guide Release 3.2* for further information on the type of TGO objects that can appear in the Cisco 12000/10720 Router Manager.

OSI Mappings

Table 2-6 gives the complete list of OSI mappings for all combinations of the Admin and Operational status.

Table 2-6 *OSI Mappings for the different combinations of the Admin and Operational Status*

Operational Status	Admin Status	OSI Mapping	Icon Representation
Up	Up	EnabledActiveUnlocked(Availability: Providing Service)	
Down/Testing	Down	DisabledIdleLocked	
Down/Testing	Up	EnabledIdleUnlocked (Availability: Degraded)	
Down/Testing	Testing	DisabledIdleLocked	



Note

Although, the EnabledIdleUnlocked is used for the errored state (admin status up), this does not follow the TGO standard definitions, however within the standard definitions there is no available combination that accurately represents this state.

Views

Cisco 12000/10720 Router Manager views can be accessed by clicking on the Viewer icon in the Cisco EMF launchpad. These views appear in the frame at the left of the window when you open the Map Viewer window (see [Figure 2-4 on page 2-11](#)).

Cisco 12000/10720 Router Manager views model hierarchical relationships between objects, both physical and logical. Objects are organized into different views and can exist in multiple views simultaneously by reference. Each object can have a number of parent and child objects. You can access Cisco 12000/10720 Router Manager objects by navigating through one of the views to find the object. You can navigate through views by expanding text. Click on the + sign next to any object to expand text. A - sign next to an object indicates there is no more text to expand. Each view represents a different way of containing and grouping objects.

Cisco 12000/10720 Router Manager adds specific views to the standard views supplied by Cisco EMF. The standard Cisco EMF views are the Physical and Network views (for further information on these views, refer to the *Cisco Element Management Framework User Guide Release 3.2*).

The number in parenthesis next to a view indicates how many top-level objects are contained within the view.


The Views section covers the following areas:

- [Component Managed View](#)
- [Layer 3 QoS View](#)
- [Network View](#)
- [Physical View](#)
- [VLAN View](#)

Component Managed View

The Component Managed view displays all objects within the Cisco EMF system. The Component Managed view displays all the physical objects and most of the logical objects.

Figure 2-4 Hierarchy of Component Managed View



Layer 3 QoS View

The Layer 3 QoS view displays only Layer 3 QoS objects within Cisco 12000/10720 Router Manager, such as the following:

- Access Lists
- CAR objects
- WRED objects

You can work within this view to create and configure Access Lists or CAR or WRED objects by accessing the respective Cisco 12000/10720 Router Manager menus.


Network View

This view displays all network devices within their relevant networks and subnets. The auto-discovery system of Cisco EMF uses this view to calculate which devices have already been added to the system, so that it does not try to discover the same device multiple times. For details on auto-discovery, see [“IP Auto Discovery of the Cisco Chassis”](#) section on page 3-19.

Physical View

Physical view displays all the physical objects. Objects in the Physical view are ordered according to their relative physical location.

Figure 2-5 Hierarchy of Physical View



84627

VLAN View

The VLAN view displays the VLAN objects in Cisco 12000/10720 Router Manager. The VLAN view can contain one or more domains. A domain is a user-defined grouping of the VLAN objects. This grouping may be done on a customer name basis, on logical groupings like 'Accounting Vlans' or it could

be any other user maintained VLAN grouping. There can be multiple domains in the VLAN view and each domain can contain multiple VLAN objects. The same VLAN id can be duplicated across different domains. Each VLAN object can have multiple sub-interface objects.




Note

The sub-interface objects are shown only under the VLAN objects and in the component managed view. Only Ethernet sub-interfaces are displayed.

Cisco 12000/10720 Router Manager Object States

Cisco 12000/10720 Router Manager object states reflect the life cycle of an object. Whatever stage the object is in at any given time is reflected in the state type. The state of an object can change frequently, depending upon what actions are being performed on the object. All objects in Cisco 12000/10720 Router Manager have a state assigned to them which appears at the bottom left corner of each FCAP window for a selected object (see [Figure 2-6](#)).

Figure 2-6 Cisco 12000/10720 Router Manager Object States



The two most common object states are Normal and Decommissioned. For example, when you deploy a line card in Cisco 12000/10720 Router Manager, the initial state of the line card is decommissioned. You can then commission the line card to begin active management (for details on how to commission a module, see [“Commissioning a Selected Module”](#) section on page 5-4). When you commission the line card, it passes through two transitory states: discovery and commissioning. The commissioning process determines which state to move the object into (typically Normal). This example reflects the basic process of deploying and commissioning an object.

Certain states ripple down to any objects below. For example, if you decommission a chassis, all subchassis objects are also decommissioned. If you enable performance logging on a line card, all interfaces on the line card are also transitioned to performance logging.

By default, FCAP windows refresh at a rate dependent upon the type of window. For example, inventory windows are refreshed at a lower rate than performance windows. The average refresh rate is every 30 seconds.

The following sections describe the possible states that an object may be in and provides a description of these states.

Decommissioned State

The decommissioned state indicates that an object is not managed. When you manually deploy an object, it is normally placed into a decommissioned state.



Tip

Initially deployed objects are decommissioned to leave you with the option of managing the object or not. If you want to manage the object, you need to commission the object.

The following actions occur on a decommissioned object:

- Active management stops
- All sub objects are also decommissioned

Decommission buttons are located in Chassis, Module, Interface and VLAN Configuration windows. When you decommission an object, any children of that object also change their state to decommissioned. For example, if you decommission a chassis, all objects within that chassis (GRP card, line cards, interfaces, connections) are also decommissioned. If you decommission a line card, all interfaces and connections on that line card are decommissioned, and so on.

Normal State

The normal state indicates that an object is operational. When any physical object enters the normal state, Cisco 12000/10720 Router Manager performs heartbeat polling on the objects. The heartbeat polling interval for chassis object is 1 minute and for all modules and interface objects, the heartbeat polling interval is 5 minutes.

Errored

When the object is in a non-operational state, it moves into the errored state. In the errored state, performance polling (if activated) is stopped; however, the heartbeat polling (which polls an object every 5 minutes to verify its existence and current state) continues, until the device responds positively to the heartbeat request. When the module is operational again, it responds positively to the heartbeat requests, and then moves into the state which it previously held.

Performance Logging On

When performance logging is started on an object in the Normal state, the object moves into the Performance Logging On state. This means that the performance data is collected on the object and is viewed in the Performance windows or the Performance Manager windows. Performance logging is enabled for GRPs, interfaces and VLAN sub-interfaces. You can enable performance logging on a global scale or on an individual object basis. Enabling global performance logging puts all subchassis objects into a performance logging on state. However, remember that only GRPs and interfaces actually collect performance data. (For more information on global performance logging, see [“Starting Global Performance Logging” section on page 4-9](#).)

Performance logging occurs every 15 minutes. This means that when you enable performance logging or global performance logging initially on an object, it takes 15 minutes for the data to be collected and displayed in Cisco 12000/10720 Router Manager performance menus.

Heartbeat polling is performed on an object in the performance logging on state. If the object moves into the errored state, it is returned to the performance logging on state when the error is rectified. For example, if a line card is in the performance logging on state and it goes down in the device, the EM moves the line card into the errored state. When heartbeat polling finds that the line card is operational, the EM restores the line card to the performance logging on state.

Lost Comms

The lost comms (lost communications) state indicates that the object is not contactable. Cisco 12000/10720 Router Manager can apply this state to a chassis, module, or interface. During this state, heartbeat polling is performed on the object. When the object becomes contactable again, it moves out of the lost comms state.

Discovery Lost Comms

The discovery lost comms state is quite similar to the lost comms state; however, this state only occurs during subchassis discovery. For example, if you commission a chassis (which begins the process of subchassis discovery), and if a pre-deployed line card is not present then, the line card is moved into the discovery lost comms state. When the linecard is re-inserted in the device, subchassis discovery is resumed, and the object moves out of the discovery lost comms state.

Mismatched

The mismatched state occurs when a mismatch is found between what is in the hardware and what is deployed in Cisco 12000/10720 Router Manager. For example, say you are expecting an ATM OC-3 line card. So you predeploy and perform offline configuration in Cisco 12000/10720 Router Manager to prepare for that type of line card. Now, when the line card becomes available and is placed into the chassis, it is not an ATM OC-3 line card, but a POS OC-3 line card. So when Cisco 12000/10720 Router Manager detects the new line card, it finds a mismatch. The line card gets placed into the mismatch state, and a major alarm is raised against the line card.

Transient Object States

Certain states in Cisco 12000/10720 Router Manager are temporary or transient, that is, they exist only for a short time while a process is being performed. The following states are transient:

- **Download**—Temporary state that is assigned to objects in Cisco 12000/10720 Router Manager when an Cisco IOS Download is being performed.
- **Discovery**—Temporary state that is assigned to objects in Cisco 12000/10720 Router Manager during subchassis discovery. Objects are being discovered at this stage.
- **Synchronization**—This temporary state is applicable only for chassis. During this state, the EM synchronizes with its ATM connection information with the device.



Getting Started

This chapter describes the typical tasks you should complete to start using the Cisco 12000/10720 Router Manager application. See [Figure 3-1 on page 3-2](#) for further details.


This chapter provides the following information:

- [Cisco 12000/10720 Router Manager Workflow](#)
- [Starting Cisco EMF and Cisco 12000/10720 Router Manager](#)
- [Deployment](#)

Cisco 12000/10720 Router Manager Workflow

[Figure 3-1](#) outlines the steps involved in installing, configuring and using the Cisco 12000/10720 Router Manager application.

Figure 3-1 Workflow for Cisco 12000/10720 Router Manager



Starting Cisco EMF and Cisco 12000/10720 Router Manager

The Cisco 12000/10720 Router Manager application is viewed through the Cisco Element Management Framework (Cisco EMF). It is important to understand how Cisco EMF works before you use the Cisco 12000/10720 Router Manager application (refer to the *Cisco Element Management Framework User Guide* for further details). Cisco 12000/10720 Router Manager automatically starts when you start a Cisco EMF user session.

**Note**

Each active Cisco EMF session uses a single Cisco EMF user license.

This section covers the following:

- [Starting a Cisco EMF User Session](#)
- [Launchpad](#)
- [Quitting a Cisco EMF User Session](#)

Starting a Cisco EMF User Session

**Note**

Cisco EMF should already be running. When you try to invoke a Cisco EMF session, and if you receive a message that Cisco EMF is not running, contact your system administrator, or refer to the *Cisco Element Management Framework User Guide* for further details.

To start a Cisco EMF user session, proceed as follows:

Step 1



From the command line on the terminal window, enter `<CEMF_ROOT>/bin/cemf session`

**Note**

`<CEMF_ROOT>` is the Cisco EMF installation root directory (for example, `/opt/CEMF`).

The Login window (see [Figure 3-2](#)) appears.

Figure 3-2 Login Window



75403

Step 2 Enter a valid user name and password.

Step 3 Click **Ok** to proceed.

When an unknown user name or password is entered, an error is displayed. Click **Ok**, then enter a valid user name and password.




Note You have three attempts to enter a valid user name and password. After the third failed attempt the session does not start and the Login window closes.

When a valid user name and the password are entered, the session starts and the Cisco EMF Launchpad (see [Figure 3-3](#)) appears.

Launchpad

The icons displayed in the CEMF Manager and Event Manager panels on the Launchpad represent the applications provided by this Cisco EMF installation. Extra icons may appear when additional packages are installed. The icons (see [Figure 3-3](#)) represent the standard Cisco EMF tools.

Figure 3-3 Launchpad



Launching an Application

From the Launchpad, click the desired icon. The application is launched. A “busy” icon and a message in the status bar is displayed during launch. More than one instance of an application can be opened at any time.



Note

If an application is already open, it appears in the Windows list. Click **Window** and choose the application you require from the drop down menu.

Map Viewer (Viewer)

MapViewer allows complete flexibility in viewing, building, and monitoring your network using graphical representations of network elements.

MapViewer is the primary entry point into the Cisco 12000/10720 Router Manager. When the MapViewer application is launched, a window appears corresponding to the highlighted map icon in the hierarchy pane. You can easily monitor the status of all network elements or abstractions of elements contained within the network and you can launch any of the additional applications on the Launchpad.

Refer to the *Cisco Element Management Framework User Guide* for further details on the MapViewer application.

Groups

Object Group Manager allows you to organize network elements into object groups. An object group is a collection of objects which are related in some way. They may all be the same type of equipment or all belong to the same customer.

Object groups can be built manually or by building a query. Some Cisco EMF subsystems may also build object groups which may be visible and usable by the Cisco EMF user.

Refer to the *Cisco Element Management Framework User Guide* for further details on the Object Group Manager application.

Access

User Access Control allows system administrators the opportunity to control the features of their system that can be accessed by various levels of personnel. This is important for secure network management.

Refer to the *Cisco Element Management Framework User Guide* for further details on the User Access Control application.

Event Browser (Events)

One of the most important aspects of Network Service Management is the ability to identify faults and other events on the network and to take action to resolve them quickly and efficiently. For example, there may be a power supply fault in a chassis which would require an engineer to be sent out to rectify the fault. This fault is critical to the running of the network and would need prompt attention.

In Cisco EMF, when a condition (fault) occurs on a managed object in the network, the system is notified immediately. Notification is shown as an event and can be viewed with the Event Browser (when configured to do so).

Refer to the *Cisco Element Management Framework User Guide Release 3.2* for further details on the Event Browser application.

Discovery

Discovery allow you to examine the network for IP and SNMP devices and create a managed object for each new device discovered. Auto-discovery can be opened from the Launchpad window or from a pop up menu available on selected objects.

Refer to the *Cisco Element Management Framework User Guide Release 3.2* for further details on the Auto-discovery application.

Notification Profiles

An important aspect of a monitoring system which captures and reacts to events on the network is when and how a network operator is informed of these events. The Event Manager uses notifications for this. For example, when the temperature of a line card rises 10 degrees above normal an e-mail might be sent to the network operator warning of a potential problem and a minor event might be generated if the temperature does not fall to within ten degrees of normal within twenty minutes.

Notification profiles are collections of notifications. Each notification profile has a name and description and can be accessed by all Event Manager users. Each includes a list of notifications, and is run following a trigger, which could be an event entering an event group, or a threshold breach in a thresholding regime. For example, when the first event is received by an event group a notification profile may be triggered which causes a sound to occur which alerts the operator. As well as audible alerts, a notification could be set up to display on screen, or to trigger an external notification such as an e-mail.

Refer to the *Cisco Element Management Framework User Guide Release 3.2* for further details on the Notification Profiles application.

Thresholding Regimes

A Thresholding Regime is a set of threshold conditions for specified object attributes which, when breached, causes one or more notification profiles to be run. The Thresholding Regime defines which attributes should be polled and on what period, and defines the thresholding conditions. The Thresholding Regime specifies object groups which contain the objects whose attributes will be polled.

Refer to the *Cisco Element Management Framework User Guide Release 3.2* for further details on the Thresholding Regimes application.

Event Groups

Event Groups allows you to organize network elements into event groups, and also view the status of these groups as scoreboards. Users can create, delete and modify event groups and scoreboards. Event groups are available to all users.

Event groups can be any combination of objects derived from the managed object class. These groups are set up using queries which can be configured to match your requirements. For example, you could choose to monitor a particular device, specify a time period, and choose to look at events which are warnings or critical. You define a query so that the event group only includes the events which meet the criteria you define. As soon as the group is created it starts monitoring against the criteria specified in the event query setup. Event groups created in the Event Groups application are persistent, they are not cleared when the application is closed.

The Event Groups application also enables you to view the events associated with an event group in a scoreboard format. This displays the overall status of the event group as a pie chart, with the associated severity color coding. A scoreboard also shows the total number of events which have entered the event group and the highest severity of the events in the group. An icon is displayed when a running notification has been set up for the event group.

Event Groups is opened from the Launchpad.

Refer to the *Cisco Element Management Framework User Guide Release 3.2* for further details on the Event Groups application.

PreFilter

Event pre-filtering allows any event generated by the network which matches the criteria established in the filter to be “filtered out”, and thus not saved into the database.

Pre-filtering offers you the capability to eliminate unwanted or undesired events from entering the management system altogether. Pre-filtering is managed through the PreFilter application or from the Event Browser. The PreFilter application is launched via the PreFilter icon on the Launchpad.

The PreFilter manager window displays, listing each of the pre-filters established, in the order in which they are to be processed (from top to bottom).

Refer to the *Cisco Element Management Framework User Guide Release 3.2* for further details on the PreFilter application.

Quitting a Cisco EMF User Session

To quit the current Cisco EMF session, proceed as follows:

-
- Step 1** Choose **File > Quit**. You see the question `Do you wish to quit the Cisco EMF Manager System?`.
- Step 2** Click **Yes** to quit the session (all active applications are closed and the session terminates) or click **No** to return to the current Cisco EMF session.
-

Deployment

The first step toward managing a Cisco 12000/10720 Router is to deploy or pre-deploy the physical objects that you want to manage. Deploying a physical object creates a representative object in Cisco EMF and as a result, makes the Cisco 12000/10720 Router Manager application aware of the physical object’s presence.

Cisco 12000/10720 Router Manager objects can be discovered automatically or deployed manually. For example, to deploy a chassis, you can use auto discovery or you can manually deploy the chassis. If you wish to deploy objects under the chassis, you can use subchassis discovery or manually deploy each object (interfaces are automatically created when you deploy each line card).

If all or most of your chassis objects are physically present and if you have a large amount of objects to deploy, you might want to automate these processes by using auto discovery. For example, if Cisco 12000/10720 Router Manager is installed into an existing network of Cisco 12000/10720 Routers, auto discovery can dramatically reduce the amount of operator input required. If you only want to deploy a few objects or if many of your objects are not yet physically present, you might want to deploy manually.

Cisco 12000/10720 Router Manager objects can be manually pre-deployed before the hardware arrives on-site. See [“Pre-deployment” section on page 3-58](#) for further details.

The following supporting modules can be deployed using subchassis discovery only, no manual deployment is available for these modules:

- AC or DC power supply card
- Fan tray module
- Blower module

You can also deploy either of the following logical objects:

- SVC—See “[Deploying an SVC Object](#)” section on page 12-22
- PVC—See “[Deploying a PVC Object](#)” section on page 12-18
- VLAN Domain, VLAN and VLAN sub-interface—See “[Deploying VLAN objects](#)” section on page 13-4



Tip

WRED (Weighted Random Early Detection) and CAR (Committed Access Rate) objects are not created using the deployment wizard. For details on creating these objects manually, see [Chapter 11, “Layer 3 QoS.”](#)


The Deployment section covers the following areas:

- [Deployment Process Outline](#)
- [Manually Deploying a Generic Site Object](#)
- [IP Auto Discovery of the Cisco Chassis](#)
- [Manually Deploying a Cisco 12000/10720 Chassis](#)
- [Commissioning and Subchassis Discovery](#)
- [Manually Deploying Modules](#)—Includes deploying line cards for 12000 Series router chassis and 10720 chassis
- [Pre-deployment](#)

Deployment Process Outline

Producing a manageable Cisco 12000/10720 Router chassis in Cisco EMF is a three-stage process (see [Figure 3-4](#)).

Figure 3-4 Deployment Process Workflow



1. The first deployment stage is to manually deploy a Generic (Site) object. A Site object can be looked upon as a container object where you can deploy further objects that represent the Cisco 12000/10720 Router chassis, line cards and interfaces contained within the chassis. See [“Manually Deploying a Generic Site Object”](#) section on page 3-10 for further details.
2. The second deployment stage is at the chassis level. The Cisco 12000/10720 Router chassis can be auto discovered or manually deployed. See [“IP Auto Discovery of the Cisco Chassis”](#) section on page 3-19 or the [“Manually Deploying a Cisco 12000/10720 Chassis”](#) section on page 3-20 for further details.



Note You can pre-deploy objects (that is, manually predeploy objects) before the Cisco hardware arrives on-site. See [“Pre-deployment”](#) section on page 3-58 for further details.

3. The third deployment stage is at subchassis level. This involves either subchassis discovery or deploying subchassis objects (modules) manually. See [“Commissioning and Subchassis Discovery”](#) section on page 3-26 or the [“Manually Deploying Modules”](#) section on page 3-30 for further details.

Manually Deploying a Generic Site Object

Generic objects are non-technology specific objects. When deploying a generic object, the information you are prompted to provide differs according to the type and number of generic objects you are deploying.

[Table 3-1](#) displays a list of generic objects that can be deployed using Cisco 12000/10720 Router Manager.


Table 3-1 Generic Object Deployment Templates

Object to be Deployed	Deployment Templates Available
Generic	Bay
	IP Device
	Region
	SNMP Agent
	SNMP MIB-2 Agent
	SNMP Proxied Device
	Site

This section provided an example that shows how to deploy a Site object. The deployment process differs slightly for other types of generic object.


To deploy a Generic (Site) object, proceed as follows:

-
- Step 1** Place the cursor over a relevant object to determine the objects you can deploy from. In this example we will deploy a Site object from the Physical view.
 - Step 2** Click and hold down the right mouse button.
 - Step 3** Choose **Deployment>Deploy Generic Objects...**

Figure 3-5 Deploying a Site Object

The Deployment Wizard - Templates window appears (see [Figure 3-6](#)) displaying a list of available generic object deployment profiles. Deployment profiles are templates that prompt you for the appropriate information required to deploy the selected object successfully.


Figure 3-6 Deployment Wizard - Templates Window



- Step 4** Select the generic object that you wish to deploy from the list supplied. In this example (shown in [Figure 3-6](#)) shows the deployment profile for a Site object is selected. The Deployment Wizard steps through a series of windows that prompt you for the information required to deploy the Site object.
- Step 5** Click **Forward**.

The Deployment Wizard - Object Parameters window appears (see [Figure 3-7](#)).


Figure 3-7 *Deployment Wizard - Object Parameters Window (1 of 2)*



Step 6 Enter the number of **Sites** required. A single site was entered in this example.

Step 7 Click **Forward**.


Figure 3-8 Deployment Wizard - Object Parameters Window (2 of 2)



- Step 8** Enter a Site name. Each Site must have a unique name. In this example the site is called **Site-srp**.
- Step 9** Click **Forward**.

The Deployment Wizard - Views window appears.


Figure 3-9 *Deployment Wizard—Views Window*



Step 10 Click **Select**, to select a physical view.


The Object Selector Window appears.

Figure 3-10 Object Selector



- Step 11** Select the object where you wish to place the Site object.
- Step 12** Click **Apply**. The Deployment Wizard - Views window re-appears with the selection displayed.

Figure 3-11 Deployment Wizard—Views Window




Step 13 Click **Forward**.



Note You are prompted to repeat Steps 8 to 13 if you are deploying more than one Site.


The Deployment - Wizard Summary window appears. The Summary window provides details of the object you are about to deploy.

Figure 3-12 Deployment Wizard—Summary Window



- Step 14** Click **Finish** (when the Deployment Summary information is correct) to complete deployment and close the Deployment Wizard - Summary window. The new Site object (that is, Site-srp) is created and displayed in the Map Viewer window.

Figure 3-13 Example Showing the Newly Deployed Site-srp Object



**Note**

This deployment procedure can be applied to the deployment of any of the generic objects although all of the steps may not apply to the particular generic object that you are deploying.

IP Auto Discovery of the Cisco Chassis

Auto discovery is the application that discovers existing Cisco 12000/10720 Routers, saving time and effort.

The auto discovery window can be opened from the Viewer or Discovery icon in the Launchpad. For further information, refer to the *Cisco Element Management Framework User Guide*.

The Auto discovery application has three mechanisms for discovering chassis:

- IP—ICMP pings are used to find chassis in a given IP address range. This finds which IP devices exist, but does not discover what kind of device they are.
- SNMP—SNMP get requests are used to find chassis in a given IP address range. Several SNMP community strings can be used so that equipment with different community strings can be discovered in the same discovery session. The SNMP information returned by devices is used to work out what kind of device has been found.
- IP and SNMP—ICMP pings are used to find chassis and then SNMP requests are used to interrogate the chassis to find out what kind of chassis they are. This is the default mechanism.


Auto discovery can discover chassis on more than one subnetwork using multi-hop discovery. It can be scheduled to run at preset times (the *Cisco Element Management Framework User Guide* details how to set the schedules).

After the chassis is detected, an object representing the chassis is created and placed under the site from which auto discovery was launched. A map of the chassis is also created, as shown in [Figure 3-21 on page 3-26](#).

**Note**

If you wish to auto-discover a chassis that can be managed by Cisco 12000/10720 Router Manager, then the Physical Path option must be enabled and an appropriate Physical Path (terminated with a Site) must be selected. Provided this is done, the auto discovery application will create a chassis below the selected Physical Path for each discovered chassis.

Figure 3-14 Example of Auto Discovery



Manually Deploying a Cisco 12000/10720 Chassis




Tip

It is recommended that you ping the Cisco 12000/10720 Router you intend to deploy to ensure the device can be contacted.

To deploy a chassis, proceed as follows:

- Step 1** In the Map Viewer, right click on the site object under which you wish to deploy the chassis, then choose **Deployment>Cisco 12000/10720 Manager>12008 or 12012 or 12016 or 12404 or 12406 or 12410 or 12416 or 10720>Chassis**. The Deployment Wizard appears.

Figure 3-15 Deployment Wizard—Object Parameters (1 of 3)



Step 2 Enter the number of **chassis** objects you want to deploy. Click **Forward**.

Figure 3-16 Deployment Wizard—Object Parameters Window (3 of 3)

84771

Step 3 Enter the following information:

12000 Chassis Name—Type in a name (including prefix and suffix) for the chassis you are deploying. A default prefix appears (for example, “12008”). You can delete this prefix and use your own, or you can keep it and add your own suffix. This name must be unique.

IP Address—Type in the IP address for the chassis you are deploying.

Subnet Mask—The subnet mask for the IP address of the chassis.

SNMP Details—Type in the SNMP read and write communities, and select the SNMP version. The default SNMP version is 2c.


Chassis Initial State—Specify the initial state for the chassis after deployment. The default initial state of the chassis is decommission. When the user selects commission, the chassis is automatically commissioned upon deployment.



Note Cisco 12000/10720 Router Manager allows the user to deploy a single chassis, more than once provided they have unique subnet masks.


Step 4 Click **Forward** to continue. The Deployment Wizard-Views window appears.

Figure 3-17 Deployment Wizard—Views




Step 5 Click on Select. The Object Selector window appears.

Figure 3-18 Object Selector Window




- Step 6** Choose the site under which you want to deploy the chassis. Click Apply. The Deployment Wizard-Views window is displayed with the selected Site object.

Figure 3-19 Deployment Wizard—Views



- Step 7** Click Forward. A Deployment Wizard Summary window is displayed.

Figure 3-20 Deployment Wizard Summary




- Step 8** The Deployment Summary details appear in the Deployment Summary Screen. If the Deployment Summary information is correct, click **Finish**. If the Deployment Summary information is incorrect, click **Cancel** to stop deployment.
- Step 9** To proceed, you have two options:
- To perform subchassis discovery, see [“Commissioning and Subchassis Discovery” section on page 3-26](#)
 - If you wish to continue deploying individual modules, proceed to the [“Manually Deploying Modules” section on page 3-30](#).

Commissioning and Subchassis Discovery

After you deploy a chassis, the next step in creating a manageable system is to commission the chassis (which begins the process of subchassis discovery). [Figure 3-21](#) shows a Cisco 12008 chassis map in the Physical view before subchassis discovery. Subchassis discovery discovers all physical objects (that is, modules and interfaces) within the chassis and places them onto the chassis map.

Figure 3-21 Before Subchassis Discovery



Line cards and interfaces located within the chassis are discovered at this time. Commissioning not only discovers all the physical objects within the chassis, but also uploads the ATM connection objects (ATM PVC objects only) and initiates heartbeat polling that allows alarms to be raised on the chassis and all the physical objects within the chassis.

Because the chassis is the highest-level object, all objects under the chassis are commissioned as well when you commission the chassis. One level down, if you commission a GRP, you commission all physical objects underneath that level. If you commission a line card, you commission all interfaces on that line card, and so on. However, note that before you can commission any module within a chassis, the chassis object itself must be commissioned. This means that you must run subchassis discovery by commissioning the chassis before you can commission or decommission any individual objects under the chassis. If you do not want to actively manage all objects within the chassis, you can decommission the objects you are not ready to manage after commissioning the chassis.

**Tip**

If you are not ready to commission the chassis, you can manually deploy modules within the chassis (for details, see [“Manually Deploying Modules” section on page 3-30](#)). Modules can also be commissioned individually, provided the chassis is commissioned.


Commissioning a Chassis

When you commission a chassis, subchassis discovery begins automatically. Subchassis discovery discovers and commissions all objects within the chassis. Commissioning automatically starts active management (such as polling) on the chassis and all commissioned objects within the chassis.

To commission a chassis, proceed as follows:

- Step 1** It is recommended that the Cisco IOS Username and Passwords are set correctly before proceeding. Right click on the Site object that contains the chassis you wish to commission, then choose **Cisco 12000/10720 Manager>Configuration>Chassis>Configuration**. The Chassis Configuration window appears.

Figure 3-22 Chassis Configuration Window



- Step 2** Choose the **Chassis** you want to commission from the list box at left of the window. Cisco 12000/10720 Router Manager allows you to select and commission multiple chassis simultaneously.



Note To select a contiguous block of chassis, click on the first chassis; then, without releasing the mouse button, drag to the last desired entry and release. A subsequent click anywhere on the window deselects all previous selections. To extend a currently selected block of chassis, hold the **Shift** key down and click on the entry at the end of the group to be added. To add a non-contiguous entry to the selection group, hold down the **Ctrl** (Control) key and click on the entry to be added. It is recommended to commission at the most 15 chassis at a time.

- Step 3** Configure the parameters displayed on the Configuration and Additional Description tabs, as required.



Note See “[Chassis Configuration](#)” section on page 4-7 for detailed information on the Chassis Configuration window.

- Step 4** Click **Commission** (located in the Actions frame).

Decommissioning a Chassis

Decommissioning a chassis, decommissions all the objects within the chassis, and active management (such as polling) stops on the chassis and on all objects within the chassis.

To decommission a chassis, proceed as follows:

-
- Step 1** Right click on the chassis you want to decommission, then choose **Cisco 12000/10720 Manager>Configuration>Chassis>Configuration**.
- The Chassis Configuration window appears (see [Figure 3-22](#)).
- Step 2** Choose the **Chassis** you want to decommission in the Chassis list box at left of the window.
- Step 3** Click **Decommission** (located in the Actions area). The chassis and all objects contained within the chassis are decommissioned. A status report appears in the Commission Status area, which shows whether the action has succeeded or failed.
-

Object States

After subchassis discovery all objects enter a specific state. See [“Cisco 12000/10720 Router Manager Object States” section on page 2-13](#) for details about object states.

Manually Deploying Modules

This section details the procedure to manually deploy modules using the Deployment Wizard. You can manually deploy modules before they are physically present (for details, see [“Pre-deployment” section on page 3-58](#)). In this scenario, you need to manually deploy modules, as a subchassis discovery will not pick up their presence. You can also decommission these modules if you do not want active management to be carried out on them.

Deployable modules include the following:

- GRPs
- Line cards (ATM, POS, Ethernet, DS-3, SRP or Modular Ethernet)



Tip

Supporting modules, such as AC or DC power supply cards, fan tray modules, and blower modules, can only be deployed through subchassis discovery. You cannot manually deploy these modules.



Note

Manual deployment of SRP Modules is currently not supported.

User Named vs. Auto Named Module Deployment

When you deploy a module, you have two initial options:

- To deploy an auto-named module
- To deploy a user-named module

The user-named option allows you to name the module as you like. For example, if you have a specific naming scheme you want to use, then select the user-named option.

The auto-named option assigns an auto-generated name to the module, with the slot number appended to the name. For example, if you deployed an auto-named ATM line card in slot 5, the name given would be "A5." This option is most useful when you have numerous line cards of the same type to deploy.

However, the line cards must be deployed in sequence within the slots. For example, if you wanted to deploy five ATM line cards in slots 1 to 5, then the auto-named option would be ideal.

Manually Deploying a GRP Card

Each chassis must have at least one GRP card deployed. A second optional GRP card can be deployed for the purpose of redundancy.




Note

This feature is not applicable to the 10720 chassis

To deploy a GRP, proceed as follows:


-
- Step 1** Right-click on the slot within the chassis where you want the GRP to be deployed, then choose **Deployment>Cisco 12000/10720 Manager>Module>RP>GRP**. The Deployment Wizard appears.

Figure 3-24 Deployment Wizard—Templates



- Step 2** Choose one of the Template Choices from the list displayed (either auto-named or user-named deployment). Ensure that your choice is highlighted before continuing. See [“User Named vs. Auto Named Module Deployment”](#) section on page 3-31 for further information on auto vs. user named deployment.
- Step 3** Click **Forward**. The Deployment Wizard - Object Parameters window appears.

Figure 3-25 Deployment Wizard—Object Parameters




- Step 4** Enter the Number of GRP objects you wish to deploy. Enter in the slot number where you want the GRP to be deployed. If you are deploying two GRPs, the primary GRP must be placed in a slot with a lower number than the secondary GRP.

**Caution**


If you deploy a module in a slot that is already occupied, deployment will fail at the **Finish** point. Also deployment fails, if a module is deployed with a name that already exists in the EM.

- Step 5** Click **Forward**. The Deployment Wizard - Views window appears. Two Cisco 12000/10720 Router Manager views are displayed at the left side of the Deployment Wizard - Views window (that is, Physical and ComponentManaged).

Figure 3-26 Deployment Wizard—Views


Step 6 Click **Select**. The Object Selector window appears.

Figure 3-27 Object Selector Window



- Step 7** Navigate through the hierarchy and choose the chassis that the GRP will be deployed within. Grayed out objects are not available for selection.
- Step 8** Click **Apply**. The Deployment Wizard - Views window re-appears with the location where the object will be placed.

Figure 3-28 Deployment Wizard—Views




Step 9 Repeat Steps 6 to 8 to place the chassis object in each of the Physical and ComponentManaged views.



Note You are prompted to repeat steps 6 to 8 if you are deploying more than one GRP card.

Step 10 Click **Forward**. The Deployment Wizard-Summary window appears.

Figure 3-29 Deployment Wizard—Summary



- Step 11** The deployment summary details appear in the Deployment Summary window. If the deployment summary information is correct, click **Finish**. If the deployment summary information is incorrect, click **Cancel** to stop deployment.



Note Two objects are deployed when deploying each GRP card: the GRP module object itself, and the Ethernet interface object, representing the Ethernet interface on the GRP.

Manually Deploying Line Cards

The Cisco 12000 Series Router chassis supports six types of technology specific line cards (ATM, POS, Ethernet, SRP, DS-3 and Modular Ethernet). See [Table 3-2](#) to [Table 3-7](#) for further details.

Line Cards Supported by Cisco 12000 Series Routers

[Table 3-2](#) displays a list of the ATM line cards supported by Cisco 12000 Series Routers.

Table 3-2 ATM Line Cards Supported by Cisco 12000 Series Routers

Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
atm-qoc3-sm	ATM > OC-3 4 > SM	4 Port OC3 ATM Single Mode (SM) Line Card
atm-qoc3-mm	ATM > OC-3 4 > MM	4 Port OC3 ATM Multi Mode (MM) Line Card
gsr-en-8oc3	ATM > OC-3-8 > SM	GSR enhanced 8 port OC3c/STM-1 ATM Line Card
sr-atm-en-8oc3-mm	ATM > OC-3-8 > MM	GSR enhanced 8 port OC3c/STM-1 Multimode ATM Line Card
atm-oc12-sm	ATM > OC-12 1 > SM	Single Port OC-12 Single Mode (SM) Line Card
atm-oc12-mm	ATM > OC-12 1 > MM	Single Port OC-12 Multi Mode (MM) Line Card
gsr-qoc12-sm	ATM > OC-12 4 > SM	4 port OC12 ATM Single Mode (SM) Line Card
gsr-qoc12-mm	ATM > OC-12 4 > MM	4 port OC12 ATM Multi Mode (MM) Line Card
gsr-e48-atm-4oc12-mm-sr-sc	cannot be manually deployed	GSR Edge Engine 48, ATM, 4 port OC12/STM4Multi Mode Short Reach Line Card
gsr-e48-atm-4oc12-sm-ir-sc	cannot be manually deployed	GSR Edge Engine 48, ATM, 4 ports OC12/STM4 Single Mode Intermediate Reach Line Card

[Table 3-3](#) displays a list of the POS line cards supported by Cisco 12000 Series Routers.

Table 3-3 POS Line Cards Supported by Cisco 12000 Series Routers

POS		
Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
pos-qoc3-sm	POS > OC-3 4 > E4 SM	4 Port Packet Over SONET OC-3c/SM Single Mode Line Card
pos-qoc3-sm-l	POS > OC-3 4 > E4 SM-LR	4 Port Packet Over SONET OC-3c/STM-1 Single Mode Long Reach Line Card
pos-qoc3-mm	POS > OC-3 4 > E4 MM	4 Port Packet Over SONET OC-3c/MM Multi Mode Line Card
gsr-e48-pos-4oc3-mm-sr-mtrj	POS > OC-3 4 > E4+ MM-SR	4 Port POS OC 48 Multi Mode Short Reach Line Card
gsr-e48-pos-4oc3-sm-lr-lc	POS > OC-3 4 > E4+ SM-LR	4 Port POS OC 48 Single Mode long Reach Line Card
gsr-e48-pos-4oc3-sm-ir-lc	POS > OC-3 4 > E4+ >SM-IR	4 Port POS OC 48 Single Mode Intermediate Reach Line Card

Table 3-3 POS Line Cards Supported by Cisco 12000 Series Routers (continued)

POS		
Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
pos-8oc3-mm	POS > OC-3 8 Port > E4 MM	8 Port OC3 Multimode POS
pos-8oc3-ir	POS > OC-3 8 Port > E4 SM	8 Port OC3 SM Intermediate Reach POS
pos-8oc3-lr	POS > OC-3 8 Port > E4 SM-LR	8 port OC3 SM Long Reach POS
gsr-e48-pos-8oc3-mm-sr-mtrj	POS > OC-3 8 Port > E4+ MM-SR	8 Port POS OC 3 multi MOde Short Reach Line Card
gsr-e48-pos-8oc3-sm-ir-lc	POS > OC-3 8 Port > E4+ SM-IR	8 Port POS OC 3 Single Mode Intermediate Reach Line Card
pos-oc12-sm	POS > OC-12 1 Port > SM	1 Port Packet Over SONET OC-12 Single Mode (SM) Line Card
pos-oc12-mm	POS > OC-12 1 Port > MM	1 Port Packet Over SONET OC-12 Multi Mode (MM) Line Card
pos-qoc12-sm-lr	POS > OC-12 4 Port > SM	4 Port (Quad) OC-12 POS Card, Single Mode, Long Reach
pos-qoc12-mm-sr	POS > OC-12 4 Port > MM	4 port (Quad) OC-12 POS Card, Single Mode, Short Reach
pos-en-qoc12-sr	POS > Enhanced OC-12 4 Port > MM	Enhanced 4 Port OC-12 Short Reach Line Card
pos-en-qoc12-ir	cannot be manually deployed	Enhanced 4 port OC-12 Intermediate Reach Line Card
pos-oc48-sm-lr-fc	POS > OC-48 > LR-FC	1 Port Packet Over Sonet OC-48, Single Mode, Long Reach, FC Connector Card
pos-oc48-sm-lr-sc	POS > OC-48 > LR-SC	1 Port Packet Over Sonet OC-48, Single Mode, Long Reach, SC Connector Card
pos-oc48-sm-sr-fc	POS > OC-48 > SR-FC	1 Port Packet Over SONET OC-48c/STM-16 Single Mode Short Reach with FC Connector
pos-oc48-sm-sr-sc	POS > OC-48 > SR-SC	1 Port Packet Over Sonet OC-48, Single Mode, Short Reach, SC Connector Card
pos-en-oc48-lr-fc	POS > Enhanced OC-48 > LR-FC	Enhanced OC-48 Long Reach FC Connector Line Card
pos-en-oc48-lr-sc	POS > Enhanced OC-48 > LR-SC	Enhanced OC-48 Long Reach SC Connector Line Card
pos-en-oc48-sr-fc	POS > Enhanced OC-48 > SR-FC	Enhanced OC-48 Short Reach FC Connector Line Card
pos-en-oc48-sr-sc	POS > Enhanced OC-48 > SR-SC	Enhanced OC-48 Short Reach SC Connector Line Card
pos-en-qoc48-sm-sr-sc	POS > Enhanced OC-48 4 > E4 SR-SC	4 Port (Quad) Enhanced OC-48 Short Reach SC Connector Line Card
pos-en-qoc48-sm-sr-fc	POS > Enhanced OC-48 4 > E4 SR-FC	4 Port (Quad) Enhanced OC-48 Short Reach FC Connector Line Card

Table 3-3 POS Line Cards Supported by Cisco 12000 Series Routers (continued)

POS		
Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
pos-en-qoc48-sm-lr-sc	POS > Enhanced OC-48 4 > E4 LR-SC	4 Port (Quad) Enhanced OC-48 Long Reach SC Connector Line Card
pos-en-qoc48-sm-lr-fc	POS > Enhanced OC-48 4 > E4 LR-FC	4 Port (Quad) Enhanced OC-48 Long Reach FC Connector Line Card
gsr-e-qoc48-sm-sr-sc	POS > Enhanced OC-48 4 > E4+ SR-SC	4 Port Enhanced OC 48 Short Reach SC Connector Line Card
gsr-e-qoc48-sm-sr-fc	POS > Enhanced OC-48 4 > E4+ SR-FC	4 Port Enhanced OC 48 Short Reach FC Connector Line Card
gsr-e-qoc48-sm-lr-sc	POS > Enhanced OC-48 4 > E4+ LR-SC	4 Port Enhanced OC 48 Long Reach SC Connector Line Card
gsr-e-qoc48-sm-lr-fc	POS > Enhanced OC-48 4 > E4+ LR-FC	4 Port Enhanced OC 48 Long Reach FC Connector Line Card
pos-oc192-sm-sr-sc	POS > OC-192 1 > E4 SR-SC	OC-192 Short Reach SC Connector Line Card
pos-oc192-sm-sr-fc	POS > OC-192 1 > E4 SR-FC	OC-192 Short Reach FC Connector Line Card
pos-oc192-sm-ir-sc	POS > OC-192 1 > E4 IR-SC	OC-192 Intermediate Reach SC Connector Line Card
pos-oc192-sm-ir-fc	POS > OC-192 1 > E4 IR-FC	OC-192 Intermediate Reach FC Connector Line Card
pos-en-oc192-sm-vsr	POS > OC-192 1 > E4 VSR	Enhanced OC-192 Very Short Reach Line Card
gsr-e-oc192-sm-sr2-sc	POS > OC-192 1 > E4 SR2-SC	GSR Edge 1 Port OC 192 Short Reach 2 SC Connector Line Card
gsr-e-oc192-sm-sr2-fc	POS > OC-192 1 > E4 SR2-FC	GSR Edge 1 Port OC 192 Short Reach 2 FC Connector Line Card
pos-en-oc192-sm-sr2-sc	POS > OC-192 1 > E4+ SR2-SC	Enhanced 1 Port OC 192 Short Reach 2 SC Connector Line Card
pos-en-oc192-sm-sr2-fc	POS > OC-192 1 > E4+ SR2-FC	Enhanced 1 Port OC 192 Short Reach 2 FC Connector Line Card
gsr-e-oc192-sm-sr-sc	POS > OC-192 1 > E4+ SR-SC	1 Port OC 192 Short Reach SC Connector Line Card
gsr-e-oc192-sm-sr-fc	POS > OC-192 1 > E4+ SR-FC	1 Port OC 192 Short Reach FC Connector Line Card
gsr-e-oc192-sm-ir-sc	POS > OC-192 1 > E4+ IR-SC	1 Port OC 192 Intermediate Reach SC Connector Line Card
gsr-e-oc192-sm-ir-fc	POS > OC-192 1 > E4+ IR-FC	1 Port OC 192 Intermediate Reach FC Connector Line Card
gsr-e-oc192-vsr	POS > OC-192 1 > E4+ VSR-SC	Enhanced OC-192 Very Short Reach SC Connector Line Card
pos-16oc3-lr	POS > OC-3 16 > E4 LR	16 Port OC3 SM long Reach POS

Table 3-3 POS Line Cards Supported by Cisco 12000 Series Routers (continued)

POS		
Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
pos-16oc3-ir	POS > OC-3 16 > E4 SM	16 Port OC3 SM Intermediate Reach POS
pos-16oc3-mm	POS > OC-3 16 > E4 MM	16 Port OC3 Multi Mode POS
gsr-e48-pos-16oc3-mm-sr-mtrj	POS> OC-3 16 > E4+ MM-SR	16 Port OC3 Multi Mode Short Reach POS
gsr-e48-pos-16oc3-sm-ir-lc	POS > ISE > OC-3 16 > IR	16 Port OC3 SM Intermediate Reach POS
gsr-e48-pos-qoc12-sm-ir-sc	POS > ISE > OC-12 4 > IR	4 Port OC12 SM Intermediate Reach POS
gsr-e48-pos-oc48-sm-ir-lc	POS > ISE > OC-48 1> IR	1 Port OC48 Intermediate Reach POS
gsr-e48-pos-oc48-sm-sr	POS > ISE > OC-48 1> SR	1 Port OC48 Short Reach POS
gsr-e48-pos-oc48-sm-lr	POS > ISE > OC-48 1> LR	1 Port OC48 Long Reach POS

Table 3-4 displays a list of the Ethernet line cards supported by Cisco 12000 Series Routers.

Table 3-4 Ethernet Line Cards Supported by Cisco 12000 Series Routers

Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
gsr-1ge	Ethernet > Giga > 1 Port	1 Port Gigabit Ethernet Line Card
gsr-3ge	Ethernet > Giga > 3 Port	3 Port Gigabit Ethernet Line Card (trident)
gsr-10pge	Ethernet>Giga > 10 Port	10 port Gigabit Ethernet Line Card
gsr-8fe-tx	Ethernet > Fast > 8 Port > Copper	8 port Fast Ethernet card with Copper Interface
gsr-8fe-fx	Ethernet > Fast > 8 Port > Fiber	8 port Fast Ethernet card with Fiber Interface
gsr-1p10ge	Ethernet > 10Giga > 1 Port	1 Port 10Giga Ethernet Line Card
gsr-pa-1ge	Ethernet > Modular > Gigabit/ FastEthernet Card	1 Port Modular Gigabit Fast Ethernet Line Card
gsr-pa-3ge	Ethernet > Modular > Port Adaptor > 3 Port Gigabit	3 Port Modular Port Adaptor Gigabit Line Card
gsr-pa-24fe	Ethernet > Modular > Port Adaptor > 24 Port FastEthernet	24 Port Modular Port Adaptor Fast Ethernet Line Card

Table 3-5 displays a list of the DS-3 line cards supported by Cisco 12000 Series Routers.

Table 3-5 DS-3 Line Cards Supported by Cisco 12000 Series Routers

Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
copper-6ds3	DS3 > 6 Port	6 Port Copper DS3 Interface Line Card
copper-12ds3	DS3 > 12 Port	12 Port Copper DS3 Interface Line Card

Table 3-6 displays a list of the E3 line cards supported by Cisco 12000 Series Routers.

Table 3-6 E3 Line Cards Supported by Cisco 12000 Series Routers

Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
copper-6e3	E3 > 6 Port	6 Port E3 Interface Line Card
copper-1e3	E3 > 12 Port	12 Port E3 Interface Line Card

Table 3-7 displays a list of the SRP line cards supported by Cisco 12000 Series Routers.

Table 3-7 SRP Line Cards Supported by Cisco 12000 Series Routers

Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
srp-oc12-sm-ir	cannot be manually deployed	1 Port OC-12 Single Mode SRP Intermediate Reach Line Card
srp-oc12-mm	cannot be manually deployed	1 Port OC-12 Multi Mode SRP Line Card
srp-oc48-sm-sr	cannot be manually deployed	1 Port OC-48 SRP Single Mode Short Reach Line Card
srp-oc48-sm-lr	cannot be manually deployed	1 Port OC-48 SRP Single Mode Long Reach Line Card
ssrp-e48-2oc12-sm-ir	cannot be manually deployed	2 Port OC 12 Single Mode Intermediate Reach Line Card
ssrp-e48-2oc12-sm-xr	cannot be manually deployed	2 Port OC 12 Single Mode Line Card
ssrp-oc192-sm-lr	cannot be manually deployed	GSR 1 port SONET based SRP OC-192c/STM-64
ssrp-oc192-sm-ir	cannot be manually deployed	OC 192 Single Mode Intermediate Reach Line Card
ssrp-oc192-sm-sr	cannot be manually deployed	OC 192 Single Mode Short Reach Line Card
ssrp-oc192-sm-vsr	cannot be manually deployed	OC 192 Single Mode Very Short Reach Line Card
gsr-dtp-dense48	cannot be manually deployed	A dual mode card. It can function as a 4xOC48 or 2xSRP48

Line Cards Supported by Cisco 10720 Routers

Table 3-8 displays a list of the SRP line cards supported by Cisco 10720 Routers.

Table 3-8 SRP Line Cards Supported by Cisco 10720 Routers

Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
srp-oc48-sr	cannot be manually deployed	1 port OC-48c SRP SM short reach uplink card
srp-oc48-ir	cannot be manually deployed	1 port OC-48c SRP SM intermediate reach uplink card
ul-srp48-lr1	cannot be manually deployed	1 port OC-48c SRP SM long (40km) reach uplink card
ul-srp48-lr2	cannot be manually deployed	1 port OC-48c SRP SM long (80km) reach uplink card
ul-pos-srp48-sm-sr	POS > SR	c10720 OC-48c POS/SRP SM short reach uplink card
ul-pos-srp48-sm-ir	POS > IR	c10720 OC-48c POS/SRP SM intermediate reach uplink card
ul-pos-srp48-sm-lr1	POS > LR1	c10720 OC-48c POS/SRP SM Long Reach (40Km) uplink card
ul-pos-srp48-sm-lr2	POS > LR2	c10720 OC-48c POS/SRP SM Long Reach (80Km) uplink card

Table 3-9 displays a list of the Ethernet line cards supported by Cisco 10720 Routers.

Table 3-9 Ethernet Line Cards Supported by Cisco 10720 Routers


Card Type	Cisco 12000/10720 Router Manager Menu Option	Card Description
acc-24fe-tx	Fast > 24 Port	24 port fast Ethernet TX access card
acc-24fe-fx-mm	Fast > 24 Port	24 port fast Ethernet FX MM (2km) access card
acc-24fe-fx-sm	Fast > 24 Port	24 port fast Ethernet FX SM (15km) access card

To deploy a line card of any type, proceed as follows:

- Step 1** Right click on the chassis object under which you want to deploy the line card, then choose **Deployment>Cisco 12000/10720 Manager>Module>ATM or POS or Ethernet or DS-3**, then choose the exact type of line card to be deployed (for example, OC-3 4 Port or OC12 1 Port). Now, choose the exact variant (for example, SM, or MM) if applicable.

The Deployment Wizard appears.

Figure 3-30 Deployment Wizard—Templates




- Step 2** Choose the type of deployment (either auto-named or user-named).

- Step 3** Click **Forward**.



Note The sample windows displayed are for an ATM OC-3 4 port MM line card.

Figure 3-31 Deployment Wizard—Object Parameters



Step 4 Enter the number of line card objects you want to deploy.


Step 5 Enter the slot number where the card will be deployed.



Note Deployment will fail (at the **Finish** point later on) if you try to deploy a module in a slot that is already occupied.


Step 6 Click **Forward**. The Deployment Wizard - Views window appears. Two Cisco 12000/10720 Router Manager views are displayed at the left side of the Deployment Wizard - Views window (that is, Physical and ComponentManaged).

Figure 3-32 Deployment Wizard—Views




- Step 7** Click **Select** to choose where you wish to place the object within the view. The Object Selector window appears.

Figure 3-33 Object Selector Window



- Step 8** Choose the chassis you want to place the ATM line card under. Objects which are not available for selection are greyed out. Click on the + sign to expand the view. Select the chassis under which you want to deploy the line card.
- Step 9** Once you have highlighted your selection, click **Apply**. The Deployment Wizard - Views window re-appears with the location where the object will be placed.

Figure 3-34 Deployment Wizard—Views




- Step 10** Repeat Steps 7 to 9 to place the object in each of the Physical and ComponentManaged views.
- Step 11** Click **Forward**.



Note You are prompted to repeat steps 4 through 11 if you are deploying multiple line cards.

The Deployment Wizard—Summary window appears.

Figure 3-35 Deployment Wizard—Summary



- Step 12** The deployment summary details appear in the Deployment Summary window. If the information is correct, click **Finish**. Click **Cancel** if the information is incorrect, and the deployment process stops.



Note

The number of objects deployed reflects the line card object plus the number of ports or interfaces on the line card. For example, if you have deployed an OC-3 4 port line card, 5 objects are deployed in total. The five objects are four interfaces and the actual line card.

Manually Deploying Supporting Modules

The Cisco 12000 Series Router chassis support the following supporting modules:

- Clock Scheduler Cards (CSCs)
- Switch Fabric Cards (SFCs)
- AC Power supply modules
- Fan tray modules
- Blower modules



Note

The AC power supply, fan tray and blower modules can only be discovered during subchassis discovery (that is, they cannot be manually deployed).

The Cisco 12000 Series Router chassis supports the following CSC and SFC line cards. See [Table 3-10](#) for further details.

Table 3-10 Cisco 12000/10720 Router Manager Supported CSC and SFC Line Cards


Card	Card Type	Card Description
CSC	CSC0	OC48 Clock Scheduler Card
	CSC4	OC48 ClockScheduler Card
	CSC8	OC48 Clock Scheduler Card
	CSC16	OC48 Clock Scheduler Card for 12016 chassis
	CSC16XOC192	OC192 Clock Scheduler Card for 12416 chassis
	CSC10XOC192	OC192 Clock Scheduler Card for 12410 chassis
	CSC6XOC192	OC192 Clock Scheduler Card for 12406 chassis
	CSCSFC64	Combined CSC-SFC card for 12404 chassis
SFC	SFC0	OC48 Switch Fabric Card
	SFC8	OC48 Switch Fabric Card
	SFC16	OC48 Switch Fabric Card for 12016 chassis
	SFC16XOC192	OC192 Switch Fabric Card for 12416 chassis
	SFC10XOC192	OC192 Switch Fabric Card for 12410 chassis
	SFC6XOC192	OC192 Switch Fabric Card for 12406 chassis

Deploying a Clock Scheduler Card

To deploy a clock scheduler card (CSC), proceed as follows:


- Step 1** Right click on the chassis under which you want to deploy the CSC, then choose the correct CSC card from the service menu **Deployment>Cisco 12000/10720 Manager>Module>CSC**. The Deployment Wizard—Views window appears.

Figure 3-36 Deployment Wizard—Views




- Step 2** Click **Select** to choose where you wish to place the object within the view. Click on the + sign to expand the view if required. The Object Selector window appears.

Figure 3-37 Object Selector Window




- Step 3** Navigate through the hierarchy and choose where you wish to place the object within the view. Click on the + sign to expand the view if required.
- Step 4** Click **Apply**. The Deployment Wizard - Views window re-appears with the location where the object will be placed.

Figure 3-38 Deployment Wizard—Views

Step 5 Click **Forward**. The Deployment Wizard—Summary window appears.

Figure 3-39 Deployment Wizard—Summary




- Step 6** The deployment summary details appear in the Deployment Summary window. If the information is correct, click **Finish**. If the information is incorrect, click **Cancel** to stop deployment.

Deploying a Switch Fabric Card

To deploy a switch fabric card (SFC), proceed as follows:


- Step 1** Right click on the chassis you want to deploy the switch fabric card under, then choose the correct SFC card from the service menu **Deployment>Cisco 12000/10720 Manager>12008>Module>SFC**. The Deployment Wizard—Views window appears.

Figure 3-40 Deployment Wizard—Views




- Step 2** Click **Select** to choose where you wish to place the object within the view. The Object Selector window appears.

Figure 3-41 Object Selector Window




- Step 3** Choose where you wish to place the object within the view. Click on the + sign to expand the view if required.
- Step 4** Click **Apply**. The Deployment Wizard - Views window re-appears with the location where the object will be placed.

Figure 3-42 Deployment Wizard—Views



- Step 5** Repeat Steps 2 to 4 to place the object in each of the Physical and ComponentManaged views.
- Step 6** Click **Forward**. The Deployment Wizard—Summary window appears.

Figure 3-43 Deployment Wizard—Summary



- Step 7** The deployment summary details appear in the Deployment Summary window. If the information is correct, click **Finish**. If the information is incorrect, click **Cancel** to stop deployment.

Pre-deployment

Cisco 12000/10720 Router Manager objects can be manually pre-deployed before the equipment arrives on-site. The following objects can be pre-deployed in Cisco 12000/10720 Router Manager:

- Cisco 12000/10720 Router chassis
- Line cards and interfaces

For example, if you know that you will be receiving a certain line card, you can manually predeploy that line card before it is actually present.



Note

Manual Deployment of SRP modules is currently not supported.

Performing Pre-deployment

Say that you are expecting the following hardware:

- Cisco 12016 chassis and GRP(s)
- ATM and POS line cards (with respective interfaces)

To perform both manual pre-deployment and offline configuration, proceed as follows:

-
- Step 1** Manually deploy a site object. See [“Manually Deploying a Generic Site Object”](#) section on page 3-10 for further details.
 - Step 2** Manually deploy the Cisco 12000 Series Router chassis under a site. See [“Manually Deploying a Cisco 12000/10720 Chassis”](#) section on page 3-20 for further details.
 - Step 3** Manually deploy GRP(s). See [“Manually Deploying a GRP Card”](#) section on page 3-31 for further details.
 - Step 4** Manually deploy the ATM line cards. ATM interfaces are deployed simultaneously. See [“Manually Deploying Line Cards”](#) section on page 3-38 for further details.
 - Step 5** Manually deploy the POS line cards. POS interfaces are deployed simultaneously. See [“Manually Deploying Line Cards”](#) section on page 3-38 for further details.

Now you have pre-deployed and thus created representative objects in Cisco 12000/10720 Router Manager for your expected hardware, modules, and interfaces. All of these objects will be in the Decommissioned state.



Managing Chassis

This chapter describes the various chassis management tasks that can be performed using the Cisco 12000/10720 Router Manager application.

The Chassis Management chapter details the following information:

- [Launching the Chassis Management Windows](#)
- [Management Information](#)
- [Chassis Configuration](#)
- [SNMP Management](#)
- [Chassis Inventory](#)
- [Chassis Fault Management](#)
- [Command Log](#)
- [System Log](#)
- [Configuration Backup/Restore Using RME](#)
- [IOS Image Download Using RME](#)
- [APS Status](#)
- [Initiating a Telnet Service](#)
- [Launching the Web Console](#)
- [Configuration Editor](#)—Not Applicable for the 10720 chassis
- [RPR Configuration](#)
- [RPR Status](#)
- [IP Routing Status](#)
- [TCP Status](#)
- [UDP Status](#)

Launching the Chassis Management Windows

Table 4-1 displays the Cisco 12000/10720 Router Manager Chassis Management windows that can be launched from each object type. For example, the Management Information window can be launched from a Site, or Chassis object, but cannot be launched from a Module or an Interface object.



Note

Table 4-1 lists the menu options to launch the chassis management dialogs from the site level.

Table 4-1 Launching the Chassis Management Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
Management Information	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Configuration>Chassis> Management Information
Chassis Configuration	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>Configuration
SNMP Management	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>SNMP Management
Chassis Inventory	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Accounting>Chassis>Inventory
Chassis Fault Management	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis> Fault Management
Command Log	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Accounting>Chassis>View>Command Log
System Log	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis>SysLog Messages
APS Status	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis> POS APS Status
RPR Configuration	Yes	Yes	No	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>RPR Configuration
RPR Status	Yes	Yes	No	No	No	Cisco 12000/10720 Manager>Fault>Chassis> RPR Status
IP Routing Status	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis>IP Routing Status
TCP Status	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis> TCP Status
UDP Status	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis> UDP Status
The dialogs mentioned below are launched from the chassis level.						
Launching the Web Console	No	Yes	Yes	Yes	Yes	Technology Specific Tools>Launch Web Console

Table 4-1 Launching the Chassis Management Windows (continued)

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
Initiating a Telnet Service	No	Yes	Yes	Yes	Yes	Technology Specific Tools>Initiate Telnet Service
Configuration Editor	No	Yes	No	No	No	Technology Specific Tools>Open Configuration Editor

**Note**

The Cisco 12000/10720 Router Manager Chassis Management windows cannot be opened when multiple objects are selected (the menu options to open the windows are grayed out). Available menu options can be launched from a site object containing the required objects.

Management Information

The Management Information window allows you to perform the following functions:

- Configure the chassis IP address fields
- Set or change IOS CLI username and passwords
- Set or change the system attributes

**Caution**

It is strongly recommended that only a System Administrator should have access to the Management Information window, because access passwords can be configured and modified in this window.

The Management Information section covers the following areas:


- [Viewing the Management Information Window](#)
- [System Configuration](#)
- [Entering or Changing IOS CLI Username and Passwords](#)
- [Management Information Window—Detailed Description](#)

Viewing the Management Information Window

To view the Management Information window, proceed as follows:

- Step 1** Right click on the chassis object and select the **Configuration>Management Information** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the Management Information window. The Management Information window appears, with the Configuration tab displayed.

Figure 4-1 Management Information Window—Configuration Tab



- Step 2 Choose an **IOS Host** from the list box displayed at the left of the window.

System Configuration

To configure the fields within the Configuration tab, proceed as follows:

- Step 1 Open the Management Information window. See [“Viewing the Management Information Window” section on page 4-3](#) for further details.
- Step 2 Choose a **chassis** from the list box displayed at the left of the window.
- Step 3 Configure the fields in the Configuration tab. For detailed information on the fields in this tab, see [“Management Information Window—Detailed Description” section on page 4-6](#).



Note If the operator enters an invalid IP address, for example, a different device (not a Cisco 12000 Series Router or a different variant to that currently deployed) then the chassis object will enter the mismatched state and a critical alarm will be raised. Modules and interfaces are moved into the mismatched state. These should be ignored. To recover, the chassis should be decommissioned, the correct IP address entered, saved and the chassis commissioned again.

- Step 4 Click **Save** to save your changes.


Entering or Changing IOS CLI Username and Passwords

In Cisco 12000/10720 v3.1.1 Router Manager some dialogs use the IOS CLI to retrieve or configure information. When a dialog uses the IOS CLI, the IOS password must be set up. For details of which dialogs use the IOS CLI, see [What Dialogs Use the IOS CLI Instead of SNMP?](#), page 21-2.

To enter or change the IOS CLI username or passwords, proceed as follows:

-
- Step 1** Open the Management Information window. See “[Viewing the Management Information Window](#)” section on page 4-3 for further details.
- Step 2** Choose the **IOS/Command Line Security** tab.

Figure 4-2 Management Information Window—IOS Command Line Security Tab



- Step 3** Enter the login password (mandatory). You must also enter a username and the exec password.
- Step 4** If you know the passwords that are set on the device:
- Click **Save Locally** to save your passwords locally on the selected chassis. This changes the passwords stored within Cisco 12000/10720 Router Manager only or
 - Click **Save to Device**. This changes passwords both on the device and locally in Cisco 12000/10720 Router Manager. Click **Save to Device** if you want to reconfigure the passwords on the device, if previous passwords have been specified. This option will work only if previous valid passwords have been saved locally.
- Step 5** Click **Save** to save your changes.
-

Management Information Window—Detailed Description

The Management Information window displays two tabs: Configuration and IOS/Command Line Security.

Configuration Tab

The Configuration tab (see [Figure 4-1 on page 4-4](#)) displays a single System Configuration area.

System Configuration

The System Configuration area displays the following fields:

IP Address—Allows you to enter the IP address of the system.

System Name—Allows you to enter the name of the system.

System Contact—Allows you to enter the name and contact details for the person administering the node.

System Location—Allows you to specify the physical location of the system.

Extra Location Information (optional)—Allows you to specify additional information describing the location of the system.

IOS/Command Line Security Tab

The IOS/Command Line Security tab (see [Figure 4-2 on page 4-5](#)) displays the security details area, IOS Username and Passwords.

IOS Username and Passwords

The IOS Username and Passwords area contains the following fields:

User Name—Allows you to enter a unique user name which combined with the passwords below provides additional levels of security for accessing the Cisco 12000/10720 Router.

Login Password—Allows you to set a telnet access password to protect the Cisco 12000/10720 Router from access by unauthorized personnel.

Confirm Login Password—Allows you to re-enter the login password for confirmation.

Exec Password—Allows you to set the access password for the chassis, enabling you to perform specific operations on the Cisco 12000/10720 Router chassis.

Confirm Exec Password—Allows you to re-enter the exec password for confirmation.

Save Locally—Click **Save Locally** to save your passwords locally in Cisco 12000/10720 Router Manager for a selected chassis.

Save to Device—Click **Save to Device** when you wish to reconfigure both the local Cisco 12000/10720 Router Manager password and the password on the device, or when you want to change the current passwords for the selected chassis.

Chassis Configuration

The Chassis Configuration window allows you to view and configure parameters, commission or decommission, and switch global performance logging on or off for the selected chassis. The Chassis Configuration (Additional Descriptions tab) allows you to specify additional description information for a selected chassis. The Description 1 and Description 2 attributes allow you to enter any additional text descriptions for identification purposes.

The Chassis Configuration section covers the following areas:


- [Viewing the Chassis Configuration Window](#)
- [Commissioning a Chassis](#)
- [Decommissioning a Chassis](#)
- [Starting Global Performance Logging](#)
- [Stopping Global Performance Logging](#)
- [Entering Additional Descriptions for a Selected Chassis](#)
- [Device Management Tab in Configuration Window](#)
- [Chassis Configuration Window—Detailed Description](#)

Viewing the Chassis Configuration Window

To view the Chassis Configuration window, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Configuration>Chassis Configuration** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the Chassis Configuration window. The Chassis Configuration window appears, with the Configuration tab displayed.

Figure 4-3 Chassis Configuration Window—Configuration Tab



Not applicable for Cisco 12000/10720 Router Manager

Step 2 Choose a **chassis** from the list displayed at the left of the window.

Commissioning a Chassis

See [“Commissioning a Chassis” section on page 3-27](#) for further details.

Decommissioning a Chassis

See [“Decommissioning a Chassis” section on page 3-30](#) for further details.

Starting Global Performance Logging

Global performance logging, when set, collects performance information on GRPs and interfaces on a specified chassis. Performance data can then be viewed through performance menus or through the Performance Manager.



Note

Performance logging can also be started on a per module (GRP) or physical interface basis. For details on how to start performance logging for a selected module (GRP), see [“Module Performance” section on page 5-9](#). For details on how to start performance logging for a selected physical interface (such as Ethernet, ATM, or DS-3), see [“Starting Performance Logging for a Selected Interface” section on page 10-5](#).

If you start global performance logging on a chassis, all subchassis objects are placed into the performance logging on state. However, performance data is only collected for GRPs and interfaces, so any other modules will not collect performance data, despite having a state of performance logging on.




Note

Global Performance Logging can use a lot of bandwidth, so use discretion.

To start global performance logging for a selected chassis, proceed as follows:

- Step 1** Open the Chassis Configuration window. See [“Viewing the Chassis Configuration Window” section on page 4-7](#) for further details.
- Step 2** Select the relevant **Chassis** from the list displayed at the left of the window.
- Step 3** Click **Start** to begin performance logging on the selected chassis. An Action Report window appears:

Figure 4-4 Action Report Window



The Action Report window (see [Figure 4-4](#)) informs you whether the performance logging “on” action was successful or not.

- Step 4** Click **Close** to close the Action Report window.

Stopping Global Performance Logging




Note

Performance logging can also be stopped on a per module (GRP) or physical interface basis. For details on how to stop performance logging for a selected module (GRP), see [“Module Performance” section on page 5-9](#). For details on how to stop performance logging for a selected physical interface (such as Ethernet, ATM, or DS-3), see [“Starting Performance Logging for a Selected Interface” section on page 10-5](#).

To stop global performance logging for a selected chassis, proceed as follows:

- Step 1** Open the Chassis Configuration window. See [“Viewing the Chassis Configuration Window” section on page 4-7](#) for further details.
- Step 2** Select the relevant **Chassis** from the list displayed at the left of the window.
- Step 3** Click **Stop** to stop global performance logging for the selected chassis. An Action Report window appears:

Figure 4-5 Action Report Window



The Action Report window (see [Figure 4-5](#)) informs you whether the performance logging “off” action was successful or not.

- Step 4** Click **Close** to close the Action Report window.

Entering Additional Descriptions for a Selected Chassis




Note Entering additional descriptions for a chassis is optional.

To enter additional descriptions for a selected chassis, proceed as follows:

- Step 1** Open the Chassis Configuration window. See “[Viewing the Chassis Configuration Window](#)” section on page 4-7 for further details.

Figure 4-6 Chassis Configuration Window—Additional Descriptions Tab



- Step 2** Select the relevant **Chassis** from the list displayed at the left of the window.
- Step 3** Choose the **Additional Descriptions** tab.
- Step 4** Enter additional descriptions into the Descriptions 1 and Descriptions 2 areas, as required.



Note You can enter any information you wish into the Description 1 and Description 2 data entry fields. For example, you might wish to record additional text descriptions for identification purposes, such as CLI codes.


Step 5 Click **Save** to save your changes.

Device Management Tab in Configuration Window

To view the Device Management tab in the configuration window, proceed as follows:

Step 1 Open the Chassis Configuration window. See “[Viewing the Chassis Configuration Window](#)” section on [page 4-7](#) for further details.

Figure 4-7 Chassis Configuration Window—Device Management Tab



Step 2 Choose the **Device Management** tab.



Note The Synchronize action is not applicable to Cisco 12000/10720 Router Manager

When Write Mem is invoked, the running configuration information is copied to the startup configuration on the device.

Chassis Configuration Window—Detailed Description

The Chassis Configuration window displays three tabs: Configuration, Additional Descriptions and Device Management.

Configuration Tab

The Configuration tab ([Figure 4-3 on page 4-8](#)) displays five areas: Validation Parameters, Action (not applicable to Cisco 12000/10720 Router Manager), Clock (not applicable), Power Supply (not applicable), Actions, and, Commission Status.

Validation Parameters

The Validation Parameters area contains attributes that describe the population characteristics of a chassis and are used to validate module deployment.

Number of Slots—Displays the number of slots in the chassis for plug-in modules.

Unavailable Slots—Displays a comma separated list of slots that modules cannot be deployed into.

Max Number of Sub-Modules per Slot—Defines the maximum number of sub-modules that can be deployed into each slot for the selected chassis.

Action

This area is not applicable to Cisco 12000/10720 Router Manager.

Clock

This area is not applicable to Cisco 12000/10720 Router Manager.

Power Supply

This area is not applicable to Cisco 12000/10720 Router Manager.

Actions

The Actions area is sub-divided into Management and Global Performance Logging areas.

Management

The Management area allows you to commission or decommission the selected chassis.

Commission—Click **Commission** to commission the selected chassis.

Decommission—Click **Decommission** to decommission the selected chassis.

Global Performance Logging

The Global Performance Logging area allows you to start or stop global performance logging.

Start—Click **Start** to begin global performance logging.

Stop—Click **Stop** to stop global performance logging.

Commission Status

The Commission Status area displays the result of the last commission, either Succeeded or Failed.

Additional Descriptions Tab

The Additional Descriptions tab ([Figure 4-6 on page 4-11](#)) displays a single Additional Descriptions area.

Additional Descriptions

The Additional Descriptions tab optionally allows you to specify description information for a selected chassis. Any additional text descriptions can be entered in the description 1 and description 2 data entry fields. For example, you might want to record additional text descriptions for identification purposes, such as CLI codes.

Device Management Tab

The Device Management tab displays two areas: Alarm Synchronization and Write Config to Flash

Actions

Synchronize— not applicable to Cisco 12000/10720 Router Manager

WriteMem—When invoked, copies the running configuration information to the startup configuration on the device

SNMP Management

The SNMP Management window allows you to select or modify SNMP community strings or versions, and enable or disable trap generation.

The SNMP Management section covers the following areas:


- [Viewing the SNMP Management Window](#)
- [Modifying SNMP Community Names or Version](#)
- [Enabling or Disabling Trap Generation](#)
- [SNMP Management Window—Detailed Description](#)

Viewing the SNMP Management Window

To view the SNMP Management window, proceed as follows:

- Step 1** Right click on the chassis object and select the **Configuration>SNMP Management** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the SNMP Management window. The SNMP Management window appears, with the SNMP Management tab displayed:

Figure 4-8 SNMP Management Window—SNMP Management Tab



Choose an **IOS Host** from the box displayed at the left of the window.

Modifying SNMP Community Names or Version

To choose or modify SNMP community names, proceed as follows:

- Step 1** Open the SNMP Management window. See [“Viewing the SNMP Management Window”](#) section on [page 4-15](#) for further details.
- Step 2** Choose an **IOS Host** from the list displayed at the left of the window.

- Step 3** Choose the SNMP version to be used. Note that Cisco 12000/10720 Router Manager release 3.0 does not support SNMPv3, and when using version 2 of SNMP, complete the community names for V2 read and V2 write.
- Step 4** Save your changes by clicking the **Save** icon on the toolbar.
-

Enabling or Disabling Trap Generation

Traps can be sent by the device to the Cisco 12000/10720 Router Manager application when trap generation is enabled. When the Cisco 12000/10720 Router Manager application receives a trap, alarms are raised on the chassis or its modules or interfaces. When trap generation is disabled for a device, no alarms are received by Cisco 12000/10720 Router Manager and therefore no alarms raised.

Traps generate alarms and send them to the Cisco 12000/10720 Router Manager Chassis object with the specified IP Address when trap generation is enabled. When trap generation is enabled, you can see alarms raised in the appropriate view. Trap generation can also be disabled so that traps and alarms are not generated for the selected chassis.

To enable or disable trap generation on a selected chassis, proceed as follows:

- Step 1** Open the SNMP Management window. See [“Viewing the SNMP Management Window”](#) section on [page 4-15](#) for further details.
- Step 2** Choose an **IOS Host** from the list displayed at the left of the window.
- Step 3** Click **Enable** to allow trap generation, or click **Disable** to stop trap generation.
- Step 4** Save your changes by clicking the **Save** icon on the toolbar.



Note Make sure that the SNMP version is V2, the default version is V2c

SNMP Management Window—Detailed Description

The SNMP Management window displays a single SNMP Management tab. The SNMP Management tab contains three areas: Community Names, Version, and Trap Generation.

Community Names

Community names provide a security mechanism for SNMP communications. The device holds its own community names, so the correct community names must be used in order to get or set attributes from the device.

V2 Read—Community string used when retrieving attributes from a device using the SNMPv2c protocol.

V2 Write—Community string used when setting attributes on a device using the SNMPv2c protocol.

Version

Displays the SNMP version.

SNMP Version—Allows you to choose the SNMP version. Note that Cisco 12000/10720 Router Manager release 3.0 does not support SNMPv3.

Trap Generation

Enable—Click **Enable** to enable trap generation for the selected chassis. Traps generated by the selected chassis are sent to Cisco 12000/10720 Router Manager which is configured in the Cisco 12000 Series Router device.

Disable—Click **Disable** to disable trap generation for the selected chassis. No traps will be generated by the selected chassis.

Chassis Inventory

The Chassis Inventory window displays general inventory information, it is a read-only window (you cannot configure any fields in this window).

The Chassis Inventory section covers the following areas:


- [Viewing the Chassis Inventory Window](#)
- [Chassis Inventory Window—Detailed Description](#)

Viewing the Chassis Inventory Window

To view the Chassis Inventory window, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Accounting>Chassis Inventory** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the SNMP Management window. The Chassis Inventory window appears, with the General tab displayed.

Figure 4-9 Chassis Inventory Window—General Tab



Not applicable for Cisco 12000/10720 Router Manager

Step 2 Choose a **Chassis** from the list box displayed at the left of the window.

See “[Chassis Inventory Window—Detailed Description](#)” section on page 4-18 for further details on the fields displayed.

Chassis Inventory Window—Detailed Description

The Chassis Inventory window contains two tabs: General and Asset Tracking. The Asset Tracking tab is not applicable for Cisco 12000/10720 Router Manager.

General Tab

The General tab (see [Figure 4-9 on page 4-18](#)) displays five areas: Chassis Details, System Details, Version Details, PCMCIA Slot Details, and Power Supply Details.

Chassis Details

The Chassis Details area displays the following information:

Serial Number—Not applicable to Cisco 12000/10720 Router Manager.

Number of Slots—Displays the number of slots in the chassis.

Backplane Type—Not applicable to Cisco 12000/10720 Router Manager.

Type—Displays the chassis type.

Environmental Monitor Type—Displays the type of environmental monitor located in the chassis.

System Details

The System Details area displays the following information:

Host Name—Displays the host name for the selected chassis.

Boot Image Host—Displays the IP address of the host, which supplies the software currently running.

Description—Displays the system's hardware type, software operating system, and networking software of the selected chassis.

ROM ID—Displays the system boot trap description and version identifier.

Domain Name—Displays the domain portion of the domain name of the host.

Services—Displays the set of services potentially offered by the selected chassis.

Version Details

The Version Details are an area displays the following information:

IOS—Displays the version of IOS software in the selected chassis.

Firmware—Not applicable to Cisco 12000/10720 Router Manager.

Software—Not applicable to Cisco 12000/10720 Router Manager.

Hardware—Displays the version of the selected chassis.

PCMCIA Slot Details

The PCMCIA Slot Details area is not applicable to Cisco 12000/10720 Router Manager.

Power Supply Details

The Power Supply Details area is not applicable to Cisco 12000/10720 Router Manager.

Asset Tracking Tab

The Asset Tracking tab is not applicable to Cisco 12000/10720 Router Manager.

Chassis Fault Management

The Chassis Fault Management window displays general chassis availability details, Power Supply information, Temperature information, and Fan information. You cannot configure any parameters in the Chassis Fault Management window, it is a read only window.

The EM, for the chassis object, provides fault management of the overall management connectivity and the environmental aspects of the router. More details on management connectivity can be found in [Chapter 18, “Fault Management.”](#)

Environmental fault management is provided in the form of four tables that report the status of Power Supplies, Voltage, Temperature and Fans within the chassis. Each table contains a State column that indicates the current state of each testpoint. This can be either Normal, Warning, Critical, Shutdown or Not Present. This functionality is supplemented by the processing of notifications from the Cisco 12000/10720 Router. See [Chapter 18, “Fault Management,”](#) for further information.

When an environmental fault is detected, then the recommended procedures documented at <http://www.cisco.com/univercd/cc/td/doc/product/core/cis12000/cis12016/icg/hfricgr.htm#xtocid543212> should be followed.



Note

If the chassis object is deployed as a chassis of a different type then the chassis transits to the mismatch state and an appropriate alarm is raised.

The Chassis Fault Management section covers the following areas:


- [Viewing the Chassis Fault Management Window](#)
- [Changing Column Width](#)
- [Chassis Fault Management Window—Detailed Description](#)

Viewing the Chassis Fault Management Window

To view the Chassis Fault Management window, proceed as follows:

- Step 1 Right click on the chassis object and select the **Fault>Fault Management** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the Chassis Fault Management window. The Chassis Fault Management window appears, with the General tab displayed.

Figure 4-10 Chassis Fault Management Window—General Tab




Not applicable for Cisco 12000/10720 Router Manager

- Step 2** Choose a **Chassis** from the list box displayed at the left of the window. General fault management details are displayed.
- Step 3** Choose the **Power Supply** tab. The power supply and voltage details for the selected chassis appear. For further information on the fields displayed in this window, see [“Chassis Fault Management Window—Detailed Description”](#) section on page 4-25.



Note Click on the More (arrow) button (if required) to view all the information listed.

Figure 4-11 Chassis Fault Management Window—Power Supply Tab




Not applicable for Cisco 12000/10720 Router Manager

- Step 4 Choose the **Temperature Supply** tab. The temperature details for the selected chassis appear. For further information on the fields displayed in this window, see [“Chassis Fault Management Window—Detailed Description”](#) section on page 4-25.



Note You can alter the width of the columns displayed in the table(s). See [“Changing Column Width”](#) section on page 4-24 for further details. Click on the More (arrow) button (if required) to view all the information listed.

Figure 4-12 Chassis Fault Management Window—Temperature Tab




Not applicable for Cisco 12000/10720 Router Manager

- Step 5** Choose the **Fan** tab. The fan details for the selected chassis appear in the tab. For further information on the fields displayed in this window, see [“Chassis Fault Management Window—Detailed Description”](#) section on page 4-25.



Note You can alter the width of the columns displayed in the table(s). See [“Changing Column Width”](#) section on page 4-24 for further details. Click on the More (arrow) button (if required) to view all the information listed.

Figure 4-13 Chassis Fault Management Window—Fan Tab



Not applicable for Cisco 12000/10720 Router Manager

Changing Column Width

The Chassis Fault Management window displays four tabs: General, Power Supply, Temperature, and Fan. The Power Supply, Temperature, and Fan tabs display tables. Text wider than the column width, displayed in these tables is truncated. Column widths can be altered to allow you to view the details displayed in the columns more clearly. This section describes how to change the width of a column.

To change the width of a column, proceed as follows:

- Step 1** Move the mouse pointer to the left of a column heading. The mouse pointer changes to a double headed arrow.
- Step 2** Click and hold the left mouse button, a line appears down the length of the column.
- Step 3** Drag the line (until the column is at the required width) then release the mouse button.



Note Columns return to their default width when you close the window.

Chassis Fault Management Window—Detailed Description

The Chassis Fault Management window displays four tabs: General, Power Supply, Temperature, and Fan.

General Tab

The General tab (see [Figure 4-10 on page 4-21](#)) displays three areas: Chassis Availability, LED Status, and Cisco Contact Details.

Chassis Availability

The Chassis Availability area contains attributes that reflect the availability of the chassis, as follows:

Up Time—Displays the up time after the last reset.

Last Changed Time—Displays the time the chassis hardware was last modified.



Note

Software and configuration changes through IOS CLI & SNMP are detected by SYSLOG and ConfigManEvent traps (see [Chapter 18, “Fault Management,”](#) for further information) and the Event Command History Table that can be launched from the Chassis.

Last Restart Reason—Displays the reason for the last restart.

Last Authentication Failure Address—Displays the last authorization failure IP address for the selected chassis. The Last Authentication Failure Address field refers to the fact that the SNMP agent on the Cisco 12000/10720 Router has received a protocol message that is not properly authenticated. The IP address is the source of the message. This is a security issue which should be investigated.

Clock Source Status—Not applicable to Cisco 12000/10720 Router Manager.

LED Status

The LED Status area is not applicable to Cisco 12000/10720 Router Manager.

Cisco Contact Details

The Cisco Contact Details area displays any provided Cisco contact details.

Power Supply Tab

The Power Supply tab (see [Figure 4-11 on page 4-22](#)) displays two areas: Power Supply and Voltage.

Power Supply

The Power Supply area displays the following information for each power supply (in tabular format):

Description—Textual information for the power supply.

State—Current state of the power supply. Possible state values can be Normal, Warning, Critical, Shutdown or Not Present.

Source—Power supply source. Possible source values are: unknown, ac, dc, external, or internal redundant.

Voltage

The Voltage area displays the following:

Description—Textual information on voltage.

Status Value—Current status of the voltage for the selected chassis.

Minimum Threshold—Lowest status value assigned before a shutdown is initiated and notifications generated.

Maximum Threshold—Highest status value assigned before a shutdown is initiated and notifications generated.

Last Shutdown—Last shutdown initiated.

State—Current voltage state. Possible state values can be Normal, Warning, Critical, Shutdown or Not Present.



Note

The minimum and maximum threshold values specify the range that can be associated with the object before an emergency shutdown is initiated.

Temperature Tab

The Temperature tab (see [Figure 4-12 on page 4-23](#)) displays a single Temperature area.

Temperature

The Temperature area displays the following details for the core temperature status and the inlet temperature status:

Description—Textual information on temperature for the selected chassis.

Status Value—Current status value of the temperature of the selected chassis.

Threshold—Highest value associated with the object before a shutdown is initiated.

Last Shutdown—Status of the chassis when shutdown was last initiated.

State—Current temperature state of the selected chassis. Possible state values can be Normal, Warning, Critical, Shutdown or Not Present.

Fan Tab

The Fan tab (see [Figure 4-13 on page 4-24](#)) displays a single Fan area.

Fan

The Fan area displays a description and the current state of the fan status in tabular format.

Description—Textual information for the fan.

State—Current state of the fan in the selected chassis. Possible state values can be Normal, Warning, Critical, Shutdown or Not Present.

Command Log

The Command Log window maintains a record of all the user-initiated configuration changes on the selected device (chassis).

The Command Log section covers the following areas:


- [Viewing the Command Log Window](#)
- [Command Log Window—Detailed Description](#)

Viewing the Command Log Window

To view the Command Log window, proceed as follows:

- Step 1** Right click on the chassis object and select the **Accounting>Command Log** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the Command Log window. The Command Log window appears, with the Command Log Details tab displayed:

Figure 4-14 Command Log Window



- Step 2** Choose a **Chassis** from the list box displayed at the left of the window. The Command Log Details information for the selected chassis appears. For further information, see [“Command Log Window—Detailed Description”](#) section on page 4-28.

- Step 3** Scroll through the list of event commands, using the arrow bars, until the relevant event command appears.



Note You can alter the width of the columns displayed in the table. See [“Changing Column Width” section on page 4-24](#) for further details. The More (arrow) button is not applicable in this window.

Command Log Window—Detailed Description

The Command Log window displays a single Command Log Details tab.

Command Log Details Tab

The Command Log Details tab (see [Figure 4-14 on page 4-27](#)) displays a Command Log Details table and Event History Details area.

Command Log Details Table

The Command Log Details table displays the following information:

Index—Arbitrary integer value to uniquely identify the listed events. When it reaches the maximum value, the agent wraps the value back to 1 and can flush existing entries

Time—Value of system up time when the event occurred.

Command Source—Source of the command that instigated the event. You will see either command Line or SNMP.

Config Source—Configuration data source for the event.

Config Destination—Configuration data destination for the event.

Terminal Type—When the command source field is set to command line, the terminal type appears (unknown, console, terminal, virtual or auxiliary). Otherwise, not applicable appears.

Terminal Number—When the command source field is set to command line, the terminal number appears. When the terminal is not available or not applicable, -1 appears.

Terminal User—When the command source is set to command line, the name of the logged in user appears. When the terminal type is not available or not applicable, the field appears empty.

Terminal Location—When the command source is set to command line, the hard-wired location of the terminal or the remote host for an incoming connection appears. When the terminal type is not available or not applicable, the field appears empty.

Command Source Address—When the terminal type field is set to virtual, the internet address of the connected system appears. When the command source is set to SNMP, the internet address of the requester appears.

Virtual Host Name—When the terminal type field is set to virtual, the host name of the connected system appears. When the terminal type is not available or not applicable, the field appears empty.

Server Address— If Config Source (or) Config Destination field is 'networkTftp' or 'networkRcp', the Internet address of the storage file server is displayed. The value is 0.0.0.0 if Config Source (or) Config Destination field is N/A.

File—When the config source field or the config destination field is set to network tftp or network rcp, the configuration filename at the storage file server appears.

RCP User—When the config source field or the config destination field is set to network rcp, the remote user name appears.

Event History Details

The Event History Details area displays the following information:

Uptime at Last Save—Displays the amount of time the system had been up for, when the running configuration was last saved (written).

Uptime at Last Change—Displays the amount of time the system had been up from when the running configuration was last changed.



Note

When the value of the uptime at last change field is greater than the uptime at last save field, the configuration has been changed, but not saved.

Maximum Table Entries—Maximum number of entries that can be displayed.

Entries Deleted from Table—Number of times the oldest entry was deleted to make room for a new entry.

System Log

The System Log Messages window provides a table of all activity carried out by users via CLI or SNMP on a device. You can opt to be notified of all user activities through alarm notification, if required.

The System Log section covers the following areas:


- [Viewing the SysLog Messages Window](#)
- [System Log Window—Detailed Description](#)

Viewing the SysLog Messages Window

To view the SysLog Messages window, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Fault>SysLog Messages** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the SysLog Messages window. The SysLog Messages window appears, with the SysLog Messages tab displayed.

Figure 4-15 Sys Log Messages Window



- Step 2** Choose an **IOS Host** from the list box displayed at the left of the window. The SysLog Message information appears for the selected chassis. For further information, see [“System Log Window—Detailed Description”](#) section on page 4-30
- Step 3** Scroll through the list of system messages, using the arrow keys, until you find the information you want. You can view all the entries by using the horizontal scroll bar.



Note You can alter the width of the columns displayed in the table(s). See [“Changing Column Width”](#) section on page 4-24 for further details. Click on the More (arrow) button (if required) to view all the information listed.

System Log Window—Detailed Description

The SysLog Messages window displays a single Sys Log Messages tab.

SysLog Message Tab

The SysLog Message tab (see [Figure 4-15 on page 4-30](#)) displays SysLog Messages and Sys Log Message Details areas.

SysLog Messages Area

The Sys Log Messages area displays the following information:

Index—Arbitrary integer value to uniquely identify the listed messages. When it reaches the maximum value the agent flushes the area and wraps the value back to 1.

Facility—Name of the facility that generated the facility message.

Severity—Displays the severity of the message.

Message Name—Textual identification for the message type. A facility name in conjunction with a message name uniquely identifies a message type.

Message Text—Displays the text of the message. When the text of the message exceeds 255 bytes, the message is truncated to 254 bytes and a '*' character is appended, indicating that the message has been truncated.

Time Stamp—Displays the time the system has been running (when the message was generated).

Sys Log Message Details

The Sys Log Message Details area displays the following information:

Messages Not Recorded—Displays the number of syslog messages that were ignored.

Messages Not Processed—Displays the number of messages which could not be processed due to lack of system resources.

Messages Deleted From Table—Number of entries that have been removed to make room for new entries.

Notifications Sent—Displays the number of notifications sent.

Maximum Table Entries—Displays the upper limit on the number of entries that the area can contain.

Minimum SysLog Severity—Any message with a severity less than this one will be ignored by the agent. This field can be set to emergency, alert, critical, error, warning, notice, info, or debug.

Notifications Enabled—Displays whether notifications are enabled or not enabled.

Using RME for Chassis Management Tasks

The Cisco 12000/10720 Router Manager is integrated with Resource Manager Essentials (RME) as the GUI tool for Network Element Administration – part of the Operations and Administration functions of OAM&P in Cisco Service Provider EMSs. Refer to the *Cisco 12000/10720 v3.1.1 Installation and Configuration Guide* for details about administering RME (http://www.cisco.com/en/US/products/sw/netmgtsw/ps156/products_installation_and_configuration_guide_books_list.html).

The RME application set provides a range of GUI-based applications for network element administration tasks including:

- [Configuration Backup/Restore Using RME](#)
- [IOS Image Download Using RME](#)

Configuration Backup/Restore Using RME

You should use Cisco IOS Configuration Archiving in RME for Configuration backup and restore.

For more information about configuration backup and restore in RME, refer to *User Guide for Resource Manager Essentials*.

http://www.cisco.com/en/US/products/sw/cscowork/ps2073/products_user_guide_book09186a008017ac58.html.

IOS Image Download Using RME

You should use Cisco IOS Image Management in RME for IOS Image Download.

For more information about IOS image download in RME, refer to *User Guide for Resource Manager Essentials*.

http://www.cisco.com/en/US/products/sw/cscowork/ps2073/products_user_guide_book09186a008017ac58.html.

APS Status

The APS status window provides a single read only view which displays all APS circuits configured on a selected Cisco 12000/10720 Router.



Note

You can also view APS circuits that are configured on another router.

The APS Status window displays the APS redundancy configuration for a selected chassis.

The APS Status section contains the following areas:


- [Viewing the APS Status Window](#)
- [APS Status Window—Detailed Description](#)

Viewing the APS Status Window

To view the APS Status window, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Fault>POS APS Status** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the APS Status window. The APS Status window appears.

Figure 4-16 APS Status Window



- Step 2** Choose a **Chassis** from the list displayed at the left of the window. For further information on the fields displayed in this window, see [“APS Status Window—Detailed Description”](#) section on page 4-34.

A list of all APS circuits set up on the selected chassis appear in the APS Circuits area. When the Cisco 12000/10720 Router being managed is configured with an APS circuit that connects to another Cisco 12000/10720 Router, then either the Working or Protect field (whichever is appropriate) in the Table will indicate “Remote”.



Note You can alter the width of the columns displayed in the table(s). See [“Changing Column Width”](#) section on page 4-24 for further details.

APS Status Window—Detailed Description

The APS Status window displays a single APS Circuits area.

APS Circuits Area

The APS Circuits area displays a table with the following headings:

Group—Group number of the APS circuit or interface.

Working Slot/Port—Slot/port number of the working interface. For a circuit, if the working interface is part of another chassis, “remote” is displayed instead of the slot/port number.

Protect Slot/Port—Slot/port number of the protected interface. For a circuit, if the protected interface is part of another chassis, “remote” is displayed instead of the slot/port number.

Initiating a Telnet Service

The Initiate Telnet Service application allows you to log onto the device, in order to configure or retrieve information from the device.

To launch a telnet window, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Technology Specific Tools>Initiate Telnet Service** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the telnet window. The telnet window appears:

Figure 4-17 Telnet Window



- Step 2** Enter the required password (the device may also require a valid user name).
-

Launching the Web Console

Another way to retrieve information from a device is through a web browser using the Web Console application.

To launch the Web Console application, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Technology Specific Tools>Launch Web Console** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the Web Console application. A security window appears.
- Step 2** Enter the required user ID and password. Access to the Cisco web console is now provided.
-

Configuration Editor



Note The login password to the Cisco 12000 Series Router must be set on the Cisco 12000/10720 Router Manager to allow you to upload, edit and then download the running configuration from a selected chassis. See [“Entering or Changing IOS CLI Username and Passwords” section on page 4-5](#) for further details.



Note This feature is not available with the Cisco 10720 Routers.

The Configuration Editor allows you to perform the following:

- Upload the running configuration from a selected chassis and edit using the vi editor
- Download the edited configuration file to a selected chassis

The Configuration Editor section covers the following areas:


- [Viewing the Configuration Editor Window](#)
- [Configuration Editor Window—Detailed Description](#)

Viewing the Configuration Editor Window

To view the Configuration Editor window, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Technology Specific Tools>Open Configuration Editor** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the Configuration Editor window. The Configuration Editor window appears with the Configuration Editor tab displayed.

Figure 4-18 Configuration Editor Window



- Step 2** Choose a **Chassis** from the list displayed at the left of the window. For further information on the fields displayed in this window, see [“Configuration Editor Window—Detailed Description”](#) section on page 4-37.

Downloading, Opening, or Editing the Running Configuration from a Selected Chassis

To download, open or edit the running configuration configuration from a selected chassis, proceed as follows:

- Step 1** Open the Configuration Editor window, see [“Viewing the Configuration Editor Window”](#) section on page 4-35 for further details.
- Step 2** Choose a **Chassis** from the list displayed at the left of the window.
- Step 3** Click **Upload**. A vi editor window appears, with the running configuration for the selected chassis displayed.
- Step 4** Edit the running configuration as desired. To search for specific text within the running configuration file, see [Searching in the Configuration Editor](#).



Caution

If you wish to delete a line in the uploaded configuration, you must type “no” at the beginning of the line. If order is a concern, deleting a line might cause problems, so use extreme discretion when deleting a line.

**Note**

If you receive an error message after clicking **Upload**, you might need to make sure the tftpboot server is running on the workstation that Cisco 12000/10720 Router Manager is running on. The tftpboot server must be running before you can upload the running configuration. Make sure that the IOS username and password are set correctly in the Management Information.

Searching in the Configuration Editor

To search using the configuration editor, proceed as follows:

- Step 1** In the search criteria field, type in the text you wish to search for.
- Step 2** Now, click **Add**. The text you specified appears in the criteria name box under the Selection area.
- Step 3** Click **Upload**. A vi editor window appears, with the running configuration displayed. The first instance of the specified search criteria is displayed.
- Step 4** If you want to delete your text from the criteria name box, simply click on the text you want to delete in the box, then click **Delete**.

**Note**

Before downloading the modified running config, the vi editor launched with the running configuration of the selected chassis must be closed.

Downloading the Edited Configuration File to a Selected Chassis

After you have edited the running configuration, save the changes and click **Download** to download the modified running configuration to the selected chassis. This new configuration is reflected onto the startup configuration and the running configuration.

Configuration Editor Window—Detailed Description

The Configuration Editor window displays a single Configuration Editor tab.

Configuration Editor Tab

The Configuration Editor tab (see [Figure 4-18 on page 4-36](#)) displays two areas: Selection and Operations on Device.

Selection

Criteria Name—Any text strings you have searched for appear in this list.

Search Criteria—Enter search text into the search criteria data entry box. Click **Add** to move the text string into the configuration criteria list.

Operations Done Locally

Add—Click **Add** to move the text string (displayed in the search criteria data entry box) into the criteria name list. Then click **Upload** to commence your search.

Delete—Click **Delete** to remove any selected text string from the criteria name list.

Operations on Device

Upload—Click **Upload** to upload the running configuration file from the selected chassis and automatically open the running configuration file in a vi editor (allowing you to edit the configuration file).

Download—Click **Download** to download the edited running configuration file to the selected chassis.

RPR Configuration

**Note**

This feature is not available with the Cisco 10720 Routers.

The RPR Configuration window allows you to configure the Redundancy Mode, Preferred route processor and the perform switchover operation. The RPR Configuration section covers the following areas:


- [Viewing the RPR Configuration Window](#)
- [RPR Configuration Window—Detailed Description](#)

Viewing the RPR Configuration Window

To view the RPR Configuration window, proceed as follows:

-
- Step 1** Right click (on a relevant object icon in the Map Viewer window or from an object pick list) and select **Configuration>RPR Configuration** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the RPR Configuration window.

Figure 4-19 RPR Configuration Window



- Step 2** Choose a **Chassis** from the list displayed at the left side of the window. For further information on the fields displayed in this window, see [RPR Configuration Window—Detailed Description](#) for further details.

RPR Configuration Window—Detailed Description

The RPR Configuration window displays two tabs: Configuration and Switch Over

Configuration Tab

Redundancy Mode—Displays and sets the redundancy mode of the selected chassis. The redundancy mode can be RPR, RPR- Plus or SSO



Note

If the mode of the RP changes, then the standby RP is reloaded.

Preferred RP—Displays and sets the value (either “Active Slot No” or “Standby Slot No”) that determines the active RP on the next reload.

Switch Over Tab

Active RP—Displays the slot number of the active Route Processor.

Actions

Switch Over—Choose Switch Over to force a RP from standby to active.



Note

A user can forcefully switchover and make the standby RP to an Active one, by clicking on “**Switch Over**”.

RPR Status



Note

This feature is not available with the Cisco 10720 Routers.

The RPR Status section covers the following areas:


- [Viewing the RPR Status Window](#)
- [RPR Status Window—Detailed Description](#)

Viewing the RPR Status Window

To view the RPR Status window, proceed as follows:

- Step 1 Right click (on a relevant object icon in the Map Viewer window or from an object pick list) and select **Fault>RPR Status** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the RPR Status window.

Figure 4-20 RPR Configuration Window



- Step 2** Choose a **Chassis** from the list displayed at the left side of the window. For further information on the fields displayed in this window, see [RPR Status Window—Detailed Description](#) for further details.

RPR Status Window—Detailed Description

The RPR Status window displays two tabs: RP Status and LC Status.

RP Status

Redundancy Mode—Displays the current redundancy mode in the chassis. The redundancy mode can be RPR, RPR- Plus or SSO.

Active Slot No Id—Displays the current Active RP slot number identifier (id).

Standby RP Slot Id—Displays the current Standby RP slot number identifier (id).

Preferred RP —Displays a slot number of the chassis (either “Active Slot No” or “Standby Slot No”) that determines the active RP on the next reload.

LC Status

This area displays the status of all the Line cards for the selected chassis. It displays a table that lists the potential slot numbers and the corresponding supported redundancy mode.



Note

The slots identified by the slot numbers in the table, may not contain an RP or CSC or SFC.

Slot No—Displays the slot number of the available modules of the chassis.

RPR Mode—Displays the redundancy mode of the slot identified by the slot number.

IP Routing Status

IP routing is the process of moving packets from one network to another and delivering the packets to the hosts. Classless Inter-domain Routing (CIDR) is a method supported by classless routing protocols such as OSPF and BGP4. This is based on the concept of ignoring the IP class of the address permitting route aggregation and VLSM that enables the routers to combine the routes in order to minimize the routing information that needs to be conveyed by the primary routers. It allows a group of IP networks to appear to other networks as a unified and larger entity.

The IP Routing Status dialog displays the number of CIDR routes and details of the routes configured for the selected chassis. The user can use this information available in the IP Routing Status dialog to view and debug problems related to network CIDR routes.

An IP routing entry in the device can be configured using the following command sequence:

```
Router Prompt > configure terminal
ip route <Destination prefix> <Destination prefix mask> <Forwarding Router's Address>
```

The IP routing entries can be viewed using the command:

```
Router Prompt > show ip route
```

The Cisco 12000/10720 Router Manager uses the IP-FORWARD-MIB to populate the IP Routing Status dialog fields.

The IP Routing Status section covers the following areas:


- [Viewing the IP Routing Status window](#)
- [IP Routing Status Window—Detailed Description](#)

Viewing the IP Routing Status window

To view the IP Routing Status window for a chassis, proceed as follows:

- Step 1 Right click on the chassis object and select the **Cisco 12000/10720 Manager>Fault>IP Routing Status** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the IP Routing Status window.

Figure 4-21 IP Routing Status Window



Step 2 Choose the chassis from the left side of the window.

IP Routing Status Window—Detailed Description

The IP Routing Status dialog displays a single tab: Classless Inter-Domain Routing

Classless Inter-Domain Routing Tab

This tab contains the CIDR Info area that displays the following fields.

CIDR Info

No. of CIDR Routes—The number of current IPCIDRRouteTable entries that are not invalid.

Destination—Destination IP address of this route in the format of A.B.C.D

Subnet Mask—Indicate the mask to be logical-ANDed with destination address in the format of A.B.C.D

Next Hop—The address of the next system in the path to the destination in the format of A.B.C.D. otherwise its 0.0.0.0

Name of the Associated Interface/Sub-Interface—Local interface through which the next hop of this route should be reached.

Routing Protocol—The Routing Protocol via which this route was learned.

IP TOS—The Policy specifier applied to the route. The IP TOS with 0 indicates default path if no specific policy applies.

Routing Type—The type of the route. The possible values of the Routing Type field are other, reject, local, remote.

Route Info—Reference to the MIB definitions specific to the particular routing protocol which is responsible for this route.

Next Hop AS—The Autonomous System Number of the Next hop. If this Field is Not relevant to the route then value will be 0.

Route Age—The number of seconds since this route was last updated or otherwise determined to be correct.

Metric1—The Primary Routing metric for this route. If this metric is not used, its value will be -1.

Metric2—An alternate routing metric for this route. If this metric is not used, its value will be -1.

Metric3—An alternate routing metric for this route. If this metric is not used, its value will be -1.

Metric4—An alternate routing metric for this route. If this metric is not used, its value will be -1.

Metric5—An alternate routing metric for this route. If this metric is not used, its value will be -1.

TCP Status

TCP is a connection-oriented, reliable protocol that is defined at the Transport layer of the OSI reference model. TCP is responsible for breaking messages into segments, reassembling them at the destination station, and resending anything that is not received.

The TCP Status dialog gives complete information on the TCP sessions available on the device. It also gives a detailed description of the TCP counters. The dialog is also updated whenever a new TCP connection is established on the device. The network engineer can view the existing TCP connection and use this information to debug the problems in the network.

The TCP connections can be viewed using the following commands:

- `show tcp brief`
- `show tcp`

The Cisco 12000/10720 Router Manager uses the TCP-MIB to populate the TCP Status dialog fields.

The TCP Status section covers the following areas:


- [Viewing the TCP Status Window](#)
- [TCP Status Window—Detailed Description](#)

Viewing the TCP Status Window

To view the TCP Status window for a chassis, proceed as follows:


- Step 1** Right click on the chassis object and select the **Cisco 12000/10720 Manager>Fault>TCP Status** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the TCP Status window.

Figure 4-22 TCP Status Window



- Step 2** Choose the TCP Connections tab, if required.

Figure 4-23 TCP Status Window—TCP Connections Tab



TCP Status Window—Detailed Description

The TCP Status dialog displays two tabs: TCP Status and TCP Connections.

TCP Status Tab

The TCP Status tab displays the following fields:

TCP Status

Current Establishment—The number of TCP connections for which the current state is ESTABLISHED or CLOSE-WAIT.

Retransmitting Algorithm—The Algorithm used to determine the timeout value used for retransmitting unacknowledged octets.

Minimum Retransmission Timeout—The minimum value permitted by a TCP implementation for the retransmission timeout measured in milliseconds.

Active Opens—The number of times TCP connections have made a direct transition to the SYN-SENT state from the CLOSED state.

Establishment Resets—The number of times TCP connections have made a direct transition to the CLOSED state from either the ESTABLISHED state or the CLOSE-WAIT state.

Input Segments—The total number of segments received, including those received in error. This count includes segments received on currently established connections.

Retransmitted Segments—The total number of segments retransmitted - that is, the number of TCP segments transmitted containing one or more previously transmitted octets.

Attempts Failed—The number of times TCP connections have made a direct transition to the CLOSED state from either the SYN-SENT or the SYN-RCVD state plus the number of times TCP connections have made a direct transition to the LISTEN state from the SYN-RCVD state.

Maximum TCP Connections—The limit on the total number of TCP connections the entity can support. In entities where the maximum number of connections is dynamic, this object contains the value of -1.

Maximum Retransmission Timeout—The maximum value permitted by a TCP implementation for the retransmission timeout measured in milliseconds.

Passive Opens—The number of times TCP connections have made a direct transition to the SYN-RCVD state from the LISTEN state.

Output Resets—The number of TCP segments sent containing the RST flag.

Output Segments—The total number of segments sent, including those on current connections but excluding those containing only retransmitted octets.

Input Errors—The total number of segments received in error (e.g., bad TCP checksums).

TCP Connections Tab

The TCP Connections tab displays information from the TCP Connection Table. The TCP Connection Table contains information specific to the TCP connections. This Tab contains a “Connection Table” area that contains the following fields:

Connections Table

Local Port—Displays the local port number for the TCP connection. It can be any integer between 0 and 65535.

Local IP Address—Displays the local IP address for the TCP connection. If the TCP connection is in a listening state that is willing to accept connections for any IP interface associated with the node, then the value used and hence displayed will be 0.0.0.0

Remote Port—Displays the remote port number for the TCP connection. It can be any integer between 0 and 65535.

Remote IP Address—Displays the remote IP address for the TCP connection.

Connection State—Displays the current state of the TCP connection.

UDP Status

UDP is a connectionless, unacknowledged, and unreliable protocol that is defined at the Transport layer of the OSI reference model. Although UDP is responsible for transmitting messages, no software checking for segment delivery is provided at this layer. UDP depends on upper-layer protocols for verification.

The UDP Status dialog provides general details of all UDP connections established on the device. The dialog is also updated whenever a new UDP connection is established on the device. The network engineer can view the existing UDP connection and use the information to debug the problems in the network.

The UDP connections can be viewed using the following commands:

- `show ip traffic`
- `show ip sockets`

The Cisco 12000/10720 Router Manager uses the UDP-MIB to populate the UDP Status dialog fields.

The UDP Status section covers the following areas:


- [Viewing the UDP Status Window](#)
- [UDP Status Window—Detailed Description](#)

Viewing the UDP Status Window

To view the UDP Status window for a chassis, proceed as follows:

-
- Step 1** Right click on the chassis object and select the **Cisco 12000/10720 Manager>Fault>UDP Status** option. See [Table 4-1 on page 4-2](#) for information on which objects allow you to launch the UDP Status window.

Figure 4-24 UDP Status Window



Step 2 Choose the chassis from the left side of the window.

UDP Status Window—Detailed Description

The UDP Status dialog displays a single tab: Status

Status

This Tab displays an area, UDP and a table, UDP Port Information. The UDP area displays the following fields:

UDP

Incoming Datagrams—This displays the total number of UDP datagrams delivered to UDP users.

Outgoing Datagrams—This displays the total number of UDP datagrams sent from this entity.

Incoming Errored Datagrams—This displays the number of received UDP datagrams that could not be delivered for reasons other than the lack of an application at the destination port.

Number of Ports—This displays the total number of received UDP datagrams for which there was no application at the destination port.

UDP Port Information

The table UDP Table Information, displays the UDP Listener Information and it displays the following fields:

Local Port—The local port number for this UDP listener.

Local Address—This displays the local IP address for this UDP listener. If the UDP listener that is willing to accept datagrams for any IP interface associated with this node, then the value 0.0.0.0 is set and displayed.



Managing Modules

This chapter describes the management tasks that can be performed on the modules in the Cisco 12000/10720 Router being managed using the Cisco 12000/10720 Router Manager application.

The following modules can be managed using the Cisco 12000/10720 Router Manager:

- GRPs
- Line cards—ATM, Ethernet, SRP, POS, DS-3, Fast Ethernet, and Gigabit Ethernet
- Supporting modules—CSCs, SFCs, AC or DC power supply modules, fan tray modules, blower modules, alarm modules and bus board

This chapter contains the following sections:

- [Cisco 12000/10720 Router Manager Module Names](#)
- [Launching the Module Management Windows](#)
- [Module Configuration](#)
- [Module Fault Management](#)
- [Module Performance](#) (only available on GRPs)
- [Module Inventory](#)

Cisco 12000/10720 Router Manager Module Names

The naming convention used in Cisco 12000/10720 Router Manager for line cards, GRPs, CSCs, and SFCs is an abbreviated form of the type of module, followed by the slot number of the module. For example, an ATM line card in slot 6 is called A6, and a POS line card in slot 3 is called P3.

[Table 5-1](#) identifies each module type and its respective abbreviation in Cisco 12000/10720 Router Manager.

Table 5-1 *Abbreviated Module Names*

Module	Cisco 12000/10720 Router Manager Abbreviation
DS-3	D
POS	P
ATM	A
Fast Ethernet	FE

Table 5-1 Abbreviated Module Names (continued)

Module	Cisco 12000/10720 Router Manager Abbreviation
Gigabit Ethernet	GE
SRP	S
Unrecognized Modules*	GM (Generic Module)
GRP	RP
CSC	C
SFC	SF
Lower Blower	LBM
Upper Blower	UBM
Power Supply	PSM
Alarm	ALR

*Note that basic module management services are provided for any non-standard Cisco 12000/10720 Router Manager modules.

Launching the Module Management Windows

Table 5-2 displays the Module Management windows that can be launched from each object type. For example, the Module Fault Management window can be launched from a Site, Chassis or Module object, but cannot be launched from an Interface object.



Note

Table 5-2 lists the menu options to launch the module management dialogs from the site level.

Table 5-2 Launching the Module Management Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
Module Configuration	Yes	Yes	Yes	Yes	No	Cisco 12000/10720 Manager>Configuration>Module >Configuration
Module Fault Management	Yes	Yes	Yes	Yes	No	Cisco 12000/10720 Manager>Fault>Module>Fault Management
Module Performance	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Performance>Module> Performance
Module Inventory	Yes	Yes	Yes	Yes	No	Cisco 12000/10720 Manager>Accounting>Module>Inventory

**Note**

Cisco 12000/10720 Router Manager windows cannot be opened when multiple objects are selected (the menu options to open the Cisco 12000/10720 Router Manager windows are grayed out). Available menu options can be launched from a site object containing the required objects, when needed.

Module Configuration

The Configuration window allows you to commission or decommission any module. You can also provide text descriptions of the specific module, if required.

The Module Configuration section provides the following information:


- [Viewing the Configuration Window](#)
- [Commissioning a Selected Module](#)
- [Decommissioning a Selected Module](#)
- [Module Configuration Window—Detailed Description](#)

Viewing the Configuration Window

To view the Configuration window, proceed as follows:

- Step 1** Right click on a module and select the **Cisco 12000/10720 Manager>Configuration>Module Configuration** option. See [Table 5-2 on page 5-2](#) for information on which objects allow you to launch the Configuration window. The Configuration window appears with the Configuration tab displayed.

Figure 5-1 Configuration Window



Step 2 Choose a **Chassis** and **Module** from the list boxes displayed at the left of the window.

Commissioning a Selected Module

Commissioning any card also commissions all the interfaces under the card.



Note


You can select multiple Modules (from the Module object selector list) which allows you to commission all of the selected modules simultaneously. You can choose multiple modules in a list by holding down the Shift key and then selecting the first and last module in the list. You can choose multiple individual modules by holding down the Ctrl key and clicking on the individual modules.

To commission a module, proceed as follows:

- Step 1** Open the Configuration window. See [“Viewing the Configuration Window”](#) section on page 5-3 for further details.
- Step 2** Choose a **Chassis** and **Module** from the list boxes displayed at the left of the window.
- Step 3** Enter additional descriptions into the Description 1 and Description 2 fields in the Additional Descriptions area (if required). Entering additional descriptions is optional.

- Step 4** Click **Commission** to commission the selected module. An Action Report window appears confirming that the commissioning action was completed successfully.

Figure 5-2 Action Report Window



- Step 5** Click **Close** to close the Action Report window.

The selected module is now commissioned. Commissioning a GRP or any supporting module initiates the following activities:

- Heartbeat polling begins on the object
- The state is changed to normal
- Status data becomes available

Commissioning a line card initiates the following activities:

- All interfaces on the line card are also commissioned
- Heartbeat polling begins on the line card and interfaces
- The line card and active interfaces are placed in the normal state
- Any interfaces that are pre-deployed but not active change to the errored state
- Status data becomes available on the line card and interfaces

Decommissioning a Selected Module



Note


You can select multiple Modules from the Module object selector list. Selecting multiple modules allows you to decommission all of the selected modules simultaneously. You can choose multiple modules in a list by holding down the Shift key and then selecting the first and last module in the list. You can choose multiple individual modules by holding down the Ctrl key and clicking on the individual modules.

Decommissioning a GRP card also decommissions all interfaces under that GRP card.

To decommission a module, proceed as follows:

-
- Step 1** Open the Configuration window. See “[Viewing the Configuration Window](#)” section on page 5-3 for further details.
- Step 2** Choose a **Chassis** and **Module** from the list boxes displayed at the left of the window.
- Step 3** Click **Decommission** to decommission the selected module. An Action Report window appears confirming that the decommissioning action was completed successfully.

Figure 5-3 Action Report Window



- Step 4** Click **Close** to close the Action Report window.

The selected module is now decommissioned. Decommissioning a GRP or any supporting module initiates the following activities:

- Heartbeat polling stops on the object
- The state is changed to decommissioned
- Status data is no longer available
- Performance polling stops on the module (if enabled)

Decommissioning a line card initiates the following activities:

- All interfaces and ATM connections on the line card are also decommissioned
 - Heartbeat polling stops on the line card and interfaces
 - The line card, interfaces, and ATM connections are placed in the decommissioned state
 - Status data is no longer available on the line card and interfaces
 - Performance polling stops on the line card and interfaces (if enabled)
-

Module Configuration Window—Detailed Description

The Module Configuration window displays a single Configuration tab.

Configuration Tab

The Configuration tab (see [Figure 5-1 on page 5-4](#)) displays three areas: Additional Descriptions Actions, and Commission Status.

Additional Descriptions

The Descriptions 1 and Descriptions 2 fields (optional) allow you to specify additional description information for the selected module (if required).

Actions

The Actions area contains two buttons:

Commission—Commissions the selected module.

Decommission—Decommissions the selected module.

Commission Status

The Commission Status area displays the status of the last commission performed on the selected module. Possible values are Succeeded or Failed.

Module Fault Management

The Module Fault Management window is a read-only window and provides fault information for a selected module. You do not need to enter any information into any of the fields. This section provides the following information:


- [Viewing the Module Fault Management Window](#)
- [Module Fault Management Window—Detailed Description](#)

Viewing the Module Fault Management Window

To view the Module Fault Management window, proceed as follows:

- Step 1** Right click on a module and select the **Cisco 12000/10720 Manager>Fault>Module Fault Management** option. See [Table 5-2 on page 5-2](#) for information on which objects allow you to launch the Module Fault Management window. The Module Fault Management window appears, with the Fault Management tab displayed.

Figure 5-4 Module Fault Management Window



- Step 2** Choose a **Chassis** and **Module** from the list boxes at the left of the window. The fault management information for the selected module appears. For detailed information on the areas within this tab, see “[Module Fault Management Window—Detailed Description](#)” section on page 5-8.

Module Fault Management Window—Detailed Description

The Module Fault Management window displays a single Fault Management tab. The Fault Management tab displays two areas: Module Availability and Cisco Contact Details.



Note

The details related to the modules are available only if the module is in a managed state.

Module Availability

The Module Availability area contains the following fields:

- **Up Time**—Displays the time after the network portion of the system was last re-initialized for the selected module.
- **Free Memory**—Displays the memory space (in bytes) currently unused by the selected GRP module.
- **Last Restart Reason**—Displays the reason for the system being re-initiated for the selected GRP module.

- Last Authentication Failure Address—Displays the last authorization failure IP address for the selected module.
- Operational Status—Displays the current operational status of the selected GRP module. Possible values are:
 - Up—Module is recognized by the device and is operational.
 - Down—Module is not recognized by the device or not enabled for operation.
 - Standby—Module is enabled and is acting as standby. This value is only applicable for redundant GRPs.

Cisco Contact Details

The Cisco Contact Details area provides Cisco contact details.

Module Performance

The Module Performance window displays the current performance information for the selected GRP module.



Note

You can select multiple Modules from the Module object selector list. Selecting multiple modules allows you to start or stop performance logging for all of the selected modules simultaneously. You can choose multiple modules in a list by holding down the Shift key and then selecting the first and last module in the list. You can choose multiple individual modules by holding down the Ctrl key and clicking on the individual modules.

The Module Performance tab displays CPU Usage information and allows you to Start or Stop performance logging for one or more selected modules.



Note

Performance logging can also be started on a per module (GRP) or physical interface basis. For details on how to start performance logging for a selected module (GRP), see “[Module Performance](#)” section on page 5-9. For details on how to start performance logging for a selected physical interface (such as Ethernet, ATM, or DS-3), see “[Starting Performance Logging for a Selected Interface](#)” section on page 10-5.

Selecting a module provides performance data for the selected module. The values displayed relate to CPU performance, so modules without a CPU display the same value as the CPU card in the chassis.

The Module Performance section provides the following information:

- [Viewing the Module Performance Window](#)
- [Starting or Stopping Performance Logging](#)
- [Module Performance Window—Detailed Description](#)

Viewing the Module Performance Window




Note

The Module performance window can be launched from the chassis level. Please note that this window cannot be launched from the module level.

To view the Module Performance window, proceed as follows:

- Step 1** Right click on the chassis object and select the **Performance>Module>Performance** option. See [Table 5-2 on page 5-2](#) for information on which objects allow you to launch the Module Performance window. The Module Performance window appears, with the Performance tab displayed.

Figure 5-5 Module Performance Window



- Step 2** Choose a **Chassis** and **Module(s)** from the list boxes displayed at the left of the window. The performance information for the selected GRP module is displayed.

Starting or Stopping Performance Logging

Performance logging allows performance information to be collected for a selected module. This historical information can then be viewed using the Cisco EMF Performance Manager application. [Chapter 20, “Performance Management and Historical Data,”](#) provides further information on how to use the Performance Manager application.

To Start/Stop performance logging for a selected module, proceed as follows:

-
- Step 1** Open the Module Performance window. See “[Viewing the Module Performance Window](#)” section on [page 5-10](#) for further details.
- Step 2** Choose a **Chassis** and **Module(s)** from the list boxes displayed at the left of the window. The performance information for the selected GRP module is displayed.



Note You can select multiple Modules from the Module object selector list. Selecting multiple modules allows you to start/stop performance logging for all of the selected modules simultaneously. You can choose multiple modules in a list by holding down the Shift key and then selecting the first and last module in the list. You can choose multiple individual modules by holding down the Ctrl key and clicking on the individual modules.

- Step 3** Click **Start** to begin performance logging for the selected module. Click **Stop** to stop performance logging for the selected module.
- Step 4** Launch the Performance Manager application to view the historical performance information for the selected module. See [Chapter 20, “Performance Management and Historical Data,”](#) for further information on how to use the Performance Manager application.
-

Module Performance Window—Detailed Description

The Module Performance window (see [Figure 5-5 on page 5-10](#)) displays a single Performance tab. The Performance tab has two areas: CPU Usage and Performance Logging.

CPU Usage

The CPU Usage area displays the following fields:

- **CPU Busy%**—Displays the percentage of CPU put to use for the selected GRP module.
- **Average (1 min)**—Displays the percentage of CPU being utilized averaged over a one minute period for the selected GRP module.
- **Average (5 min)**—Displays the percentage of CPU being utilized averaged over five minute period for the selected GRP module.

Performance Logging

The Performance Logging area allows you to start or stop performance logging.

- **Start**—Click **Start** to enable performance logging for the selected GRP module. Enabling performance logging allows performance data to be gathered for the selected module. Performance polling occurs every 15 minutes. Performance data is then gathered and stored for historical review.
Current performance data can be viewed in the performance windows, or you can view historical performance data in Performance Manager.
- **Stop**—Click **Stop** to stop all performance logging on the selected module. Disabling performance logging stops performance data from being gathered for the selected GRP module.

Module Inventory

The Module Inventory section provides the following information:


- [Viewing the Module Inventory Window](#)
- [Module Inventory Window—Detailed Description](#)

Viewing the Module Inventory Window

To view the Module Inventory window for a selected module, proceed as follows:

- Step 1 Right click on the module and select the **Cisco 12000/10720 Manager>Accounting>Module Inventory** option. See [Table 5-2 on page 5-2](#) for information on which objects allow you to launch the Module Inventory window. The Module Inventory window appears, with the General tab displayed.

Figure 5-6 Module Inventory Window



Not applicable for Cisco 12000/10720 Router Manager

- Step 2** Choose a **Chassis** and **Module** from the list boxes at the left of the window. The inventory information for the selected module appears.



Note The Module Inventory window is read-only.

Module Inventory Window—Detailed Description

The Module Inventory window has two tabs: General and Asset Tracking. Only the General tab is applicable to Cisco 12000/10720 Router Manager. The Asset Tracking tab is not applicable to Cisco 12000/10720 Router Manager.

General

The General tab (see [Figure 5-5 on page 5-10](#)) has four areas:

Module Details

The Module Details area contains the following fields:

Serial Number—Displays the serial number of the selected module. This number is zero if data is unavailable.

Description—Displays a description of the selected module.

Type—Displays the type of the selected module.

System Details

The System Details area contains the following fields:

Host Name—Displays the host name of the system which contains the selected module.

Boot Image Host—Displays the IP address of the host, which supplies the software currently running.

Description—Displays the hardware type, software operating system, and networking software of the system that contains the selected module.

ROM ID—Displays the system boot strap description and version identifier.

Domain Name—Displays the domain portion of the domain name for the system which contains the selected module.

Services—Displays all the services available on the system.

Version Details

The Version Details area contains the following fields:

IOS—Displays the IOS operating software version being used by the selected module.

Hardware—Displays the version of the selected module.

Firmware—Not applicable to Cisco 12000/10720 Router Manager.

Software—Displays the software version installed in the card. No information appears if data is not available.

Slot & Ports

The Slot & Ports area contains the following fields:

Slot Number—Slot position the module occupies in the chassis.

Max Supported Ports—Maximum number of ports supported on this module.

Sub Slot Number—Not applicable to Cisco 12000/10720 Router Manager.

Number of Working Ports—Not applicable to Cisco 12000/10720 Router Manager.

Asset Tracking


The Asset Tracking tab is not applicable to Cisco 12000/10720 Router Manager.



Managing Interfaces

This chapter describes the management tasks that can be performed on the interfaces of the Cisco 12000 Series and the Cisco 10720 Router being managed using the Cisco 12000/10720 Router Manager application. A number of interface topics (and the order in which they should be carried out) are identified in [Figure 6-1](#).

Figure 6-1 Managing Interfaces



Cisco 12000/10720 Router Manager Interface Naming Conventions

The interfaces under each linecard are named according to the names displayed by the IOS in the router, for example, interfaces under an ATM Linecard in slot 1 are named as: ATM 1-0, ATM 1-1, ATM 1-2, ATM 1-3 and interfaces on a POS Linecard in slot 3 are named as POS 3-0, POS 3-1 and so on.

[Table 6-1](#) lists abbreviated interface names for other linecards in Cisco 12000/10720 Router Manager.

Table 6-1 Abbreviated Interface Names

Interface	Cisco 12000/10720 Router Manager Abbreviation
POS	POS 2-0
Fast Ethernet	FastEthernet 2-0
Gigabit Ethernet	GigabitEthernet 3-0
SRP	SRP 4-0
DS3	Serial 6-0
Ethernet (GRP)	Ethernet 0-0
ATM	ATM 7-0

The following chapters describe the interface management topics:


- [Chapter 7, “Interface Profiles”](#)
- [Chapter 8, “Interface Configuration”](#)
- [Chapter 9, “Interface Status”](#)
- [Chapter 10, “Interface Performance”](#)
- [Chapter 11, “Layer 3 QoS”](#)
- [Chapter 12, “Managing ATM Connections”](#)
- [Chapter 18, “Fault Management”](#)



Interface Profiles

This chapter describes how to create interface profiles using the Cisco 12000/10720 Router Manager application. Cisco 12000/10720 Router Manager allows you to create and apply profiles to interfaces (see [Figure 7-1](#)).

Figure 7-1 Interface Profiles Workflow



Profiles allow you to apply a set of existing parameters to a number of similar type objects, eliminating the need to enter the same data numerous times. Once you have created a profile, you can apply that same profile to a number of interfaces, as applicable. This saves you from having to enter the same configuration information each time for the same type of objects.



Tip

When you choose a profile name, it is recommended to use a naming convention that describes the profile type. For example, an ATM profile might be called ATM1, a POS profile might be called POS2, and an HSRP profile could be HSRP1.

This chapter contains the following information:

- “Interface Profile Types” section on page 7-2
- “Launching the Interface Profile Windows” section on page 7-2
- “Creating an ATM Interface Profile” section on page 7-3
- “Creating a POS Interface Profile” section on page 7-12
- “Creating an HSRP Profile” section on page 7-9
- “Creating a SRP Side Profile” section on page 7-17

Interface Profile Types

Table 7-1 outlines the profile types available, and details the windows that apply to each profile type.

Table 7-1 Interface Profile Types and Applicable Cisco 12000/10720 Router Manager Windows

Interface Profile Type	Applicable Windows
ATM Profile	ATM Configuration
HSRP Profile	Ethernet Configuration
POS Profile	POS Configuration
SRP Side Profile	SRP Side Configuration

Launching the Interface Profile Windows

Table 7-2 displays the Interface Profile windows that can be launched from each object type. For example, the POS Interface Profile window can be launched from a Site, Chassis, Module or a POS Interface.



Note

Table 7-2 lists the menu options to launch the interface profile dialogs from the site level.

Table 7-2 Launching the Interface Profile Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
Creating an ATM Interface Profile	Yes	Yes	No	Yes	Generic, ATM	Cisco 12000/10720 Manager>Configuration>Interface>ATM> Configuration Profile
Creating an HSRP Profile	Yes	Yes	Yes	Yes	Generic, Ethernet	Cisco 12000/10720 Manager>Configuration>Interface> IP>HSRP Configuration Profile
Creating a POS Interface Profile	Yes	Yes	Yes	Yes	Generic, POS	Cisco 12000/10720 Manager>Configuration>Interface> POS>Configuration Profile
Creating a SRP Side Profile	Yes	Yes	Yes	Yes	Generic, SRP	Cisco 12000/10720 Manager>Configuration>Interface>SRP> Side>Configuration Profile

**Note**

Cisco 12000/10720 Router Manager windows cannot be opened when multiple objects are selected (the menu options to open the Cisco 12000/10720 Router Manager windows are grayed out). Available menu options can be launched from a site object containing the required objects, when required.

Creating an ATM Interface Profile

**Note**

The ATM Interface Profile is not supported on the 10720 chassis.

To create an ATM interface profile, proceed as follows:

- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>ATM>Configuration Profile** option from an ATM interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the ATM Interface Configuration Profile window.

Figure 7-2 ATM Interface Configuration Profile Window (Configuration (1) Tab)

ATM Interface Configuration Profile

File Edit Options Window Actions Help

Configuration (1) Configuration (2)

ATM Configuration

Interface Type	other	UNI Type	public
ATM Interface Side	user	UNI Signalling Version	atmfUni3Dot0
SVC UPC Intent	passing	Signalling Admin Status	enabled
Loopback	line	Well-known VC Mode	automatic
Maximum VPCs	1	Transmit Queue Limit	
Maximum VCCs	128	Maximum Active VPI Bits	1
Number of VCs per VP	128	Maximum Active VCI Bits	1
Clock Source	none		

ILMI Configuration

Keepalive Time	55	Trap	disabled
Auto-Configuration	enabled	Configuration	enabled
Address Registration	enabled		

ATM Profile

Create Profile

Dynamic updates are enabled

84718

Not applicable for Cisco 12000/10720 Router Manager

See “ATM Interface Configuration Profile Window—Detailed Description” section on page 7-7 for further information on the parameters displayed in this window.

- Step 2** Click **Create Profile**. A Prompt window appears (see Figure 7-3) for you to enter a name for the new profile.



Note Each profile must have a unique name. Do not insert spaces into a profile name. When you choose a profile name, it is recommended to use a naming convention that describes the profile type. For example, an ATM profile might be called ATM1.

Figure 7-3 Prompt Window



- Step 3** Enter a name for the new profile in the Enter profile name data entry box.
- Step 4** Click **Ok**. The ATM Interface Configuration Profile window reappears with the new profile name displayed in the ATM Profile list at the left of the window.



Note Choose the **Copy** and **Copy Page Configuration** options in the **Edit** menu to cut and paste between different profiles. This is useful when you wish to copy information from one profile to the next.

- Step 5** Configure the parameters displayed in the ATM Configuration and ILMI Configuration areas, as required.



Note You can apply an existing profile to a new profile to save time when configuring new profiles. Choose the **Apply Profile** option from the **Edit** menu and then choose the existing profile you wish to apply from the profiles listed. The configuration settings are copied from the existing profile to the new profile. The settings copied appear in blue.



Note The parameters displayed in the **Configuration (2)** tab are not applicable to Cisco 12000/10720 Router Manager.

- Step 6** Choose **File > Save** to save the parameters you have selected for your profile.
- Step 7** Choose **File > Close** to close the window.



Note You have now created a profile for the ATM Interface. Proceed to the [“Configuring and Commissioning a Generic Interface”](#) section on page 8-4 for details on applying the profile and configuring the interface.

Editing an Existing ATM Interface Profile

To edit an existing ATM Interface profile, proceed as follows:


-
- Step 1 Choose the **Cisco 12000/10720 Manager>Configuration>ATM>Configuration Profile** option from an ATM interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the ATM Interface Configuration Profile window.
 - Step 2 Choose the profile you wish to edit from the list of existing profiles displayed in the ATM Interface list at the left of the window (see [Figure 7-2](#)).
 - Step 3 Edit the parameters displayed in the Configuration (1) tab, as required.
 - Step 4 Choose **File > Save** to save the changes made to the service profile.
 - Step 5 Choose **File > Close** to close the window.
-

Deleting an Existing ATM Interface Profile

To delete an existing ATM Interface profile, proceed as follows:

-
- Step 1 Choose the **Cisco 12000/10720 Manager>Configuration>ATM>Configuration Profile** option from an ATM interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the ATM Interface Configuration Profile window.
 - Step 2 Choose the **Edit > Delete Profile**. Choose the profile you wish to delete from the list displayed. A Deletion Prompt window appears (see [Figure 7-4](#)) for you to confirm that you wish to delete the selected profile.

Figure 7-4 Deletion Prompt Window



- Step 3 Click **Yes** to delete the selected profile or click **No** to close the window without deleting the profile. When a profile is deleted it disappears from the list of existing profiles displayed in the ATM Profile list at the left of the window.
-

ATM Interface Configuration Profile Window—Detailed Description

The ATM Interface Configuration Profile window displays two tabs: Configuration (1) and Configuration (2).

Configuration (1) Tab

The Configuration (1) tab (see [Figure 7-2](#)) displays two areas: ATM Configuration, and ILMI Configuration.

ATM Configuration

The ATM Configuration area displays the following attributes:

Interface Type—Not applicable for Cisco 12000/10720 Router Manager.

ATM Interface Side—Not applicable for Cisco 12000/10720 Router Manager.

SVC UPC Intent—Not applicable for Cisco 12000/10720 Router Manager.

Neighbor Address Type—IP address of the neighbor system connected to the far end of this interface. Not applicable for Cisco 12000/10720 Router Manager.

Neighbor Interface Name—Name of the connected interface on the neighbor system at the far end of this interface. Not applicable for Cisco 12000/10720 Router Manager.

Loopback—Allows you to choose the loopback mode. The following options are available:

- Line—Packets are transmitted back to the source to test the interface functionality and ensure that packets transmitted through the interface reach the destination without data loss.

- No Loopback—Restricts connection status (success or failure) messages from being received.

- Diagnostic —Transmit data stream is looped to the transmit direction.

Maximum VPCs—Not applicable for Cisco 12000/10720 Router Manager.

Maximum VCCs—The maximum number of VCCs (PVCs and SVCs) supported at this interface.

Number of VCs per VP—Allows you to set the number of virtual channels per virtual path.

UNI Type—Not applicable for Cisco 12000/10720 Router Manager.

UNI Signalling Version—Version of UNI signalling that is currently being used on the interface. The appropriate value, either atmUni3Dot0, atmUni3Dot1, or atmUni4Dot0, is used when the interface is an UNI or IISP interface. The value “not applicable” is used when the interface is a PNNI interface or when signalling is disabled. Setting this variable to a value of not applicable is not allowed. To modify this field, the interface admin status has to be down and the interface Ilmi auto configuration disabled.

Signalling Admin Status—Enables or disables signalling/sscop on this interface. The disabled action causes all the active SVCs on this interface to be cleared. Not applicable for Cisco 12000/10720 Router Manager.

Well-known VC Mode—Not applicable for Cisco 12000/10720 Router Manager.

Transmit Queue Limit—Not applicable for Cisco 12000/10720 Router Manager.

Maximum Active VPI Bits—Not applicable for Cisco 12000/10720 Router Manager.

NSAP (Network Service Access Point) Address—Specify the NSAP address. Not applicable for Cisco 12000/10720 Router Manager.

Maximum Active VCI Bits—Not applicable for Cisco 12000/10720 Router Manager.

Clock Source—Source of the clock.

ILMI Configuration

The ILMI Configuration area contains the following fields:

Keepalive Time—The amount of time that should elapse between successive ILMI keepalive messages sent on this interface. A value of 0 disables ILMI keepalive messages on this interface.

Auto-Configuration—You can enable or disable the ILMI link and interface type determination. The configuration takes effect only on the next interface restart.

Address Registration—You can enable or disable ILMI Address Registration on this interface. The configuration takes effect only on the next interface restart.

Configuration—Enable or disable ILMI configuration on this interface. The configuration takes effect only on the next interface restart. Disabling this object will also disable address registration, auto-configuration, and keepalive time.

Trap—Allows you to enable or disable the ILMI traps.

Actions

Create Profile—Choose **Create Profile** to create a new profile.

Configuration (2) Tab

The Configuration (2) tab displays three areas: Information Element Transfer, Physical layer and DS1/E1/DS3/E3.

Information Element Layer

Not applicable to Cisco 12000/10720 Router Manager.

Physical Layer

Not applicable to Cisco 12000/10720 Router Manager.

DS1/E1/DS3/E3

Line Buildout—Not applicable to Cisco 12000/10720 Router Manager.


Framing Mode—The framing format present on the physical interface.

Creating an HSRP Profile

To create an HSRP profile, proceed as follows:

- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>IP>HSRP Configuration Profile** option from an Ethernet interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the HSRP Profile window.


Figure 7-5 HSRP Profile Window



See “[HSRP Profile Window—Detailed Description](#)” section on page 7-11 for further information on the parameters displayed in this window.

- Step 2** Click **Create**. A Prompt window appears (see [Figure 7-9](#)) for you to enter a name for the profile.

Figure 7-6 Prompt Window



Step 3 Enter a name for the new profile in the Enter profile name data entry box.



Note Each profile must have a unique name. When you choose a profile name, it is highly recommended to use a naming convention that describes the profile type. For example, an HSRP profile could be HSRP1.

Step 4 Click **Ok**. The HSRP Profile window reappears with the new profile name displayed in the HSRP Profile list at left of the window.



Note Choose the **Edit > Copy** and **Edit > Copy Page Configuration** to cut and paste between different profiles. This is useful when you wish to copy information from one profile to the next.

Step 5 Configure the parameters displayed, as required.



Note You can apply an existing profile to a new profile to save time when configuring new profiles. Choose **Edit > Apply Profile** and then choose the existing profile you wish to apply from the profiles listed. The configuration settings are copied from the existing profile to the new profile. The settings copied appear in blue.

Step 6 Choose **File > Save** to save the parameters you have selected for your profile.

Step 7 Choose **File > Close** to close the window.



Note You have now created a profile for the HSRP Interface. Proceed to the [“Ethernet Interface Configuration” section on page 8-9](#) for details on applying the profile and configuring the interface.

Editing an Existing HSRP Interface Profile

To edit an existing HSRP Interface profile, proceed as follows:

Step 1 Choose the **Cisco 12000/10720 Manager>Configuration>IP>HSRP Configuration Profile** option from an Ethernet interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the HSRP Profile window.

Step 2 Choose the profile you wish to edit from the list of existing profiles displayed in the HSRP Profile list at the left of the window (see [Figure 7-8](#)).

Step 3 Edit the parameters displayed, as required.

Step 4 Choose **File > Save** to save the changes made to the service profile.


Step 5 Choose **File > Close** to close the window.

Deleting an Existing HSRP Interface Profile

To delete an existing HSRP Interface profile, proceed as follows:

- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>IP>HSRP Configuration Profile** option from an Ethernet interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the HSRP Profile window.
- Step 2** Choose **Edit > Delete Profile**. Choose the profile you wish to delete from the list displayed. A Deletion Prompt window appears (see [Figure 7-7](#)) for you to confirm that you wish to delete the selected profile.

Figure 7-7 Deletion Prompt Window



- Step 3** Click **Yes** to delete the selected profile or click **No** to close the window without deleting the profile. When a profile is deleted it disappears from the list of existing profiles displayed in the HSRP Profile list at the left of the window.

HSRP Profile Window—Detailed Description

The HSRP Profile window displays a single tab: HSRP Profile Parameters

HSRP Profile Parameters Area

The HSRP Profile Parameters area allows you to configure the following information:

Group Number—The group number on the interface for which HSRP is being activated. Standby routers are grouped and assigned a group number.

Standby Priority—Displays the standby priority for the interface. Standby priority can be set to:

Enabled—When the current interface fails it automatically switches to the standby interface.

Disabled—When the current interface fails it does not switch to a standby interface.

Standby Authentication—Allows you to enable or disable the standby authentication string. Options available are:

Enabled—It will check for the authentication string set and will allow you to configure the interface on presence of the set string.

Disabled—It will not check for an authentication string.

Standby Hello Time [1-255]—Enter the hello interval in seconds (1 to 255). The default time is 3 seconds.

Standby Preempt—Allows you to set the standby preempt. The standby router waits for the set time and takes over as the active router if the current router fails or does not respond to the packets sent.

IP Address—Enables HSRP and sets the virtual ip address.

Priority [0-255]—Allows you to set the priority value that prioritizes a potential Hot Standby router. The allowable range is 0 to 255.

Authentication String—Enter the set authentication string. Its purpose is to avoid any damage to the interface and can be up to eight characters in length.

Standby Hold Time [1-255]—Allows you to set the time (in seconds) for standby system to wait for the active interface to communicate about its status. On expiry of time set, the standby interface takes over as the active interface. The default time is 10 seconds.

Actions


Create—Choose **Create** to create a new profile.

Creating a POS Interface Profile

To create a POS interface profile, proceed as follows:

-
- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>POS>Configuration Profile** option from a POS interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the POS Profile Dialog window.

Figure 7-8 POS Profile Dialog —POS Config Tab



See “[POS Profile Window—Detailed Description](#)” section on page 7-15 for further information on the parameters displayed in this window.

- Step 2** Click **Create Profile**. A Prompt window appears (see [Figure 7-9](#)) for you to enter a name for the new profile.

Figure 7-9 Prompt Window



- Step 3** Enter a name for the new profile in the Enter profile name data entry box.



Note Each profile created must have a unique name. Do not insert spaces into a profile name. When you choose a profile name, it is highly recommended to use a naming convention that describes the profile type. For example, a POS profile might be called POS1.

- Step 4** Click **Ok**. The POS Profile window reappears with the new profile name displayed in the POS Profile list at left of the window.



Note Choose the **Edit > Copy** and **Edit > Copy Page Configuration** to copy and paste between different profiles. This is useful when you wish to copy configuration information from one profile to the next.

- Step 5** Configure the parameters displayed in the General, SONET Overhead, Alarm Reporting & Threshold, and Alarm Reporting areas, as required.



Note You can apply an existing profile to a new profile to save time when configuring new profiles. Choose **Edit > Apply Profile** and then choose the existing profile you wish to apply from the profiles listed. The configuration settings are copied from the existing profile to the new profile. The settings copied appear in blue.

- Step 6** Choose **File > Save** to save the parameters you have selected for your profile.

- Step 7** Choose **File > Close** to close the window.



Note You have now created a profile for the POS Interface. Proceed to the [“POS Interface Configuration” section on page 8-15](#) for details on applying the profile and configuring the interface.

Editing an Existing POS Interface Profile

To edit an existing POS Interface profile, proceed as follows:


- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>POS>Configuration Profile** option from a POS interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the POS Profile Dialog window.
- Step 2** Choose the profile you wish to edit from the list of existing profiles displayed in the POS Profile list at the left of the window (see [Figure 7-8](#)).
- Step 3** Edit the parameters displayed in the POS Config tab, as required.
- Step 4** Choose **File > Save** to save the changes made to the service profile.
- Step 5** Choose **File > Close** to close the window.

Deleting an Existing POS Interface Profile

To delete an existing POS Interface profile, proceed as follows:

-
- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>POS>Configuration Profile** option from a POS interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the POS Profile Dialog window.
- Step 2** Choose **Edit > Delete Profile**. Choose the profile you wish to delete from the list displayed. A Deletion Prompt window appears (see [Figure 7-10](#)) for you to confirm that you wish to delete the selected profile.

Figure 7-10 Deletion Prompt Window



- Step 3** Click **Yes** to delete the selected profile or click **No** to close the window without deleting the profile. When a profile is deleted it disappears from the list of existing profiles displayed in the POS Profile list at the left of the window.
-

POS Profile Window—Detailed Description

The POS Interface Configuration window displays a single POS Config tab.

POS Config Tab

The POS Config tab displays four areas: General, SONET Overhead, Alarm Reporting & Threshold and Alarm Reporting.

General

The General area allows you to configure the following information:

POS SPE Scrambling—Allows you to enable or disable POS SPE scrambling. The Disabled option is selected by default.

Loopback—Allows you to select the loopback mode. Options available are: Disabled, Internal or Line.

Clock Source—Allows you to choose clock source from available options. There is a clock in every device, which measures the speed of the device. This can either be Internal (within the device) or Line (the network clock).

Keepalive—Allows to set keepalive period. The system sends packets to know if the interface or the network is up for routing packets. By default it is 10 seconds.

POS Framing—Allows you to select SDH or SONET type POS framing.

Encapsulation—Allows you to select HDLC, PPP or FRAME RELAY encapsulation type. The default value is HDLC.

Cyclic Redundancy Check—Allows you to select an option for cyclic redundancy check. Cyclic redundancy check basically consists of 16 or 32 bit verification code which has to be same at the both the transmitting and receiving to ensure the packets sent are received in full without loss of data. By default it is 32 bit code.

SONET Overhead

The SONET Overhead area allows you to configure the following information:

Path Signal Identifier—Allows you to set the path signal identifier. Permissible values range from 0 to 255.

Section Trace Byte—Allows you to set the section trace byte. Permissible values are 0 to 255.

Payload Pointer Byte—Allows you to select an option for payload pointer byte from the drop down menu. Permissible values range from 0 to 3.

Alarm Reporting & Threshold

The Alarm Reporting & Threshold area allows you to configure the following information:

B1 BER Threshold Crossing Alarm—Allows you to fix threshold limits for the system to prompt appropriate B1 BER Threshold alarm messages.

B2 BER Threshold Crossing Alarm—Allows you to fix threshold limits for the system to prompt appropriate B2 BER Threshold alarm messages.

B3 BER Threshold Crossing Alarm—Allows you to fix threshold limits for the system to prompt appropriate B3 BER Threshold alarm messages.

Signal Degrade BER—Allows you to fix threshold limits for the system to prompt appropriate Signal Degrade BER Threshold alarm messages.

Signal Fail BER—Allows you to fix threshold limits for the system to prompt appropriate Signal Fail BER Threshold alarm messages.

Threshold (in 10e-)—Displays a threshold value.

Alarm Reporting

The Alarm Reporting area allows you to configure the following information:

Path Remote Defect Indication Errors—Allows you to enable or disable the path remote defect indication errors alarm messages.

Line Remote Defect Indication Errors—Allows you to enable or disable the line remote defect indication errors alarm messages.

Line Alarm Indication Signal Errors—Allows you to enable or disable the line alarm indication signal errors alarm messages.

Receive Data Out of Lock Errors—Allows you to enable or disable the Receive data output of lock errors alarm messages.

Path Alarm Indication Signal Errors—Allows you to enable or disable the path alarm indication signal errors alarm messages.

Section Loss of Signal Errors—Allows you to enable or disable the loss of signal errors alarm messages.

LAIS on Interface Shutdown—Allows you to enable or disable the LAIS on interface shutdown alarm messages.

Section Loss of Frame Errors—Allows you to enable or disable the section loss of frame errors alarm messages.

Path Loss of Pointer Errors—Allows you to enable or disable the path loss of pointer errors alarm messages.

Action


Create Profile—Choose **Create Profile** to create a new profile.

Creating a SRP Side Profile

To create a SRP Side profile, proceed as follows:

- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>SRP>Side>Configuration Profile** option from a SRP side interface object. See [Table 7-2 on page 7-2](#) for information on which objects allow you to launch the SRP Side Profile window.

Figure 7-11 SRP Side Profile Window



75248

- Step 2** Click **Create Profile**. A Prompt window appears (see [Figure 7-13](#)) for you to enter a name for the profile.
- Step 3** Click on the Alarms tab, if required.

Figure 7-12 SRP Side Profile Window—Alarms tab





Figure 7-13 Prompt Window



- Step 4** Enter a name for the new profile in the Enter Profile Name data entry box.

- Step 5** Click **OK**. The SRP Side Profile window reappears with the new profile name displayed in the SRP Side Profile list at left of the window.



Note Each profile must have a unique name. Do not insert spaces into a profile name. A profile with a null value cannot be created. When you choose a profile name, it is highly recommended to use a naming convention that describes the profile type. For example, an SRP Side profile could be named as Side01.

- Step 6** Modify the parameters in the tab as required. See “[SRP Side Profile Window—Detailed Description](#)” section for further details.



Note Choose the **Copy**, **Copy Page Configuration** and **Paste and Save Configuration** options in the **Edit** menu to cut and paste between different profiles. This is useful when you wish to copy configuration information from one profile to the next.

- Step 7** Choose **File > Save** to save the parameters you have selected for your profile.

- Step 8** Choose **File > Close** to close the window.



Note You have now created a profile for the SRP Side Interface.

Editing an Existing SRP Side Profile

To edit an existing SRP Side Profile, proceed as follows:


- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>SRP>Side>Configuration Profile** option from a SRP side interface object to launch the SRP Side Profile window.
- Step 2** Choose the SRP Side Profile from the SRP Side Profile list displayed at the left side of the window.
- Step 3** Modify the parameters, as required.
- Step 4** Click **Save** to save the changes.

Deleting an Existing SRP Side Profile

To delete an existing SRP Side Profile, proceed as follows:

- Step 1** Choose the SRP Side Profile you wish to delete.
- Step 2** Choose **Edit > Delete Profile**. Choose the profile you wish to delete from the list displayed. A Deletion Prompt window appears (see [Figure 7-14](#)) for you to confirm that you wish to delete the selected profile.

Figure 7-14 Deletion Prompt Window



Step 3 Click **Yes** to delete the selected profile or click **No** to close the window without deleting the profile.

Figure 7-15 Information window



When a profile is deleted it disappears from the list of existing profiles displayed in the SRP Side Profile list at the left of the window.

SRP Side Profile Window—Detailed Description

The SRP Side Profile window has two tabs namely: General, and Alarms

General Tab

The General tab displays four areas: General, SONET Overhead, IPS SONET and Create Profile.

General

The General area allows you to configure the following information:

Clock Source—Allows you to choose clock source from available options. This can either be internal (within the device) or line (the network clock).

Loopback—Allows you to select the loopback mode. It indicates the loopback mode for the SRP Side profile. The available options are: disabled, internal or line

Framing—Allows you to select sdh or sonet type framing. It indicates the framing mode of the side profile.

IPS Management Request Mode—Allows you to select the IPS management request mode for the side profile. The available options are: noRequest, forced-switch, manual-switch, waitToRestore, signalDegrade, and signalFail.

SONET Overhead

Path Signal Identifier—Allow you to set the path signal identifier. The permissible values range from 0 to 255.

Section Trace Byte—Allows you to set the section trace byte. The permissible values are from 0 to 255.



Note

If the device has pre-defined default values for the **Path Signal Identifier** and **Section Trace Byte** parameters, the same values are displayed in this area when the profile is created.

IPS SONET

Protected—Allows you to select the Protected mode. The available options are: enable and disable

SD Threshold <3-9> (in 10e-)—Allows you to select the Signal Degrade threshold value in 10e-, between 3-9

SF Threshold <3-9> (in 10e-)—Allows you to select the Signal Fail BER threshold value in 10e-, between 3-9

Create Profile

Create Profile—Choose Create Profile to create a new SRP Side profile.

Alarms Tab

The Alarms tab displays two areas: Reporting & Threshold, and Reporting

Reporting and Threshold

The Alarm Reporting & Threshold area allows you to configure the following information:

B1 BER Threshold Crossing Alarm—Allows you to enable/disable threshold limits for the system to prompt appropriate B1 BER Threshold alarm messages.

B2 BER Threshold Crossing Alarm—Allows you to enable/disable threshold limits for the system to prompt appropriate B2 BER Threshold alarm messages.

B3 BER Threshold Crossing Alarm—Allows you to enable/disable threshold limits for the system to prompt appropriate B3 BER Threshold alarm messages.

Signal Degrade BER—Allows you to enable/disable threshold limits for the system to prompt appropriate Signal Degrade BER Threshold alarm messages

Signal Fail BER—Allows you to enable/disable threshold limits for the system to prompt appropriate Signal Fail BER Threshold alarm messages

B1 Threshold <3-9> (in 10e-)—Displays B1 BER threshold value in 10e-, between 3-9

B2 Threshold <3-9> (in 10e-)—Displays B2 BER threshold value in 10e-, between 3-9

B3 Threshold <3-9> (in 10e-)—Displays B3 BER threshold value in 10e-, between 3-9

SD Threshold <3-9> (in 10e-)—Displays Signal Degrade threshold value in 10e-, between 3-9

SF Threshold <3-9> (in 10e-)—Displays Signal Fail BER threshold value in 10e-, between 3-9

Reporting

Section Loss of Frame Errors—Allows you to enable/disable the loss of frame errors alarm messages.

Section Loss of Signal Errors—Allows you to enable/disable the loss of signal errors alarm messages.

Line Alarm Indication Signal Errors—Allows you to enable/disable the line alarm indication signal errors alarm messages.

Line Remote Defect Indication Errors—Allows you to enable/disable the line remote defect indication errors alarm messages.

Path Loss of Pointer Errors—Allows you to enable/disable the path loss of pointer errors alarm messages.

Path Alarm Indication Signal Errors—Allows you to enable/disable the path alarm indication signal errors alarm messages.

Path Remote Defect Indication Errors—Allows you to enable/disable the path remote defect indication errors alarm messages.



Interface Configuration

This chapter describes how to configure or set up the interfaces associated with each line card. You can configure or set up any interface through the Interface Configuration windows associated with each line card.

This chapter contains the following information:

- [Interfaces and Related Technology-Specific Windows](#)
- [Launching the Interface Configuration Windows](#)
- [Generic Interface Configuration](#)
- [ATM Interface Configuration](#)
- [Ethernet Interface Configuration](#)
- [IP Configuration](#)
- [POS Interface Configuration](#)
- [APS Interface Configuration](#)
- [SRP Interface Configuration](#)
- [SRP Interface Side Configuration](#)

Interfaces and Related Technology-Specific Windows

Interfaces on line cards can support multiple technologies. Configuration windows are technology-specific. For example, a POS interface supports three configurable technologies: Generic, POS, and IP. Therefore, if you want to view or modify the configuration of a POS interface, you might need to view three windows:

- Generic Interface Configuration window
- POS Interface Configuration window
- IP Interface Configuration window

This same process is applicable to all different types of interfaces. [Table 8-1](#) outlines which technology-specific configuration windows apply to each interface type.

Table 8-1 Interfaces and Configuration Windows

Interfaces	Technology-Specific Configuration Windows
POS	Generic, POS and IP
ATM	Generic, ATM and IP
Ethernet	Generic, Ethernet and IP
SRP	Generic, IP and SRP
SRP Side	SRP Side

**Note**

Layer 3 QoS configuration, which includes CAR and WRED, is applicable to all types of interfaces on the 12000 Series Router chassis. This is not applicable to the Cisco 10720 Router chassis. For details on CAR and WRED configuration windows, see [Chapter 11, “Layer 3 QoS.”](#)

Launching the Interface Configuration Windows

[Table 8-2](#) displays the Interface Configuration windows that can be launched from each object type. For example, the ATM Interface Configuration window can be launched from a Site, Chassis, Module, or ATM Interface object.

**Note**

[Table 8-2](#) lists the menu options to launch the interface configuration dialogs from the site level.

**Note**

Commissioning/decommissioning an interface is only available from the Generic Interface Configuration window. Refer the [“Configuring and Commissioning a Generic Interface” section on page 8-4.](#)

Table 8-2 Launching the Interface Configuration Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
Generic Interface Configuration	Yes	Yes	Yes	Yes	All interfaces	Cisco 12000/10720 Manager>Configuration>Interface>Generic> Configuration
ATM Interface Configuration	Yes	Yes	No	Yes	ATM	Cisco 12000/10720 Manager>Configuration>Interface> ATM> Configuration
Ethernet Interface Configuration	Yes	Yes	Yes	Yes	Ethernet	Cisco 12000/10720 Manager>Configuration >Interface>Ethernet>Configuration
IP Configuration	Yes	Yes	Yes	Yes	All interfaces	Cisco 12000/10720 Manager>Configuration>Interface>IP>Configuration
POS Interface Configuration	Yes	Yes	Yes	Yes	POS	Cisco 12000/10720 Manager>Configuration>Interface>POS>Configuration

Table 8-2 Launching the Interface Configuration Windows (continued)

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
APS Interface Configuration	Yes	Yes	Yes	Yes	POS	Cisco 12000/10720 Manager>Interface>POS>APS Configuration
SRP Interface Configuration	Yes	Yes	Yes	Yes	SRP	Cisco 12000/10720 Manager>Configuration>Interface>SRP>Configuration
SRP Interface Side Configuration	Yes	Yes	Yes	Yes	SRP and SRP Side	Cisco 12000/10720 Manager>Configuration>Interface>SRP>Side>Configuration

**Note**

The Interface Configuration windows cannot be opened when multiple objects are selected (the menu options to open the Interface Configuration windows are grayed out). Available menu options can be launched from a site object containing the required objects, when needed.

Generic Interface Configuration

The Generic Interface Configuration window allows you to carry out part of the configuration on a selected interface. The Generic Interface Configuration window allows you to commission or decommission a selected interface.

**Note**

Commissioning/decommissioning an interface is only available from the Generic Interface Configuration window.

The Generic Interface Configuration section covers the following areas:


- [Viewing the Generic Interface Configuration Window](#)
- [Configuring and Commissioning a Generic Interface](#)
- [Decommissioning an Interface](#)
- [Generic Interface Configuration Window—Detailed Description](#)

Viewing the Generic Interface Configuration Window

To view the Interface Configuration window, proceed as follows:

- Step 1** Right click on the interface object and select the **Cisco 12000/10720 Manager>Configuration>Generic>Configuration** option. See [Table 8-1 on page 8-2](#) for information on which objects allow you to launch the Interface Configuration window. The Interface Configuration window appears with the Configuration tab displayed.

Figure 8-1 Interface Configuration Window—Configuration Tab



- Step 2** Choose a **Chassis**, **Module** and **Interface** from the list boxes displayed at the left of the window.

Configuring and Commissioning a Generic Interface



Note

Commissioning/decommissioning an interface is only available from the Generic Interface Configuration window.

To configure and commission a selected interface, follow these steps:

-
- Step 1** Open the Generic Interface Configuration window. See [“Viewing the Generic Interface Configuration Window” section on page 8-4](#) for further details.
 - Step 2** Choose a **Chassis**, **Module** and **Interface** from the lists displayed at the left of the window.
 - Step 3** Configure the parameters displayed in the Configuration tab, as required.
 - Step 4** Click **Commission** when the status is Decommissioned. The status of the selected interface appears at the bottom left-hand-corner of the window. The interface is now commissioned and its state changes to **Commissioning** and then to **Normal** or **Errored** state depending on whether the interface is active or not.
 - Step 5** Click **Save** to save any changes.



Note You have now commissioned the selected interface. You should now proceed to the appropriate interface configuration window section in this chapter to configure specific interface attributes. For example, the ATM Interface Configuration window allows you to configure ATM specific attributes for a selected ATM interface.

Decommissioning an Interface

To decommission an interface, follow these steps:

-
- Step 1** Open the Generic Interface Configuration window. See [“Viewing the Generic Interface Configuration Window” section on page 8-4](#) for further details.
 - Step 2** Choose a **Chassis**, **Module** and **Interface** from the lists displayed at the left of the window.
 - Step 3** Click **Decommission**. The status of the selected interface appears at the bottom left-hand-corner of the window. The interface is now decommissioned and its state changes to **Decommissioned**.
 - Step 4** Click **Save** to save any changes.
-

Generic Interface Configuration Window—Detailed Description

The Interface Configuration window contains a single Configuration tab.

Configuration Tab

The Configuration tab (see [Figure 8-1 on page 8-4](#)) contains two areas: Configurable Parameters, and Actions.

Configurable Parameters

The Configurable Parameters area contains the following fields:

Alias—Name for the interface, as specified by the network manager.

Administration Status—Allows you to enable or disable the interface.

Link Up/Down Trap Enable—Allows you to choose whether link up/down traps should be generated for this interface.

Supplementary Information—Any additional information.

Actions

The Actions area allows you to commission or decommission a selected interface.

Commission—Click **Commission** to commission the selected interface.

Decommission—Click **Decommission** to decommission the selected interface.

ATM Interface Configuration

The ATM Interface Configuration window allows you to configure a selected ATM interface. The ATM Interface Configuration section covers the following areas:

- [Viewing the ATM Interface Configuration Window](#)
- [Configuring an ATM Interface](#)
- [ATM Interface Configuration Window—Detailed Description](#)



Note

The ATM Interface Configuration dialog is not supported by the Cisco 10720 Series Router, as it does not support the ATM interfaces.


Viewing the ATM Interface Configuration Window

To view the ATM Interface Configuration window, proceed as follows these steps:

-
- Step 1** Right-click on a selected ATM interface, then choose **Cisco 12000/10720 Manager> Configuration>ATM>Configuration**.

The ATM Interface Configuration window appears:

Figure 8-2 ATM Interface Configuration Window—Configuration 1 Tab



Not applicable to Cisco 12000/10720 Router Manager

- Step 2** Choose a **Chassis**, **Module**, and **ATM Interface** from the lists displayed at the left of the window.

Configuring an ATM Interface

To configure an ATM Interface, follow these steps:

- Step 1** Open the ATM Interface Configuration window. See [“Viewing the ATM Interface Configuration Window”](#) section on page 8-6 for further details.
- Step 2** Choose a **Chassis**, **Module**, and **ATM Interface** from the lists displayed at the left of the window.

- Step 3 Choose **Edit > Apply Profile** and then choose the profile you wish to apply from the list displayed (if you are applying a profile). When a profile is applied, the attributes applied from the profile appear in blue.
 - Step 4 Edit the parameters displayed in the Configuration (1) tab, as required. See [“ATM Interface Configuration Window—Detailed Description” section on page 8-8](#) for further details.
 - Step 5 Click **Save** to save your configuration changes.
 - Step 6 Choose **File > Close** to close the window.
-

ATM Interface Configuration Window—Detailed Description

The ATM Interface Configuration window contains two tabs: Configuration (1) and Configuration (2).

Configuration (1) Tab

The Configuration (1) tab (see [Figure 8-2](#)) contains two areas: ATM Configuration, and ILMI Configuration.

ATM Configuration

The ATM Configuration area contains the following fields:

Neighbor IP Address—Not applicable to Cisco 12000/10720 Router Manager.

Neighbor Interface Name—Not applicable to Cisco 12000/10720 Router Manager.

Interface Type—Not applicable to Cisco 12000/10720 Router Manager.

UNI Type—Not applicable to Cisco 12000/10720 Router Manager.

ATM Interface Side—Not applicable to Cisco 12000/10720 Router Manager.

UNI Signalling Version—Version of UNI signalling that is currently being used on the interface. The appropriate value, either atmUni3Dot0, atmUni3Dot1, or atmUni4Dot0, is used when the interface is an UNI or IISP interface. The value “not applicable” is used when the interface is a PNNI interface or when signalling is disabled. Setting this variable to a value of not applicable is not allowed. To modify this field, the interface admin status has to be down and the interface Ilmi auto configuration disabled.

SVC UPC Intent—Not applicable to Cisco 12000/10720 Router Manager.

Signalling Admin Status—Not applicable to Cisco 12000/10720 Router Manager.

Well-known VC Mode—Not applicable to Cisco 12000/10720 Router Manager.

Loopback—The following options are available:

- Line—Packets are transmitted back to the source to test the interface functionality and ensure that packets transmitted through the interface reach the destination without data loss.

- No loopback—Restricts connection status (success or failure) messages from being received.

- Diagnostic—Transmit data stream is looped to the transmit direction.

Transmit Queue Limit—Not applicable to Cisco 12000/10720 Router Manager.

Maximum VPCs—Not applicable to Cisco 12000/10720 Router Manager.

Maximum Active VPI Bits—Not applicable to Cisco 12000/10720 Router Manager.

Maximum VCCs—Maximum number of VCCs (PVCs and SVCs) supported at this interface.

Maximum Active VCI Bits—Not applicable to Cisco 12000/10720 Router Manager.

Number of VCs per VP—Set the number of virtual channels per virtual path.

Clock Source—Source of the clock.

NSAP (Network Service Access Point) Address—Specify the NSAP address.

ILMI Configuration

The ILMI Configuration area contains the following fields:

Keepalive Time—Amount of time that should elapse between successive ILMI keepalive messages are sent on this interface. A value of 0 disables ILMI keepalive messages on this interface.

Auto-Configuration—Enable or disable the ILMI link and interface type determination. The configuration takes effect only on the next interface restart.

Address Registration—Enable or disable ILMI address registration on this interface. The configuration takes effect only on the next interface restart.

Configuration—Enable or disable ILMI configuration on this interface. The configuration takes effect only on the next interface restart. Disabling this object will also disable address registration, auto-configuration, and keepalive time.

Configuration (2) Tab

The Configuration (2) tab displays three areas: Information Element Transfer, Physical layer and DS1/E1/DS3/E3.

Information Element Layer

Not applicable to Cisco 12000/10720 Router Manager.

Physical Layer

Not applicable to Cisco 12000/10720 Router Manager.

DS1/E1/DS3/E3

Line Buildout—Not applicable to Cisco 12000/10720 Router Manager.

Framing Mode—The framing format present on the physical interface.

Ethernet Interface Configuration

The Ethernet Interface Configuration window allows you to configure Ethernet fields, such as loopback, and keepalive period.

The Ethernet Interface Configuration section covers the following areas:


- [Viewing the Ethernet Interface Configuration Window](#)
- [Configuring an Ethernet Interface](#)
- [Ethernet Interface Configuration Window—Detailed Description](#)

Viewing the Ethernet Interface Configuration Window

To view the Ethernet Interface Configuration window, proceed as follows:

- Step 1** Right-click on a selected Ethernet line card or an Ethernet interface, then choose **Cisco 12000/10720 Manager>Configuration>Ethernet>Configuration**. The Ethernet Interface Configuration window appears:

Figure 8-3 Ethernet Interface Configuration Window—Configuration Tab




- Step 2** Choose a **Chassis**, **Module**, and **Ethernet Interface** from the lists displayed at the left of the window.

Configuring an Ethernet Interface

To configure an Ethernet Interface, follow these steps:

- Step 1 Open the Ethernet Interface Configuration window. See [“Viewing the Ethernet Interface Configuration Window” section on page 8-10](#) for further details.
- Step 2 Choose a Chassis, Module, and Ethernet Interface from the lists displayed at the left of the window.
- Step 3 Edit the parameters displayed in the Configuration tab, as required. See [“Ethernet Interface Configuration Window—Detailed Description” section on page 8-12](#) for further details.
- Step 4 Choose the HSRP Parameters tab.
- Step 5 Choose **Edit > Apply Profile** and then select the profile you wish to apply from the list displayed (if you are applying a profile). When a profile is applied, the attributes applied from the profile appear in blue.

Figure 8-4 Ethernet Interface Configuration Window—HSRP Parameters Tab



84941

- Step 6** Configure the fields in the HSRP Parameters tab, as required. For further information on the fields displayed in this window, see [“Ethernet Interface Configuration Window—Detailed Description” section on page 8-12](#).
- Step 7** Click **Save** to save your configuration changes.
- Step 8** Choose **File > Close** to close the window.
-

Ethernet Interface Configuration Window—Detailed Description

The Ethernet Interface Configuration window displays two tabs: Configuration and HSRP Parameters.

Configuration Tab

The Configuration tab (see [Figure 8-3 on page 8-10](#)) contains a single General area.

General

The General area displays the following fields:

Loopback—The following options are available:

Internal—No cable is needed to connect the input and output ports. The data is looped back within the device itself. Applicable only for Gigabit and Fast Ethernet interfaces.

External—Input and output ports are physically connected by a cable to simulate a loopback. When data is transmitted, it travels through the output port and enters the device through the input port. Applicable only for Gigabit and Fast Ethernet interfaces.

Enabled—Packets are transmitted back to the source to test the interface functionality and ensure that packets transmitted through the interface reach the destination. Applicable only for GRP Ethernet interfaces.



Caution

When the loopback for the Ethernet interface in the GRP is enabled, the Ethernet communication link to the Cisco 12000 Series Router will be lost.



Note

If the communication link to the Cisco 12000 Series Router is lost it cannot be switched on again from Cisco EMF, and access to the Cisco 12000 Series Router is required before the link can be re-enabled.

Disabled—Disables switches loopback off for GRP, Fast and Gigabit Ethernet interfaces.

Keepalive Period—Displays set the keepalive period. The system sends packets after this interval to know if the interface or the network is up for routing packets. By default this interval is 10 seconds.

HSRP Parameters Tab

The HSRP Parameters tab (see [Figure 8-4 on page 8-11](#)) displays a Configured Group Numbers field and an HSRP Parameters area.

Configured Group Numbers—List of configured HSRP group numbers.

HSRP Parameters

The HSRP Parameters area contains the following fields:

Group Number—Group number on the interface for which HSRP is being activated. The default is zero.

Standby Priority—Enable or disable the priority for the HSRP interface. Possible values are as follows:

Enabled—When the current interface fails, it automatically switches to the standby interface.

Disabled—When the current interface fails, it does not switch to a standby interface.

Standby Authentication—Enable or disable the standby authentication string. Options available are:

Enabled—Checks for an authentication string set and allows you to configure the interface on presence of the set string.

Disabled—Does not check for an authentication string.

Standby Hello Time—(in seconds) Can be an integer from 1 to 255. The default is 3 seconds.

Standby Preempt—Standby router waits for the set time and takes over as active router if the current router fails or does not respond to the packets sent.

IP Address—IP address of the hot standby router interface.

Priority—Priority value that prioritizes a potential hot standby router. The range is 1 to 255; the default is 100.

Authentication String—Serves as a check to avoid any damage to the interface. It can be up to eight characters in length.

Standby Hold Time—The time in seconds before the active or standby router is declared to be down. This is an integer from 1 to 255. The default is 10 seconds.

IP Configuration

The IP Configuration window allows you to configure generic IP fields (for example, IP address, and interface state).

The IP Configuration section covers the following areas:


- [Viewing the IP Configuration Window](#)
- [Configuring an IP Interface](#)
- [IP Configuration Window—Detailed Description](#)

Viewing the IP Configuration Window

To view the IP Configuration window, proceed as follows:

- Step 1** Right-click a selected IP line card or IP interface, then choose **Cisco 12000/10720 Manager> Configuration>IP>Configuration**. The IP Configuration window appears, with the Generic Parameters tab displayed.

Figure 8-5 IP Configuration Window—Generic Parameters Tab



- Step 2** Choose a **Chassis**, **Module**, and **IP Interface** from the lists displayed at the left of the window.

Configuring an IP Interface

To configure an IP Interface, follow these steps:

- Step 1** Open the IP Interface Configuration window. See [“Viewing the IP Configuration Window”](#) section on page 8-14 for further details.
- Step 2** Choose a **Chassis**, **Module**, and **IP Interface** from the lists displayed at the left of the window.
- Step 3** Configure the parameters displayed in the Generic Parameters tab, as required. See [“IP Configuration Window—Detailed Description”](#) section on page 8-15 for further details.

- Step 4** Click **Save** to save your configuration changes.
- Step 5** Choose **File > Close** to close the window.
-

IP Configuration Window—Detailed Description

The IP Configuration window (see [Figure 8-1](#)) contains one tab: Generic Parameters

Generic Parameters Tab

The Generic Parameters tab contains a single Generic Parameters area.

Generic Parameters

The Generic Parameters area contains the following fields:

IP Address—IP address for the selected interface.

Subnet Mask—Address mask for the selected interface.

Maximum Transmission Unit—Maximum packet size, in bytes, that the selected interface can handle.

IP Maximum Transmission Unit—Maximum packet size, in bytes, that the selected IP interface can handle.

Interface State—Choose the interface state to be used from the drop down list.

Cisco Discovery Protocol (CDP)—Enable or disable CDP on the interface. CDP allows a device to advertise its existence to other devices and receive information about other devices on the same LAN or on the remote side of a WAN.

IP Multicast Fast Switching—Enable or disable IP Multicast Fast Switching on the interface.

POS Interface Configuration

The POS Interface Configuration window allows you to configure a selected POS Interface.

The POS Interface Configuration section covers the following areas:


- [Viewing the POS Interface Configuration Window](#)
- [Configuring a POS Interface](#)
- [POS Interface Configuration Window—Detailed Description](#)

Viewing the POS Interface Configuration Window

To view the POS Interface Configuration window, proceed as follows:

- Step 1** Right-click on a selected POS line card or POS interface, then choose **Cisco 12000/10720 Manager>Configuration>POS>Configuration**. The POS Interface Configuration window appears.
-

Figure 8-6 POS Interface Configuration Window—POS Config Tab



- Step 2 Choose a **Chassis**, **Module**, and **POS Interface** from the lists displayed at the left of the window.

Configuring a POS Interface

To configure a POS Interface, follow these steps:

- Step 1 Open the POS Interface Configuration window. See [“Viewing the POS Interface Configuration Window” section on page 8-15](#) for further details.
- Step 2 Choose a Chassis, Module, and POS Interface from the lists displayed at the left of the window.
- Step 3 Choose **Edit > Apply Profile** and then choose the profile you wish to apply from the list displayed (if you are applying a profile). When a profile is applied, the attributes applied from the profile appear in blue.
- Step 4 Configure the parameters displayed in the POS Config tab, as required. See [“POS Interface Configuration Window—Detailed Description” section on page 8-17](#) for further details.
- Step 5 Click **Save** to save your configuration changes.
- Step 6 Choose **File > Close** to close the window.

POS Interface Configuration Window—Detailed Description

The POS Interface Configuration window contains one tab, POS Config.

POS Config Tab

The POS Config tab (see [Figure 8-6](#)) contains four areas: General, SONET Overhead, Alarm Reporting and Threshold, and Alarm Reporting.

General

The General area contains the following fields:

POS SPE Scrambling—Enable or disable POS SPE scrambling. Scrambling is similar to encrypting. The enabled option is selected by default.

Loopback—Choose the loopback mode. The following options are available:

Internal—Packets are transmitted back to the source to test the interface functionality and ensure that packets transmitted through the interface reach the destination without data loss.

Line—Restricts connection status (success or failure) messages from being received.

Disabled—Disables the loopback mode.

Clock Source—Choose a clock source from the available options. There is a clock in every device, which measures the speed of the device. This can either be **Internal** (within the device) or **Line** (network clock).

Keepalive—Set keepalive period. The system sends packets after this interval to know if the interface or the network is up for routing packets. By default this interval is 10 seconds.

POS Framing—Choose the type of POS framing, SDH or SONET.

Encapsulation—Select HDLC, PPP or FRAME-RELAY encapsulation type.

Cyclic Redundancy Check—Choose an option for cyclic redundancy check. Cyclic redundancy checks consists of 16 or 32 bit verification code which has to be same at both the transmitting and receiving ends to ensure the packets sent are received in full without loss of data. By default, it is 32 bit code.

SONET Overhead

The Sonet Overhead area contains the following fields:

Path Signal Identifier—Permissible values range from 0 to 255.

Section Trace Byte—Permissible values range from 0 to 255.

Payload Pointer Byte—Choose an option for payload pointer byte from the drop down menu. Permissible values range from 0 to 3.

Alarm Reporting & Threshold

The Alarm Reporting & Threshold area allows you to configure and enable alarms generated by the system. This area contains the following fields:

B1 BER Threshold Crossing Alarm (TCA)—Set threshold limits for the system to prompt appropriate B1 BER TCA threshold alarm messages. The field beside this value displays the threshold for the B1 BER TCA.

B2 BER Threshold Crossing Alarm (TCA)—Set threshold limits for the system to prompt appropriate B2 BER TCA threshold alarm messages. The field beside this value displays the threshold for the B2 BER TCA.

B3 BER Threshold Crossing Alarm (TCA)—Set threshold limits for the system to prompt appropriate B3 BER TCA threshold alarm messages. The field beside this value displays the threshold for the B3 BER TCA.

Signal Degrade BER—Set threshold limits for the system to prompt appropriate signal degrade BER threshold alarm messages. The field beside this value displays the threshold for the signal degrade BER.

Signal Fail BER—Set threshold limits for the system to prompt appropriate signal fail BER threshold alarm messages. The field beside this value displays the threshold for the signal fail BER.

Alarm Reporting

The Alarm Reporting area contains the following fields:

Path Remote Defect Indication Errors—Enable or disable the path remote defect indication errors alarm messages.

Line Remote Defect Indication Errors—Enable or disable the line remote defect indication errors alarm messages.

Line Alarm Indication Signal Errors—Enable or disable the line alarm indication signal errors alarm messages.

Receive Data Out of Lock Errors—Enable or disable the Receive data output of lock errors alarm messages.

Path Alarm Indication Signal Errors—Enable or disable the path alarm indication signal errors alarm messages.

Section Loss of Signal Errors—Enable or disable the section loss of signal errors alarm messages.

LAIS on Interface Shutdown—Enable or disable the LAIS on interface shutdown alarm messages.

Section Loss of Frame Errors—Enable or disable the section loss of frame errors alarm messages.

Path Loss of Pointer Errors—Enable or disable the path loss of pointer errors alarm messages.

APS Interface Configuration

The APS Interface Configuration window allows you to configure APS for a POS Interface. APS Configuration allows you to configure APS (Automatic Protection Switching)



Note

It is recommended that only a system administrator have access to the APS Configuration window.

The APS Interface Configuration section covers the following areas:


- [Viewing the APS Configuration Window](#)
- [APS Configuration Window—Detailed Description](#)

Viewing the APS Configuration Window

To view the APS Configuration window, proceed as follows:

- Step 1** Right-click on a selected POS line card or POS interface, then choose **Cisco 12000/10720 Manager>Configuration>POS>APS Configuration**. The APS Configuration window appears:

Figure 8-7 APS Configuration Window—APS Tab



- Step 2** Choose a **Chassis**, **Module**, and **POS Interface** from the lists displayed at the left of the window.

The APS Configuration window allows you to:

- Add a working interface
- Remove a working interface
- Add a protected interface
- Remove a protected interface



Note A working and a protected interface cannot be configured at the same time.

Adding a Working Interface

To add a working interface, proceed as follows:

-
- Step 1 Choose a **Chassis, Module, and POS Interface** from the list boxes at the left of the window.
 - Step 2 Click **Working**.
 - Step 3 Enter appropriate text in the Authentication and Group fields (for details on these fields, see [“APS Configuration Window—Detailed Description”](#) section on page 8-21).
 - Step 4 Click **Save**.
-

Removing a Working Interface

To remove a working interface, proceed as follows:

-
- Step 1 Choose a **Chassis, Module, and POS Interface** from the list boxes displayed at the left of the window.
 - Step 2 The **Working** button for the selected interface should already be selected. Click **Working** to deactivate.
 - Step 3 Click **Save**.
-

Adding a Protected Interface

To add a protected interface, proceed as follows:

-
- Step 1 Choose a **Chassis, Module, and POS Interface** from the list boxes displayed at the left of the window.
 - Step 2 Click **Protect**.
 - Step 3 Enter appropriate text in all fields (for details on these fields, see [“APS Configuration Window—Detailed Description”](#) section on page 8-21).
 - Step 4 Click **Save**.
-

Removing a Protected Interface

To remove a protected interface, proceed as follows:

-
- Step 1 Choose a **Chassis, Module, and POS Interface** from the list boxes displayed at the left of the window.
 - Step 2 The **Protect** button for the selected interface should already be selected. Click **Protect** to deactivate.
 - Step 3 Click **Save**.
-

APS Configuration Window—Detailed Description

The APS Configuration window displays a single APS tab.

APS Tab

The APS tab (see [Figure 8-7 on page 8-19](#)) displays a single APS Interface area.

APS Interface

The APS Interface area contains the following buttons and fields:

Working—Select this button to establish a working interface.

Protect—Select this button to establish a protected interface.

Group—Represents the group association of the interfaces. The value of Group ranges from 0 to 255.

Authentication—Allows you to set values, which serve as check on entry of packets (information) sent over the network. This shields the system from any damage on account of data download.

Hello Time—Set time for the working interface to report on its status to the protected interface. The interface is bidirectional by default.

Hold Time—Set the time for protected interface (standby system) to wait for the working interface to communicate on its status. On expiry of time set, the protected interface takes over as the working or the active interface.

Revert Mode—Choose “Revertive” to enable automatic switch-over from the protected interface to the working interface after the working interface becomes available.

Direction Mode—Choose the interface direction mode. Options available are:

Unidirectional—Packets are received and transmitted independently.

Bidirectional—Packets are transmitted and received in pairs.

Authentication String—Specifies a string which must be present to accept any packet on the OOB (Out Of Band) communication channel.

Interconnect IP Address—IP Address of the router that contains the working interface.

Lockout—Set the value to yes or no. Yes prevents the working interface from switching to the protected interface.

Revert Time—Set the revert time, the system reverting automatically to the working interface from protected interface (standby system) once the working interface is online.

Switch to Circuit—Set the value for the circuit to switch to protected interface when working interface fails. The options are: manual, force, or none.

SRP Interface Configuration

The SRP Interface Configuration window allows you to configure a selected SRP Interface. The SRP Interface Configuration section covers the following areas:


- [Viewing the SRP Interface Configuration Attributes](#)
- [Configuring a SRP Interface](#)
- [SRP Interface Configuration Window—Detailed Description](#)

Viewing the SRP Interface Configuration Attributes

To view the attributes in the SRP Interface Configuration window, proceed as follows:

- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>SRP>Configuration** option from a SRP interface object to launch the SRP Configuration window. Refer to [Table 8-2 on page 8-2](#) for information on which objects allow you to launch the SRP Interface Configuration window.

Figure 8-8 SRP Interface Configuration Window



- Step 2** Choose a **Chassis, Module, and SRP Interface** from the lists displayed at the left side of the window to view the configuration details of the SRP interface.

Configuring a SRP Interface

To configure a SRP Interface, proceed as follows:

-
- Step 1** Launch the SRP Interface Configuration window. Refer to [Table 8-2 on page 8-2](#) for information on which objects allow you to launch the SRP Interface Configuration window.
 - Step 2** Choose a **Chassis**, **Module**, and **SRP Interface** from the lists displayed at the left side of the window.
 - Step 3** Edit the parameters displayed in the SRP Interface Configuration window, as required. See “[SRP Interface Configuration Window—Detailed Description](#)” section for further details.
 - Step 4** Click **Save** to save your configuration changes.
-

SRP Interface Configuration Window—Detailed Description

The SRP Interface Configuration window contains two areas: General and IPS

General

Topology Timer—Allows you to configure the time (in seconds) that determines the interval for sending the topology discovery packets to the ring

Priority Threshold—Allows you to configure the incoming packet priority limit

Tx Traffic Rate – High—Allows you to configure the high rate limit of outgoing traffic, in megabits per second

Tx Traffic Rate – Low—Allows you to configure the low rate limit of outgoing traffic, in megabits per second



Note

The **Priority Threshold**, **Tx Traffic Rate – High**, **Tx Traffic Rate – Low** parameters are applicable only to OC-48 SRP Interfaces.

IPS

IPS Lock—Allows you to configure the boolean flag (true or false) to indicate node LockedOut of protection state.

IPS Timer—Allows you to configure the frequency at which the IPS messages are to be displayed, in seconds.

IPS Wait To Restore Timer—Allows you to configure the time interval in seconds, for an interface to remain in the wrap state, after the cause of a wrap is removed.

SRP Interface Side Configuration

The SRP Side Configuration window allows you to configure a selected SRP Side. The SRP Side Configuration section covers the following areas:


- [Viewing the SRP Interface Side Configuration Attributes](#)
- [Configuring a SRP Side](#)
- [SRP Interface Side Configuration Window—Detailed Description](#)

Viewing the SRP Interface Side Configuration Attributes

To view the SRP Side Configuration window, proceed as follows:

- Step 1** Choose the **Cisco 12000/10720 Manager>Configuration>SRP>Side>Configuration** option from a SRP Side object icon to launch the SRP Side Configuration window. Refer to [Table 8-2 on page 8-2](#) for information on which objects allow you to launch the SRP Interface Side Configuration window.


Figure 8-9 SRP Interface Side Configuration Window



- Step 2** Choose a **Chassis, Module, SRP Interface** and **SRP Side** from the lists displayed at the left of the window to view the configuration details of the SRP Side.

Step 3 Click on the Alarms tab, if required.

Figure 8-10 SRP Side Configuration window—Alarms tab



Configuring a SRP Side

To configure a SRP Side, proceed as follows:

- Step 1** Launch the SRP Interface Side Configuration window. Refer to [Table 8-2 on page 8-2](#) for information on which objects allow you to launch the SRP Interface Side Configuration window.
- Step 2** Choose a **Chassis**, **Module**, **SRP Interface** and **SRP Side** from the lists displayed at the left side of the window.
- Step 3** Edit the parameters displayed in the General and Alarm tabs, as required. See “[SRP Interface Side Configuration Window—Detailed Description](#)” section for further details.
- Step 4** Click **Save** to save your configuration changes.

SRP Interface Side Configuration Window—Detailed Description

The SRP Interface Side Configuration window has two tabs namely: General, and Alarms

General Tab

The General tab displays three areas: General, SONET Overhead and IPS SONET.

General

The General area allows you to configure the following information:

Clock Source—Allows you to configure the clock source from available options. This can either be internal (within the device) or Line (the network clock).

Loopback—Allows you to configure the loopback mode. It indicates the loopback mode for the SRP Side. The available options are: Disabled, Internal or Line

Framing—Allows you to configure SDH or SONET type framing. It indicates the framing mode of the side.

IPS Management Request Mode—Allows you to configure the IPS management request mode for the side. The available options are: noRequest, forced-switch, manual-switch, waitToRestore, signalDegrade, and signalFail.



Note

The waitToRestore, signalDegrade and SignalFail modes cannot be set for the Interface, however the user can view the values as they are read-only values.

SONET Overhead

Path Signal Identifier—Allow you to configure the path signal identifier. The permissible values range from 0 to 255.

Section Trace Byte—Allows you to configure the section trace byte. The permissible values are 0 to 255.



Note

If the device has pre-defined default values for the **Path Signal Identifier** and **Section Trace Byte** parameters, the same values are displayed in this area when the window is opened.

IPS SONET

Protected—Allows you to configure the Protected mode. The available options are: enable and disable

SD Threshold <3-9> (in 10e-)—Allows you to select the Signal Degrade threshold value in 10e-, between 3-9

SF Threshold <3-9> (in 10e-)—Allows you to select the Signal Fail BER threshold value in 10e-, between 3-9

Alarms Tab

The Alarms tab displays two areas: Reporting & Threshold, and Reporting

Reporting and Threshold

The Reporting & Threshold area allows you to configure the following information:

B1 BER Threshold Crossing Alarm—Allows you to enable/disable threshold limits for the system to prompt appropriate B1 BER Threshold alarm messages.

B2 BER Threshold Crossing Alarm—Allows you to enable/disable threshold limits for the system to prompt appropriate B2 BER Threshold alarm messages.

B3 BER Threshold Crossing Alarm—Allows you to enable/disable threshold limits for the system to prompt appropriate B3 BER Threshold alarm messages.

Signal Degrade BER—Allows you to enable/disable threshold limits for the system to prompt appropriate Signal Degrade BER Threshold alarm messages

Signal Fail BER—Allows you to enable/disable threshold limits for the system to prompt appropriate Signal Fail BER Threshold alarm messages

B1 Threshold <3-9> (in 10e-)—Displays B1 BER threshold value in 10e-, between 3-9

B2 Threshold <3-9> (in 10e-)—Displays B2 BER threshold value in 10e-, between 3-9

B3 Threshold <3-9> (in 10e-)—Displays B3 BER threshold value in 10e-, between 3-9

SD Threshold <3-9> (in 10e-)—Displays Signal Degrade threshold value in 10e-, between 3-9

SF Threshold <3-9> (in 10e-)—Displays Signal Fail BER threshold value in 10e-, between 3-9

Reporting

Section Loss of Frame Errors—Allows you to enable/disable the loss of frame errors alarm messages.

Section Loss of Signal Errors—Allows you to enable/disable the loss of signal errors alarm messages.

Line Alarm Indication Signal Errors—Allows you to enable/disable the line alarm indication signal errors alarm messages.

Line Remote Defect Indication Errors—Allows you to enable/disable the line remote defect indication errors alarm messages.

Path Loss of Pointer Errors—Allows you to enable/disable the path loss of pointer errors alarm messages.

Path Alarm Indication Signal Errors—Allows you to enable/disable the path alarm indication signal errors alarm messages.

Path Remote Defect Indication Errors—Allows you to enable/disable the path remote defect indication errors alarm messages.



Interface Status

This chapter describes how to view status information for each of the interfaces on the Cisco device being managed using the Cisco 12000/10720 Router Manager application.

This chapter contains the following information:

- [Interfaces and Related Technology-Specific Windows](#)
- [Launching the Interface Status Windows](#)
- [Generic Interface Status](#)
- [ATM Interface Status](#)
- [ATM Interface Faults](#)
- [DS3/E3 Interface Status](#)
- [SONET Interface Status](#)
- [SRP Interface Status](#)
- [SRP Side IPS Status](#)
- [SRP Topology Map](#)

Interfaces and Related Technology-Specific Windows

Interfaces on line cards can support multiple technologies. Status windows are technology-specific. For example, a DS-3 interface supports two technologies: Generic and DS-3. Therefore, if you wish to view the status of a DS-3 interface, you must view two windows: the Generic Interface Status window and the DS-3 Interface Status window.

This process is also applicable to ATM, Ethernet, POS or SRP interfaces. The following table outlines which technology-specific status windows apply to each interface type.

Table 9-1 *Interface Types and Status Windows*

Interface Type	Technology-Specific Status Window
DS-3	Generic and DS-3
ATM	Generic, ATM and SONET
Ethernet	Generic
POS	Generic and SONET

Table 9-1 Interface Types and Status Windows (continued)

Interface Type	Technology-Specific Status Window
SRP	Generic, SRP and SRP Side
SRP Side	SRP Side and SONET

Launching the Interface Status Windows

Table 9-2 displays the Interface Status windows that can be launched from each object type. For example, the Generic Interface Status window can be launched from a Site, Chassis, Module, or Generic Interface object only.



Note Table 9-2 lists the menu options to launch the interface status dialogs from the site level.

Table 9-2 Launching the Interface Status Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
Generic Interface Status	Yes	Yes	Yes	Yes	All interfaces	Cisco 12000/10720 Manager>Fault>Interface>Generic>Status
ATM Interface Status	Yes	Yes	No	Yes	ATM Interface	Cisco 12000/10720 Manager>Fault>Interface>ATM>Status
ATM Interface Faults	Yes	Yes	No	Yes	ATM interface	Cisco 12000/10720 Manager>Fault>Interface>ATM>Fault
DS3/E3 Interface Status	Yes	Yes	No	Yes	DS3 and ATM Interface	Cisco 12000/10720 Manager>Fault>Interface>DS3>Status
SONET Interface Status	Yes	Yes	Yes	Yes	SRP and POS Interface	Cisco 12000/10720 Manager>Fault>Interface>SONET>Status
SRP Interface Status	Yes	Yes	Yes	Yes	SRP Interface	Cisco 12000/10720 Manager>Fault>Interface>SRP>Status
SRP Side IPS Status	Yes	Yes	Yes	Yes	SRP and SRP Side Interface	Cisco 12000/10720 Manager>Fault>Interface>SRP>Side>IPS Status
SRP Topology Map	Yes	Yes	Yes	No	SRP Interface only	Cisco 12000/10720 Manager>Fault>Interface>SRP>Topology



Note The Status windows cannot be opened when multiple objects are selected (the menu options to open the Status windows are grayed out). Available menu options can be launched from a site object containing the required objects, when required.

Generic Interface Status

The Generic Interface Status section covers the following areas:

- [Viewing the Generic Interface Status Window](#)
- [Generic Interface Status Window—Detailed Description](#)


Viewing the Generic Interface Status Window

To view the Generic Interface Status window for any type of interface, proceed as follows:

- Step 1** Right click on the interface object and choose **Cisco 12000/10720 Manager>Fault>Interface>Generic>Status**. See [Table 9-2 on page 9-2](#) for information on which objects allow you to launch the Interface Status window.

The Interface Status window appears with the Status tab displayed:

Figure 9-1 Interface Status Window



- Step 2** Choose a **Chassis**, **Module**, and **Interface** from the lists displayed at the left of the window.

Generic Interface Status Window—Detailed Description

The Generic Interface Status tab has three areas: Interface Details, Last Change Details, and Transmission Details.

Interface Details

The Interface Details area displays the following fields:

Type—Type of interface.

Description—Information about the interface. Generally contains the interface name.

Operational Status—Current operational status of the interface. Possible values are as follows:

- Up—Ready to pass packets (if admin status is changed to up, then operational status should change to up if the interface is ready to transmit and receive network traffic)
- Down—If admin status is down, then operational status should be down
- Testing—In test mode, no operational packets can be passed
- Unknown—Status can not be determined for some reason
- Dormant—Interface is waiting for external actions
- NotPresent—Some component is missing, typically hardware
- LowerLayerDown—Down due to state of lower layer interface

Physical Address—Interface's address at its protocol sub-layer. For example, an 802.x interface normally contains a MAC address. For interfaces that do not have such an address (such as a serial line), this object should contain an octet string of zero length.

Keep Alive—Displays whether keepalives are enabled or not on this interface.

Line Protocol—Displays whether the line protocol is up or not.

Connector Present—If the interface sublayer has a physical connector, this object has the value true. Otherwise, this value will be false.

Last Change Details

The Last Change Details area displays the following fields:

Current State Duration—This value indicates the time duration since the last interface operational status was changed. This, however, is not applicable to the SRP interface side objects and the VLAN sub-interface objects.

Reason for Last Change—Reason for the interface's last status change.

Transmission Details

The Transmission Details area displays the following fields:

Speed—(in bps) Estimate of the interface's current bandwidth in bits per second.

High Speed—Estimate of the interface's current bandwidth in gigabits per second.

Maximum Transmission Unit—Size of the largest packet which can be sent or received on the interface, specified in octets.

ATM Interface Status

The ATM Interface Status section covers the following areas:

- [Viewing the ATM Interface Status Window](#)
- [ATM Interface Status Window—Detailed Description](#)



Note


The ATM Interface Status dialog is not supported by the Cisco 10720 chassis.

Viewing the ATM Interface Status Window

To view the ATM interface status window for an ATM interface, proceed as follows:

-
- Step 1** Right click on the ATM interface object and choose **Cisco 12000/10720 Manager>Fault>Interface>ATM>Status**. See [Table 9-2 on page 9-2](#) for information on which objects allow you to launch the ATM Interface Status window. The ATM Interface Status window appears with the Status tab displayed.

Figure 9-2 ATM Interface Status Window



Not applicable to Cisco 12000/10720 Router Manager

Step 2 Choose a **Chassis**, **Module**, and **ATM Interface** from the lists displayed at the left of the window.

ATM Interface Status Window—Detailed Description

The Status tab displays five areas: ATM Transmit Status, ATM Receive Status, Physical Layer Status, ATM Port Status, and Action.

ATM Transmit Status

The ATM Transmit Status area is not applicable to Cisco 12000/10720 Router Manager.

ATM Receive Status

The ATM Receive Status area is not applicable to Cisco 12000/10720 Router Manager.

Physical Layer Status

The Physical Layer Status area contains the following fields:

Physical Interface Status—Not applicable to Cisco 12000/10720 Router Manager.

Clock Source Status—Not applicable to Cisco 12000/10720 Router Manager.

Physical Port Type—Type of physical layer medium on this interface.

ATM Port Status

The ATM Port Status area contains the following fields:

Number of VPCs—Not applicable to Cisco 12000/10720 Router Manager.

Admin Address—Not applicable to Cisco 12000/10720 Router Manager.

Number of VCCs—Number of PVCs and SVCs at this interface.

ATM Address Type—Not applicable to Cisco 12000/10720 Router Manager.

Number of PVCs—Not applicable to Cisco 12000/10720 Router Manager.

NSAP (Network Service Access Point) Address—NSAP address of the interface.

Number of PVPs—Not applicable to Cisco 12000/10720 Router Manager.

Configured VP Interface—Not applicable to Cisco 12000/10720 Router Manager.

Number of PCs—Not applicable to Cisco 12000/10720 Router Manager.

SVC Minimum VCI—Not applicable to Cisco 12000/10720 Router Manager.

Number of SCs—Not applicable to Cisco 12000/10720 Router Manager.

Active SVPs—Not applicable to Cisco 12000/10720 Router Manager.

Total Connections—Not applicable to Cisco 12000/10720 Router Manager.

Active SVCs—Not applicable to Cisco 12000/10720 Router Manager.

Action

The Action area displays a single **Show Connections** button. When you choose the Show Connections button an Action report window appears displaying IOS information regarding the status of the connections on the selected interface.

ATM Interface Faults

The ATM Interface Faults section covers the following areas:


- [Viewing the ATM Interface Faults Window](#)
- [ATM Interface Faults Window—Detailed Description](#)

Viewing the ATM Interface Faults Window

To view the ATM Interface Faults window, proceed as follows:

- Step 1 Right-click on a selected ATM interface, then choose **Cisco 12000/10720 Manager>Fault>Interface>ATM>Fault**. The ATM Interface Faults window appears:

Figure 9-3 ATM Interface Faults Window



Not applicable to Cisco 12000/10720 Router Manager

- Step 2** Choose a **Chassis**, **Module**, and **ATM Interface** from the lists displayed at the left of the window. The fault information is displayed for the selected ATM interface.
-

ATM Interface Faults Window—Detailed Description

The ATM Interface Faults window displays a single Fault tab.

Fault Tab

The Fault tab (see [Figure 9-3](#)) displays three areas: General Errors, SONET Frame Errors, and DS1/E1/DS3/E3 Errors.

General Errors

The General Errors area is not applicable to Cisco 12000/10720 Router Manager.

SONET Frame Errors

The SONET Frame Errors area displays the following information:

Path FEBE Errors—Number of G1 (path FEBE) errors on the physical interface.

Line FEBE Errors—Number of Z2 (line FEBE) errors on the physical interface.

Path Parity Errors—Number of B3 (BIP) errors on the physical interface.

Line Parity Errors—Number of B2 (BIP) errors on the physical interface.

Section Parity Errors—Number of B1 (BIP) errors on the physical interface.

DS1/E1/SD3/E3 Errors

The DS1/E1/DS3/E3 Errors area is not applicable to Cisco 12000/10720 Router Manager.

DS3/E3 Interface Status

The DS3/E3 Interface Status section covers the following areas:

- [Viewing the DS3/E3 Interface Status Window](#)
- [DS3/E3 Interface Status Window—Detailed Description](#)


Viewing the DS3/E3 Interface Status Window

To view the DS3/E3 Interface Status window, proceed as follows:

- Step 1** Right click on the DS3/E3 interface object and choose **Cisco 12000/10720 Manager>Fault>Interface>DS3> Status**. See [Table 9-2 on page 9-2](#) for information on which objects allow you to launch the DS3/E3 Interface Status window.

The DS3/E3 Interface Status window appears with the Status tab displayed.

Figure 9-4 DS3/E3 Interface Status Window



Step 2 Choose a **Chassis**, **Module**, and **DS3/E3 Interface** from the lists displayed at the left of the window.

DS3/E3 Interface Status Window—Detailed Description

The DS3/E3 Interface Status window has a single Status tab.

Status Tab

The Status tab displays two areas: DS3/E3 Status, and Far End DS3/E3 Status.

DS3/E3 Status

The DS3/E3 Status area displays the following fields:

Send Code—Type of code that is being sent across the DS-3 interface by the device.

Valid Intervals—Number of previous near end intervals for which data was collected.

Time Elapsed—Number of seconds that have elapsed after the beginning of the near end current error measurement period started.

Line Coding—Zero code suppression used in this interface.

No Error—No alarms/errors are present in the interface and the traffic signal is colored green.

Loss of Signal—Presence or absence of signal loss in the line.

Loss of Frame—Presence or absence of frame loss in the line.

Loopback State—Indicates whether the received signals are looped or not.

Rx Remote Alarm Indication—Indicates whether remote alarm signal is being received or not.

Rx Alarm Indicate Signal—Indicates whether alarm signal is being received or not.

Rx Test Code—Indicates whether the line is receiving a test pattern or not.

Tx Remote Alarm Indication—Indicates whether remote alarm signal is being transmitted or not.

Tx Alarm Indicate Signal—Indicates whether alarm signal is being transmitted or not.

Far End DS3/E3 Status

The Far End DS3/E3 Status area displays the following fields:

Facility ID Code—Code that identifies a specific far end DS-3 path.

Location ID Code—Far end location identification code that describes the specific location of the equipment.

Unit Code—Far end code that identifies the equipment location within a bay.

Valid Intervals—Number of previous far end interval for which valid data was collected.

Time Elapsed—Time elapsed after the current far end measurement period started.

Equip Code—Far end equipment identification code that describes the specific piece of equipment.

SONET Interface Status

The SONET Interface Status section covers the following areas:


- [Viewing the SONET Interface Status Window](#)
- [SONET Status Window—Detailed Description](#)

Viewing the SONET Interface Status Window

To view the SONET Interface Status window, proceed as follows:


- Step 1** Right click (on a relevant object icon in the Map Viewer window or from an object pick list) and choose **Cisco 12000/10720 Manager>Fault>Interface>SONET>Status**. See [Table 9-2 on page 9-2](#) for information on which objects allow you to launch the SONET Interface Status window. The SONET Interface Status window appears with the Medium tab displayed.

Figure 9-5 SONET Interface Status—Medium Tab



- Step 2** Choose a **Chassis**, **Module**, and **SONET Interface** from the list boxes displayed at the left of the window. The details for the selected interface appear.
- Step 3** Choose the Section tab, if required (see [Figure 9-6 on page 9-13](#)).


Figure 9-6 SONET Interface Status—Section Tab



84944


Step 4 Choose the Line tab, if required (see [Figure 9-7](#)).

Figure 9-7 SONET Interface Status—Line Tab



Step 5 Choose the **Path** tab, if required (see [Figure 9-8](#)).

Figure 9-8 SONET Interface Status—Path Tab



Note The Virtual Tributary tab is not applicable to Cisco 12000/10720 Router Manager.

SONET Status Window—Detailed Description

The Sonet Status Window displays five tabs: Medium, Section, Line, Path, and Virtual Tributary (not applicable to Cisco 12000/10720 Router Manager).

Medium

The Medium tab (see [Figure 9-5 on page 9-12](#)) displays the following fields:

Type—Displays if the signal used across this interface is SONET or SDH.

Line Coding—Type of line coding used in the interface. Can be B3ZS for electrical SONET signals or NRZ for optical SONET signals.

Line Type—Line type for the interface. Can be short range single mode, long range single mode, or multi-mode for fiber interfaces; for electrical interfaces, it can be coax or UTP; and for all other line types it will be other.

Valid Intervals—Number of previous intervals for which valid data is stored.

Time Elapsed—Time elapsed (in seconds) after the start of the current error-measurement period. Includes partial seconds.

Circuit ID—Transmission vendor's circuit identifier.

Section

The Section tab (see [Figure 9-6 on page 9-13](#)) displays the following fields:

Loss of Signal—Presence or absence of signal loss in the SONET section.

Loss of Frame—Presence or absence of frame loss in the SONET section.

No Defect—Presence or absence of section defects.

Line

The Line tab (see [Figure 9-7 on page 9-14](#)) displays the following fields:

Alarm Indication Signal—Presence or absence of alarm signals in the SONET line.

Remote Defect Indication—Presence or absence of remote defects in the SONET line.

No Defect—Presence or absence of line defects.

Path

The Path tab (see [Figure 9-8 on page 9-15](#)) displays the following fields:

Signal Label Mismatch—Presence or absence of signal label mismatch in the SONET path.

STS - Alarm Indication Signal—Presence or absence of alarm signal in the SONET path.

STS - Remote Defect Indication—Presence or absence of remote defects in the SONET path.

STS - Loss of Pointer—Presence or absence of pointer loss in the SONET path.

Unequipped—Presence or absence of path equipment errors.

No Defect—Presence or absence of path defects.

Virtual Tributary

The Virtual Tributary tab is not applicable to Cisco 12000/10720 Router Manager.

SRP Interface Status

The SRP Interface Status section covers the following:


- [Viewing the SRP Interface Status Attributes](#)
- [SRP Interface Status Window—Detailed Description](#)

Viewing the SRP Interface Status Attributes

To view the SRP Interface Status window, proceed as follows:

- Step 1** Right click on the SRP interface and choose **Cisco 12000/10720 Manager>Fault>SRP>Status**. See [Table 9-2 on page 9-2](#) for information on which objects allow you to launch the SRP Interface Status window.

Figure 9-9 SRP Interface Status Window



84736

- Step 2** Choose a **Chassis, Module** and **SRP Interface** from the list boxes displayed on the left side of the window.
-

SRP Interface Status Window—Detailed Description

The SRP Interface Status window displays the Interface tab.

Interface Tab

MAC Address—Displays the node MAC address

MAC Passthrough—Displays the status of the MAC Passthrough. If set, the path for the data is available even if the node is not operational.

Total Nodes On the Ring—Displays the total number of nodes on the ring

Priority Threshold—Displays the incoming packet priority limit

IPS Wait To Restore Timer—Displays the time interval (in seconds) for the interface to remain in the wrap state, after the cause of the wrap is removed.

IPS Lock—Displays the status of the IPS lock (The status of the lock can be on or off)



Note

In case of a misconnection at a node (assuming to be the current node), if both the sides of an interface are incorrectly connected then the problem is at the current node. However, if one side of an interface is incorrectly connected then the problem is at the remote node connecting to the respective side of the interface.

Side A Frame

Wrap Status—Displays the status of the Side A Wrap. Is set to wrapped, if Side A wraps.

Misconnection—Displays true, if the Side A of the SRP Interface at the current node is connected to the Side A of the Interface at the remote host.

Optical Status—Displays the optical status of the Side A Wrap. Applicable only for Cisco 10720 chassis

Side B Frame

Wrap Status—Displays the status of the Side B Wrap. Is set to wrapped, if Side B wraps.

Misconnection—Displays true, if Side B of the Interface at the current node is connected to the Side B of the Interface at the remote host.

Optical Status—Displays the optical status of the Side B Wrap. Applicable only for Cisco 10720 chassis

SRP Side IPS Status

The Side IPS Status section covers the following:


- [Viewing the IPS Status Attributes](#)
- [IPS Status Window—Detailed Description](#)

Viewing the IPS Status Attributes

This dialog displays the Intelligent Protection Switching (IPS) status of the selected side interface. To view the IPS status window, proceed as follows:

- Step 1** Right click a SRP side interface and choose **Cisco 12000/10720 Manager>Fault>SRP>Side>IPS Status**. See [Table 9-2 on page 9-2](#) for information on which objects allow you to launch the IPS Status window.

Figure 9-10 IPS Status Window



- Step 2** Choose a **Chassis**, **Module**, **SRP Interface** and **SRP Side** from the list boxes displayed on the left side of the window.

IPS Status Window—Detailed Description

The IPS Status window displays two areas: IPS Status and Remote Node.

IPS Status

Side Wrap Status—Displays the wrap status of the Sides at the node

IPS Wrap Counter—Displays the number of transitions from unwrap to wrap state

Neighbor MAC Address—Displays the neighbor's MAC address on the ring

IPS Management Request Mode—Displays the current IPS management mode on the side

IPS Active Mode—Displays the currently active IPS mode for the local node

IPS Auto Detect Mode—Displays the current IPS mode that is automatically detected by the local node

IPS Remote Mode—Displays the IPS mode indicated in the IPS messages that are received from the other nodes on the ring

IPS Remote Type—Displays the type of the IPS Remote mode

Last Wrap Time—Displays the time (in seconds) for the last wrap

Last Unwrap Time—Displays the time (in seconds) for the last unwrap

Remote Node

Host Name—Displays the name of the remote host

IP Address—Displays the IP address of the remote host

Interface—Displays the Interface at the remote host

Connecting Side—Displays the connecting Side at the remote node

SRP Topology Map

The SRP Topology Map covers the following areas:


- [Viewing the SRP Topology Map](#)
- [SRP Topology Map—Detailed Description](#)

Viewing the SRP Topology Map

To view the SRP Topology map, proceed as follows:

-
- Step 1 Right click a SRP interface object and choose **Cisco 12000/10720 Manager>Fault>SRP>Topology**. See [Table 9-2 on page 9-2](#) for information on which objects allow you to launch the SRP Topology Map.

Figure 9-11 SRP Topology Map



- Step 2** Choose a **Chassis**, **Module** and **SRP Interface** from the list boxes displayed on the left side of the window. The topology details of the selected SRP interface appears in the table on the right side of the window.

SRP Topology Map—Detailed Description

The SRP Topology Map window displays the Topology Map area.

Topology Map

Hops—Displays either 0 or a positive integer. This value determines the number of hops the next node is away from the current node, around the ring, in the clock wise direction.

Remote Node MAC Address—Displays the 48-bit MAC address of the remote node.

Wrap Status—Displays the IPS status of the remote node.

Name—Displays the host name of the remote node.



Interface Performance

This chapter describes how to view performance information for each of the interfaces on the Cisco 12000/10720 Routers you are managing, using the Cisco 12000/10720 Router Manager application.

There are two performance options in Cisco 12000/10720 Router Manager: the Interface Performance windows and the Performance Manager application. Performance Manager displays historical data as well as current data in the form of a line chart, bar chart, or table; Interface Performance windows display only current data in a raw numerical format.



Note

See [Chapter 20, “Performance Management and Historical Data”](#) for information on viewing historical performance information for a selected chassis, module, or interface using the Performance Manager.

This chapter contains the following information:

- [Interfaces and Related Technology-Specific Windows](#)
- [Launching the Interface Performance Windows](#)
- [Generic Interface Performance](#)
- [SONET Interface Performance](#)
- [DS3/E3 Interface Performance](#)
- [Ethernet Interface Performance](#)
- [SRP Performance](#)
- [SRP Side Performance](#)

Interfaces and Related Technology-Specific Windows

Interfaces on line cards can support multiple technologies. Performance windows are technology-specific. For example, a POS interface supports two technologies: Generic and SONET.

Therefore, to view the performance of a POS interface, you need to view two windows: the Generic Interface Performance window, and the SONET Interface Performance window.

This same process is applicable to all different types of interfaces: POS, DS-3, ATM, SRP or Ethernet.

Table 10-1 details which technology-specific performance windows apply to each interface type.

Table 10-1 Interface Types and Performance Windows

Interface Type	Technology-Specific Performance Window
DS-3	Generic, and DS-3
ATM	Generic, and SONET
Ethernet	Generic, and Ethernet
POS	Generic, and SONET
SRP	Generic, SRP and SRP Side
SRP Side	Generic, and SRP Side

Launching the Interface Performance Windows

Table 10-2 displays the Interface Performance windows that can be launched from each object type. For example, the Generic Interface Performance window can be launched from a Site, Chassis, Module, or Interface object.



Note

Table 10-2 lists the menu options to launch the interface performance windows from the site level.

Table 10-2 Launching the Interface Performance Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
Generic Interface Performance	Yes	Yes	Yes	Yes	Generic	Cisco 12000/10720 Manager>Performance>Interface>Generic>Performance
SONET Interface Performance	Yes	Yes	Yes	Yes	SONET	Cisco 12000/10720 Manager>Performance>Interface>SONET>Performance
DS3/E3 Interface Performance	Yes	Yes	No	Yes	DS3	Cisco 12000/10720 Manager>Performance>Interface>DS3>Performance
Ethernet Interface Performance	Yes	Yes	Yes	Yes	Ethernet	Cisco 12000/10720 Manager>Performance>Interface>Ethernet>Performance
SRP Performance	Yes	Yes	Yes	Yes	SRP	Cisco 12000/10720 Manager>Performance>Interface>SRP>Performance
SRP Side Performance	Yes	Yes	Yes	Yes	SRP and SRP Side	Cisco 12000/10720 Manager>Performance>Interface>SRP>Side>Performance



Note

The Interface Performance windows cannot be opened when multiple objects are selected (the menu options are grayed out). Available menu options can be launched from a site object containing the required objects, when required.

Generic Interface Performance

The Generic Interface Performance section covers the following areas:


- [Viewing the Generic Interface Performance Window](#)
- [Starting Performance Logging for a Selected Interface](#)
- [Stopping Performance Logging for a Selected Interface](#)
- [Generic Interface Performance Window—Detailed Description](#)

Viewing the Generic Interface Performance Window

To view the Interface Performance window, proceed as follows:

- Step 1** Right click on the interface object and choose **Cisco 12000/10720 Manager>Performance>Generic>Performance**. See [Table 10-1 on page 10-2](#) for information on which objects allow you to launch the Interface Performance window. The Interface Performance window appears, with the Performance (1) tab displayed.

Figure 10-1 Interface Performance Window—Performance (1) Tab



84689


- Step 2** Choose a **Chassis**, **Module**, and **Interface** from the list boxes displayed at the left of the window. The interface performance information for the selected interface appears in the tabs at right.



Note Transmitted/Received Bandwidth Utilization will not be calculated and displayed until after a performance logging poll (15 minutes), and only if performance logging is active for the interface.

- Step 3** Choose **Performance(2)** tab, if required.


Figure 10-2 Interface Performance Window—Performance (2) Tab



The Error Statistics for the selected interface appear.

- Step 4** Choose the Performance (3) tab, if required.

Figure 10-3 Interface Performance Window—Performance (3) Tab



The Packets/Octets statistics for the selected interface appear.

Starting Performance Logging for a Selected Interface



Note

Performance logging can also be started/stopped on a global basis for a selected chassis. See [“Starting Global Performance Logging”](#) section on page 4-9. Performance logging can also be started on a per module (GRP) basis. For details on how to start performance logging for a selected module (GRP), see [“Module Performance”](#) section on page 5-9.

Starting performance logging allows performance data to be gathered for the selected interface. Performance polling occurs every polling period (15 minutes). Performance data is then gathered and stored for historical review. Current performance data can be viewed in the Interface Performance window, or you can view historical performance data in Performance Manager.




Note

You must start performance logging if you want to view historical data in the Performance Manager. You do not need to have performance logging enabled on an interface to view the current data in the Interface Performance window.

To start performance logging for a selected interface, proceed as follows:


- Step 1** Open the Interface Performance window. See [“Viewing the Generic Interface Performance Window” section on page 10-3](#) for further details.
- Step 2** Choose a **Chassis**, **Module**, and **Interface** from the lists displayed at the left of the window.
- Step 3** Click **Start** to begin performance logging for the selected interface. A window appears for you to confirm that you wish to start performance logging.

Figure 10-4 Start Performance Logging Confirmation Window



- Step 4** Click **Yes** to begin performance logging for the selected interface. An Action Report window appears to confirm that performance logging has started.

Figure 10-5 Action Report Window




- Step 5** Click **Close** to close the Action Report window.
 - Step 6** Choose **File > Close** to close the Interface Performance window.
- See [Chapter 20, “Performance Management and Historical Data”](#) chapter for information on viewing historical performance information for a selected interface.

Stopping Performance Logging for a Selected Interface

To stop performance logging for a selected interface, proceed as follows:


- Step 1** Open the Interface Performance window. See “[Viewing the Generic Interface Performance Window](#)” section on page 10-3 for further details.
- Step 2** Choose a **Chassis**, **Module**, and **Interface** from the lists displayed at the left of the window.
- Step 3** Choose **Stop** to stop performance logging for the selected interface. A window appears for you to confirm that you wish to stop performance logging.

Figure 10-6 Stop Performance Logging Confirmation Window



- Step 4** Click **Yes** to stop performance logging for the selected interface. An Action Report window appears to confirm that performance logging has been stopped for the selected interface.

Figure 10-7 Action Report Window



- Step 5** Click **Close** to close the Action Report window.
- Step 6** Choose **Close** from the **File** menu to close the Interface Performance window.

Generic Interface Performance Window—Detailed Description

The Interface Performance window contains three tabs: Performance (1), Performance (2) and Performance (3).

Performance (1) Tab

The Performance (1) tab (see [Figure 10-1](#)) contains three areas: General Information, Packets/Octets Statistics, and Performance Logging.

General Information

The General area contains the following fields:

Resets—Number of times the interface is internally reset.



Note

Transmitted/Received Bandwidth Utilization will not be calculated and displayed until after a performance logging poll (15 minutes), and only if performance logging is active for the interface.

Transmitted Bandwidth Utilization—Percentage of transmitted bandwidth utilization. The percentage is calculated as packets per second divided by the speed of interface, averaged over the polling period (if performance polling is active).

Received Bandwidth Utilization—Percentage of received bandwidth utilization. The percentage is calculated as packets per second divided by the speed of interface, averaged over the polling period (if performance polling is active).

Packets/Octets Statistics

The Packets/Octets Statistics area contains the following fields:

In Octets—Total number of packets received on the interface, including framing characters.

Out Octets—Total number of packets transmitted out of the interface, including framing characters.

In Bits/sec—Five-minute exponentially decayed moving average of input bits per second.

Out Bits/sec—Five-minute exponentially decayed moving average of output bits per second.

In Packets/sec—Five-minute exponentially decayed moving average of input packets per second.

Out Packets/sec—Five-minute exponentially decayed moving average of output packets per second.

In Unicast Packets—Total number of packets received by the layer which were not addressed as multicast or broadcast.

Out Unicast Packets—Total number of packets transmitted by the layer which were not addressed as multicast or broadcast.

In Multicast Packets—Total number of packets received by this layer addressed as multicast

Out Multicast Packets—Total number of packets transmitted by this layer addressed as multicast

In Broadcast Packets—Total number of packets received by this layer which was broadcasted.

Out Broadcast Packets—Total number of packets transmitted by this layer which was broadcasted.

Performance Logging

The performance Logging area displays Start and Stop buttons.

Start—Click Start to begin performance logging for the selected interface.

Stop—Click Stop to stop performance logging for the selected interface.



Note

The VLAN sub-interfaces do not support the fields, *In Bits/sec*, *In Packets/sec*, *Out Bits/sec*, *Out Packets/sec*, displayed in the **Packets/Octets Statistics** area in the Performance (1) tab.

Performance (2) Tab

The Performance (2) tab (see [Figure 10-2](#)) displays a single Error Statistics area.

Error Statistics

The Error Statistics area displays the following fields:

Runts—Number of packets input which were smaller than the physical media permitted.

Giants—Number of input packets which were larger than the physical media permitted.

Collisions—Number of output collisions detected on this interface.

Aborted Packets—Number of input packets which were aborted.

Ignored Packets—Number of input packets which were ignored by the interface.

Overrun Packets—Displays the number of input packets that arrived too quickly for the hardware to receive.

Misaligned Packets—Number of input packets which were misaligned.

In Errored Packets—Number of inbound packets that contained errors.

In Discarded Packets—Number of inbound packets chosen to be discarded even though no errors were found.

In Packets Dropped—Number of packets dropped because the input queue was full.

Out Errored Packets—Number of outbound packets that could not be transmitted because of errors.

Out Discarded Packets—Number of outbound packets chosen to be discarded even though no errors were found.

Out Packets Dropped—Number of packets dropped because the output queue was full.

CRC Errored Packets—Number of input packets which had cyclic redundancy checksum errors.



Note

The VLAN sub-interfaces do not support the fields displayed in the Performance (2) tab.

Performance (3) Tab

The Performance (3) tab (see [Figure 10-3](#)) displays a single Packets/Octets Statistics (High Capacity) area.

Packets/Octets Statistics (High Capacity)

In Octets—The total number of octets received on the interface (64-bit counter)

Out Octets—The total number of octets transmitted out of the interface (64-bit counter)

In Unicast Packets—Total number of packets received by the layer which were not addressed as multicast or broadcast. (64-bit counter)

Out Unicast Packets—Total number of packets transmitted by the layer which were not addressed as multicast or broadcast. (64-bit counter)

In Multicast Packets—Total number of packets received by this layer addressed as multicast (64-bit counter)

Out Multicast Packets—Total number of packets transmitted by this layer addressed as multicast (64-bit counter)

In Broadcast Packets—Total number of packets received by this layer which was broadcasted (64-bit counter)

Out Broadcast Packets—Total number of packets transmitted by this layer which was broadcasted (64-bit counter)

SONET Interface Performance

The SONET Interface Performance section covers the following areas:


- [Viewing the SONET Interface Performance Window](#)
- [SONET Performance Window—Detailed Description](#)

Viewing the SONET Interface Performance Window

To view the SONET Interface Performance window, proceed as follows:


-
- Step 1** Right click on the SONET interface object and choose **Cisco 12000/10720 Manager> Performance>SONET>Performance**. See [Table 10-2 on page 10-2](#) for information on which objects allow you to launch the SONET Interface Performance window. The SONET Interface Performance window appears, with the Section tab displayed.

Figure 10-8 SONET Interface Performance—Section Tab



- Step 2** Choose a **Chassis**, **Module**, and **SONET Interface** from the list boxes at the left of the window. The performance information for the selected interface appears (see [Figure 10-8](#)).
- Step 3** Choose the **Line** tab, if required.

Figure 10-9 SONET Interface Performance—Line Tab



Step 4 Choose the **Path** tab, if required.

Figure 10-10 SONET Interface Performance—Path Tab

The screenshot displays the SONET Interface Performance application window. The main area is divided into four tabs: Section, Line, Path, and Virtual Tributary. The Path tab is selected, showing performance metrics for the Path and Far End Path. The metrics are as follows:

Metric	Value
Errored Seconds	0
Severely Errored Seconds	0
Unavailable Seconds	0
Coding Violations	0

The interface also includes a left-hand navigation pane with sections for Chassis (listing ALR0, ALR1, CSC0, FE4, LBM, PSM1, RP6, S0, S1, S5) and Module (listing Side 0-0-A, Side 0-0-B). The status bar at the bottom indicates: Status: CiscoSONETFunctionality (normal), CiscoModule (normal), CiscoChassis (...) Dynamic updates are enabled. Last update Thu Nov 14 15:43:30 2002.



Note The Virtual Tributary tab is not applicable to Cisco 12000/10720 Router Manager.

SONET Performance Window—Detailed Description

The SONET Performance window displays four tabs: Section, Line, Path, and Virtual Tributary (not applicable to Cisco 12000/10720 Router Manager).

Section Tab

The Section tab (see [Figure 10-8 on page 10-11](#)) displays a single Section area containing the following fields:

Errored Seconds—Total number of errored seconds encountered by the SONET interface in the current 15 minute interval.

Severely Errored Seconds—Number of severely errored seconds encountered by the SONET interface in the current 15 minute interval.

Severely Errored Framing Seconds—Number of severely errored framing seconds encountered by the SONET interface in the current 15 minute interval.

Coding Violations—Number of coding violations encountered by the SONET interface in the current 15 minute interval.

Line Tab

The Line tab (see [Figure 10-9 on page 10-12](#)) displays two areas: Line and Far End Line, as follows:

Line

The Line area displays the following fields:

Errored Seconds—Total number of errored seconds encountered by the SONET line.

Severely Errored Seconds—Number of severely errored seconds encountered by the SONET line.

Unavailable Seconds—Total number of unavailable seconds encountered by the SONET line.

Coding Violations—Number of coding violations encountered by the SONET line.

Far End Line

The Far End Line area displays the following fields:

Errored Seconds—Total number of far end errored seconds encountered by the SONET line.

Severely Errored Seconds—Number of far end severely errored seconds encountered by the SONET line.

Unavailable Seconds—Total number of far end unavailable seconds encountered by the SONET line.

Coding Violations—Number of far end coding violations encountered by the SONET line.

Path Tab

The Path tab (see [Figure 10-10 on page 10-13](#)) displays two areas: Path and Far End Path.

Path

The Path area displays the following fields:

Errored Seconds—Total number of errored seconds encountered by the SONET path.

Severely Errored Seconds—Number of severely errored seconds encountered by the SONET path.

Unavailable Seconds—Total number of unavailable seconds encountered by SONET path.

Coding Violations—Number of coding violations encountered by the SONET path.

Far End Path

The Far End Path area displays the following fields:

Errored Seconds—Total number of far end errored seconds encountered by the SONET path.

Severely Errored Seconds—Number of far end severely errored seconds encountered by the SONET path.

Unavailable Seconds—Total number of far end unavailable seconds encountered by the SONET path.

Coding Violations—Number of far end coding violations encountered by the SONET path.

Virtual Tributary Tab

The Virtual Tributary tab is not applicable to Cisco 12000/10720 Router Manager.

DS3/E3 Interface Performance

The DS3/E3 Interface Performance section covers the following areas:

- [Viewing the DS3/E3 Interface Performance Window](#)
- [DS3/E3 Interface Performance Window—Detailed Description](#)



Note


The DS3 interface support is not provided by the Cisco 10720 chassis.

Viewing the DS3/E3 Interface Performance Window

To view the DS3/E3 Interface Performance window, proceed as follows:


- Step 1** Right click on a DS3 interface object and choose **Cisco 12000/10720 Manager>Performance>DS3>Performance**. See [Table 10-2 on page 10-2](#) for information on which objects allow you to launch the DS3/E3 Interface Performance window. The DS3/E3 Interface Performance window appears, with the DS3 Performance tab displayed.

Figure 10-11 DS3/E3 Interface Performance Window—DS3 Performance Tab



- Step 2** Choose a **Chassis**, **Module**, and **DS3 Interface** from the list boxes displayed at the left of the window. The DS3/E3 interface performance information for the selected interface appears.
- Step 3** Choose the **E3 Performance** tab, if required, to view the E3 Performance details (see [Figure 10-12](#)).

Figure 10-12 DS3/E3 Interface Performance Window—E3 Performance Tab



DS3/E3 Interface Performance Window—Detailed Description

The DS3/E3 Interface Performance window displays two tabs: DS3 Performance and E3 Performance.

DS3 Performance Tab

The DS3 Performance tab (see [Figure 10-11 on page 10-16](#)) displays two areas: DS3 Statistics and Far End DS3 Statistics.

DS3 Statistics

The DS3/E3 Statistics area displays the following information:

C-bit Coding Violations—Number of C-bit coding violations encountered by the interface.

C-bit Errored Seconds—Number of C-bit errored seconds detected by the interface.

C-bit Severely Errored Seconds—Number of times C-bit severely errored seconds detected by the interface.

P-bit Coding Violations—Number of P-bit coding violations detected by the interface.

P-bit Errored Seconds—Number of P-bit errored seconds detected by the interface.

P-bit Severely Errored Seconds—Number of P-bit severely errored seconds encountered by the interface.

Unavailable Seconds—Count of the unavailable seconds encountered by interface.

Far End DS3 Statistics

Not applicable to Cisco 12000/10720 Router Manager.

E3 Performance Tab

The E3 Performance tab (see [Figure 10-12 on page 10-17](#)) displays three areas: Current E3 Status, Interval E3 Status, and Total E3 Status.

Current E3 Status

The Current E3 Status area displays the following information:

C-Severely Errored Framing Seconds—Number of C-bit severely errored seconds encountered by the interface in the current 15 minute interval.

C-Line Errored Seconds—Number of line errored seconds encountered by the interface in the current 15 minute interval.

C-Line Coding Violations—Number of line coding violations encountered by the interface in the current 15 minute interval.

Interval E3 Status

Not applicable to Cisco 12000/10720 Router Manager.

Total E3 Status

The Total E3 Statistics area displays the following information:

T-Severely Errored Framing Seconds—Number of T-line severely errored framing seconds encountered by the interface in the current 24 hour interval.

T-Line Errored Seconds—Number of errored seconds encountered by the interface in the current 24 hour interval.

T-Line Coding Violations—Number of coding violations encountered by the interface in the current 24 hour interval.

- Step 2** Choose a **Chassis**, **Module**, and **Ethernet Interface** from the list boxes displayed at the left of the window. The performance information for the selected interface appears.
-

Ethernet Interface Performance Window—Detailed Description

The Ethernet Interface Performance tab (see [Figure 10-13 on page 10-19](#)) displays two areas: General Statistics and Collision Statistics.

General Statistics

The General Statistics area displays the following statistics:

Multiple Collision Frames—Count of frames transmitted across an interface where more than one collision exists.

Frame Check Sequence Errors—Count of Frames received with Frame Check Sequence Error status.

Alignment Error—Count of Frames received with alignment errors.

Internal MAC Transmit Errors—Count of frames transmitted that failed due to an external transmit error.

Deferred Transmissions—Number of first transmissions attempts delayed because the medium was busy.

Frames Too Long—Number of frames transmitted, where the size of the frames are larger than the permissible frame size.

Carrier Sense Errors—Number of times the carrier sense was lost while transferring frames.

Late Collisions—Number of collisions detected on the interface after the transmission of a packet.

Signal Quality Errors (SQE)—Count of SQE error messages generated by the interface.

Single Collision Frames—Count of frames transmitted across an interface with one collision.

Excessive Collisions—Number of times transmission failed due to excessive collision.

Internal MAC Receive Errors—Count of frames transmitted that failed due to an internal MAC receive error.

Collision Statistics

The Collision Statistics area displays the following statistics:

Collision Count—Number of collisions per frame on a particular interface

Collision Frequency—The corresponding count of frames for the specified number of collisions.

SRP Performance

The SRP Performance section covers the following areas:


- [Viewing the SRP Performance Window](#)
- [SRP Performance Window—Detailed Description](#)

Viewing the SRP Performance Window

To view the SRP Performance window, proceed as follows:


- Step 1** Right click on the SRP interface object and choose **Cisco 12000/10720 Manager>Performance>SRP>Performance**. See [Table 10-2 on page 10-2](#) for information on which objects allow you to launch the SRP Performance window. The SRP Performance window appears, with the Ring tab displayed.

Figure 10-14 SRP Performance Window



- Step 2** Choose a **Chassis**, **Module**, and **SRP Interface** from the list boxes displayed at the left of the window. The performance information for the selected interface appears.
- Step 3** Click on the Outer Ring tab, if required.


Figure 10-15 SRP Performance window—Outer Ring tab



89977

Step 4 Click on the Inner Ring tab, if required.

Figure 10-16 SRP Performance Window—Inner Ring Tab



Step 5 Click on the Side tab, if required.

Figure 10-17 SRP Performance window—Side tab

The screenshot shows the SRP Performance window with the Side tab selected. The window displays the following data:

Counters For Last x Seconds	
Time Elapsed	179 sec.

Side A Data Traffic (Bytes)	
Total Transmit Traffic	6846
Host Transmit Traffic	1165
Total Receive Traffic	120
Host Receive Traffic	120

Side B Data Traffic (Bytes)	
Total Transmit Traffic	0
Host Transmit Traffic	0
Total Receive Traffic	6734
Host Receive Traffic	2561

SRP Interface

Status: CiscoSRPFunctionality (normal), CiscoModule (normal), CiscoChassis (no ...)
 Status as of Thu Apr 10 17:16:23 2003

Dynamic updates are enabled



Note The performance windows are not applicable to the OC-12 line cards.

SRP Performance Window—Detailed Description

The SRP Performance window displays four tabs: Interface, Outer Ring, Inner Ring and Side



Note All the counters that are mentioned in this dialog are subjected to the current 15 minutes interval on the device.



Note This dialog is not supported on OC-12 SRP interface (except Engine 3 OC-12c/STM-4 line card interface) objects.

Interface Tab

The Interface tab displays three areas: Counters for last x seconds, Utilization and Data Traffic

Counters for last x seconds

Time Elapsed—Indicates the number of seconds which have elapsed in the current interval. The Time Elapsed value ranges between 0 to 900. When this value is 0, all the counters in the dialog are of value 0. For example, when the value of Time Elapsed is 100 sec, all the counters displayed in this dialog are calculated using the traffic in the last 100 seconds.

Utilization

Bandwidth Utilization—The percentage bandwidth of the interface utilized in the specified time. For example, when the bandwidth utilization is 60, it means that the interface is utilized at 60% on average in the last Time Elapsed seconds.

Data Traffic

The Data Traffic area has two panes: bits/sec and Packets/sec.

The bits/sec area has the following attributes:

Transit Traffic—The rate of traffic passing through this node but not meant for this node. The displayed value is in bits/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

Node Traffic—The rate of traffic reached to/going from this host. The displayed value is in bits/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

Node Transmit Traffic—The rate of traffic transmitted by this node into the ring. The displayed value is in bits/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

Node Receive Traffic—The rate of traffic received by this node from the ring. The displayed value is in bits/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

The Packets/sec area has the following attributes,

Transit Traffic—The rate of traffic passing through this node but not meant for this node. Displayed value is in Packets/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

Node Traffic—The rate of traffic reached to/going from this host. The displayed value is in Packets/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

Node Transmit Traffic—The rate of traffic transmitted by this node into the ring. The displayed value is in Packets/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

Node Receive Traffic—The rate of traffic received by this node from the ring. The displayed value is in Packets/sec, the traffic in the last Time Elapsed seconds is considered for calculation.

Outer Ring Tab

The Outer Ring tab displays three areas: Counters for last x seconds, Utilization and Data Traffic

Counters for last x seconds

Time Elapsed—Indicates the number of seconds that have elapsed in the current interval. The Time Elapsed value ranges between 0 to 900. When this value is 0, all the counters in the dialog are of value 0. For example, when the value of Time Elapsed is 100 sec, it means that all the counters displayed in this dialog are calculated using the traffic in the last 100 seconds.

Utilization

Bandwidth Utilization—The percentage bandwidth of the outer ring utilized in the specified time. For example, when the bandwidth utilization is 60, it means that the outer ring is utilized at 60% on average in the last Time Elapsed seconds.



Note

To get the correct bandwidth utilization, please ensure that the interface bandwidth is set to the maximum value in IOS. To achieve this, run the “no bandwidth” command in the interface mode in IOS CLI.

Data Traffic

The Data Traffic area has two panes: bits/sec and Packets/sec.

The bits/sec area has the following attributes,

Transit Traffic—The rate of traffic passing through the outer ring at this node but not meant for this node. The displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Traffic—The rate of traffic on the outer ring, reached to/going from this host. The displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Transmit Traffic—The rate of traffic on the outer ring, transmitted by this node into the ring. Displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Receive Traffic—The rate of traffic on the outer ring, received by this node from the ring. The displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

The Packets/sec area has the following attributes,

Transit Traffic—The rate of traffic passing through the outer ring at this node but not meant for this node. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Traffic—The rate of traffic on the outer ring, reached to/going from this host. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Transmit Traffic—The rate of traffic on the outer ring, transmitted by this node into the ring. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Receive Traffic—The rate of traffic on the outer ring, received by this node from the ring. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Inner Ring Tab

The Inner Ring tab displays three areas: Counters for last x seconds, Utilization and Data Traffic

Counters for last x seconds

Time Elapsed—Indicates the number of seconds that have elapsed in the current interval. The Time Elapsed value ranges between 0-900. When the Time Elapsed is of value 0, all the counters in the dialog are of value 0. For example, when the Time Elapsed is of value 100 sec, it means that all the counters displayed in this dialog are calculated using the traffic in the last 100 seconds.

Utilization

Bandwidth Utilization—The percentage bandwidth of the inner ring utilized in the specified time. For example, when the bandwidth utilization is 60, it means that the inner ring is utilized at 60% on average in the last Time Elapsed seconds.

**Note**

To get the correct bandwidth utilization, please ensure that the interface bandwidth is set to the maximum value in IOS. To achieve this, run the “no bandwidth” command in the interface mode in IOS CLI.

Data Traffic

The Data Traffic area has two panes: bits/sec and Packets/sec.

The bits/sec area has the following attributes,

Transit Traffic—The rate of the traffic passing through the inner ring at this node but not meant for this node. The displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Traffic—The rate of traffic on the inner ring, reached to/going from this host. The displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Transmit Traffic—The rate of traffic on the inner ring, transmitted by this node into the ring. The displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Receive Traffic—The rate of traffic on the inner ring, received by this node from the ring. The displayed value is in bits/sec, traffic in the last Time Elapsed seconds is considered for calculation.

The Packets/sec area has the following attributes,

Transit Traffic—The rate of traffic passing through the inner ring at this node but not meant for this node. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Traffic—The rate of traffic on the inner ring, reached to/going from this host. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Transmit Traffic—The rate of traffic on the inner ring, transmitted by this node into the ring. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Node Receive Traffic—The rate of traffic on the inner ring, received by this node from the ring. The displayed value is in Packets/sec, traffic in the last Time Elapsed seconds is considered for calculation.

Side Tab

The Side tab displays three areas: Counters for last x seconds, Side A Data Traffic (Bytes) and Side B Data Traffic (Bytes).

Counters for last x seconds

Time Elapsed—Indicates the number of seconds that have elapsed in the current interval. The Time Elapsed value ranges between 0-900. When the Time Elapsed is of value 0, all the counters in the dialog are of value 0. For example, when the Time Elapsed is 100 sec, it means that all the counters displayed in this dialog are calculated using the traffic in the last 100 seconds.



Note

All the counters displayed are in Bytes.

Side A Data Traffic (Bytes)

Total Transmit Traffic—Total traffic reaching side A on both rings. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

Host Transmit Traffic—Total traffic at side A, transmitted by this node into the ring. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

Total Receive Traffic—Total traffic going from side A on both rings. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

Host Receive Traffic—Total traffic at side A, received by this node from the ring. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

Side B Data Traffic (Bytes)

Total Transmit Traffic—Total traffic reaching side B on both rings. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

Host Transmit Traffic—Total traffic at side B, transmitted by this node into the ring. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

Total Receive Traffic—Total traffic going from side B on both rings. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

Host Receive Traffic—Total traffic at side B, received by this node from the ring. The displayed value is in Bytes, traffic in the last Time Elapsed seconds is considered for calculation.

SRP Side Performance

The SRP Side Performance section covers the following areas:


- [Viewing the SRP Side Performance Window](#)
- [SRP Side Performance Window—Detailed Description](#)

Viewing the SRP Side Performance Window

To view the SRP Side Performance window, proceed as follows:


- Step 1** Right click on a SRP Side interface object and choose **Cisco 12000/10720 Manager> Performance>SRP>Side>Performance**. See [Table 10-2 on page 10-2](#) for information on which objects allow you to launch the SRP Side Performance window. The SRP Side Performance window appears, with the Ring tab displayed.

Figure 10-18 SRP Side Performance Window




- Step 2** Choose a **Chassis**, **Module**, **SRP Interface** and **SRP Side** from the list boxes displayed at the left of the window. The performance information for the selected interface appears.
- Step 3** Click on the Host tab, if required.

Figure 10-19 SRP Side Performance window—Host tab



Step 4 Click on the Errors tab, if required.

Figure 10-20 SRP Side Performance window—Errors Tab





Note The performance dialogs are not applicable to the OC-12 line cards

SRP Side Performance Window—Detailed Description

The SRP Side Performance window displays three tabs: Ring, Host and Errors.



Note

All the counters that are mentioned in this dialog are subjected to the current 15 minutes interval on the device.

Ring Tab

The Ring tab displays four areas: Packets In, Packets Out, Octets In and Octets Out.

Packets In

Low Priority Unicast—Displays the number of low priority unicast packets received from the physical layer.

High Priority Unicast—Displays the number of high priority unicast packets received from the physical layer.

Low Priority Multicast—Displays the number of low priority multicast packets received from the physical layer.

High Priority Multicast—Displays the number of high priority multicast packets received from the physical layer.

Packets Out

Low Priority Unicast—Displays the number of low priority unicast packets going to the physical layer.

High Priority Unicast—Displays the number of high priority unicast packets going to the physical layer.

Low Priority Multicast—Displays the number of low priority multicast packets going to the physical layer.

High Priority Multicast—Displays the number of high priority multicast packets going to the physical layer.

Octets In

Low Priority Unicast—Displays the number of low priority unicast octets received from the physical layer.

High Priority Unicast—Displays the number of high priority unicast octets received from the physical layer.

Low Priority Multicast—Displays the number of low priority multicast octets received from the physical layer.

High Priority Multicast—Displays the number of high priority multicast octets received from the physical layer.

Octets Out

Low Priority Unicast—Displays the number of low priority unicast octets going to the physical layer.

High Priority Unicast—Displays the number of high priority unicast octets going to the physical layer.

Low Priority Multicast—Displays the number of low priority multicast octets going to the physical layer.

High Priority Multicast—Displays the number of high priority multicast octets going to the physical layer.

Host Tab

The Host tab displays four areas: Packets In, Packets Out, Octets In and Octets Out

Packets In

Low Priority Unicast—Displays the number of low priority unicast packets received from the higher layer.

High Priority Unicast—Displays the number of high priority unicast packets received from the higher layer.

Low Priority Multicast—Displays the number of low priority multicast packets received from the higher layer.

High Priority Multicast—Displays the number of high priority multicast packets received from the higher layer.

Packets Out

Low Priority Unicast—Displays the number of low priority unicast packets going to the higher layer.

High Priority Unicast—Displays the number of high priority unicast packets going to the higher layer.

Low Priority Multicast—Displays the number of low priority multicast packets going to the higher layer.

High Priority Multicast—Displays the number of high priority multicast packets going to the higher layer.

Octets In

Low Priority Unicast—Displays the number of low priority unicast octets received from the higher layer.

High Priority Unicast—Displays the number of high priority unicast octets received from the higher layer.

Low Priority Multicast—Displays the number of low priority multicast octets received from the higher layer.

High Priority Multicast—Displays the number of high priority multicast octets received from the higher layer.

Octets Out

Low Priority Unicast—Displays the number of low priority unicast octets going to the higher layer.

High Priority Unicast—Displays the number of high priority unicast octets going to the higher layer.

Low Priority Multicast—Displays the number of low priority multicast octets going to the higher layer.

High Priority Multicast—Displays the number of high priority multicast octets going to the higher layer.

Errors Tab

The Errors tab displays two areas: Ring and Host

Ring

Received TTL Expiry Packets—Displays the number of discarded packets received from the physical layer, due to TTL expiry

Received Aborted Packets—Displays the number of packets aborted from the physical layer by an abort sequence code.

Received Giant Packets—Displays the number of giant packets received from the physical layer.



Note

A giant packet is larger than the maximum size packet, which is 9216 octets

Received Short Packets—Displays the number of short packets received from the physical layer.



Note

A short packet is 16 octets or less

CRC Error Packets—Displays the number of packets with CRC errors.

Host

Received Discarded Packets—Displays the number of packets that are not delivered to a higher layer due to lack of resources.

Received Giant Packets—Displays the number of packets discarded due to packet size being too big for the higher layer.

Received Short Packets—Displays the number of packets discarded due to packet size being too small for the higher layer.



Layer 3 QoS

This chapter describes how to create and configure Layer 3 QoS (Quality of Service), Committed Access Rate (CAR) policies, Cos Queue groups and Weighted Random Early Detection To-Fabric (WRED ToFab) policies.

The Layer 3 QoS dialogs are not available for the 10720 chassis.

This chapter contains the following information:

- [Launching the Layer 3 QoS Windows](#)
- [CAR and WRED Overview](#)
- [The Workflow for CAR](#)
- [CAR Policy Configuration](#)
- [Access List Configuration](#)
- [CAR Policy Apply](#)
- [CAR Policy Status](#)
- [The Workflow for WRED/DRR](#)
- [CoS Queue Group Configuration](#)
- [WRED Tx Configuration](#)
- [WRED ToFab Configuration](#)
- [WRED Rx Configuration](#)

Launching the Layer 3 QoS Windows

[Table 11-1](#) displays the Layer 3 QoS windows that can be launched from each of the available object types. For example, the CAR Policy Configuration window can be launched for 12000 Series Router chassis from a Site, Chassis, Module, Interface or a CAR Policy, but not from the WRED-MDRR container or a CoS Queue Group object.



Note

[Table 11-1](#) lists the menu options to launch the Layer3QoS dialogs from the site level.

Table 11-1 Launching the Layer 3 QoS Windows

Layer 3 QoS Window/Task	Objects (that can be selected) to Open the Window									Menu Options to Launch the Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	CAR Policy	Access List	WRED MDRR	CoS Queue Group	
CAR Policy Configuration	Yes	Yes	No	Yes	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager> Configuration>Interface>QoS> CAR Policy Configuration
Access List Configuration	Yes	Yes	No	Yes	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager> Configuration>Interface>QoS> Access List Configuration
CAR Policy Apply	Yes	Yes	No	Yes	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager> Configuration>Interface>QoS> CAR Policy Apply
CAR Policy Status	Yes	Yes	No	Yes	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager> Fault>Interface>QoS> CAR Policy Status
CoS Queue Group Configuration	Yes	Yes	No	Yes	Yes	No	No	Yes	Yes	Cisco 12000/10720 Manager> Configuration>Interface>QoS> CoS Queue Group Configuration
WRED Tx Configuration	Yes	Yes	No	Yes	Yes	No	No	Yes	Yes	Cisco 12000/10720 Manager> Configuration>Interface>QoS> WRED Tx Configuration
WRED ToFab Configuration	Yes	Yes	No	Yes	No	No	No	Yes	Yes	Cisco 12000/10720 Manager> Configuration>Module> ToFab>ToFab Configuration
WRED Rx Configuration	Yes	Yes	No	Yes	No	No	No	Yes	Yes	Cisco 12000/10720 Manager> Configuration>Module> ToFab>WRED Rx Configuration

**Note**

Cisco 12000/10720 Router Manager windows cannot be opened when multiple objects are selected (the menu options to open the Cisco 12000/10720 Router Manager windows are grayed out). The available menu options can be launched from a site object (containing the chassis, module or interface objects) to perform the various operations as and when required.

CAR and WRED Overview

Access Lists

Access lists enhance the abilities of a CAR policy. For example, access lists allow you to specify certain types of traffic, or certain locations where the traffic is coming from.

Committed Access Rate (CAR)

CAR is a policing mechanism that allows you to partition your network into multiple priority levels or classes of service. You set the IP precedence for packets entering the network. Networking devices (within your network) can then use the configured IP precedence in the packets to determine how to treat the traffic. CAR services, limit the input or output transmission rate on an interface or sub-interface, based on a flexible set of criteria. CAR is often configured on interfaces at the edge of a network to limit traffic into or out of the network. CAR, can rate limit traffic based on certain matching criteria, such as incoming interface, incoming and outgoing traffic, IP precedence, or IP access list. You can configure the actions CAR will take when traffic conforms to or exceeds the rate limit. Each interface can have multiple CAR policies, corresponding to different types of traffic. For example, low priority traffic can be limited to a lower rate than high priority traffic.



Note

In Cisco 12000/10720 Router Manager, you can currently apply only one CAR policy to a module.

Weighted Random Early Detection (WRED)

WRED is a congestion avoidance mechanism that takes advantage of Transmission Control Protocol (TCP) congestion control mechanism. WRED drops packets selectively, prior to periods of high congestion, based on IP precedence. Packets with a higher IP precedence are less likely to be dropped than packets with a lower precedence. WRED is normally used in the core routers of a network, rather than on the edge. Edge routers assign IP precedence to packets as they enter the network. WRED uses these precedents to determine how it treats different types of traffic.

You can have a symmetric as well as asymmetric data rate for network transmissions. In order to smoothen the data traffic at transmit as well as the receive end, the WRED QoS parameters can be configured for the transmitting and receiving traffic. The WRED ToFabric (henceforth referred as WRED ToFab, see [Towards the Fabric \(ToFab\)](#) for more details) feature enables the user to configure the WRED at the receive side in conjunction with the transmit side.

All WRED processing takes place on the line card, rather than on the GRP management card. No default configuration values are supplied. You must provide values for all configurable fields. WRED also incorporates Modified Deficit Round Robin (MDRR).

You can see from the descriptions where these two mechanisms differ. CAR focuses more on classifying traffic according to QoS parameters, while WRED functions to ease network traffic and prioritize specified traffic.

Towards the Fabric (ToFab)

ToFab describes the receive side traffic queues from a line card to (towards) the Switch fabric. Cisco 12000/10720 Router Manager supports this functionality through the following dialogs,

- ToFab Configuration (used for creating ToFab policies)
- WRED Rx Configuration (used to apply/remove the ToFab policies for the chassis slots)

The ToFab Configuration dialog lists all the CosQ groups already created and so the user can form the Slot-Table-Cos (ToFab) by associating them for any destination slots. This basically defines a CosQ group to any slot with reference to the slot (line card) for which the policy would be applied.



Note

Only one CosQ group can be applied to a destination slot.

The WRED Rx Configuration dialog is used to apply the same against a Preferred line card (Slot). Similar to CosQ group management, Engine Type Support is also provided.

Any ToFab policy that is created is available under the Container View Layer3QoSView ==> WRED-MDRR ==> TOFABPolicies.

The service menu for ToFab management is available from the module and its parents. The ToFab dialogs can also be launched for the Layer3QoSView container.

MDRR Overview

Modified Deficit Round Robin (MDRR) is a traffic latency control function. It allows the operators to guarantee traffic latency for differentiated flows by controlling the packet de-queuing process. Packet classification is based on IP Precedence. MDRR differs from DRR in that one of the eight available queues is designated as a low-latency queue.

There are two basic modes of operation which govern how packets are de-queued from the low-latency queue in relation to other queues. They are:

- Alternate Priority—Queues are serviced by alternating between the low-latency queue & the other queues in round-robin.
- Strict Priority—Low-latency queue is continually serviced to keep it empty.

MDRR in Cisco 12000/10720 Router Manager

The MDRR implementation uses COS Queue Groups to encapsulate the required profile. Consequently, Cisco 12000/10720 Router Manager provides MDRR support via COS Queue Groups: the operator creates a COS Queue Group & uses the MDRR configuration Window to encapsulate the required parameters. The COS Queue Group is then available to be applied to any interface.

Implications of Engine Type

Engine type refers to different hardware architectures. From a management perspective, the engine type determines what functionality is available to the client. Currently, this only applies to Layer 3 QoS. The following is a summary of how engine type affects Layer 3 QoS:

- CAR—Supported for Engine 0 and 1
- CAR—Limited support for Engine 4
- PIRC—Supported for Engine 2 (see [“Per Interface Rate Control \(PIRC\) Support”](#) section on page 11-6 for further details).
- WRED—Supported for Engine 0, 2, and 4 (see [“Engine Type Support for WRED”](#) section on page 11-22 for further details).

Cisco 12000/10720 Router Manager will detect the engine type applicable to a given module (line card) and prevent operations that are not applicable.



Note

Auto-detection is not supported for Engine type 4.

CAR and WRED in Cisco 12000/10720 Router Manager

CAR and WRED are modeled as objects in Cisco 12000/10720 Router Manager. There are two types of CAR objects: CAR policies and access lists. There are two types of WRED objects: CoS (Class of Service) queue groups and ToFab policies.

When you create these objects in Cisco 12000/10720 Router Manager, you can work within the Layer 3 QoS view to create, apply, delete or edit Layer 3 QoS objects. Created CAR policies are placed under the CAR Policies container in the Layer 3 QoS view. Created access lists are placed under the Access List container in the Layer 3 QoS view. Created CoS queue groups are placed under the WRED-MDRR container in the Layer 3 QoS view. Created ToFab policies are placed under the WRED-MDRR container in the Layer3QoS view.



Tip

Access lists are only supported within the realm of CAR and do not function as stand-alone objects.

It is important to note that Layer 3 QoS CAR and WRED objects (access lists, policies, CoS queue groups, ToFab policies) are global, meaning they can be applied to any module/interface object within Cisco 12000/10720 Router Manager. For example, the CosQ groups are applied to interfaces whereas the ToFab policies are applied to modules (line cards).

The Workflow for CAR

To begin working with CAR objects, proceed as follows:

-
- Step 1** Create and configure a CAR policy.
 - Step 2** Create and configure an access list (optional).
 - Step 3** Apply one or more access lists to the CAR policy.
 - Step 4** Apply the created CAR policy to one or multiple interfaces.

At any given time, you also have the option to edit or delete CAR policies (which are not applied), change the association of CAR policies, or view the status of CAR policies on any interface.

CAR Policy Configuration

CAR policies can rate limit traffic based on certain matching criteria, such as incoming interface, IP Precedence, or IP access list. You configure the actions CAR will take when traffic conforms to or exceeds the rate limit. You can set CAR policies that are associated with one of the following:

- All IP traffic
- IP precedence
- MAC address
- IP access list, both standard and extended. Matching to IP access lists is more processor-intensive than matching based on other criteria.

Each interface can have only one CAR policy applied.

The CAR Policies section covers the following areas:

- [Creating a CAR Policy](#)
- [Applying an Access List to a CAR Policy](#)
- [CAR Policy Configuration Window—Detailed Description](#)

Per Interface Rate Control (PIRC) Support

From the operator's perspective, the same workflows used for CAR will be available for the creation, application and maintenance of PIRC Policies. Specifically, the following functions are applicable to PIRC:

- Incoming only (Rx direction)
- Only one rule is allowed in a PIRC statement
- Available conform-actions are:
 - drop
 - set-prec-transmit
 - transmit
- No access-group matching is available in Cisco 12000/10720 Router Manager

- Available exceed-actions are:
 - drop (drop packet)
 - set-prec-transmit (rewrite packet precedence and send it)
 - transmit (transmit packet)

If an attempt is made to apply a CAR policy to an engine 2 module, then the request will be refused and an appropriate error message is displayed, if an attempt is made to use CAR functionality other than that listed above.

On engine 0 and 1 modules, the full range of CAR functions is supported.

Limited Support for Engine 4

The Engine-4 line cards (10 Port GigaEthernet and 1 Port OC-192 POS) have the following limitations for applying CAR policies.


1. It is not PIRC Supported.
2. Traffic direction is restricted to Input Only.
3. ACL can be only IP-Precedence (ACL Index can have only 1-99).
4. Rate limited ACLs can be only IP-Precedence (ACL Index can have only 1-99).
5. Confirm-Action can be: Drop, Transmit and Set Prec. to X transmit.
6. Exceed-Action can be: Drop, Transmit and Set Prec. to Y transmit.

Creating a CAR Policy

To create a CAR policy, proceed as follows:

-
- Step 1** Choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS>CAR Policy Configuration** from a relevant object to launch the CAR Policy Configuration window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the CAR Policy Configuration window.

Figure 11-1 CAR Policy Configuration Window



- Step 2** Choose **Create CAR Policy**. A popup window appears asking for you to enter a name for the CAR policy.
- Step 3** Enter a name for the CAR policy you are about to create, then choose **Ok**.
A window appears, confirming if you were successful or not. The name of your new profile appears in the list box at the left of the window.
- Step 4** Modify the configuration fields, as desired (see below for a detailed description of the fields within this window).
- Step 5** Choose **Save** to save the changes.

Applying an Access List to a CAR Policy

- Step 1** You can apply an access list to a selected CAR policy if desired (to create an access list, see [“Access List Configuration”](#) section on page 11-10). To apply an access list, proceed as follows:
- Step 2** Choose **Yes** in the Access List Choice area. Available access lists appear at the left of the window.
- Step 3** Choose the access list you want to apply.

- Step 4** In the Actions area, choose the right facing arrow to move the selected access list into the Required Access List.
- Step 5** Choose **Save** to save the changes.
-

CAR Policy Configuration Window—Detailed Description

The CAR Policy Configuration displays a single CAR Policy Configuration tab.

CAR Policy Configuration Tab

The CAR Policy Configuration tab displays four tabs: CAR Parameters, Access List Choice, Conform Action, and Exceed Action.

CAR Parameters

The CAR Parameters area contains the following fields:

Traffic Direction—Choose either incoming (input) or outgoing (output) traffic.

Average Transmission Rate—Normal transmission rate based on a long term average in bps.

Normal Burst Size (in bytes)—Bytes allowed in a burst before some packets will exceed the rate limit. Larger bursts are more likely to exceed the rate limit.

Maximum Burst Size (in bytes)—Bytes allowed in a burst before all packets will exceed the rate limit. This value should be greater than or equal to the normal burst size.

Access List Choice

The Access List Choice area contains the following fields:

With Access List—Choose yes to apply a selected access list to the selected CAR policy; choose No if you do not want to apply an access list to the selected CAR policy.

Available Access List—Pane that lists all created access lists.

Actions—Contains two arrow buttons to move access lists between the available access list and the required access list.

Required Access List—Pane that lists all access lists, which are required to be associated with the selected CAR policy.

Conform Action

The Conform Action area contains the following fields:

Continue—Evaluate the next rate-limit command.

Drop—Choose to drop the packet or not.

Transmit—Choose to transmit the packet or not.

Set Prec. To X and Continue—(numbers 0-7) Set precedence to an integer and continue.

Set Prec. To X and Transmit—(numbers 0-7) Set precedence to an integer and transmit.

Exceed Action

The Exceed Action area contains the following fields:

Continue—Evaluate the next rate-limit command.

Drop—Choose to drop the packet or not.

Transmit—Choose to transmit the packet or not.

Set Prec. To Y and Continue—(numbers 0-7) Set precedence to an integer and continue.

Set Prec To Y and Transmit—(numbers 0-7) Set precedence to an integer and transmit.

Access List Configuration

Access lists are supplemental to CAR policies. They enhance the abilities of a CAR policy. For example, access lists allow you to specify certain types of traffic, or certain locations where the traffic is coming from.

The Access List section covers the following areas:


- [Creating Access Lists](#)
- [Access List Configuration Window—Detailed Description](#)

Creating Access Lists

To create an access list, proceed as follows:

-
- Step 1** Choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS>Access List Configuration** from a relevant object to launch the Access List Configuration window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the Access List Configuration window.

Figure 11-2 Access List Configuration—General Tab



- Step 2** Choose **Create Access List**. A popup window appears asking you to enter a name for the access list.
- Step 3** Enter a name for the access list you are about to create, then choose **Ok**.
A window appears, confirming if the access list creation was successful or not. The name of your new access list appears in the list box at the left of the window.
- Step 4** In the General tab, choose the type of access list you want to create. You can also enable logging level at this time (see [Access List Configuration Window—Detailed Description](#)).
- Step 5** Modify the configuration fields in the respective tab, as desired (for a detailed description of the fields within this window, see below).
- Step 6** Choose **Save** to save the changes.
- Step 7** To apply an access list to a CAR policy, see [“Applying an Access List to a CAR Policy”](#) section on page 11-8.

Access List Configuration Window—Detailed Description

The Access List Configuration window contains one button, **Create**. The **Create** button is used to create an access list. When you choose **Create**, a new access list of type IP standard is created and the next available index is assigned. The access list type can be changed and saved if desired. When the access list type is changed, the index can be manually or automatically reallocated to the next available index for the new type selected.

The Access List Configuration window displays five tabs: General, IP Standard, IP Precedence, MAC, and IP Extended.

**Note**

The General tab is always accessible. One of the corresponding tabs, based on the access list type, is also accessible. Any non-relevant tabs are grayed out. The fields in all the tabs are populated with default values. The fields can be changed as desired.

General Tab

The General tab contains a single General tab.

General

The General tab displays four fields:

Index Allocation Mode—Possible values are Manual or Automatic. When the access list type is changed, the index can be manually or automatically reallocated to the next available index for the new type selected.

Index—Identification number for an access list. The Index field is automatically generated if the Index Allocation Mode is set to Automatic.


Type—Lists the type of access list. Possible types include: IP Standard, IP Precedence, MAC and IP Extended.

Logging Level—(This field is only applicable to IP standard and IP extended access lists). If you enable the logging level, then informational messages about the packet that matched the criteria specified in the access list are generated.

IP Standard Tab

The IP Standard tab displays a single IP Standard area:

Figure 11-3 Access List Configuration—IP Standard Tab



IP Standard

The IP Standard area displays five fields:

Access Action—Action to be taken if the conditions are matched. This value will be either deny or permit.

Host Type—Host type indicates the hosts for which the access action are available. Possible values for this field include the following:

- Any—All hosts
- Host Name—Specified host name with wild card bits
- A.B.C.D—Specified IP address with wild card bits
- Host Hostname—Only the specified hostname
- Host A.B.C.D—Only the specified IP address



Note Values are grayed out in the IP Standard area depending upon the Host Type selected.

Host Name—Name of the host (or source of the packet) for which the access action is applicable.


IP Address—IP address of the host (or source of the packet) for which the access action is applicable.

Wild Card—If the access action is applicable for more than one host, then this field should be used as a mask. For example, the wild card 255.255.255.255 effectively represents any.

IP Precedence Tab

The IP Precedence tab appears as follows:

Figure 11-4 Access List Configuration—IP Precedence Tab



The IP Precedence tab contains one area: IP Precedence.

IP Precedence

The IP Precedence area contains three fields:

Mask—If more than one precedence comes into the same classification, mask should be used for classification. Enabling mask enables the precedence bit mask field and disabling mask enables the precedence field.


Precedence—IP precedence to be matched. Possible values are 0 to 7.

Precedence Bit Mask—If more than one precedence comes into the same classification, precedence bit mask should be used. Possible values for this field are 00 to FF.

MAC

The MAC tab appears as follows:

Figure 11-5 Access List Configuration—MAC Tab



The MAC tab contains one area: MAC.

MAC


The MAC area contains one field:

MAC Address—Type in the MAC address for the packets to be classified.

IP Extended Tab

The IP Extended tab displays a single IP Extended area. The IP Extended area is further split into three sub-areas: Dynamic List, Source, and Destination.

Figure 11-6 Access List Configuration Window—IP Extended Tab



IP Extended

The IP Extended area contains two fields:

Access Action—Action to be taken if the conditions are matched. Possible actions are deny and permit.

Protocol Name—Name or number of an IP protocol. Valid protocol number values are 0 to 255. Valid protocol names are as follows:

Table 11-2 Valid Protocol Names

Valid Protocol Names	
ahp	ipinip
eigrp	nos
gre	ospf
icmp	pcp
igmp	pim
igrp	tcp
ip	udp
esp	

Dynamic—Defines the selected access list to be dynamic. Dynamic access lists grant access per user to a specific source or destination host through a user authentication process. You can allow user access through a firewall dynamically, without compromising security restrictions.

Dynamic List

Name—Defines a name for the dynamic list (only available if Dynamic button is selected).

Time Out—Specifies the absolute length of time (in minutes) that a temporary access list entry can remain in a dynamic access list. The default (0) is an infinite length of time and allows an entry to remain permanently (only available if Dynamic button is selected).

Source and Destination

The Source and Destination areas contain the following fields:

Host Type—Indicates the hosts for which the access action are available. Possible values for this field include the following:

- Any—All hosts
- A.B.C.D—Specified IP address with wild card bits
- Host Hostname—Only the specified hostname
- Host A.B.C.D—Only the specified IP address

Host Name—Name of the host (or source of the packet) for which the access action is applicable.

IP Address—IP address of the host (or source of the packet) for which the access action is applicable.

Wild Card—If the access action is applicable for more than one host, then this field should be used as a mask. For example, the wild card 255.255.255.255 effectively represents any.

Port Criteria—Criteria to be applied on the specified port (interface) number. Possible values are as follows:

- None—Port number is insignificant
- Equal To—Equal to the port number
- Not Equal To—Not equal to the port number
- Greater Than—Greater than the port number
- Less Than—Less than the port number
- Range—Port number range

Port

The Port sub-area in the Source and Destination areas contains the following fields:

Number—Port (interface) number from/to where the packet is sent or destined.

Range—Defines which port (interface) numbers will be allowed through this filter.

CAR Policy Apply

The CAR Policy Apply section covers the following areas:


- [Applying a CAR Policy to an Interface](#)
- [Removing a CAR Policy from an Interface](#)
- [Editing or Deleting a CAR Policy](#)
- [CAR Policy Apply Window—Detailed Description](#)

Applying a CAR Policy to an Interface

To apply a CAR policy to an interface, proceed as follows:

- Step 1** Choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS>CAR Policy Apply** from a relevant object icon (in the Map Viewer window or from an object pick list) to launch the CAR Policy Apply window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the CAR Policy Apply window.

Figure 11-7 CAR Policy Apply Window



- Step 2** Choose a **Chassis, Module, and IP Interface** you want to apply the CAR policy to are selected in the list boxes at the left of the window. You can choose multiple chassis, modules, or interfaces if required.
- Step 3** Choose the policy you want to apply (in the Available Policies listbox), and choose the right facing arrow to move that policy into the Required Order box.

Step 4 When you have moved the CAR policy choose **Apply**.



Note If a CAR policy fails to be applied to an interface the Apply Status area on the CAR Policy Apply window (see [Figure 11-7](#)) is updated accordingly.

If the interface is being managed, the selected CAR policy is downloaded to the device.

For more details on the fields within this tab, see [“CAR Policy Apply Window—Detailed Description” section on page 11-20](#).

Removing a CAR Policy from an Interface

To remove CAR policies from an interface, proceed as follows:

- Step 1** Within the CAR Policy Apply window (see [Figure 11-7](#)), ensure that the correct chassis, module, and interface are selected in the list boxes at the left of the window.
- Step 2** Use the directional arrows to move CAR policies from the Required Order list back to the Available Policies list.
- Step 3** Choose **Apply** to apply the changes, removing the selected CAR policies from the interface.


Editing or Deleting a CAR Policy

A CAR policy can only be edited or deleted if it is not currently being applied to an interface. Once you have applied a CAR policy to an interface, you cannot edit or delete it unless you first remove it from the interface. If that CAR policy is being used by any other interface, you will still not be able to edit or delete the CAR policy. For this reason, it is a good idea to note down which interfaces have which CAR policies applied to them. If you keep such a list, if you later want to edit or delete the CAR policy, you can simply remove it from the interfaces that are using it, then proceed to edit the fields within the CAR Configuration window or delete the CAR policy.

To delete an existing CAR policy, proceed as follows:

- Step 1** Choose the CAR policies you wish to delete within the Layer 3 QoS view. See [““Layer 3 QoS View” section on page 2-12”](#) for details of the Layer 3 QoS view.
- Step 2** Choose **Deployment>Delete Objects**. The Deployment Wizard appears with a summary of what will be deleted.

Figure 11-8 Deployment Wizard—Summary



- Step 3 Choose **Finish**, and the CAR policy is deleted. If deletion fails, another interface might be currently using the CAR policy, therefore you cannot delete the object.

CAR Policy Apply Window—Detailed Description

The CAR Policy Apply window has one tab, CAR Policy Apply.

CAR Policy Apply Tab

The CAR Policy Apply tab contains two list boxes and two areas, Actions and Apply Status.

Available Policies—Lists all created CAR Policies that are available to apply to a selected interface.

Required Order—Displays CAR policy that is applied to the selected interface.

Actions

The Actions area displays the following:

Force synchronization—Allows you to choose whether to force synchronization with the selected device or not. Choose Yes to force synchronization or choose No if you do not wish to force synchronization.

Right arrow button (>>)—Allows you to move CAR policies from the Available Policies list to the Required Order list.

Left arrow button (<<)—Allows you to move CAR policies from the Required Order list to the Available Policies list.

Apply button—Allows you to apply the CAR policies listed in the Required Order list to the selected interface.

Apply Status

The Apply Status area contains one field, as follows:

Status of Last Apply—Status of the last CAR policy applied to an interface. This value can be either succeeded or failed.

CAR Policy Status


The CAR Policy Status window displays the CAR policy that is currently applied to a selected interface, and in what order.

Viewing the CAR Policy Status Window

To view the CAR Policy Status window, proceed as follows:

-
- Step 1** Choose the **Cisco 12000/10720 Manager>Fault>Interface>QoS> CAR Policy Status** option from a relevant object icon (in the Map Viewer window or from an object pick list) to launch the CAR Policy Status window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the CAR Policy Status window.

Figure 11-9 CAR Policy Status Window



Step 2 Choose the correct **Chassis**, **Module**, and **IP Interface** from the list boxes at the left of the window.

The Workflow for WRED/DRR

To begin working with WRED objects, the first step is to create and configure a CoS queue group (which includes DRR, or Distributed Round Robin). You can then apply the created CoS queue group to one or multiple interfaces. At a time, only one CoS queue group can be applied to any number of interfaces.

At any given time, you also have the option to edit, delete, or change the association of a CoS queue group.

Engine Type Support for WRED

If an attempt is made to apply a WRED policy to an engine 1 or 3 module, then the request will be refused and an appropriate error message issued to the client. The full range of WRED functionality will be supported for engine 0, 2, 4 and 4+ modules.

CoS Queue Group Configuration

The CoS Queue Group Configuration section covers the following areas:


- [Creating a CoS Queue Group Under WRED](#)
- [Editing an Existing CoS Queue Group](#)
- [Deleting an Existing CoS Queue Group](#)
- [CoS Queue Group Configuration Window—Detailed Description](#)

Creating a CoS Queue Group Under WRED

To create a CoS queue group under WRED, proceed as follows:

- Step 1** Choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS>CoS Queue Group Configuration** from a relevant object icon (in the Map Viewer window or from an object pick list) to launch the CoS Queue Group Configuration window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the CoS Queue Group Configuration window.

Figure 11-10 CoS Queue Group Configuration Window—CoS Queue Group Tab



50676

- Step 2 Choose **Create**.
 - Step 3 Enter the CoS queue group name, then choose **Ok**. A window appears, confirming if the CosQ group creation was successful or not. If successful, the name of your new CoS queue group appears in the list box at the left of the window.
 - Step 4 Modify the parameters in both tabs, as required. See [“CoS Queue Group Configuration Window—Detailed Description”](#) section on page 11-25 for further details.
 - Step 5 Choose **Save** to save the changes.
-

Editing an Existing CoS Queue Group

An existing CoS queue group can only be edited if it is not currently being applied to any interfaces. Once you have applied a CoS queue group to an interface, you cannot edit it unless you remove it from the interface.

To edit an existing CoS queue group, proceed as follows:

- Step 1 Choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS>CoS Queue Group Configuration** from a relevant object icon (in the Map Viewer window or from an object pick list) to launch the CoS Queue Group Configuration window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the CoS Queue Group Configuration window (see [Figure 11-10 on page 11-23](#)).
 - Step 2 Choose the appropriate CoS Queue Group from the list box displayed at the left of the window.
 - Step 3 Modify the parameters in both tabs, as required. See [“CoS Queue Group Configuration Window—Detailed Description”](#) section on page 11-25 for further details.
 - Step 4 Choose **Save** to save the changes.
-


Deleting an Existing CoS Queue Group

An existing CoS queue group can only be deleted if it is currently not applied to any interfaces. Once you have applied a CoS queue group to an interface, you cannot delete it unless you remove it from the interface.

To delete an existing CoS queue group, proceed as follows:

- Step 1 Choose the CoS queue group you wish to delete within the Layer 3 QoS view. See [“Layer 3 QoS View”](#) section on page 2-12.
- Step 2 Choose **Deployment>Delete Objects**. The Deployment Wizard appears with a summary of what will be deleted.

Figure 11-11 Deployment Wizard—Summary



- Step 3** Click **Finish**, and the CoS queue group is deleted. If deletion fails, another interface might be currently using the CoS queue group; therefore, you cannot delete the object.

CoS Queue Group Configuration Window—Detailed Description

The CoS Queue Group Configuration window has two tabs: CoS Queue Group and DRR (Deficit Round Robin).

CoS Queue Group Tab

In the CoS Queue Group tab, you can configure the WRED parameters and the mapping of the IP precedence to the specific WRED profile you wish to use. The CoS Queue Group tab has two areas: IP Precedence and WRED Parameters. The CoS Queue Group tab also has one outside field, as follows:

Exponential Weighting Constant—(numbers 0 to 16) Sets the weight used in calculating the average queue depth for this CoS queue group.

IP Precedence

The IP Precedence area contains a table with two headings: IP Precedence and Drop Label.

IP Precedence—This column allows the user to map packets that have a particular IP precedence to a WRED profile in this CoS queue group. You can map several or all precedences to the same WRED profile if you wish. By default, precedence values are mapped so that they are not dropped due to WRED.

Drop Label—Choose a number, 0 to 6 or no-drop, which is the number of the corresponding drop label in the WRED parameters table.

All—On checking All, the configuration of the first IP precedence is applied to all the Ip precedences.

WRED Parameters

The WRED Parameters area contains a table with four headings: Drop Label, Min Threshold, Max Threshold, and Max Prob Denominator. The last three headings describe the actual WRED curve.

Drop Label—Drop label is a placeholder number for this set of WRED parameters. This is the number you map IP precedence values to.

Min Threshold—When the weighted queue average is below the minimum threshold, no packets are dropped.


Max Threshold—When the weighted queue average is above the maximum queue threshold, all packets are dropped until the average drops below the maximum threshold.

Max Prob Denominator—When the weighted queue average is between the minimum and the maximum thresholds, the probability that the packet is going to be dropped can be calculated by a straight line from the minimum threshold (probability of drop will be 0) to the maximum threshold (probability of drop is equal to the max prob denominator).

DRR Tab

The DRR tab appears as follows:

Figure 11-12 CoS Queue Group Configuration Window—DRR Tab



The DRR tab has two areas: DRR Mapping and DRR Queue. There is also a Low-latency field.

DRR Mapping

The DRR Mapping area allows you to map a particular IP precedence to a regular DRR queue (values 0-6 or low-latency).

DRR Queue

The DRR Queue area allows you to give a relative weight to each DRR queue.

Low-latency—Only applicable for MDRR. This value can be set to one of the following values:

Alternate priority—You must specify a weight in the DRR queue area.

Strict priority—No weight is specified.

None—If low latency is not mapped to any of the IP Precedences in the DRR Queue, then you must set the low latency to none.

WRED Tx Configuration

The WRED Tx Configuration section covers the following areas:


- [Applying a CoS Queue Group to an Interface](#)
- [Removing a CoS Queue Group from an Interface](#)
- [Changing the Association of a CoS Queue Group](#)
- [WRED Tx Configuration Window—Detailed Description](#)

Applying a CoS Queue Group to an Interface

To apply a CoS Queue Group to an interface, proceed as follows:

-
- Step 1** Choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS>WRED Tx Configuration** from a relevant object icon (in the Map Viewer window or from an object pick list) to launch the WRED Tx Configuration window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the WRED Tx Configuration window (see [Figure 11-13 on page 11-29](#)).

Figure 11-13 WRED Tx Configuration Window



- Step 2** Choose the **Chassis**, **Module** and **Interface** to apply the CoS queue group to from the list boxes displayed at the left of the window. More than one Chassis, Module or Interface can be selected at a time.
- Step 3** Choose the correct CoS queue group and highlight it in the Available CoS Queue Group list.
- Step 4** Choose **Apply**. If the interfaces are currently being managed (are commissioned), then the CoS queue group is downloaded to the device and the status in the Associated CoS Queue Group Information area changes to the name of the applied CoS queue group.



Note Once the Layer3 QoS object is applied to the interface object, the instance of the layer3 QoS object is displayed under the interface (to which the Layer QoS is applied) in the Component Managed views.



Note If a CoS queue group fails to be applied to an interface the Apply Status area on the WRED Tx Configuration window (see [Figure 11-13 on page 11-29](#)) is updated accordingly.

Removing a CoS Queue Group from an Interface

To remove an applied CoS queue group from an interface, proceed as follows:

-
- Step 1 In the Layer 3 QoS view, right-click on the desired CoS queue group, then choose **Cisco 12000/10720 Manager>Configuration>QoS>WRED Tx Configuration**. The WRED Tx Configuration window appears (see [Figure 11-13 on page 11-29](#)).
 - Step 2 Choose a Chassis, Module and Interface from the list boxes at the left of the window that contain the CoS queue group that you wish to remove.
 - Step 3 Choose **Remove**.
-

Changing the Association of a CoS Queue Group

To change the association of a CoS queue group, proceed as follows:

-
- Step 1 Right click on a CosQ group object in the Layer3QoS view and choose **Cisco 12000/10720 Manager>Configuration>QoS>WRED Tx Configuration** to launch the WRED Tx Configuration window. See [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the WRED Tx Configuration window (see [Figure 11-13 on page 11-29](#)).
 - Step 2 Choose the Chassis, Module and Interface from the list boxes at the left of the window that contain the interface(s) you want to apply the CoS queue group to. More than one Chassis, Module, and Interface can be selected at a time.
 - Step 3 Choose the CoS queue group you wish to apply.



Note Only one CosQ group can be applied.

- Step 4 Choose **Apply**. Previously applied CoS queue groups are removed and the new CoS queue group is applied.
-

WRED Tx Configuration Window—Detailed Description

The WRED Tx Configuration window displays a single Tx Config tab.

Tx Config Tab

The Tx Config tab displays three areas: Available COS Queue Group, Associated COS Queue Group Information, and Apply Status.

Available COS Queue Group

The Available CoS Queue Group area displays the following fields:

Available COS Queue Group—This list box displays all the available CoS queue groups. You can Apply or Remove a CoS queue group from the selected interface in this pane as well. If the selected interface has a CoS queue group applied to it, that CoS queue group will be highlighted in this box. If the selected interface has no CoS queue group applied to it, the top CoS queue group will be highlighted by default.

Actions

The Available CoS Queue Group area displays an Actions sub-area. The Actions sub-area displays two buttons: Apply and Remove.

Apply—Once you have highlighted the CoS queue group in the Available COS Queue Group list, choose Apply to apply it to the selected interface.

Remove—Once you have selected the interface from which the CosQ group has to be removed, choose Remove.

Associated COS Queue Group Info

Applied COS Queue Group—This field is blank, when no CosQ group is applied to the interface. When a CosQ group is applied, the field displays name of applied CosQ group.

Apply Status

This area displays the status of the last apply action.

WRED ToFab Configuration

The WRED ToFab section covers the following areas:

- [Creating a ToFab Policy](#)
- [Editing an Existing ToFab policy](#)
- [Deleting an Existing ToFab policy](#)
- [WRED ToFab Policy Configuration Window—Detailed Description](#)

Creating a ToFab Policy


A user can create a WRED ToFab policy and associate the policy to line cards across devices. To create a ToFab policy under WRED, proceed as follows:

-
- Step 1** Launch the Map Viewer, and choose the Layer3QoSView. Right click on the WRED-MDRR object and choose **Cisco 12000/10720 Manager>Configuration>Module>ToFab>ToFab Configuration** to launch the ToFab Configuration window. Refer [Table 11-1 on page 11-2](#) for information on different objects that allow you to launch the WRED ToFab Configuration window (see [Figure 11-14 on page 11-33](#)).



Note To associate a ToFab policy to a module, the user must create a CosQ group using the WRED functionality. See [Creating a CoS Queue Group Under WRED](#) for information on creating a CosQ group.

Figure 11-14 ToFab Configuration Window—ToFab Policy Configuration Tab



- Step 2 Click **Create**.
- Step 3 Enter the WRED ToFab policy name, and then choose **Ok**. A window appears, confirming if you were successful or not. The name of your new ToFab policy appears in the list box at the left side of the window.
- Step 4 Modify the parameters as required. See “[WRED ToFab Policy Configuration Window—Detailed Description](#)” section for further details.

Editing an Existing ToFab policy

A ToFab Policy can be edited only if it is not associated to any line card. If the policy is associated to a line card(s), it cannot be edited unless it is disassociated from the line card(s).

To edit an existing ToFab policy, proceed as follows:

- Step 1 Launch the Map Viewer, choose the Layer3QoSView. Right click on the WRED-MDRR object and choose **Cisco 12000/10720 Manager>Configuration >ToFab>ToFab Configuration** to launch the WRED ToFab Configuration window. Refer [Table 11-1 on page 11-2](#) for information on different objects that allow you to launch the WRED ToFab Configuration window
- Step 2 Choose the appropriate ToFab policy from the list displayed at the left side of the window.

- Step 3** Modify the parameters in the ToFab Configuration tab, as required. See [WRED ToFab Policy Configuration Window—Detailed Description](#) for further details.
- Step 4** Click **Save** to save the changes.


Deleting an Existing ToFab policy

A ToFab policy can be deleted only if it is not currently associated to any line cards. If a policy is associated to a line card, it cannot be deleted unless it is disassociated from the line card.

To delete an existing ToFab policy, proceed as follows:

- Step 1** Launch the Map Viewer, and choose the Layer3QoSView. Right click on the WRED-MDRR object and choose **Cisco 12000/10720 Manager>Configuration>ToFab>ToFab Configuration** to launch the WRED ToFab Configuration window. Refer [Table 11-1 on page 11-2](#) for information on different objects that allow you to launch the WRED ToFab Configuration window.
- Step 2** Choose the appropriate ToFab policy from the list displayed at the left side of the window.
- Step 3** Choose **Deployment>Delete Objects**. The Deployment Wizard appears with a summary of what will be deleted.

Figure 11-15 Deployment Wizard—Summary



Step 4 Click **Finish**, and the ToFab policy is deleted.



Note If deletion fails, another module/line card might be currently using the ToFab policy; therefore, you cannot delete the object.

WRED ToFab Policy Configuration Window—Detailed Description

The WRED ToFab Policy Configuration window displays a single ToFab Policy Configuration tab.

ToFab Policy Configuration tab

In the WRED ToFab Policy Configuration tab, the left hand side indicates the ToFab policies available in the device. The right hand side of the tab displays the slot numbers, the available COS-Queue groups and the combination of the Slot-CosQ group configurations.

Slot Table Parameters

On creation of a ToFab policy, the Slot-CosQ Groups listbox is empty. The user needs to choose the slot number to which a CosQ group has to be associated. However, different CosQ groups cannot be associated with the same slot number. The status of the policy indicates the number of modules that are using the current ToFab Policy.

Slot Number—Displays the destination slot number.



Note The number of slots is limited to 16.

CosQ Groups—The user can choose a CosQ group from this list to associate it to a slot.

Actions

Add—To add a Slot-CosQ group combination, choose a slot from the drop down list box and choose the CosQ group to be associated for the slot and then click the Add button. This action results in adding an entry into the ToFab policy in the SlotNumber-COSQueue group name format.

Remove—To remove a Slot-CosQ group combination from the list, choose Remove. This action results in the removal of the Slot-CosQ group combination from the list.

Create—To create a ToFab policy, click Create, a window pops up asking the user to enter the name for the ToFab policy.

Slot-CosQ Groups

The Slot-CosQ group listbox lists the combination of the slots and the respective CosQ groups associated.

WRED Rx Configuration

The WRED Rx Configuration section covers the following areas:


- [Associating a ToFab Policy to a Line card](#)
- [Disassociating a ToFab Policy from a Line card](#)
- [Changing the Association of a ToFab Policy](#)
- [WRED Rx Configuration Window—Detailed Description](#)

Associating a ToFab Policy to a Line card

To associate a ToFab policy to a line card, proceed as follows:

- Step 1** Launch the Map Viewer, and choose the Layer3QoSView. Right click on the WRED-MDRR object and choose **Cisco 12000/10720 Manager>Configuration>ToFab>WRED Rx Configuration** from a relevant object icon to launch the WRED Rx Configuration window. Refer [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the WRED Rx Configuration window.

Figure 11-16 WRED Rx Configuration



- Step 2** Choose the **Chassis** and **Module** to associate the ToFab policy from the list box displayed at the left of the window. More than one Chassis or Module can be selected at a time.
 - Step 3** Choose the ToFab policy in the available ToFab policy list.
 - Step 4** Click **Associate**
-

Disassociating a ToFab Policy from a Line card

To disassociate a ToFab policy from a line card, proceed as follows:

- Step 1** Launch the Map Viewer, choose the Layer3QoSView. Right click on the WRED-MDRR object and choose **Cisco 12000/10720 Manager>Configuration>ToFab>WRED Rx Configuration** to launch the WRED Rx Configuration window. Refer [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the WRED Rx Configuration window.
 - Step 2** Choose the Chassis and Module from the list boxes at the left of the window to which the ToFab policy is associated.
 - Step 3** Click **Disassociate**
-

Changing the Association of a ToFab Policy

To change the association of a ToFab policy to a line card, proceed as follows:

- Step 1** Launch the Map Viewer, choose the Layer3QoSView. Right click on the WRED-MDRR object and choose **Cisco 12000/10720 Manager>Configuration>ToFab>WRED Rx Configuration** to launch the WRED Rx Configuration window. Refer [Table 11-1 on page 11-2](#) for information on which objects allow you to launch the WRED Rx Configuration window.
- Step 2** Choose the **Chassis** and **Module** from the list boxes at the left of the window to which a ToFab policy is associated.
- Step 3** Choose the ToFab policy that you want to associate.
- Step 4** Click **Associate**



Note If a ToFab policy was previously associated with the interface, it is removed and the new ToFab policy is associated.

WRED Rx Configuration Window—Detailed Description

The WRED Rx Configuration window displays a single Rx Configuration Tab.

Rx Configuration Tab

Policy Name—The user can choose the ToFab policy from this list. This list contains all the ToFab policies.

Actions

Associate—Highlight the ToFab Policy in the ToFab list, click **Associate** to apply it to the selected modules.

Disassociate—Choose the chassis and module from the listbox on the left side of the window, click **Disassociate** to remove it from the selected module.

Associated slot—Table Info

The associated ToFab policy is displayed in this area.

Apply Status

This area displays the status of the previous apply action.



Managing ATM Connections

This chapter describes the ATM connections supported by the Cisco 12000/10720 Router Manager application and guides you through the creation and configuration of these connections.



Note

The features described in this chapter are not applicable to the Cisco 10720 Routers.

The Cisco 12000 Series Routers use both terminating Permanent Virtual Circuits (PVCs) and Switched Virtual Circuits (SVCs). A PVC is modeled in Cisco 12000/10720 Router Manager as an object that is deployed beneath an interface. The interface acts as the endpoint. An SVC is modeled in Cisco 12000/10720 Router Manager as an object that is deployed beneath an interface, but it has two endpoints. The remote endpoint can either be a non-Cisco EMF endpoint (which means it is outside Cisco EMF) or a Cisco EMF endpoint (which means it is within Cisco EMF).

SVCs are similar to PVCs in setup; however, they function differently. The PVC is always operating and is always up. On the other hand, the SVC shuts down when it is not in use. It does not cease to exist, but only goes down until traffic occurs, then it re-establishes.



Note

Fields appear on various windows within the Cisco 12000/10720 Router Manager application that are not applicable. In such cases these fields should be ignored. Information detailing the fields that should be ignored are provided in the appropriate sections.

This chapter contains the following information:

- [ATM Connections Supported by Cisco 12000/10720 Router Manager](#)
- [Launching the ATM Connections Windows](#)
- [ATM Connection Synchronization](#)
- [Creating ATM Connections](#)
- [Uploading Existing ATM Connections and QoS Profiles](#)
- [Managing ATM QoS Profiles](#)
- [Deploying ATM Connection Objects](#)
- [Applying an ATM QoS Profile to an ATM Connection](#)
- [ATM PVC Configuration](#)
- [SVC Configuration](#)
- [PVC Status](#)

ATM Connections Supported by Cisco 12000/10720 Router Manager

ATM connections are modeled in Cisco 12000/10720 Router Manager as objects that are deployed beneath an ATM interface. Cisco 12000/10720 Router Manager supports two types of ATM Connection: Terminating Permanent Virtual Circuits (PVCs), and Switched Virtual Circuits (SVCs).



Note

The ATM connections can be viewed only in the Component Managed view.

Both types of ATM connection are now discussed in greater detail.


PVC Connections

A PVC is a permanent logical connection that must be configured from source to destination. PVCs save bandwidth associated with establishing a circuit when a virtual circuit must exist all the time. You can deploy a PVC (which creates the PVC within Cisco EMF), apply an ATM Traffic Descriptor to the PVC, then create the connection on the device. Deploying and creating a PVC creates a cross-connection within one device.

Terminating PVC Connections

A terminating PVC connection object is modeled in Cisco 12000/10720 Router Manager as a single object deployed beneath a ATM interface (see [Figure 12-1](#)). The ATM interface acts as the end point.


Figure 12-1 Terminating PVC Connection



SVC Connections

An SVC is modeled in Cisco 12000/10720 Router Manager as an object deployed beneath two interfaces (see Figure 12-2). The remote endpoint can be a non-Cisco EMF endpoint (that is, outside Cisco EMF) or a Cisco EMF-endpoint (that is, within Cisco EMF). Deploying and creating an SVC creates a connection between the outgoing port (or source) on one device and the incoming port (or destination) on a second device.

Figure 12-2 SVC Connection



SVCs are similar to PVCs in setup; however, they function differently. The PVC is always operating and is always up. On the other hand, the SVC shuts down when it is not in use. It does not cease to exist, but only goes down until traffic occurs, then it re-establishes again. The SVC saves bandwidth as opposed to the PVC, but is generally slower in operation.

Launching the ATM Connections Windows

Table 12-1 displays each object type that can be used to open the Cisco 12000/10720 Router Manager windows that allow you to upload, create and configure ATM connections.



Note

Table 12-1 lists the menu options to launch the ATM Connections dialogs from the site level.

For example, the ATM QoS Profiles Configuration window can be launched from a Site, Chassis, Module and interface object.

Table 12-1 Launching the ATM Connection Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
ATM Connection Upload	Yes	Yes	No	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>Upload ATM Connections
ATM QoS Profile Configuration	Yes	Yes	No	Yes	Yes	Cisco 12000/10720 Manager>Configuration>Interface>QoS>ATM QoS Profile Configuration
ATM QoS Profile Management	Yes	Yes	No	Yes	Yes	Cisco 12000/10720 Manager>Configuration>Interface>QoS>ATM QoS Profile Management
ATM SVC Configuration	Yes	Yes	No	Yes	Yes	Cisco 12000/10720 Manager>Configuration>Interface>ATM>SVC Configuration
ATM VCL Configuration	Yes	Yes	No	Yes	Yes	Cisco 12000/10720 Manager>Configuration>Interface>ATM>VCL Configuration
ATM VCL Status	Yes	Yes	No	Yes	Yes	Cisco 12000/10720 Manager>Fault>Interface>ATM>Connection Status

ATM Connection Synchronization

The idea behind the ATM Connection Synchronization is to provide a mechanism to update the ATM connection details stored in the Cisco EMF from the current configuration on a device. This is necessary if the device is updated, for e.g., if a new ATM connection is added (or removed) then the Cisco EMF should be able to re-read from the device and update the Cisco EMF by creating new objects if necessary.

The Synchronization process is initiated in the following circumstances:

- Every time the chassis is commissioned.
- When the chassis loses connectivity and again establishes connection with the device.
- Changes to device configuration made via SNMP requests from a source other than Cisco 12000/10720 Router Manager.
- Changes to device configuration made via IOS CLI requests from a source other than the one that has the Cisco 12000/10720 Router Manager running.

- Data has been provisioned onto the device via Cisco 12000/10720 Router Manager but a Write Mem has not been performed. The device then reboots. The newly provisioned data is modeled in Cisco 12000/10720 Router Manager but not on the device.
- Auto synchronization is initiated automatically every 30 minutes on the device.

The policies that are available for ATM connection synchronization are described in the [Table 12-2](#).

Table 12-2 ATM Connection Synchronization Policies

Policy Name	Value
Normal	0
Device_is_Master (default policy)	1
CEMF_is_Master_After_First_Sync	2

Device_is_Master (default policy)

The Device_is_Master policy creates new PVC connection objects in the EM, for the connections available on the device. In case connection object that is available in the EM is removed from the device, then the Device_is_Master policy moves the connection object into the decommissioned state during the next synchronization. If the same object with the same configuration details is again added to the device, the Device_is_Master policy identifies the object and moves it to the normal state. However if a new connection object is added to the device with different configuration details, then the Device_is_Master policy creates the connection object in the EM and moves it to the normal state. The ATM Connection synchronization never deletes any ATM connection object.

Syntax for Set:

```
cd <CEMF_ROOT>/bin
./objectUtilsTestRig setIntValue "ComponentManaged:<absolute-path of the chassis>"
ciscoPlatformCon:CiscoChassis-MIB.DeleteConnections 0
```

For policy information, see [Table 12-2](#)

```
./objectUtilsTestRig setIntValue "ComponentManaged:<absolute-path of the chassis>"
ciscoPlatformCon:CiscoChassis-MIB.DeleteConnections 1
```

For policy information, see [Table 12-2](#)

```
./objectUtilsTestRig setIntValue "ComponentManaged:<absolute-path of the chassis>"
ciscoPlatformCon:CiscoChassis-MIB.DeleteConnections 2
```

For policy information, see [Table 12-2](#)

Syntax for Get:

```
./objectUtilsTestRig getAttrValue "ComponentManaged:<absolute-path of the chassis>"
ciscoPlatformCon:CiscoChassis-MIB.DeleteConnections
```

Table 12-3 DevicelsMaster Policy

VCL in Cisco EMF	VCL State	VCL on Device	Behavior
Present	Normal	Not Present	Remove from Cisco EMF

Table 12-3 *DevicesMaster Policy (continued)*

VCL in Cisco EMF	VCL State	VCL on Device	Behavior
Present	Decommission	Not Present	Remove from Cisco EMF
Present	Normal	Present	Do not do anything
Present	Decommission	Present	Change state to Normal
Not Present	N/A	Present	Create in Cisco EMF
Not Present	N/A	Not Present	N/A

Normal Policy

This setting specifies that the Cisco device is the reference point for PVC creations and deletions. Cisco 12000/10720 Router Manager will sync up to the device. If a connection is present on the Cisco device but not in Cisco 12000/10720 Router Manager, it will create the connection. If a connection is absent on the Cisco device but present in Cisco 12000/10720 Router Manager, it will delete the connection.

Table 12-4 *Normal Policy*

VCL in Cisco EMF	VCL State	VCL on Device	Behavior
Present	Normal	Not Present	Change state to decommission
Present	Decommission	Not Present	Do not do anything
Present	Normal	Present	Do not do anything
Present	Decommission	Present	Change state to Normal
Not Present	N/A	Present	Create in Cisco EMF
Not Present	N/A	Not Present	N/A

CEMF_is_Master_After_First_Sync

This setting specifies that Cisco 12000/10720 Router Manager is the reference point for PVC creations and deletions, after the first synchronization. The device syncs up to the Cisco 12000/10720 Router Manager for information about PVC settings. If the connection is present in Cisco 12000/10720 Router Manager but not the Cisco device and the state of the VCL connection is Normal, Cisco 12000/10720 Router Manager creates the connection in the Cisco device. If the connection is absent in Cisco 12000/10720 Router Manager but present in the Cisco device, Cisco 12000/10720 Router Manager deletes the connection from the Cisco device.

Table 12-5 *CemflsMasterAfterFirstSync Policy*

VCL in Cisco EMF	VCL State	VCL on Device	Behavior
Present	Normal	Not Present	Create in Device
Present	Decommission	Not Present	Do not do anything
Present	Normal	Present	Do not do anything
Present	Decommission	Present	Remove it from device

Table 12-5 CemflsMasterAfterFirstSync Policy (continued)

VCL in Cisco EMF	VCL State	VCL on Device	Behavior
Not Present	N/A	Present	Remove it from device
Not Present	N/A	Not Present	N/A

Creating ATM Connections

To create a PVC or SVC, proceed as follows:

1. Upload any existing ATM connections and QoS (Quality of Service) profiles, if available (for details, see [“Uploading Existing ATM Connections and QoS Profiles”](#) section on page 12-7) or
2. Create an ATM QoS profile, when required (see [“Managing ATM QoS Profiles”](#) section on page 12-12 for further details):
 - a. Deploy (create) the PVC or SVC in the CEMF, using the Deployment Wizard (for details, see [“Deploying a PVC Object”](#) section on page 12-18 or [“Deploying an SVC Object”](#) section on page 12-22). This process creates the PVC or SVC in Cisco EMF only; it does not create the connection on the device.
 - b. Apply the QoS profile to the PVC or SVC (for details, see [“Applying an ATM QoS Profile to an ATM Connection”](#) section on page 12-28).
 - c. Configure the fields for the PVC or SVC, including layer 2 information (for details, see [“ATM PVC Configuration”](#) section on page 12-30 or the [“SVC Configuration”](#) section on page 12-37). You can then create the connection on the device by commissioning the PVC or SVC for management.

Uploading Existing ATM Connections and QoS Profiles

This section describes how to upload existing ATM connections and profiles (previously configured on a Cisco device) into the Cisco 12000/10720 Router Manager application. Uploading saves time and effort re-configuring ATM connections and profiles that already exist on the device.

When you upload PVCs, any corresponding ATM QoS profiles are also uploaded. PVCs are discovered and placed into the normal state, so that management of these connections begins automatically. Once these connections and/or profiles are uploaded, you can view and adjust them within Cisco 12000/10720 Router Manager. Existing ATM connections and QoS profiles are uploaded from the ATM Connection Upload window.



Note

The processes of uploading ATM connections and synchronizing the connections function in a similar manner to upload the existing ATM connections and QoS profiles. So, any policy set for synchronization (i.e. Normal, Device_is_Master, or CEMF_is_Master_after_first_sync) is applicable to Upload as well. Refer [ATM Connection Synchronization](#) section for details on policy setting for ATM Connection Synchronization.

Naming Convention for the Uploaded Connection Objects

The ATM Connection Upload queries the device for the VPI and VCI values of the PVCs through the MIBs and simultaneously, it telnets to the device to query the names of the PVCs for creating the connection objects in the EM. Hence, if the management passwords are not configured in the EM, then the names for the connection objects cannot be retrieved by the EM.

The naming conventions that are followed for the connection objects during upload can be by,

- Configuring the Management password information, or
- Without configuring the Management password information.

Configuring the Management Password Information

When the Management password information is set, the naming convention followed for the PVCs is different. In this scenario, if any PVC is created in the device, it is represented in the EM in accordance with the value set in the management information window. For example, for a named PVC, ciscoPVC1 and for an unnamed PVC, it would be displayed as VCL_7-0_30.75

Without configuring the Management Password Information


When an ATM Connection upload is initiated, all the connections in the device are uploaded to the EM and the PVCs would be named as VCL_interface_vpi.vci (ex: VCL_7-0_30.75). In this case, the PVC names are ignored, if any PVCs are created with the name specified in the device.



Note

All the PVCs are represented by this convention in the EM.

Figure 12-3 Example of PVC Naming conventions



The Uploading PVCs and ATM QoS Profiles section covers the following areas:


- [Viewing the ATM Connection Upload Window](#)
- [Uploading Existing ATM Connections and ATM QoS Profiles](#)
- [ATM Connection Upload Window—Detailed Description](#)

Viewing the ATM Connection Upload Window

To open the ATM Connection Upload window, proceed as follows:

- Step 1** Right-click a chassis object, then choose **Cisco 12000/10720 Manager>Configuration>Chassis>Upload ATM Connections**. The ATM Connection Upload window appears.

Figure 12-4 ATM Connection Upload Window



Note See “[ATM Connection Upload Window—Detailed Description](#)” section on page 12-11 for further information on the fields displayed in the ATM Connection Upload window.

- Step 2** Choose a **Chassis** from the list displayed at the left of the window.



Note The ATM Connection Upload window displays the values of the attributes for the chassis object selected first when multiple chassis objects are selected in the list at the left of the window.

Uploading Existing ATM Connections and ATM QoS Profiles


Note


Only PVC connections can be uploaded (SVC upload is not available).

ATM connections (PVC only) and ATM QoS profiles can be uploaded using the ATM Connection Upload window. When you upload, existing ATM connections are discovered and placed into the Normal state. This allows management of the connections to begin automatically in the Cisco 12000/10720 Router Manager application. Once these connections/profiles are uploaded, you can view and reconfigure them (if necessary) using the Cisco 12000/10720 Router Manager application.

To upload ATM connections and ATM QoS profiles, proceed as follows:


- Step 1** Open the ATM Connection Upload window. See [“Viewing the ATM Connection Upload Window” section on page 12-9](#) for further details.
- Step 2** Choose a Chassis from the list displayed at the left of the window.
- Step 3** Choose **Upload**. A pop-up dialog appears asking you to confirm that you wish to upload.

Figure 12-5 Upload Confirmation Window



- Step 4** Choose **Yes** to upload. All ATM connections and ATM QoS profiles currently configured on the selected device are uploaded into Cisco 12000/10720 Router Manager. Upload Progress and Upload Status is displayed in the Upload area.

Figure 12-6 ATM Connection Upload Window (After Upload)



Uploaded ATM connections and ATM QoS profiles are named according to the following formats:

- ATM connections—*PVC* - ("VCL_index_VPI.VCI", for example VCL_10.20) or Named PVC.
- ATM QoS Profiles—*QoSProfile_(assigned number)*.

Step 5 Choose **Save** from the **File** menu to save your changes.

Step 6 Choose **Close** from the **File** menu to close the window.

ATM Connection Upload Window—Detailed Description

The ATM Connection Upload window displays a single Connection Upload tab.



Note

The ATM Connection Upload window displays the values of the attributes for the chassis object selected first when multiple chassis objects are selected in the Chassis list at the left of the window.

Connection Upload Tab

The Connection Upload tab contains a single Upload area.

Upload

Upload Progress—Progress of the upload operation.

Upload Status—Upload status messages for the first selected chassis.

Upload—Choose one or more chassis and choose **Upload** to initiate the upload of the ATM connections and QoS profiles from all the selected chassis.

Managing ATM QoS Profiles

The ATM QoS Profile Configuration window allows you to create and save ATM QoS profiles. ATM QoS profiles are stored in Cisco 12000/10720 Router Manager and the associated fields are created on the device when the connection (PVC or SVC) is created.



Note

ATM QoS profiles can only be edited when they are not applied, that is, if any connections are using the profile, you cannot edit the profile. You can view which specific connections are using a certain profile by running a Cisco EMF query against the profile name (see *Cisco Element Management Framework User Guide* for further details).

This section covers the following areas:


- [Creating ATM QoS Profiles](#)
- [Editing an ATM QoS Profile](#)
- [Deleting an ATM QoS Profile](#)
- [ATM QoS Profiles Configuration Window—Detailed Description](#)

Creating ATM QoS Profiles

To create ATM QoS profiles, proceed as follows:

- Step 1** Right-click on an interface, then choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS> ATM QoS Profile Configuration**. See [Table 12-6 on page 12-18](#) for information on the objects that allow you to launch the ATM QoS Profiles window.

Figure 12-7 ATM QoS Profiles Configuration Window—Profile Tab



See “ATM QoS Profiles Configuration Window—Detailed Description” section on page 12-17 for further details.



Note To create a profile based on an existing profile, click the profile you want to model from the profile list box at the left of the window.

Step 2 Choose **Create Profile**. A Prompt window appears for you to enter the name of your new profile.

Figure 12-8 Prompt Window




Step 3 Enter a name for the new profile.



Note Each profile created must have a unique name. Do not insert spaces into a profile name.

- Step 4** Click **Ok**.. The ATM QoS Profiles Configuration window reappears with the new profile name displayed in the QoS Profiles list at left-hand-side of the window.
- Step 5** Complete the fields in the Profile tab as required.
- Step 6** Choose the RxTx Parameters tab and configure the fields as applicable.

Figure 12-9 ATM QoS Profiles Configuration Window—RxTx Parameters Tab



Not applicable for PVCs

- Step 7** Click **Save** to save your changes.
- Step 8** Choose **Close** from the **File** menu to close the window.

Editing an ATM QoS Profile



Note

An existing ATM QoS profile can only be edited if it is not currently applied to an interface. Once you have applied a QoS profile to an interface, you cannot edit it (unless you remove it from the interface first). If that QoS profile is being used by any other interfaces, you will still not be able to edit or delete the QoS profile. If you want to view the connections that are using a specific profile, run a Cisco EMF query against the profile name (for details, refer to the *Cisco Element Management Framework User Guide*). Once you have removed a QoS profile from all interfaces, you can proceed to edit the fields within the ATM QoS Profiles Configuration window or delete the selected QoS profile.

To edit an existing ATM QoS Profile, proceed as follows:

-
- Step 1** Right-click on an interface, then choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS> ATM QoS Profile Configuration**. See [Table 12-6 on page 12-18](#) for information on the objects that allow you to launch the ATM QoS Profiles window.
 - Step 2** Choose the profile you wish to edit from the list of existing profiles displayed in the list at the left of the window.
 - Step 3** Edit the fields displayed in the tabs, as required.
 - Step 4** Choose **Save** from the **File** menu to save the changes made to the profile.
 - Step 5** Choose **Close** from the **File** menu to close the window.
-

Deleting an ATM QoS Profile




Note

An existing ATM QoS profile can only be deleted if it is not currently applied to any interfaces. Once you have applied a QoS profile to a connection, you cannot edit or delete it unless you remove it from the connection. If that QoS profile is being used by any other connections, you will still not be able to edit or delete the QoS profile. If you want to view the connections that are using a specific profile, run a Cisco EMF query against the profile name (refer to the *Cisco Element Management Framework User Guide* for details). Once you have removed a QoS profile from all connections, you can proceed to edit the attributes within the QoS Configuration window or delete the selected QoS profile.

To delete an existing ATM QoS profile, follow these steps:


-
- Step 1** Right-click on an interface, then choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS> ATM QoS Profile Configuration**. See [Table 12-6 on page 12-18](#) for information on the objects that allow you to launch the ATM QoS Profiles window.
 - Step 2** Choose the profile you wish to delete from the list of existing profiles displayed in the QoS Profiles list.
 - Step 3** Right click on the profile and choose **Deployment>Delete Objects**. The Deployment Wizard - Summary window appears (see [Figure 12-10](#)).

Figure 12-10 Deployment Wizard—Summary Window



- Step 4 Click **Finish** to delete the selected profile. An Information window appears to confirm that the profile has been deleted.

Figure 12-11 Information Window



- Step 5 Click **Ok**.
When a profile is deleted it disappears from the list of existing profiles displayed in the QoS Profiles list.

ATM QoS Profiles Configuration Window—Detailed Description

The ATM QoS Profiles Configuration window displays two tabs: Profile and RxTx Parameters.

Profile Tab

The Profile tab contains the following fields:

Profile Type—Enter the type of profile you are creating. This is the level of service, for example, gold service or bronze service.

Profile Description—Enter a description for this profile. Use the horizontal and vertical scroll tools to view text not displayed in the window.

RxTx Parameters Tab

It is possible to choose a Service Category that is not supported, for example,ubr. However, this will be detected when an attempt is made to create the connection on the device & the operator informed. Also, Transmit & Receive are applicable to SVCs. Only Transmit is applicable for PVCs. The RxTx Parameters tab contains the Receive and Transmit Parameters for the selected ATM QoS profile.

The RxTx Parameters tab displays three areas: Category, Receive Parameters (applicable on the EM only for SVCs), and Transmit Parameters.

Category

The Category area contains one field, as follows:

QoS—Service category of the selected QoS profile.

Transmit Parameters

The Transmit Parameters area contains the following fields:

CLP (Cell Loss Priority)—Not applicable to Cisco 12000/10720 Router Manager.

SCR (Sustainable Cell Rate)—Maximum sustained-cell-rate (scr) traffic parameter that is allowed for connections.

PCR (Peak Cell Rate)—Maximum transmitting rate of cells.

MCR (Minimum Cell Rate)—Lowest acceptable transmitting rate (specified in cells per second) for connections.

MBS (Maximum Burst Cell Size)—Maximum burst cell size permitted by cells of connections.

CDVT (Cell Delay Variation Tolerance)—Cell delay variation estimated to be experienced by cells of connections.

Deploying ATM Connection Objects

This section describes how to deploy ATM connection objects (that is, PVC and SVC objects).

Table 12-6 Deployment Launch Points

Object Type to be Deployed	Launch Point to Deploy Object(s) From					Menu Options to Launch Deployment Wizard
	Views	Site	Chassis	Module	ATM Interface	
PVC	No	No	Yes	Yes	Yes	Deployment>Cisco 12000/10720 Manager>ATM Connections>PVC
SVC	No	No	Yes	Yes	Yes	Deployment>Cisco 12000/10720 Manager>ATM Connections>SVC

See “[ATM Connections Supported by Cisco 12000/10720 Router Manager](#)” section on page 12-2 for further details on the PVC and SVC connections supported by the Cisco 12000/10720 Router Manager application.

Deploying a PVC Object




Tip

PVC and VCL are interchangeable terms in Cisco 12000/10720 Router Manager.

You can deploy a PVC under a main interface or a subinterface. To deploy a PVC object, proceed as follows:


- Step 1** Right-click on a selected line card or physical interface, then choose **Deployment>Cisco 12000/10720 Manager>ATM Connections>PVC**. The Deployment Wizard appears.

Figure 12-12 Deployment Wizard—Templates



- Step 2** Choose the template you wish to use, either: Cisco PVC under ATM EndPoint or Cisco PVC under ATM EndPoint on Sub Interface, and choose either auto named or user named (for details on auto vs. user named, see [“Manually Deploying Modules”](#) section on page 3-30). Make sure your selection is highlighted before clicking **Forward**.


Figure 12-13 Deployment Wizard—Object Parameters



- Step 3** Enter the number of PVC connections you want to create.
- Step 4** Enter a profile name for the PVC object.
- Step 5** Enter the Subscriber ID for the PVC object.


- Step 6 Enter the VPI and VCI values for the PVC object.
- Step 7 Enter either 0 or 1 to disable or enable the Auto Allocate Source for the PVC object.
- Step 8 Enter either 0 (no) or 1 (yes) to auto connect the PVC object to the device.
- Step 9 Enter the start number for the PVC object. This number is included in the PVC name.
- Step 10 Click **Forward** to proceed.

Figure 12-14 Deployment Wizard—Object Parameters




- Step 11 Choose **Select**. An Object Selector window appears.

Figure 12-15 Object Selector Window



- Step 12** Navigate down the hierarchy until you find the interface you wish to deploy the PVC under. Click on the object to select, then click **Apply**. You are returned to the window (Figure 12-14 on page 12-20).

Figure 12-16 Deployment Wizard—Summary




- Step 13** Click **Finish** if the deployment summary information is correct. The Deployment Wizard closes and the object is created under the selected interface.

Deploying an SVC Object


To deploy a SVC object on a main interface, proceed as follows:

- Step 1** In the Map Viewer, within the Cisco 12000/10720 Router Manager view, right-click on a selected line card, then choose **Deployment>Cisco 12000/10720 Manager>ATM Connections>SVC**. The Deployment Wizard appears.


Figure 12-17 Deployment Wizard—Templates



- Step 2** Choose a template, either an SVC with a Cisco EMF end point or an SVC with a non-Cisco EMF end point, and choose either auto named or user named (for details on auto vs. user named, see [“Manually Deploying Modules”](#) section on page 3-30). Make sure your selection is highlighted before clicking **Forward**. Click **Forward** to proceed.


Figure 12-18 Deployment Wizard—Object Parameters

- Step 3** Enter the number of SVC connections you want to deploy.
- Step 4** Enter the suffix start number.
- Step 5** Click **Forward** to proceed.

Figure 12-19 Deployment Wizard—Object Parameters


- Step 6** Enter the profile name of the SVC object.
- Step 7** Enter the destination NSAP address for the SVC object.
- Step 8** Enter either 0 (no) or 1 (yes) to auto connect the SVC object to the device.
- Step 9** Click **Forward** to proceed.

Figure 12-20 Deployment Wizard—Views




Step 10 Choose **Select** to open the object selector window.

Figure 12-21 Deployment Wizard—Object Selector




- Step 11** Navigate down the hierarchy until you find the interface which will be the local endpoint. Click on the object to select, then click **Apply**.

Figure 12-22 Deployment Wizard—Object Parameters

- Step 12** When you have selected the appropriate interfaces or sub-interfaces for both endpoints (if applicable), You are returned to the window above. If you have selected the Cisco EMF endpoint option, you need to repeat this process for the second interface (remote endpoint) by clicking the second **Select** button.
- Step 13** Click **Forward** to proceed.

Figure 12-23 Deployment Summary



- Step 14 Click **Finish** if the Deployment Summary information is correct. Click **Cancel** to stop the deployment. The Deployment Wizard closes and the object is created under the selected interface.

Applying an ATM QoS Profile to an ATM Connection


Now you can apply the ATM QoS Profile you created earlier to a PVC or an SVC. To view the ATM QoS Profiles Management window, proceed as follows:

- Step 1 Right-click on the interface that contains the created ATM connection, then choose **Cisco 12000/10720 Manager>Configuration>Interface>QoS>ATM QoS Profile Management**. The ATM QoS Profiles Management window appears.



Note Profiles can be applied to PVC/SVC that are in the decommissioned state.

Figure 12-24 ATM QoS Profiles Management—Profile Tab



- Step 2** Choose a **Chassis, Module, Interface,** and **Connections** (PVC or SVC) from the list box at the left of the window. This connection should be the PVC or SVC that you want to apply the ATM QoS profile to. Any current ATM QoS profiles applied to the selected PVC or SVC appear in the tabs at right.
- Step 3** Choose **Edit > Apply Profile**. A list of ATM QoS profiles appear. Click the named ATM QoS profile you want to apply. After you apply the profile, a status line appears in the lower left corner of the window, telling you if the profile was applied successfully or not. The information for the selected new profile appears in the tabs.

ATM PVC Configuration

The PVC Configuration section covers the following areas:


- [Viewing the ATM VCL Configuration Window](#)
- [Connecting or Disconnecting a PVC](#)
- [Decommissioning or Re-Commissioning a PVC](#)
- [ATM OAM Ping](#)
- [ATM VCL Configuration Window—Detailed Description](#)

Viewing the ATM VCL Configuration Window

To view the ATM VCL Configuration window, proceed as follows:

- Step 1** Right-click on a selected interface, then choose **Cisco 12000/10720 Manager>Configuration>ATM>VCL Configuration**. The ATM VCL Configuration window appears, with the Configuration tab displayed.

Figure 12-25 ATM VCL Configuration Window—Configuration Tab



Not applicable to Cisco 12000/10720 Router Manager

- Step 2** Choose the **Chassis, Module, Interface, and Cisco VCL (PVC)** from the list boxes at the left of the window.

- Step 3** Configure the fields in both tabs, using the drop-down lists and data entry boxes. For a detailed description of the fields within both tabs, see “[ATM VCL Configuration Window—Detailed Description](#)” section on page 12-34.
- Step 4** Click the **Save** icon to save the changes made.


Connecting or Disconnecting a PVC

You can connect or disconnect a PVC in the Layer 3 Configuration tab.

Connecting a PVC creates the PVC on the device, which makes it a real, working connection. The PVC is also commissioned at this time, which allows you to manage configuration and status details.

Disconnecting a PVC disconnects the connection entirely from the device.

Figure 12-26 ATM VCL Configuration Window—Layer 3 Configuration Tab



- Make sure that the Cisco VCL (PVC) you want to connect or disconnect is selected in the list box at the left of the window.
- Click **Connect** or **Disconnect** in the Action area.

Decommissioning or Re-Commissioning a PVC

When you connect a PVC, it is automatically commissioned as well. Decommissioning does not disconnect the PVC.

To decommission a connected PVC:

- Make sure that the PVC you want to decommission is selected in the list boxes at the left of the window. You can choose multiple PVCs if desired.
- Click the **Decommission** button in the Action area.

Once you have decommissioned a connected PVC, you might want to commission it again. To re-commission a PVC, simply click **Connect** and the connection is commissioned.

ATM OAM Ping

The ATM OAM Ping feature is used to send an Operation, Administration, and Maintenance (OAM) packet to verify Permanent Virtual Circuit (PVC) connectivity. The status of the PVC is displayed when a response to the OAM packet is received. The ATM OAM Ping feature supports interactive ping functionality.

This feature provides two ATM OAM ping options:

- End loopback—Verifies the end-to-end PVC integrity.
- Segment loopback—Verifies the PVC integrity to the neighboring ATM device.




Note

A PVC must already be configured for the virtual path identifier (VPI) and virtual channel identifier (VCI) values.

To initiate an ATM OAM Ping, proceed as follows:


- Step 1** Right-click on a selected interface, then choose **Cisco 12000/10720 Manager>Configuration>ATM>VCL Configuration**. The ATM VCL Configuration window appears, with the Configuration tab displayed. Click on the OAM Ping tab.
- Step 2** Enter valid values for the Timeout and Repeat Count fields. Select the End Loopback type and click **Ping**.

Figure 12-27 ATM VCL Configuration—OAM Ping tab




Step 3 An action report summarizing the ping operation is displayed.

Figure 12-28 Action Report



Step 4 The status of the ping operation is also displayed in the Last Ping Status area in the OAM Ping tab.

Figure 12-29 OAM Ping Tab after Ping operation



ATM VCL Configuration Window—Detailed Description

The ATM VCL Configuration window (see [Figure 12-25](#)) contains three tabs: Configuration Layer 3 Configuration and OAM Ping.

Configuration Tab

The Configuration tab (see [Figure 12-25](#)) contains four areas: VPI/VCI, Traffic Information, Encapsulation Parameters, and OAM Information.

VPI/VCI

The VPI/VCI area allows you to configure the following fields:

VPI—Current VPI values for the PVC

VCI—Current VCI values for the PVC

Traffic Information

The Traffic Information area is not applicable to Cisco 12000/10720 Router Manager.

Encapsulation Parameters

The Encapsulation Parameters area is not applicable to Cisco 12000/10720 Router Manager.

OAM Information

The OAM Information area is not applicable to Cisco 12000/10720 Router Manager.

Layer 3 Configuration Tab

The Layer 3 Configuration tab (see [Figure 12-26](#)) contains the following areas:

- VCL Config
- Interface
- VCL Parameters
- VPI/VCI (including Auto Suggestion feature)
- Subscriber
- OAM Parameters
- Actions

VCL Config

The VCL Config area contains one field:

Encapsulation—The following values can be selected for this field:

- None—No encapsulation is selected.
- ILMI—Used for setting up an ILMI PVC in an SVC environment. In an SVC environment, you must configure a PVC for communication with the ILMI so that the router can receive SNMP traps and new network prefixes.
- Qsaal—This signaling PVC can only be set up on ATM main interfaces, not on ATM sub-interfaces.

Interface

The Interface area contains one field:

Sub-Interface Number—The subinterface number under which this PVC is deployed.

VCL Parameters

The VCL Parameters area contains the following fields:

AAL5 Encapsulation—Configure the ATM adaptation layer (AAL) 5 encapsulation type.

Destination IP Address—Enter the IP address of the destination interface to which you want to pass traffic.

Broadcast—Choose yes if you want to send duplicate broadcast packets for all protocols configured on a PVC.

VPI/VCI

The VPI/VCI area contains one field:

Auto Suggestion—If you enable auto suggestion, Cisco 12000/10720 Router Manager automatically suggests VPI or VCI values for you.

Subscriber

The Subscriber area contains one field:

Subscriber ID—Type in your subscriber ID.

OAM Parameters

The OAM Parameters area contains the following fields:

Manage—If this value is set to yes, then the value in frequency will be considered.

Frequency—Specify the frequency (in seconds) that end-to-end OAM loopback cells should be transmitted when a change in up or down state is being verified.

Retry Down Count—Specify the number of consecutive end-to-end OAM loopback cell responses that are not received in order to tear down a PVC.

Retry Up Count—Specify the number of consecutive end-to-end OAM loopback cell responses that must be received in order to change a PVC connection state to up.

Retry Frequency—If a PVC is up and a loopback cell response is not received after the specified frequency attribute, then loopback cells are sent at the retry frequency to verify whether or not the PVC is down.

Autodetect—If the value is set to yes, initiates auto-detection of the peer OAM command cells.

Optimum—If the value is set to yes, configures an optimum mode so that when the traffic monitoring timer expires, the PVC sends an OAM command cell at the locally configured frequency instead of going into Retry mode immediately. If there is no response, the PVC goes into Retry mode.

Actions

The Action area contains three buttons:

Connect—Allows you to connect the selected PVC, creating the connection on the device, making it real and active.

Disconnect—Allows you to disconnect the selected PVC, disconnecting the connection on the device, making it inactive.

Decommission—Allows you to decommission the selected PVC.

OAM Ping Tab

The OAM Ping tab displays an area, OAM Ping Parameters.

OAM Ping Parameters

Timeout in seconds—Timeout interval. The default value is set to two seconds.

Repeat Count—Number of ping packets that are sent to the destination address. The default value is set to five.

Loopback—The type of the ATM OAM Ping options. The available values are: end-loopback and seg-loopback.

Last Ping Result—Status after the last ping operation for the selected PVC.

Action

Ping—Invokes the OAM ping operation.

SVC Configuration

The SVC Configuration section covers the following areas:


- [Viewing the SVC Configuration Window](#)
- [Connecting or Disconnecting an SVC](#)
- [Decommissioning or Recommissioning an SVC](#)
- [SVC Configuration Window—Detailed Description](#)

Viewing the SVC Configuration Window

To view the SVC Configuration window, proceed as follows:

- Step 1** Right-click on a selected interface, then choose **Cisco 12000/10720 Manager>Configuration> ATM> SVC Configuration**. The ATM SVC Configuration window appears, with the Configuration tab displayed.

Figure 12-30 ATM SVC Configuration Window—Configuration Tab



- Step 2** Choose the **Chassis, Module, Interface, and Connections (SVC)** from the list boxes at the left of the window.
- Enter the relevant values in the tab, using the drop-down lists and data entry boxes. For a detailed description of the fields within this tab, see [“SVC Configuration Window—Detailed Description” section on page 12-38](#).
- Step 3** Click the **Save** icon to save the changes made.
-

Connecting or Disconnecting an SVC

Connecting an SVC creates the SVC on the device and makes it a real, working connection. The SVC is also commissioned at this time, which allows you to manage configuration and status details.

Disconnecting an SVC disconnects the connection entirely from the device.

To connect or disconnect an SVC:

- Make sure that the SVC you want to connect or disconnect is selected in the list boxes at the left of the window.
- Click the **Connect** or **Disconnect** button in the Action area.

Decommissioning or Recommissioning an SVC

When you connect an SVC, it is automatically commissioned as well. Decommissioning does not disconnect the SVC.

To decommission a connected SVC:

- Make sure that the SVC you want to decommission is selected in the list boxes at the left of the window.
- Click **Decommission** in the Action area. The SVC is placed into the Decommissioned state.

Once you have decommissioned a connected SVC, you might want to recommission it, which re-establishes management on the connection. To recommission a decommissioned SVC, simply click **Connect**.

SVC Configuration Window—Detailed Description

The ATM SVC Configuration window (see [Figure 12-30](#)) contains one tab: Configuration.

Configuration

The Configuration tab contains four areas:

- SVC Parameters.
- VC Parameters.
- OAM Parameters.
- Actions.

SVC Parameters

The SVC Parameters area allows you to configure the following fields:

NSAP Address (Network Service Access Point)—ATM address you need to provide if you are configuring an SVC.

VC Parameters

The VC Parameters area allows you to configure the following fields:

AAL5 Encapsulation—Configure the ATM adaptation layer (AAL) 5 encapsulation type.

Sub Interface Number—The number of sub-interfaces under which you can configure the SVCs

Destination IP Address—Enter the IP address of the destination interface to which you want to pass traffic.

Broadcast—Click on if you want to send duplicate broadcast packets for all protocols configured on a SVC.

Idle Timeout—Specify an interval of inactivity after which any idle SVC on an interface is torn down.

Minimum Rate—In addition to configuring the interval of inactivity, you can optionally specify the minimum rate in kilobits per second (Kbps). This is the minimum traffic rate required on an ATM SVC to maintain the connection.

OAM Parameters

The OAM Parameters area allows you to configure the following fields:

Manage—If this value is set to yes, then the value in frequency will be considered.

Frequency—Specify the frequency (in seconds) that end-to-end OAM loopback cells should be transmitted when a change in up or down state is being verified.

Retry Down Count—Specify the number of consecutive end-to-end OAM loopback cell responses that are not received in order to tear down a PVC.

Retry Up Count—Specify the number of consecutive end-to-end OAM loopback cell responses that must be received in order to change a PVC connection state to up.

Retry Frequency—If a PVC is up and a loopback cell response is not received after the specified frequency attribute, then loopback cells are sent at the retry frequency to verify whether or not the PVC is down.

Action

The Action area contains three buttons:

Connect—Allows you to connect the selected SVC, creating the connection on the device, making it real and active.


Disconnect—Allows you to disconnect the selected SVC, disconnecting the connection on the device, making it inactive.

Decommission—Allows you to decommission the selected SVC.

PVC Status

- Step 1** Right-click on a specified line card, then choose **Cisco 12000/10720 Manager>Fault>Interface>ATM>Connections Status**. The ATM VCL Status window appears.


Figure 12-31 ATM VCL Status Window—Status Tab



Not applicable to Cisco 12000/10720 Router Manager

- Step 2** Choose a **Chassis**, **Module**, **Interface**, and **Cisco VCL (PVC)** from the list boxes displayed at the left of the window. The status information for the selected PVC appears.
- Step 3** Choose the OAM tab to view the state of the OAM cells when the ATM OAM traffic reduction is enabled.

Figure 12-32 ATM VCL Status Window—OAM Tab



93167

ATM VCL Status Window—Detailed Description

The ATM VCL Status window displays two tabs: Status and OAM.

Status tab

The Status tab has four areas: PVC Status, Soft PVC Details, Characteristics, and OAM Details.

PVC Status

The PVC Status area has the following fields:

Operational State—Not applicable to Cisco 12000/10720 Router Manager.

Last Change—Time elapsed after the last status change.

Install Time—Not applicable to Cisco 12000/10720 Router Manager.

Soft PVC Details

The Soft PVC Details area is not applicable to Cisco 12000/10720 Router Manager.

Characteristics

The Characteristics area is not applicable to Cisco 12000/10720 Router Manager.

OAM Details

The OAM Details area is not applicable to Cisco 12000/10720 Router Manager.

OAM tab

The OAM tab has a single area: Auto Detect Statistics.

Auto Detect Statistics

Displays the state of the OAM cells when the ATM OAM traffic reduction is enabled. Table [Table 12-7 on page 12-42](#) displays the various fields displayed in the Auto Detect Statistics area.

Table 12-7 ATM OAM Auto Detect Statistics

Field	Description
Auto Detection Statistics	
ATM OAM AUTO DETECT INIT	Indicates the number of VCs in the initial ATM_OAM_AUTO_DETECT_INIT state.
ATM OAM SENDING MONITORING	Indicates the number of VCs in the ATM_OAM_SENDING_MONITORING state. During this state, the peer VC is sending OAM command loopback cells and the Cisco IOS software is monitoring and also sending OAM command loopback cells.
ATM OAM MONITORING	Indicates the number of VCs in the ATM_OAM_MONITORING state. During this state, the peer is sending OAM command loopback cells and the Cisco IOS software is monitoring the cells. This state can also indicate that transmission of OAM command cells has been switched off.
OAM Loopback Statistics	
DownRetry	ATM OAM loopback cell DownRetry state.
UpRetry	ATM OAM loopback cell UpRetry state.
Verified	ATM OAM loopback cells are verified.
Not Verified	ATM OAM loopback cells are not verified.



Managing VLANs

This chapter describes the VLAN functionality supported by the Cisco 12000/10720 Router Manager application and guides you through the process of creating and configuring VLAN objects. VLANs support logical grouping of network nodes to reduce broadcast traffic and allow more control in implementing security policies.

The main advantages of VLANs are efficient traffic separation and excellent bandwidth utilization. VLANs improve scaling by logically segmenting the physical LAN structure into sub-networks so that the packets are switched between ports within the same VLAN. This proves to be beneficial for security, broadcast containment, and accounting.

The Cisco 12000/10720 Router Manager facilitates the configuration of VLANs and also manages these VLANs that are provisioned from the EMS. Cisco 12000/10720 Router Manager also provides a synchronization facility so that the VLAN information is retrieved from the entire network, when the sync is initiated for the first time.

This chapter provides the following information:

- [Launching the VLAN Windows](#)
- [VLAN Synchronization](#)
- [Deploying VLAN objects](#)
- [VLAN Configuration](#)
- [VLAN Performance](#)
- [Reparenting VLANs and VLAN Sub-Interfaces](#)
- [Deleting VLAN Objects](#)

Launching the VLAN Windows

[Table 13-1](#) displays each object type that can be used to open the Cisco 12000/10720 Router Manager windows that allow you to view performance, configuration, and synchronization of the VLAN objects.



Note

[Table 13-1](#) lists the menu options for launching the VLAN dialogs from the VLAN view.

These windows have to be launched from the VLAN objects in the VLAN view. For example, the VLAN Performance window can be launched from a Site and Chassis, but cannot be launched from a module or an Interface object.

Table 13-1 Launching the VLAN Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
VLAN Performance	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Performance>VLAN Management>Performance
VLAN Configuration	Yes	No	No	No	No	Cisco 12000/10720 Manager>Configuration>VLAN Management>Configuration
VLAN Synchronization	Yes	No	No	No	No	Cisco 12000/10720 Manager>Configuration>VLAN Management>Synchronize

VLAN Synchronization

VLAN synchronization is provided to synchronize the EM with the VLAN information present in the network. The synchronization process gets the VLAN information from the devices in the network and all the previous VLAN information is lost. Once the VLAN synchronization is completed, all the VLAN objects and the sub-interfaces are deployed under a **DefaultDomain**. See “[VLAN View](#)” section on [page 2-12](#) for more details on domains.



Note

It is recommended that synchronization should not be performed at a time when there is heavy load on the system i.e., when all the chassis are in the performance logging state.


The first time sync is a clean sync which means that the VLAN information from the entire network is cleaned up and then retrieved.

VLAN synchronization happens only on the chassis which are in the managed state i.e., normal or performance logging state.

To synchronize the VLAN objects, proceed as follows:

- Step 1 Right click on a domain in the VLAN view and choose **Cisco 12000/10720 Manager>Configuration>VLAN Management>Synchronize**. The VLAN synchronization dialog can be launched from the VLAN view or see [Table 13-1 on page 13-2](#) for information on which objects allow you to launch the VLAN Synchronize window.

Figure 13-1 VLAN Synchronize Window



- Step 2** Click **Synchronize** to initiate the synchronization process. An Information window appears seeking confirmation whether to proceed with the synchronization or not

Figure 13-2 VLAN Synchronize



- Step 3** Click **Yes** to continue with synchronization.




Caution Choosing **Yes**, initiates the VLAN synchronization process and all the previous performance data and the information related to the VLAN objects is lost.

- Step 4** The status of the synchronization process is displayed in the **Synchronization Status** area in the VLAN Synchronization window.



Note All the sub-interface objects are created under the VLAN objects that are created under the DefaultDomain in the VLAN view and the sub-interfaces are created under the parent interface in the Component Managed view.

Figure 13-3 VLAN Synchronize—Status Window



Deploying VLAN objects

Cisco 12000/10720 Router Manager provides deployment wizard dialogs to deploy a Domain, VLAN and a VLAN sub-interface. All the VLAN related objects are displayed in the VLAN view. Refer “[VLAN View](#)” section on page 2-12 for more details on VLAN view. A domain is deployed independent of any object. Deploying a VLAN object, typically involves the following steps:


- [Deploying a Domain](#)
- [Deploying a VLAN and a Sub-Interface Object Under an Existing Domain](#)

Deploying a Domain

To deploy a domain, proceed as follows:


- Step 1 Place the cursor in the VLAN view to determine the objects you can deploy in the VLAN view.
- Step 2 Choose **Deployment>Cisco 12000/10720 Manager >Deploy VLAN Related Objects**.

Figure 13-4 Deploying a VLAN object




The Deployment Wizard - Templates window appears (see Figure 13-5) displaying a list of available VLAN object deployment profiles. Deployment profiles are templates that prompt you for the appropriate information required to deploy the selected object successfully.

Figure 13-5 Deployment Wizard—Templates Window



- Step 3 Choose the deployment profile **Template for VLAN domain** to deploy a Domain (shown in Figure 13-6).
- Step 4 Click **Forward**.


Figure 13-6 Deployment Wizard—Object Parameters Window



Step 5 Enter the number of Domains required. A single domain was entered in this example.

Step 6 Click **Forward**.

Figure 13-7 Deployment Wizard—Object Parameters Window




Step 7 Enter a **Domain** name. Each Domain must have a unique name. In this example the domain is called Domain-2.

Step 8 Click **Forward**.

The Deployment - Wizard Summary window appears. The Summary window provides details of the object you are about to deploy.

Figure 13-8 Deployment Wizard—Summary



- Step 9** Click **Finish** (when the Deployment Summary information is displayed) to complete deployment and close the Deployment Wizard - Summary window. The new domain object (that is, Domain-2) is created and displayed in the Map Viewer window under the VLAN view.

Deploying a VLAN and a Sub-Interface Object Under an Existing Domain


To deploy a VLAN object and a VLAN sub-interface object from a domain, proceed as follows:



Note Make sure that the IOS usernames and passwords are correctly set in the Management Information.


- Step 1** Place the cursor on the domain to determine the objects you can deploy in the VLAN view.
- Step 2** Click and hold down the right mouse button.
- Step 3** Choose **Deployment>Cisco 12000/10720 Manager >Deploy VLAN Related Objects**.

Figure 13-9 Deploying a VLAN object



The Deployment Wizard - Templates window appears (see [Figure 13-5](#)) displaying a list of available VLAN object deployment profiles.

Figure 13-10 Deployment Wizard—Templates Window




- Step 4** Choose the deployment profile **VLAN and VLAN-SubInterface under VLAN Domain** to deploy a VLAN object (shown in [Figure 13-6](#)).



Note You can deploy a sub-interface under a VLAN object by using the **VLAN SubInterface under VLAN** as shown in [Figure 13-10](#) on page 13-8.

- Step 5** Click **Forward**.


Figure 13-11 Deployment Wizard—Object Parameters Window



Step 6 Enter the number of **VLAN objects** required to be deployed. A single VLAN object was entered in this example.

Step 7 Click **Forward**.

Figure 13-12 Deployment Wizard—Object Parameters Window



Step 8 Enter the **VLAN number**. The VLAN number should be in the range of 1 to 4095.

Step 9 Enter the number of SubInterface objects that should be deployed under the VLAN object.

Step 10 Click **Forward**.

Figure 13-13 Deployment Wizard—Object Parameters

Step 11 Enter the IP address of the sub-interface to be deployed under the VLAN object.

Step 12 Enter the subnet mask of the sub-interface.




Note These are optional fields.

Step 13 Enter the sub-interface number. The number can range between 1 to 2147483647.


Step 14 Click **Forward**.

Figure 13-14 Deployment Wizard—Views




Step 15 Choose **Select**. An Object Selector window appears.

Figure 13-15 Object Selector Window




- Step 16** Navigate down the hierarchy until you find the interface you wish to deploy the VLAN object under. Click on the object, then click **Apply**.
- Step 17** The Deployment Wizard, Component Managed field appears.

Figure 13-16 Deployment Wizard—Views



- Step 18** Click **Forward**. The Deployment - Wizard Summary window appears. The Summary window provides details of the object you are about to deploy.

Figure 13-17 Deployment Wizard—Summary




- Step 19** Click **Finish** (when the Deployment Summary information is displayed) to complete deployment and close the Deployment Wizard - Summary window. The new VLAN object and the sub-interface object is created and displayed in the Map Viewer window.



Note For managing sub-interface objects, use the same dialogs as those for the interfaces.

Figure 13-18 Example showing the newly deployed Domain, VLAN and Sub-interface



VLAN Configuration

The Configuration window allows you to commission or decommission any VLAN objects in a specific domain. It also allows the performance logging to be enabled/disabled for the sub-interfaces under a VLAN object. All the state changes ripple down to the sub-interface child objects.

The VLAN Configuration section provides the following information:


- [Viewing the VLAN Configuration Window](#)
- [Commissioning a VLAN](#)
- [Decommissioning a VLAN](#)
- [Start Performance Logging](#)
- [Stop Performance Logging](#)
- [VLAN Configuration Window—Detailed Description](#)

Viewing the VLAN Configuration Window

To view the VLAN Configuration window, proceed as follows:

- Step 1** Right click on a VLAN object in the VLAN view and choose **Cisco 12000/10720 Manager>Configuration>VLAN Management>Configuration**. See [Table 13-1 on page 13-2](#) for information on which objects allow you to launch the VLAN Configuration window. The VLAN Configuration window appears with the Configuration tab displayed.

Figure 13-19 VLAN Configuration Window



Step 2 Choose a **Domain** and **VLAN** from the list boxes displayed at the left of the window.

Commissioning a VLAN




Note

You can select multiple VLANs (from the VLAN object selector list) which allows you to commission all of the selected VLANs simultaneously. You can choose multiple VLANs in a list by holding down the Shift key and then selecting the first and last VLAN in the list. You can choose multiple individual VLANs by holding down the Ctrl key and clicking on the individual VLANs. Multiple selection of domains is possible in the VLAN configuration window.

To commission a VLAN, proceed as follows:

- Step 1** Open the VLAN Configuration window. See [“Viewing the VLAN Configuration Window”](#) section on page 13-14 for further details.
- Step 2** Choose a **Domain** and **VLAN** from the list boxes displayed at the left of the window.
- Step 3** Choose **Commission** to commission the selected VLAN. An Action Report window appears confirming that the commissioning action was completed successfully.

Figure 13-20 Action Report Window

- Step 4** Click **Close** to close the Action Report window.
-

Decommissioning a VLAN




Note

You can select multiple VLANs (from the VLAN object selector list) which allows you to decommission all of the selected VLANs simultaneously. You can choose multiple VLANs in a list by holding down the Shift key and then selecting the first and last VLAN in the list. You can choose multiple individual VLANs by holding down the Ctrl key and clicking on the individual VLANs.

To decommission a VLAN, proceed as follows:

- Step 1** Open the VLAN Configuration window. See [“Viewing the VLAN Configuration Window”](#) section on page 13-14 for further details.
- Step 2** Choose a **Domain** and **VLAN** from the list boxes displayed at the left of the window.
- Step 3** Choose **Decommission** to decommission the selected VLAN. An Action Report window appears confirming that the decommissioning action was completed successfully.

Figure 13-21 Action Report Window



- Step 4 Choose **Close** to close the Action Report window.

Start Performance Logging



Note

You can select multiple VLANs (from the VLAN object selector list) which allows you to start performance logging on all the selected VLANs simultaneously. You can choose multiple VLANs in a list by holding down the Shift key and then selecting the first and last VLAN in the list. You can choose multiple individual VLANs by holding down the Ctrl key and clicking on the individual VLANs.


To start performance logging, proceed as follows:

- Step 1 Open the VLAN Configuration window. See [“Viewing the VLAN Configuration Window”](#) section on page 13-14 for further details.
- Step 2 Choose a **Domain** and **VLAN** from the list boxes displayed at the left of the window.
- Step 3 Choose **Start** to start performance polling on the VLAN. An Action Report window appears confirming that the state of the VLAN object was successfully changed.



Note

There is no performance data gathered on the VLANs but all the sub-interfaces (in the Normal state) under the VLAN move to the performance logging state and the performance data is gathered for the sub-interfaces.

Figure 13-22 Action Report Window

- Step 4** Choose **Close** to close the Action Report window.
-

Stop Performance Logging




Note

You can select multiple VLANs (from the VLAN object selector list) which allows you to stop performance logging on all the selected VLANs simultaneously. You can choose multiple VLANs in a list by holding down the Shift key and then selecting the first and last VLAN in the list. You can choose multiple individual VLANs by holding down the Ctrl key and clicking on the individual VLANs.

To stop performance logging, proceed as follows:

- Step 1** Open the VLAN Configuration window. See [“Viewing the VLAN Configuration Window”](#) section on page 13-14 for further details.
- Step 2** Choose a **Domain** and **VLAN** from the list boxes displayed at the left of the window.
- Step 3** Choose **Stop** to stop the performance polling on the VLAN. An Action Report window appears confirming that the state of the VLAN object was successfully changed.

Figure 13-23 Action Report Window



Step 4 Choose **Close** to close the Action Report window.

VLAN Configuration Window—Detailed Description

The VLAN Configuration window displays a single Configuration tab.

Configuration Tab

The Configuration tab (see [Figure 13-19 on page 13-15](#)) displays two areas: Status and Performance Logging.

Status

The Status area contains two action buttons:

Commission—Commissions the selected VLAN.

Decommission—Decommissions the selected VLAN.

Performance Logging

The Performance Logging area contains two action buttons:

Start—Starts the performance polling for the selected VLAN.

Stop—Stops the performance polling for the selected VLAN.

VLAN Performance

The VLAN Performance window displays the current performance information for all the VLANs on a selected chassis. Performance polling is not done on a VLAN object, instead, when a VLAN object is moved to the performance polling state, all the child sub-interfaces are also moved into the performance polling state.

The VLAN Performance section provides the following information:

- [Viewing the VLAN Performance Window](#)
- [VLAN Performance Window—Detailed Description](#)


Viewing the VLAN Performance Window

The VLAN performance data is available on a per chassis basis and the performance data is received directly from the device. The VLAN performance window displays the statistics for all the VLANs configured on a selected chassis.

To view the VLAN Performance window, proceed as follows:

- Step 1** Right click on a VLAN object in the VLAN view and choose **Cisco 12000/10720 Manager>Performance>VLAN Management> Performance**. See [Table 13-1](#) on [page 13-2](#) for information on which objects allow you to launch the VLAN Performance window. The VLAN Performance window appears, with the **VLAN Performance** tab displayed.

Figure 13-24 VLAN Performance Window



- Step 2** Choose a **Chassis** from the list box displayed at the left of the window. The performance information for the selected chassis is displayed.

VLAN Performance Window—Detailed Description

The VLAN Performance window (see [Figure 13-24 on page 13-20](#)) displays a single VLAN Performance tab. The VLAN Performance tab has a single tabular area with the following fields:

VLAN Id—Identifier for the VLAN object.

Packets transmitted—The number of packets transmitted by this VLAN.

Packets Received—The number of packets received by this VLAN.



Note

The performance data for the VLAN sub-interfaces can be viewed in the Generic Interface Performance dialog. Refer [“Generic Interface Performance” section on page 10-3](#) for further information.

Reparenting VLANs and VLAN Sub-Interfaces

After the VLAN synchronization process is completed, all the VLAN objects and their corresponding sub-interface objects are placed under a single domain called the DefaultDomain. Reparenting allows you to relocate a VLAN object under a domain or a sub-interface object under a VLAN as per the requirements.



Caution

It is strongly recommended that the user does not move any VLAN related objects out of VLANView. This could result in unexpected behavior.

Reparenting is basically used to relocate the VLAN and sub-interface objects under different domains after synchronization.



Note

To reparent a sub-interface object under a VLAN, it is mandatory that the vlan id of the parent VLAN object should be identical. The VLAN object must be placed under a different domain.


For example: Say, you have deployed two domains, D1 and D2. D1 has a VLAN object V1 with sub-interface E1 placed under it and D2 has a VLAN object V2. It will not be possible to place E1 from domain D1 under V2 in domain D2 as the VLAN ids of the VLAN objects are different. But, if a VLAN object is deployed in D2 having id as V1, it would be possible for you to place sub-interface object E1 under V1 in domainD2.

To reparent a VLAN object, proceed as follows:

Step 1

Right click on a VLAN object in the VLAN view and choose **View Manipulation>Reparent Object(s)...** . The Reparent dialog can be launched from a VLAN or sub-interface object.

Figure 13-25 VLAN—Reparent Objects Window



- Step 2** Select a parent object from the list of VLAN objects displayed under the specific domain in the VLAN view.
- Step 3** Choose **Apply**.


Deleting VLAN Objects



Note A VLAN or sub-interface object can be deleted only if it is in the decommissioned state. To decommission a sub-interface object, refer [“Decommissioning an Interface” section on page 8-5](#).

To delete an existing VLAN or a sub-interface object, proceed as follows:

- Step 1** Choose the VLAN objects you wish to delete within the VLAN view. See [“VLAN View” section on page 2-12](#) for details of the VLAN view.
- Step 2** Choose **Deployment>Delete Objects**. The Deployment Wizard appears with a summary of what will be deleted.

Figure 13-26 Deployment Wizard—Summary

Step 3 Click **Finish**, and the VLAN object is deleted. If deletion fails, another interface might be currently using the VLAN object, therefore you cannot delete the object.



Note Similarly, a domain can be deleted provided the VLAN and sub-interface objects are decommissioned.



Routing

This chapter describes the Border Gateway Protocol and the Open Shortest Path First Routing Protocol. Border Gateway Protocol is an exterior gateway routing protocol that addresses the task of path determination. The Cisco 12000/10720 Router Manager supports Configuration and Fault Management of BGP routing processes and BGP address families. The Open Shortest Path First is a link-state, interior gateway routing protocol. It is designed to operate in Transmission Control Protocol/Internet Protocol networks and to address the shortcomings of the Routing Information Protocol. The Cisco 12000/10720 Router Manager supports the Configuration and Fault Management of OSPF processes and areas on the routers.

This chapter contains the following information:

- [Launching the Routing Windows](#)
- [BGP Configuration](#)
- [BGP Status](#)
- [BGP Address-Family Synchronization](#)
- [BGP Address Family Configuration](#)
- [BGP Address-Family Status](#)
- [OSPF Configuration](#)
- [OSPF Status](#)

Launching the Routing Windows

[Table 14-1](#) displays the Routing windows that can be launched from each object type.



Note

[Table 14-1](#) lists the menu options to launch the Routing windows from the site level.

Table 14-1 Launching the Routing Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window					Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	
BGP Configuration	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>BGP>BGP Configuration
BGP Status	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis>BGP>BGP Status
BGP Address-Family Synchronization	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>BGP>BGP Address-Family Synchronization
BGP Address Family Configuration	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>BGP>BGP Address-Family Configuration
BGP Address-Family Status	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis>BGP>BGP Address-Family Status
OSPF Configuration	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Configuration>Chassis>OSPF>OSPF Configuration
OSPF Status	Yes	Yes	Yes	No	No	Cisco 12000/10720 Manager>Fault>Chassis>OSPF>OSPF Status

**Note**

The routing windows cannot be opened when multiple objects are selected (the menu options to open the windows are grayed out). Available menu options can be launched from a site object containing the required objects, when required.

BGP Management

BGP is an interautonomous system routing protocol that is used to exchange routing information for the internet. The customers connect to the Internet Service Providers (ISPs), and the ISPs use BGP to exchange customer and ISP routing information. When BGP is used between autonomous systems (AS), the protocol is referred to as External BGP (EBGP). If a service provider is using BGP to exchange routes within an AS, then the protocol is referred to as Interior BGP (IBGP).

BGP uses the Transmission Control Protocol (TCP) as its transport protocol. Any two routers that have opened a TCP connection to each other for the purpose of exchanging routing information are known as peers or neighbor.

BGP Configuration

The BGP Configuration window allows the user to enable, modify and disable a BGP process in the device. The BGP Configuration window also allows the user to configure a BGP Network, BGP Neighbor and BGP Redistribute protocol.

The BGP Configuration section covers the following:

- [Viewing the BGP Details Tab on the BGP Configuration Window](#)
- [BGP Details Tab—Detailed Description](#)
- [Enabling BGP on a Chassis](#)
- [Enable BGP Window—Detailed Description](#)
- [Modifying BGP on a Chassis](#)
- [BGP Modify Window—Detailed Description](#)
- [Disabling BGP on a Chassis](#)
- [Viewing the Network Tab on the BGP Configuration Window](#)
- [Network Tab—Detailed Description](#)
- [BGP Network Configuration](#)
- [BGP Network Configuration Window—Detailed Description](#)
- [Viewing the Neighbor Tab on the BGP Configuration Window](#)
- [Neighbor Tab—Detailed Description](#)
- [BGP Neighbor Configuration](#)
- [BGP Neighbor Configuration Window—Detailed Description](#)
- [Viewing the Redistribution Tab on the BGP Configuration Window](#)
- [Redistribution Tab—Detailed Description](#)
- [BGP Redistribute Configuration](#)
- [BGP Redistribute Configuration—Detailed Description](#)

Viewing the BGP Details Tab on the BGP Configuration Window


The BGP Details tab displays the BGP information. The user can enable, disable or modify BGP running on the device. To view the BGP Configuration window for a chassis, proceed as follows:

- Step 1** Right click on the chassis object and choose **Configuration>BGP>BGP Configuration**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Configuration window.



Note The BGP Details tab is always displayed upon launching the BGP Configuration window.

Figure 14-1 BGP Configuration Window—BGP Details



Step 2 Choose the chassis from the left side of the window.

BGP Details Tab—Detailed Description

The BGP-Details tab displays two areas: BGP General and BGP Information

BGP General

Local Autonomous System—The id of the BGP process running in the device. If the value is 0 it means no BGP process is running on the device.

Actions

Enable—The Enable action button is active when there is no BGP running on the device. Clicking Enable action button opens the BGP Enable window through which the user can create a new BGP process in the device. For more details on enabling BGP on a chassis, see [“Enabling BGP on a Chassis” section on page 5](#).

Disable—The Disable action button is active when there is a BGP process running in the device. Clicking Disable action button removes the BGP process running in the device. For more details on disabling BGP, see [“Disabling BGP on a Chassis” section on page 8](#).

BGP Information

BGP Identifier—It is the Router Identifier for the BGP speaking router. By default, BGP Identifier is set to IP address of the loopback interface if it is configured otherwise it is the highest IP address configured for a physical interface on that router.

BGP Version— It displays the supported BGP version.

BGP Synchronization—It displays whether BGP synchronization with IGP is enabled or disabled.

BGP Auto-Summary—It displays whether Automatic network number summarization for BGP is enabled or disabled.

BGP Log Neighbor-Changes—It displays whether logging of BGP neighbor resets is enabled or disabled.

Default-Metric—It displays the default-metric value set for redistributed routes.

BGP Default IPV4-Unicast—It displays whether the IP version 4 (IPv4) unicast for peers is enabled or disabled on the router.

Action

Modify—The Modify action button is active only when there is BGP running in the device. Clicking the Modify action button opens the BGP Modify window through which the user can modify the General BGP parameters. For more details on modifying BGP, see [“Modifying BGP on a Chassis” section on page 7](#).

Enabling BGP on a Chassis

The Enable BGP window allows the user to enable a BGP process on the device. To enable a BGP process, proceed as follows:

Step 1 Open the BGP Configuration window. See [“Viewing the BGP Details Tab on the BGP Configuration Window” section on page 14-3](#) for further details.

Step 2 Choose a chassis from the left side of the window.




Note You can choose multiple chassis (from the chassis list) which allows you to launch the Enable BGP window for the selected chassis.

Step 3 Click on the Enable button. The Enable BGP window appears.



Note The Enable button is active only when there is no BGP running on the device.

Figure 14-2 Enable BGP Window



- Step 4 Choose the chassis from the left side of the window.
- Step 5 Enter a value for the BGP AS Number.
- Step 6 Choose the Enable BGP button.

Enable BGP Window—Detailed Description

Local Autonomous System—The id of the BGP process to be created on the device.

Action

Enable BGP—Clicking on the Enable BGP button creates the BGP process on the device.

Modifying BGP on a Chassis

The BGP Modify Window allows the user to modify the BGP Configurations on the device. To modify a BGP process, proceed as follows:

Step 1 Open the BGP Configuration window. See [“Viewing the BGP Details Tab on the BGP Configuration Window”](#) section on page 14-3 for further details.

Step 2 Choose a chassis from the left side of the window.




Note You can choose multiple chassis (from the chassis list) which allows you to launch the BGP Modify window for the selected chassis.

Step 3 Click on the Modify button. The BGP Modify window appears.



Note The Modify button is active only when there is BGP running on the device.

Figure 14-3 BGP Modify Window



- Step 4** Choose the chassis from the left side of the window.
- Step 5** Modify the values of the fields and save the changes.

BGP Modify Window—Detailed Description

The BGP Modify window displays the following:

Local AS—The Autonomous System number in the router.

BGP Identifier—Used to configure the Router Identifier for the BGP speaking router.



Note Peering sessions are reset if the router ID is changed.

BGP Synchronization—This is used to Enable or Disable BGP synchronization with Interior Gateway Protocol (IGP).

BGP Auto-Summary—This is used to Enable or Disable Automatic network number summarization for BGP

BGP Log Neighbor-Changes—This is used to set logging of BGP neighbor resets. This value can be set to “Yes” or “No”.

BGP Default IPV4-Unicast—This is used to set the default as the IP version 4 (IPv4) unicast for BGP peers on the router.

BGP Default-Metric—This is used to configure the default-metric value for redistributed routes.



Note If this attribute is set to zero, then the default metric is removed from the device.

Disabling BGP on a Chassis

This section describes the procedure to disable a BGP process running in the device. To disable a BGP process, proceed as follows:

- Step 1** Open the BGP Configuration window. See [“Viewing the BGP Details Tab on the BGP Configuration Window” section on page 14-3](#) for further details.
- Step 2** Choose the chassis for which you want to disable BGP from the left side of the window.




Note You can choose multiple chassis (from the chassis list) which allows you to disable BGP for the selected chassis.

- Step 3** Click on the Disable button.



Note The Disable button is active only when there is BGP running on the device.

Figure 14-4 Disable BGP—Alert




- Step 4** Click Yes to disable BGP on the chassis.
- Step 5** Click No to abort the Disable BGP operation.

Viewing the Network Tab on the BGP Configuration Window

The Network tab displays the information about paths to destination networks from all the BGP4 Peers. The user can add or remove a BGP network on the device. To view the Network tab on the BGP Configuration window for a chassis, proceed as follows:

- Step 1** Right click on the chassis object and choose **Configuration>BGP>BGP Configuration**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Configuration window.
- Step 2** Click on the Network tab.

Figure 14-5 BGP Configuration Window—Network Tab



Step 3 Choose the chassis from the left side of the window.

Network Tab—Detailed Description

The Network tab displays a single area, BGP Network Information.

BGP Network Information

Neighbor IP Address—The IP address of the peer where the path information was learnt.

Network Mask—Length in bits of the IP address prefix in the Network Layer Reachability Information field.

Network Address—An IP address prefix in the Network Layer Reachability Information field. This object is an IP address containing the prefix with the length specified by the Network Mask attribute. Any bits beyond the length specified by Network Mask attribute are zeroed.

Path Origin—The ultimate origin of the path information.

Border Router IP Address—The address of the border router that should be used for the destination network.

Best Path—Indicates whether the BGP4 route is the best chosen or not.

Multiple Exit Point Discriminate Metric—This metric is used to discriminate between multiple exit points to an adjacent autonomous number. A value of -1 indicates the absence of this attribute.

Degree of Preference—The originating BGP4 speaker's degree of preference for an advertised route. A value of -1 indicates the absence of this attribute.

Calculated Degree of Preference—The degree of preference calculated by the receiving BGP4 speaker for an advertise route.

Less Specific Route Selected—Indicates whether or not the local system has selected a less specific route without selecting a more specific route.

Router Aggregator AS—The AS number of the last BGP4 speaker that performed route aggregation. When the value is zero, it indicates the absence of this attribute.

Route Aggregator IP Address—The IP address of the last BGP4 speaker that performed route aggregation.

Actions

Add/Remove Network—Clicking this button opens the BGP Network Configuration window. For more details, see [“BGP Network Configuration” section on page 11](#).

BGP Network Configuration

The BGP Network Configuration window allows the user to add or remove a network entry to be advertised through the BGP Network. To configure the BGP Network, proceed as follows:


- Step 1** Open the BGP Configuration window. See “[Viewing the BGP Details Tab on the BGP Configuration Window](#)” section on page 14-3 for further details. Click on the Network tab.
- Step 2** Choose the chassis, for which you want to configure the BGP path, from the left side of the window.



Note You can choose multiple chassis (from the chassis list) which allows you to launch the BGP Network Configuration window for the selected chassis.

- Step 3** Click Add/Remove Network. The BGP Network Configuration window appears.

Figure 14-6 BGP Network Configuration Window



- Step 4** Edit the fields displayed in the window, as required.

BGP Network Configuration Window—Detailed Description

The BGP Network Configuration window displays the following:

Local AS—The Autonomous System number in the router.

Network Address—This is used to configure the IP address of a network to be advertised through BGP.

Network Mask—This is used to configure the subnet mask of the network to be advertised

Action

Add Network Entry—Clicking on the Add Network Entry button, adds the network entry on the device. Thus, the user is able to add the networks associated with the BGP routing process.


Remove Network Entry—Clicking on the Remove Network Entry button, removes the network entry from the device. Thus, the user is able to remove the networks associated with the BGP routing process.

Viewing the Neighbor Tab on the BGP Configuration Window

The Neighbor tab displays the connection related information for the BGP Neighbors. Each entry corresponds to a BGP Neighbor. The user can add or remove the neighbor configurations on the device. To view the Neighbor tab on the BGP Configuration window for a chassis, proceed as follows:

- Step 1 Right click on the chassis object and choose **Configuration>BGP>BGP Configuration**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Configuration window.
- Step 2 Click on the Neighbor tab.

Figure 14-7 BGP Configuration Window—Neighbor Tab



- Step 3 Choose the chassis from the left side of the window.

Neighbor Tab—Detailed Description

The Neighbor tab displays a single area, BGP Neighbor Information.

BGP Neighbor Information

Neighbor IP Address—Specifies the IP address of the neighbor router.

Neighbor ID—Indicates the BGP identifier of the BGP peer entry

State—Specifies the state of the neighbor router that can be one of Idle, Active, Established, Opensent, Connect or Openconfirm.

Negotiated Version—Specifies the negotiated version of BGP running between the two peers.

Remote AS—Specifies the neighbor routers autonomous system number which can be from 1-65535.

Received Update Messages—The number of BGP Update messages received on this connection.

Transmitted Update Messages—The number of BGP Update messages transmitted on this connection.

Total Received Messages—The total number of messages received from the remote peer on this connection.

Total Transmitted Messages—The total number of messages transmitted to the remote peer on this connection.

Hold Time—The Hold Timer established with the peer (in seconds).

KeepAlive Time—The KeepAlive timer established with the peer (in seconds).

Configured Hold Time—The Hold Time configured for this BGP speaker with this peer (in seconds).

Configured KeepAlive Time—The KeepAlive timer configured for this BGP speaker with this peer (in seconds).

Actions

Add/Remove Neighbor—Clicking on the Add/Remove Neighbor action button opens the BGP Neighbor Configuration window. For more details, see [“BGP Neighbor Configuration” section on page 13](#).

BGP Neighbor Configuration

The BGP Neighbor Configuration window allows the user to add or remove neighbor configurations for BGP address families. To configure the BGP Neighbor, proceed as follows:


- Step 1 Open the BGP Configuration window. See [“Viewing the BGP Details Tab on the BGP Configuration Window” section on page 14-3](#) for further details. Click on the Neighbor tab.
- Step 2 Choose the chassis, for which you want to configure the BGP Neighbor, from the left side of the window.



Note You can choose multiple chassis (from the chassis list) which allows you to launch the BGP Neighbor Configuration window for the selected chassis.

Step 3 Click on the Add/Remove Neighbor button. The BGP Neighbor Configuration window appears.

Figure 14-8 BGP Neighbor Configuration Window



Step 4 Edit the fields displayed in the window, as required.

BGP Neighbor Configuration Window—Detailed Description

The BGP Neighbor Configuration window displays the following:

Local AS—The Autonomous System number in the router.

Neighbor IP Address—This is used to configure the IP address of the neighbor router.

Neighbor Remote AS—This is used to configure the neighbor routers AS number with the values ranging from 1 to 65535.

Update-Source—This is used to set the BGP sessions to use a specific operational interface for TCP connections.



Note

The Update Source command in the device can specify any interface (physical, virtual, loopback) to be used as source IP address of the BGP session with the neighbor; but in the EM only the loopback interface can be specified.

Loopback—This is used to configure Router's Loopback Interface Number. This is valid only if Update-Source is set to YES.

Action

Add Neighbor Entry—Clicking on the Add Neighbor Entry action button adds the neighbor entry in the device.


Remove Neighbor Entry—Clicking on the Remove Neighbor Entry action button removes the neighbor entry from the device.

Viewing the Redistribution Tab on the BGP Configuration Window

The Redistribution tab displays the redistributed information from other routing protocols. The user can add or remove the redistributed protocol entries on the device. To view the Redistribution tab on the BGP Configuration window for a chassis, proceed as follows:

- Step 1** Right click on the chassis object and choose **Configuration>BGP>BGP Configuration**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Configuration window.
- Step 2** Click on the Redistribution tab.

Figure 14-9 BGP Configuration Window—Redistribution Tab



- Step 3** Choose the chassis from the left side of the window.

Redistribution Tab—Detailed Description

The Redistribution tab displays a single area, BGP Redistribution Information

BGP Redistribution Information

Protocol—This displays the protocol whose routes are redistributed by BGP. The redistribute configuration causes the corresponding routes to be redistributed into BGP.

AS/Tag—A Process ID of the redistributed protocol

IS-IS Routing Level—Routing level of ISIS Protocol

Redistribution Metric—Specifies the metric used for redistributed routes.

Actions

Add/Remove Redistribute—Clicking the Add/Remove Redistribute action button opens the BGP Redistribute Configuration window. For more details, see [“BGP Redistribute Configuration” section on page 16](#).

BGP Redistribute Configuration

The BGP Redistribute Configuration window allows the user to add or remove a redistribution entries from the device. To configure the BGP Redistribute protocol, proceed as follows:


-
- Step 1** Open the BGP configuration window. See [“Viewing the BGP Details Tab on the BGP Configuration Window” section on page 14-3](#) for further details. Click on the Redistribution tab.
 - Step 2** Choose the chassis, for which you want to configure the BGP Redistribute, from the left side of the window.



Note You can choose multiple chassis (from the chassis list) which allows you to launch the BGP Redistribute Configuration window for the selected chassis.

- Step 3** Click on the Add/Remove Redistribute button. The BGP Redistribute Configuration window appears.

Figure 14-10 BGP Redistribute Configuration Window



Step 4 Edit the fields displayed in the window, as required.

BGP Redistribute Configuration—Detailed Description

The BGP Redistribute Configuration window displays the following:

Local AS—The Autonomous System number in the router.

Protocol—Specifies the protocol to be redistributed into BGP. Valid Protocol Names that can be redistributed are connected, static, ospf, isis, igmp, eigrp, egp, rip, mobile, odr, dvmrp.

Source ID—Indicates the Process ID of the redistributed protocol. A Positive Integer will indicate the process id of the redistributed protocol; a character string will indicate the ISO routing area tag. In case of protocols like CONNECTED and STATIC this attribute cannot be configured.

IS-IS Routing Level—Specifies the routing level of ISIS Protocol. The values for this field are: level-1, level-2 or level-1-2 when protocol is IS-IS.

Redistribution Metric—Specifies the metric used for redistributed routes.

Action

Add Redistribute Entry—Clicking on the Add Redistribute action button adds the redistribution entry to the device.

Remove Redistribute Entry—Clicking on the Remove Redistribute Entry action button removes the redistribution entry from the device.

BGP Status

The BGP Status window displays the BGP configurations existing on the device including basic BGP information, path information, peer information and redistribution information.

The BGP Status section covers the following:


- [Viewing the BGP Status Window](#)
- [BGP Status Window—Detailed Description](#)

Viewing the BGP Status Window

To view the BGP Status window, proceed as follows:


- Step 1** Right click on the chassis and choose **Fault>BGP>BGP Status**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Status window. The BGP Detail tab displays the BGP information.

Figure 14-11 BGP Status Window




- Step 2** Choose a Chassis from the list box displayed on the left side of the window. Choose the Network tab, if required. The Network tab displays the information about paths to destination networks from all the BGP4 Peers.

Figure 14-12 BGP Status—Network Tab




- Step 3** Choose the Neighbor tab, if required. The Neighbor tab displays the information about BGP Peers and it contains one entry per BGP Peer, information about the connections with BGP Peers.

Figure 14-13 BGP Status—Neighbor Tab



- Step 4** Choose the Redistribution tab, if required. The Redistribution tab displays the redistributed information from other routing protocols.

Figure 14-14 BGP Status—Redistribution Tab



BGP Status Window—Detailed Description

The BGP Status window displays four tabs: BGP-Details, Network, Neighbor and Redistribution.

BGP-Details

The BGP-Details tab displays two areas: BGP General and BGP Information

BGP General

Local Autonomous System—The id of the BGP process running in the device. If the value is 0 it means no BGP process is running on the device.

BGP Information

BGP Identifier—It is the Router Identifier for the BGP speaking router. By default, BGP Identifier is set to IP address of the loopback interface if it is configured otherwise it is the highest IP address configured for a physical interface on that router.

BGP Version—It displays the supported BGP version.

BGP Synchronization—It displays whether BGP synchronization with IGP is enabled or disabled.

BGP Auto-Summary—It displays whether Automatic network number summarization for BGP is enabled or disabled.

BGP Log Neighbor-Changes—It displays whether logging of BGP neighbor resets is enabled or disabled.

Default-Metric—It displays the default-metric value set for redistributed routes.

BGP Default IPV4-Unicast—It displays whether the IP version 4 (IPv4) unicast for peers is enabled or disabled on the router.

Network

The Network tab displays a single area, BGP Network Information

BGP Network Information

Neighbor IP Address—The IP address of the peer where the path information was learnt.

Network Mask—Length in bits of the IP address prefix in the Network Layer Reachability Information field

Network Address—An IP address prefix in the Network Layer Reachability Information field. This object is an IP address containing the prefix with the length specified by the Network Mask attribute. Any bits beyond the length specified by Network Mask attribute are zeroed

Path Origin—The ultimate origin of the path information

Border Router IP Address—The address of the border router that should be used for the destination network.

Best Path—Indicates whether the BGP4 route is the best chosen or not.

Multiple Exit Point Discriminate Metric—This metric is used to discriminate between multiple exit points to an adjacent autonomous number. A value of -1 indicates the absence of this attribute.

Degree of Preference—The originating BGP4 speaker's degree of preference for an advertised route. A value of -1 indicates the absence of this attribute.

Calculated Degree of Preference—The degree of preference calculated by the receiving BGP4 speaker for an advertise route.

Less Specific Route Selected—Indicates whether or not the local system has selected a less specific route without selecting a more specific route.

Router Aggregator AS—The AS number of the last BGP4 speaker that performed route aggregation. When the value is zero, it indicates the absence of this attribute.

Route Aggregator IP Address—The IP address of the last BGP4 speaker that performed route aggregation.

Neighbor

The Neighbor tab displays a single area, BGP Neighbor Information.

BGP Neighbor Information

Neighbor IP Address—Specifies the IP address of the neighbor router.

Neighbor ID—Indicates the BGP identifier of the BGP peer entry

State—Specifies the state of the neighbor router that can be one of Idle, Active, Established, Opensent, Connect or Openconfirm.

Negotiated Version—Specifies the negotiated version of BGP running between the two peers.

Remote AS—Specifies the neighbor routers autonomous system number which can be from 1-65535.

Received Update Messages—The number of BGP Update messages received on this connection.

Transmitted Update Messages—The number of BGP Update messages transmitted on this connection.

Total Received Messages—The total number of messages received from the remote peer on this connection.

Total Transmitted Messages—The total number of messages transmitted to the remote peer on this connection.

Hold Time—The Hold Timer established with the peer (in seconds).

KeepAlive Time—The KeepAlive timer established with the peer (in seconds).

Configured Hold Time—The Hold Time configured for this BGP speaker with this peer (in seconds).

Configured KeepAlive Time—The KeepAlive timer configured for this BGP speaker with this peer (in seconds).

Redistribution

The Redistribution tab displays a single area, BGP Redistribution Information.

BGP Redistribution Information

Protocol—Specifies the protocol to be redistributed into BGP. Valid Protocol Names that can be redistributed are connected, static, ospf, isis, igrp, eigrp, egp, rip, mobile, odr, dvmrp.

Source ID—Indicates the Process ID of the redistributed protocol. A Positive Integer will indicate the process id of the redistributed protocol; a character string will indicate the ISO routing area tag. In case of protocols like CONNECTED and STATIC this attribute cannot be configured.

IS-IS Routing Level—Specifies the routing level of ISIS Protocol. The values for this field are: level-1, level-2 or level-1-2 when protocol is IS-IS.

Redistribution Metric—Specifies the metric used for redistributed routes.

BGP Address-Family Synchronization

BGP, by default, carries the routing information only for IPv4 unicast addresses. Address family is used to enable BGP to carry the routing information for multiple address types (ipv4 multicast, ipv4 unicast, ipv4 vrf, vpnv4 unicast). BGP Address Family synchronization is provided to synchronize BGP Address Families configured on the device with the EM. When the synchronization process is initiated for the first time on the chassis, the address families in the device are uploaded to the EM. For the subsequent synchronizations, only the new address families configured on the device are uploaded to the EM and the address families that are removed from the device are deleted from the EM.


To synchronize the BGP address families, proceed as follows:

- Step 1** Right click on a chassis and choose **Configuration>BGP>BGP Address-Family Synchronization**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Address-Family Synchronization window.




Note You can choose multiple chassis (from the chassis list displayed in the left side of the BGP Address-Family Synchronization window) which allows you to synchronize all the selected chassis simultaneously.

Figure 14-15 BGP Address-Family Synchronization Window




- Step 2** Choose Synchronize to initiate the synchronization process. An Action Report appears summarizing the synchronization process.

Figure 14-16 Action Report



- Step 3** The status of the synchronization process is displayed in the Synchronization Status area in the BGP Address-Family Synchronization window.

Figure 14-17 BGP Address-Family Synchronization—Status Report



BGP Address-Family Synchronization—Detailed Description

The BGP Address-Family Synchronization window displays a single tab: Synchronization.

Synchronization Tab

The Synchronization tab consists of a single area: BGP Address Family Synchronization. Synchronization Status—Displays the status of the synchronization process.

Action

Synchronize—Uploads the existing BGP address families in the device to the EM.



Note

The uploaded BGP address families are listed in the “Address Family List” in the BGP Address-Family Configuration window.

BGP Address Family Configuration

The BGP Address Family Configuration window allows the user to create, remove and configure BGP address families. This section covers the following topics:

- [Viewing the AF-General Tab on the BGP Address-Family Configuration Window](#)
- [AF-General Tab—Detailed Description](#)
- [Configuring Address Family](#)
- [Configure Address Family—Detailed Description](#)
- [Modifying BGP Address Family](#)
- [BGP Address Family-Modify Address Family Parameters—Detailed Description](#)
- [Viewing the AF-Network Tab on the BGP Address-Family Configuration Window](#)
- [AF-Network Tab—Detailed Description](#)
- [BGP Address Family—Network Configuration](#)
- [BGP Address Family-Network Configuration—Detailed Description](#)
- [Viewing the AF-Neighbor Tab on the BGP Address-Family Configuration Window](#)
- [AF-Neighbor Tab—Detailed Description](#)
- [BGP Address Family—Neighbor Configuration](#)
- [BGP Address Family-Neighbor Configuration—Detailed Description](#)
- [Viewing the AF-Redistribute Tab on the BGP Address-Family Configuration Window](#)
- [AF-Redistribute Tab—Detailed Description](#)
- [BGP Address Family—Redistribute Configuration](#)
- [BGP Address Family-Configure Redistribute Protocol—Detailed Description](#)

Viewing the AF-General Tab on the BGP Address-Family Configuration Window

The AF-General tab displays the BGP address family parameters. The user can create, remove or modify the BGP Address Family Parameters. To view the AF-General tab on the BGP Address Family Configuration window for a chassis, proceed as follows:

- Step 1** Right click on the chassis object and choose **Configuration>BGP>BGP Address-Family Configuration**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Address-Family Configuration window.




Note When the BGP Address-Family Configuration window is launched, the AF-General tab is displayed by default.



Note The action buttons are greyed when there is no BGP configured on the device.

Figure 14-18 BGP Address-Family Configuration Window



- Step 2** Choose the Chassis and the Address Family List from the left side of the window.

AF-General Tab—Detailed Description

The AF-General tab displays two areas: BGP General and BGP Address Family Information.

BGP General

Local Autonomous System—The id of the BGP process running in the device. If the value is 0 it means no BGP process is running on the device.

BGP Address Family Information

Address Family—Unique identifier of the address family type.

VRF Name—Identifier of the VRF Name if the address family type is ipv4 vrf.

Auto Summary—Displays whether the automatic network number summarization is enabled/disabled for the address family.

Synchronization—Displays whether the BGP synchronization with IGP is enabled/disabled for the address family.



Note

This field is applicable only for the ipv4 unicast and ipv4 vrf address families.

Default Metric—Displays the default metric value set for redistributed routes of the address family.

Action

Modify Address Family—Clicking on the “Modify Address Family” button, opens the BGP Address Family - Modify Address Family Parameters window.

Add/Remove Address Family—Clicking on the “Add/Remove Address Family” button, opens the Configure Address Family window.

Configuring Address Family

The Configure Address Family window allows the user to create or remove BGP address families. To add or remove a BGP address family, proceed as follows:

Step 1 Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window”](#) section on page 14-27 for further details. Click on the AF-General Tab.

Step 2 Choose the chassis from the left side of the window.




Note

You can choose multiple chassis (from the chassis list) which allows you to launch the Configure Address Family window for the selected chassis.

Step 3 Click on the Add/Remove Address Family button to open the Configure Address Family window.

Figure 14-19 Configure Address Family Window



- Step 4** Choose the chassis from the Chassis list for which you want to configure the BGP address family.
- Step 5** Edit the fields displayed in the window, as required.

Configure Address Family—Detailed Description

The Configure Address Family window displays a single area: Add/Remove Address Family.

Add Address Family

Address Family—Unique identifier of the address family type. The available options are: ipv4 unicast, ipv4 multicast and vpnv4 unicast.



Note

In Cisco 12000/10720 Router Manager Release 3.1, the ipv4 vrf address family type is not configurable through the EM.

Neighbor IP Address—Specifies the IP address of the neighbor router for the address family

Remote AS—Specifies the neighbor router's autonomous system number. This value can range from 1 to 65535.

**Note**

This attribute is configurable only for the ipv4 unicast and ipv4 vrf address families.

Send Community—Specifies the community attribute sent in the route updates to a peer. The available options are: both, extended and standard. However, the default is not to send community attribute in route updates.

Update Source—To enable or disable BGP sessions to use a specific operational interface for TCP connections.

**Note**

The Update Source command in the device can specify any interface (physical, virtual, loopback) to be used as source IP address of the BGP session with the neighbor; but in the EM only the loopback interface can be specified. This attribute is configurable only for the ipv4 unicast and ipv4 vrf address families.

Loopback No—This is used to configure Router's Loopback Interface Number. This is valid only if Update-Source is set to YES.

**Note**

This attribute is configurable only for the ipv4 unicast and ipv4 vrf address families.


Action

Add Address Family—Clicking on the “Add Address Family” button, adds the address family to the device.

Remove Address Family—Clicking on the “Remove Address Family” button, removes the address family from the device.

Modifying BGP Address Family


The BGP Address Family- Modify Address Family Parameters allows the user to modify the basic parameters for BGP address families. To modify the BGP Address Family, proceed as follows:

-
- Step 1** Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window”](#) section on page 14-27 for further details. Click on the AF-General Tab.
- Step 2** Choose a chassis and the address family from the left side of the window.
- 

Note You can choose multiple chassis and address families (from the list provided at the left side of the window) which allows you to launch the BGP Address Family - Modify Address Family Parameters window for the selected chassis.

- Step 3** Click on the Modify Address Family button to open the BGP Address Family - Modify Address Family Parameters window.

Figure 14-20 BGP Address Family—Modify Address Family Parameters Window



- Step 4** Choose the chassis from the Chassis list and the address family from the Address Family list for which you want to modify the BGP address family parameters.
- Step 5** Edit the fields displayed in the window, as required and save the changes.

BGP Address Family-Modify Address Family Parameters—Detailed Description

The BGP Address Family - Modify Address Family Parameters window displays a list of the Address Family and an area: Modify Address Family Parameters.

Modify Address Family Parameters

Address Family—Unique identifier of the address family type

VRF Name—Identifier of the VRF Name if the address family type is IPv4 VRF

Auto Summary—This is used to enable/disable the automatic network number summarization for the address family.

Default Metric—This is used to set the value for the redistributed routes for the address family.

**Note**

This attribute is not configurable only for the vpnv4 unicast address families. If this attribute is set to zero, then the default metric is removed from the device for that address family.

Synchronization—This is used to enable/disable the BGP synchronization with IGP for the address family.

**Note**


This field is applicable only for the ipv4 unicast and ipv4 vrf address families.

Viewing the AF-Network Tab on the BGP Address-Family Configuration Window

The AF-Network tab displays the network paths and the associated path information for the BGP address family. The user can add or remove network paths for an address family. To view the AF-Network tab on the BGP Address-Family Configuration window for a chassis, proceed as follows:

- Step 1 Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window”](#) section on page 14-27 for further details.
- Step 2 Click on the AF-Network tab.

Figure 14-21 BGP Address-Family Configuration Window—AF-Network Tab



- Step 3** Choose the Chassis and the Address Family from the left side of the window.
-

AF-Network Tab—Detailed Description

The AF-Network tab displays a single area: Network Information

Network Information

Network Address—An IP address prefix in the Network Layer Reachability Information field. This object is an IP address containing the prefix with the length specified by the Prefix Len attribute. Any bits beyond the length specified by Network Mask attribute are zeroed.

Prefix Len—Length in bits of the IP address prefix in the network layer reachability information field.

Path Origin—The ultimate origin of the network path information.

Next Hop Ip Address—The address of the border router that should be used for the destination network.

Metric—This metric is used to discriminate between multiple exit points to an adjacent autonomous number. A value of -1 indicates the absence of this attribute.

Degree of Preference—The originating BGP4 speaker's degree of preference for an advertised route. A value of -1 indicates the absence of this attribute.

Weightage—Specifies the BGP weight for the routing table.

Best Route—Specifies whether the network path is the best possible route. When set to true, it indicates that the network path is the best route for the router.

Action

Add/Remove AF Network—Clicking on the “Add/Remove AF Network” opens the BGP Address Family - Network Configuration window.

BGP Address Family—Network Configuration

The BGP Address Family - Network Configuration window allows the user to add or remove network paths for BGP address families. To configure a Network path for an address family, proceed as follows:

- Step 1** Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window” section on page 14-27](#) for further details. Click on the AF-Network Tab.


- Step 2** Choose a chassis and the address family from the left side of the window.



Note You can choose multiple chassis and address families (from the list provided at the left side of the window) which allows you to launch the BGP Address Family - Network Configuration window for the selected chassis.

- Step 3** Click on the Add/Remove AF Network button to open the BGP Address Family - Network Configuration window.

Figure 14-22 BGP Address Family—Network Configuration Window



- Step 4** Choose the chassis from the Chassis list and the address family from the Address Family List, for which you want to configure the Network path.
- Step 5** Edit the fields displayed in the window, as required.

BGP Address Family-Network Configuration—Detailed Description

The Configure Network window displays a list of Address Families and an area: Add/Remove Network.

Address Family—Displays a list of the address families.

Add/Remove Network

Address Family—Unique identifier of the address family type.

VRF Name—Identifier of the VRF Name if the address family type is IPv4 VRF

Network Number—This is used to configure the IP address of a network to be advertised through BGP.

Network Mask—This is used to configure the subnet mask of the network to be advertised



Note

You cannot configure a network for vpv4 address families.

Action

Add Network Entry—Clicking the “Add Network Entry” button, adds the network entry for the address family on the device.


Remove Network Entry—Clicking the “Remove Network Entry” button, removes the network entry for the address family on the device.

Viewing the AF-Neighbor Tab on the BGP Address-Family Configuration Window

The AF-Neighbor tab displays the neighbor information (peer) for a BGP address family. The user can add or remove neighbor entries for an address family. To view the AF-Neighbor tab on the BGP Address-Family Configuration window for a chassis, proceed as follows:

- Step 1** Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window”](#) section on page 14-27 for further details.
- Step 2** Click on the AF-Neighbor tab.

Figure 14-23 BGP Address-Family Configuration Window—AF-Neighbor Tab



- Step 3** Choose the Chassis and the Address Family from the left side of the window.

AF-Neighbor Tab—Detailed Description

The AF-Neighbor tab displays a single area: Neighbor Information.

Neighbor Information

Neighbor IP Address—Specifies the IP address of the neighbor router for the address family.

Remote AS—Specifies the neighbor routers autonomous system number. This value can range from 1 to 65535.

Activate—Enables the neighbor to exchange prefixes for the specified family type with the local router.

Neighbor Send Community—Specifies the community attribute sent in the route updates to a peer. The default is not to send community attribute in route updates.

Action

Add/Remove AF Neighbor—Clicking on the Add/Remove AF Neighbor button opens the BGP Address Family - Neighbor Configuration window.

BGP Address Family—Neighbor Configuration

The BGP Address Family - Neighbor Configuration window allows the user to add or remove neighbor configurations for BGP address families. To configure a Neighbor for an address family, proceed as follows:

Step 1 Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window”](#) section on page 14-27 for further details. Click on the AF—Neighbor Tab.


Step 2 Choose a chassis and the address family from the left side of the window.



Note You can choose multiple chassis and address families (from the list provided at the left side of the window) which allows you to launch the BGP Address Family - Neighbor Configuration window for the selected chassis.

Step 3 Click on the Add/Remove AF Neighbor button to open the BGP Address Family - Neighbor Configuration window.

Figure 14-24 BGP Address Family—Neighbor Configuration Window



- Step 4** Choose the chassis from the Chassis list and the address family from the Address Family List, for which you want to configure the Neighbor.
- Step 5** Edit the fields displayed in the window, as required.

BGP Address Family-Neighbor Configuration—Detailed Description

The Configure Neighbor window displays a list of Address Families and an area: Add/Remove Neighbor.

Address Family List—Displays a list of the address families.

Add/Remove Neighbor

Address Family—Unique identifier of the address family type.

VRF Name—Identifier of the VRF Name if the address family type is IPv4 VRF

Neighbor IP Address—This is used to configure the IP address of the neighbor router for the address family.

Remote AS—This is used to configure the neighbor router's autonomous system number. This value can range from 1 to 65535.



Note

This attribute is configurable only for the ipv4 unicast and ipv4 vrf address families.

Send Community—This is used to select the community attribute sent in the route updates to a peer. The default is not to send community attribute in route updates. The available options are: both, extended and standard.

Update Source—To enable or disable BGP sessions to use a specific operational interface for TCP connections. The available options are: No and Yes.

**Note**

The Update Source command in the device can specify any interface (physical, virtual, loopback) to be used as source IP address of the BGP session with the neighbor; but in the EM only the loopback interface can be specified. This attribute is configurable only for the ipv4 unicast and ipv4 vrf address families.

Loopback No—This is used to configure Router's Loopback Interface Number. This is valid only if Update-Source is set to YES.

**Note**

This attribute is configurable only for the ipv4 unicast and ipv4 vrf address families.

Action

Add Neighbor Entry—Clicking on the “Add Neighbor Entry” button, adds the neighbor entry for the BGP Address Family.


Remove Neighbor Entry—Clicking on the “Remove Neighbor Entry” button, removes the neighbor entry for the BGP Address Family.

Viewing the AF-Redistribute Tab on the BGP Address-Family Configuration Window

The AF-Redistribute tab displays the information about the redistribute protocols configured for a BGP address family. The user can add or remove the redistribute entries for an address family. To view the AF-Redistribute tab on the BGP Address Family Configuration window for a chassis, proceed as follows:

- Step 1** Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window”](#) section on page 14-27 for further details.
- Step 2** Click on the AF-Redistribute tab.

Figure 14-25 BGP Address-Family Configuration Window—AF-Redistribute Tab



Step 3 Choose the Chassis and the Address Family from the left side of the window.

AF-Redistribute Tab—Detailed Description

The AF-Redistribute tab displays a single area: Redistribute Information.

Redistribute Information

Protocol—Displays the protocol whose routes are redistributed by BGP. The redistribute configuration causes the corresponding routes to be redistributed into BGP.

AS/Tag—Indicates the Process ID of the redistributed protocol. A Positive Integer will indicate the process id of the redistributed protocol; a character string will indicate the ISO routing area tag.

IS-IS Route Level—Specifies the routing level of ISIS Protocol.

Redistribution Metric—Specifies the metric used for redistributed routes for this address family.

Action

Add/Remove AF Redistribute—Clicking on the “Add/Remove AF Redistribute” button opens the BGP Address Family - Redistribute Configuration window.

BGP Address Family—Redistribute Configuration

The BGP Address Family - Redistribute Configuration window allows the user to add or remove redistribute configurations for BGP address families. To configure the Redistribute protocol for an address family, proceed as follows:

Step 1 Open the BGP Address-Family Configuration window. See [“Viewing the AF-General Tab on the BGP Address-Family Configuration Window”](#) section on page 14-27 for further details. Click on the AF—Redistribute Tab.


Step 2 Choose a chassis and the address family from the left side of the window.



Note You can choose multiple chassis and address families (from the list provided at the left side of the window) which allows you to launch the BGP Address Family - Redistribute Configuration window for the selected chassis.

Step 3 Click on the Add/Remove AF Redistribute button to open the BGP Address Family - Redistribute Configuration.

Figure 14-26 BGP Address Family—Redistribute Configuration Window



Step 4 Choose the chassis from the Chassis list and the address family from the Address Family list, for which you want to configure the Redistribution protocol.

Step 5 Edit the fields displayed in the window, as required.

BGP Address Family-Configure Redistribute Protocol—Detailed Description

The BGP Address Family - Configure Redistribute Protocol window displays a list Address Families and an area: Add/Remove Redistribution Information.

Address Family—Displays a list of the address families.

Add/Remove Redistribution Information

Address Family—Specifies the address family type.

VRF Name—Identifier of the VRF Name if the address family type is ipv4 vrf

Protocol—This is used to set the protocol whose routes are redistributed by BGP Address Family. The redistribute configuration causes the corresponding routes to be redistributed into BGP. Valid Protocol Names that can be redistributed are connected, static, ospf, isis, igmp, eigrp, egp, rip, mobile, odr, dvmrp.

IS-IS Routing Level—This is used to choose the routing level of ISIS Protocol. The values for this field are: level-1, level-2 or level-1-2 when protocol is 'isis'.

Source ID—This is used to configure the Process ID of the redistributed protocol. A Positive Integer will indicate the process id of the redistributed protocol; a character string will indicate the ISO routing area tag. In case of protocols like CONNECTED and STATIC this attribute cannot be configured.

Metric—This is used to configure the metric used for redistributed routes.



Note

You cannot configure a redistribute protocol for vpnv4 address families.

Action

Add Redistribute Entry—Clicking on the Add Redistribute Entry button, adds the redistribution entry to the BGP Address Family on the device.

Remove Redistribute Entry—Clicking on the “Remove Redistribute Entry” button, removes the redistribution entry from the BGP Address Family on the device.

BGP Address-Family Status

The BGP Address Family Status window displays the BGP address family configurations existing on the device including basic BGP address family parameters information, path information, peer information and redistribution information. The BGP Address-Family Status section covers the following:


- [Viewing the BGP Address-Family Status window](#)
- [BGP Address-Family Status Window—Detailed Description](#)

Viewing the BGP Address-Family Status window

To view the BGP Address-Family Status window, proceed as follows:


-
- Step 1** Right click on the chassis and choose **Fault>BGP>BGP Address-Family Status**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the BGP Address-Family Status window. The AF-General tab displays the BGP address family parameters.

Figure 14-27 BGP Address-Family Status Window




- Step 2** Choose a Chassis and the address family from the list box displayed on the left side of the window. Choose the AF-Network tab, if required. The AF-Network tab displays the network paths and the associated path information for the BGP address family.

Figure 14-28 BGP Status—AF-Network Tab




- Step 3** Choose the AF-Neighbor tab, if required. The AF-Neighbor tab displays the neighbor information (peer) for a BGP address family.

Figure 14-29 BGP Status—AF-Neighbor Tab



- Step 4** Choose the AF-Redistribute tab, if required. The AF-Redistribute tab displays the information about the redistribute protocols configured for a BGP address family.

Figure 14-30 BGP Status—AF-Redistribute Tab



BGP Address-Family Status Window—Detailed Description

The BGP Address-Family Status window displays four tabs: AF-General, AF-Network, AF-Neighbor and AF-Redistribute.

AF-General

The AF-General tab displays two areas: BGP General and BGP Address Family Information.

BGP General

Local Autonomous System—The id of the BGP process running in the device. If the value is 0 it means no BGP process is running on the device.

BGP Address Family Information

Address Family—Unique identifier of the address family type.

VRF Name—Identifier of the VRF Name if the address family type is ipv4 vrf.

Auto Summary—Displays whether the automatic network number summarization is enabled/disabled for the address family.

Synchronization—Displays whether the BGP synchronization with IGP is enabled/disabled for the address family.

Default Metric—Displays the default metric value set for redistributed routes of the address family.

AF-Network

The AF—Network tab displays a single area: Network Information.

Network Information

Network Address—An IP address prefix in the Network Layer Reachability Information field. This object is an IP address containing the prefix with the length specified by the Prefix Len attribute. Any bits beyond the length specified by Network Mask attribute are zeroed.

Prefix Len—Length in bits of the IP address prefix in the network layer reachability information field.

Path Origin—The ultimate origin of the network path information.

Next Hop Ip Address—The address of the border router that should be used for the destination network.P

Metric—This metric is used to discriminate between multiple exit points to an adjacent autonomous number. A value of -1 indicates the absence of this attribute.

Degree of Preference—The originating BGP4 speaker's degree of preference for an advertised route. A value of -1 indicates the absence of this attribute.

Weightage—Specifies the BGP weight for the routing table.

Best Route—Specifies whether the network path is the best possible route. When set to true, it indicates that the network path is the best route for the router.

AF-Neighbor

The AF—Neighbor tab displays a single area: Neighbor Information.

Neighbor Information

Neighbor IP Address—Specifies the IP address of the neighbor router for the address family.

Remote AS—Specifies the neighbor routers autonomous system number. This value can range from 1 to 65535.

Activate—Enables the neighbor to exchange prefixes for the specified family type with the local router.

Neighbor Send Community—Specifies the community attribute sent in the route updates to a peer. The default is not to send community attribute in route updates.

AF-Redistribute

The AF—Redistribute tab displays a single area: Redistribute Information.

Redistribute Information

Protocol—Displays the protocol whose routes are redistributed by BGP. The redistribute configuration causes the corresponding routes to be redistributed into BGP.

AS/Tag—Indicates the Process ID of the redistributed protocol. A Positive Integer will indicate the process id of the redistributed protocol; a character string will indicate the ISO routing area tag.

IS-IS Route Level—Specifies the routing level of ISIS Protocol.

Redistribution Metric—Displays the metric used for redistributed routes for this address family.

OSPF Management

Open Shortest Path First (OSPF) is a TCP/IP internet routing protocol. OSPF is classified as an Interior Gateway Protocol (IGP). This means that it distributes routing information between routers belonging to a single Autonomous System (AS). The OSPF protocol is based on link-state or SPF technology based on Dijkstra's algorithm. Each OSPF router maintains an identical database describing the Autonomous System's topology. From this database, a routing table is calculated by constructing a shortest-path tree.

OSPF has been designed expressly for the TCP/IP internet environment, including explicit support for Classless Inter-Domain Routing (CIDR) and the tagging of externally-derived routing information. OSPF also provides for the authentication of routing updates, Variable Length Subnet Masks (VLSM), route summarization and utilizes IP multicast when sending/receiving the updates. OSPF recalculates routes quickly in the face of topological changes, utilizing a minimum of routing protocol traffic.

OSPF Configuration

The OSPF Configuration window allows the user to enable or remove OSPF configurations on a router. The OSPF configuration section covers the following topics:


- [Viewing the OSPF Configuration Window](#)
- [Config Tab—Detailed Description](#)
- [Adding an OSPF Process](#)
- [Removing an OSPF Process](#)
- [Viewing the Network Tab on the OSPF Configuration Window](#)
- [Network Tab—Detailed Description](#)
- [Configuring a Network](#)
- [Configure Network—Detailed Description](#)

Viewing the OSPF Configuration Window

To view the Config tab on the OSPF Configuration window for a chassis, proceed as follows:

-
- Step 1** Right click on the chassis object and choose **Configuration>OSPF>OSPF Configuration**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the OSPF Configuration window.

Figure 14-31 OSPF Configuration Window



Step 2 Choose the chassis from the left side of the window.

Config Tab—Detailed Description

The Config tab displays two areas: Add OSPF, Remove OSPF and a listbox, OSPF Process.

Config

Process ID—The OSPF process ID of the selected chassis.

OSPF Process—The OSPF processes currently configured for the selected chassis.

Action

Add OSPF Process—Adds the OSPF Process and Network details (Network Number, Network Mask and Area ID) to the selected chassis.


Remove OSPF Processes—Removes the OSPF Process from the selected chassis.

Adding an OSPF Process

This section explains the procedure to add an OSPF process to the device. To add an OSPF process, proceed as follows:

- Step 1** Open the OSPF configuration window. See “[Viewing the OSPF Configuration Window](#)” section on [page 14-47](#) for further details.
- Step 2** Enter an OSPF process id in the Process ID textbox.
- Step 3** Click on the Add OSPF Process button. An action report appears.

Figure 14-32 Action Report




Note The number of OSPF processes that can be created on a device depends on the number of interfaces (with IP address) present on the device.

Removing an OSPF Process

This section explains the procedure to remove an OSPF process from the device. To remove an OSPF process, proceed as follows:


- Step 1 Open the OSPF configuration window. See “[Viewing the OSPF Configuration Window](#)” section on page 14-47 for further details.
- Step 2 Choose the OSPF process from the OSPF Process list.
- Step 3 Click on the Remove OSPF Processes button. An action report appears.

Figure 14-33 Remove OSPF—Alert



- Step 4 Click on Yes to remove the OSPF process. An action report summarizing the Remove OSPF operation is displayed.

Figure 14-34 Action Report




Note Multiple OSPF processes can be selected and removed from the device.

Viewing the Network Tab on the OSPF Configuration Window

The Network tab allows the use to view the network entries configured on the device. To view the Network tab on the OSPF Configuration window for a chassis, proceed as follows:

- Step 1 Right click on the chassis object and choose **Configuration>OSPF>OSPF Configuration**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the OSPF Configuration window.
- Step 2 Click on the Network tab.

Figure 14-35 OSPF Configuration Window—Network Tab



Network Tab—Detailed Description

The Network tab displays a single area, Ospf Network.

Ospf Network

Process ID—The OSPF process ID of the selected chassis.

Network Number—The Network Number for corresponding Process ID of the selected chassis.

Network Mask—The Network Mask for corresponding Process ID of the selected chassis.

Area ID—The Area ID for corresponding Process ID of the selected chassis.

Action


Configure Network—Opens another window **Configure Network**.

Configuring a Network


The Configure Network window allows the user to associate or disassociate a network entry (IP address of interfaces) to the areas. To configure a network, proceed as follows:

- Step 1 Open the OSPF configuration window. See “[Viewing the OSPF Configuration Window](#)” section on page 14-47 for further details.
- Step 2 Choose the Network tab and click on the Configure Network button, the Configure Network window appears.


Figure 14-36 Configure Network Window



- Step 3 To add a network, enter the values in the textboxes and click on the Add Network button. An action report is displayed.

Figure 14-37 Action Report

- Step 4** To remove a network, enter the values in the textboxes and click on the Remove Network button. An action report is displayed.

Figure 14-38 Action Report

Configure Network—Detailed Description

The Configure Network window displays a single area: Configure Network.

Configure Network

Process ID—The OSPF process ID of the selected chassis.

Network Number—The Network Number for corresponding Process ID of the selected chassis.

Network Mask—The Network Mask for corresponding Process ID of the selected chassis.

Area ID—The Area ID for corresponding Process ID of the selected chassis.

OSPF Status

The OSPF Status window displays the OSPF configurations for a device. The OSPF Status section covers the following:


- [Viewing the OSPF Status Window](#)
- [OSPF Status—Detailed Description](#)

Viewing the OSPF Status Window

To view the OSPF status window for a chassis, proceed as follows:


-
- Step 1** Right click on the chassis and choose **Fault>OSPF>OSPF Status**. See [Table 14-1 on page 14-2](#) for information on which objects allow you to launch the OSPF Status window. The OSPF Status window appears with the General Group tab displayed. The General tab displays the attributes that apply globally to the OSPF processes configured on the router.

Figure 14-39 OSPF Status Window



- Step 2** Choose the Process Information tab, if required. The Process Information tab displays Process Information tab displays two areas, Process Summary and Network Details. The Process Summary details all processes that exist on the device. This includes its Router id, number of areas configured, number of normal areas, number of stub areas, and number of nssa areas. The Network Details lists the networks configured on OSPF processes and also VRF/VPN instance associated with OSPF process(if any). It includes associated VPN/ VRF Instance (if any), Network entries (Network number, N/w Mask, Area id).

Figure 14-40 OSPF Status—Process Information Tab



Step 3 Choose the Area tab, if required. The Area tab displays the complete information describing the configured parameters and cumulative statistics of one of the router's attached areas.

Figure 14-41 OSPF Status—Area Tab

OSPF Status

File Options Window Help

General Group Process Information Area Interface Neighbor Link State Host

Area

OSPF Area ID	Auth Type	Import AS Extern	SPF Runs	Area Border Rou
1.2.3.4	1	true	1999	675
1.2.3.5	1	true	2052	728
1.2.3.6	1	true	1936	1104
1.2.3.7	1	true	2014	923

Stub Area

Stub TOS	Stub Area ID	Stub Metric	Stub Status
1	1.2.3.4	1	valid
2	1.2.3.4	1	valid
3	1.2.3.4	1	valid
4	1.2.3.4	1	valid
5	1.2.3.4	1	valid

Area Range


Area Range ID	Area Range Net	Area Range Mask	Area Range Status
1.2.3.4	1.2.3.4	1.2.3.4	valid
1.2.3.4	1.2.3.5	1.2.3.4	valid
1.2.3.4	1.2.3.6	1.2.3.4	valid
1.2.3.4	1.2.3.7	1.2.3.4	valid
1.2.3.4	1.2.3.8	1.2.3.4	valid

Chassis

Status: CiscoRoutingFunctionality (normal) Dynamic updates are enabled


- Step 4** Choose the Interface tab, if required. The Interface tab displays the complete information about the interfaces and their statistics.

Figure 14-42 OSPF Status—Interface Tab




Step 5 Choose the Neighbor tab, if required. The Neighbor tab displays all the neighbors in the locality of the selected router.

Figure 14-43 OSPF Status—Neighbor Tab




- Step 6** Choose the Link State tab, if required. The Link State tab displays the Link State Advertisements from the areas that the device is attached to.

Figure 14-44 OSPF Status—Link State Tab



Step 7 Choose the Host tab, if required. The Host tab displays hosts that are directly attached to the router, and their metrics and types of service advertised for them.

Figure 14-45 OSPF Status—Host Tab



OSPF Status—Detailed Description

The OSPF Status window displays seven tabs: General Group, Process information, Area, Interface, Neighbor, Link State and Host.

General Group

The General Group tab displays a single area, General.

Router ID—Unique identifier of the router in the AS.

Version—Displays the current version number of the OSPF protocol

TOS Support—Specifies the router's support for type-of-service routing

External LSA Count—The number of external (LS type 5) link-state advertisements in the link-state database.

Originated New LSA Count—The number of new link-state advertisements that have been originated. This number is incremented each time the router originates a new LSA.

Admin Status—The administrative status of the OSPF protocol in the router. When the value is set to enabled, it signifies that the OSPF Process is active on at least one interface and when the value is set to disabled, the OSPF process is disabled on all the interfaces.

Received New LSA Count—The number of link-state advertisements received determined to be new instantiations. This number does not include newer instantiations of self-originated link-state advertisements.

AS Border Router—A flag to indicate whether this router is an Autonomous System Border router.

Area Border Router—A flag to indicate whether this router is an area border router.

ExternalLSA Checksum—LS checksums of the external link-state advertisements contained in the link-state database. This sum can be used to determine if there has been a change in a router's link state database, and to compare the link-state database of two routers.

Process Information

Process Information tab displays two areas: Process Summary and Network Details.

Process Summary

This table lists all processes that exist on the device. This includes its Router id, number of areas configured, number of normal areas, number of stub areas, and number of nssa areas.

Process Id—Unique identifier for a OSPF Process.

Router Id—Unique identifier of the router in the AS.

Domain Id—Domain Identifier, will be set when VRF is associated with this OSPF Process.

No. of Areas Configured—Displays the count of total number of areas configured on this OSPF Process.

Normal Areas—Displays the count of total number of "Normal" areas configured on this OSPF Process.

Stub Areas—Displays the count of total number of "Stub" areas configured on this OSPF Process.

Nssa Areas—Displays the count of total number of "nssa" areas configured on this OSPF Process.

Network Details

This table lists the networks configured on OSPF processes and also VRF/VPN instance associated with the OSPF process (if any). This includes associated VPN/ VRF Instance (if any), Network entries (Network number, N/w Mask, Area id).

Process Id—Unique identifier for a OSPF Process.

N/W IP Address—Network IP Address

Subnet Mask—Subnet Mask

Area Id—Area ID on which this process is configured.

VRF Associated—Associated VRF name(if any). else, "None".

Area

The Area tab displays three areas: Area, Stub Area and Area Range.

Area

OSPF Area ID—Unique identifier of the area.

Auth Type—The authentication type specified for an area. Additional authentication types may be assigned locally on a per Area basis.

Import AS Extern—The area's support for importing AS external link-state advertisements.

SPF Runs—The number of times that the intra-area route table has been calculated using this area's link-state database.

Area Border Router Count—The total number of area border routers reachable within this area.

AS Border Router Count—The total number of Autonomous System border routers reachable within this area.

Area LSA Count—The total number of link-state advertisements in this area's link-state database, excluding AS External LSA's.

Area LSA Checksum—Link-state advertisements' LS checksums contained in this area's link-state database.

Stub Area

Stub TOS—The Type of Service associated with the metric.

Stub Area ID—Unique identifier for a Stub area.

Stub Metric—The metric value applied at the indicated type of service. By default, this equals the least metric at the type of service among the interfaces to other areas.

Stub Status—This variable displays the validity or invalidity of the entry. When this value is set to invalid, it has the effect of rendering it inoperative.

Area Range

Area Range ID—The Area the Address Range is to be found within.

Area Range Net—The IP Address of the Net or Subnet indicated by the range.

Area Range Mask—The Subnet Mask that pertains to the Net or Subnet.

Area Range Status—Displays the validity or invalidity of the entry. When this value is set to invalid, it has the effect of rendering it inoperative.

Interface

The Interface tab displays three areas: Interface, Interface Metric and Virtual Interface.

Interface

Addressless Interface—Differentiates the addressless interfaces from the addressed interfaces. When the value is set to zero, it signifies that the interface has an IP address.

Interface IP Address—The IP address of the OSPF interface.

Interface Area ID—Unique identifier of the area to which the interface connects. Area ID 0.0.0.0 is used for the OSPF backbone.

Interface Type—The type of the Interface.

Interface Admin Status—The OSPF interface's administrative status. When the value is set to enabled, it signifies that the neighbor relationships may be formed on the interface, and the interface is advertised as an internal route to some area. When the value is set to disabled, it signifies that the interface is external to OSPF.

Router Priority—The priority of this interface. When the value is set to 0, it signifies that the router is not eligible to become the designated router on this particular network.

Transit Delay—The estimated number of seconds it takes to transmit a link-state update packet over this interface.

Interface Retransmit Interval—The number of seconds between the link-state advertisement retransmissions, for adjacencies belonging to this interface. This value is also used when retransmitting database description and link-state request packets.

Hello Interval—The time interval, in seconds, between the Hello packets that the router sends on the interface. This value must be the same for all the routers attached to a common network.

Router Dead interval—The time interval, in seconds, during which a router's Hello packets are not received before it's neighbors declare the router down. This is a multiple of the Hello interval. This value must be the same for all the routers attached to a common network.

Poll Interval—The larger time interval, in seconds, between the Hello packets sent to an inactive non-broadcast multi-access neighbor.

Interface State—The OSPF Interface State.

Designated Router—The IP Address of the Designated Router.

Backup Designated router—The IP Address of the Backup Designated Router.

Interface Events—The number of times this OSPF interface has changed its state, or an error has occurred.

Interface Metric

Addressless Interface—Differentiates the addressless interfaces from the addressed interfaces. When the value is set to zero, it signifies that the interface has an IP address.

Interface Metric TOS—The type of service metric being referenced.

Interface Metric IP Address—The IP address of this OSPF interface.

Metric—The metric of using this type of service on this interface. The default value of the TOS 0 Metric is $10^8 / \text{ifSpeed}$.

Metric Status—Displays the validity or invalidity of the entry. Setting it to 'invalid' has the effect of rendering it inoperative.

Virtual Interface

Vir Interface Neighbor—The Router ID of the Virtual Neighbor.

Vir Interface Area ID—The Transit Area that the Virtual Link traverses.

Vir Interface Transit Delay—The estimated number of seconds it takes to transmit a link-state update packet over this interface.

Vir Interface Retransmit Interval—The number of seconds between link-state advertisement retransmissions, for adjacencies belonging to this interface. This value is also used when retransmitting the database description and link-state request packets. This value should be greater than the expected round-trip time.

Vir Interface Hello Interval—The time interval, in seconds, between the Hello packets that the router sends on the interface. This value must be the same for the virtual neighbor.

Vir Interface Router Dead Interval—The time interval, in seconds, during which a router's Hello packets are not received before it's neighbors declare the router down. This is a multiple of the Hello interval. This value must be the same for the virtual neighbor.

Vir Interface State—Signifies the OSPF virtual interface states.

Vir Interface Events—The number of state changes or error events on this virtual link.

Vir Interface Status—Displays the validity or invalidity of the entry. Setting it to 'invalid' has the effect of rendering it inoperative.

Neighbor

The Neighbor tab displays two areas: Neighbor and Virtual Neighbor.

Neighbor

Neighbor IP Address—The IP address of this Neighbor.

Addressless Interface—Differentiates the addressless interfaces from the addressed interfaces. When the value is set to zero, it signifies that the interface has an IP address.

Neighbor Router ID—Unique identifier of the neighboring router in the Autonomous System.

Neighbor Options—A bit mask corresponding to the neighbor's options field. When the value is set to 0, it indicates that the area accepts and operates on external information. If the value is zero, it signifies a stub area. When the value is set to 1, it indicates that the system operates on the type of service metrics other than TOS 0. If the value is zero, the neighbor ignores all the metrics except the TOS 0 metric.

Neighbor Priority—Signifies the priority of this neighbor in the designated router. When the value is set to 0, it signifies that the neighbor is not eligible to become the designated router on this particular network.

Neighbor State—The state of the relationship with this Neighbor.

Neighbor Events—The number of times this neighbor relationship has changed state, or an error has occurred.

Neighbor LS Retransmit Q Len—The current length of the retransmission queue.

NBMA Neighbor Status—Displays the validity or invalidity of the entry. Setting it to 'invalid' has the effect of rendering it inoperative.

Virtual Neighbor

Vir Nbr Area—The identifier of the Transit Area.

Vir Nbr Router ID—An integer that uniquely identifies the neighboring router in the Autonomous System.

Vir Nbr IPAddr—The IP address that is used by this Virtual Neighbor.

Vir Nbr Options—A bit map corresponding to the neighbor's options field. Thus, Bit 1, if set, indicates that the neighbor supports Type of Service Routing; if zero, no metrics other than TOS 0 are in use by the neighbor.

Vir Nbr State—The state of the Virtual Neighbor Relationship.

Vir Nbr Events—The number of times this virtual link has changed its state, or an error has occurred.

Vir Nbr LS Retransmit Q Len—The current length of the retransmission queue.

Link State

The Link State tab displays a single area namely, Lsdb

Lsdb

LSDB LSID—The Link State ID is an LS Type Specific field containing either a Router ID or an IP Address.

LSDB RouterID—Displays the number that uniquely identifies the originating router in the Autonomous System.

LSDB Type—The type of the link state advertisement. Each link state type has a separate advertisement format.

LSDB Area ID—Unique identifier of the Area from which the LSA was received.

LSDB Sequence—Detects the old and duplicate link state advertisements. The larger the sequence number the more recent is the advertisement.

LSDB Age—Signifies the age of the link state advertisement in seconds.

LSDB Checksum—Displays the checksum of the complete contents of the advertisement, except the age field.

Host

The Host tab displays a single area namely, Hosts.

Hosts

Host TOS—The Type of Service of the route being configured.

Host IP Address—The IP Address of the Host

Host Metric—The Metric to be advertised.

Host Status—Displays the validity or invalidity of the entry. When this value is set to invalid, it has the effect of rendering it inoperative.



MPLS Management

This chapter describes the Multi Protocol Label Switching (MPLS) management tasks that can be performed using the Cisco 12000/10720 Router Manager application.

This chapter details the following information:

- [Introduction](#)
- [MPLS Management Workflow](#)
- [Launching the MPLS Management Windows](#)
- [MPLS Forwarding Information](#)
- [Fault Management for MPLS LSR Interfaces](#)
 - [MPLS Interface Status](#)
 - [MPLS Interface Information](#)
- [Performance Management for MPLS LSR Interfaces](#)
 - [MPLS Interface Performance](#)
- [Fault Management for MPLS LDP](#)
 - [MPLS LDP Entity Status Window](#)
 - [MPLS LDP Hello Adjacencies](#)
 - [MPLS LDP Peer Status](#)
- [Fault Management for MPLS Traffic Engineering](#)
 - [MPLS Tunnel Information](#)

Introduction

Multiprotocol Label Switching (MPLS) fuses the intelligence of routing with the performance of switching and provides significant benefits to networks with a pure IP architecture as well as those with IP and ATM or a mix of other Layer 2 technologies. MPLS technology is key to scalable virtual private networks (VPNs) and end-to-end quality of service (QoS), enabling efficient utilization of existing networks to meet future growth and rapid fault correction of link and node failure. Similar to Layer 2 networks (for example, Frame Relay or ATM), MPLS assigns labels to packets for transport across packet- or cell-based networks. The forwarding mechanism throughout the network is label swapping, in which units of data (for example, a packet or a cell) carry a short, fixed-length label that tells switching nodes along the packet's path how to process and forward the data.

The significant difference between MPLS and traditional WAN technologies is the way labels are assigned and the capability to carry a stack of labels attached to a packet. The concept of a label stack enables new applications, such as Traffic Engineering (TE), Virtual Private Networks (VPN), fast rerouting around link and node failures, and so on.

Packet forwarding in MPLS is in stark contrast to today's connection less network environment, where each packet is analyzed on a hop-by-hop basis, its Layer 3 header is checked, and an independent forwarding decision is made based on the information extracted from a network layer routing algorithm.

A router supporting MPLS is a Label Switch Router, or LSR. An edge node is an LSR connecting to a non-LSR. An ingress LSR is the one by which a packet enters the MPLS network, an egress LSR is one by which a packet leaves the MPLS network. Labels are small identifiers placed in the traffic. They are inserted by the ingress LSR, and ultimately removed by the egress LSR (so nothing will remain to perplex the non-MPLS devices outside the MPLS network). For IP-based MPLS, some bytes are inserted prior to the IP header. For ATM, the VPI/VCI addressing is the label. For Frame Relay, the DLCI is the label.

MPLS technology also helps deliver highly scalable, differentiated end-to-end IP services with simpler configuration, management, and provisioning for both Internet providers and subscribers.

The Cisco 12000/10720 Router Manager focuses on providing basic troubleshooting capabilities for MPLS configuration set-up in the Cisco 12000 and 10720 Series Routers. The Cisco 12000/10720 Router Manager provides the following MPLS functionality:

- Fault Management for LSR Interfaces, Label Distribution Protocol (LDP) entities and MPLS tunnels.
- Performance Management for MPLS enabled interfaces.
- Creation and association of VRFs.
- Fault Management for VRFs.
- MPLS trap management.

MPLS Management Workflow

The MPLS Management workflows covered in this chapter are:

- [MPLS Forwarding Information](#)
- [Fault Management for MPLS LSR Interfaces](#)
 - [MPLS Interface Status](#)
 - [MPLS Interface Information](#)
- [Performance Management for MPLS LSR Interfaces](#)
 - [MPLS Interface Performance](#)
- [Fault Management for MPLS LDP](#)
 - [MPLS LDP Entity Status Window](#)
 - [MPLS LDP Hello Adjacencies](#)
 - [MPLS LDP Peer Status](#)
- [Fault Management for MPLS Traffic Engineering](#)
 - [MPLS Tunnel Information](#)

Launching the MPLS Management Windows

Table 15-1 displays the MPLS Management windows that can be launched from various object types. For example, the MPLS Forwarding Information window can be launched from a Site, or Chassis object, but cannot be launched from a Module or an Interface object.



Note

Table 15-1 lists the menu options to launch the MPLS Management dialogs from the site level.

Table 15-1 Launching the MPLS Management Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window						Menu Options to Select to Open Window
	Site	Chassis		Module	Interface	VRF	
		12000 Series	10720				
MPLS Forwarding Information	Yes	Yes	Yes	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS Forwarding Information
MPLS Interface Status	Yes	Yes	Yes	Yes	Yes	No	Cisco 12000/10720 Manager> Fault> Interface> MPLS> Status
MPLS Interface Information	Yes	Yes	Yes	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS Interface Information
MPLS Interface Performance	Yes	Yes	Yes	Yes	Yes	No	Cisco 12000/10720 Manager> Performance> Interface> MPLS> Performance
MPLS LDP Entity Status Window	Yes	Yes	Yes	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS LDP Entity Status
MPLS LDP Hello Adjacencies	Yes	Yes	Yes	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS LDP Hello Adjacencies
MPLS LDP Peer Status	Yes	Yes	Yes	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS LDP Peer Status
MPLS Tunnel Information	Yes	Yes	Yes	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS Tunnel Information



Note

The Cisco 12000/10720 Router Manager MPLS Management windows cannot be opened when multiple objects are selected (the menu options to open the windows are grayed out). Available menu options can be launched from a site object containing the required objects.

MPLS Forwarding Information

The MPLS Forwarding Information window allows the user to view the label forwarding information, for any packet, on a managed chassis configured as an MPLS Label Switch Router (LSR). Using this information the user can traverse the path of a LSP to view the exact forwarding path of a packet given its label.

**Note**

The MPLS Forwarding Information window uses IOSDrep for configuration and population of the attributes. The user needs to configure the management information for the chassis against which the MPLS Forwarding Information window is launched.

The MPLS Forwarding Information section covers the following:


- [Viewing the MPLS Forwarding Information Window](#)
- [MPLS Forwarding Information Window—Detailed Description](#)

Viewing the MPLS Forwarding Information Window

To view the MPLS Forwarding Information window, proceed as follows:

-
- Step 1** Right click on an appropriate object and choose **Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS Forwarding Information**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the MPLS Forwarding Information window. The MPLS Forwarding Information window appears, with the MPLS Forwarding Information tab displayed.

Figure 15-1 MPLS Forwarding Information Window—MPLS Forwarding Information Tab



- Step 2** Choose a **Chassis** from the list box displayed at the left of the window. The MPLS forwarding information for the selected chassis appears at the right hand side of the window. For further information, see the “[MPLS Forwarding Information Window—Detailed Description](#)” section on page 15-5.

MPLS Forwarding Information Window—Detailed Description

The MPLS Forwarding Information window (see [Figure 15-1](#)) displays a single MPLS Forwarding Information tab.

MPLS Forwarding Information Tab

The MPLS Forwarding Information tab displays a table with the following information:

Local Tag—Local label assigned by the LSR.

Outgoing Interface—Displays information about the outgoing interface to which packets are switched.

Outgoing Tag/VC Tag—Displays information about the label attached to the outgoing packet, which is learned from the downstream router.

Prefix/Tunnel Id—Displays the IP address of the egress interface or tunnel ID for the incoming packet.

Bytes Switched—Bytes Switched across the LSR.

Next Hop—Displays information about the next hop address.

Fault Management for MPLS LSR Interfaces

This section describes Fault Management for MPLS LSR interfaces. This section provides the following information:

- [“MPLS Interface Status” section on page 15-6](#)
- [“MPLS Interface Information” section on page 15-8](#)

MPLS Interface Status

The MPLS Interface Status window displays information about MPLS configuration and capability for the interfaces on a managed chassis (12000 Series and Cisco 10720). For any interfaces that have MPLS configured, that is, having an MPLS layer active, their current configuration is displayed in the MPLS Interface Status window. The MPLS Interface Status window can also be used to verify if MPLS is enabled on the selected interface, or if sufficient interface buffer space is available.



Note

You can view the MPLS Sub-interface status using the MPLS Interface Information window (which can be launched from the chassis level). See the [“MPLS Interface Information” section on page 15-8](#) for further details.

The MPLS Interface Status section covers the following:

- [Viewing the MPLS Interface Status Window](#)
- [MPLS Interface Status Window—Detailed Description](#)

Viewing the MPLS Interface Status Window

To view the MPLS Interface Status window, proceed as follows:

- Step 1** Right click on an appropriate object and choose **Cisco 12000/10720 Manager> Fault> Interface> MPLS> Status**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the MPLS Interface Status window. The MPLS Interface Status window appears, with the Interface Setup tab displayed.

Figure 15-2 MPLS Interface Status Window—Interface Setup Tab



- Step 2** Choose a **Chassis**, **Module** and then **Interface** from the list box displayed at the left of the window. The MPLS Interface Status Details information for the selected interface appears. For further information, see the “[MPLS Interface Status Window—Detailed Description](#)” section on page 15-7.

MPLS Interface Status Window—Detailed Description

The MPLS Interface Status window (see [Figure 15-2](#)) displays a single Interface Setup tab.

Interface Configuration Tab

The Interface Setup tab displays a General and an MPLS area.

General

The General area displays the following information:

Operational Status—Displays information about the current operational status of the selected MPLS active interface (up or down).

Last Change—Displays the value of the sysUpTime at the time the MPLS active interface entered its current operational status.

MTU—Displays the size of the largest packet that can be sent/received on the selected MPLS active interface.

Counter Discontinuity Time—Displays the value of the sysUpTime on the most recent occasion at which any one or more of this MPLS active interfaces counters suffered a discontinuity.

MPLS

The MPLS area displays the following information:

Min Label In—This is the minimum value of an MPLS label that this LSR is willing to receive on this interface.

Max Label In—This is the maximum value of an MPLS label that this LSR is willing to receive on this interface.

Available Buffer—This value reflects the total amount of buffer space available on this interface.

Available Bandwidth—This value indicates the total amount of available bandwidth available on this interface and is specified in kilobits per second (Kbps). This value is calculated as the difference between the amount of bandwidth currently in use and that specified in `mplsInterfaceTotalBandwidth`.

Label Participation Type—Per platform or per interface setting.

Conf Storage Type—Displays the storage type for this entry.

Min Label Out—This is the minimum value of an MPLS label that this LSR is willing to send on this interface.

Max Label Out—This is the maximum value of an MPLS label that this LSR is willing to send on this interface.

Total Buffer—This value indicates the total amount of buffer space allocated for this interface.

Total Bandwidth—This value indicates the total amount of usable bandwidth on this interface and is specified in kilobits per second (Kbps).

MPLS Interface Information

The MPLS Interface Information window displays the MPLS configuration and performance details for any MPLS enabled interfaces and sub-interfaces on a managed chassis (12000 Series and 10720). The MPLS Interface Information window also helps to overcome the limitations with MPLS Interface Status and MPLS Interface Performance windows which cannot be used for viewing the status and performance details of MPLS interfaces and sub-interfaces.

The MPLS Interface Information section covers the following:


- [Viewing the MPLS Interface Information Window](#)
- [MPLS Interface Information Window—Detailed Description](#)

Viewing the MPLS Interface Information Window

To view the MPLS Interface Information window, proceed as follows:

-
- Step 1** Right click on an appropriate object and choose **Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS Interface Information**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the Interface Information window. The MPLS Interface Information window appears, with the Interface Setup tab displayed.

Figure 15-3 MPLS Interface Information Window—Interface Setup Tab



- Step 2** Choose a **Chassis** from the list displayed at the left side of the window.
- Step 3** Choose an **MPLS Interface/Subinterface** from the list displayed in the Select Interface area. For further details on the information displayed in this window, see the “[MPLS Interface Information Window—Detailed Description](#)” section on page 15-9.

MPLS Interface Information Window—Detailed Description

The MPLS Interface Information window displays four tabs: Interface Setup, MPLS Setup, Interface Performance, and the MPLS Performance tab.

Interface Setup Tab

The Interface Setup tab (see [Figure 15-3](#)) displays a single Select Interface area.

Select Interface

The Select Interface area displays the following information:

MPLS Interface/Subinterface list—Lists all the MPLS enabled interfaces and MPLS enabled sub-interfaces on the selected chassis.

Operational Status—Displays information about the current operational status of the selected interface (up or down).

MTU—Displays the size of the largest packet that can be sent/received on the selected interface.


Last Change—Displays the value of the sysUpTime at the time the interface entered its current operational status.

Counter Discontinuity Time—Displays the value of the sysUpTime on the most recent occasion at which any one or more of this interfaces counters suffered a discontinuity.

MPLS Setup Tab

The MPLS Setup tab (see [Figure 15-4](#)) displays a single Select Interface area.

Figure 15-4 MPLS Interface Information Window—MPLS Setup Tab



Select Interface

The Select Interface area displays MPLS interface configuration information as follows:

MPLS Interface/Subinterface list—Lists all the MPLS enabled interfaces and MPLS enabled sub-interfaces on the selected chassis.

Min Label In—Displays the minimum value of an MPLS label that this LSR is willing to receive on this interface.

Min Label Out—Displays the minimum value of an MPLS label that this LSR is willing to send on this interface.

Max Label In—Displays the maximum value of an MPLS label that this LSR is willing to receive on this interface.

Max Label Out—This is the maximum value of an MPLS label that this LSR is willing to send on this interface.

Available Buffer—This value reflects the total amount of buffer space available on this interface. This variable is not applicable when applied to the interface with index 0.

Total Buffer—This value indicates the total amount of buffer space allocated for this interface. This variable is not applicable when applied to the interface with index 0.

Available Bandwidth—This value indicates the total amount of available bandwidth available on this interface and is specified in kilobits per second (Kbps). This value is calculated as the difference between the amount of bandwidth currently in use and that specified in `mplsInterfaceTotalBandwidth`. This variable is not applicable when applied to the interface with index 0.

Total Bandwidth—This value indicates the total amount of usable bandwidth on this interface and is specified in kilobits per second (Kbps). This variable is not applicable when applied to the interface with index 0.


Label Participation Type—Displays either the per platform or per interface setting.

Conf Storage Type—The storage type for this entry.

Interface Performance Tab

The Interface Performance tab (see [Figure 15-5](#)) displays a single Select Interface area.

Figure 15-5 MPLS Interface Information Window—Interface Performance Tab



Select Interface

The Select Interface area displays the following information:

MPLS Interface/Subinterface list—Lists all the MPLS enabled interfaces and MPLS enabled sub-interfaces on the selected chassis.

In Octets—Displays the total number of octets received on the selected interface including framing characteristics.

Out Octets—Displays the total number of octets transmitted from the interface including framing characteristics.

In Unicast Packets—Displays the number of packets delivered by this sub-layer to a higher sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer.

Out Unicast Packets—Displays the total number of packets that higher level protocols requested be transmitted and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.

In Octets (64 bit)—Displays the total number of 64 bit octets received on the selected interface including framing characteristics.

Out Octets (64 bit)—Displays the total number of 64 bit octets transmitted from the interface including framing characteristics.


In Unicast Packets (64 bit)—Displays the number of 64 bit packets delivered by this sub-layer to a higher sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer.

Out Unicast Packets (64 bit)—Displays the total number of 64 bit packets that higher level protocols requested be transmitted and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.

MPLS Performance Tab

The Interface Performance tab (see [Figure 15-6](#)) displays a single Select Interface area.

Figure 15-6 MPLS Interface Information Window—MPLS Performance Tab



Select Interface

The Select Interface area displays the following information:

MPLS Interface/Subinterface list—Lists all the MPLS enabled interfaces and MPLS enabled sub-interfaces on the selected chassis.

In Labels Used—This value indicates the specific number of labels that are in use at this point in time on this interface in the incoming direction.

In Discards—The number of inbound labeled packets, which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a labeled packet could be to free up buffer space.

In Packets—This variable reflects the number of labeled packets that have been received on this interface.

Out Labels Used—Indicates the number of top-most labels in the outgoing label stacks that are in use at this point in time on this interface.

Out Discards—The number of outbound labeled packets, which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a labeled packet could be to free up buffer space.

Out Packets—Displays the number of labeled packets that have been transmitted on this interface.

Out Fragments—Displays the number of outgoing MPLS packets that required fragmentation before transmission on this interface.

Performance Management for MPLS LSR Interfaces

This section describes performance management for MPLS LSR interfaces.

MPLS Interface Performance

The MPLS Interface Performance window provides information about MPLS performance attribute information for interfaces on a managed Chassis (Cisco 12000 and 10720 Series Routers). For any interfaces that have MPLS configured, that is, having an MPLS layer active, their current performance attributes are displayed in the MPLS Interface Performance window.



Note

The performance attributes displayed in the MPLS Interface Performance window can be collected at 15-minute intervals by enabling performance polling on the selected interface (or globally at chassis level). See the [“Starting Global Performance Logging” section on page 4-9](#) for further information on starting performance logging globally on a per chassis basis, or see the [“Starting Performance Logging for a Selected Interface” section on page 10-5](#) for further information on starting performance logging on a per interface basis.



Note

You can view the MPLS sub-interface performance details through the MPLS Interface Information window (which can be launched from the chassis level). See the [“MPLS Interface Information” section on page 15-8](#) for further details.

The MPLS Interface Performance section covers the following:


- [Viewing the MPLS Interface Performance Window](#)
- [MPLS Interface Performance Window—Detailed Description](#)

Viewing the MPLS Interface Performance Window

To view the MPLS Interface Performance window, proceed as follows:

- Step 1** Right click on an appropriate object and choose **Cisco 12000/10720 Manager> Performance> Interface> MPLS> Performance**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the MPLS Interface Performance window. The MPLS Interface Performance window appears, with the General Performance Statistics tab displayed.

Figure 15-7 MPLS Interface Performance Window—General Performance Statistics Tab



- Step 2** Choose a **Chassis**, **Module** and **Interface** from the list box displayed at the left of the window. The MPLS interface performance information appears for the selected interface. For further information, see the “[MPLS Interface Performance Window—Detailed Description](#)” section on page 15-15.

MPLS Interface Performance Window—Detailed Description

The MPLS Interface Performance window provides MPLS performance information on a per-interface basis for every interface on which MPLS has been enabled. The MPLS Interface Performance window displays two tabs: General Performance Statistics, and MPLS Performance Statistics.

General Performance Statistics Tab

The General Performance Statistics tab (see [Figure 15-7](#)) displays two areas, Counters and High Speed Counters.

Counters

The Counters area displays the following information:

In Octets—Displays the total number of octets received by the MPLS layer on the selected interface including framing characteristics.

Out Octets—Displays the total number of octets transmitted by the MPLS layer from the interface including framing characteristics.

In Unicast Packets—Displays the number of packets delivered by this sub-layer to a higher sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer.

Out Unicast Packets—Displays the total number of packets that higher level protocols requested be transmitted and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.

High Speed Counters



Note

Only the High Speed Counters (64bit counters) from the General Performance Statistics tab will be available for collection and not the 32bit counters. Data shown in Performance Statistics tab is also available for collection.

The High Speed Counters area displays the following information:

In Octets (64 bit)—Displays the total number of 64 bit octets received by the MPLS layer on the selected interface including framing characteristics.

Out Octets (64 bit)—Displays the total number of 64 bit octets transmitted by the MPLS layer from the interface including framing characteristics.


In Unicast Packets (64 bit)—Displays the number of 64 bit packets delivered by this sub-layer to a higher sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer.

Out Unicast Packets (64 bit)—Displays the total number of 64 bit packets that higher level protocols requested be transmitted and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.

MPLS Performance Statistics Tab

The MPLS Performance Statistics tab (see [Figure 15-8](#)) displays the Failed Label Lookups attribute and Incoming Direction and Outgoing Direction areas.

Figure 15-8 MPLS Interface Performance Window—MPLS Performance Statistics Tab



Failed Label Lookups—Displays the number of labeled packets that have been received on this interface and were discarded because there were no matching entries found for forwarding them.

Incoming Direction

The Incoming Direction area displays the following information:

In Labels Used—This value indicates the specific number of labels that are in use at this point in time on this interface in the incoming direction.

In Discards—The number of inbound labeled packets, which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a labeled packet could be to free up buffer space.

In Packets—This variable reflects the number of labeled packets that have been received on this interface.

Outgoing Direction

The Outgoing Direction area displays the following information:

Out Labels Used—Indicates the number of top-most labels in the outgoing label stacks that are in use at this point in time on this interface.

Out Discards—The number of outbound labeled packets, which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a labeled packet could be to free up buffer space.

Out Packets—Displays the number of labeled packets that have been transmitted on this interface.

Out Fragments—Displays the number of outgoing MPLS packets that required fragmentation before transmission on this interface.

Fault Management for MPLS LDP

MPLS is packet forwarding technology that uses a short, fixed length value called “Label” in packets to determine the next hop for packet transport through an MPLS network by means of label switching router (LSRs). The label agreement is achieved in an MPLS network by means of procedures defined in the Label Distribution Protocol (LDP).

This section describes fault management for MPLS Label Distribution Protocol (LDP). This section describes the following information:

- [MPLS LDP Entity Status Window, page 15-18](#)
- [MPLS LDP Hello Adjacencies, page 15-26](#)
- [MPLS LDP Peer Status, page 15-28](#)

MPLS LDP Entity Status Window


The MPLS LDP Entity Status window displays information related to LDP entities on a selected router.

Viewing the MPLS LDP Entity Status Window

To view the MPLS LDP Entity Status window, proceed as follows:

-
- Step 1** Right click on an appropriate object and choose **Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS LDP Entity Status**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the LDP Entity Status window. The MPLS LDP Entity Status window appears, with the Entity tab displayed.

Figure 15-9 MPLS LDP Entity Status Window—Entity Tab



Step 2 Choose a **Chassis** from the list box displayed at the left of the window. Information on LDP entities is displayed for the selected chassis.

MPLS LDP Entity Status Window—Detailed Description

The MPLS LDP Entity Status window displays five tabs: Entity, Entity Statistics, General Label Range, ATM Parameters, ATM Label Range.

Entity Tab

The Entity tab (see [Figure 15-9](#)) displays basic information about LDP entities. The Entity tab displays two areas, General and General LDP Status.

General

The General area displays the following information:

LSR Identifier—The LSRs identifier.

LSR Loop Detection—A indication of whether this Label Switch Router supports loop detection:

- none—Loop Detection is not supported on this LSR.
- other—Loop Detection is supported but by a method other than those listed below.
- hopCount—Loop Detection is supported by Hop Count only.
- pathVector—Loop Detection is supported by Path Vector only.

- **hopCountAndPathVector**—Loop Detection is supported by both Hop Count And Path Vector. Since Loop Detection is determined during Session Initialization, an individual session may not be running with loop detection. This object simply gives an indication of whether or not the LSR has the ability to support Loop Detection and which types.

General LDP Status

The General LDP Status area displays a table that displays information about the MPLS Label Distribution Protocol Entities which exist on this Label Switch Router (LSR). An entry in this table represents an LDP entity. An entry can be created by a Network Administrator or by an SNMP agent as instructed by LDP.

The table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Protocol Version—The version number of the LDP protocol that will be used in the session initialization message.

Admin Status—The administrative status of this LDP entity.

Operational Status—The operational status of this LDP entity.

TCP Dsc Port—The TCP Discovery Port for LDP. The default value (646) is the well-known value of this port.

UDP Dsc Port—The UDP Discovery Port for LDP. The default value (646) is the well-known value for this port.

Maximum PDU Length—The maximum PDU Length that is sent in the Common Session Parameters of an Initialization Message. A value of 255 or less specifies the default maximum length of 4096 octets.

Keep Alive Hold Timer—The two octet value which is the proposed keep alive hold timer for this LDP Entity.

Hello Hold Timer—The two octet value which is the proposed Hello hold timer for this LDP Entity. A value of 0 means use the default, which is 15 seconds for Link Hellos and 45 seconds for Targeted Hellos. A value of 65535 means infinite.

Init Session Threshold—When attempting to establish a session with a Peer, the given LDP Entity should send out the SNMP notification, Init Session Threshold, when the number of Session Initialization messages sent exceeds this threshold.

Label Distribution Method—For any given LDP session, the method of label distribution must be specified (downstreamOnDemand, or downstreamUnsolicited).

Label Retention Mode—The LDP Entity can be configured to use either conservative or liberal label retention mode. If the value of this object is conservative then advertised label mappings are retained only if they will be used to forward packets, that is, if label came from a valid next hop. If the value of this object is liberal then all advertised label mappings are retained whether they are from a valid next hop or not.

PVL—If the value of this object is 0 (zero) then Loop Detection for Path Vectors is disabled. Otherwise, if this object has a value greater than zero, then Loop Detection for Path Vectors is enabled, and the Path Vector Limit is this value.

HopCountLimit—Maximum allowable value for Hop count when Loop Detection using Hop Counters as a metric.

Target Peer—If this LDP entity uses targeted peer then set this to “true”.

Target Peer Address Type—The type of the internetwork layer address used for the Extended Discovery.

Target Peer Address—The value of the internetwork layer address used for the Extended Discovery.

Optional Parameters—This attribute specifies whether or not the optional parameters for the LDP Initialization Message is set or not.


Discontinuity Time—The value of sysUpTime on the most recent occasion at which any one or more of this entity's counters suffered a discontinuity.

Storage Type—The storage type for the LDP entry.

Entity Statistics Tab

The Entity Statistics tab displays statistics for each LDP entity configured on a router. The Entity Statistics tab (see [Figure 15-10](#)) displays a single Entity Statistics area.

Figure 15-10 MPLS LDP Entity Status Window—Entity Statistics Tab



Entity Statistics

The Entity Statistics area displays a read-only table which expands on the information provided in the “Entity Tab” section on page 15-19. The purpose of this table is to display statistical information about the LDP Entities on the LSR. The table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Attempted Sessions—A count of the total attempted sessions for this LDP Entity.

Session Rejected No Hello Errors—A count of the Session Rejected/No Hello Error Notification Messages sent or received by this LDP Entity.

Session Rejected Ad Errors—A count of the Session Rejected/Parameters Advertisement Mode Error Notification Messages sent or received by this LDP Entity.

Session Rejected Max PDU Errors—A count of the Session Rejected/Parameters Max PDU Length Error Notification Messages sent or received by this LDP Entity.

Session Rejected LR Errors—A count of the Session Rejected/Parameters Label Range Notification Messages sent or received by this LDP Entity.

Bad Identifier Errors—This object counts the number of Bad LDP Identifier Fatal Errors detected by the session(s) (past and present) associated with this LDP Entity.

Bad PDU Length Errors—This object counts the number of Bad PDU Length Fatal Errors detected by the session(s) (past and present) associated with this LDP Entity.

Bad Message Length Errors—This object counts the number of Bad Message Length Fatal Errors detected by the session(s) (past and present) associated with this LDP Entity.

Bad TLV Length Errors—This object counts the number of Bad TLV Length Fatal Errors detected by the session(s) (past and present) associated with this LDP Entity.

Malformed TLV Value Errors—This object counts the number of Malformed TLV Value Fatal Errors detected by the session(s) (past and present) associated with this LDP Entity.

KeepAlive Timer Exp Errors—This object counts the number of Session Keep Alive Timer Expired Errors detected by the session(s) (past and present) associated with this LDP Entity.


Shutdown Notif Received—This object counts the number of Shutdown Notifications received related to session(s) (past and present) associated with this LDP Entity.

Shutdown Notif Sent—This object counts the number of Shutdown Notifications sent related to session(s) (past and present) associated with this LDP Entity.

General Label Range Tab

The General Label Range tab displays the general range configurations on the router for each LDP entity. The General Label Range tab (see [Figure 15-11](#)) displays a single General Label Range area.

Figure 15-11 MPLS LDP Entity Status Window—General Label Range Tab



General Label Range

The General Label Range area displays the General Label Range table. This table specifies a contiguous range of generic labels, or a “label range” for LDP Entities. LDP Entities which use Generic Labels must have at least one entry in this table. One row entry in this table contains information on a single range of labels represented by the configured Upper and Lower Bounds pairs.



Note

There is no corresponding LDP message which relates to the information in this table, however, this table does provide a way for a user to 'reserve' a generic label range. The ranges for a specific LDP Entity are unique and non-overlapping. A row will not be created unless a unique and non-overlapping range is specified.

General Label Range table displays the following information:

LDP Identifier—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Associated Interface Name—This value represents the Interface Name where the Generic Label would be created. The Value “ ” means the interface is not known.

Minimum Label Range—The minimum label configured for this range.


Maximum Label Range—The maximum label configured for this range.

Storage Type—Displays the storage type for the LDP entry.

ATM Parameters Tab

ATM parameters configuration is displayed in the ATM Parameters tab (see [Figure 15-12](#)) for LDP entities that use ATM as their underlying technology. The ATM Parameters tab displays a single ATM Parameters area.

Figure 15-12 MPLS LDP Entity Status Window—ATM Parameters Tab



ATM Parameters

The table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Associated Interface Name—This value represents the Interface Name where the ATM Labels would be created. The Value 0 means the Interface is not known.

Merge Cap—Displays the Merge Capability of this entity. Possible values are notSupported, or vcMerge.

LR Components—Number of Label Range Components in the Initialization message.

VC Directionality—This value represents whether to use a given VCI, within a given VPI, as a label in unidirectional or bi-directional.

LSR Connectivity—The peer LSR may be connected indirectly by means of an ATM VP so that the VPI values may be different on either endpoint so the label must be encoded entirely within the VCI field.

DefaultControl VPI—The default VPI value for the non-MPLS connection. The default value of this is 0 (zero) but other values may be configured. This object allows a different value to be configured.

DefaultControl VCI—The default VCI value for a non-MPLS connection. The default value of this is 32 but other values may be configured. This object allows a different value to be configured.

Unlab Traffic VPI—VPI value of the VCC supporting unlabeled traffic. This non-MPLS connection is used to carry unlabeled (IP) packets. The default value is the same as the default value of the **DefaultControlVpi**, however another value may be configured.

Unlab Traffic VCI—VCI value of the VCC supporting unlabelled traffic. This non-MPLS connection is used to carry unlabelled (IP) packets. The default value is the same as the default value of the **DefaultControlVci**, however another value may be configured.


Storage Type—The storage type for this entry.

ATM Label Range Tab

Configured ATM label range parameters are displayed in the ATM Label Range tab (see [Figure 15-13](#)) for LDP entities that use ATM as their underlying technology.

The ATM Label Range tab displays a single ATM Label Range area.

Figure 15-13 MPLS LDP Entity Status Window—ATM Label Range Tab



ATM Label Range

The table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Label Range Min VPI—The minimum VPI number configured for this range.

Label Range Min VCI—The minimum VCI number configured for this range.

Label Range Max VPI—The maximum VPI number configured for this range.

Label Range Max VCI—The maximum VCI number configured for this range.

Storage Type—The storage type for this entry.

MPLS LDP Hello Adjacencies

The LDP operations begin with a discovery (Hello) process during which an LDP entity (a local LSR) finds a cooperating LDP peer in the network and negotiates basic operating procedures between them. The recognition and identification of a peer by means of this discovery process results in an Hello adjacency, which represents the context within which label binding information is exchanged between the local LSR and its LDP peer. The MPLS LDP Hello Adjacencies window displays a table of hello adjacencies of the LSR. This window is a read-only window.

The MPLS LDP Hello Adjacencies section covers the following:


- [Viewing the MPLS LDP Hello Adjacencies Window](#)
- [MPLS LDP Hello Adjacencies Window—Detailed Description](#)

Viewing the MPLS LDP Hello Adjacencies Window

To view the MPLS LDP Hello Adjacencies window, proceed as follows:

-
- Step 1** Right click on an appropriate object and choose **Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS LDP Hello Adjacencies**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the MPLS LDP Hello Adjacencies window. The MPLS LDP Hello Adjacencies window appears, with the Hello Adjacencies tab displayed.

Figure 15-14 MPLS LDP Hello Adjacencies Window—Hello Adjacencies Tab



- Step 2** Choose a **Chassis** from the list box displayed at the left of the window. See the “[MPLS LDP Hello Adjacencies Window—Detailed Description](#)” section on page 15-27 for further details on the fields displayed.

MPLS LDP Hello Adjacencies Window—Detailed Description

The MPLS LDP Hello Adjacencies window (see [Figure 15-14](#)) displays a single Hello Adjacency tab.

Hello Adjacencies Tab

The Hello Adjacencies tab (see [Figure 15-14](#)) displays a single Hello Adjacencies area.

Hello Adjacencies

The table displays the following information:

Local LDP Id—The LDP identifier for the selected LSR.

Index—This index is used as a secondary index to uniquely identify this row.

Peer LDP Id—The LDP identifier of the LDP peer.

Adjacency Number—Displays an identifier for this specific adjacency.

Time Remaining—The time remaining for this Hello Adjacency. This interval will change when the “next” Hello message which corresponds to this Hello Adjacency is received.

Adjacency Type—This adjacency is the result of a “link” hello if the value of this object is link. Otherwise, it is a result of a “targeted” hello, targeted.

MPLS LDP Peer Status

The LDP Peer refers to a remote LDP entity (that is, a non local LSR). The MPLS LDP Peer Status window displays information about LDP peers known by the LDP entities on a router.

The MPLS LDP Peer Status section covers the following:


- [Viewing the MPLS LDP Peer Status Window](#)
- [MPLS LDP Peer Status Window—Detailed Description](#)

Viewing the MPLS LDP Peer Status Window

To view the MPLS LDP Peer Status window, proceed as follows:

- Step 1** Right click on an appropriate object and choose **Cisco 12000/10720 Manager> Fault> Chassis> MPLS> MPLS LDP Peer Status**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the MPLS LDP Peer Status window. The MPLS LDP Peer Status Window appears, with the Peers tab displayed.

Figure 15-15 MPLS LDP Peer Status Window—Peers Tab



Choose an **IOS Host** from the box displayed at the left of the window.

MPLS LDP Peer Status Window—Detailed Description

The MPLS LDP Peer Status window (see [Figure 15-15](#)) displays four tabs: Peers, Sessions, Session Statistics, and ATM Sessions.

Peers Tab

The Peers tab displays information about the LDP peers known by the LDP entities on the selected router. The Peers tab displays a single LDP Peers area.

LDP Peers

The LDP Peers area displays a table that displays information from the Entity-Peer interaction during session initialization. The table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Peer LDP Id—The LDP identifier of this LDP Peer.

Label Distribution Method—For any given LDP session, the method of label distribution must be specified. Possible values are `downstreamOnDemand`, or `downstreamUnsolicited`.


Loop Detection—An indication of whether loop detection based on path vectors is disabled or enabled for this Peer. If this object has a value of `disabled`, then loop detection is disabled. Otherwise, if this object has a value of `enabled`, then loop detection based on path vectors is enabled.

Path Vector Limit—If Loop Detection is enabled for the peer, then this attribute represents the Path Vector Limit for this peer.

Sessions Tab

The Sessions tab (see [Figure 15-16](#)) displays information about each session between an LDP entity and an LDP peer. The Sessions tab displays a single LDP Sessions area.

Figure 15-16 MPLS LDP Peer Status Window—Sessions Tab



LDP Sessions

The LDP Session area displays a table. An entry in this table represents information on a single session between an LDP Entity and LDP Peer. The information contained in a row is read-only.

The LDP Sessions table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Peer LDP Id—The LDP identifier of this LDP Peer.

Session State—The current state of the session.

Protocol Version—The version of the LDP protocol which this session is using. This is the version of the LDP protocol which has been negotiated during session initialization.

Keep Alive Hold Time Remaining—The keep alive hold time remaining for this session.


Max PDU Length—The value of maximum allowable length for LDP PDUs for this session. This value may have been negotiated during the Session Initialization.

Discontinuity Time—The value of sysUpTime on the most recent occasion at which any one or more of this session's counters suffered a discontinuity.

Session Statistics Tab

The Session Statistics tab (see [Figure 15-17](#)) displays statistics for sessions between LDP entities and LDP peers. The Session Statistics tab displays a single LDP Session Statistics area.

Figure 15-17 MPLS LDP Peer Status Window—Session Statistics Tab



LDP Session Statistics

The LDP Session Statistics area displays a table of statistics for sessions between LDP Entities and LDP Peers. The LDP Session Statistics table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Peer LDP Id—The LDP identifier of this LDP Peer.


Unknown Message Type Errors—This object counts the number of Unknown Message Type Errors detected during the current session. Discontinuities in the value of this counter can occur at re-initialization of the EM, and at other times as indicated by the value of `mplsLdpSesDiscontinuityTime`.

Unknown TLV Errors—This object counts the number of Unknown TLV Errors detected during the current session. Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of `mplsLdpSessionDiscontinuityTime`.

ATM Sessions Tab

The ATM Sessions tab (see [Figure 15-18](#)) displays information about the label range intersection between an LDP entity and its LDP peer where the underlying medium is ATM. The ATM Sessions tab displays a single LDP ATM Session area.

Figure 15-18 MPLS LDP Peer Status Window—ATM Sessions Tab



LDP ATM Session

The LDP ATM Session area displays a table that relates Sessions in the LDP Session Table and their label range intersections. There could be one or more label range intersections between an LDP Entity and LDP Peer using ATM as the underlying media. Each row represents a single label range intersection. The table displays the following information:

Local LDP Id—Displays the LDP identifier.

Index—This index is used as a secondary index to uniquely identify this row.

Peer LDP Id—The LDP identifier of this LDP Peer.

Minimum VPI Number—The minimum VPI number.

Minimum VCI Number—The minimum VCI number.

Maximum VPI Number—The maximum VPI number.

Maximum VCI Number—The maximum VCI number.

Fault Management for MPLS Traffic Engineering

This section describes Fault Management for MPLS traffic engineering (TE).

MPLS Tunnel Information

The MPLS Tunnel Information window displays the status information about the MPLS tunnels configured on the managed chassis (Cisco 12000 and 10720 Series Routers). The MPLS Tunnel Information window uses the MPLS-TE-MIB to populate window. This window can be used to find: the tunnels that exist on a device, the LSPs that originate or transit this device and whether the MPLS entities are functionally up or down.

The MPLS Tunnel Information section covers the following:


- [Viewing the MPLS Tunnel Information Window](#)
- [MPLS Tunnel Information Window—Detailed Description](#)

Viewing the MPLS Tunnel Information Window

To view the MPLS Tunnel Information window, proceed as follows:

-
- Step 1** Right click on an appropriate chassis object and choose **Fault> MPLS> MPLS Tunnel Information**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the MPLS Tunnel Information window. The MPLS Tunnel Information window appears, with the Select Tunnel tab displayed.

Figure 15-19 MPLS Tunnel Information Window—Select Tunnel Tab



- Step 2 Choose an **Chassis** from the list displayed at the left of the window. For further information on the fields displayed in this window, see the “[MPLS Tunnel Information Window—Detailed Description](#)” section on page 15-34.

MPLS Tunnel Information Window—Detailed Description

The MPLS Tunnel Information window displays seven tabs: Select Tunnel, Head Tunnel Setup, Head Tunnel Hops, LSP Setup, LSP Hops, LSP Resource, and Performance.

Select Tunnel Tab

The Select Tunnel tab lists all the head tunnels and LSP tunnels available in the selected managed chassis. Tunnels are sorted to display head tunnels first and then LSPs. The first tunnel in the list is automatically selected (by default), and all the other fields are populated for that selected tunnel. The “Select Tunnel” area information is provided in all the other tabs available in the window as well. When selecting a tunnel from the tunnel list in the Select Tunnel area in any of the Tabs then the same information will be updated in all the other Tabs as well.

The Select Tunnel tab (see [Figure 15-19](#)) displays two areas, Select Tunnel and General.

Select Tunnel

The Select Tunnel area displays the following information:

Tunnel Id—Displays the tunnel identification number.

Instance—Displays the tunnel instance of the LSP. It is useful to identify multiple instances of tunnels for the purposes of backup and parallel tunnels.

Ingress LSR—Displays the source IP address of the LSP.

Egress LSR—Displays the egress LSR IP address.

General

The General area displays the following information:

Maximum Hops Number—The maximum number of hops that can be specified for a tunnel on this device.

TE Distribution Protocol—The traffic engineering distribution protocol(s) used by this LSR. Note that an LSR may support more than one distribution protocols simultaneously. Possible values are other, ospf, and isis.

Configured Tunnels Number—The number of tunnels configured on this device.

Active Tunnels Number—The number of tunnels active on this device.

Head Tunnel Setup Tab

The Head Tunnel Setup tab displays the informations specific to the head tunnels available on the managed chassis.




Note

Though the Head Tunnel Setup tab lists all the LSP tunnels in the Select Tunnel area, this tab provides information specific to Head Tunnels. For more information regarding LSPs select the [LSP Setup Tab](#) or the [LSP Hops Tab](#).

The Head Tunnel Setup tab (see [Figure 15-20](#)) displays four areas, Select Tunnel, Tunnel Info, Tunnel Status and Advanced.

Figure 15-20 MPLS Tunnel Information Window—Head Tunnel Setup Tab



Note

To view head tunnel setup information, select the head tunnel in the Select Tunnel area.

Select Tunnel

The Select Tunnel area displays the following information:

Tunnel Id—Displays the tunnel identification number.

Instance—Displays the tunnel instance of the LSP. It is useful to identify multiple instances of tunnels for the purposes of backup and parallel tunnels.

Ingress LSR—Displays the source IP address of the LSP.

Egress LSR—Displays the egress LSR IP address.

Tunnel Info

Tunnel Name—Displays the name assigned to the tunnel. This name can be used to refer to the tunnel on the LSRs console port.

Tunnel Descr—Displays a textual string containing information about the tunnel. If there is no description this object contains a zero length string.

Tunnel Type—Displays either head tunnel or LSP.

Signalling Protocol—Displays the signaling protocol, if any, which was used to setup this tunnel. Possible values are none, rsvp, crldp, or other.

Storage Type—This variable indicates the storage type for this object.

Creation Time—Specifies the value of SysUpTime when the first instance of this tunnel came into existence.

Tunnel Status

Admin Status—Displays the desired operational status of this tunnel. Possible values are up ready to pass packets, down, or testing in some test mode.

Operational Status—Indicates the actual operational status of this tunnel, which is typically but not limited to, a function of the state of individual segments of this tunnel. Possible values are: up ready to pass packets, down, testing in some test mode, unknown status cannot be determined, dormant, notPresent some component is missing or lowerLayerDown down due to the state of lower layer interfaces.

Total Up Time—This value represents the aggregate up time for all instances of this tunnel, if available. If this value is unavailable, it must return a value of 0.

Primary Time Up—Specifies the total time the primary instance of this tunnel has been active.

Advanced

Setup Priority—Displays the setup priority of this tunnel. Possible values are 0 through 7.

Holding Priority—Displays the holding priority for this tunnel. Possible values are 0 through 7.

Session Attributes—This bitmask indicates optional session values for this tunnel. The following describes these bitfields:

- **fastReroute**—This flag indicates that the any tunnel hop may choose to reroute this tunnel without tearing it down. This flag permits transit routers to use a local repair mechanism which may result in violation of the explicit routing of this tunnel. When a fault is detected on an adjacent downstream link or node, a transit router can reroute traffic for fast service restoration.
- **mergingPermitted**—This flag permits transit routers to merge this session with other RSVP sessions for the purpose of reducing resource overhead on downstream transit routers, thereby providing better network scalability.
- **isPersistent**—Indicates whether this tunnel should be restored automatically after a failure occurs.
- **isPinned**—This flag indicates whether the loose- routed hops of this tunnel are to be pinned.
- **isComputed**—This flag indicates whether the tunnel path is computed using a constraint-based routing algorithm based on the mplsTunnelHopTable entries.
- **recordRoute**—This flag indicates whether or not the signaling protocol should remember the tunnel path after it has been signaled.

Owner—Indicates which protocol created and is responsible for managing this tunnel. Values rsvp and crldp should not be used at the head-end of a MPLS tunnel. Possible values are: admin represents all management entities, rsvp, crldp, policyAgent, or other.

Local Protect In Use—Displays that the local repair mechanism is in use to maintain this tunnel (usually in the face of an outage of the link it was previously routed over).

Path Changes—Displays the number of times the paths has changed for this tunnel.

Last Path Change—Displays the time since the last path change for this tunnel.

State Transitions—Displays the number of times the state of this tunnel instance has changed.

Include Any Affinity—A link satisfies the include-any constraint if and only if the constraint is zero, or the link and the constraint have a resource class in common.

Include All Affinity—A link satisfies the include-all constraint if and only if the link contains all of the administrative groups specified in the constraint.

Exclude All Affinity—A link satisfies the exclude-all constraint if and only if the link contains none of the administrative groups specified in the constraint.


Path In Use—This value denotes the configured path that was chosen for this tunnel. This value reflects the secondary index into the TunnelHopTable. This path may not exactly match the one in the ARHopTable due to the fact that some CSPF modification may have taken place. See the ARHopTable for the actual path being taken by the tunnel. A value of zero denotes that no path is currently in use or available.

Role—This value signifies the role that this tunnel entry/instance represents. This value must be set to head at the originating point of the tunnel. This value must be set to transit at transit points along the tunnel, if transit points are supported. This value must be set to tail at the terminating point of the tunnel if tunnel tails are supported.

Head Tunnel Hops Tab

The Head Tunnel Hops tab (see [Figure 15-21](#)) displays hop information for head tunnels. The Head Tunnel Hops tab displays the Select Tunnel and Hop Table areas.

Figure 15-21 MPLS Tunnel Information Window—Head Tunnel Hops Tab



Note

To view head tunnel hop information, choose a head tunnel in Select Tunnel area and choose a Hop Index in the Hop Table area. Information appears for the selected head tunnel and its Hop Index.

Select Tunnel

The Select Tunnel area displays the following information:

Tunnel Id—Displays the tunnel identification number.

Instance—Displays the tunnel instance of the LSP. It is useful to identify multiple instances of tunnels for the purposes of backup and parallel tunnels.

Ingress LSR—Displays the source IP address of the LSP.

Egress LSR—Displays the egress LSR IP address.

Hop Table

Hop Index—The number of explicit route hops for a tunnel.

Path Option—Identifies a particular group of hops representing a particular configured path.

Hop Number—Identifies a particular hop.

Hop Address Type—Displays the address type of this tunnel hop. Possible values are: ipV4, ipV6, asNumber, or lspid.

Hop IPv4 Address—If the Hop Address Type is set to ipV4, then this value will contain the IPv4 address of this hop. This object is otherwise insignificant and should contain a value of 0.

Hop IPv4 Prefix Length—If the Hop Address Type is ipV4, then the prefix length for this hop's IPv4 address is contained herein. This object is otherwise insignificant and should contain a value of 0.

Hop IPv6 Address—If the Hop Address Type is set to ipV6, then this variable contains the IPv6 address of this hop. This object is otherwise insignificant and should contain a value of 0.

Hop IPv6 Prefix Length—If the Hop Address Type is set to ipV6, this value will contain the prefix length for this hops IPv6 address. This object is otherwise insignificant and should contain a value of 0.

Hop AS Number—If the Hop Address Type is set to asNumber, then this value will contain the AS number of this hop. This object is otherwise insignificant and should contain a value of 0 to indicate this fact.

Hop LSP ID—If the Hop Address Type is set to lspid, then this value will contain the LSPID of a tunnel of this hop. The present tunnel being configured is “tunneled” through this hop (using label stacking). This object is otherwise insignificant and should contain a value of 0 to indicate this fact.

Hop Type—Displays whether this tunnel hop is routed in a strict or loose fashion.

Hop Storage Type—Displays the storage type.

LSP Setup Tab

The LSP Setup tab (see [Figure 15-22](#)) displays information about the tunnel, which are LSPs.

**Note**


The LSP Setup tab displays information specific to LSPs, even though the Select Tunnel Area lists head tunnels, for more information regarding head tunnels choose the [Head Tunnel Setup Tab](#) and the [Head Tunnel Hops Tab](#).

**Note**

To view LSP Setup information, choose the LSP in the Select Tunnel Area.

The LSP Setup tab displays four areas, Select Tunnel, Tunnel Info, Tunnel Status and Advanced.

Figure 15-22 MPLS Tunnel Information Window—LSP Setup Tab



Select Tunnel

The Select Tunnel area displays the following information:

Tunnel Id—Displays the tunnel identification number.

Instance—Displays the tunnel instance of the LSP. It is useful to identify multiple instances of tunnels for the purposes of backup and parallel tunnels.

Ingress LSR—Displays the source IP address of the LSP.

Egress LSR—Displays the egress LSR IP address.

Tunnel Info

Tunnel Descr—Displays a textual string containing information about the tunnel. If there is no description this object contains a zero length string.

Tunnel Type—Displays whether or not the entry represents an interface.

Signalling Protocol—Displays the signaling protocol, if any, which was used to setup this tunnel. Possible values are none, rsvp, crldp, or other.

Storage Type—This variable indicates the storage type for this object.

Tunnel Status

Admin Status—Displays the desired operational status of this tunnel. Possible values are up ready to pass packets, down, or testing in some test mode.

Operational Status—Indicates the actual operational status of this tunnel, which is typically but not limited to, a function of the state of individual segments of this tunnel. Possible values are: up ready to pass packets, down, testing in some test mode, unknown status cannot be determined, dormant, notPresent some component is missing or lowerLayerDown down due to the state of lower layer interfaces.

Instance Uptime—This value identifies the total time that this tunnel instances operational status has been Up.

Advanced

Setup Priority—Displays the setup priority of this tunnel. Range of values are 0 through 7.

Holding Priority—Displays the holding priority for this tunnel. Range of values are 0 through 7.

Session Attributes—This bitmask indicates optional session values for this tunnel. The following describes these bitfields:

- **fastReroute**—This flag indicates that the any tunnel hop may choose to reroute this tunnel without tearing it down. This flag permits transit routers to use a local repair mechanism which may result in violation of the explicit routing of this tunnel. When a fault is detected on an adjacent downstream link or node, a transit router can reroute traffic for fast service restoration.
- **mergingPermitted**—This flag permits transit routers to merge this session with other RSVP sessions for the purpose of reducing resource overhead on downstream transit routers, thereby providing better network scalability.
- **isPersistent**—Indicates whether this tunnel should be restored automatically after a failure occurs.
- **isPinned**—This flag indicates whether the loose- routed hops of this tunnel are to be pinned.
- **isComputed**—This flag indicates whether the tunnel path is computed using a constraint-based routing algorithm based on the mplsTunnelHopTable entries.
- **recordRoute**—This flag indicates whether or not the signaling protocol should remember the tunnel path after it has been signaled.

Owner—Indicates which protocol created and is responsible for managing this tunnel. Values rsvp and crldp should not be used at the head-end of a MPLS tunnel. Possible values are: admin represents all management entities, rsvp, crldp, policyAgent, or other.

Local Protect In Use—Displays that the local repair mechanism is in use to maintain this tunnel (usually in the face of an outage of the link it was previously routed over).

Instance Priority—This value indicates priority (in descending order, with 0 indicating the lowest priority) within a group of tunnel instances.

Role—This value signifies the role that this tunnel entry/instance represents. This value must be set to head at the originating point of the tunnel. This value must be set to transit at transit points along the tunnel, if transit points are supported. This value must be set to tail at the terminating point of the tunnel if tunnel tails are supported.

LSP Hops Tab

The LSP Hops tab (see [Figure 15-23](#)) displays the actual route hops and the computed hops for the selected chassis. This tabs fields are specific to LSPs.




Note

To view ARHop and CHop information for a LSP:

- 1) Choose LSP in the Select Tunnel Area.
- 2) Note the ARHopListIndex and CHop List Index, and
- 3) Choose AR Hop Table and CHop Table with the noted Hop List Index.

The LSP Hops tab displays the Select Tunnel, Actual Route Hop Table, and Computed Hop Table areas.

Figure 15-23 MPLS Tunnel Information Window—LSP Hops Tab



Select Tunnel

The Select Tunnel area displays the following information:

Tunnel Id—Displays the tunnel identification number.

Instance—Displays the tunnel instance of the LSP. It is useful to identify multiple instances of tunnels for the purposes of backup and parallel tunnels.

Ingress LSR—Displays the source IP address of the LSP.

Egress LSR—Displays the egress LSR IP address.

AR Hop List Index—Displays the actual hops traversed by the tunnel.

C Hop List Index—Displays the computed hops traversed by the tunnel.

Actual Route HOP Table

The Actual Route Hop Tunnel area displays the following information:

Hop Index—The number of explicit route hops for a tunnel.

Address Type—Displays the address type of this tunnel hop. Possible values are ipV4, ipV6, asNumber, or lspid.

IPv4 Address—If the Address Type is set to ipV4, then the IPv4 Address value will contain the IPv4 address of this hop. This object is otherwise insignificant and should contain a value of 0.

IPv4 Prefix Length—If the Address Type is ipV4, then the prefix length for this hops IPv4 address is contained herein. This object is otherwise insignificant and should contain a value of 0.

IPv6 Address—If the Address Type is set to ipV6, then the IPv6 Address variable displays the IPv6 Address of this hop. This object is otherwise insignificant and should contain a value of 0.

IPv6 Prefix Length—If the Address Type is set to ipV6, this value will contain the prefix length for this hops IPv6 address. This object is otherwise insignificant and should contain a value of 0.

AS Number—If the Address Type is set to asNumber, then this value will contain the AS number of this hop. This object is otherwise insignificant and should contain a value of 0 to indicate this fact.

Hop Type—Displays whether this tunnel hop is routed in a strict or loose fashion. Possible values are: strict, or loose.

Computed HOP Table

The Actual Route Hop Tunnel area displays the following information:

Hop Index—The number of explicit route hops for a tunnel.

Address Type—Displays the address type of this tunnel hop. Possible values are ipV4, ipV6, asNumber, or lspid.

IPv4 Address—If the Address Type is set to ipV4, then the IPv4 Address value will contain the IPv4 address of this hop. This object is otherwise insignificant and should contain a value of 0.

IPv4 Prefix Length—If the Address Type is ipV4, then the prefix length for this hops IPv4 address is contained herein. This object is otherwise insignificant and should contain a value of 0.

IPv6 Address—If the Address Type is set to ipV6, then the IPv6 Address variable displays the IPv6 Address of this hop. This object is otherwise insignificant and should contain a value of 0.

IPv6 Prefix Length—If the Address Type is set to ipV6, this value will contain the prefix length for this hops IPv6 address. This object is otherwise insignificant and should contain a value of 0.

AS Number—If the Address Type is set to asNumber, then this value will contain the AS number of this hop. This object is otherwise insignificant and should contain a value of 0 to indicate this fact.

Hop Type—Displays whether this tunnel hop is routed in a strict or loose fashion. Possible values are: strict, or loose.

LSP Resource Tab


The LSP Resource tab (see Figure 15-24) displays the resource information specific to LSPs. The LSP Resource tab displays the Select Tunnel and Resource Table areas.



Note

To view LSP Resource information, choose an LSP in the Select Tunnel area and a Resource Index in the Resource Table area. Information is displayed for the selected Resource index for the selected LSP.

Figure 15-24 MPLS Tunnel Information Window—LSP Resource Tab



Select Tunnel

The Select Tunnel area displays the following information:

Tunnel Id—Displays the tunnel identification number.

Instance—Displays the tunnel instance of the LSP. It is useful to identify multiple instances of tunnels for the purposes of backup and parallel tunnels.

Ingress LSR—Displays the source IP address of the LSP.

Egress LSR—Displays the egress LSR IP address.

Resource Index—This variable represents a pointer to the traffic parameter specification for this tunnel.

Resource Table

This table allows a manager to specify which resources are desired for an MPLS tunnel. This table also allows several tunnels to point to a single entry in this table, implying that these tunnels should share resources.

The Resource Table area displays the following information:

Resource Max Rate—The maximum rate in bits/second.

Resource Mean Rate—This object is copied into an instance of `mplsTrafficParamMeanRate` in the `mplsTrafficParamTable`.


Resource Max Burst Size—The maximum burst size in bytes.

Resource Storage Type—Displays the storage type for this object.

Performance Tab

The Performance tab (see [Figure 15-25](#)) displays the tunnel performance statistics. It provides the packet and byte counters for each tunnel. The Performance tab displays the Tunnel Performance area.

Figure 15-25 MPLS Tunnel Information Window—Performance Tab



Tunnel Performance

The Select Tunnel area displays the following information:

Tunnel Id—Displays the tunnel identification number.

Instance—Displays the tunnel instance of the LSP. It is useful to identify multiple instances of tunnels for the purposes of backup and parallel tunnels.

Ingress LSR—Displays the source IP address of the LSP.

Egress LSR—Displays the egress LSR IP address.

Packets—Displays the number of packets forwarded by the tunnel.

HC Packets—High capacity counter for the number of packets forwarded by the tunnel.

Errors—Displays the number of errored packets.

Bytes—Displays the number of bytes forwarded by the tunnel.

HC Bytes—High capacity counter for the number of bytes forwarded by the tunnel.



MPLS VRF Management

This chapter describes the various MPLS VRF Management tasks that can be performed using the Cisco 12000/10720 Router Manager application. This chapter is divided into the following main sections:

- [Introduction to VRF Management](#)
- [VRF Management Workflows](#)
- [Launching the MPLS VRF Management Windows](#)
- [Creating VRF Objects in the EM](#)
- [Creating and Configuring the VRF Policy on a Device](#)
- [Associating a VRF Policy with an Interface](#)
- [VRF Fault Management](#)

Introduction to VRF Management

VPN Routing and Forwarding (VRF) is an IOS route table instance for connecting a set of sites to a VPN service. A VRF contains a template of VPN Routing/Forwarding table in a PE router.

The overlapping addresses, usually resulting from usage of private IP addresses in customer networks, are one of the major obstacles to successful deployment of peer-to-peer VPN implementation. The MPLS/VPN technology provides an elegant solution to dilemma.

Each VPN has its own routing and forwarding table in the router, so any customer or site that belongs to a VPN is provided access only to the set of routes contained within that table. Any PE router in the MPLS/VPN network therefore contains a number of per-VPN routing tables and a global routing table, that is used to reach other routers in the provider network. Effectively, a number of virtual routers are created in a single physical router.

VRF Manager provides an encapsulation for the VRF template as EM Object Model for better manageability and user friendly Graphical User Interface (GUI).

VRF Management Workflows

This chapter describes the following workflows:

- [Creating VRF Objects in the EM, page 16-3](#)
 - [Deploying VRF Objects, page 16-3](#)
- [Creating and Configuring the VRF Policy on a Device, page 16-8](#)
 - [Configuring and Creating a VRF Policy on a Selected Chassis, page 16-8](#)
 - [Removing a VRF Policy from a Selected Chassis, page 16-10](#)
 - [Adding a Routing Target to a Selected Chassis, page 16-10](#)
 - [Deleting a Routing Target from a Selected Chassis, page 16-10](#)
- [Associating a VRF Policy with an Interface, page 16-12](#)
 - [Associating VRF Policies, page 16-13](#)
 - [Removing a VRF Policy from a Selected Interface, page 16-14](#)
- [VRF Fault Management, page 16-15](#)
 - [VRF Status, page 16-15](#)
 - [Interface VRF Status, page 16-19](#)
 - [VPN Status, page 16-20](#)
 - [VRF Object Status, page 16-26](#)

Launching the MPLS VRF Management Windows

[Table 16-1](#) displays the Cisco 12000/10720 Router Manager MPLS VRF Management windows that can be launched from each object type. For example, the VRF Configuration window can be launched from a Site, or Chassis object, but cannot be launched from a Module or an Interface object.



Note

[Table 16-1](#) lists the menu options to launch the MPLS VRF Management dialogs from the site level.

Table 16-1 Launching the MPLS VRF Management Windows

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window								Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	Software Folder	VRF Folder	VRF	
Deploying a VRF Object	Yes	Yes	Yes	No	No	Yes	Yes	No	Deployment> Cisco 12000/10720 Manager> 12xxx or 10720> VRF
VRF Configuration Window	Yes	Yes	Yes	No	No	Yes	Yes	Yes	Cisco 12000/10720 Manager> Configuration> Chassis> MPLS> VRF Configuration

Table 16-1 Launching the MPLS VRF Management Windows (continued)

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window								Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	Software Folder	VRF Folder	VRF	
VRF Association Window	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Cisco 12000/10720 Manager> Configuration> Interface> MPLS> VRF Association
VRF Status Window	Yes	Yes	Yes	No	No	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> VRF Status
Interface VRF Status Window	Yes	Yes	Yes	No	No	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> Interface VRF Status
VPN Status Window	Yes	Yes	Yes	No	No	No	No	No	Cisco 12000/10720 Manager> Fault> Chassis> MPLS> VPN Status
VRF Object Status Window	No	No	No	No	No	No	No	Yes	Cisco 12000/10720 Manager> Fault> Chassis> MPLS>VRF Object Status

**Note**

The Cisco 12000/10720 Router Manager MPLS VRF Management windows cannot be opened when multiple objects are selected (the menu options to open the windows are grayed out). Available menu options can be launched from a site object containing the required objects.

Creating VRF Objects in the EM

The Cisco 12000/10720 Router Manager application provides a deployment wizard to help you deploy VRF objects within your EM. All the VRF related objects are displayed beneath the Chassis object in the Software/VRF folder.

Deploying VRF Objects


**Note**

VRF objects must be deployed within the Chassis/Software/VRF folder.

To deploy a VRF object, proceed as follows:


- Step 1** Right click on an appropriate object and choose **Deployment> Cisco 12000/10720 Manager> 12xxx or 10720> VRF**.

Figure 16-1 Deploying a VRF Object




The Deployment Wizard - Object Parameters window appears (see Figure 16-2):

Figure 16-2 Deployment Wizard - Object Parameters Window



- Step 2** Enter the number of **VRF Objects** required. A single VRF object was entered in this example.
- Step 3** Choose **Forward**.


Figure 16-3 Deployment Wizard - Object Parameters Window



Step 4 Enter a **VRF** name. Each VRF must have a unique name. In this example the VRF is called VRF-1.


Step 5 Choose **Forward**. The Deployment Wizard - Views window appears:

Figure 16-4 Deployment Wizard - Views




Step 6 Choose **Select** (for the ComponentManaged view). The Object Selector window appears:

Figure 16-5 Object Selector Window



- Step 7** Navigate down the hierarchy until you find the VRF folder (Chassis> Software >VRF). You can only deploy a VRF object within the VRF folder. Click on the VRF folder to select it and then click **Apply**.
- Step 8** The Deployment Wizard - Views window re-appears with the selected object displayed (VRF in this example) in both the ComponentManaged and Physical fields.

Figure 16-6 Deployment Wizard—Views




93103

Step 9 Choose **Forward**.

Step 10 The Deployment Wizard - Summary window appears. The Summary window provides details of the object you are about to deploy.


Figure 16-7 Deployment Wizard—Summary



93111

- Step 11** Choose **Finish** (when the Deployment Summary information is displayed) to complete deployment and close the Deployment Wizard - Summary window. The new VRF object (that is, VRF-1) is created and displayed in the Map Viewer window beneath the Chassis object in the Software/VRF folder.

Figure 16-8 Example Showing the Newly Deployed VRF Object



The VRF object is now created (VRF-1 in the example in [Figure 16-8](#)) and available in the EM. You can now create and associate a VRF policy within the chassis. See the “[Creating and Configuring the VRF Policy on a Device](#)” section on [page 16-8](#) for further details.

Creating and Configuring the VRF Policy on a Device

This section describes the following areas:

- [Configuring and Creating a VRF Policy on a Selected Chassis](#)
- [Removing a VRF Policy from a Selected Chassis](#)
- [Adding a Routing Target to a Selected Chassis](#)
- [Deleting a Routing Target from a Selected Chassis](#)
- [VRF Configuration Window—Detailed Description](#)

Configuring and Creating a VRF Policy on a Selected Chassis




Note

You can only create (upload) the policy to the device when the chassis object is in a managed state and the VRF is not present (uploaded) in to the chassis already. It is not possible to modify the configuration of VRF policy if it is already created (uploaded) in to the chassis. If you wish to modify a VRF policy that is already on a chassis you must firstly remove the VRF policy from the chassis. To remove a VRF policy from a chassis, see the “[Removing a VRF Policy from a Selected Chassis](#)” section on [page 16-10](#) for further details.

To configure and create a VRF policy on a selected device, proceed as follows:

- Step 1** Right click on a chassis object and choose **Configuration >MPLS> VRF Configuration**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VRF Configuration window. The VRF Configuration window appears, with the VRF Configuration tab displayed:

Figure 16-9 VRF Configuration Window



- Step 2** Choose a **Chassis** and **VRF** from the list box displayed at the left of the window.
- Step 3** Configure the fields in the VRF Configuration tab as required. For further information, see the [“VRF Configuration Window—Detailed Description”](#) section on page 16-11.
- Step 4** Choose the **Save** icon on the toolbar to save your changes.
- Step 5** Choose **Create** (located in the Device Actions area) to create (upload) the VRF policy to the chassis. A status report appears displaying whether the create action succeeded or failed. An error report will appear if a VRF policy with same name is already present in the device.



Note The Status bar (at the bottom left of the window) displays information about the current state of the VRF Policy (VRF(1) indicates that the VRF policy is in the applied/uploaded state and VRF(0) indicates that the VRF policy has been removed from the device).

Once the VRF policy object is created and available in the device, it should be possible to associate/disassociate that VRF object to/from the interface which inherits the CiscoVRFFunctionality. See the [“Creating and Configuring the VRF Policy on a Device”](#) section on page 16-8 for further details.

Removing a VRF Policy from a Selected Chassis

To remove a VRF policy from a selected device, proceed as follows:

-
- Step 1 Right click on the chassis object and choose **Configuration> MPLS> VRF Configuration**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VRF Configuration window. The VRF Configuration window appears, with the VRF Configuration tab displayed (see [Figure 16-9 on page 16-9](#)):
 - Step 2 Choose a **Chassis** and **VRF** from the list box displayed at the left of the window.
 - Step 3 Choose **Remove** (located in the Device Actions area) to remove the VRF from the selected chassis. A status report appears displaying whether the remove action succeeded or failed.
-

Adding a Routing Target to a Selected Chassis



Note You can only add a routing target to the device when the VRF is not present (uploaded) in to the chassis.

To add a routing target to a selected device, proceed as follows:

-
- Step 1 Right click on the chassis object and choose **Configuration> MPLS> VRF Configuration**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VRF Configuration window. The VRF Configuration window appears, with the VRF Configuration tab displayed (see [Figure 16-9 on page 16-9](#)):
 - Step 2 Choose a **Chassis** and **VRF** from the list box displayed at the left of the window.
 - Step 3 Configure the fields in the Routing Target area as required. For further information, see the [“VRF Configuration Window—Detailed Description” section on page 16-11](#).
 - Step 4 Choose **Add** (located in the Routing Target area) to add the routing target from the selected chassis. An Action Report window appears only if the add action fails.
Choose the **Save** icon on the toolbar to save your changes.
-

Deleting a Routing Target from a Selected Chassis

To delete a routing target from a selected device, proceed as follows:

-
- Step 1 Right click on the chassis object and choose **Configuration> MPLS> VRF Configuration**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VRF Configuration window. The VRF Configuration window appears, with the VRF Configuration tab displayed (see [Figure 16-9 on page 16-9](#)):
 - Step 2 Choose a **Chassis** and **VRF** from the list box displayed at the left of the window.
 - Step 3 Enter the Route Target to remove in the Route ID field and then select the appropriate route type from the Route Type drop down box.

- Step 4** Choose **Delete** (located in the Routing Target area) to delete the routing target from the selected chassis. An Action Report window appears only if the delete action fails.
- Step 5** Choose the **Save** icon on the toolbar to save your changes.
-

VRF Configuration Window—Detailed Description



Note

You can only configure the attributes in the VRF Configuration window when the VRF is not present (uploaded) in to the chassis.

The VRF Configuration window (see [Figure 16-9](#)) displays the VRF Configuration tab.

VRF Configuration Tab

The VRF Configuration tab displays the following areas: VPN Details, Routing Destination, Threshold, Maximum Routes, Device Actions, Export, Import and Routing Target.

VPN Details

The VPN Details area displays the following information:

VPN—Allows you to configure the VPN ID for the selected VRF (as specified in RFC2685).

Routing Destination

The Routing Destination area displays the following information:

Routing Destination Id—Allows you to specify a route distinguisher to create routing and forwarding tables to uniquely identify the customer address though the customer site is not globally unique.

Threshold

The Threshold area displays the following information:

Illegal RX Threshold—Allows you to set the threshold on the number of illegally received labels above which the notification needs to be issued.

Maximum Routes

The Maximum Routes area displays the following information:

Maximum Routes—Allows you to configure the maximum number of routes allowed in this routing table.

Threshold in%—Allows you to configure the threshold value (in percentage of number of entries in routing table) at which to generate a warning message).

Device Action

The Device Action area displays the following information:

Remove button—Choose **Remove** to remove (unload) the VRF policy from the chassis. You can only remove the policy from the device when the chassis object is in managed state and the VRF is already created (uploaded) into the device.

Create button—Choose **Create** to create (upload) the VRF policy to the chassis. You can only create the policy to the device when the chassis object is in a managed state and the VRF is not present (uploaded) in to the chassis already.

Export

The Export area displays the following information:

VRF Export—Allows you to associate the specified route map with the VRF policy (to import route).

Import

The Import area displays the following information:

VRF Import—Allows you to associate the specified route map with the VRF policy (to export route).

Routing Target

The Routing Target area displays the following information:

Type—Allows you to select the routing target community type (import, export or both) from a drop down list.

Route Id—Allows you to enter a target VPN extended community (ASN:nn or IP-address:nn format).

Add Button—Choose **Add** to add the selected route target to the VRF policy.

Delete Button—Choose **Delete** to delete the selected route target from the VRF policy.

Route Target—Displays a list of import and/or export target communities for the selected VRF policy.

Associating a VRF Policy with an Interface

After the VRF policy object is created and available in the device you can associate/disassociate the VRF object to/from the interfaces which inherits the CiscoVRFFunctionality using the VRF Association window. The VRF Association window allows you to apply/remove any of the VRF policy (provided it is already created in the device through the VRF Configuration window) to one or more of the VRF functionality interfaces (in managed state).

The VRF Association section covers the following areas:


- [Associating VRF Policies](#)
- [Removing a VRF Policy from a Selected Interface](#)
- [VRF Association Window—Detailed Description](#)

Associating VRF Policies

To associate a the VRF policy with one or more selected interfaces, proceed as follows:

- Step 1** Right click on the chassis object and choose **Configuration> Interface> MPLS> VRF Association**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VRF Association window. The VRF Association window appears, with the VRF tab displayed:

Figure 16-10 VRF Association Window



- Step 2** Choose a **Chassis**, **Module** and **Interface** from the list displayed at the left of the window. For further information, see the [“VRF Association Window—Detailed Description”](#) section on page 16-14.
- Step 3** Choose a VRF from the list of VRF policies in the Available Policies area.
- Step 4** Click the **Apply** button to associate the selected VRF policy with the selected interface. An Action report window appears to inform you that the VRF policy has been associated successfully. An error message appears if the VRF policy is already applied to the interface.

Removing a VRF Policy from a Selected Interface

It is possible to remove the VRF policies from selected interfaces, only when the interfaces are in a managed state and they are already associated with the VRF policy.

To associate a VRF policy with one or more selected interfaces, proceed as follows:

-
- Step 1** Right click on the chassis object and choose **Configuration> Interface> MPLS> VRF Association**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VRF Association window. The VRF Association window appears, with the VRF tab displayed.
- Step 2** Choose a **Chassis**, and one or more **Modules** and **Interfaces** from the list displayed at the left of the window. For further information, see the “[VRF Association Window—Detailed Description](#)” section on [page 16-14](#). You can multi select interfaces and modules but only one chassis.



Note To select a contiguous block of interfaces or modules, click on the first; then, hold down the **Shift** key and click on the entry at the end of the group to be added. To add a non-contiguous entry to the selection group, hold down the **Ctrl** (Control) key and click on the entry to be added. A subsequent click anywhere on the window deselects all previous selections.

- Step 3** Click the **Remove** button to remove the VRF policy from the interface. An Action Report window appears to inform you if the VRF policy has failed to be removed successfully.
-

VRF Association Window—Detailed Description

The VRF Association window (see [Figure 16-10](#)) displays the VRF Config tab.

VRF Tab

The VRF tab displays four areas: Available VRF Policies, Actions, Associated VRF Policy Information, and Apply Status.

Available VRF Policies

The Available VRF Policies area displays the following information:

VRF Policies—Displays a list of available VRF policies in the selected chassis.

Actions

The Actions area displays the following information:

Apply Button—Choose **Apply** to apply the selected VRF policies to the selected interfaces.

Remove Button—Choose **Remove** to remove the selected VRF policies from the selected interfaces.

Associated VRF Policy Information

The Associated VRF Policy Information area displays the following information:

Applied VRF Policy—Displays the VRF policy associated to the selected interface.

Apply Status

The Apply Status area displays the following information:

Status of Last Apply—Displays the result of the last (Apply/Remove) operation.

VRF Fault Management

The VRF Fault Management section covers the following areas:

- [VRF Status](#)
- [Interface VRF Status](#)
- [VPN Status](#)
- [VRF Object Status](#)

VRF Status

The VRF Status window displays basic information for all the VRFs on a selected chassis. The VRF Status section describes the following information:


- [Viewing the VRF Status Window](#)
- [VRF Status Window—Detailed Description](#)

Viewing the VRF Status Window

To view the VRF Status window, proceed as follows:

-
- Step 1** Right click on an appropriate object and choose **Fault> MPLS> VRF Status**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VRF Status window. The VRF Status window appears, with the General tab displayed.

Figure 16-11 VRF Status Window



- Step 2** Select a **Chassis** from the list box displayed at the left of the window. The appropriate information appears for the selected chassis.
- Step 3** Select a **VRF** from the list of VRFs displayed in the VRF Details area. The appropriate information appears for the selected VRF. For further information, see [“VRF Status Window—Detailed Description” section on page 16-16](#).

VRF Status Window—Detailed Description

The VRF Status window provides basic information for all the VRFs on a chassis. The VRF Status window displays two tabs: General, and Performance And Security.

General Tab

The General tab (see [Figure 16-11](#)) displays VRF details in two areas, VRF Details and General.

VRF Details

The VRF Details area displays the following information:

VRF—List of VRFs configured in the device (listed according to VRF names).

General

The General area displays the following information:

VRF Description—The description of this VRF.

Oper Status—Denotes whether a VRF is operational or not. A VRF is up when at least one interface associated with the VRF, which interface operation status is up. A VRF is down when:

- There does not exist at least one interface whose interface operation status is up.
- There are no interfaces associated with the VRF.

Route Distinguisher—Displays the route distinguisher for this VRF.

No. of Active Interfaces—The number of VRFs which are active on this node. Total number of interfaces connected to this VRF with interface operation status = up.

No. of Associated Interfaces—Total number of interfaces connected to this VRF (independent of interface operation status type).

No. of Max Routes—Denotes maximum number of routes which the device will allow all VRFs jointly to hold. If this value is set to 0, this indicates that the device is unable to determine the absolute maximum. In this case, the configured maximum may not actually be allowed by the device.

Mid Route Threshold—Displays mid-level water marker for the number of routes which this VRF may hold.

High Route Threshold—Displays high-level water marker for the number of routes which this VRF may hold.

Creation Time—Displays the time at which this VRF entry was created.


Config Last Changed—The value of sysUpTime at the time of the last change of this table entry, which includes changes of VRF parameters defined in this table or addition or deletion of interfaces associated with this VRF.

Storage Type—Displays the storage type for this entry.

Performance and Security Tab

The Performance and Security tab (see [Figure 16-12](#)) displays performance and security details in three areas, VRF Details, Performance and Security.

Figure 16-12 VRF Status Window—Performance and Security Tab



VRF Details

The VRF Details area displays the following information:

VRF List—List of VRFs configured in the device.

Performance

The Performance area displays the following information:

No. of Current Routes—Displays the number of routes currently used by this VRF.

No. of Routes Added—Displays the number of routes added to this VPN/VRF over the course of its lifetime.

No. of Routes Deleted—Displays the number of routes removed from this VPN/VRF.

Security

The Security area displays the following information:

No. of illegally received labels—Indicates the number of illegally received labels on this VPN/VRF.

No. of illegal labels threshold value—The number of illegally received labels above which the notification is issued.

Interface VRF Status

The Interface VRF Status window displays the interfaces on a chassis which are associated with VRFs and their associated VRF information.

The Interface VRF Status section covers the following areas:


- [Viewing the Interface VRF Status Window](#)
- [Interface VRF Status Window—Detailed Description](#)

Viewing the Interface VRF Status Window

To view the Interface VRF Status window, proceed as follows:

- Step 1** Right click on a chassis object and choose **Fault > MPLS > Interface VRF Status**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the Interface VRF Status window. The Interface VRF Status window appears, with the Interface VRF Association tab displayed:

Figure 16-13 Interface VRF Status Window



- Step 2** Choose a **Chassis** from the list box displayed at the left of the window. The status information appears for the selected chassis. For further information, see [“VRF Status Window—Detailed Description” section on page 16-16](#).

Interface VRF Status Window—Detailed Description

The Interface VRF Status window provides information about every interface that is capable of supporting MPLS/BGP VPNs. The Interface VRF Status window displays a single Interface VRF Association tab.

Interface VRF Association Tab

The Interface VRF Association tab (see [Figure 16-13](#)) displays two areas, Interface VRF Association and Association Status.

Interface VRF Association

The Interface VRF Association area displays the following information:

VRF Interface/Sub-Interface—Displays only those interfaces that are enabled for MPLS/BGP VPN. The interfaces/sub-interfaces are listed alphabetically.

Association Status

The Association Status area displays the following information:

Label Edge Type—Either the providerEdge (PE) or customerEdge (CE).

Storage Type—Displays the storage type for this entry.

VPN Classification—Link participation: carrier-of-carrier or enterprise or as inter provider.

Route Distribution Protocol—Displays the route distribution protocol across the PE-CE link.

Associated VRF—Displays the name of the VRF associated with the selected interface.

Interface Status—Displays the operational status of the selected interface.

VPN Status

The VPN Status window displays VPN Status. The VPN Status section contains the following areas:


- [Viewing the VPN Status Window](#)
- [VPN Status Window—Detailed Description](#)

Viewing the VPN Status Window

To view the VPN Status window, proceed as follows:

- Step 1 Right click on a chassis object and choose **Fault>MPLS>VPN Status**. See [Table 16-1 on page 16-2](#) for information on which objects allow you to launch the VPN Status window. The VPN Status window appears, with the General tab displayed.

Figure 16-14 VPN Status Window



- Step 2** Choose a **Chassis** from the list displayed at the left of the window. For further information on the fields displayed in this window, see the “[VPN Status Window—Detailed Description](#)” section on page 16-21.

VPN Status Window—Detailed Description

The VPN Status window displays four tabs: General, Routes, Route Targets, and BGP Neighbor.

General Tab

The General tab (see [Figure 16-18](#)) displays a single General area.

General

The General area displays the following information:

No. of Configured VRFs—Displays the number of VRFs that are configured on this node.

No. of Connected Interfaces—Displays the total number of interfaces that are connected to the selected VRF.

No. of Maximum Possible Routes—Displays the maximum number of allowable routes on the device.


No. of Active VRFs—Displays the number of VRFs that are active on this node.

Notification Status—Displays the notification status.

Routes Tab

The Routes tab (see [Figure 16-15](#)) displays the route table information for VRFs in a single VRF Routes area.

Figure 16-15 VPN Status Window—Routes Tab



VRF Routes

The VRF Routes area displays a table with the following information:

VRF—Name of the VRF which is responsible for this route.

Associated Interface Name—Name of the interface to which the VRF is associated.

Destination—The destination IP address of this route.

Subnet Mask—The subnet mask of the Destination IP address.

Next Hop—On remote routes, the address of the next system or route.

Route Tos—The IP TOS Field is used to specify the policy to be applied to this route.

Dest Addr Type—The address type of the destination IP address.

Mask Addr Type—The address type of the subnet mask.

Next Hop Addr Type—The address type of the Next Hop Address.

Route Type—The type of route.

Route Proto—The routing mechanism via which this route was learned. Inclusion of values for gateway routing protocols is not intended to imply that hosts should support those protocols.

Route Age—The number of seconds since this route was last updated or otherwise determined to be correct.

Route Info—A reference to MIB definitions specific to the particular routing protocol which is responsible for this route, as determined by the value specified in the route's RouteProto value.

Next Hop AS—The Autonomous System Number of the Next Hop. The semantics of this object are determined by the routing-protocol specified in the route's RouteProto value. When this object is unknown or not relevant its value should be set to zero.

Metric1—The primary routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Metric2—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Metric3—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Metric4—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.


Metric5—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Storage Type—Displays the storage type for this entry.

Route Targets Tab

The Route Targets tab (see [Figure 16-21](#)) displays VRF route target information in a single VRF Route Targets area.

Figure 16-16 VPN Status Window—Route Targets Tab



VRF Route Targets

The VRF Route Targets area displays a table. This table specifies per-VRF route target association. Each entry identifies a connectivity policy supported as part of a VPN. The VRF Route Targets table with the following information:

VRF—Name of VRF which is responsible for VPN target communication.

Route Target—Route target distribution policy.

Route Target Descr—Description of the route target.


Route Target Type—The route target export distribution type.

Route Target Index—Auxiliary index for Route Targets configured for a particular VRF.

BGP Neighbor Tab

The BGP Neighbor tab (see [Figure 16-22](#)) displays per-interface MPLS/EBGP neighbor information in a single Interface MPLS/EBGP Neighbor area.

Figure 16-17 VPN Status Window—BGP Neighbor Tab



Interface MPLS/EBGP Neighbor

The Interface MPLS/EBGP Neighbor area displays a table. Each entry in this table specifies a per-interface MPLS/EBGP neighbor. An entry in this table is created by an LSR for every VRF capable of supporting MPLS/BGP VPN. The indexing provides an ordering of VRFs per-VPN interface.

The Interface MPLS/EBGP Neighbor table displays the following information:

VRF—VRF name responsible for this MPLS/BGP route.

Associated Interface Name—Interface Name to which VRF is associated.

Neighbor Addr—Displays the EBGP neighbor address

Neighbor Type—Displays the address family of the PE address.

Neighbor Role—Displays the role played by this EBGP neighbor with respect to this VRF.

Neighbor Index—Displays a unique tertiary index for an entry in the MPLS/BGP Neighbor Table.

Neighbor Storage Type—The storage type for this entry.

VRF Object Status

The VRF Object Status window displays information specifically for the VRF object from which the window was launched. This window displays values only for VRFs created in the device through the EM.



Note

The VRF Status, VPN Status and Interface VRF Status windows at chassis level display similar information for all the VRFs on that chassis.

The VRF Object Status section contains the following areas:


- [Viewing the VRF Object Status Window](#)
- [VRF Object Status Window—Detailed Description](#)

Viewing the VRF Object Status Window

To view the VRF Object Status window, proceed as follows:

- Step 1** Right click on the VRF object and choose **Cisco 12000/10720 Manager> Fault> Chassis> MPLS>VRF Object Status**. See [Table 15-1 on page 15-3](#) for information on which objects allow you to launch the VRF Object Status window. The VRF Object Status window appears.

Figure 16-18 VRF Object Status Window



- Step 2** Choose a **VRF** from the list displayed at the left of the window. For further information on the fields displayed in this window, see the “[VRF Object Status Window—Detailed Description](#)” section on [page 16-27](#).

VRF Object Status Window—Detailed Description

The VRF Object Status window displays five tabs: General, Routes, Route Targets, Interface Association and Performance.

General Tab

The General tab (see [Figure 16-18](#)) displays VRF details in two areas, General and Security.

General

The General area displays the following information:

Oper Status—Denotes whether a VRF is operational or not. A VRF is up when at least one interface associated with the VRF, which interface operation status is up. A VRF is down when:

- There does not exist at least one interface whose interface operation status is up.
- There are no interfaces associated with the VRF.

Mid Route Threshold—Denotes mid-level water marker for the number of routes which this VRF may hold.

Storage Type—Displays the storage type for this entry.

VRF Description—Displays the description of this VRF.

Associated Interfaces—Total number of interfaces connected to this VRF (independent of interface operation status type).

No. of Active Interfaces—The number of VRFs which are active on this node. Total number of interfaces connected to this VRF with interface operation status = up.

Route Distinguisher—Displays the route distinguisher for this VRF.

Creation Time—Displays the The time at which this VRF entry was created.

High Route Threshold—Displays high-level water marker for the number of routes which this VRF may hold.

Conf Last Changed On—Displays the value of sysUpTime at the time of the last change of this table entry, which includes changes of VRF parameters defined in this table or addition or deletion of interfaces associated with this VRF.

Max No. of Routes—Displays the maximum number of routes which this VRF is configured to hold.

Security

The VPN VRF Details area displays the following information:


No. of illegally received labels—Indicates the number of illegally received labels on this VPN/VRF.

Notification issued after no. of illegal labels—The number of illegally received labels above which this notification is issued.

Routes Tab

The Routes tab (see [Figure 16-21](#)) displays the route table information for VRFs in a single Routes area.

Figure 16-19 VRF Object Status Window—Routes Tab



Routes

The Routes area displays the following information:

Destination—The destination IP address of this route.

Associated Interface Name—Interface Name to which VRF is associated.

Subnet Mask—The subnet mask of the Destination IP address.

Route Tos—The IP TOS Field is used to specify the policy to be applied to this route.

Next Hop—On remote routes, the address of the next system or route.

Dest Addr Type—The address type of the destination IP address.

Mask Addr Type—The address type of the subnet mask.

Next Hop Addr Type—The address type of the Next Hop Address.

Route Type—The type of route.

Route Proto—The routing mechanism via which this route was learned. Inclusion of values for gateway routing protocols is not intended to imply that hosts should support those protocols.

Route Age—The number of seconds since this route was last updated or otherwise determined to be correct.

Route Info—A reference to MIB definitions specific to the particular routing protocol which is responsible for this route, as determined by the value specified in the route's RouteProto value.

Next Hop AS—The Autonomous System Number of the Next Hop. The semantics of this object are determined by the routing-protocol specified in the route's RouteProto value. When this object is unknown or not relevant its value should be set to zero.

Metric1—The primary routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Metric2—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Metric3—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Metric4—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.


Metric5—An alternate routing metric for this route. The semantics of this metric are determined by the routing-protocol specified in the route's RouteProto value. If this metric is not used, its value should be Notused.

Storage Type—Displays the storage type for this entry.

Route Targets Tab

The Route Targets tab (see [Figure 16-21](#)) displays the route table information for VRFs in a single Routes area.

Figure 16-20 VRF Object Status Window—Route Targets



Route Targets

The Route Targets area displays the following information:

Route Target—Route target distribution policy.

Route Target Descr—Description of the route target.


Route Target Type—The route target export distribution type.

Route Target Index—Auxiliary index for Route Targets configured for a particular VRF.

Interface Association Tab

The Interface Association tab (see [Figure 16-22](#)) displays all of the interfaces that the selected VRF is associated to, in a single Interface Association area.

Figure 16-21 VRF Object Status Window—Interface Association Tab



Interface Association

The Interface Association area displays the following information:

Associated Interface Name—Interface Name to which VRF is associated.

Interface Status—Displays the operational status of the selected interface.

Label Edge Type—Either the providerEdge (PE) or customerEdge (CE).

VPN Classification—Denotes whether this link participates in a carrier-of-carrier's, enterprise, or inter-provider scenario.


Route Distribution Protocol—Displays the route distribution protocol across the PE-CE link.

Storage Type—Displays the storage type for this entry.

Performance Tab

The Performance tab (see [Figure 16-22](#)) displays VRF performance statistics in a single Performance area.

Figure 16-22 VRF Object Status Window—Performance Tab



Performance

The Performance area displays the following information:

No. of Curr Routes—Displays the number of routes currently used by this VRF.

No. of Routes Deleted—Displays the number of routes removed from this VPN/VRF.

No. of Routes Added—Displays the number of routes added to this VPN/VRF over the course of its lifetime.



MPLS Trap Management

This chapter describes MPLS traps that can be configured using the Cisco 12000/10720 Router Manager application using the MPLS Trap Configuration window.

The MPLS Trap Configuration window allows you to enable/disable MPLS related Traps on a managed Cisco 12000 Series Router or a 10720 Router. The MPLS based traps that can be configured through the Cisco 12000/10720 Router Manager application are as follows:

- LDP traps
- VPN traps
- Traffic engineering traps

Cisco 12000/10720 Router Manager is capable of receiving the above-mentioned traps and address as alarms with a predefined severity against the respective chassis objects.

This chapter provides the following information:

- [MPLS Traps Supported by the C12000/10720 Router Manager](#)
- [Enabling/Disabling Traps on the Device](#)
- [MPLS CLI Troubleshooting Services](#)

MPLS Traps Supported by the C12000/10720 Router Manager

[Table 17-1](#) provides a lists of MPLS traps with the detailed description, severity and Clear correlation information:

Table 17-1 MPLS Traps/Alarms Raised

Trap	Alarm Description	Severity	Clears
LdpSessionUp	LDP Session Up between <LdpEntityLdpId> <LdpEntityIndex> <LdpPeerLdpId>	Normal	LdpSessionUp and LdpSessionDown
LdpSessionDown	LDP Session Down between <LdpEntityLdpId> <LdpEntityIndex> <LdpPeerLdpId>	Major	LdpSessionDown

Table 17-1 MPLS Traps/Alarms Raised (continued)

Trap	Alarm Description	Severity	Clears
LdpPvlMismatch	LDP Entity <LdpEntityLdpId> Number <LdpEntityIndex> with Path Vector Limit <LdpEntityPVL> does not match Peer LDP Entity's <LdpPeerLdpId> Path vector Limit of <LdpPeerPVL>	Warning	LdpPvlMismatch
LdpInitSesThresholdExceed	LDP Entity <LdpEntityLdpId> Number <LdpEntityIndex> exceeded threshold <LdpEntityInitSesThreshold> of Session Initialization messages.	Warning	LdpInitSesThresholdExceed
VrfIfUp	Interface <ifIndex> associated with VRF <VpnVrfName> is up	Normal	VrfIfUp and VrfIfDown
VrfIfDown	Interface <ifIndex> associated with VRF <VpnVrfName> is down	Major	VrfIfDown
VrfRouteMidThreshExceed	Current number of routes <VpnVrfPerfCurrNumRoutes> exceeds the Mid-Threshold for vrf <VpnVrfName>	Warning	VrfRouteMidThreshExceed and VrfRouteMaxThreshExceed
VrfRouteMaxThreshExceed	Current number of routes <VpnVrfPerfCurrNumRoutes> exceeds the Max-Threshold for vrf <VpnVrfName>	Warning	VrfRouteMaxThreshExceed and VrfRouteMidThreshExceed
VrfSecIllegalLabelThreshExceeded	Number of illegally label violations <VpnVrfSecIllegalLabelViolations> exceed the threshold value for vrf <VpnVrfName>	Warning	VrfSecIllegalLabelThreshExceeded
TunnelUp	Tunnel <TunnelIndex> Up. Admin Status: <TunnelAdminStatus>, Operational Status: <TunnelOperStatus>, Ingress LSR Id: <TunnelIngressLSRId>, Egress LSR Id: <TunnelEgressLSRId>	Normal	TunnelUp and TunnelDown
TunnelDown	Tunnel <TunnelIndex> Down. Admin Status: <TunnelAdminStatus>, Operational Status: <TunnelOperStatus>, Ingress LSR Id: <TunnelIngressLSRId>, Egress LSR Id: <TunnelEgressLSRId>	Major	TunnelDown
TunnelRerouted	Tunnel <TunnelIndex> ReRouted. Admin Status: <TunnelAdminStatus>, Operational Status: <TunnelOperStatus>, Ingress LSR Id: <TunnelIngressLSRId>, Egress LSR Id: <TunnelEgressLSRId>	Minor	TunnelRerouted

Enabling/Disabling Traps on the Device

To enable or disable MPLS trap generation on a selected chassis, proceed as follows:


- Step 1** Open the MPLS Trap Configuration window. Right click on an appropriate object and select the **Cisco 12000/10720 Manager> Configuration> Chassis> MPLS> MPLS Trap Configuration** option. See [Table 17-2](#) for information on which objects allow you to launch the MPLS Trap Configuration window.

Table 17-2 Launching the MPLS Trap Configuration Window

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window						Menu Options to Select to Open Window
	Site	Chassis		Module	Interface	VRF	
		12000 Series	10720				
Enabling/Disabling Traps on the Device	Yes	Yes	Yes	No	No	No	Cisco 12000/10720 Manager> Configuration> Chassis> MPLS> MPLS Trap Configuration

The MPLS Trap Configuration window appears, with the Traps tab displayed.

Figure 17-1 MPLS Trap Configuration Window—Traps Tab



**Note**

The MPLS Trap Configuration window uses IOSDrep for configuration and population of the attributes. The user needs to configure the management information for the chassis against which the MPLS Trap Configuration window is launched.

**Note**

Enabling the LDP traps through the MPLS Trap Configuration window enables all the MPLS LDP based traps on the managed device. For example, if the user is selecting Enable against the LDP field then saves the changes then the MPLS Trap Configuration window will enable the LDP session Up, Session Down, Threshold and Path Vector traps on the device. Currently the EM does not provide the support to enable or disable the sub category of traps mentioned for LDP separately. Also, even if the selected chassis has any one of the LDP (session Up, Session Down, Threshold and Path Vector) traps enabled, then the dialog will show “Enabled” against the LDP field. This does not mean that all the related LDP traps are enabled in the selected device. The above information is also applicable to VPN and Traffic Engineering (TE) traps.

Step 2 Choose a **Chassis** from the list displayed at the left of the window.

Step 3 To Enable the traps:

Select Enable in the drop-down list and save the changes from the dialog. When user Enables the respective Traps the “**snmp-server enable traps {ldp/ traffic-eng / vpn}**” command is issued to the device.

To Disable the Traps:

Select Disable in the drop-down list. When user disables the respective Traps “**no snmp-server enable traps {ldp / traffic-eng / vpn}**” command will be issued to the device

**Note**

To receive traps from the managed routers the EM has to be configured as the Trap Host on the routers. This can be achieved using the SNMP Management window at chassis level. See the “[SNMP Management](#)” section on page 4-14 for further details.

See the “[MPLS Trap Configuration Window—Detailed Description](#)” section on page 17-4 for further details of the attributes displayed.

Step 4 Save your changes by clicking the **Save** icon on the toolbar.

MPLS Trap Configuration Window—Detailed Description

The MPLS Trap Configuration window displays a single Traps tab.

Traps Tab

The Traps tab displays a single Traps area:

VPN Traps—Allows you to choose whether to Enable/Disable VPN based traps. The VPN based traps supported by the Cisco 12000/10720 Router Manager application are the VRF trap names described in [Table 17-1 on page 17-1](#).

Traffic Engineering (TE) Traps—Allows you to choose whether to Enable/Disable Traffic Engineering based traps. The TE traps supported by the Cisco 12000/10720 Router Manager application are described in [Table 17-1 on page 17-1](#).

LDP Traps—Allows you to choose whether to Enable/Disable LDP based traps. The LDP traps supported by the Cisco 12000/10720 Router Manager application are described in [Table 17-1 on page 17-1](#).

MPLS CLI Troubleshooting Services

This section describes the MPLS CLI troubleshooting services that can be accessed using the Cisco 12000/10720 Router Manager application.

Launching the MPLS CLI Troubleshooting Services Windows

[Table 17-3](#) displays the Cisco 12000/10720 Router Manager MPLS CLI Troubleshooting windows that can be launched from each object type. For example, the Verify Routing Protocols window can be launched from a chassis object, but cannot be launched from any other object types.

Table 17-3 *Launching the MPLS CLI Troubleshooting Services Windows*

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window								Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	Software Folder	VRF Folder	VRF	
Verify Routing Protocols	No	Yes	Yes	No	No	No	No	No	Fault> MPLS> CLI Troubleshooting> Verify Routing Protocols
Verify Routing Tables	No	Yes	Yes	No	No	No	No	No	Fault> MPLS> CLI Troubleshooting> Verify Routing Tables
Verify CEF Switching	No	Yes	Yes	No	No	No	No	No	Fault> MPLS> CLI Troubleshooting> Verify CEF Switching
Verify CEF Switching Summary	No	Yes	Yes	No	No	No	No	No	Fault> MPLS> CLI Troubleshooting> Verify CEF Switching Summary
Verify MPLS Interfaces	No	Yes	Yes	No	No	No	No	No	Fault> MPLS> CLI Troubleshooting> Verify MPLS Interfaces
Verify Label Distribution	No	Yes	Yes	No	No	No	No	No	Fault> MPLS> CLI Troubleshooting> Verify Label Distribution

Table 17-3 Launching the MPLS CLI Troubleshooting Services Windows (continued)

Cisco 12000/10720 Router Manager Window/Task	Objects (that can be selected) to Open the Window								Menu Options to Select to Open Window
	Site	Chassis 12000 Series	Chassis 10720	Module	Interface	Software Folder	VRF Folder	VRF	
Verify Label Bindings	No	Yes	Yes	No	No	No	No	No	Fault> MPLS> CLI Troubleshooting> Verify Label Bindings
Verify Interface CEF Switching	No	No	No	No	Yes	No	No	No	Cisco 12000/10720 Manager> Fault> MPLS> CLI Troubleshooting> Verify Interface CEF Switching

Verify Routing Protocols

To open the Verify Routing Protocols window see [Table 17-3](#). The Verify Routing Protocols window (see [Figure 17-2](#)) displays the results of the **show ip protocols** command.

Figure 17-2 Verify Routing Protocols Window

```

GSR12416-10.76.82.136: show ip protocols
IP Address: 10.76.82.136
WARNING: username not set

>>>show ip protocols
*** IP Routing is NSF aware ***
Routing Protocol is "eigrp 100"
  Outgoing update filter list for all interfaces is not set
  Incoming update filter list for all interfaces is not set
  Default networks flagged in outgoing updates
  Default networks accepted from incoming updates
  EIGRP metric weight K1=1, K2=0, K3=1, K4=0, K5=0
  EIGRP maximum hopcount 100
  EIGRP maximum metric variance 1
  Redistributing: eigrp 100
  Automatic network summarization is in effect
  Routing for Networks:
  Routing Information Sources:
    Gateway         Distance      Last Update
  Distance: internal 90 external 170


Routing Protocol is "ospf 4"
  Invalid after 0 seconds, hold down 0, flushed after 0
  Outgoing update filter list for all interfaces is not set
  
```

93139

Verify Routing Tables

To open the Verify Routing Tables window see [Table 17-3](#). The Verify Routing Tables window (see [Figure 17-3](#)) displays the results of the **show ip route** command.

Figure 17-3 Verify Routing Tables Window



```

GSR12416-10.76.82.136: show ip route
IP Address: 10.76.82.136
WARNING: username not set

>>>show ip route
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default, U - per-user static route, o - ODR

Gateway of last resort is 0.0.0.0 to network 0.0.0.0

 2.0.0.0/32 is subnetted, 1 subnets
 B    2.2.2.2 [20/0] via 172.138.66.2, 07:41:07
 70.0.0.0/16 is subnetted, 1 subnets
 C    70.70.0.0 is directly connected, Loopback100
 S    64.0.0.0/8 is directly connected, Ethernet0
 66.0.0.0/8 is variably subnetted, 2 subnets, 2 masks
 B    66.66.0.0/16 [20/0] via 172.138.66.2, 07:41:07
 B    66.44.45.4/31 [20/0] via 172.138.66.2, 07:41:07
 C    172.138.0.0/16 is directly connected, SRP0/0
 52.0.0.0/32 is subnetted, 1 subnets

```

Close

93140

Verify CEF Switching

To open the Verify CEF Switching window see [Table 17-3](#). The Verify CEF Switching window (see [Figure 17-4](#)) displays the results of the **show ip cef** command.

Figure 17-4 Verify CEF Switching Window

```

GSR12416-10.76.82.136: show ip cef
IP Address: 10.76.82.136
WARNING: username not set


>>>show ip cef
Prefix          Next Hop      Interface
0.0.0.0/0       attached     Ethernet0
0.0.0.0/32      receive
2.2.2.2/32      172.138.66.2 SRP0/0
10.51.20.205/32 10.51.20.205 Ethernet0
10.76.82.128/27 attached     Ethernet0
10.76.82.128/32 receive
10.76.82.129/32 10.76.82.129 Ethernet0
10.76.82.135/32 10.76.82.135 Ethernet0
10.76.82.136/32 receive
10.76.82.138/32 10.76.82.138 Ethernet0
10.76.82.139/32 10.76.82.139 Ethernet0
10.76.82.141/32 10.76.82.141 Ethernet0
10.76.82.142/32 10.76.82.142 Ethernet0
10.76.82.143/32 10.76.82.143 Ethernet0
10.76.82.152/32 10.76.82.152 Ethernet0
10.76.82.153/32 10.76.82.153 Ethernet0
10.76.82.155/32 10.76.82.155 Ethernet0
10.76.82.156/32 10.76.82.156 Ethernet0
  
```

93136

Verify CEF Switching Summary

To open the Verify CEF Switching Summary window see [Table 17-3](#). The Verify CEF Switching Summary window (see [Figure 17-5](#)) displays the results of the **show ip cef summary** command.

Figure 17-5 Verify CEF Switching Summary Window



```
GSR12416-10.76.82.136: show ip cef summary
IP Address: 10.76.82.136
WARNING: username not set

>>>show ip cef summary
IP Distributed CEF with switching (Table Version 750), flags=0x0, bits=8
 86 routes, 0 reresolve, 0 unresolved (0 old, 0 new), peak 79
136 leaves, 145 nodes, 164928 bytes, 3518 inserts, 3382 invalidations
 0 load sharing elements, 0 bytes, 0 references
universal per-destination load sharing algorithm, id 07D8C388
 2(0) CEF resets, 12 revisions of existing leaves
12 in-place/0 aborted modifications
Resolution Timer: Exponential (currently 1s, peak 2s)
refcounts: 40276 leaf, 39936 node

Table epoch: 0 (86 entries at this epoch)
Transient memory used: 0, max: 371676


Adjacency Table has 120 adjacencies
csipl-136
>>>exit
```

93138

Verify MPLS Interfaces

To open the Verify MPLS Interfaces window see [Table 17-3](#). The Verify MPLS Interfaces window (see [Figure 17-6](#)) displays the results of the **show mpls interfaces** command.

Figure 17-6 Verify MPLS Interfaces Window



The screenshot shows a window titled "GSR12416-10.76.82.136: show mpls interfaces". The window contains the following text:

```
IP Address: 10.76.82.136
WARNING: username not set


>>>show mpls interfaces
Interface          IP          Tunnel  Operational
Ethernet0         Yes (ldp)   No      Yes
SRP0/0            Yes (ldp)   No      Yes
csipl-136
>>>exit
```

At the bottom of the window, there is a "Close" button. The number "93141" is visible in the bottom right corner of the window frame.

Verify Label Distribution

To open the Verify Label Distribution window see [Table 17-3](#). The Verify Label Distribution window (see [Figure 17-7](#)) displays the results of the **show tag-switching tdp discovery** command.

Figure 17-7 Verify Label Distribution Window



```
GSR12416-10.76.82.136: show tag-switching tdp discovery
IP Address: 10.76.82.136
WARNING: username not set

>>>show tag-switching tdp discovery
Local TDP Identifier:
 60.60.60.1:0
Discovery Sources:
Interfaces:
  Ethernet0 (ldp): xmit
  SRP0/0 (ldp): xmit
Directed Hellos:
 60.60.60.1 -> 100.19.18.10 (ldp): active, xmit

csipl-136
>>>exit
```


Close

93143

Verify Label Bindings

To open the Verify Label Bindings window see [Table 17-3](#). The Verify Label Bindings window (see [Figure 17-8](#)) displays the results of the **show tag-switching tdp bindings** command.

Figure 17-8 Verify Label Bindings Window



```

GSR12416-10.76.82.136: show tag-switching tdp bindings
IP Address: 10.76.82.136
WARNING: username not set


>>>show tag-switching tdp bindings
tib entry: 0.0.0.0/0, rev 6
    local binding: tag: imp-null
tib entry: 10.76.82.128/27, rev 2
    local binding: tag: imp-null
tib entry: 60.60.60.1/32, rev 4
    local binding: tag: imp-null
tib entry: 64.0.0.0/8, rev 8
    local binding: tag: imp-null
tib entry: 70.70.0.0/16, rev 42
    local binding: tag: imp-null
tib entry: 172.138.0.0/16, rev 12
    local binding: tag: imp-null
csipl-136
>>>exit
  
```

93142

Verify Interface CEF Switching

To open the Verify Interface CEF Switching window see [Table 17-3](#). The Verify Interface CEF Switching window (see [Figure 17-9](#)) displays the results of the **show ip cef <interfaceName Slot/Port>** command.

Figure 17-9 Verify Interface CEF Switching Window



```

GSR12416-10.76.82.136: show ip cef Ethernet0
IP Address: 10.76.82.136
WARNING: username not set

>>>show ip cef Ethernet0
Prefix          Next Hop        Interface
0.0.0.0/0       attached        Ethernet0
10.51.20.205/32 10.51.20.205    Ethernet0
10.76.82.128/27 attached        Ethernet0
10.76.82.129/32 10.76.82.129    Ethernet0
10.76.82.135/32 10.76.82.135    Ethernet0
10.76.82.138/32 10.76.82.138    Ethernet0
10.76.82.139/32 10.76.82.139    Ethernet0
10.76.82.141/32 10.76.82.141    Ethernet0
10.76.82.142/32 10.76.82.142    Ethernet0
10.76.82.143/32 10.76.82.143    Ethernet0
10.76.82.152/32 10.76.82.152    Ethernet0
10.76.82.153/32 10.76.82.153    Ethernet0
10.76.82.155/32 10.76.82.155    Ethernet0
10.76.82.156/32 10.76.82.156    Ethernet0
10.76.82.162/32 10.76.82.162    Ethernet0
10.76.86.132/32 10.76.86.132    Ethernet0
10.77.6.202/32  10.77.6.202     Ethernet0
10.77.11.132/32 10.77.11.132    Ethernet0
  
```

93137



Fault Management

This chapter describes how to view appropriate fault information on the Cisco 12000/10720 Routers you are managing. The Cisco 12000/10720 Routers can be configured to send SNMP traps when various conditions are detected. This may be a fault, the correction/resolution of a previous condition or a status update. Traps are translated into Cisco EMF alarms and raised against the appropriate Cisco 12000/10720 Router Manager object. These alarms are cleared automatically (if the resolution can be clearly detected by Cisco 12000/10720 Router Manager) or manually.

This chapter contains the following information:

- [Cisco 12000/10720 Router Manager Alarms](#)
- [Cisco 12000/10720 Router Trap Support](#)
- [Heartbeat Polling](#)

Cisco 12000/10720 Router Manager Alarms

Cisco 12000/10720 Router Manager enables you to identify faults or alarms generated by Cisco 12000/10720 Routers. Within the Map Viewer application, you are notified of alarms on individual objects by the colored status icons next to each managed object. The following table details all status colors and their related severities.

Table 18-1 Monitored Attributes for a GRP Module

Color	Severity of Alarms
Red	Critical
Orange	Major
Yellow	Minor
Cyan	Warning
Green	No Alarms (Normal)
White	Informational

Alarms are propagated up the object hierarchy, and are reflected up to the highest level. For example, say a major (orange) alarm occurs on an interface. If you do not have the chassis map open, and if the interface text is not apparent, how would you know an alarm had occurred at that level? The answer is:

propagation. The interface alarm would be propagated up the hierarchy to site level. This means that whatever level you are working at, you will see that an alarm has occurred. You can follow the path to discover where the alarm exists.

**Note**

Cisco 12000/10720 Router Manager is complimented by the Event Manager application. Among other features, the Event Manager enables you to set thresholds for certain system parameters and to monitor any supported Cisco 12000/10720 Router Manager MIB variables. Refer to the *Cisco Element Management Framework User Guide* for further information.

Viewing Alarms

Alarms can be viewed using the Event Browser application that is part of the Cisco EMF.

Event Browser can be launched in two ways:

- Click the **Events** icon in the Launchpad to launch the Event Browser application. The Event Browser window appears.

Event Browser allows you to view all alarms on all objects. The Query Editor window appears automatically when you launch the Event Browser application. The Query Editor allows you to set up a query (or filter) that allows you to filter all the alarms available and display only the alarms matching the query criteria you selected.

When the event browser is launched against an object, by default, all the alarms against that object and its descendents are displayed in the event browser. For e.g., if the event browser is launched against a chassis, then by default it displays all the alarms against the chassis and the module and interfaces objects available in that chassis. Refer to the *Cisco Element Management Framework User Guide* for further details on using the Event Browser.

- To view a specific alarm on one object, open the Map Viewer application (**Viewer**), right-click the object that generated the alarm, then choose **Tools>Open Event Browser**. The selected object alarm and its child objects alarms are displayed. You can open the Query Editor from the Event Browser window to modify your criteria to include only the selected object. Refer to the *Cisco Element Management Framework User Guide* for detailed information on using the Query Editor.

**Note**

The maximum number of cleared alarms stored against an object is 300. When this value is reached, the cleared alarms are deleted until there are only 150 alarms left against the object.

Cisco 12000/10720 Router Trap Support

When a fault occurs on a managed object in the network, Cisco 12000/10720 Router Manager receives immediate notification, through a “trap” that is sent through the network. This trap manifests itself as an alarm in Cisco 12000/10720 Router Manager. A trap of any of the above category can be one of five severity types:

- Critical
- Major
- Warning

- Informational
- Normal

Chassis Alarms

Table 18-2 provides information on traps that result in alarms raised against the chassis object.

Table 18-2 Monitored Attributes for a GRP Module

Trap	Alarm Description	Severity	Clears
Cold start	Cold Start: Agent reinitializing; configuration may have changed.	Major	Cold start
RPR+ Switchover	RPR+ Cold Start: Agent reinitializing; configuration may have changed	Major	RPR+ Switchover
RPR Switchover	RPR Cold Start: Agent reinitializing; configuration may have changed	Major	RPR Switchover
Redundancy Framework (RF) Progression	RF Notification: RF state has changed. Active Unit: <slot-no> State: <RF-state>. Peer Unit: <slot-no> State: <RF-state>	Major	Redundancy Framework (RF) Progression
Warm start	Warm Start: Agent reinitializing; configuration is unaltered.	Major	Warm start
Authentication Failure	Authentication Failure	Major	Authentication Failure
Voltage Normal	Voltage higher Chassis, normal, <value> mV	Normal	Normal, Critical, Shutdown, Warning, NotPresent
Voltage Warning	Voltage higher Chassis, warning, <value> mV	Warning	Critical, Shutdown, Warning, NotPresent
Voltage Critical	Voltage higher Chassis, critical, <value> mV	Critical	Critical, Shutdown, Warning, NotPresent
Voltage Shutdown	Voltage higher Chassis, shutdown, <value> mV	Critical	Critical, Shutdown, Warning, NotPresent
Voltage Not Present	Voltage higher Chassis, notPresent, <value> mV	Informational	Critical, Shutdown, Warning, NotPresent
Temperature Normal	Slot <no>: Switch Fabric Card Hot Sensor, normal, <value> degree celsius	Normal	Normal, Critical, Shutdown, Warning, NotPresent
Temperature Warning	Slot <no>: Switch Fabric Card Hot Sensor, warning, <value> degree celsius	Warning	Critical, Shutdown, Warning, NotPresent
Temperature Critical	Slot <no>: Switch Fabric Card Hot Sensor, critical, <value> degree celsius	Critical	Critical, Shutdown, Warning, NotPresent
Temperature Shutdown	Slot <no>: Switch Fabric Card Hot Sensor, shutdown, <value> degree celsius	Critical	Critical, Shutdown, Warning, NotPresent
Temperature Not Present	Slot <no>: Switch Fabric Card Hot Sensor, notPresent, <value> degree celsius	Informational	Critical, Shutdown, Warning, NotPresent

Table 18-2 Monitored Attributes for a GRP Module (continued)

Trap	Alarm Description	Severity	Clears
Fan Normal	Fan Tray 1, normal	Normal	Normal, Critical, Shutdown, Warning, NotPresent
Fan Warning	Fan Tray 1, warning	Warning	Critical, Shutdown, Warning, NotPresent
Fan Critical	Fan Tray 1, critical	Critical	Critical, Shutdown, Warning, NotPresent
Fan Shutdown	Fan Tray 1, shutdown	Critical	Critical, Shutdown, Warning, NotPresent
Fan Not Present	Fan Tray 1, notPresent	Informational	Critical, Shutdown, Warning, NotPresent
Power Supply Normal	Power Supply 1, normal	Normal	Normal, Critical, Shutdown, Warning, NotPresent
Power Supply Warning	Power Supply 1, warning	Warning	Critical, Shutdown, Warning, NotPresent
Power Supply Critical	Power Supply 1, critical	Critical	Critical, Shutdown, Warning, NotPresent
Power Supply Shutdown	Power Supply 1, shutdown	Critical	Critical, Shutdown, Warning, NotPresent
Power Supply Not Present	Power Supply 1, notPresent	Informational	Critical, Shutdown, Warning, NotPresent
BGP Connection Established	BGP Connection Established with Peer <peer-IP-Address>, Connection is in <peer-state> State	Normal	BGP Connection Established, BGP Connection Broken
BGP Connection Broken	BGP Connection Broken with Peer <peer-IP-Address>, Connection is in <peer-state> State	Major	BGP Connection Broken
FlashDeviceChange	A Flash Device has been inserted or removed from the chassis	Informational	FlashDeviceChange



Note Temperature traps include the affected slot in the alarm description.

As can be seen from the table, Cisco EMF alarms may be cleared by other alarms. The general pattern is that an alarm clears alarms of the same or higher severity. All other alarms should be cleared manually.

Interface Alarms

Table 18-3 provides information on traps that result in alarms raised against interface objects.

Table 18-3 Alarms Raised Against Interface Objects

Trap	Alarm Description	Severity	Clears
Link down	Interface:<interface_name> Down,Operational Status:Down, Administrative Status:Down Reason:Administratively down	Major	Link down
Link up	Interface:<interface_name> Up, Operational Status:Up	Normal	Link up, link down
Flow Created	A New Flow has been generated for <rsvp-FlowIndex> from Link <interface index>	Normal	Flow Created, Flow Lost
Flow Lost	Flow Lost for <rsvp-FlowIndex> from Link <interface index>	Informational	Flow Lost
PVC Failed	Total <no_of_failed_PVCs> PVCs are not up on ATM Interface <interface Index>	Informational	PVC Failed

Table 18-4 Alarms Raised Against SRP Side Interface Objects for Wrap Status

Trap	Alarm Description	Severity	Clears
SRP Ring Wrapped	SRP Ring Wrapped	Major	SRP Ring Wrapped
SRP Ring Restored	SRP Ring Restored	Normal	SRP Ring Wrapped, SRP Ring Restored

Syslog Traps



Note

Care should be taken when using the Syslog alarm feature since there are multiple possible severity levels that can be activated which can result in large trap volumes. This can affect Cisco 12000/10720 Router Manager performance (for example, when opening an Event Browser) and hinder effective monitoring because of the high numbers of alarms that will be raised. It is advised that only the high severity traps are monitored by default, switching on others if more information is required.

Cisco IOS can be configured to send Syslog traps to a designated server. There are eight levels of Syslog information which are mapped into four categories of Cisco EMF alarm severity. Syslog specific data is inserted into the Message portion of the Cisco EMF alarm. In all cases, alarms are raised against the Chassis object. Table 18-5 summarizes the severity mapping between trap and alarm:

Table 18-5 Syslog to Cisco EMF Mappings

Trap	Alarm Description
Emergency	Critical
Alert	Critical
Critical	Critical
Error	Major
Warning	Minor
Notification	Minor
Informational	Informational
Debug	Informational

Syslog alarms have a Description in the Event Browser application in the following format:

“Asserted [<clogHistMsgText>] by facility [<clogHistFacility>], Message name [<clogHistMsgName>]”

Where:

clogHistMsgText is the message text

clogHistFacility is the facility name (where the message came from)

clogHistMsgName is the message name

An example Syslog Alarm Description is

“Asserted [Critical/high priority process ATM Periodic may not dismiss.] by facility [SCHED], Message name [EDISMSCRIT]”

Configuration Management Traps



Note

Care should be taken when using the Configuration Management alarm feature since there are possibilities which can result in large trap volumes. This can affect the performance of the Cisco 12000/10720 Router Manager (for example, when opening an Event Browser) and hinder effective monitoring because of the high numbers of alarms that will be raised.

When a change is made to the configuration of a Cisco 12000 Series Router, Cisco IOS can send a “configuration management event trap”. This trap is translated into a Cisco EMF alarm with the following description:

“Config Change, Command Source: <ccmHistoryEventCommandSource>, Config Source: <ccmHistoryEventConfigSource>, Config Destination: <ccmHistoryEventConfigDestination>”

Where:

- ccmHistoryEventCommandSource is the source of the command that instigated the event – either command line or snmp.
- ccmHistoryEventConfigSource is the configuration data source for the event.
- ccmHistoryEventConfigDestination is the configuration data destination for the event.

An example Configuration Management Event Alarm Description is:

“Config Change, Command Source: commandLine, Config Source: running, Config Destination: commandSource”.

This would be received when a <write memory> command was issued.

Alarms are raised against the Chassis object with Informational Severity.

Heartbeat Polling

Heartbeat polling begins automatically when you commission a chassis. The chassis and all objects within the chassis are polled every five minutes. There are two types of heartbeat polling: Connectivity Management and Operational Status Polling.

The Heartbeat Polling section covers the following areas:

- [Connectivity Management](#)
- [Operational Status Polling](#)
- [Disabling Heartbeat Polling](#)
- [Performance Logging](#)

Connectivity Management

Cisco 12000/10720 Router Manager polls the management interface on the Cisco 12000/10720 Router every 60 seconds to determine network connectivity. If management connectivity is lost, the chassis enters into a lost comms state and this state ripples down to all subchassis objects. A major lost comms alarm is raised against the chassis. The chassis continues to poll. If it detects re-establishment, it puts the chassis state back to the relevant state and this state ripples down to all subchassis objects as well. An alarm of Normal severity is then raised which clears the major lost comms alarm.

Operational Status Polling

Operational Status Polling—Occurs at module and interface levels. Each module and interface polls for its own operational status. For modules or interfaces, this is every 5 minutes. If a module or interface detects that its operational status is down, it enters into the Errored state and raises a Major alarm. In the Errored state the module or interface will continue to poll if the condition has been rectified. If it detects that the operational state has moved back to healthy then the object will transition into the Normal state and raise an alarm of Normal severity which will clear the previous Major alarm.

Disabling Heartbeat Polling

You can stop heartbeat polling on an individual interface by decommissioning the interface. You might want to do this if you have interfaces that are not yet connected or live. For example, when you commission a chassis, subchassis discovery is automatically initiated. If you have pre-deployed interfaces that are not yet live, these are discovered and put into an Errored state, after no connectivity is detected on them. An alarm is also be raised on the interface. To correct this situation, you need to decommission the inactive interface and clear the alarm manually.

Performance Logging

Heartbeat polling is unaffected if an object is in the performance logging state.



Change Management

This chapter describes how to manage the insertion and removal of line cards (ATM, Ethernet, POS, DS-3, SRP, Modular Ethernet) in Cisco 12000/10720 Routers being managed by the Cisco 12000/10720 Router Manager application.

This chapter contains the following information:

- [Inserting a Line Card](#)
- [Mismatched State](#)
- [Removing a Line Card](#)

Change management also deals with removal and insertion of other modules into a Cisco 12000/10720 Router. Removing or inserting modules have implications in Cisco 12000/10720 Router Manager and need to be handled effectively. Cisco 12000 Series Routers support the Online Insertion/Removal (OIR) feature for the following modules:

- GRPs (only for dual RPs)
- AC or DC power supply modules
- Fan trays
- Blower modules

Modules inserted into a chassis are discovered within one minute. When Cisco 12000/10720 Router Manager detects the presence of a module, the chassis enters subchassis discovery to determine the type of module that was inserted. When the new module is discovered, it is added to the appropriate Cisco 12000/10720 Router Manager views and automatically commissioned.

When you remove an existing module from a chassis, Cisco 12000/10720 Router Manager detects this by heartbeat polling. An informative alarm is raised against the chassis object. The chassis rediscovers itself and its child objects. The removed module is then placed in the lost comms state, which causes a major alarm to be raised against that module. When the module is re-inserted into the chassis, the chassis rediscovers itself and its child objects due to change in the hardware configuration. The re-inserted module is placed in the appropriate state and the previously raised major alarm is cleared.



Note

For detailed information on individual states, see [“Cisco 12000/10720 Router Manager Object States”](#) section on page 2-14.


Inserting a Line Card

When a line card is inserted into a chassis being managed by Cisco 12000/10720 Router Manager, then the EMS detects that a line card has been inserted through the chassis heartbeat polling (which occurs every minute). Once the EMS detects that the line card is inserted, an informative alarm is raised against the respective chassis object in Cisco 12000/10720 Router Manager with a description `The chassis configuration has changed`. After this the chassis rediscovers itself and all its child objects. After the chassis has been rediscovered, the line card and interface objects for the newly inserted line card with its associated graphic will be deployed and commissioned against the appropriate slots. It is placed in the appropriate state in the device in both the componentManaged view and the Physical view. The OSI icons for line cards and interfaces discovered after insertion and in normal state are displayed below.

Figure 19-1 Line Card in Normal State



Figure 19-2 Interface in Normal State



Mismatched State

The mismatched state occurs when a mismatch is found between the hardware and what is deployed in Cisco 12000/10720 Router Manager. The mismatched state appears if you insert an incorrect module that does not correspond with the module type that has been pre-deployed in Cisco 12000/10720 Router Manager, or, if the pre-deployment for the new module is incorrect. For example: you are expecting an ATM OC-3 line card, so you pre-deploy and pre-configure Cisco 12000/10720 Router Manager to prepare for that type of line card. Now, when the line card becomes available and is placed into the chassis, it is not an ATM OC-3 line card, but a POS OC-3 line card. What happens? Once the Cisco 12000/10720 Router Manager detects the new line card, it finds a mismatch. The line card gets placed into the mismatch state and a major alarm is raised against the line card.

To rectify a mismatch problem, first you must assess the source of the problem. If the operator was at fault and pre-deployed an incorrect module, the operator should decommission and delete the pre-deployed module and re-deploy the correct module. If the engineer is at fault and inserted the wrong type of module into the chassis, then the module should be removed. When you remove a module, Cisco 12000/10720 Router Manager moves that module into a lost comms state. When the correct module is re-inserted, Cisco 12000/10720 Router Manager finds the new module and downloads the correct pre-deployment and pre-configuration information, then places the module into a normal state.

Two example scenarios during which a line card can be moved to mismatched state are described as follows:

Example 19-1 Scenario 1

Scenario 1—The mismatched state appears if you insert an incorrect line card that does not correspond with the line card type that has been pre-deployed and managed in Cisco 12000/10720 Router Manager.

This can occur during an Online Insertion removal process. For example, consider that a chassis has an 8 port fast Ethernet line card at Slot-1 and its being managed. If the 8 port fast Ethernet line card is removed from the device and a 3 port gigabit Ethernet line card is inserted, now the Cisco 12000/10720 Router Manager will force a rediscovery on the respective chassis. After the chassis rediscovery is completed the previously deployed and managed 8 port fast Ethernet line card object at Slot-1 will be moved to MisMatched State, with a major alarm raised against the line card object with the description `Deployed module does not match actual module`, because the newly inserted line card at slot-1 (ie.3 port gigabit Ethernet) is of different type against the originally pre-deployed and managed 8 port fast Ethernet line card. Similarly all the interface objects of the mismatched line card object will also be moved to MisMatched state.

The mismatched line card object and all its interface object icons in the viewer are hashed and also will be associated with an OSI Icon as displayed below, under the Component Managed and Physical (object's GIFs) views.

Figure 19-3 Line Card in Mismatched State




Figure 19-4 Interface in Normal State



To rectify the line card mismatch problem caused due to this scenario, either the incorrect line card can be removed from the device and the correct type of line card can be inserted at Slot-1 or if the newly inserted 3 port gigabit Ethernet line card needs to be retained in the device, then the mismatched line card object need to be decommissioned and deleted, then need to re-commission the chassis object. This will result in discovering the 3 port gigabit Ethernet line card and all its interface objects in appropriate states.

Example 19-2 Scenario 2

Scenario 2—If a line card have been pre-deployed incorrectly in the Cisco 12000/10720 Router Manager and commissioned.

This can occur if an incorrect line card type is pre-deployed and commissioned. For example, if an 8 port fast Ethernet line card is pre-deployed against slot-0, but the slot-0 of the device actually has a 3 port gigabit Ethernet line card inserted, then commissioning the pre-deployed line card will result in a mismatched state.

To rectify the line card mismatch problem caused due to the above scenario, decommission and delete the mismatched line card object and redeploy the correct type of line card object.

Removing a Line Card

When you remove an existing line card from a chassis, Cisco 12000/10720 Router Manager detects that the line card has been removed by heartbeat polling (which occurs every minute). Once Cisco 12000/10720 Router Manager detects that the line card is removed, an informative alarm is raised against the chassis object in Cisco 12000/10720 Router Manager with a description `The chassis configuration has changed`. The chassis rediscovers itself and its child objects. After this process, the removed line card is placed in the lost comms state, which causes a major alarm to be raised against that line card. This situation is rectified when the line card is re-inserted in the chassis. When the line card is re-inserted into the chassis, the chassis rediscovers itself and its child objects due to change in the hardware configuration. The re-inserted line card is placed in the appropriate state and the previously raised major alarm is cleared.

After the chassis has been rediscovered the removed line card object will be moved to lostcomms state with a major alarm raised against the line card object with the description `Connection to the device lost`. Similarly all the interface objects of the removed line card object will also be moved to lostcomms state.

The removed line card object and all its interface objects are hashed and display an OSI Icon as displayed below, under the Component Managed and Physical (object's GIFs) views.

Figure 19-5 Line Card in Lostcomms State




Figure 19-6 Interface in Lostcomms State



This situation is rectified when the removed line card is re-inserted into the chassis. When the line card is re-inserted into the chassis, the chassis rediscovers itself and its child objects due to change in the hardware configuration. The re-inserted line card and its child objects will be placed in the appropriate state and the previously raised major alarm is cleared.



Performance Management and Historical Data

An important component of efficient network management is the ability to collect and analyze performance information in a large network of many devices. This performance information can assist you to pro-actively manage your network elements, and troubleshoot network problems.

This chapter describes the Cisco EMF Performance Manager application that is used in conjunction with the Cisco 12000/10720 Router Manager application to view performance statistics from the Cisco 12000/10720 Routers managed on your network.

Performance Manager collects historical performance data for interfaces and GRPs. You can only view performance information in Performance Manager if performance logging is switched on. Performance Manager is a powerful, flexible tool that enables you to view general and performance specific attributes in one application and in a variety of formats (for example, graphs and tables). You define the attributes or parameters, choose the objects you want to view, select the date and time of the view, and set the summary interval.

Performance logging can be switched on/off globally (that is, for all modules and interfaces below these modules) from the Chassis Configuration window. See [“Starting Global Performance Logging” section on page 4-9](#) or [“Stopping Global Performance Logging” section on page 4-10](#) for further details.

Module performance logging can be switched on/off on a per module basis from the Module Performance window. Switching performance logging on for a selected module also switched performance logging on for the interfaces and VLAN sub-interfaces on the module. See [“Starting or Stopping Performance Logging” section on page 5-10](#) for further details.

VLAN sub-interfaces or interface performance logging can be switched on/off on a per interface basis from the Generic Interface Performance window. See [“Starting Performance Logging for a Selected Interface” section on page 10-5](#) for further details.

Performance Manager collects data for all different technologies on an interface. For example, if you want to view Performance Manager data for an ATM interface, performance attributes are listed for Generic and SONET technologies, because both apply to ATM interfaces.

Performance information in Cisco 12000/10720 Router Manager application can be viewed in two ways:

1. Using Performance Manager to display historical data as well as current data in the form of a line chart, bar chart, or table.
2. Using the Interface Performance windows option to view current data in a raw numerical format. See [Chapter 10, “Interface Performance,”](#) for further information.

This chapter describes the Performance Manager application and the various historical performance statistics available on the various objects within the Cisco 12000/10720 Router Manager.

**Note**

Further information on Performance Manager is available in the *Cisco Element Management Framework User Guide*, when required.

Performance Information Available Using Cisco 12000/10720 Router Manager

Cisco 12000/10720 Router Manager collects a variety of performance information. The performance information collected can be viewed “real time” (as it happens), on a number of Interface Performance windows (see [Chapter 10, “Interface Performance,”](#)), or as historical information using Performance Manager.

[Table 20-1](#) summarizes the performance attributes that can be monitored for a GRP module and then viewed using the Performance Manager application.

Table 20-1 Monitored Attributes for a GRP Module

Monitored Attribute	Description
CPU% performance	Displays the percentage of the CPU performance for the selected module.
CPU performance averaged over 1 minutes	Displays the percentage of the CPU utilized for the selected module, averaged over a one minute period.
CPU performance averaged over 5 minute	Displays the percentage of the CPU utilized for the selected module, averaged over a five minute period.

Viewing the Performance Manager Window

To view the Performance Manager window, proceed as follows:

- Step 1** Right click (on a relevant object icon in the Map Viewer window or from an object pick list) and select the **Tools>Performance Manager...** option. See [Table 20-2 on page 20-2](#) for information on which objects allow you to launch the Performance Manager window. The Performance Manager window appears, with the Line Chart tab displayed:

Table 20-2 Accessing Performance Manager


Objects (that can be selected) to Open the Performance Manager Window				Menu Options to Select to Open Window
Site	Chassis	Module	Interface	
No	Yes	Yes	Yes	Tools>Performance Manager

**Note**

The Performance Manager window cannot be opened when multiple objects are selected (the menu options to open the Cisco 12000/10720 Router Manager windows are grayed out). Available menu options can be launched from a site object containing the required objects, when required.

The Performance Manager window appears (see [Figure 20-1](#)).

Figure 20-1 Performance Manager Window



The Performance Manager window allows you to:

- Identify all Monitored Attributes on a selected managed object. See [“Performance Information Available Using Cisco 12000/10720 Router Manager”](#) section on page 20-2 for details.
- Identify all time periods configured for sampling each monitored attribute.
- Identify all summary methods configured for selected monitored attributes and selected summary periods.
- View historical performance data over a requested period of time (as a Line Chart, Table Display).

- Print performance data to a printer.
- Save/export performance data to a file, for subsequent analysis and processing, for example, using a spreadsheet application.

Step 2 Proceed to the [“Viewing Performance Statistics” section on page 20-4](#) for details on viewing performance statistics.

**Note**

Cisco EMF provides a command line utility (history Admin) that allows mass export of performance history data. Refer to the *Cisco Element Management Framework User Guide* for further information.

Viewing Performance Statistics

To view performance statistics, follow these steps:

Step 1 Open Performance Manager. See [“Viewing the Performance Manager Window” section on page 20-2](#) for further details.

Step 2 Choose the attribute you wish to monitor in the Monitored Attributes panel (for details on this panel, see [“Performance Manager Window—Detailed Description” section on page 20-7](#)). You can choose multiple attributes in a list by holding down the Shift key and then selecting the first and last attributes in the list. You can choose multiple individual attributes by holding down the Ctrl key and clicking on individual items.

**Note**

Only the first selected attribute is shown in the line chart or bar chart. The table display tab shows all selected attributes.

Step 3 Set the start Date and Time in the Time Period area. Enter the date on which you want to begin viewing performance data in the Start Date entry boxes. The format must be mm/dd/yyyy. Enter the time you want the performance data to start on in the Start Time data entry boxes. Set a start time and an end time using the 24 hour clock notation. The times are inclusive.

Step 4 Set the End date. You have two options when setting the end date. Enter the date on which you want to stop viewing performance data in the End Date entry boxes. The format must be mm/dd/yyyy. Or, check the Now check box to view the data from the selected start date to the current time. By selecting this option, you do not have to update the end date and time fields.

Step 5 Set the end time in the Time Period area. You have two options when setting the end time. Enter the end time at which you wish to stop viewing performance data in the End Time entry fields. The format must be mm/dd/yyyy. Or, check the Now check box to view the data from the selected start date to the current time. By selecting this option, you do not have to update the end date and time fields.

Step 6 Choose the summary interval from the drop down list in the Summary area. The summary interval is the period of time over which the rule is applied. This varies according to the attribute selected. You can choose the Raw option, which displays performance data in its most detailed format, not summarized.

**Note**

The performance information corresponds to the attributes’ raw values. If you choose a summary period, the information is displayed according to the summary rule. No summary period is associated with raw data.



Note When you choose Raw, the bar chart view is sometimes not available, and the Summary Rule option is grayed out.

Step 7 Click **Refresh Screen**. The Refresh Screen button is grayed out when not available. The Refresh Screen button is available for selection when Now is selected, or when any criteria has changed and you have moved the cursor away from the changed value by clicking the **Tab** key or by using the mouse.

The performance information appears as a line chart by default. You can view performance information as a Line Chart or as a Table Display by selecting the corresponding tab.

The performance information corresponds to the attributes' value returned during the raw sampling period. When a summary period other than raw is selected, the information appears according to the summary rule.



Note In some circumstances (possibly due to Cisco 12000/10720 Router Manager being shut down or a heavy network load), polls can be missed. Performance Manager deals with this problem by displaying missed polls in red. The missed poll value is replaced by the last valid value collected. Performance Manager graphs and charts also indicate when an attribute started and stopped being polled due to history storage criteria being added, edited or removed. Start and stop polling events are shown in charts and tables. The start polling events point is shown in green, and the stop polling events point is shown in red.

A polling events key is displayed for selection.

Viewing a Chart

You can zoom in, zoom out and move around the displayed charts using the key presses detailed in [Table 20-3](#). You must first select the chart before using the key presses detailed in [Table 20-3](#).

Table 20-3 Table of Key Presses

Press	Action
Right arrow key	Moves the chart one unit to the right
Left arrow key	Moves the chart one unit to the left
Up arrow key	Moves the chart to the bottom
Down arrow key	Moves the chart to the top
Shift and Z key	Zooms in on the chart's x axis
Shift and U key	Zooms out on the chart's x axis
Z key	Zooms in on the chart's y axis
U key	Zooms out on the chart's y axis
Shift and F key	Fits all information on the x axis in window
F key	Fits all information on the y axis in window

Printing a Performance File

You can print performance statistics from the Performance Manager, either as a chart or as a table. A chart prints out the information which can be seen in the window, and a table prints out all of the performance statistics in a plain text format.

The output is printed by the default printer set up on your network.

-
- Step 1 Open the Performance Manager and select the desired performance statistics.
 - Step 2 From the **File** menu, select **Print**.
 - Step 3 Choose **As Chart** or **As Table**.
-

Saving Performance Data to a File

Performance data is stored in the Cisco EMF database. It is not exported to ASCII file by default. To save performance data, follow these steps:

-
- Step 1 Open the Performance Manager and view the performance statistics you want to save.
 - Step 2 Choose **File > Export to File** or click **Save As** on the Toolbar.
 - Step 3 The File Chooser window appears. The left hand panel displays the directories and the right hand panel displays the files. Use the scroll bars to locate the desired file. Click **Filter** to expand the list of options.
 - Step 4 Choose the file. The full path name of the selected file is displayed in the File Filter box, as well as the Choice box.



Note You can save the data to a new location or to a new file. Type in the new names as required in the Choice boxes.

- Step 5 Click **Apply** to save the file or **Cancel** to return to the Performance Manager window.
-

Archiving

Collected data is archived each day. The applied file name is generated automatically using the format mm-dd-yyyy.log. When entries are archived, they are purged from the database. By default, only raw data is archived.



Note If more than one purge is carried out in a day, the original log file is overwritten and the information stored is lost. After a purge, only the information in the current sample period is available for display.

**Note**

Cisco EMF contains a utility called historyAdmin. HistoryAdmin enables you to selectively export performance data for groups in an automated manner. Refer to the *Cisco Element Management Framework User Guide* for further details.

Exporting A Performance File

Performance data can be exported for use in other applications. To export performance data, follow these steps:

- Step 1** Open the Performance Manager and view the performance statistics you want to export.
- Step 2** Choose **File > Export to File** or click **Save As** on the Toolbar.
- Step 3** The File Chooser window appears. The left hand panel displays the directories and the right hand panel displays the files. Use the scroll bars to locate the desired file. Click **Filter** to expand the list of options.
- Step 4** Choose the file. The full path name of the selected file is displayed in the File Filter box, as well as the Choice box.

**Note**

You can save the data to a new location or to a new file. Type in the new names as required in the Choice boxes.

- Step 5** Click **Apply** to save the file or **Cancel** to return to the Performance Manager window.

Performance Manager Window—Detailed Description

The Performance Manager window displays three areas: Monitored Attributes, Time Period, and Summary. The Performance Manager window also displays three tabs: Line Chart, and Table Display.

Monitored Attributes

The monitored attributes list at the left of the window allows you to select the specific attribute you wish to view performance information for. The fields in this list change, depending upon the type of interface that you launched Performance Manager from. For example, if your selected interface is was an ATM line card, you will be able to select all the performance fields that can be found on the following performance windows: SONET Performance, and Generic Performance. Both of these technologies apply to ATM line cards, therefore all performance information for both technologies is listed in the Performance Manager. This list is extensive.

Time Period

The Time Period area contains two sub-areas: Start and End.

Start

The Start area displays two fields: Date and Time.

Date—Enter the date on which you want to begin viewing performance data. The format must be mm/dd/yyyy.

Time—Enter the time you want the performance data to start. Set a Start time using the 24 hour clock notation.

End

The End area displays three fields: Date, Time and Now.

Date—Enter the date on which you want to stop viewing performance data. The format must be mm/dd/yyyy.

Time—Enter the time you want the performance data to stop. Set an End time using the 24 hour clock notation.

Now—Choose the Now check box to view the data from the selected start date to the current time. By selecting this option, you do not have to update the end date and time fields.

Summary

The Summary area displays two drop down boxes: Interval and Rule.

Interval—Choose the summary interval from the drop down list in the Summary area. The summary interval is the period of time over which the Rule is applied. This varies according to the attribute selected. You can choose the Raw option, which displays performance data in its most detailed format, not summarized.



Note

The performance information corresponds to the attributes' raw values. If you choose a summary period, the information is displayed according to the summary rule. No summary period is associated with raw data. When you choose Raw, the bar chart view is sometimes not available, and the Summary Rule option is grayed out.

Rule—From the drop down list, choose the **Rule** to be used. This gives you the option to view data summarized according to various rules as defined by the history storage criteria as follows:

- **Total**—totals all values gathered in the summary period
- **Average**—takes the average of all values gathered in the summary period
- **Trough**—presents the lowest value received over the summary period
- **Peak**—presents the highest value received over the summary period

- LogicalOR—displays either 1 or 0. This is typically used for status flags. Some attributes may have only two potential values (such as, true or false; yes or no; 1 or 0). When summaries are generated from values such as these, and the logicalOR rule is used, the summarized value is 1 if any value in the summary interval is 1. If all values in the summary interval are 0, then the summarized value is 0.



Note The **Rule** option is not available when the option to view raw data is chosen.

Refresh

Refresh—The **Refresh** button is blue when it is available. It is grayed out when not available. The **Refresh** button is available for selection when **Now** is selected, or when any criteria has changed and you have moved the cursor away from the changed value by pressing the **Tab** key or by using the mouse.

Line Chart Tab

The Line Chart tab displays the retrieved data in a graphical format. The X-axis displays the time at which the polling was done, and the Y-axis displays the value retrieved or the value when the equipment did not respond properly.

Further information regarding the element, units, and missed polls is provided, using the appropriate color coding displayed at the top of the chart. Blue represents the values retrieved and red identifies any polled values missed.

Table Display Tab

The Table tab displays the data retrieved in a tabular format. The first column shows the time of polling, and the second column shows the retrieved values. Blue represents the values retrieved and red identifies any polled values missed.



Troubleshooting and FAQs

The Troubleshooting and FAQs section details answers to some commonly asked questions or problems.



Note

Cisco 12000/10720 Router Manager also provides a debugging support tools and utilities package to assist in data gathering and problem analysis. Refer to the *Cisco 12000/10720 v3.1.1 Installation and Configuration Guide* for more information.

[Table 21-1](#) lists the questions and shows where you can find information.

Table 21-1 Commonly Asked Questions

Administration

[What Version is the Software?](#), page 21-1

[What Dialogs Use the IOS CLI Instead of SNMP?](#), page 21-2

Configuration

[Verifying SNMP, Log, and Trap Settings](#), page 21-3

[BGP Configuration](#), page 21-5

[ATM Sub-Interface Configuration](#), page 21-5

[ATM IP Configuration GUI Display ERROR Settings](#), page 21-5

[Viewing ATM Physical Port Configurations?](#), page 21-6

Administration

What Version is the Software?

Q. How can I verify the software version?

A. Use `<CEMF_ROOT>/cemf install -show`. This will show the versions of all the installed software.

What Dialogs Use the IOS CLI Instead of SNMP?

- Q. What dialogs are retrieving or configuring information using the IOS CLI instead of SNMP?
- A. In Cisco 12000/10720 v3.1.1 Router Manager some dialogs use only the IOS CLI, some use only SNMP, and some use both IOS CLI and SNMP. [Table 21-2](#), [Table 21-3](#), and [Table 21-4](#) detail each instance.

When a dialog uses the IOS CLI, the IOS password must be set up. See [Entering or Changing IOS CLI Username and Passwords](#), page 4-5.

Table 21-2 Dialogs launched from Chassis objects

Dialog uses IOS CLI (Need to set the Management Passwords on the EM)	Dialog uses SNMP	Dialog uses IOS CLI and SNMP (Need to set the Management Passwords on the EM)
Configuration Editor	Chassis Configuration	SNMP Management
POS APS Status	Chassis Management Information	ATM Connection Upload
RPR Configuration	Chassis Inventory	BGP Configuration
RPR Status	Chassis Status	BGP Status
BGP Address-Family Synchronization	System Log	OSPF Status
BGP Address-Family Configuration	Command History	
BGP Address-Family Status	TCP Status	
OSPF Configuration	UDP Status	
MPLS Forwarding Information	IP Routing Status	
MPLS Trap Configuration Dialog	MPLS Interface Status	
VRF Deployment	MPLS Tunnel Information	
VRF Configuration	MPLS LDP Entity Status	
	MPLS LDP Peer Status	
	MPLS LDP Hello Adjacencies	
	VRF Status	
	VPN Status	
	Interface VRF Status	
	VRF Object Status	

Table 21-3 Dialogs launched from Module objects

Dialog uses IOS CLI (Need to set the Management Passwords on the EM)	Dialog uses SNMP	Dialog uses IOS CLI and SNMP (Need to set the Management Passwords on the EM)
WRED-Rx Configuration	Module Performance	
	Module Inventory	
	Module Status	

Table 21-4 Dialogs launched from Interface objects

Dialog uses IOS CLI (Need to set the Management Passwords on the EM)	Dialog uses SNMP	Dialog uses IOS CLI and SNMP (Need to set the Management Passwords on the EM)
ATM Interface Configuration	Generic Interface Configuration	SRP Interface Configuration
ATM Interface Faults	Generic Interface Performance	SRP Interface Status
ATM Interface Status	Generic Interface Status	SRP Side Interface Configuration
IP Interface Configuration	SONET Interface Status	IPS Status
Ethernet Interface Configuration	SONET Interface Performance	
POS Interface Configuration	DS3 Interface Status	
POS APS Configuration	DS3 Interface performance	
CAR Policy Apply	Ethernet Interface Performance	
CAR Policy Status	MPLS Interface Performance	
WRED-Tx Configuration	MPLS Interface Information	
ATM PVC Connection Deployment	ATM PVC Status	
ATM SVC Connection Deployment	SRP Interface Topology Map	
ATM PVC Configuration	SRP Side Performance	
ATM SVC Configuration	SRP Interface Performance	
Deployment of Vlan-Domains, VLANs and sub-interfaces	VLAN Synchronization	
VLAN Performance		
VRF Association		

Configuration

Verifying SNMP, Log, and Trap Settings

- Q. Three GSRs are configured and commissioned. I believe the Cisco 12000/10720 Router Manager is talking with the GSRs since the GUI shows the number of alarms that each GSR has.

How do I verify that SNMP, TRAP, and LOGGING are configured correctly? Are there any specific CLI commands I can use to verify?

- A. In Cisco EMF, when a condition (fault) occurs on a managed object in the network, the system is notified immediately. This notification is shown as an event and can be viewed with the Event Browser. The Event Browser is opened from the Launchpad or from a selected object.

For details on Event Browser, refer to the Cisco EMF Release 3.2 Service Pack 4 User Guide, http://www.cisco.com/en/US/products/sw/netmgmtsw/ps829/products_user_guide_chapter09186a00800ffd09.html

To verify that SNMP and Traps are configured to be sent to the Cisco 12000/10720 Router Manager, in the CLI enter:

show running-config | begin snmp

This command will list all the SNMP configurations for the router. You should see the following statement defining the SNMP read community strings for the router. When the following statement is configured in the router, the SNMP agent is up and running:

snmp-server community public RO



Note You should also define the SNMP write community string. Cisco IOS only requires the read community string defined in order to have the SNMP agent running in the router.

Traps and trap recipients can be configured from the Cisco 12000/10720 Router Manager.

Right click on the chassis object and choose **Configuration > SNMP Management**. In the SNMP Management window, click **Enable** to allow trap generation. You will get a report message with the details on the IOS CLI commands that were executed.

Once you have enabled traps, you will see the following trap entries. In the CLI, enter **show running-config | begin snmp** command in IOS to view the following output:

```
snmp-server enable traps snmp authentication linkdown linkup coldstart warmstart
snmp-server enable traps atm subif
snmp-server enable traps srp
snmp-server enable traps hsrp
snmp-server enable traps config
snmp-server enable traps entity
snmp-server enable traps envmon
snmp-server enable traps syslog
snmp-server enable traps fru-ctrl
snmp-server enable traps bgp
snmp-server enable traps pim neighbor-change rp-mapping-change
invalid-pim-messagesnmp-server enable traps msdp
snmp-server enable traps frame-relay
snmp-server enable traps frame-relay subif
snmp-server enable traps rtr
snmp-server enable traps mpls ldp
snmp-server enable traps mpls traffic-eng
snmp-server enable traps mpls vpn
```



Note You should see an entry for trap recipient (like the Cisco 12000/10720 Router Manager server) similar to:

```
snmp-server host 172.29.139.6 version 2c public
```

You should see an entry for enabling syslog messages to be sent as SNMP traps:

```
snmp-server enable traps syslog
```

In order to verify that logging (syslog) is configured in IOS, execute the following commands:

show running configuration | include logging

You will see the following entries related to the Syslog configuration:

```
logging history size 10
logging history debugging
logging trap debugging
show logging history
```

This provides summary information on the logging facilities, the number of messages sent/dropped, etc.

Syslog can be configured from the Cisco 12000/10720 Router Manager. Right click on the chassis object and select the **Fault > Syslog Messages** option. You can configure the following Syslog options:

- Maximum Table Entries—Displays the upper limit on the number of entries that the area can contain.
- Minimum SysLog Severity—Any message with a severity less than this one will be ignored by the agent. This field can be set to emergency, alert, critical, error, warning, notice, info, or debug.
- Notifications Enabled—Displays whether Syslog SNMP notifications are enabled or not enabled.

BGP Configuration

- Q. The GSR is configured for BGP but the BGP Configuration GUI displays ERROR on most of the settings. The GSRs
Decommissioned then commissioned GSRs again. Settings are seen on BGP Configuration GUI.
- A. Make sure you have IOS Login and Enable passwords configured in the EMS. Right click on the chassis object and choose **Configuration > Management Information**. You configure the passwords on the IOS/Command Line Security tab.

ATM Sub-Interface Configuration

- Q. Where do I find ATM sub-interface configuration? The ATM Interface Configuration GUI gives no such information.
- A. VCLs, SVCs, and VLANs are only shown under the Component Managed View not the Physical View. In order to invoke the ATM VCL Configuration window, go to the Component Managed View, then right-click on a selected interface, then choose **Cisco 12000/10720 Manager > Configuration > ATM > VCL Configuration**.

ATM IP Configuration GUI Display ERROR Settings

- Q. Though we have the ATM IP settings for an ATM port on the ATM IP Configuration GUI, it displays ERROR for all settings.
- A. Make sure you have IOS Login and Enable passwords configured in the Cisco 12000/10720 Router Manager. Right click on the chassis object and choose **Configuration > Management Information**. Choose the IOS/Command Line Security tab.

Viewing ATM Physical Port Configurations?

- Q. How do I view the ATM physical port configurations? It looks like ATM Configuration GUIs are for configurations only.
- A. To view what is configured in the ATM physical port, use all the configuration windows provided by the Cisco 12000/10720 Router Manager. For IP (Layer3) information use the IP Configuration Window. For Interface Status: Use the Interface Configuration window, etc.

Configuration windows are technology-specific. For example, an ATM interface supports three configurable technologies: Generic, ATM, and IP. Therefore, if you want to view or modify the configuration of an ATM interface you might need to view three windows as follows:

- Generic Interface Configuration window
- ATM Interface Configuration window
- IP Interface Configuration window

See

http://www.cisco.com/en/US/products/sw/netmgts/ps156/products_user_guide_chapter09186a008017824a.html for more details.



SONET/SDH Conversion Chart

The term Synchronous Optical Network (SONET) is used instead of Synchronous Digital Hierarchy (SDH) throughout this Guide. However, these two terms are somewhat interchangeable. The Cisco 12000/10720 Router Manager application handles both SDH and SONET in the same manner. The Cisco 12000 Series Routers support both SDH and SONET.

SONET was defined by the American National Standards Institution (ANSI) and is used in North America.

SDH was defined by the European Telecommunications Standards Institute (ETSI) and is now used everywhere outside of North America and Japan. SDH was standardized by the International Telecommunications Union (ITU).

[Table A-1](#) compares SONET and SDH speeds.

Table A-1 SONET and SDH Speeds

SONET	SDH
OC-3	STM-1
OC-12	STM-4
OC-48	STM-16
OC-192	STM-64



GUI Synchronization Details

GUIs that Synchronize with the Device when Launched

- MPLS Interface Status
- MPLS Interface Performance
- MPLS Interface Information
- MPLS Forwarding Information
- MPLS Tunnel Information
- MPLS Trap Configuration
- MPLS LDP Entity Status
- MPLS LDP Hello Adjacencies
- MPLS LDP Peer Status
- VRF Status
- Interface VRF Status
- VRF Object Status
- VPN Status
- BGP Configuration
- BGP Status
- BGP Address-Family Configuration
- BGP Address-Family Status
- BGP Address-Family Synchronization (After the first Synchronization)
- OSPF Configuration
- OSPF Status
- TCP Status
- UDP Status
- IP Routing Status

GUIs that do not Synchronize with the Device when Launched


- VRF Configuration
- VRF Association
- COSQGroup Configuration
- WRED Tx Configuration
- ToFab Configuration
- WRED Rx Configuration
- CAR Policy Configuration
- Access List Configuration
- CAR Policy Apply
- CAR Policy Status



Investigating LSP Black Holes Using Cisco 12000 Series Router Manager

Network Diagram

Figure C-1 Example Network Diagram



93226

Setup

On a U10 running the Solaris 8 operating system, the following was installed:

- Cisco EMF 3.2 with required patches
- Cisco 12000/10720 Router Manager

A Cisco 12000/10720 Router Manager chassis was deployed with the IP address of the P router as shown in [Figure C-1](#). The object was commissioned to discover all interfaces. The links shown in [Figure C-1](#) comprise of the following technologies:

- CE1—PE1: Fast Ethernet
- PE1—P :Gigabit Ethernet

- P—PE2 :Gigabit Ethernet
- PE2—CE2 : POS

Problem

The problem is that the user is unable to ping from CE1 to CE2 (192.168.1.196). The reason for this is because we have manually created an LSP Blackhole between the P router, which in this case is the GSR, and PE2. This has been manually configured in the running-config for PE2 by specifying a loopback address for PE2 to be:


- interface Loopback0
 - ip address 10.5.5.5 255.255.255.0
 - no ip directed-broadcast

Analysis of Problem

The LSP Black Hole can be easily displayed when you select the P router, and launch the MPLS Forwarding Information window. This can be found on the pull-right menu of the chassis, under **Fault> MPLS> MPLS Forwarding Information**.

As can be seen from the dialog, there is no out-going label for 10.5.5.5. When the packet leaves PE1 it carries two labels, the BGP next hop label generated by the P router (12307) and the VPN label generated by PE2.

Figure C-2 Example MPLS Forwarding Information Window



The entry on the P router shows untagged, so label-switched packets for this destination will be sent out without any labels. Since the VPN label was lost, it will never be received by PE2, and PE2 will not have the correct information to forward the packet to the proper VPN destination.

This information is the same as that displayed when the following Cisco IOS command is executed:
`show mpls forwarding-table`

The output you see is as shown in [Table C-1](#):

Table C-1 Example Output


Local	Outgoing	Prefix	Bytes Tag	Outgoing	Next Hop
tag	tag or VC	or Tunnel Id	Switched	Interface	
12307	Untagged	10.5.5.5/32	365	Gi1/0	10.8.8.5

Solution

There are several solutions to this problem, and the easiest is to change the sub-net mask for the loopback address on PE2 to 255.255.255.255, from 255.255.255.0.

When you do this, and refresh the MPLS Forwarding Information window, or wait for it to manually update, you now see:

Figure C-3 Example MPLS Forwarding Information Window



93224

This shows that the out-going label is now a pop tag, and hence the packets are no longer sent out untagged. This means that the top label for the BGP next hop will be popped as the packets traverse the router, but the packets will still have the second VPN label.

And more importantly, you can ping from CE1 to CE2.

If you re-run the `show mpls forwarding-table 10.5.5.5` command, you will see results similar to [Table C-2](#):

Table C-2 Example Output

tag	tag or VC	or Tunnel Id	Switched	Interface
12306	Pop tag	10.2.2.2/32	23675	Gi4/1 10.6.6.2
12307	Pop tag	10.5.5.5/32	365	Gi1/0 10.8.8.5



Note

See http://www.cisco.com/warp/customer/105/troubleshoot_mpls_vpn.html for background information.

Running Configs

CE1

```

!
version 12.0
no service pad
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
no service single-slot-reload-enable
!
hostname cl-7505-1
!
boot system flash flash:cl-7505-1-configNewTest
redundancy
no keepalive-enable
no logging buffered
no logging console
enable password atlantech
!
username lab password 0 amaf
username mozart password 0 amaf
ip subnet-zero
ip cef
no ip domain-lookup
no mpls traffic-eng auto-bw timers frequency 0
file prompt noisy
!
!
!
!
interface Serial2/0/0
 no ip address
 no ip directed-broadcast
!

```

```

interface Serial2/0/1
  no ip address
  no ip directed-broadcast
  shutdown
!
interface Serial2/0/2
  no ip address
  no ip directed-broadcast
  shutdown
!
interface Serial2/0/3
  no ip address
  no ip directed-broadcast
  shutdown
!
interface FastEthernet3/1/0
  ip address 10.1.1.1 255.255.255.0
  no ip directed-broadcast
!
ip classless
ip route 0.0.0.0 0.0.0.0 10.2.2.2
ip http access-class 1
!
!
snmp-server community public RO
snmp-server community private RW
!
banner motd _
This router only has 32M ram and won't run
ios version higher than 120-22.S3.
-
!
!
end

```

PE1

```

!
version 12.0
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
no service single-slot-reload-enable
!
hostname cl-7513-1
!
boot system flash rsp-pv-mz.120-24.S.bin
redundancy
  no keepalive-enable
  mode hsa
enable password atlantech
!
username admin password 0 amaf
ip subnet-zero
ip cef
ip vrf aqua
  rd 100:1
  route-target export 1:1
  route-target import 1:1
!
mpls label protocol ldp

```

```

no mpls ldp logging neighbor-changes
no mpls traffic-eng auto-bw timers frequency 0
!
!
!
interface Loopback0
  ip address 10.2.2.2 255.255.255.255
  no ip directed-broadcast
  no ip mroute-cache
!
interface POS4/0/0
  bandwidth 100000
  ip address 192.168.1.37 255.255.255.252
  no ip directed-broadcast
  no keepalive
  shutdown
  mpls traffic-eng tunnels
  mpls traffic-eng administrative-weight 100
  tag-switching ip
  fair-queue
  clock source internal
  pos ais-shut
  no cdp enable
  ip rsvp bandwidth 60000 60000 sub-pool 30000
  ip rsvp signalling dscp 0
!
interface FastEthernet8/0/0
  ip vrf forwarding aqua
  ip address 10.1.1.2 255.255.255.0
  no ip directed-broadcast
!
interface Serial8/1/0
  no ip address
  no ip directed-broadcast
  shutdown
!
interface Serial8/1/1
  no ip address
  no ip directed-broadcast
  shutdown
!
interface Serial8/1/2
  no ip address
  no ip directed-broadcast
  clock source internal
!
interface Serial8/1/3
  no ip address
  no ip directed-broadcast
  shutdown
!
interface GigabitEthernet9/0/0
  ip address 10.6.6.2 255.255.255.0
  no ip directed-broadcast
  no keepalive
  no negotiation auto
  tag-switching ip
!
interface ATM10/0/0
  no ip address
  no ip directed-broadcast
  shutdown
  no atm enable-ilmi-trap
  no atm ilmi-keepalive

```

```

!
router ospf 1
  log-adjacency-changes
  network 0.0.0.0 255.255.255.255 area 0
!
router bgp 1
  bgp log-neighbor-changes
  neighbor 10.5.5.5 remote-as 1
  neighbor 10.5.5.5 update-source Loopback0
  no auto-summary
  !
  address-family ipv4 multicast
  no auto-summary
  exit-address-family
  !
  address-family vpnv4
  neighbor 10.5.5.5 activate
  neighbor 10.5.5.5 send-community extended
  no auto-summary
  exit-address-family
  !
  address-family ipv4
  neighbor 10.5.5.5 activate
  no auto-summary
  no synchronization
  exit-address-family
  !
  address-family ipv4 vrf aqua
  redistribute connected
  no auto-summary
  no synchronization
  exit-address-family
!
ip classless
ip route 0.0.0.0 0.0.0.0 10.51.20.1
!
!
!
snmp-server community public RO
snmp-server community private RW
!
!
!
end

```

P

```

!
version 12.0
no service pad
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
hostname cl-12008-1
!
redundancy
  mode rpr
no logging console
enable password atlantech
!

```

```
!  
!  
!  
ip subnet-zero  
mpls label protocol ldp  
mpls ldp logging neighbor-changes  
no mpls traffic-eng auto-bw timers frequency 0  
!  
!  
interface Loopback0  
    ip address 10.7.7.7 255.255.255.255  
    no ip directed-broadcast  
!  
interface GigabitEthernet1/0  
    ip address 10.8.8.7 255.255.255.0  
    no ip directed-broadcast  
    no negotiation auto  
    tag-switching ip  
!  
interface FastEthernet2/0  
    no ip address  
    no ip directed-broadcast  
    shutdown  
!  
interface FastEthernet2/0.10  
    encapsulation dot1Q 10  
    no ip directed-broadcast  
!  
interface FastEthernet2/0.123  
    encapsulation dot1Q 1  
    no ip directed-broadcast  
!  
interface FastEthernet2/1  
    no ip address  
    no ip directed-broadcast  
    shutdown  
!  
interface FastEthernet2/2  
    no ip address  
    no ip directed-broadcast  
    shutdown  
!  
interface FastEthernet2/3  
    no ip address  
    no ip directed-broadcast  
    shutdown  
!  
interface FastEthernet2/4  
    no ip address  
    no ip directed-broadcast  
    shutdown  
!  
interface FastEthernet2/5  
    no ip address  
    no ip directed-broadcast  
    shutdown  
!  
interface FastEthernet2/6  
    no ip address  
    no ip directed-broadcast  
    shutdown  
!  
interface FastEthernet2/7  
    no ip address
```

```
no ip directed-broadcast
shutdown
!
interface POS3/0
bandwidth 100000
ip address 192.168.1.14 255.255.255.252
no ip directed-broadcast
no keepalive
shutdown
mpls traffic-eng tunnels
mpls traffic-eng administrative-weight 100
tag-switching ip
crc 16
clock source internal
pos ais-shut
pos scramble-atm
ip rsvp bandwidth 50000 50000 sub-pool 30000
ip rsvp signalling dscp 0
ip rsvp signalling hello
!
interface GigabitEthernet4/0
no ip address
no ip directed-broadcast
shutdown
no negotiation auto
!
interface GigabitEthernet4/1
ip address 10.6.6.7 255.255.255.0
no ip directed-broadcast
no negotiation auto
tag-switching ip
!
interface GigabitEthernet4/2
no ip address
no ip directed-broadcast
shutdown
no negotiation auto
!
interface ATM7/0
no ip address
no ip directed-broadcast
no atm enable-ilmi-trap
no atm ilmi-keepalive
pvc 1/1
no broadcast
oam retry 3 5 1
!
pvc pvc2 1/2
!
pvc 1/5
!
!
interface ATM7/0.100 point-to-point
no ip directed-broadcast
no atm enable-ilmi-trap
pvc test1 254/1
!
!
interface ATM7/0.101 multipoint
no ip directed-broadcast
no atm enable-ilmi-trap
pvc test2 254/2
!
pvc test5 254/5
```

```

!
pvc test6 254/6
!
pvc test4 254/10
!
!
interface ATM7/1
  no ip address
  no ip directed-broadcast
  atm pvc 1000 80 800 ilmi 64000 32000
  no atm enable-ilmi-trap
  no atm ilmi-keepalive
  pvc 10/100
  oam-pvc manage 30
  !
  pvc 10/101
  !
!
interface ATM7/2
  no ip address
  no ip directed-broadcast
  no atm enable-ilmi-trap
  no atm ilmi-keepalive
!
interface ATM7/2.100 point-to-point
  ip address 10.51.21.101 255.255.255.0
  no ip directed-broadcast
  no atm enable-ilmi-trap
!
interface ATM7/3
  no ip address
  no ip directed-broadcast
  no atm enable-ilmi-trap
  no atm ilmi-keepalive
!
interface ATM7/3.100 point-to-point
  ip address 10.51.22.100 255.255.255.0
  no ip directed-broadcast
  no atm enable-ilmi-trap
!
interface Ethernet0
  ip address 10.51.20.105 255.255.255.0
  no ip directed-broadcast
  ip route-cache cef
!
router ospf 1
  log-adjacency-changes
  network 0.0.0.0 255.255.255.255 area 0
!
ip classless
ip route 0.0.0.0 0.0.0.0 10.51.20.1
!
ip rsvp signalling hello
!
!
snmp-server community private RW
snmp-server community public RO
!
!
end

```


PE2

```

!
version 12.0
no service pad
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
no service single-slot-reload-enable
!
hostname cl-7505-3
!
boot system flash rsp-pv-mz.120-24.S.bin
redundancy
    no keepalive-enable
enable password atlantech
!
ip subnet-zero
ip cef distributed
ip vrf aqua
    rd 100:1
    route-target export 1:1
    route-target import 1:1
!
mpls label protocol ldp
no mpls ldp logging neighbor-changes
no mpls traffic-eng auto-bw timers frequency 0
!
!
!
interface Loopback0
    ip address 10.5.5.5 255.255.255.0
    no ip directed-broadcast
    no ip route-cache
    no ip mroute-cache
!
interface GigabitEthernet2/0/0
    ip address 10.8.8.5 255.255.255.0
    no ip directed-broadcast
    no negotiation auto
    tag-switching ip
!
interface FastEthernet3/0/0
    ip address 10.51.20.239 255.255.255.0
    no ip directed-broadcast
    no ip route-cache
    no ip mroute-cache
!
interface POS3/1/0
    ip vrf forwarding aqua
    ip address 10.10.10.5 255.255.255.0
    no ip directed-broadcast
    no ip route-cache
    no keepalive
    tag-switching ip
    clock source internal
    pos ais-shut
    pos scramble-atm
    pos flag c2 22
!
router ospf 1
    log-adjacency-changes
    network 0.0.0.0 255.255.255.255 area 0

```

```

!
router rip
  version 2
  !
  address-family ipv4 vrf aqua
  version 2
  network 10.0.0.0
  no auto-summary
  exit-address-family
!
router bgp 1
  bgp log-neighbor-changes
  neighbor 10.2.2.2 remote-as 1
  neighbor 10.2.2.2 update-source Loopback0
  no auto-summary
  !
  address-family ipv4 multicast
  no auto-summary
  exit-address-family
  !
  address-family vpv4
  neighbor 10.2.2.2 activate
  neighbor 10.2.2.2 send-community extended
  no auto-summary
  exit-address-family
  !
  address-family ipv4
  neighbor 10.2.2.2 activate
  no auto-summary
  no synchronization
  exit-address-family
  !
  address-family ipv4 vrf aqua
  redistribute connected
  redistribute rip
  no auto-summary
  no synchronization
  exit-address-family
!
ip classless
!
!
!
cns config partial 10.51.20.248 80
cns id hostname
cns event 10.51.20.248 11011
snmp-server community public RO
!
!
!
end

```

CE2

```

!
version 12.0
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
no service single-slot-reload-enable
!
hostname cl-7505-2

```

```
!
redundancy
  no keepalive-enable
enable password atlantech
!
ip subnet-zero
no ip cef
no mpls ldp logging neighbor-changes
no mpls traffic-eng auto-bw timers frequency 0
!
!
!
interface Loopback0
  ip address 192.168.1.196 255.255.255.192
  no ip directed-broadcast
!
interface POS0/0/0
  bandwidth 100000
  ip address 192.168.1.38 255.255.255.252
  no ip directed-broadcast
  no keepalive
  shutdown
  mpls traffic-eng tunnels
  mpls traffic-eng administrative-weight 100
  tag-switching ip
  fair-queue
  clock source internal
  pos ais-shut
  pos flag c2 22
  no cdp enable
  ip rsvp bandwidth 60000 60000 sub-pool 30000
  ip rsvp signalling dscp 0
!
interface FastEthernet3/0/0
  ip address 10.51.20.238 255.255.255.0
  no ip directed-broadcast
!
interface POS3/1/0
  bandwidth 100000
  ip address 10.10.10.6 255.255.255.0
  no ip directed-broadcast
  no keepalive
  clock source internal
  pos ais-shut
  pos scramble-atm
  pos flag c2 22
  no cdp enable
!
router rip
  version 2
  network 10.0.0.0
  network 192.168.1.0
  no auto-summary
!
ip classless
!ip route 0.0.0.0 0.0.0.0 10.51.20.1
ip route 0.0.0.0 0.0.0.0 10.10.10.5
!
!
!
snmp-server community public RO
snmp-server community private RW
!
end
```




A

about this guide

conventions and terminology [xxviii](#)

access lists [11-5](#)

APS

adding protected interfaces [8-20](#)

adding working interfaces [8-20](#)

removing protected interfaces [8-20](#)

removing working interfaces [8-20](#)

archiving

Performance Manager [20-6](#)

ATM

configuration [8-6](#)

connections [12-1](#)

overall process of creating [12-7](#)

interface faults [9-8](#)

QoS profiles

applying to ATM connection [12-28](#)

creating [12-12](#)

ATM interface profile

creating [7-3](#)

deleting [7-6](#)

editing [7-6](#)

auto discovery [3-19](#)

average, Summary Rule [20-8](#)

C

C12kM

alarms [18-1](#)

objects and interfaces [2-1](#)

object states [2-13](#)

decommissioned [2-14](#)

discovery [2-15](#)

discovery lost comms [2-15](#)

download [2-15](#)

errored [2-14](#)

lost comms [2-15](#)

mismatched [2-15](#)

normal [2-14](#)

performance logging on [2-14](#)

performance information [20-2](#)

CAR

applying policies to interfaces [11-18](#)

creating access lists [11-10](#)

creating policies [11-6](#)

editing or deleting policies [11-19](#)

overview [11-3](#)

removing policies from interfaces [11-19](#)

status [11-21](#)

workflow [11-6](#)

CAR and WRED in C12kM [11-5](#)

change management [19-1](#)

inserting linecards [19-2](#)

removing linecards [19-4](#)

chassis

commissioning [4-8](#)

configuration [4-7](#)

fault management [4-20, 15-4](#)

management information [4-3](#)

SNMP management [4-14](#)

system log [4-29, 15-14](#)

Cisco 12000 Series chassis

deployment [3-20](#)

Cisco 12000 series chassis [2-3](#)

Cisco EMF and C12kM [3-3](#)

Cisco EMF user session

start [3-3](#)

CLLI [4-12, 4-14](#)

clock scheduler cards (CSCs) [2-5](#)

deployment [3-50](#)

commissioning

chassis [3-26, 3-27, 3-30](#)

modules [5-4](#)

CoS queue group

applying [11-28](#)

creating [11-23](#)

creating

ATM interface profile [7-3](#)

HSRP IP profile [7-9, 7-17](#)

POS interface profile [7-12](#)

subchassis discovery [3-26](#)

supporting modules [3-50](#)

to deploy a generic object [3-11](#)

user named and auto named [3-31](#)

discovery lost comms state [2-15](#)

DRR [11-27](#)

E

editing

an existing ATM interface profile [7-6](#)

an existing POS interface profile [7-14](#)

editing an existing POS interface profile [7-14](#)

element manager windows

launching [4-2, 5-2, 15-3](#)

errored state [2-14](#)

Ethernet configuration [8-9](#)

Event Browser, uses [3-6](#)

event outstanding state [2-8](#)

event unacknowledged count [2-8](#)

event unacknowledged state [2-8](#)

F

Fault, Configuration, Accounting, Performance, and Security (FCAPS) [2-1](#)

FCAPS [2-1](#)

G

getting started [3-1](#)

global performance logging

starting or stopping [4-9](#)

graphs and charts - Performance Manager [20-5](#)

GRP, deployment [3-31](#)

H

heartbeat polling [18-7](#)

D

decommissioned state [2-14](#)

decommissioning

interface [8-5](#)

modules [5-5](#)

deploying

modules

GRPs [3-31](#)

line cards [3-38](#)

PVCs [12-18](#)

supporting modules

clock scheduler cards (CSCs) [3-50](#)

switch fabric cards (SFCs) [3-55](#)

SVCs [12-22](#)

deployment [3-8](#)

auto discovery [3-19](#)

Cisco 12000 series chassis [3-20](#)

commissioning chassis [3-26, 3-27, 3-30](#)

modules [3-30](#)

predeployment and offline configuration [3-58](#)

process [3-9](#)

connectivity management [18-7](#)
 operational status polling [18-7](#)
 HSRP IP interface
 deleting [7-11](#)
 HSRP IP interface profile
 editing [7-10](#)

ATM [9-5](#)
 DS-3 [9-9](#)
 generic [9-3](#)
 SONET [9-12](#)
 IOS image download [4-32, 16-26](#)
 IP configuration [8-13](#)

I

icons
 Cisco EMF Launchpad [3-5](#)
 interface
 ATM
 configuration [8-6](#)
 faults [9-8](#)
 configuration [8-3](#)
 ethernet
 configuration [8-9](#)
 IP
 configuration [8-13](#)
 performance
 DS-3 [10-15](#)
 ethernet [10-19](#)
 generic [10-3](#)
 SONET [10-10](#)
 POS
 configuration [8-15, 8-18](#)
 status
 ATM [9-5](#)
 DS-3 [9-9](#)
 generic [9-3](#)
 SONET [9-12](#)
 interface performance
 DS-3 [10-15](#)
 ethernet [10-19](#)
 generic [10-3](#)
 SONET [10-10](#)
 interface profile types [7-2](#)
 interface status

L

launching
 interface profile windows [11-1](#)
 Performance Manager [20-2](#)
 linecard
 inserting new [19-2](#)
 removing [19-4](#)
 line cards
 deployment [3-38, 1](#)
 logical objects [2-6](#)
 LogicalOR, Summary Rule [20-9](#)
 Login window [3-4](#)
 lost comms state [2-15](#)

M

managing
 chassis [4-1](#)
 modules [5-1](#)
 Map Viewer [1-2](#)
 event outstanding state [2-8](#)
 event unacknowledged count [2-8](#)
 event unacknowledged state [2-8](#)
 object class [2-8](#)
 object name [2-8](#)
 object state [2-8](#)
 mapviewer [3-6](#)
 Max, Summary Rule [20-8](#)
 Min, Summary Rule [20-8](#)
 mismatched state [2-15](#)

module

- commissioning [5-4](#)
- configuration [5-3](#)
- decommissioning [5-5](#)
- deployment [3-30](#)
- fault management [5-7](#)
- performance [5-9](#)
- monitored attributes [18-1, 18-3, 20-2](#)

N

- normal state [2-14](#)

O

object

- associated network element [2-8](#)
- defined [2-8](#)
- object class [2-8](#)
- object name [2-8](#)
- object state [2-8](#)
- overview [1-1](#)

P

- password [3-4](#)
- performance information
 - available using C12kM [20-2](#)
- performance logging
 - module [20-1](#)
 - starting or stopping [5-10, 5-11](#)
- performance logging on state [2-14](#)
- Performance Manager
 - archiving [20-6](#)
 - launching [20-2](#)
 - printing a performance file [20-6](#)
 - saving performance data [20-6](#)
 - start polling events point [20-5](#)

- stop polling events point [20-5](#)

- Summary Rule [20-8](#)

- window [20-2](#)

performance statistics

- printing [20-6](#)

physical interfaces and technologies [2-5](#)physical objects [2-2](#)POS configuration [8-15, 8-18](#)

POS interface profile

- creating [7-12](#)

- deleting [7-15](#)

printing performance statistics [20-6](#)

profiles

creating

- HSRP IP profile [7-9, 7-17](#)

- POS interface [7-12](#)

deleting

- ATM interface profile [7-6](#)

- HSRP IP interface profile [7-11](#)

- POS interface profile [7-15](#)

editing

- ATM interface profile [7-6](#)

- HSRP IP interface [7-10](#)

- POS interface profile [7-14](#)

PVC

- configuration [12-30](#)

- connecting or disconnecting [12-31](#)

- decommissioning or recommissioning [12-32](#)

- defined [12-1](#)

- deploying [12-18](#)

- status [12-40](#)

- uploading [12-7](#)

Q

QoS queue group

- changing association [11-30](#)

- removing [11-30](#)

quitting a Cisco EMF user session [3-8](#)

R

Refresh button - Performance Manager [20-9](#)
 refresh screen button [20-5](#)

S

saving performance data to a file [20-6](#)
 SONET/SDH conversion chart [A-1](#)
 stopping
 performance logging
 interface/port [10-7](#)
 subchassis discovery [3-26](#)
 subchassis modules
 deployment [1](#)
 Summary Rule
 Average [20-8](#)
 LogicalOR [20-9](#)
 Peak [20-8](#)
 Total [20-8](#)
 Trough [20-8](#)
 Summary Rule - Performance Manager [20-8](#)
 supporting modules [2-5](#)
 deployment [3-50, 1](#)
 SVC
 configuration [12-37](#)
 connecting or disconnecting [12-38](#)
 decommissioning or recommissioning [12-38](#)
 defined [12-1](#)
 deploying [12-22](#)
 switch fabric cards (SFCs) [2-5](#)
 deployment [3-55](#)

T

telecom graphical object (TGO) [2-8](#)
 tgo [2-8](#)
 total, Summary Rule [20-8](#)

U

user name - Cisco EMF login [3-4](#)
 user named and auto named deployment [3-31](#)
 user password
 Cisco EMF login [3-4](#)

V

viewing alarms [18-2](#)
 views [2-11](#)
 component managed view [2-11](#)
 layer 3 QoS view [2-12](#)
 network view [2-12](#)
 physical view [2-12](#)

W

workflow
 C12kM processes [3-1](#)
 WRED
 applying CoS queue groups to interfaces [11-28](#)
 changing the association of CoS queue groups [11-30](#)
 creating CoS queue groups [11-23](#)
 DRR [11-27](#)
 editing or deleting a CoS queue group [11-24](#)
 overview [11-3](#)
 removing CoS queue groups from interfaces [11-30](#)
 workflow [11-22](#)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>