

clarion®

Owner's manual
Mode d'emploi
Istruzioni per l'uso
Manual de instrucciones

M275

MARINE CD/MP3/WMA RECEIVER
RADIO CD/MP3/WMA MARIN
LETTORE CD/MP3/WMA PER USO MARINO
RECEPTOR MARINE CD/MP3/WMA

CLARION PRODUCT REGISTRATION INFORMATION

For USA and Canada only

www.clarion.com

Dear Customer:

Congratulations on your purchase of a Clarion mobile electronic products. We are confident that you'll enjoy your Clarion experience.

There are many benefits to registering your product. We invite you to visit our website at www.clarion.com to register your Clarion product.

We have made product registration simple with our easy to use website. The registration form is short and easy to complete. Once you're registered, we can keep you informed of important product information.

Register at www.clarion.com - it's easy to keep your Clarion product up to date.

Contents

1. FEATURES	2
2. CONTROLS	3
MAIN UNIT	3
3. NOMENCLATURE	4
Names of the Buttons and Their Functions	4
Display Items	5
LCD Screen	5
4. PRECAUTIONS	6
5. HANDLING COMPACT DISCS	7
6. DCP (Detachable Control Panel)	8
7. OPERATIONS	9
Basic Operations	9
Radio Mode Operations	12
CD/MP3/WMA Mode Operations	14
8. OTHER OPERATIONS	20
9. TROUBLESHOOTING	22
10. ERROR DISPLAYS	23
11. SPECIFICATIONS	24

1. FEATURES


- Auxiliary Audio Input
- CD-R, CD-RW, WMA, & MP3 Compatible
- Rotary Volume Control & HD Display



Be sure to unfold and read the next page.
Veillez déplier et vous référer à la page suivante.
Assicurarsi di aprire e leggere la pagina successiva.
Cerciórese de desplegar y de leer la página siguiente.

2. CONTROLS / LES COMMANDES / CONTROLLI / CONTROLES

MAIN UNIT / APPAREIL PRINCIPAL / APPARECCHIO PRINCIPALE / UNIDAD PRINCIPAL



Note: Be sure to unfold this page and refer to the front diagrams as you read each chapter.

Remarque: Veuillez déplier cette page et vous référer aux schémas quand vous lisez chaque chapitre.

Nota: Assicurarsi di aprire questa pagina e fare riferimento a questi diagrammi quando si legge ciascun capitolo.

Nota: Cuando lea los capítulos, despliegue esta página y consulte los diagramas.

4. PRECAUTIONS

1. When it is very cold in the boat and the unit is used soon after switching on the heater, the disc and the optical components may become fogged and not operate properly. Wipe fogged discs with a soft cloth. Fogged optical components will naturally return to normal when the unit is left for about one hour after which it will operate normally.
2. When the boat is underway in rough water the sound may skip as a result of intense vibrations and shock.
3. This unit uses a precision mechanism. Even in the event that trouble arises, never open the case, disassemble the unit, or lubricate the rotating parts.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to consult the dealer or an experienced radio/TV technician for help.

⚠ CAUTION


USE OF CONTROLS, ADJUSTMENTS, OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN, MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

THE COMPACT DISC PLAYER SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT PROPERLY QUALIFIED SERVICE PERSONNEL.

INFORMATION FOR USERS:

CHANGES OR MODIFICATIONS TO THIS PRODUCT NOT APPROVED BY THE MANUFACTURER WILL VOID THE WARRANTY AND WILL VIOLATE FCC APPROVAL.

CE	MODEL	M275	clarion
12V  GROUND	USA: AM 530-1710kHz / FM 87.9-107.9MHz		
 15A Load 4Ω	EUROPE: AM 531-1602kHz / FM 87.5-108MHz		
	AUSTRALIA: AM 531-1629kHz / FM 87.0-108MHz		
THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.			
THIS PRODUCTION COMPLIES WITH DHHS RULES 21 CFR SUBCHAPTER J APPLICABLE AT DATE OF MANUFACTURE.			
CLARION CO., LTD. 50 KAMITODA, TODA-SHI, SAITAMA-KEN, JAPAN			
This product includes technology owned by Microsoft Corporation and cannot be used or distributed without a license from MSLGP			
CLASS 1 LASER PRODUCT			
051 722 877			
MANUFACTURED: CLARION MALAYSIA			
SERIAL No. PE-3008B	 276-0277-00 Clarion Co., Ltd. MADE IN MALAYSIA		



Bottom View of Source Unit


5. HANDLING COMPACT DISCS

This unit has been designed specifically for playback of compact discs bearing the mark. No other discs can be played.



To remove the compact disc from its storage case, press down on the center of the case and lift the disc out, holding it carefully by the edges.

Removing the disc




Proper way to hold the compact disc




Always handle the compact disc by the edges. Never touch the surface.

To remove fingermarks and dust, use a soft cloth, and wipe in a straight line from the center of the compact disc to the circumference.




New discs may have some roughness around the edges. The unit may not work or the sound may skip if such discs are used. Use a ball-point pen, etc. to remove roughness from the edge of the disc.



Note on compact discs


Never stick labels on the surface of the compact disc or mark the surface with a pencil or pen.

No




Do not use any solvents such as commercially available cleaners, anti-static spray, or thinner to clean compact discs.

No




Do not use compact discs that have large scratches, are misshapen, or cracked, etc. Use of such discs will cause misoperation or damage.

No



Do not expose compact discs to direct sunlight or any heat source.

No



Note:

- Do not use commercially available CD protection sheets or discs equipped with stabilizers, etc. These may get caught in the internal mechanism and damage the disc.

3. NOMENCLATURE

Note:

- Be sure to read this chapter referring to the front diagrams of chapter "2. CONTROLS" on page 3 (unfold).

Names of the Buttons and Their Functions

[RELEASE] button

- Press the [RELEASE] button to unlock the detachable panel.

[▲] button

- Eject a CD when it is loaded in the unit.

[D] button

- During Radio mode, switch the display indication in the following order:

Main Display → Clock Display → Main Display...

- During CD/AUX mode, switch the display indication (Main Display, Clock Display).

- During MP3/WMA mode, switch the display indication in the following order:

Track No./Play Time → Folder No./Play Time
→ Track Name → Folder Name → Title Tag →
Album Tag → Artist Tag → Clock Display →
Track No./Play Time...

- Press and hold the button for 1 second or longer to enter the Adjustment mode.

[♪] button

- Use the button to enter to the Sound mode. (Z-Enhancer, Bass, Treble, Balance, Fader).
- Press and hold for 1 second or longer to turn on or off the M-B EX mode.

[ISR] button

- Recall ISR radio station in memory.
- Press and hold for 2 seconds or longer: Store current station into ISR memory (Radio mode only).

[DIRECT] buttons

- Store a station into memory or recall it directly while in the Radio mode.

[SCN] button

- Perform scan play for 10 seconds of each track while in the CD/MP3/WMA mode.
- Press and hold the button for 1 second or longer to perform all scan play while in the MP3/WMA mode.

[RPT] button

- Repeat play while in the CD/MP3/WMA mode.
- Press and hold the button for 1 second or longer to perform all repeat play while in the MP3/WMA mode.

[RDM] button

- Perform random play while in the CD/MP3/WMA mode.
- Press and hold the button for 1 second or longer to perform all random play while in the MP3/WMA mode.

[UP], [DN] buttons

- Select the folder (MP3/WMA disc only).

[◀◀], [▶▶] buttons

- Seek a station while in the Radio mode or select a track when listening to a CD. These buttons are used to make various settings.
- Press and hold the button for 1 second or longer to enter the fast-forward or fast-backward in CD/MP3/WMA mode.

[▶||] button

- Perform preset scan while in the Radio mode. Press and hold the button for 2 seconds or longer to perform auto store.
- Play or pause a track while in the CD/MP3/WMA mode.
- Perform second level adjustment or selection.

[SRC] button

- Press the button to turn on the power. Press and hold the button for 1 second or longer to turn off the power.
- Switch the Operation mode among the Radio mode, CD/MP3/WMA mode and AUX mode.

[BND] button

- Switch the band, or seek tuning or manual tuning while in the Radio mode.
- Play the first track while in the CD/MP3/WMA mode.
- Press and hold the button for 1 second or longer to select CD-DA or MP3/WMA on a Multi-session disc.

[ROTARY] knob

- Adjust the volume by turning the knob clockwise or counterclockwise.
- Use the knob to perform various settings.


6. DCP (Detachable Control Panel)

The control panel can be detached to prevent theft. When detaching the control panel, store it in the DCP (Detachable Control Panel) case to prevent scratches.


We recommend taking the DCP with you when leaving the boat.

Removing the DCP

1. Press the [SRC] button for 1 second or longer to switch off the power.
2. Press in the [RELEASE] button.




3. Remove the DCP.




Attaching the DCP

1. Insert the right side of the DCP into the main unit.
2. Insert the left side of the DCP to attach into the main unit.




Storing the DCP in the DCP case

Hold the DCP, in the orientation as shown in the figure below, and put it into the supplied DCP case. (Ensure the DCP is in the correct orientation.)



CAUTION

- The DCP can easily be damaged by impact. After removing it, be careful not to drop it or subject it to strong shocks.
- When the Release button is pressed and the DCP is unlocked, the intense vibration and shock may cause it to fall. To prevent damage to the DCP, always store it in its case after detaching it. (See figure above.)
- The connector connecting the main unit and the DCP is an extremely important part. Be careful not to damage it by pressing on it with fingernails, pens, screwdrivers, etc.



Note:

- If the DCP is dirty, wipe off the dirt with a soft, dry cloth only.

7. OPERATIONS

Basic Operations

Note: Be sure to read this chapter referring to the front diagrams of chapter "2. CONTROLS" on page 3 (unfold).

⚠ CAUTION

Be sure to lower the volume before switching off the unit power or the ignition key. The unit remembers its last volume setting. If you switch the power off with the volume up, when you switch the power back on, the sudden loud volume may hurt your hearing and damage the unit.

Turning on/off the power

Note:

- Be careful about using this unit for a long time without running the engine. If you drain the boat's battery too much, you may not be able to start the engine and this can reduce the service life of the battery.

1. Press the [SRC] button.
2. The illumination and display on the unit light up. The unit automatically remembers its last Operation mode and will automatically switch to display that mode.
3. Press and hold the [SRC] button for 1 second or longer to turn off the power for the unit.

Selecting a mode

1. Press the [SRC] button to change the Operation mode.
2. Each time you press the [SRC] button, the Operation mode changes in the following order:

Radio mode → **CD/MP3/WMA mode** →
AUX mode → **Radio mode...**

Note:

- If the CD mode is selected when no disc is inserted, the display shows "NO DISC".

Switching the display

Press the [D] button to select the desired display.

Each time you press the [D] button, the display switches in the following order:

● Radio mode

Main Display → Clock Display → Main Display...

● CD mode

Main Display (Track No., Play Time) →
Clock Display → Main Display...

● MP3/WMA mode

Main-1 Display (Track No., Play Time) →
Main-2 Display (Folder No., Play Time) →
Track → Folder → Title → Album → Artist →
Clock Display → Main-1 Display...

● AUX mode

Main Display → Clock Display → Main Display...

- * Once selected, the preferred display becomes the display default. When a function adjustment such as volume is made, the screen will momentarily switch to that function's display, then revert back to the preferred display several seconds after the adjustment.


Adjusting the volume

Turning the [ROTARY] knob clockwise increases the volume; turning it counterclockwise decreases the volume. "VOL XX" will be displayed where "XX" is the volume level from 0 (minimum) to 33 (maximum).

- * The factory default setting for volume is "VOL 13".

Sound mode adjustments

1. Press the [J] button to enter the Sound Adjustment mode.
2. Press the [◀▶] button to select the "item name".



Basic Operations

3. Turning the [ROTARY] knob to adjust the selected Sound mode.

Z-EHCR :

Selection type : OFF ↔ B-BOOST ↔
IMPACT ↔ EXCITE ↔ OFF...

BASS :

Adjustment range : -7 to +7

TREBLE :

Adjustment range : -7 to +7

BALANCE :

Adjustment range : LEFT 12 to RIGHT 12

FADER :

Adjustment range : FRONT 12 to REAR 12


Notes:




- If no operation is performed for more than 10 seconds, the Audio mode is cancelled and returns to the previous mode.
- Bass and Treble can only be adjusted when the "Z-EHCR" is off.

Setting the Z-Enhancer

This unit is provided with 3 types of sound tone effects stored in memory. Select the one you prefer.

- 2-1. Press the [◀◀, ▶▶] button and select "Z-EHCR".
- 3-1. Turning the [ROTARY] knob to change to the following sound tone effect.



- OFF : no sound effect
- B-BOOST : bass emphasized
() indicator lights in the display
- IMPACT : bass and treble emphasized
() indicator lights in the display
- EXCITE : bass and treble emphasized mid de-emphasized
() indicator lights in the display

Note:

- The factory default setting is "OFF".

Adjusting the bass

- 2-1. Press the [◀◀, ▶▶] button and select "BASS".

- 3-1. Turning the [ROTARY] knob clockwise emphasizes the bass; turning it counterclockwise attenuates the bass.

"BASS XX" will be displayed where "XX" is the value from -7 to +7.

Note:

- The factory default setting is "BASS 0".

Adjusting the treble

- 2-1. Press the [◀◀, ▶▶] button and select "TREBLE".

- 3-1. Turning the [ROTARY] knob clockwise emphasizes the bass; turning it counterclockwise attenuates the bass.

"TREB XX" will be displayed where "XX" is the value from -7 to +7.

Note:

- The factory default setting is "TREB 0".

Adjusting the balance

- 2-1. Press the [◀◀, ▶▶] button and select "BALANCE".

- 3-1. Turning the [ROTARY] knob clockwise emphasizes the sound from the right speaker; turning it counterclockwise emphasizes the sound from the left speaker.

The display changes as follows:

"RIGHT XX" will be displayed where "XX" is the value from 1 to 12.

"LEFT XX" will be displayed where "XX" is the value from 1 to 12.

Notes:

- When Balance is 0, "CENTER" will be displayed instead.
- The factory default setting is "CENTER".

Basic Operations

Adjusting the fader

2-1. Press the [◀▶] button and select "FADER".

3-1. Turning the [ROTARY] knob clockwise emphasizes the sound from the front speakers; turning it counterclockwise emphasizes the sound from the rear speakers.

The display changes as follows:

"FRONT XX" will be displayed where "XX" is the value from 1 to 12.

"REAR XX" will be displayed where "XX" is the value from 1 to 12.

Notes:

- When Fader is 0, "CENTER" will be displayed instead.
- The factory default setting is "CENTER".

Adjusting MAGNA BASS EX

The MAGNA BASS EX does not adjust the low sound area like the normal sound adjustment function, but emphasizes the deep bass sound area to provide you with a dynamic sound.

1. Press and hold the [🎵] button for 1 second or longer to turn on the MAGNA BASS EX effect.



indicator lights in the display.

2. Press and hold the [🎵] button for 1 second or longer to turn off the MAGNA BASS EX effect.



indicator goes off from the display.

Note:

- The factory default setting is "OFF".


AUX function

This system has an external jack input in the front panel where you can listen to sounds and music from external devices connected to this unit.

1. Connect the external music player to the [AUX] input.
2. Press the [SRC] button and select the AUX mode to activate the AUX function.

Notes:

- Use only the 3.5mm stereo jack for the AUX jack input.
- Volume can be adjusted through the unit. If you face difficulties of hearing sound even after volume has been adjusted, please refer section "Selecting AUX IN sensitivity" on page 20 for details.



Radio Mode Operations

Listening to the radio

1. Press the [SRC] button and select the Radio mode, then the radio will be on.
2. To select a preset band, press the [BND] button, and then select one of the preset bands such as FM1, FM2, FM3 or AM.
Every time the [BND] button is pressed, the band switches in the following order:
F1 → F2 → F3 → AM → F1...
3. Press the [◀◀, ▶▶] button to tune in the desired station.

Seek tuning

1. Press the [BND] button and select the desired band (FM or AM).
 - * If "MANU" is lit in the display, press and hold the [BND] button for 1 second or longer.
"MANU" in the display goes off and seek tuning is now available.
2. Press the [◀◀, ▶▶] button to start automatic station tuning.
When the [▶▶] button is pressed, search will be performing in the direction of higher frequencies. When the [◀◀] button is pressed, search will be performed in the direction of lower frequencies.

Manual tuning

There are 2 ways available: Quick tuning and step tuning.

When you are in the step Tuning mode, the frequency changes one step at a time. In the quick Tuning mode, you can quickly tune the desired frequency.

1. Press the [BND] button and select the desired band (FM or AM).
 - * If "MANU" is not lit in the display, press and hold the [BND] button for 1 second or longer.
"MANU" is lit in the display and manual tuning is now available.
2. Tune into a station.

● Quick tuning:

Press and hold the [◀◀, ▶▶] button for 1 second or longer to begin station tuning.

● Step tuning:

Press the [◀◀, ▶▶] button to perform manual tuning.

Preset memory function

Preset memory function can store up to 24 stations:

Six stations for each of FM1, FM2, FM3 and AM.

Manual memory function

1. Press the [BND] button and to select a band you want to store in the memory.
2. Press the [◀◀, ▶▶] button to tune into a desired station.
3. Press and hold one of the [DIRECT] buttons for 2 seconds or longer to store the current station into preset memory.

Auto store

Auto store is a function for storing up to 6 stations that are automatically tuned in sequentially. If 6 receivable stations cannot be received, a previously stored station remains un-overwritten at the memory position.

1. Press the [BND] button and select the desired band (FM or AM).
2. Press and hold the [▶▶] button for 2 seconds or longer. The stations with good reception are stored automatically to the preset channels.
"A-STORE" will be displayed.

Preset scan

Preset scan receives the stations stored in preset memory in order. This function is useful when searching for a desired station in memory.

1. Press the [▶▶] button.
2. When a desired station is tuned in, press the [▶▶] button again to continue receiving that station.
"P-SCN" will be displayed and "SCN" indicator lights in the display.

Note:

- Be careful not to press and hold the [▶▶] button for 2 seconds or longer, otherwise the auto store function is engaged and the unit starts storing stations.

Radio Mode Operations

Recalling a preset station

A total of 24 preset positions (6-FM1, 6-FM2, 6-FM3, 6-AM) exists to store individual radio stations in memory. Pressing the corresponding [DIRECT] button recalls the stored radio frequency automatically.

1. Press the [BND] button and select the desired band (FM or AM).
2. Press the corresponding [DIRECT] button to recall the stored station.

Instant station recall (ISR)

Instant station recall is a special radio preset that instantly accesses a favorite radio station at a touch of a button. The ISR function even operates with the unit in other modes.

● ISR memory

1. Select the station that you wish to store in ISR memory.
2. Press and hold the [ISR] button for 2 seconds or longer.

● Recalling a station with ISR

In any mode, press the [ISR] button to turn on the radio function and tune the selected radio station. "ISR" appears in the display. Press the [ISR] button again to return to the previous mode.

Area change

Use this function when you are using the boat stereo anywhere outside the U.S.

Switchable frequency spacing

This boat stereo is initially set to tune in frequency intervals of 10kHz for AM and 200 kHz for FM, the standard calibrations in U.S. When using the unit outside the U.S., use the following procedure to switch the frequency range.

The table below lists the frequency specifications for the U.S. and other countries.

		Initial Setting (U.S. standard)	New Setting (Third Area/ Australia standard)	New Setting (Europe standard)
AM	Frequency Spacing	10 kHz	9 kHz	9 kHz
	Frequency Range	530 to 1710 kHz	531 to 1629 kHz	531 to 1602 kHz
FM	Frequency Spacing	200 kHz	50 kHz	50 kHz
	Frequency Range	87.9 to 107.9 MHz	87.0 to 108 MHz	87.5 to 108 MHz

Switching the area change

● Inside U.S. standard (Initial Setting)

While pressing the [♪] button, press the [SCN] button, then "U.S. standard" will be selected.

● Third Area/Australia standard (New Setting)

While pressing the [♪] button, press the [RPT] button, then "Third Area/Australia standard" will be selected.

● Europe standard (New Setting)

While pressing the [♪] button, press the [RDM] button, then "Europe standard" will be selected.

CD/MP3/WMA Mode Operations

What is MP3?

MP3 is an audio compression method and classified into audio layer 3 of MPEG standards. This audio compression method has penetrated into PC users and become a standard format. This MP3 features the original audio data compression to about 12 percent of its initial size with a high quality sound. This means that about 10 music CDs can be recorded on a CD-R disc or CD-RW disc to allow a long listening time without having to change CDs.

What is WMA?

WMA is the abbreviation of Windows Media Audio, an audio file format developed by Microsoft Corporation.

Notes:

- WMA file with DRM (Digital Rights Management) will be skipped from being playback and jump to the next track.
- Windows Media™, and the Windows® logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

● To disable DRM (Digital Rights Management):

1. When using Windows Media Player 9, click on TOOL → OPTIONS → MUSIC RECORD tab, then under Recording settings, unclick the check box for RECORD PROTECTED MUSIC. Then, reconstruct files.
2. When using Windows Media Player 10/11, click on TOOL → OPTIONS → RIP MUSIC tab, then under Rip settings, unclick the check box for COPY PROTECT MUSIC. Then, reconstruct files.

Note:

- Personally constructed WMA files are used at your own responsibility.
- **Precautions when creating MP3/WMA disc**
- Usable sampling rates and bit rates:

MP3	
Decode Format	MPEG 1, 2 and 2.5 - Layer 3
Sampling Rate (kHz)	MPEG-1 : 32, 44.1, 48 MPEG-2 : 16, 22.05, 24 MPEG-2.5 : 8, 11, 025, 12
Bit-rate (kbps)	MPEG-1 : 32 - 320 MPEG-2 : 8 - 160 MPEG-2.5 : 8 - 160 VBR
WMA	
Sampling rate (kHz)	48, 44.1, 32
Bit-rate (kbps)	32 - 192

- Folder Level Limit : 8 Level
- Max. Folder Support : 128
- Max. Files Support : 254
- Folder Name : Max. 28 Characters
- File Name : Max. 28 Characters

● File extensions

- Always add a file extension “.MP3” or “.WMA” to MP3 or WMA file by using single characters letters. If you add a file extension other than specified or forget to add the file extension, the file cannot be played.

● Logical format (File system)

1. When writing MP3/WMA file on a CD-R disc or CD-RW disc, please select “**ISO9660 level 1, 2 or JOLIET or Romeo**” as the writing software format. Normal play may not be possible if the disc is recorded on another format.
2. The folder name and file name can be displayed as the title during MP3/WMA play but the title must be within 28 single byte alphabetical letters and numerals (including an extension) respectively.
3. Do not affix a name to a file inside a folder having the same name.

● Folder structure

1. A disc with a folder having more than 8 hierarchical levels will be impossible.

CD/MP3/WMA Mode Operations

● Number of files or folders

- Up to 254 files can be recognized per folder.
Up to 254 files can be played.
- Tracks are played in the order that they were recorded onto a disc. (Tracks might not always be played in the order displayed on the PC.)
- Some noise may occur depending on the type of encoder software used while recording.

CD-DA/MP3/WMA selection on multi-session CD

- If a multi-session CD which contains CD-DA and MP3/WMA files is being inserted, user can select either CD-DA or MP3/WMA files to be played.
- Default setting for files to be played on multi-session CD is CD-DA files.
- Press the [BND] button for more than 1 second will toggle between selection of CD-DA and MP3/WMA files to be played.
- When CD-DA type is selected, display will show "M-SESS" then "CD". When MP3/WMA type is selected, display will show "M-SESS" then "MP3".
- CD-DA/MP3/WMA selection function can only be performed in CD/MP3/WMA mode. It will only activate after re-insert CD. For example, current setting is CD-DA type. Press [BND] button for more than 1 second to set MP3/WMA type. User has to eject CD and re-insert again as to play MP3/WMA files.
- Types of recording that can be played are as follows.

Disc \ Setting	Set to CD	Set to MP3/WMA
Mixed with CD-DA and MP3/WMA type tracks	Play CD-DA	Play MP3/WMA
CD-DA type track only	Play CD-DA	Play CD-DA
MP3/WMA type track only	Play MP3/WMA	Play MP3/WMA

- When a Mixed mode CD is loaded and CD is set, the track to be played first is MP3/WMA file data and no sound is heard.

Note:

- When playing a CCCD (Copy Control CD), set the setting to CD type. When this is set to MP3/WMA type, the CD cannot be played normally in some cases.

CAUTION

- Do not try to put your hand or fingers in the disc insertion slot. Also never insert foreign objects into the slot.
- Do not insert discs where adhesive comes out from cellophane tape or a rental CD label, or discs with marks where cellophane tape or rental CD labels were removed. It may be impossible to extract these discs from the unit and they may cause the unit to break down.
- This unit is designed for play of 12cm compact disc only. Do not attempt to use 8cm CD singles in this unit, either with or without an adaptor, as damage to the player and/or disc can occur. Such damage will not be covered by the warranty on this product.

Backup eject function

Pressing the [▲] button ejects the disc even if the power to the unit was not turned on. Remove the disc after it is ejected.

Notes:

- If you force a CD into before auto reloading, this can damage the CD.
- If a CD (12 cm) is left in the ejected position for 15 seconds, the CD is automatically reloaded (Auto reload).

Listening to a disc already loaded in the unit

Press the [SRC] button to select the CD/MP3/WMA mode. "CD/MP3" will be displayed.

When the unit enters CD/MP3/WMA mode, play starts automatically.

Radio → CD/MP3/WMA → AUX → Radio...

Note:




- The default display is Main Display (Track No./ Play Time).

CD/MP3/WMA Mode Operations

Loading a CD

Insert a CD into the center of the CD SLOT with the labeled side facing up. "LOADING" appears in the display, the CD plays automatically after loading.

Notes:

- When the unit enters the CD/MP3/WMA mode, "FILEREAD" will be displayed to check the disc type and its contents.
- If the inserted disc is a CD-DA format, "CD" will be displayed for a while. However, if the inserted disc is a MP3/WMA format, "MP3" will be displayed for a while. MP3/WMA indicator will be lit on according to type of file detected.
 -  indicator will be lit on if MP3 file is detected.
 -  indicator will be lit on if WMA file is detected. Then, the first track will be played automatically.
- If the CD is not inserted easily, there may be another CD in the mechanism or the unit may require service.
- Discs not bearing the  mark cannot be played by this unit.
- Some CDs recorded in CD-R/CD-RW mode may not be usable.

Ejecting the CD

Press the [▲] button, then the CD will be ejected.

Notes:

- If there is no disc loaded, the indication "NO DISC" appears in the display and return to Radio mode after 4 seconds.
- If the CD is not removed after ejecting, CD will be automatically reloaded after 15 seconds and this will not automatically switch to CD/MP3/WMA mode.

Pausing play

- Press the [▶||] button to pause current playback. "PAUSE" appears in the display.
- To resume CD play, press the [▶||] button again.


Display selection

- You can choose the display type for CD-DA or MP3/WMA disc by pressing the [D] button. To select the next type, press the [D] button again.

The arrangement is shown below.

● CD-DA disc


Main-1 Display (Track No., Play Time) →
Clock Display → Main-1 Display...



● MP3/WMA disc

Main-1 Display (Track No., Play Time) →
Main-2 Display (Folder No., Play Time) →
Track → Folder → Title Tag → Album Tag →
Artist Tag → Clock Display → Main-1 Display...

where Track, Folder, Title Tag, Album Tag and Artist Tag are called Title Display.



Note:


- Each of the items in Title Display will display "TRACK", "FOLDER", "TITLE", "ALBUM" or "ARTIST" respectively for 2 seconds before showing related title information.

CD/MP3/WMA Mode Operations

Title display

- There are 5 types of display for the Title Display.

The arrangement is shown below.



- If a MP3/WMA file does not support for ID3 TAG or the file is encoded with ID3 TAG header that does not consist of any TAG information, the display will show "NO TITLE".

Notes:

- The folder name will be displayed as "ROOT" which the file allocates in the root folder.
- For MP3, it supports ID3 Tags V2.4/2.3/2.2/1.1/1.0.
- The MP3 player decodes each file ID3 TAG ver 2 by default, if ID3 TAG ver 2 is unavailable, ID3 TAG ver 1 will be decoded.
- UNICODE ID3 (Chinese, Japanese and etc) is not supported. Only ASCII characters can be displayed in Tags.
- If ID3 has Japanese or Chinese character, "*" will be displayed as substitution.

Selecting a track

● Track-up

- Press the [▶▶1] button to move to the beginning of the next track.
- Each time the [▶▶1] button is pressed, playback proceeds to another track in the advancing direction.

● Track-down

- Press the [◀◀1] button to move the beginning of the current track.
- Press the [◀◀1] button twice to move to the beginning of the previous track.

Fast-forward/fast-backward

● Fast-forward

Press and hold the [▶▶▶] button for 1 second or longer.

● Fast-backward

Press and hold the [◀◀◀] button for 1 second or longer.

- For Audio CD mode pressing the [◀◀, ▶▶] button for 1 second or longer will move forward or backward 5 times faster than normal play, and pressing it for 3 seconds or longer will do the operation 30 times faster.
- For MP3/WMA mode pressing the [◀◀, ▶▶] button for 1 second or longer will move forward or backward 5 times faster than normal play, and pressing it for 3 seconds or longer will do the operation 10 times faster.


MP3/WMA playing order

When selected for play folder up down functions, files and folders are accessed in the order in which they were written by the CD-ROM writer. Because of this, the order in which they are expected to be played may not match the order in which they are actually played. You may be able to set the order in which MP3/WMA are to be played by writing them onto a medium such as a CD-R with their file names beginning with play sequence numbers such as "01" to "99", depending on your CD writer.

For example, a medium with the following folder/file hierarchy is shown below.

CD/MP3/WMA Mode Operations

Example of a medium's folder/file hierarchy




Folder select

This function allows you to select a folder containing MP3/WMA files and start playing from the first track in the folder.

1. Press the [DN] or the [UP] button.

Press the [DN] button to move the previous folder. Press the [UP] button to move the next folder.



- * Press the [UP] button while in the final folder to shift to the first folder.
- * Folder without an MP3/WMA file is not selectable.
- * Folder name will be displayed for a while.

2. Press the [◀▶] button to select a track.

Top function

The top function resets the CD player to the first track of the disc. Press the [BND] button to play the first track (Track No. 1) on the disc.

- * In case of MP3/WMA, the first track of a folder being played will be returned.

Other various play functions

● Scan play

CD-DA:

This function allows you to locate and play the first 10 seconds of all the tracks recorded on a disc.

MP3/WMA:

This function allows you to locate and play the first 10 seconds of all the tracks in the current folder.

1. Press the [SCN] button to perform scan play. "TRK SCN" appears in the display while the "SCN" indicator lights in the display.

- * Scan play starts from the next track after the track currently being played.
- * Scan play will proceed to next folder after all the tracks in the current folder have been scanned.

● All scan play

MP3/WMA:

This function allows you to locate and play the first 10 seconds of the first track of all the folders on an MP3/WMA disc.

1. Press and hold the [SCN] button for 1 second or longer to perform folder scan play.

"ALL SCN" appears in the display while the "ALL" and "SCN" indicators light in the display.

- * All scan play starts from the first track of next folder after the track currently being played.

CD/MP3/WMA Mode Operations

● Repeat play

CD-DA, MP3/WMA:

This function allows you to play the current track repeatedly.

1. Press the **[RPT]** button to perform repeat play.
“**TRK RPT**” appears in the display while the “**RPT**” indicator lights in the display.

● All repeat play

MP3/WMA:

This function allows you to play all tracks in the MP3/WMA folder repeatedly.

1. Press and hold the **[RPT]** button for 1 second or longer to perform folder repeat play.
“**ALL RPT**” appears in the display while the “**ALL**” and “**RPT**” indicators light in the display.

● Random play

CD-DA:

This function allows you to play all tracks recorded on a disc in a random order.

MP3/WMA:

This function allows you to play all tracks of current folder in a random order.

1. Press the **[RDM]** button to perform random play.
“**TRK RDM**” appears in the display while the “**RDM**” indicator lights in the display.
* Random play will proceed to next folder after all the tracks in the current folder have been played.

● All random play

MP3/WMA :

This function allows you to play all the tracks of all the folders recorded on an MP3/WMA disc in a random order.

1. Press and hold the **[RDM]** button for 1 second or longer to perform folder random play.
“**All RDM**” appears in the display while the “**ALL**” and “**RDM**” indicators light in the display.

● To cancel play

1. Press the operating button previously selected.

8. OTHER OPERATIONS

Adjustment Mode

1. Press and hold the [D] button for more than 1 second to switch to the adjustment selection display.
2. Press the [◀▶] button to select the "item name".
 "CLOCK" ↔ "SCROLL" ↔ "AUX SENS"
 ↔ "TEL-SP" ↔ "TEL-SW"
 * Some of the items will have **ENT** indicator light on, the [▶▶] button must be pressed to display the setting value.
3. Turn the [ROTARY] knob to select the "desired setting value".
 * After completing settings, press the [D] button to return to the previous mode.

● Adjusting clock setting

- 2-1. Select "CLOCK".
- 3-1. Press the [▶▶] button
- 3-2. Press [◀▶] button to toggle HOUR and MINUTE selection. the HOUR is selected and blinking by default.
- 3-3. Turn the [ROTARY] knob clockwise to increase hour/minute or counterclockwise to decrease hour/minute.
- 3-4. Press the [▶▶] button to confirm the clock setting. The display will show "MEMORY" to indicate the setting has been stored and return to "CLOCK".

Note:

- If you remove the boat's battery for a check or repair, the clock will be reset, so user must set it again.

● Setting the method for title scroll

Set auto scroll function for MP3/WMA title.

- * The factory default setting is "ON".

- 2-1. Select "SCROLL".
- 3-1. Turn the [ROTARY] knob to select "ON" or "OFF".
 ● **ON:**
 To scroll automatically.
 ● **OFF:**
 To scroll just 1 time when the title was changed.

● Selecting AUX IN sensitivity

Make the following settings to select the sensitivity when sounds from external devices connected to this unit are difficult to hear even after adjusting the volume.

- * The factory default setting is "MID".

2-1. Select "AUX SENS".

- 3-1. Turn the [ROTARY] knob to select "LOW", "MID" or "HIGH".

● Setting the car speaker output for the cellular phone

- * The factory default setting is "RIGHT".

* To output the telephone calls, set the cellular phone interrupt to ON.

2-1. Select "TEL-SP".

- 3-1. Turn the [ROTARY] knob to select "RIGHT" or "LEFT".

Note:

- For telephone interrupt, AUX SENS is always "MID".

● "RIGHT"

Telephone calls can be heard on the front right speaker connected to this unit.

● "LEFT"

Telephone calls can be heard on the front left speaker connected to this unit.

● Cellular phone interrupt setting

If you connect this unit and your cellular phone with a separately sold unit, you can listen to your telephone calls on your boat speakers.

- * The factory default setting is "OFF".

2-1. Select "TEL-SW".

- 3-1. Turn the [ROTARY] knob to select the setting.

Each time you turn the [ROTARY] knob, the setting changes in the following order:

OFF ↔ ON ↔ MUTE.

● OFF:

This unit continues normal operation even when the cellular phone is used.

● ON:

You can listen to your telephone calls from the speakers connected to this unit.

Other Operations


- **MUTE:**

The sound from this unit is muted during telephone calls.

Notes:

- This unit requires hands-free kit that supports [**AUX**] input as a source of cellular phone audio input. Please consult your local authorized Clarion dealer for more information on the handsfree kit offered.
- If connecting a hands-free kit, please ensure the setting is ON to receive the telephone audio through the system.
- When listening to your calls on your car speakers, you can adjust the volume by turning the [**ROTARY**] knob, it will be memorized as new telephone volume.
- The factory default setting for this volume is "**VOL 15**".
- This unit requires special wiring to mute the audio signal automatically when a cellular telephone rings in the boat.
- This function is not compatible with all cellular telephones. Please contact your local authorized Clarion dealer for information on proper installation and compatibility.

9. TROUBLESHOOTING

	Problem	Cause	Measure
General	Power does not turn on. (No sound is produced)	Fuse is blown.	Replace with a fuse of the same amperage. If the fuse blows again, consult your store of purchase.
		Incorrect wiring.	Consult your store of purchase.
	No sound output when operating the unit with amplifiers or power antenna attached.	Power antenna lead is shorted to ground or excessive current is required for remote-on the amplifiers or power antenna.	<ol style="list-style-type: none"> 1. Turn the unit off. 2. Remove all wires attached to the power antenna lead. Check each wire for a possible short to ground using an ohm meter. 3. Turn the unit back on. 4. Reconnect each amplifier remote wire to the power antenna lead one by one. If the amplifiers turn off before all wires are attached, use an external relay to provide remote-on voltage (excessive current required).
	Nothing happens when button are pressed. Display is not accurate.	The microprocessor has malfunctioned due to noise, etc.	Turn off the power, then press the [RELEASE] button and remove the DCP. Press the reset button for about 2 seconds with a thin rod.  Reset button
		DCP or main unit connectors are dirty.	Wipe the dirt off with a soft cloth moistened with cleaning alcohol.
	No sound heard.	The speaker protection circuit is operating.	<ol style="list-style-type: none"> 1. Turn down sound volume. Function can also be restored by turning the power off and on again. (Speaker volume is reduced automatically when the speaker protection circuit operates). 2. If the sound is muted again, consult our service department.

	Problem	Cause	Measure
CD/MP3/WMA	No sound heard.	MP3/WMA files are absent in a disc.	Write MP3/WMA files onto the disc properly.
		Files are not recognized as an MP3/WMA file.	Use MP3/WMA files encoded properly.
		File system is not correct.	Use ISO9660 level 1, 2 or JOLIET or Romeo file system.
	Sound skips or is noisy.	Disc is dirty.	Clean the disc with a soft cloth.
		Disc is heavily scratched or warped.	Replace with a disc with no scratches.
	Sound is cut or skipped. Noise is generated or noise is mixed with sound.	MP3/WMA files are not encoded properly.	Use MP3/WMA files encoded properly.
	Sound is bad directly after power is turned on.	Water droplets may form on the internal lens.	Let dry for about 1 hour with the power on.
Wrong filename.	File system is not correct.	Use ISO9660 level 1, 2 or JOLIET or Romeo file system.	

10. ERROR DISPLAYS

	Error Display	Cause	Measure
CD/MP3/WMA	ERROR 2	A DISC is caught inside the CD deck and is not ejected.	This is a failure of CD deck's mechanism and consult your store of purchase.
	ERROR 3	A DISC cannot be played due to scratches, etc.	Replace with a non-scratched, non-warped-disc.
	ERROR 6	A DISC is loaded upside-down inside the CD deck and does not play.	Eject the disc then reload it properly.

11. SPECIFICATIONS

FM tuner

Frequency Range:

USA: FM 87.9-107.9MHz

Europe: FM 87.5-108MHz

Third Area/Australia: FM 87.0-108MHz

Usable Sensitivity: 11 dBf

50 dB Quieting Sensitivity: 17 dBf

Alternate Channel Selectivity: 75 dB

Stereo Separation (1 kHz): 35 dB

Frequency Response (± 3 dB): 30 Hz to 15 kHz

AM tuner

Frequency Range:

USA: AM 530-1710kHz

Europe: AM 531-1602kHz

Third Area/Australia: AM 531-1629kHz

Usable Sensitivity: 25 μ V

CD player

System: Compact disc audio system

Usable Discs: Compact disc

Frequency Response: 10 Hz to 20 kHz (± 3 dB)

Signal-to-Noise Ratio: 85 dB (1 kHz) IHF-A

Dynamic Range: 87 dB (1 kHz)

Harmonic Distortion: 0.01%

Audio

Maximum Power Output: 200 W (50 W X 4 ch)

Continuous Average Power Output:

17 W X 4, into 4 Ω , 20 Hz to 20 kHz, 1%THD

Bass Control Action (100 Hz): ± 14 dB

Treble Control Action (10 kHz): ± 14 dB

Line Output (with A/C 1 kHz, 10 k Ω): 1.8 V

General

Power Supply Voltage:

14.4 V DC (10.8 V to 15.6 V allowable), negative ground

Current Consumption: Less than 15 A


Speaker Impedance: 4 Ω (4 Ω to 8 Ω allowable)

Weight: 2.42 lb. (1.1 kg)

Dimensions:

178 mm Width X 50 mm Height X 152 mm

Depth



Notes:

- Specifications comply with JEITA Standards.
- Specifications and design are subject to change without notice for further improvement.
- Please make sure when connecting external power amplifier, that you properly, to the car chassis, ground the amplifier.
- If this is not done, severe damage to the source unit may happen.



Power Output:

21 W RMS x 4 Channels at 4 Ω and $\leq 1\%$ THD+N

Signal to Noise Ratio:

87 dBA (reference: 1 W into 4 Ω)

clarion

clarion ■

// High-Tech High-Touch //

» DICHIARAZIONE DI CONFORMITA' «
(D.M. 28 agosto 1995, no548)

Io, Fabbricante / Mandatario nell'UE

**Clarion Europa GmbH
Hessenring 19-21
64546 Mörfelden-Walldorf**

Dichiaro che il prodotto

**AM/FM Ricevente di suono radiodiffusione con CD
M275**

è conforme alle disposizioni contenute nel suddetto decreto relativamente alla prevenzione e l'eliminazione dei disturbi radioelettrici provocati dai ricevitori di radiodiffusione sonora e televisiva.

Io, Fabbricante / Mandatario nell'UE

Data 31 Gennaio 2007

**Clarion Europa GmbH
Hessenring 19-21
64546 Mörfelden-Walldorf**

Firma *Susumu Yawabara*

PBL No 07IRMR004M

IDCFMTFWLH002C

clarion

TEL :+49-6105-977-0
FAX :+49-6105-977-399



CE DECLARATION OF CONFORMITY

We, **Clarion Europa GmbH**

(supplier's name)

Hessenring 19-21, 64546 Mörfelden-Walldorf, GERMANY

(address)

declare under our sole responsibility that the product

AM/FM Broadcast Receiver with CD Player:

MODEL: M275

Product code: PE3008

(name, type or model, possibly sources and numbers of items)

to which this declaration relates is in conformity with the following
standard(s) or other normative document(s)

EN 55013:2001 + A1, EN 55020:2002 + A1

(title and/or number and date of issue of the standard(s) or
other normative document(s))

(if applicable) following the provisions of **89/336/EEC** Directive.

Product Family

Basic Model and Name: AM/FM Car Radio with CD Player

Difference: Trim and Use for only Recreational Craft;

(supplier's comment)

Mörfelden-Walldorf GERMANY

Susumu Yamakawa

31 JAN 2007

President

(Place and date of issue)

(name and signature or equivalent

marking of authorized person)

RefNo 07MRJN004 **D.FDQC07A009**



TEL :+49-6105-977-0
FAX :+49-6105-977-399

Clarion Co., Ltd.

All Rights Reserved. Copyright © 2007: Clarion Co., Ltd.
Printed in Malaysia / Imprimé en Malaisie / Stampato in Malaysia / Impreso en Malasia

PE-3008B
280-8544-00

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>