



# XPress™ Ethernet Bridge Multipoint: User Guide

---

## Overview

The XPress Ethernet Bridge (XEB) replaces costly wiring with a solution that can enable industrial Ethernet PLCs, electronic (LED) signs, remote Wi-Fi APs, Pan/Tilt/Zoom security cameras, VoIP phones, Internet kiosks and more. With a range of up to 15 miles (line-of-sight with a high gain antenna) and the ability to transmit through as many as 10 standard walls, the XEB uses the added range and capabilities of the 900 MHz band to communicate where Wi-Fi and other wireless data products fall short.

## Contents

- 1 XEB RF Modem: XEB09-BCS = Commercial (Indoor), XEB09-BIS = Industrial (Outdoor)

### Accessories Kit also includes:

- 1 Half-wave, 2.5 dBi dipole antenna
- 1 6VDC/110VAC power adapter (Commercial only)
- 1 12VDC/110VAC power adapter (Industrial only)
- 1 Power over Ethernet injector (Industrial only)
- 1 XEB Multipoint manual

## How It Works

The XEB radios allow you to create a long range, wireless Ethernet network for up to 16 Subscriber Units (SU) per Access Point (AP). The AP automatically scans for the best of the 12 available radio channels. Then it encrypts Ethernet data received from the network and transmits it wirelessly to the correct SU. The AP is constantly monitoring the network performance and automatically changes channels if the performance is hindered because of interference.

Select any of the 12 radio channels by toggling DIP switch settings. (See DIP Settings for additional information.) It is possible to operate up to 12 APs in the same area with each AP on a different channel. To avoid interference, space the APs at least 10 feet apart. Typically, the AP is attached to the wired network via an Ethernet Cable. The Auto MDI/MDIX feature on each XEB will work with either a straight through or crossover network cable.

**Note:** The AP does not have a MAC/IP address.

Any 10BaseT Ethernet Client Device (ECD) can be connected to an XEB SU. Each SU encrypts Ethernet traffic received from the attached ECD and transmits the data wirelessly to its AP. You can plug each SU directly into an ECD without need for any drivers or loading software on the ECD. Crossover cables are never needed.

You can only attach one ECD to each SU. The DIP switches on the SU should be in the default OFF setting. To avoid overloading the radio's receiver, place the SU at least 10 feet from the AP. 100-foot spacing is recommended if using high-gain antennas.

**Note:** The SU does not have its own MAC/IP address.

XEB radios use electronic network keys that allow you to group radios together to form a network. Network keys are shared between radios by connecting an Ethernet Cable between the RJ45 ports while the radios are in "key exchange mode" (radios that are in "key exchange mode" display the 6 LINK QUALITY LEDs blinking sequentially back and forth).

## Creating the Network

To share the keys and to create the network, follow these steps:

1. Select which radio will be the AP by setting DIP switch 1 ON.
  - The other radios will function as SUs and do not require any DIP settings.
2. Connect an Ethernet Cable from the AP to each SU to transfer the network keys.
  - For the Industrial/Outdoor XEB, the key exchange will occur through an Ethernet cable attached to the supplied POE injector. Key exchange will not work through a switch or hub.

Once the key sharing is complete, the AP and SU change their LED displays in confirmation of the successful programming:

The SU blinks one of the GREEN LINK QUALITY LEDS.

The AP illuminates the LED labeled RF RX, and the AP remains in "key exchange mode."

You can add additional SUs to the network or reprogram an SU to join a different network. Likewise, an SU can be changed into an AP and an AP into an SU. If DIP 1 is accidentally toggled, it can be turned back, and the radio still retains all the network associations it had in its previous mode (assuming that the radio had not yet successfully key exchanged with a new network). You can reset an AP by programming it as an SU and then turning it back into an AP again.

SUs that have not yet received a network key boot up in "key exchange mode" and wait to receive a key. SUs that have received a network key will boot-up for 5 seconds in "key exchange mode" and will look to see if a new AP is present. If a new AP is present, then the SU exchanges keys with the AP; otherwise, the SU begins normal operation after the 5 seconds.

APs that have not yet issued network keys boot up in "key exchange mode" until they have issued network keys to at least 1 SU. Once the AP has issued keys, it will only boot-up for 5 seconds in "key exchange mode." If an SU is present during the 5 seconds, then the AP will issue new keys to the SU and will then remain in "key exchange mode" waiting for more SUs to be attached. Once all new SUs have been attached, the AP must be power cycled. The AP will boot-up and after 5 seconds of "key exchange mode," it will enter normal operation.

## LED Display

Name	Function	Color
Power	Unit has power and has successfully booted.	Red
RFTX	Radio transmission is occurring.	Green
RFRX	Radio reception is occurring.	Green
Eth Link	The Ethernet Port has a valid Ethernet connection.	Green
1	By adding the numbers that are lit the user can determine the current radio channel. 1 903.12500 MHz 2 905.20833 MHz 3 907.29167 MHz 4 909.37500 MHz 5 911.45833 MHz 6 913.54167 MHz 7 915.62500 MHz 8 917.70833 MHz 9 919.79167 MHz 10 921.87500 MHz 11 923.95833 MHz	Green
2		
4		
8		
16		
32		

Name	Function	Color
	12 926.04167 MHz	
Link Quality Meter: The more LEDs that are lit the higher the link quality. or "Key exchange mode" when blinking sequentially	Excellent link quality No retransmissions	Green
	Very good link quality Few retransmissions	Green
	Good link quality Occasional retransmissions	Amber
	Fair link quality Some retransmissions	Amber
	Poor link quality Many retransmissions	Red
	No link quality No link available	Red

## Initial Setup

Use the following procedure to perform an initial setup:

1. Select the radio that will operate as the AP and set DIP switch 1 ON to enable the AP operation.
2. Plug in the AP:
  - The LINK QUALITY LEDs will blink sequentially showing that the radio is hunting for an SU to share keys with.
3. Plug in an SU:
  - The LINK QUALITY LEDs will blink sequentially showing the radio is hunting for an AP to supply a network key.
4. Connect an Ethernet cable from the AP to the SU and the units will automatically exchange keys over the Ethernet cable. (A key exchange will not work through a switch or hub. Crossover cables are not required.)
  - On the AP, the LINK QUALITY LEDs will show that the radio is still in "key exchange mode" and the RF TX LED will be lit showing that the keys exchanged successfully. Ignore the other LEDs.
  - On the SU, the LINK QUALITY LEDs no longer blink sequentially and will show that the radio has stopped hunting and now has a slowly blinking pulse on one of the GREEN LINK QUALITY LEDs. Ignore the other LEDs.
5. Repeat steps 3 and 4 until all SUs are successfully programmed.
6. Power cycle all radios for the new keys to take effect.
7. Deploy the radios.

## Adding New Subscriber Units to the Access Point

Use the following procedure to add new SUs to an AP:

1. Disconnect the AP from the network and disconnect power from the AP.
2. Connect an Ethernet cable from the AP to the SU. (A key exchange will not work through a switch or hub. Crossover cables are not required.)
3. Plug in the new SU then plug in the AP. The units will automatically exchange keys over the Ethernet cable.
4. Repeat steps 2 and 3 until all SUs are successfully programmed.
5. Power cycle all radios for the new keys to take effect.
6. Reconnect the AP to the Network and deploy the new SUs.

## To Re-key a Subscriber Unit to a New Access Point

---

Use the following procedure to re-key an SU to an AP:

1. Select the radio that will operate as the AP and set DIP switch 1 ON to enable Access Point operation.
2. Plug in the new AP.
3. Connect an Ethernet cable from the AP to the SU (key exchange will not work through a switch or hub – crossover cables are not required).
4. Plug in the SU.
5. Repeat steps 3 and 4 until all SUs are successfully programmed.
6. Power cycle all radios for the new keys to take effect.
7. Deploy the radios.

## DIP Settings

---

### DIP 1

---

AP or SU

- By selecting DIP 1 ON, the radio will operate as an AP.
- By selecting DIP 1 OFF, the radio will operate as an SU.

### DIP 2

---

<Manufacturer test mode - no end user functionality>

### DIP 3-8

---

**Automatic frequency selection mode** (DIP 3-8 OFF for automatic mode):

The XEB radios are designed to automatically select and continuously optimize the performance of their radio channel with frequency agility techniques. The radio channel is monitored to ensure it is providing low error rates necessary for successful data transmission. In the event that the error rate rises, the AP will automatically change to a new channel. The SUs will follow. There are 12 non-overlapping channels.

Frequency agility is turned on by default. It is recommended because it offers an RF communication channel that is highly resilient to interference. For example, in VOIP and CCTV applications, wideband technologies like Wi-Fi can get slowed or stopped by heavy interference. The XEB, in contrast, has more consistent throughput due to its narrow bandwidth at a higher power output, plus frequency agility to move to an unused section of the frequency band.

**Manual frequency selection mode:**

The operation of the XEB radios can be restricted to a specific channel within the 902-928 MHz band by setting DIP switches 3-8 on the AP as shown in the table below. The SU responds to the AP's choice of channel, and its DIP switch has no effect and does not need to be selected.

### Channels and Settings

---

Channel	DIP Setting	Center Frequency
1	3 On / 4 Off / 5 Off / 6 Off	903.12500 MHz
2	3 Off / 4 On / 5 Off / 6 Off	905.20833 MHz
3	3 On / 4 On / 5 Off / 6 Off	907.29167 MHz
4	3 Off / 4 Off / 5 On / 6 Off	909.37500 MHz
5	3 On / 4 Off / 5 On / 6 Off	911.45833 MHz
6	3 Off / 4 On / 5 On / 6 Off	913.54167 MHz
7	3 On / 4 On / 5 On / 6 Off	915.62500 MHz
8	3 Off / 4 Off / 5 Off / 6 On	917.70833 MHz
9	3 On / 4 Off / 5 Off / 6 On	919.79167 MHz
10	3 Off / 4 On / 5 Off / 6 On	921.87500 MHz
11	3 On / 4 On / 5 Off / 6 On	923.95833 MHz
12	3 Off / 4 Off / 5 On / 6 On	926.04167 MHz

## Advanced Operation

Contact Digi Support if your application requires:

- Over 16 SUs per AP for roaming/mobility applications
- Multiple APs that use the same network key for roaming/mobility
- Low packet loss rates when using broadcast or multicast Ethernet packets.


Note: If possible, fixed IP addresses are recommended on your network. This is because broadcast and multicast packets (e.g., DHCP, UDP) are sent once and may experience losses at extended range.

Unicast packets (e.g., HTTP, TCP) are sent using advanced error correction and retransmission techniques to ensure delivery.

## Technical Specifications

Characteristic	Specification/Description
RF transmission rate	1.536 Mbps
Aggregate Throughput	935 Kbps
Output power	+21dBm
Receive sensitivity	-97dBm at IOe-4 BER
Ethernet Interface	RJ45 10BaseT, Auto MDI/MDIX
Radio channels	12 Non-overlapping
Automatic frequency select	Yes - radio channel automatically selected and adaptively optimized
Manual frequency select	Yes
Status LEDs	Power, RF TX, RF RX, Ethernet Link, 6/Channel and 6/Link Quality
Error correction technique	Sub-block error detection and retransmission
Adjacent-band rejection	SAW receiver filter attenuates cellular and pager interference.
Regulator type	XEB09-BCS uses Linear Regulator and XEB09-BIS uses Switching Regulator
Power consumption	Transmit: XEB09-BCS 2W XEB09-BIS 1.5W Receive: XEB09-BCS 1.2W XEB09-BIS 1.0W
Voltage	XEB09-BCS: 5-7 VDC XEB09-BIS: 9-48 VDC Power over Ethernet
Temperature range	-40 °C to 70 °C (-40 °F to 158 °F)
Current draw	XEB09-BCS: 350 mA  XEB09-BIS: 150mA at 9VDC 110mA at 12VDC 32mA at 48VDC
Radio Size	XEB09-BCS: 5.5 in (14.0 cm) x 3.4 in (8.5 cm) x 1.2 in (3.0 cm)  XEB09-BIS: 7.9 in (20.0 cm) x 3.2 in (8.0 cm) x 2.1 in (5.5 cm)
Regulatory Approvals	FCC ID (U.S. - Part 15.247) R4N-AW900M, IC ID (Canada) 5303A-AW900M

## Example Illustration



**Commercial (Indoor)  
radios can communicate  
with Industrial  
(Outdoor) radios.**

**Figure 1: A typical point-multipoint architecture**

### Limited Warranty

#### Warranty Period:

Digi warranties hardware Product for a period of five (5) years.

#### Warranty Procedure:

Upon return of the hardware Product Digi will, at its option, repair or replace Product at no additional charge, freight prepaid, except as set forth below. Repair parts and replacement Product will be furnished on an exchange basis and will be either reconditioned or new. All replaced Product and parts become the property of Digi. If Digi determines that the Product is not under warranty, it will, at the Customers option, repair the Product using current Digi standard rates for parts and labor, and return the Product UPS Ground at no charge in or out of warranty.

### FCC Compliance

#### Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

#### Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### RF Exposure

To comply with FCC RF exposure requirements for mobile transmitting devices, this transmitter should only be used or installed at locations where there is at least 20 cm separation distance between the antenna and all persons.

#### Information to the User - Part 15.105 (b)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. This product should be installed ONLY by experienced, professional installers who are familiar with local building and safety codes, and wherever applicable, are licensed by the appropriate authorities. Failure to do so may void the warranty and may expose the user or the service provider to legal and financial liabilities.

## Contact Digi

Phone: (801) 765-9885

Online Chat: [www.digi.com](http://www.digi.com)

e-mail: [support@digi.com](mailto:support@digi.com)

© Digi International Inc., 2007. Digi, Digi International, the Digi logo, and XPress are trademarks or registered trademarks of Digi International, Inc. in the United States and other countries worldwide.

90000888-B

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>