

# **Shaft Hedge Clipper Attachment**

Operator's Manual

MODEL 99944200485

MODELS USED ON: SRM-2100SB/2400SB

**SRM-210SB/211SB** 

**SRM-260SB/261SB** 

PAS 2100/2400

PAS 210/211

PAS 230/231

PAS 260/261

**PAS-2601** 

**PAS-265** 



### **WARNING**



Read rules for safe operation and instructions carefully. ECHO provides an Operator's Manual and a Safety Manual for Pro Attachment Series power source or Split Boom Trimmer. Those manuals and this manual must be read and understood for proper and safe operation, otherwise serious personal injury may result.

X7702091901 X770001131 11/09



### INTRODUCTION


Welcome to the ECHO family. This ECHO product was designed and manufactured to provide long life and on-the-job-dependability. Read and understand this manual and the SAFETY MANUAL you found in the same package. You will find both easy to use and full of helpful operating tips and SAFETY messages.

### THE OPERATOR'S MANUAL

Read and understand this manual before operation. Keep it in a safe place for future reference. It contains specifications and information for operation and maintenance specific to the attachment.

### THE SAFETY MANUAL

Explains possible hazards and what measures you should take to insure safe operation.



## TABLE OF CONTENTS

Testura des ati a co

Introduction	4
- The Operator's Manual	2
- The Safety Manual	
Safety	
- Manual Safety Symbols and Important	
Information	3
- International Symbols	
- Personal Condition and Safety Equipment	
- Equipment	
Description	
Contents	
Assembly	8
- Power Head / Drive Shaft	8
- Loop Handle Removal	9
Operation	
- Hedge Trimming	

Maintenance	10
- Skill Levels	10
- Maintenance Intervals	10
- Lubrication	10
- Sharpening Blades	12
- Blade Adjustment	
Storage	
Specifications	
Servicing Information	
- Parts/Serial Number	
- Service	16
- ECHO Consumer Product Support	16
- Warranty Card	
- Additional or Replacement Manuals	

Copyright© 2009 By Echo, Incorporated All Rights Reserved.

Specifications, descriptions and illustrative material in this literature are as accurate as known at the time of publication, but are subject to change without notice. Illustrations may include optional equipment and accessories, and may not include all

### SAFETY

### MANUAL SAFETY SYMBOLS AND IMPORTANT INFORMATION

Throughout this manual and on the product itself, you will find safety alerts and helpful, informational messages preceded by symbols or key words. The following is an explanation of those symbols and key words and what they mean to

### **DANGER**

The safety alert symbol accompanied by the word "DANGER" calls attention to an act or condition which WILL lead to serious personal injury or death if not avoided.



### WARNING

The safety alert symbol accompanied by the word "WARNING" calls attention to an act or condition which CAN lead to serious personal injury or death if not avoided.



### CAUTION

The safety alert symbol accompanied by the word "CAUTION" calls attention to an act or condition which may lead to minor or moderate personal injury if not avoided.



#### CIRCLE AND SLASH SYMBOL

This symbol means the specific action shown is prohibited. Ignoring these prohibitions can result in serious or fatal injury.

#### NOTE

This enclosed message provides tips for use, care and maintenance of the unit.

#### **IMPORTANT**

The enclosed message provides information necessary for the protection of the unit.

### INTERNATIONAL SYMBOLS

Symbol form/shape	Symbol description/application	Symbol form/shape	Symbol description/application
<b>®</b>	Read and understand Operator's Manual.		Wear Face Shield
	Wear eyes, ears and head protection		Finger Severing Hazard
علا	Wear slip resistant foot wear.		Wear hand protection. Use two handed.
	Hot Surface		DO NOT smoke near fuel. DO NOT allow flames
$\triangle$	Safety/Alert		or sparks near fuel.

Symbol form/shape	Symbol description/application	Symbol form/shape	Symbol description/application
A	Avoid all power lines. This unit is not insu- lated against electrical current.		Do not operate closer than 15 M (50 ft.) from electrical hazards.
15 M	Keep bystanders at least 15 meters (50 feet) away.	STOP	Emergency stop
	Engine choke control.	Ignition ON OFF O	Ignition ON/OFF
<b>H</b> ■►€	Primer bulb	Н	Carburetor adjustment - High speed mixture
L	Carburetor adjustment - Low speed mixture	T	Carburetor adjustment - Idle speed



### PERSONAL CONDITION AND SAFETY EQUIPMENT



### **WARNING**

Users of this product risk injury to themselves and others if the unit is used improperly and/or safety precautions are not followed. Proper clothing and safety gear must be worn when operating unit.

### **Physical Condition**

Your judgment and physical dexterity may not be good:

- if you are tired or sick,
- if you are taking medication,
- if you have taken alcohol or drugs.

Operate unit only if you are physically and mentally well.

### Eve Protection

Wear eye protection that meets ANSI Z87.1 or CE requirements whenever you operate the unit.

#### Hand Protection

Wear no-slip, heavy duty work gloves to improve your grip on the unit handles. Gloves also reduce the transmission of machine vibration to your hands.

### Hearing Protection

ECHO recommends wearing hearing protection whenever unit is used.

### **Proper Clothing**

Wear snug fitting, durable clothing;

- Pants should have long legs, shirts with long sleeves.
- DO NOT WEAR SHORTS,
- DO NOT WEAR TIES, SCARVES, JEWELRY.

Wear sturdy work shoes with non-skid soles;

- DO NOT WEAR OPEN TOED SHOES,
- DO NOT OPERATE UNIT BAREFOOTED.

Keep long hair away from engine and air intake. Retain hair with cap or net.

#### Hot Humid Weather

Heavy protective clothing can increase operator fatigue which may lead to heat stroke. Schedule heavy work for early morning or late afternoon hours when temperatures are cooler.

### Vibration and Cold

It is believed that a condition called Raynaud's Phenomenon, which affects the fingers of certain individuals, may be brought about by exposure to vibration and cold. Exposure to vibration and cold may cause tingling and burning sensations, followed by loss of color and numbness in the fingers. The following precautions are strongly recommended, because the minimum exposure which might trigger the ailment is unknown.

- Keep your body warm, especially the head, neck, feet, ankles, hands, and wrists.
- Maintain good blood circulation by performing vigorous arm exercises during frequent work breaks, and also by not smoking.
- Limit the hours of operation. Try to fill each day with jobs where operating the trimmer or other hand-held power equipment is not required.
- If you experience discomfort, redness and swelling of the fingers followed by whitening and loss of feeling, consult your physician before further exposing yourself to cold and vibration.




### Repetitive Stress Injuries

It is believed that overusing the muscles and tendons of the fingers, hands, arms and shoulders may cause soreness, swelling, numbness, weakness, and extreme pain in those areas. Certain repetitive hand activities may put you at a high risk for developing a Repetitive Stress Injury (RSI). An extreme RSI condition is Carpal Tunnel Syndrome (CTS), which could occur when your wrist swells and squeezes a vital nerve that runs through the area. Some believe that prolonged exposure to vibration may contribute to CTS. CTS can cause severe pain for months or even years.

To reduce the risk of RSI/CTS, do the following:

- Avoid using your wrist in a bent, extended, or twisted position. Instead, try to maintain a straight wrist position. Also, when grasping, use your whole hand, not just the thumb and index finger.
- Take periodic breaks to minimize repetition and rest your hands.
- Reduce the speed and force with which you do the repetitive movement
- Do exercises to strengthen the hand and arm muscles.
- Immediately stop using all power equipment and consult a doctor if you feel tingling, numbness, or pain in the fingers, hands, wrists, or arms. The sooner RSI/CTS is diagnosed, the more likely permanent nerve and muscle damage can be prevented.





### **DANGER**

Do not operate this product indoors or in inadequately ventilated areas. Engine exhaust contains poisonous emissions and can cause serious injury or death.

#### Read the Manuals

• Provide all users of this equipment with the Operator's Manual and Safety Manual for instructions on Safe Operation.

#### Clear the Work Area

 Spectators and fellow workers must be warned, and children and animals prevented from coming nearer than 15 m (50 ft.) while the unit is in use.

#### Keep a Firm Grip


• Hold the front and rear handles with both hands, with thumbs and fingers encircling the handles.

### Keep a Solid Stance

 Maintain footing and balance at all times. Do not stand on slippery, uneven or unstable surfaces. Do not work in odd positions or on ladders. Do not over reach.

#### **Avoid Hot Surfaces**

• Keep exhaust area clear of flammable debris. Avoid contact during and immediately after operation.







### **EQUIPMENT**



### **WARNING**

Use this attachment with ECHO approved models only. Serious injury may result from the use of this attachment combined with a non approved ECHO product.

Before operation a complete check of the unit must be performed;

- Check unit for loose/missing nuts, bolts and screws. Tighten and/or replace as needed.
- Never adjust blades when the engine is operating.
- Check that the blade assembly is firmly attached and in safe operating condition. Dull, loose or damaged blades should not be used.




### WARNING

Moving parts can amputate fingers or cause severe injuries. Keep hands, clothing and loose objects away from all openings.

- ALWAYS stop engine, disconnect spark plug, and make sure all moving parts have come to a complete stop before removing obstructions, clearing debris, or servicing unit.
- DO NOT start or operate unit unless all guards and protective covers are properly assembled to unit.
- NEVER reach into any opening while the engine is running. Moving parts may not be visible through openings.

### **D**ESCRIPTION

Locate this safety decal on your attachment. Make sure the decal is legible and that you understand and follow the instructions on it. If it cannot be read, a new one can be ordered from your ECHO dealer. See PARTS ORDERING instructions for specific information.



- 1. **BLADES** Double reciprocating blades mounted to a blade support bar. Double-sided blade is capable of cutting on either side of the blade.
- 2. **DRIVE SHAFT ASSEMBLY** Lightweight aluminum drive shaft extends reach. 4-position shaft design permits blade position to be rotated in 90-degree steps.
- 3. SAFETY DECAL Contains important safety information that must be followed. (See Page 3.)
- 4. **LEFT HAND SHAFT GRIP** Cushioned grip for left hand.
- 5. **GEAR HOUSING ASSEMBLY** -Commercial grade, low weight, fast cutting speed. Grease fitting simplifies lubrication.
- 6. BLADE COVER Used to cover blade during transport and storage. Remove blade cover before using unit.



### **CONTENTS**

The ECHO product you have purchased has been factory pre-assembled for your convenience.

After opening the carton, check for damage. Immediately notify your retailer or ECHO Dealer of damaged or missing parts. Use the contents list to check for missing parts.

1 - Shaft Hedge Clipper Attachment

1 - Operators Manual

1 - Safety Manual

1 - Warranty Card

1 - Blade Cover

1 - Storage Hook Assembly











### **A**SSEMBLY

### POWER HEAD SHAFT/LOWER SHAFT ASSEMBLY

Tools Required: None


Parts Required: PAS or SRM-SB Power Head w/Shaft & Coupling.


- 1. Set Power Head/Shaft Assembly on a level surface.
- 2. Pull locator pin (A) out, and turn counter-clockwise 1/4 turn to lock-out position.
- 3. Remove vinyl cap from attachment drive shaft.
- 4. Carefully fit attachment drive shaft assembly into coupler (B) to decal assembly line (C), making sure that the inner lower drive shaft engages into the square upper drive shaft socket.

#### **NOTE**

Earlier model Power Heads may have shorter couplings. Short couplings fit flush to decal point (E). New couplings are 4-3/4 in. long, and fit flush to line (C).

- 5. Select desired blade position by aligning one of the holes (F) in lower shaft with locator pin position.
- 6. Rotate locator pin (A) 1/4 turn clockwise to engage lower shaft hole. Insure locator pin is fully engaged by twisting lower drive shaft. Locator pin should snap flush in coupler. Full engagement will prevent further shaft rotation.
- 7. Secure lower shaft assembly to coupler by tightening clamping knob (D).





### FRONT LOOP HANDLE REMOVAL

Tools Required: Screwdriver.

Parts Required: None

#### NOTE

Front loop handles/loop handles with barrier bars are not recommended for use with Hedge Clipper attachment.

- 1. Remove front handle assembly, barrier bar (if installed), and mounting hardware from PAS or SRM-SB power head.
- 2. Retain parts for future use.



### **OPERATION**



### WARNING

Moving parts can amputate fingers or cause severe injuries. Keep hands, clothing and loose objects away from all openings. Always stop engine, disconnect spark plug, and make sure all moving parts have come to a complete stop before removing obstructions, clearing debris, or servicing unit. Wear gloves to protect hands from sharp edges and hot surfaces.

### **HEDGE TRIMMING**

- 1. Hold trimmer firmly and squeeze throttle trigger to accelerate engine.
- 2. Tilt trimmer so cutting teeth are angled slightly toward the hedge or shrub and proceed to cut.




### **WARNING**

Never remove hands from unit when blades are moving.



### WARNING

The engine continues running even when the blades have stopped due to an obstruction. If this occurs, stop the engine, disconnect ignition cable and remove the obstruction.





### **M**AINTENANCE



### WARNING

Moving parts can amputate fingers or cause severe injuries. Keep hands, clothing and loose objects away from all openings. Always stop engine, disconnect spark plug, and make sure all moving parts have come to a complete stop before removing obstructions, clearing debris, or servicing unit. Allow unit to cool before performing service. Wear gloves to protect hands from sharp edges and hot surfaces.

Your ECHO product is designed to provide many hours of trouble free service. Regular scheduled maintenance will help achieve that goal. If you are unsure or are not equipped with the necessary tools, you may want to take your unit to an ECHO Service Dealer for maintenance. To help you decide whether you want to DO-IT-YOURSELF or have the ECHO Dealer do it, each maintenance task has been graded.

#### SKILL LEVELS

**Level 1** = Easy to do. Common tools may be required.

**Level 2** = Moderate difficulty. Some specialized tools may be required.

#### MAINTENANCE INTERVALS

Component	Maintenance Procedure	Skill Level	Interval
Drive Shaft	Grease	1	Every 25 hours of use [1]
Gear Housing	Grease	1	Every 15-25 hours of use [1]
Screws/Nuts/Bolts	Inspect/Tighten/Replace	1	Before Each Use
Blades	Lubrication	1	Every 15-25 hours of use
Blades	Sharpen	2	As needed
Blades	Tighten Screws/Nuts	1	Every 40 hours of use

**IMPORTANT** - Time intervals shown are maximum. Actual use and your experience will determine the frequency of required maintenance.

[1] Apply POWER BLENDX<sup>TM</sup> Grease.

### **LUBRICATION**


#### Blades

Level 1

Tools Required: Clean rag, brush, oil can

Parts Required: 20W Engine Oil (lubrication), 50-50 mixture of

kerosene and 20W oil (cleaning).






### WARNING

Blades are very sharp. Wear gloves to protect hands, otherwise serious personal injury may result.

- 1. Brush loose debris from blade and coat both sides of blade with the 50-50 cleaning mixture.
- 2. Allow cleaning mixture to soften the remaining gummy residue then wipe it from the blade.
- 3. Apply clean oil to the entire length of the blade. Be certain the blade bolts are lubricated.
- 4. Wipe excess oil from the blade before putting the unit back in service.



### Gear Housing Assembly

### Level 2

Tools required: Grease gun, clean rag


Parts required: POWER BLENDX<sup>TM</sup> 14 oz. cartridge P/N 91015 or


Lithium Based Grease

- 1. Clean dirt from grease fitting (A).
- 2. Carefully pump grease in fitting. **<u>DO NOT</u>** force grease.

  Too much pressure will force grease past seals and cause damage.

  Apply 1-2 pumps of grease every 15-25 hours of operation.





### Drive Shaft Assembly

#### Level 1.


#### NOTE

Hedge Clipper drive shaft should be greased every 25 hours of operation.

Tools required: 4 mm hex wrench, clean rag, small brush

Parts required: **POWER BLENDX**<sup>TM</sup> 8 oz. (P/N 91014) or

Lithium Based Grease.








### **WARNING**

Blades are very sharp. Wear gloves to protect hands, otherwise serious personal injury may result.

- Remove gear housing locating screw (A) and loosen clamping screw (B). Remove the gear housing assembly from the drive shaft housing.
- 2. Pull the drive shaft (C) from the housing, wipe clean and re-coat with a thin coating [1/2 oz. (15 ml)] of grease.
- 3. Slide the flexible shaft back in the drive housing being careful not to get dirt on the flex shaft.
- 4. Slide Gear Housing Assembly onto Drive Shaft. Be certain the Flex Drive Shaft engages the hole in Driver Gear.







#### **IMPORTANT**

Flat edge of washers (D) must be against drive shaft.


- Align locating hole in gear housing with locator hole in drive shaft.
- 6. Install locating screw (A). Tighten clamping screw (B).

### SHARPENING BLADES

#### Level 2.

Tools required: Flat file, Screwdriver

Parts required: None





### **WARNING**


Hedge Clipper blades are very sharp. Touching them may lead to severe personal injury. Avoid touching blades whenever possible, and always wear gloves to protect hands.

- 1. Move stop switch to stop position.
- 2. Disconnect spark plug wire.
- 3. Slide blades to allow file clearance using slots (B) on bottom of blade. Do not pry against cutting edges.
- 4. File each edge carefully. Follow the original shape of the blade.

#### **IMPORTANT**

If a power grinder is used **DO NOT** allow blade to over heat.

5. Lubricate blades (see "Lubrication instructions").



#### **IMPORTANT**

Blades should only be removed and reinstalled by an Authorized ECHO Servicing Dealer, otherwise premature wear or internal damage may occur.

#### **BLADE ADJUSTMENT**

Level 2.

Tools Required: 8 mm Socket & Extension, 4mm Hex Wrench w/

extension

- 1. Move stop switch to STOP position.
- 2. Disconnect spark plug wire.




### WARNING

Hedge clipper blades are very sharp. Touching them may lead to severe personal injury. Use long hex wrenches and sockets with extensions when tightening blade screws and blade locknuts to keep hands at a safe distance from sharp blades.

- 3. Tighten blade screws (A) securely.
- 4. Hold blade screws (A) to prevent turning, and tighten locknuts (B).







### **S**TORAGE


#### **IMPORTANT**

Always install blade cover when transporting or storing unit.

- 1. Clean and lubricate cutting blades and gear case.
- 2. Sharpen cutting blades as required.
- 3. Apply a light coating of clean 20W engine oil along entire length of blades and on blade bolts.
- 4. Install blade cover onto hedge clipper cutting blades.
- 5. Store hedge clipper attachment in a dry, dust free place out of the reach of children, using supplied storage hook.

### Storage Hook Installation

- 1. Insert small end of hook into locating hole on attachment shaft.
- 2. Slide plastic cap onto end of attachment shaft.



### **S**PECIFICATIONS

MODEL ----- Shaft Hedge Clipper Attachment

Length ----- 1250 mm (49.21 in.)

Width ----- 83 mm (3.23 in.)

Weight----- 2.12 kg (4.68 lbs.)

Gear Case ------ 4.27:1

Cutter ----- Double Reciprocating Blade - Double Edge


Effective Length ----- 502 mm (19.76 in.)

Pitch----- 35 mm (1.4 in.)

Maximum Cut

Soft Materials ----- 25.4 mm (1 in.) Diameter

Woody Materials ----- 13 mm (1/2 in.) Diameter



### SERVICING INFORMATION

### PARTS/SERIAL NUMBER

Genuine ECHO Parts and ECHO REPOWER<sup>TM</sup> Parts and Assemblies for your ECHO products are available only from an Authorized ECHO Dealer. When you do need to buy parts **always** have the Model Number and Serial Number of the attachment with you. You can find these numbers on the driveshaft model/serial number label. For future reference, write them in the space provided below.

Model No. \_\_\_\_\_SN. \_\_\_\_

### **SERVICE**

Service of this product during the warranty period must be performed by an Authorized ECHO Service Dealer. For the name and address of the Authorized ECHO Service Dealer nearest you, ask your retailer or call: 1-800-432-ECHO (3246). Dealer information is also available on our Web Site. When presenting your unit for Warranty service/repairs, proof of purchase is required.

### ECHO CONSUMER PRODUCT SUPPORT

If you require assistance or have questions concerning the application, operation or maintenance of this product you may call the ECHO Consumer Product Support Department at 1-800-673-1558 from 8:30 am to 4:30 pm (Central Standard Time) Monday through Friday. Before calling, please know the model and serial number of your unit.

#### WARRANTY REGISTRATION

To ensure trouble free warranty coverage it is important that you register your ECHO equipment on-line at <a href="https://www.echo-usa.com">www.echo-usa.com</a> or by filling out the warranty registration card supplied with your unit. Registering your product confirms your warranty coverage and provides a direct link between you and ECHO if we find it necessary to contact you.



DEALER?
Call
1-800-432-ECHO
or
www.echo-usa.com

CONSUMER PRODUCT SUPPORT 1-800-673-1558 8:30 - 4:30 Mon - Fri C.S.T.



### ADDITIONAL OR REPLACEMENT MANUALS

**Replacement Operator, Safety Manuals, and Parts Catalogs** are available from your ECHO dealer or at www.echo-usa.com or by contacting ECHO Inc., 400 Oakwood Road, Lake Zurich, IL 60047 (800-673-1558). Always check the ECHO Web Site for updated information.

Safety Videos are available from your Echo dealer. A \$5.00 shipping charge will be required for each video.



www.echo-usa.com

S07100001001/S07100999999

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com