




Goodmans

Talking set-top box instruction manual

Model number: GDB20TTS



IMPORTANT: Please read all instructions carefully before use and keep for future reference.



Introduction

Thank you for buying this product.

Not only can it receive over 50 digital TV channels, but you can also listen to up to 24 digital radio stations, all at the touch of a button. This product has talking features, audio description, and an option to change the colour settings and font size.

You may already be familiar with using similar equipment, but we recommend you take time to read these instructions. We have designed them so you can become familiar with the many features of the system and to make sure you get the very best from your set-top box.

Keep these instructions in a safe place in case you need them in the future.

Coverage

Check the coverage in your area.

Text your postcode, followed by your house number or name to 83331.
Or visit www.freeview.co.uk

For example, NW9 6NY (Costs no more than a normal text.)

The Freeview service depends on coverage in your area.

We cannot give a guarantee about broadcast signal quality. A wideband rooftop aerial will give the best results. You may need an upgrade to your aerial.

The FREEVIEW, FREEVIEW+, FREEVIEW+ HD words and logos are trademarks of DTV Services LTD. DTV Services Ltd 2002, 2008.

Safety

You must be careful whenever you use any electrical equipment. Please read the product safety section on page 75 before using your digital box. This appliance is for household use only.



Contents

- Introduction 2
- Coverage 2
- Safety 2
- What's in the box 4
- Main unit 5
- Remote control 6
- Getting connected 8
- How to connect the set-top box to a TV set 10
- How to connect to a TV set and DVD recorder or VCR? 10
- How to connect headphones 12
- How to turn the set-top box on for the first time 13
- Problems installing the channels 15
- How to turn the set-top box off 15
- How to turn the set-top box on from standby 15
- Commonly used features 16
- Changing the volume 16
- Mute 16
- Changing channel 17
- Programme information 19
- Programme guide 20
- Mini guide 22
- Favourites list 23
- Reminders list 24
- On-screen help pages 25
- Single-button functions 26
- Talking features 27
- Retuning 30
- Parental control 34
- Setting up your system 38
- Preferences 38
- Reminders list 61
- Technical settings 62
- Help 71
- System information 72
- Help and advice 73
- Safety information 75
- Cleaning 75
- Ventilation 75
- Servicing 75

Getting started

What's in the box


Carefully remove your equipment from the box it arrived in. It is recommended that you retain this packaging should the item need to be returned under warranty.

Equipment and accessories supplied

In the box you should have the items listed below.

- Main unit
- AC/DC power adapter
- Remote control
- Two AA batteries
- RF cable
- Scart-to-Scart cable
- User guide and quick start guide

These items are illustrated in the diagram below. If any items are missing, please contact our customer services department.






Getting started

Main unit

There are no control buttons on the main unit.


The remote control sensor is located on the left side of the front panel. When operating the remote control, point it at this sensor. Do not block the sensor or the remote control won't work.



Getting started

Remote control

The remote control buttons give access to all the functions required for operation of the set-top box.






Getting started

Putting batteries in the remote control

The remote control needs two type AA batteries to power it. We have supplied these.

To replace the batteries

- 1 Turn the remote control on to its front face to reveal the battery compartment cover (shown tinted in diagram below).
- 2 Push and pull the cover in the direction of the arrows on the cover and slide it off to reveal the battery compartment.
- 3 Remove the two batteries from the compartment and put them to one side. (You do not need to do this when you put batteries in for the first time.)
- 4 Insert the two AA size batteries following the diagram printed around the compartments.
- 5 Put the cover on the guides of the compartment and slide it closed. You will hear it snap closed.



Getting rid of the batteries

Make sure you get rid of the batteries safely. Never get rid of them in a fire or with household waste. Check with your local authority for regulations on this.





Getting started

About the remote control

- 1 The remote control communicates with the main unit using an infrared link between the sensor on the remote control and the sensor on the front of the main unit.
- 2 The remote control can be used up to seven metres away at an angle of 30 degrees to the front panel of the main unit.
- 3 The remote control will not work if there is something in between the remote control and the main unit. Sunlight or very bright light may mean the remote control does not work as well as usual.

How to use the remote control

- 1 Point the sensor end of the remote control towards the sensor on the front of the main unit.
- 2 Press the number buttons for the channel that you want.
- 3 The sensor on the front panel will flash as it receives commands from the remote control.
- 4 You can select a setting from the menu to sound a beep when the set-top box has received an instruction from the remote control.

Getting connected

Connecting an aerial


Before you can tune in any TV or radio stations, you must connect an aerial to your unit. You will get better results using a rooftop aerial. If you are in a strong signal area, a portable aerial may be suitable. We recommend that for the initial tuning process you use a fixed aerial to get the strongest signal. Connect the aerial to the unit as shown on page 9.

Connecting to a power supply

The main unit should only be powered using the AC/DC adapter supplied as shown opposite. The AC/DC adapter is powered from the 230V AC mains supply.



Getting started





Getting started

How to connect the set-top box to a TV set

If your TV has a SCART socket

- 1 Put your set-top box on a firm, level surface with at least a 10-centimetre gap around all the sides and close to the TV you are going to connect it to.
- 2 Turn off the mains socket your TV is plugged into or pull the plug out of the socket.
- 3 Take the aerial lead out of the TV and connect it to the 'aerial' connector on the back panel of the set-top box.
- 4 Connect the RF cable (we have provided one) between the 'RF out' socket on the set-top box and the aerial socket on the TV. This cable will allow you to watch TV programmes as you did before but with the set-top box connected.
- 5 Connect a cable which has a 'Scart' connector at each end (we have provided one) between the 'TV' socket on the back panel of the set-top box and the 'Scart' socket on your TV. If there is more than one 'Scart' socket on the TV, look in your TV instruction manual to check which one you should use.
- 6 The set-top box will not work if you do not have the scart-to-scart cable connected.
- 7 Plug the AC/DC adapter into a mains socket and then plug the connector on the adapter into the '5V DC in' connector on the back panel of the set-top box as shown on page 11.
- 8 Plug the TV mains lead back into the mains socket.

When your TV does not have a SCART socket


Connect as described above but ignore the Scart-to-Scart connection.

How to connect to a TV set and DVD recorder or VCR?

- 1 Put your set-top box on a firm, level surface with at least a 10-centimetre gap around all the sides and close to the TV and DVD recorder or VCR you are going to connect it to.
- 2 Turn off the mains socket your TV and DVD or VCR is plugged into or pull the plugs out of the sockets.
- 3 Take the aerial lead out of the TV and connect it to the 'aerial' connector on the back panel of the set-top box.



Getting started




Getting started

- 4 Connect the RF cable (we have provided one) between the 'RF out' socket on the set-top box and the aerial socket on the DVD or VCR. Also connect a second RF cable between the DVD or VCR and the 'aerial' socket on the TV. These cables will allow you to watch TV programmes as you did before but with the set-top box connected.
- 5 Connect a cable which has a Scart connector at each end (we have provided one) between the 'TV' socket on the back panel of the set-top box and the 'Scart' socket on your TV. If there is more than one 'Scart' socket on the TV, look in your TV instruction manual to check which one you should use.
- 6 Connect a cable which has a Scart connector at each end (we have not provided this) between the 'VCR or DVD' socket on the back panel of the set-top box and the 'Scart' socket on your DVD or VCR.
- 7 Plug the AC/DC adapter into a mains socket and then plug the connector on the adapter into the '5V DC in' connector on the back panel of the set-top box as shown opposite.
- 8 Plug the TV mains lead back into the mains socket.

How to connect headphones

Connect the 3.5 mm stereo jack plug on your headphones into the headphone socket on the back of the set-top box, see below.





First time installation


How to turn the set-top box on for the first time

When you have connected your set-top box to the TV (as described in the previous section), you are ready to use it.

- 1 Switch on the TV.
- 2 Set it to the input channel you have connected the set-top box to (AV1, for example).
- 3 Switch the set-top box on at the mains supply.
- 4 The power indicator on the front panel of the set-top box will light up red and will change to green as a picture is displayed. The set-top box will automatically use talking features to speak the setup instructions. You can switch this off by pressing the TF button on your remote control.



- 5 This will be the 'first-time installation' title screen (shown above).
- 6 Check your aerial is connected correctly and then press the OK button.




First time installation

- 7 The 'Scanning' window will open (shown below) and the box will search for the TV and radio channels (services). If you have left talking features on you will hear a progress update every 15 seconds.



- 8 The progress will be shown in the bar along the bottom of the window as the services the box finds are listed above this bar. See above for an example.



- 9 When scanning finishes, the box will show the number of services (TV and radio stations). An example is shown above.
- 10 After a short time, the first TV channel in the list of channels the box has found will





First time installation

be shown. This is usually BBC1. An information banner will appear along the top of the picture for a short time which gives basic details of the TV programme you are watching.

Problems installing the channels

If you could not receive any channels as described previously, do the following.

- Check all the connections to your set-top box and TV making sure the connections are secure and connected to the correct sockets.
- Try the installation again by following the 'Retuning procedure' given on page 30.

How to turn the set-top box off

If you watch TV regularly, you should leave the set-top box in standby mode when you are not watching TV. You should only switch it off at the mains if you are away or do not want to use the TV for a long time, one month for example.

Your set-top box will automatically update the stored channels while it is standby mode as they become available. It can also receive updates to the operating software during this time. It cannot receive new channels and software updates when the set-top box is disconnected from the mains supply or the aerial is disconnected.

If you plan to disconnect the set-top box from the mains, you should put it into standby first.

You can put the set-top box on standby as follows.

- 1 Press the button labelled **stb**.
- 2 The front panel power indicator will change colour from green to red.
- 3 The set-top box is now in standby mode.
- 4 The set-top box 'Scart' output will now be turned off.
- 5 The TV picture will be turned off.

How to turn the set-top box on from standby


- 1 Press the button labelled **stb**.
- 2 The front panel power indicator will change colour from red to green.
- 3 This will turn on the set-top box Scart output.
- 4 The TV picture will turn on and show the station that you were watching when the set-top box was put on standby.

Basic operation

Commonly used features

As with most electrical goods there will be features that you use everyday and others that you need only occasionally. The everyday features are included in this section to help you get your set-top box up and running as quickly as possible.

Many functions will need you to use the 'navigation' buttons. These are on the centre of the remote control and are shown right.



In this user guide these buttons will be called **Up**, **Down**, **Left** and **Right** as shown in the diagram.

Talking features

All information on screen is spoken by your set-top box using talking features. You can switch talking features on and off using the TF button on your remote control.

Changing the volume


When you want to change the volume, press the Vol + or Vol- buttons. The volume indicator bar will be displayed on the screen as shown below.



Press the **Vol +** button to increase the volume or press the **Vol-** button to reduce the volume. As you press the buttons the volume level is shown on the indicator. As the volume increases the white bar gets longer; as the volume reduces this bar gets shorter.

After 5 seconds of not pressing the volume buttons, the volume indicator will disappear from the screen.

Mute

To turn the sound off quickly, press the mute button. This button has the following symbol printed on it . This symbol will also be displayed on the screen while mute is on.

To put the sound back on, press the mute button again. Sound will come back at its previous level and the mute symbol will disappear from the screen. You can also put the sound back on again if you press the **Vol +** or **Vol-** buttons.



Changing channel

When you want to change to another channel you can do this in the following ways.

- Using the **Ch+** and **Ch-** buttons.
- Entering the channel number on the numerical keypad (**0-9**).
- Choosing from your favourites list (**Fav** button).
You need to programme this list first. See page 59 for how to do this.
- Choosing from a list of channels (**TV/Radio** button).

Ch+ and Ch- buttons

To change to the channel next to the one you are watching in the channel list, press the **Ch+** button. Repeat until you reach the channel you want to watch.

To change to the channel before the one you are watching in the channel list, press the **Ch-** button.

Repeat until you reach the channel you want to watch.

When changing channel, a banner is shown across the top of the screen that shows the channel and programme information. An example is shown below.



Using the number buttons

Enter the number of the channel you want to change to using the number buttons (**0 - 9**) on the remote control.

The numbers you press will be shown in the top left corner. You can enter one, two or three digits as you need. After a short time, the channel you have entered will be shown.

Using your favourites list

You must first program this list. See page 59 for how to do this.

- 1 Press the **Fav** button.
- 2 Your favourites list will be displayed. An example is shown below.

Basic operation




- 3 Press the **Up** or **Down** buttons to move to the channel you would like to watch. The highlight panel will identify your choice.
- 4 Press the **OK** button. The channel you have chosen will be shown.

Using the channel list

- 5 Press the **TV/Radio** button. A list of all channels will be shown. See the example on the next page.
- 6 Press the TV/Radio button again to display only TV channels and again to display only Radio channels.
- 7 Repeat until the list you want is shown.
- 8 Press the **Up** or **Down** buttons to move to the channel you would like to watch. The highlight panel will identify your choice.
- 9 Press the **OK** button. The channel you have chosen will be shown.

Locked channel


When you try to switch to a locked channel, and parental control is turned on, the 'Locked channel' PIN code entry box will be shown. Enter the PIN code to watch the channel you want to see. The default PIN for the set-top box is 0000.





Programme information

To display information about the programme you are watching now, press the **Info** button.



Press the **Right** button to display the same information for the next programme to be broadcast on this channel.

To see similar information (if available) on other channels, press the **Up** and **Down** buttons until you reach the channel you want.


To watch the programme whose details are shown, press the **OK** button or press **Exit** to return to the channel you were previously watching.

Advanced features


Programme guide

The programme guide lets you see details of radio and TV programmes for the next week and set reminders for programmes you want to watch. When a programme is set with a reminder, just before the programme reaches the broadcast time, a message will be shown on the screen that the programme is about to start.

To see the programme guide press the **Guide** button. Two example are shown below. The first display layout shown here is called the 'list' layout.



The second is called 'grid' layout. Press the guide button to move between the two layouts.





Advanced features

You can set which layout displays when you press the **Guide** button. You set this up using the menu function as described on page 39.

How to move around the guide

To browse the guide press the **Up**, **Down**, **Left** and **Right** buttons to move in these directions. The highlighted panel shows which programme has been chosen.


To show the programmes for the next day, press the **blue** button. You can look ahead for up to seven days.

To show the programmes for the previous day, press the **yellow** button.

To display the programme guide for another channel, press the **Ch+** or **Ch-** buttons to step forward or backward through the channels.

To watch a programme that is on now, press the **Up**, **Down**, **Left** and **Right** buttons to highlight the programme and then press the **OK** button.

To see information about a programme, choose the programme as described above and then press the **Info** button. The 'Programme information' window will open. An example of this is shown below.



How to set a reminder

- 1 Open the programme guide as described above.
- 2 Use the **Up**, **Down**, **Left** and **Right** buttons to choose the programme you want to set the reminder for.

Advanced features

- 3 Press the **OK** button. The programme will be highlighted to show that the reminder has been set.
- 4 The reminder will appear in the reminders list which you can see using the menu function. See page 24 for details.

Mini guide

When you are watching a programme you can display the mini guide. An example of this is shown below.



This lets you see details about the programme you are watching and the next programme to be broadcast on the same channel. The programme you have chosen is enclosed in a coloured rectangle.

- 5 To see information for other programmes on the channel, press the **Up** or **Down** button to highlight the required programme you need.
- 6 To see information for programmes on another channel, press the **Left** or **Right** button until the channel or programme is highlighted.
- 7 To view programmes for the next day, press the **blue** button. To see programmes for the previous day, press the **yellow** button.
- 8 To show information about the channel you have chosen, press the **Info** button. This will display full programme information as shown on page 20.
- 9 When you want to watch a programme you have chosen, press the **OK** button. If the programme is already on, it will be displayed. If the programme is on later, a reminder will be set.
- 10 To close the mini guide, press the **Exit** button.

Favourites list

The favourites function lets you create a list of your favourite programmes, in other words, the ones you watch most often. The list can include TV and radio programmes. Using this list will make it easier to change to these channels.

You create the list using the menu function as follows.

- 1 Press the **Menu** button.
- 2 Press the **Down** button until 'Favourites' is highlighted.
- 3 Press the **OK** button.
- 4 The 'Set up favourites' window will be shown. It contains all the channels stored in your system. An example is shown below.



- 5 Press the **Up** and **Down** buttons to highlight a channel you want to add to the favourites list.
- 6 Press the **OK** button to add it to the list. A tick symbol will be shown alongside your choice to show that it is in the list.
- 7 To remove a channel from the list, highlight the channel and then press the **OK** button. The tick symbol will be deleted and the channel will no longer be in the favourites list.
- 8 Press the **Back** button to save the edited list.

Advanced features


- 9 You will be prompted by the 'Save changes' window which is shown below.
- 10 Press the **Up** or **Down** button to choose 'Yes' and then press **OK** to save the list and return to the programme you were last watching.
Or, press the **Back** button to choose to the previous menu without saving changes.
Or, press the **Up** or **Down** button to select 'No' and not save the changes
Or, press the **Exit** button to return to the programme you were last watching without saving changes.

Reminders list

The reminders list shows you the reminders you have set. The list is arranged in date and time order.

You can see the list using the menu function as follows.

- 1 Press the **Menu** button.
- 2 Press the **Down** button until 'Reminders list' is highlighted.



- 3 Press the **OK** button.
- 4 The reminders list will be shown. An example is shown on the next page.

To move up and down the list, press the **Up** and **Down** buttons.


To delete a reminder, move to the programme in the list and then press the **OK** button.

The 'Delete reminders' window will open. An example is shown on the next page.

Advanced features



- 1 Use the Up and **Down** buttons to choose 'Yes' and then press **OK**.
- 2 The reminders list will be updated and saved.



- 3 The TV will now display the previous programme you were watching without the deleted reminder.
- 4 Or choose **No** and then **OK**
Or, press the **Back** button to choose to the previous menu
Or, press the **Exit** button to return to the programme you were last watching without saving changes.

On-screen help pages


There are nine help pages available that will display information on the screen for various topics for you to call up at any time as follows.

- 1 Press the **Help** button.
- 2 The 'Help contents' list will be shown.
- 3 Use the **Up** and **Down** buttons to highlight the topic you are interested in.
- 4 Press the **OK** button to display the page of information for the topic.

Advanced features



- 5 Use the **Left** and **Right** buttons to step forward and backwards through the help pages and display the information as you do so.
- 6 To return to the previous menu, press the **Back** button.



- 7 To close the help pages and return to watching TV, press the **Exit** button.

Single-button functions

You can carry out many operations by pressing a single button such as changing the volume with the vol+ and vol- buttons and switching to another channel using the Ch+ and Ch- buttons for example. This section will describe these single-button functions. It

26



Advanced features

will not include those buttons mentioned above which are described fully in the 'Basic operation' chapter.

TV and radio (channel lists)

This function allows you to list all the channels stored in your system. It can also list TV channels only or just radio channels.

- 1 Press the **TV/Radio** button once. A list of all the channels will be shown.
- 2 Press the **TV/Radio** button again. Only radio channels will be listed.
- 3 Use the **Up** and **Down** buttons to choose a channel you wish to watch or hear.
- 4 Press the **OK** button.
- 5 The channel you have chosen will be shown.

Fav

This function will display your list of favourite channels. See page 23 for how to create the list. This function will be easier for you to choose from compared with using the TV/Radio button described above.

- 1 Press the **Fav** button to display your list of favourite channels.
- 2 Use the **Up** and **Down** buttons to choose the channel you want to change to.
- 3 Press the **OK** button to watch the channel you have chosen.

TF (talking features)

The talking features function allows you to hear spoken actions on your system, such as 'Volume control turned up, Change to channel ...' for example as you carry out the actions using the remote control or receive information from the help screens or programme information.

You can turn off the talking features using the TF button. Talking features is on as default.

- 1 Press the **TF** button.
- 2 'Talking features off' will be heard and shown briefly.
- 3 Talking features will now be turned off.
- 4 To turn talking features on again, press the **TF** button.
- 5 'Talking features on' will be heard and shown briefly on the screen.



Advanced features

AD (audio description)

Audio description is a spoken narration that describes important information about a TV programme, such as body language, facial expressions, scenery, action costumes or anything that helps to explain the plot of the story, event or image.

Audio description is not always available. Audio description is available if you see AD in the 'Programme information' window.

You can turn off the audio description feature using the AD button. Audio description is off as default.

- 1 Press the **AD** button.
- 2 'Audio description off' will be shown briefly.
- 3 The audio description feature will now be turned off.
- 4 To turn the audio description feature on again, press the **AD** button.
- 5 'Audio description on' will be shown briefly on the screen.

Swap

The swap function has a toggle action and allows you to switch directly to the previous channel you were watching.

- 1 Press the **Swap** button.
- 2 The previous channel you were watching will be shown.
- 3 Press the **Swap** button again to return to the programme you were just watching.



Advanced features

Sub (subtitles)

Subtitles give you an on-screen text version of the conversation or narrative on the TV channel you're watching. When you choose subtitles, your TV will show the subtitles for the channel you are watching at the bottom of the screen over the picture. If you change channel, subtitles will appear on the new channel until you turn the subtitles off. You cannot use subtitles at the same time as digital teletext.

Not all programmes have subtitles. If they are available you will see [S] in the programme information window.

Subtitles is off as default. The Sub button lets you instantly turn subtitles on or off if they are provided for the programme you are watching.

- 1 Press the **Sub** button while watching a programme.
- 2 'Subtitles on' will be displayed briefly on the screen.
- 3 If subtitles are provided for this programme you will see them appear on the screen.
- 4 To turn subtitles off, press the **Sub** button again.
- 5 'Subtitles off' will be shown briefly on the screen.
- 6 Subtitles will no longer appear on the screen.

Silence talking features button

The **Silence talking features** button lets you turn off all narration (audio description) and talking from talking features. The sound in the programme you are watching will not be affected.

- 1 Press the **Silence talking features** button.
- 2 You will now only hear sound from the TV programme you are watching.

? Where am I button.

The where am I button provides spoken output of your current location and the navigation buttons available. In most cases this button will not have any visual effect. However, if watching TV pressing ? will display information about the programme you are watching.

Advanced features

- 1 Press the **?** button.
- 2 The 'Programme information' window will be shown. See program information on page 20 for what is shown in this window.

Txt (text)

The Text button calls for the teletext provided by the TV channel to be loaded and displayed on the screen. Not all TV channel providers supply teletext.

To move around the various pages of teletext, use the **Up, Down, Left** and **Right** buttons and the **OK** button to make your choices.


Coloured buttons

These interactive service buttons (red, green, yellow, blue) are associated with teletext displays provided by some TV channels providers. See the information provided by the TV channel provider for how to use these buttons.

Talking features is not available for interactive services, such as Teletext. To close interactive services press the **Txt** or **Exit** buttons.

Retuning

Retuning your set-top box is similar to installing it for the first time (where the set-top box scans for TV and radio channels and stores them). When retuning is started, all existing channel details are deleted, as are parental-control settings and your favourites list.




If you need to retune the channels, do the following.

30




Advanced features

- 1 Press the **Menu** button to display the main menu. The menu will display with the first option highlighted as shown above.
- 2 Use the **Up** and **Down** buttons to choose 'Technical settings'.




- 3 Press the **OK** button.
- 4 The Technical settings menu will be shown.
- 5 Use the **Up** and **Down** buttons to choose 'Channel tuning'.




- 6 Press the **OK** button.
- 7 The 'Channel tuning' menu will open. See below.



Advanced features




- 8 Use the **Up** and **Down** buttons to choose 'Retune channels'.
- 9 The 'Retune channels' warning window will be shown.
- 10 Press the **OK** button to start retuning.



Advanced features

- 11 The 'scanning' window will open (shown below) and the set-top box will search for TV and radio channels (services).



- 12 The progress will be shown in the bar along the bottom of the window as the services it finds are listed above this bar. See the example below.
- 13 When scanning finishes the number of services (TV and radio stations) found are displayed. An example is shown below.



- 14 After a short time, the first TV channel in the list of channels found will be shown. This is usually BBC1. An information banner will appear along the top of the picture for a short time which gives basic details of the TV programme you are watching.


Advanced features

Parental control


Parental control lets you prevent certain channels from being watched without a PIN code being entered first. This will help to prevent children from watching programmes you think are not suitable for them.

To set up parental control, do the following.

- 1 Press the **Menu** button to display the main menu. The menu will display with the first option highlighted as shown below.



- 2 Use the **Up** and **Down** buttons to choose 'Parental control'.




- 3 Press the **OK** button.
- 4 The parental control 'Enter PIN' window will open.


34



Advanced features



- 5 Enter the four-digit PIN code in the box using the **0 to 9** numbers on the remote control, or press the **Back** button to refuse. The default PIN code is 0000.
- 6 If the PIN code is correct the Parental control window will be shown with the first of three options highlighted as shown below. If the PIN code is not correct, you will be told on the screen and given the chance to enter the correct code.
- 7 Whether parental control is switched on or off is shown at the top of the message area:
The example below shows parental control is off and no channels are locked.



The settings of the channels (locked or unlocked) is not affected when you change option 1.



Advanced features

Turning parental control on and off

When parental control is off, channels which are locked do not need you to enter a PIN code.

When parental control is on, channels which are locked require a PIN code to be entered.

In the Parental control window, do the following.

- 1 Use the **Up** and **Down** buttons to choose option 1.
- 2 Press the **OK** button.
- 3 The 'Turn parental control on or off' window will be displayed.

In the 'Turn parental control on or off' window, do the following.

- 1 Use the **Up** and **Down** buttons to choose whether to turn parental control on or off.
- 2 Press the **OK** button.
- 3 A tick symbol will appear on the line you have chosen to show that this option is the current setting, and you will then return to the previous menu.
- 4 Press the **Back** button to save your changes.
- 5 When needed, choose the other option in the same way as described above.

Lock and unlock channels

This function lets you set channels to be locked and to unlock channels that are already locked.

In the Parental control window, do the following.

- 1 Use the **Up** and **Down** buttons to choose option 2.
- 2 Press the **OK** button.
- 3 The 'Lock or unlock channels' window will be shown.

In the 'Lock or unlock channels' window, do the following.

- 1 Use the **Up** and **Down** buttons to choose the channel you want to lock.
- 2 Press the **OK** button.



Advanced features

- 3 A padlock symbol will appear on the line of the channel to show that this channel is locked.
- 4 Repeat for other channels as you need.

To unlock a locked channel.

- 1 Use the **Up** and **Down** buttons to choose the channel you want to unlock.
- 2 Press the **OK** button.
- 3 The padlock symbol will be removed. This shows that the channel is not locked.

Change the PIN code

It is a good idea to change the PIN code from the default setting if you plan to use parental control. The default setting is 0 0 0 0. Choose a number you can easily remember as restoring defaults will not reset the new PIN code back to the default setting.

In the 'Parental control' window, do the following.

- 1 Use the **Up** and **Down** buttons to choose option 3.
- 2 Press the **OK** button.
- 3 The 'Change PIN' window will be shown. An example is shown below.
- 4 Enter your chosen PIN code.
- 5 Enter it again. If there is a mistake it will let you know and you will have another chance to change the PIN.

Change PIN

Enter New PIN - - - -

Confirm New PIN - - - -

Use 0 - 9





Setting up your system

Setting up your system

You carry out all settings using the menu system. We have already described some of the settings. We describe the rest in this section.

General

The menus allow you to change the settings on your set-top box. The highlight panel shows the item currently selected.

- 1 To move to a different item in the menu, use the **Up** and **Down** buttons.
- 2 To save the selected item you have chosen, press the **OK** button. This will open a new menu or return to the previous menu saving any changes you have made.
- 3 To close the menu without saving any changes, press the **Back** button to go to the previous menu.
- 4 Or, you can press the **Exit** button to return to watching TV without saving any changes.

The main menu gives access to the following main menus.

- Preferences
- Favourites
- Parental control
- Reminders list
- Technical settings
- Help
- System information


Preferences

Preferences lets you change audio (sound) and visual (picture) settings according to what you want and the requirements of your TV.


To change any preferences, do the following.

- 1 Press the **Menu** button.
- 2 The main menu will be shown with the first option highlighted as shown in the example below.

Setting up your system




- 3 Press the **OK** button.
- 4 The 'preferences menu' will be shown. See below.



Layout of the programme guide

- 1 Use the **Up** and **Down** buttons to highlight 'Programme guide layout'.
- 2 Press the **OK** button.
- 3 The 'Programme guide layout menu will be shown.

Setting up your system



- 4 Use the **Up** and **Down** buttons to choose the option you want.
- 5 Press the **OK** button to save the setting and return to the previous menu.
Or you can press the **Back** button to return to the previous menu without saving changes, Or, press the **Exit** button to ignore any changes and return to watching TV.

Set volumes


This function sets the individual volume levels that will be used by each of the features in the 'Set volumes menu' until you next change them in this menu. They are shown below.

- AD (audio description)
- Set-top box
- Talking features
- Remote button beep volume
- Power on/off beep

In the 'Preferences' menu, do the following.


- 1 Use the **Up** and **Down** buttons to highlight 'Set volumes'.
- 2 Press the **OK** button.
- 3 The 'Set volumes' menu will be shown. See below.

Setting up your system



AD volume

- 1 Use the **Up** and **Down** buttons to highlight 'AD volume'.
- 2 Press the **OK** button.
- 3 The 'AD volume' window will be shown. See below.



In the 'AD volume' window, do the following.


- 1 Use the **Left** and **Right** buttons to turn the volume up or down to suit your needs.

Setting up your system

- 2 Press the **OK** button to save the volume setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Set-top box volume

- 1 Use the **Up** and **Down** buttons to highlight 'Set-top box volume'.
- 2 Press the **OK** button.
- 3 The 'Set-top box volume' window will be shown. See below.




In the 'Set-top box volume' window, do the following.

- 1 Use the **Left** and **Right** buttons to turn the volume up or down to suit your needs.
- 2 Press the **OK** button to save the volume setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Setting up your system

Talking features volume

- 1 Use the **Up** and **Down** buttons to highlight 'Talking features volume'.
- 2 Press the **OK** button.
- 3 The 'Talking features volume' window will be shown. See below.



In the 'Talking features volume' window, do the following.


- 1 Use the **Left** and **Right** buttons to turn the volume up or down to suit your needs.
- 2 Press the **OK** button to save the volume setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Setting up your system

Remote button beep

This function lets you set whether or not to sound a beep when you press a button on the remote control. If you want to sound a beep, you can choose the volume from three settings.

- 1 Use the **Up** and **Down** buttons to highlight 'Remote button beep volume'.
- 2 Press the **OK** button to save the volume setting and return to the previous menu.
- 3 The 'Button beep volume' menu will open. See below.



In the 'Button beep volume' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight the option you want.
- 2 Press the **OK** button to save the volume setting and return to watching TV, Or, press the **Back** button to return to the previous menu without change, Or, press the **Exit** button to ignore any change and return to watching TV.

Setting up your system

Power on/off beep

This function lets you set whether or not to sound a beep when the set-top box is switching on or off. If you choose to sound a beep, you can choose the volume from three settings

- 1 Use the **Up** and **Down** buttons to highlight 'Power on/off button beep'.
- 2 Press the **OK** button.
- 3 The 'Power on/off beep' menu will open. See below.



- 4 Use the **Up** and **Down** buttons to highlight the option you want.
- 5 Press the **OK** button to save the volume setting and return to the previous menu, Or, press the **Back** button to return to the previous menu without change, Or, press the **Exit** button to ignore any change and return to watching TV.




Setting up your system

Visual

The visual preferences let you choose the colour scheme, set a larger font to be used when displaying the full programme guide or mini guide.

In the 'Preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Visual'.
- 2 Press the **OK** button.
- 3 The 'Visual preferences' menu will be shown. See below.






Setting up your system

Colour scheme

This function lets you choose the colour scheme you prefer to use when displaying the menus, programme guide and mini guide. There are three schemes to choose from, - white on blue, high contrast (white on black) and invert (black on white).

In the 'Visual preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Colour scheme'.
- 2 Press the **OK** button.
- 3 The 'Colour scheme' menu will open. See below.



- 4 Use the **Up** and **Down** buttons to highlight the colour scheme you want.
- 5 Press the **OK** button to save the colour scheme setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.


Setting up your system

Font size

This function lets you choose the size of the text used when displaying the full programme or mini guides. There are two sizes to choose from - medium (the default size) and large.

In the 'Visual preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Font size'.
- 2 Press the **OK** button.
- 3 The 'Font size' menu will open. See below.



- 4 Use the **Up** and **Down** buttons to highlight the font size you want.
- 5 Press the **OK** button to save the setting and return to the previous menu, Or, press the **Back** button to return to the previous menu without change, Or, press the **Exit** button to ignore any change and return to watching TV.




Setting up your system

Turn subtitles on and off

This function lets you select whether to have subtitles on or off as default.

In the 'Visual preferences' menu,

- 1 Use the **Up** and **Down** buttons to highlight 'Turn subtitles on/off'.
- 2 Press the **OK** button.
- 3 The 'Turn subtitles on/off' menu will open. See below.



- 4 Use the **Up** and **Down** buttons to highlight the setting you want.
- 5 Press the **OK** button to save the setting and return to the previous menu, Or, press the **Back** button to return to the previous menu without change, Or, press the **Exit** button to ignore any change and return to watching TV.


Setting up your system

Talking features

This function lets you choose whether talking features are turned on or off, the volume level, talking speed and beginner or expert mode.

In the 'Preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Talking features'.
- 2 Press the **OK** button.
- 3 The 'Talking features preferences' menu will be displayed. See below.




Setting up your system

Turn talking features (TF) on or off

This function lets you select whether talking features are on or off as default.

In the 'Talking features preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Turn TF on/off'.
- 2 Press the **OK** button.
- 3 The 'Turn talking features (TF) on/off' menu will open.



- 4 Use the **Up** and **Down** buttons to highlight the setting you want.
- 5 Press the **OK** button to save the setting and return to the previous menu, Or, press the **Back** button to return to the previous menu without change, Or, press the **Exit** button to ignore any change and return to watching TV.


Setting up your system

Volume

This function lets you set the default volume level of Talking features.

In the 'Talking features preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Volume control'.
- 2 Press the **OK** button.
- 3 The 'Talking features volume' window will be shown. See below.



- 1 Use the **Left** and **Right** buttons to decrease/increase the volume to suit your needs.
- 2 Press the **OK** button to save the volume setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.


Setting up your system

Speed control

This function lets you set the talking speed of talking features.

In the 'Talking features preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Speed control'.
- 2 Press the **OK** button.
- 3 The 'Talking features speed' window will be shown. See below.



- 1 Use the **Up** and **Down** buttons to choose the option to suit your needs.
- 2 Press the **OK** button to save the speed setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.


Setting up your system

Set mode

This function lets you set the skill level you need to understand the speech of talking features.

In the 'Talking features preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Set mode'.
- 2 Press the **OK** button.
- 3 The 'Talking features mode' menu will be displayed, see below.



- 1 Use the **Up** and **Down** buttons to choose the option to suit your needs.
- 2 Press the **OK** button to save the setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.



Setting up your system


Languages

This function lets you choose the audio language and the language to use for subtitles. The audio refers to the TV soundtrack and the audio description language. It does not include the talking features language which is only available in English.

The language choices are: English, Welsh and Scottish.

In the 'Preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Language'.
- 2 Press the **OK** button.
- 3 The 'Language preferences' menu will be shown. See below.




Setting up your system

Audio language

This function lets you set the language for the TV soundtrack and the audio description (AD).

In the 'Language preferences' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Audio language'.
- 2 Press the **OK** button.
- 3 The 'Audio language' menu will be displayed, see below.



- 4 Use the **Up** and **Down** buttons to highlight the language to suit your needs.
- 5 Press the **OK** button to save the audio language setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.


Setting up your system

Subtitle language

This function lets you set the language to use for subtitles.

In the 'Language preferences' menu

- 1 Use the **Up** and **Down** buttons to highlight 'Subtitle language'.
- 2 Press the **OK** button.
- 3 The 'Subtitle language' menu will be displayed, see below.




- 4 Use the **Up** and **Down** buttons to highlight the language to suit your requirements.
- 5 Press the **OK** button to save the subtitle language setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Setting up your system

Favourites

Favourites lets you put the channels you watch most into a list, making it easier to change to those channels.

Favourites is option 2 on the main menu. An example is shown below.



To create a favourites list, do the following.

- 1 Press the **Menu** button.
- 2 Use the **Up** and **Down** buttons to highlight 'Favourites'.
- 3 Press the **OK** button.
- 4 The 'Set up favourites' window will open. An example of a favourites list being created is shown below. Only the channels marked with the tick symbol will appear in the favourites list when using the Fav button on the remote control.


Setting up your system



- 5 Use the **Up** and **Down** buttons to highlight a channel you want to include in the favourites list.
- 6 Press the **OK** button to add it to the list.
- 7 A tick symbol will be shown in line with your choice.

To remove a channel from the favourites list.

- 1 Use the **Up** and **Down** buttons to highlight the channel (ticked) you want to remove.
- 2 Press the **OK** button.
- 3 The tick symbol alongside this channel will disappear.
- 4 Press the **Back** button to save the new list of favourites.
- 5 The Save changes window will be shown. See below.





Setting up your system

- 6 Use the **Up** and **Down** buttons to highlight 'Yes'.
- 7 Press the **OK** button.

If at step 6 you decided not to update the favourites list, press **Exit** to discard the changes and return to watching TV.

Parental control

Parental control lets you prevent certain channels from being watched without a PIN code being entered first. This will help to prevent children from watching programmes which you think are not suitable for them.

We have described this topic in the Advanced features chapter, see page 34.

Reminders list

The reminders list shows the reminders you have set. As well as listing the reminders you can also delete any programmes you no longer want to be reminded of.

We have described this topic in the Advanced features chapter, see page 24.



Setting up your system

Technical settings

The 'Technical settings' menu allows you to set up the following items:


- TV connections
- Channel tuning
- Power mode
- Auto standby mode
- Restore defaults

It also allows you to see:

- 1 channel details; and
- 2 notice of a change to the network

To display the Technical settings menu, do the following.

- 1 In the main menu, use the **Up** and **Down** buttons to highlight the 'Technical settings'.
- 2 Press the **OK** button.
- 3 The TV settings menu will be shown. See below.




Setting up your system

TV connections

In this menu you can set the aspect ratio (screen shape) of the TV your set-top box connects to. Also you can set the aspect conversion – how you want the set-top box to deal with programmes created for a TV with a different screen shape (wide (16:9) or square (4:3) for example). You can also give details of the video connection format you want to use from the set-top box to the TV using the Scart connection.

To display the TV connection settings menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'TV connection settings'.
- 2 Press the **OK** button.
- 3 The 'TV connection settings' menu will be shown. See below.




Aspect ratio

- 1 Use the **Up** and **Down** buttons to highlight 'Aspect ratio'.
- 2 Press the **OK** button.
- 3 The 'Aspect ratio' options will be shown.




Setting up your system



- 4 Use the **Up** and **Down** buttons to highlight the option to suit your needs.
- 5 Press the **OK** button to save the aspect ratio setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Aspect conversion

- 1 Use the **Up** and **Down** buttons to highlight 'Aspect conversion'.
- 2 Press the **OK** button.
- 3 The 'Aspect conversion' options will be shown. See below.




Setting up your system

- 4 Use the **Up** / **Down** buttons to highlight the option to suit your needs.
- 5 Press the **OK** button to save the aspect conversion setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Scart type

- 1 Use the **Up** and **Down** buttons to highlight 'Scart type'.
- 2 Press the **OK** button.
- 3 The 'Scart type' options will be shown. See below.



- 4 Use the **Up** and **Down** buttons to highlight the option to suit your needs.
- 5 Press the **OK** button to save the scart setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Tuning the channels


We have described this topic in the Advanced features chapter, see Retuning on page 30.

Channel details

The channel details function will give you a list of all the stored channels in your system in the format channel number (CN), channel name and channel type (TV or radio). You can choose any channel from the list and show detailed information about it.


To display the 'Channel details' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Channel details'.
- 2 Press the **OK** button.
- 3 The 'Channel details' menu will be shown. An example is shown below.



- 4 Use the **Up** and **Down** buttons to highlight the channel you would like details about.
- 5 Press the **OK** button.
- 6 The 'Channel information' window will be shown. An example is shown below.

Setting up your system



- 7 Press the **Back** button to return to the previous menu,
Or, press the **Exit** button to return to watching TV.

Low-power mode


In low-power mode some of the features are automatically turned off after a certain time when they have not been used for this period. If you do not want this to happen, you can turn low-power mode off.

To display the 'Turn low-power mode on/off' window, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Low-power mode'.
- 2 Press the **OK** button.
- 3 The 'Turn low power mode on/off' window will be shown. An example is shown below.



Setting up your system



- 4 Use the **Up** and **Down** buttons to highlight the option to suit your needs.
- 5 Press the **OK** button to save the low power mode setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,

Setting up your system


Or, press the **Exit** button to ignore any change and return to watching TV.

Auto standby mode

Auto standby mode will automatically switch off your set-top box after 3 hours of inactivity from the remote control. A menu will display on screen asking if you want to continue watching TV. If there is no response to this menu the set-top box will go into standby mode. You can decide if you want this to happen or not by changing the setting.

To display the 'Turn auto standby mode on/off' window, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Auto standby mode'.
- 2 Press the **OK** button.
- 3 The 'Turn auto standby mode on/off' window will be shown. See below.




- 4 Use the **Up** and **Down** buttons to highlight the option to suit your needs.
- 5 Press the **OK** button to save the setting and return to the previous menu, Or, press the **Back** button to return to the previous menu without change, Or, press the **Exit** button to ignore any change and return to watching TV.

Notice of change to the network

When services are updated a record of this will be stored in the 'Network change notifications' window. This may happen in the early days of a network being switched on for the first time.

To display a record of the changes received by your set-top box, do the following in the 'Technical settings window'.

- 1 Use the **Up** and **Down** buttons to highlight 'Network change notifications'.
- 2 Press the **OK** button.
- 3 The 'Network change notifications' window will open. The headings in the display area show the range of information that can be received. In the example shown below, no information has so far been received.




Setting up your system

Restore defaults

When you restore defaults, all settings go back to the factory settings, except for the PIN number if you have changed it. So, it is a good idea to choose a new PIN number you can easily remember, such as your birthday or an anniversary date.

To run the restore defaults function from the 'Technical settings' menu, do the following.

- 1 Use the **Up** and **Down** buttons to highlight 'Restore defaults'.
- 2 Press the **OK** button.
- 3 The 'Restore defaults' warning message box will open.



- 4 Follow the on-screen instructions.

Help

There are nine help pages available that will display information on the screen for various topics for you to refer to at any time. To get help, press the **Help** button at any time. The contents for the help pages are shown below and can be accessed by pressing **0** whilst in a help screen.



To read a particular help page, use the **Up** and **Down** buttons to highlight the page and then press the **OK** button to display the page.

This topic has been described in the Advanced features chapter. Please see page 25.

System information

You can display various information about your system including manufacturer's details and the software version installed.

Also, for the channel you are watching, you can see technical details including service name, provider, network and frequency of channel, signal strength and quality.

To see the system information details, do the following.

- 1 While watching, press the **Menu** button.
- 2 Use the **Up** and **Down** buttons to highlight 'System information'.
- 3 Press the **OK** button.
- 4 The system information page will be shown.
An example of this page is shown on the next page.

Setting up your system

System information			
Manufacturer:	Goodmans	Model number:	Smart Talk
Software version:	5.0	Boot code:	v1.7
Software last updated:	N/A		
Service:	1 BBC ONE	C.I.D.	0x1047
Provider:	BBC	T.I.S.	0x1007
Network:	East Anglia	N.I.T.	0x3001
Frequency (kHz)	698000		
Strength	<input type="text" value="70"/>		70%
Quality	<input type="text" value="10"/>		10

Back Previous menu **Exit** Return to TV

- 5 Use the **Up** and **Down** buttons to highlight the option to suit your needs.
- 6 Press the **OK** button to save the setting and return to the previous menu,
Or, press the **Back** button to return to the previous menu without change,
Or, press the **Exit** button to ignore any change and return to watching TV.

Help and advice

If you have difficulties using your set-top box and none of the suggestions below work, try switching your set-top box off at the mains, and then back on again. If this does not work, contact the shop you bought your set-top box from or a qualified repair technician. Never try to repair your set-top box yourself.

Please make sure you know the model number of your set-top box before contacting us. The model number is printed on the label on the underneath of the set-top box main unit.

Problem	What might be causing the problem
The 'Standby' light is not lit.	The mains lead either unplugged or the fuse in the mains plug has blown.
You cannot get a signal on your set-top box.	The aerial is not connected. The aerial is damaged or pointing in the wrong direction. You are not in an area which can receive a digital signal for the set-top box.
You cannot get a picture or any sound.	Your TV is set to the wrong AV channel. Check the channel you are using. Your set-top box may be set to digital teletext mode. You may get an encrypted channel message. You have to pay to watch this channel. The signal is encoded (encrypted) so that only authorised equipment can receive it.
Your set-top box is not responding to the remote control.	The set-top box is switched off or you are not pointing the remote control at the set-top box properly. There might be something in front of the front panel on the set-top box. You may have put the batteries in the remote control the wrong way round or you may need new batteries.
The picture is made up of square blocks or it freezes still.	The aerial may not be the right type for the set-top box. It may be damaged or pointing in the wrong direction.
You can only find some of the channels on your set-top box.	You have your favourites selected. Check your 'Channel list'.



Troubleshooting

Frequently asked questions

- Why do I get square blocks in the picture on the TV screen when I am watching Freeview channels?

The Freeview signal may be poor. You can check that you live in an area where you can receive Freeview channels by entering your postcode on the website www.freeview.co.uk or by sending your postcode in a text message to 83331. (This service is available on all major UK mobile phone networks. Standard network charges apply.)

- Can I watch the Freeview channels with only the RF cable connected between the TV and the set-top box?

No. To watch Freeview channels you must use the TV Scart connection. The RF cable connection lets you watch existing (non-digital) TV channels when the set-top box is turned off for example.



Product safety

Safety information

- Place cables where you won't walk on them and don't put anything on or against them.
- Do not use the set-top box in humid or damp conditions.
- Do not allow the set-top box to get wet.
- Do not drip or splash anything on the set-top box.
- Do not put anything with water in it (such as a vase) on top of the set-top box.
- Do not put naked flames (such as candles) on top of the set-top box.

Cleaning

- Always unplug the set-top box before you clean it.
- Do not use liquid or aerosol cleaners.
- You should clean the set-top box with a soft, cloth that is barely damp.

Ventilation

- The slots and openings on the set-top box are for ventilation (allowing air into the box to keep it cool). Do not cover or block them as this could cause the set-top box to overheat.
- Never let children push anything into the slots or openings in the case.

Servicing

- There are no parts in the set-top box which you can repair yourself
- If your set-top box doesn't work or has a fault, always take it to a qualified engineer.
- Always talk to staff in the shop where you bought the set-top box if you have any questions about installing it or how it works, or for safety instructions.

Getting rid of batteries

- Always make sure you get rid of batteries safely. Check with your local authority for how you should get rid of batteries.
- Never put batteries on a fire, or in the bin with household waste.



Goodmans



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>