



2-9868

Digital Answerer User's Guide



FCC REGISTRATION INFORMATION

Your telephone equipment is registered with the Federal Communications Commission and is in compliance with parts 15 and 68, FCC Rules and Regulations.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the FCC Registration number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.
- Consult the dealer or an experienced radio/TV technician for help.



If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

TABLE OF CONTENTS

FCC REGISTRATION INFORMATION	2
INTERFERENCE INFORMATION	2
BEFORE YOU BEGIN	4
PARTS CHECKLIST	4
MODULAR JACK REQUIREMENTS	4
INSTALLING THE BATTERY	4
INSTALLATION	5
IMPORTANT INSTRUCTIONS FOR MOVING THE ANSWERER	6
SETUP	6
RECORDING THE GREETING	6
REVIEWING THE SETTINGS	7
CHANGING THE SETTINGS	7
SETTING THE TIME	7
TO SET THE HOUR	7
TO SET THE MINUTES	7
TO SET THE DAY	8
SETTING THE RINGS TO ANSWER	8
SETTING THE INCOMING MESSAGE LENGTH	8
SETTING THE SECURITY CODE	9
ADJUSTING THE VOLUME	9
ANSWERER OPERATION	10
ANSWER ON/OFF INDICATOR	10
MESSAGES INDICATOR	10
PLAYING MESSAGES	11
ERASING ALL MESSAGES	11
LEAVING A MEMO	12
2-WAY RECORD	12
SCREENING CALLS (AUTO DISCONNECT FEATURE)	12
REMOTE ACCESS	13
GENERAL PRODUCT CARE	14
SERVICE	15
TROUBLESHOOTING TIPS	16
INDEX	17
LIMITED WARRANTY	18
REMOTE ACCESS CARD	19

**FCC NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM**


WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

	CAUTION RISK OF ELECTRICAL SHOCK DO NOT OPEN	
THE LIGHTNING FLASH AND ARROW-HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF DANGEROUS VOLTAGE INSIDE THE PRODUCT.	CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.	THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.
SEE MARKING ON BOTTOM / BACK OF PRODUCT		


BEFORE YOU BEGIN

PARTS CHECKLIST

Make sure your package includes the following items:




Answerer



AC power supply

MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.





INSTALLING THE BATTERY

In the event of a power loss, a 9-volt battery (not included) enables the answerer to retain messages stored in memory. To install the battery:

1. Remove the battery compartment door on the bottom of the unit by loosening the screw with a Phillips screwdriver. Lift the door.
2. Connect a fresh 9-volt alkaline battery (not included). The large and small contacts on the battery clip and the battery will interlock. Once connected, place the battery inside the battery compartment.
3. Replace the battery compartment door and tighten the screw.


Battery compartment door




NOTE: If the battery is low or not installed, the unit announces "Low Battery" at the end of your messages.

INSTALLATION


1. Plug the telephone line cord into a modular wall jack.



2. Connect the telephone line cord from your telephone into the jack on the back of the answerer marked PHONE. (You don't have to connect your telephone in order for the answerer to record incoming messages.)



3. Connect the small end of the power supply into the POWER 9V AC jack on the back of the answerer. Plug the other end into an AC power outlet. The unit beeps 3 times and is ready for setup or to answer calls with the default greeting and settings.



INSTALLATION INFORMATION

- Never install telephone wiring during a lightning storm.
- Never touch uninsulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

NOTE: Only use the Thomson 5-2434A power supply that was packed with this unit. Using other power supplies may damage the unit.

IMPORTANT INSTRUCTIONS FOR MOVING THE ANSWERER:

To move the answerer to a different location in the house, follow these instructions:

1. Disconnect the phone line or any phones you may have connected to the unit.
2. Install a battery, if you have not already done so. This will ensure that your messages are not lost. See "Installing the Battery".
3. Go to the electrical outlet and unplug the power supply. **DO NOT UNPLUG THE POWER JACK CONNECTED TO THE UNIT.** If you do, all memory will be erased.
4. Move the unit and phone line to the desired location.
5. Plug in the power supply into an electrical outlet.
6. The MESSAGES indicator shows that the messages have not been erased.
7. Connect all necessary phone lines.

SETUP

RECORDING THE GREETING

Before using your new answerer, you should record a greeting (the announcement callers hear when your answering system answers a call). If you don't record a greeting, callers hear a default greeting which says, *"After tone, record message."*

When recording the greeting you should be about 6 inches from the unit. Eliminate as much background noise as possible.

1. Prepare your greeting.

Sample Greeting: *Hi, this is (use your name here). I can't answer the phone right now, so please leave your name, number, and a brief message after the tone, and I'll get back to you. Thanks.*

2. Hold down the GREETING button. Record after the tone.
3. Release GREETING when you finish.

To review the greeting, press and release GREETING.

To return to the answerer's default greeting after you've recorded one, press GREETING and release it when you hear the tone, or press erase when the greeting is playing.

REVIEWING THE SETTINGS

This function allows you to review the current time, number of rings before the unit answers a call, incoming message length, and the security code. Press and release the SET button to review the current settings. To review the next or previous setting, press the NEXT or PREVIOUS button. The unit announces the current setting.

NOTE: To exit review, press and release the ALL or NEW buttons.

CHANGING THE SETTINGS

Press and hold the SET button to enter the change mode. The unit announces the current time and day. To change, press NEXT or PREVIOUS. To set and go on to the next item, press SET.

NOTE: To scroll from one setting to the next, press and release SET. To exit the change list, press ALL or NEW.

SETTING THE TIME

TO SET THE HOUR

1. Press and release NEXT or PREVIOUS until the unit announces the correct hour.
2. Once the hour is set, press SET to enter the minutes menu.


TO SET THE MINUTES

1. Press and release NEXT or PREVIOUS until the unit announces the correct minutes.
2. Once the minutes are set, press SET to enter the day menu.

Default Settings

Time	12 a.m. Sunday
Rings to Answer	4
Message Length	2 minutes
Security Code	123

SET
button



PREVIOUS
button

NEXT
button

Range of Settings

Time	
Hour	12 a.m. - 11 p.m.
Minute	0 - 59
Day	Sunday - Monday
Rings to Answer	2, 3, 4, 5, toll saver
Message Length	1, 2, 3, 4 minutes
Security Code	0 - 9, 0 - 9, 0 - 9

TO SET THE DAY

1. Press and release NEXT or PREVIOUS until the unit announces the correct day.
2. Once the day is set, press SET to enter the rings to answer menu.

SETTING THE RINGS TO ANSWER

The unit announces the rings to answer. To change, press NEXT or PREVIOUS. To set and go on to the next item, press SET.


1. Press and release NEXT or PREVIOUS until the unit announces the correct number of rings for the answer to pick up.
2. Once the rings to answer is set, press SET to enter the incoming message length menu.

SETTING THE INCOMING MESSAGE LENGTH

The unit announces the current message length. To change, press NEXT or PREVIOUS. To set and go on to the next item, press SET.

1. Press and release NEXT or PREVIOUS until the unit announces the correct incoming message length.
2. Once the length is set, press SET to enter the security code menu.

SET
button




PREVIOUS
button

NEXT
button

SETTING THE SECURITY CODE

The unit announces the current security code. To change, press NEXT or PREVIOUS. To set and exit press SET.

1. Press and release NEXT or PREVIOUS to choose the first digit. The unit announces all 3 digits, but only the selected digit will change.
2. Once you have the desired first digit, press SET to save it and move on to the second digit.
3. Press and release NEXT or PREVIOUS to choose the second digit. Only the second digit will change.
4. Once you have the desired second digit, press SET to save it and move on to the third digit.
5. Press and release NEXT or PREVIOUS to choose the third digit. Only the third digit will change.
6. Once you have the desired third digit, press SET to save it. The answerer repeats all the settings.




NOTE: To exit any menu, press and release the ALL or NEW buttons. Also, setup will cancel if no buttons have been pushed within 30 seconds.

IMPORTANT: The setup settings will not be erased even after a power outage.

ADJUSTING THE VOLUME

Use the VOLUME + and - buttons to increase the volume up and down. The unit beeps when it is not announcing a setting or playing a message.

ANSWERER OPERATION



ANSWER ON/OFF INDICATOR

The ANSWER ON/OFF indicator lets you know whether your answerer is on or off. When the answerer is off, it answers calls after 10 rings but doesn't play the greeting. The answerer doesn't take messages when it is off.

Indicator is on — Answerer is on.

Indicator is off — Answerer is off, but you might still have messages.

NOTE: Even though the answerer is off, playing messages, reviewing/changing the settings, and reviewing/changing the greeting function normally.

MESSAGES INDICATOR

The MESSAGES indicator lets you know when you have new or old messages.

- **Indicator is on** — There are no new messages, but there are old ones.
- **Indicator is off** — There are no messages or the answerer is turned off.
- **Indicator is flashing slowly** — There are new messages.
- **Indicator is flashing rapidly** — The answerer's memory is full.

NOTE: An old message is one that has been listened to completely, including the time/day stamp. A new message is one that HAS NOT been listened to completely.

PLAYING MESSAGES


Either old or new messages can be played. To hear all of the messages, including the new ones, press and release the ALL button. To hear only new messages, press and release NEW.

- To play messages, press and release ALL or NEW.
- To stop playback, press and release ALL or NEW again.
- To restart the message that is playing, press and hold PREVIOUS.
- To go back to the beginning of a previous message, press and release PREVIOUS.
- To skip to the beginning of the next message, press and release NEXT.
- To fast forward within a message, press and hold NEXT.
- To erase a message while it is playing, press and release the ERASE button. The answerer announces, "Message Erased" to confirm the message has been erased.

ERASING ALL MESSAGES

When the answerer isn't playing or recording messages, press and hold ERASE until you hear the "Messages Erased" announcement. If you do not have any messages, the unit will announce, "Zero Messages" if ERASE is pressed and held.

NOTE: New messages must be heard **completely**, including the time/day stamp, before they can be erased.



REMOTE ACCESS

You can access your answerer from any touch-tone phone by entering your 3-digit security code (the default security code is 123, but you can change it.) Be aware that remote functions do not work with rotary or push-button pulse-dialing phones. You can cut out the wallet-size remote card on page 19 so you know the touch-tone commands when you're picking up messages from another location.

To access your answerer:

1. Call your telephone number.
2. After you hear the beep that follows the greeting, enter your 3-digit security code. To bypass the greeting, you can enter your 3-digit security code any time while the greeting is playing.
3. The unit plays the remote menu after the correct security code has been entered. Menu selections can be made while the menu is playing.

NOTE: The unit answers on the 10th ring when it is turned off or the memory is full. To access the answerer, enter the 3-digit security code after the beep. If memory is full, play messages and erase some of them to restore memory. If the answerer is off, press 2 to turn it on.

NOTE: After the unit plays the remote menu, it will wait 10 seconds for a command, then disconnect.

GENERAL PRODUCT CARE

To keep your answerer working and looking good, follow these guidelines:

- Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping answerer and/or other rough treatment.
- Clean with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship it at a later date.

SERVICE

FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by Thomson Consumer Electronics could void the user's authority to operate this product. For instructions on how to obtain service, call Consumer Information at **1-800-448-0329**.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____

Name of store _____

TROUBLESHOOTING TIPS

<i>Problem</i>	<i>Explanation/Solution</i>
Doesn't answer, or answers on 10th ring	<ul style="list-style-type: none">• Make sure answerer is turned on.• Memory is full, erase some messages.• Check AC power and phone line connections.
Incoming messages are incomplete	<ul style="list-style-type: none">• Was an extension phone picked up?• The caller left a message that is longer than the message length you set during setup.• Memory is full.• You accidentally pressed ALL or NEW when you were playing the messages.
Won't respond to remote commands	<ul style="list-style-type: none">• Must use touch-tone phone.• Must enter correct security code.• Did unit hang up? If you take no action for a period of time, it automatically hangs up.
Answerer doesn't work	<ul style="list-style-type: none">• Unplug power cord from the electrical outlet and plug it back in to reset the answerer. If that doesn't work, unplug the power cord from the back of the unit and plug it back in. This is a complete reset.
Can't hear messages	<ul style="list-style-type: none">• Adjust volume control.
Unit announces "Battery Low"	<ul style="list-style-type: none">• Install a new 9-volt alkaline battery.
Can't restart message	<ul style="list-style-type: none">• You must play message for at least 5 seconds before pressing REVIEW button.
Messages indicator flashes rapidly	<ul style="list-style-type: none">• Memory is full. Erase messages.
Battery good but messages were lost	<ul style="list-style-type: none">• Was the AC power supply unplugged from back of unit?
Greeting continues to play even after an extension phone is picked up	<ul style="list-style-type: none">• This is normal operation. Auto disconnect is delayed for 2 seconds after the unit answers a call. If you are near the unit, press ALL or NEW to stop the greeting.

INDEX

Symbols

2-way record 12

A

Adjusting the volume 9
ANSWER ON/OFF indicator 10

B

Before you begin 4

C

Changing the settings 7

E

Erasing all messages 11

F

FCC registration information 2

G

General product care 14

I

Installation 5
Installing the battery 4
Interference information 2

L

Leaving a memo 12
Limited warranty 18

M

MESSAGES indicator 10
Modular jack requirements 4
Moving the answerer 6

P

Parts checklist 4
Playing messages 11

R

Remote access 13

S

Screening calls
 (auto disconnect feature) 12
Service 15
Setting the incoming message length 8
Setting the rings to answer 8
Setting the security code 9
Setting the time 7
Setup 6

T

To access your answerer 13
To set the day 8
To set the hour 7
To set the minutes 7
Troubleshooting tips 16

LIMITED WARRANTY

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- One year.

What we will do:

- Provide you with a new, or at our option, a refurbished unit.
- The exchange unit is under warranty for the remainder of the original product's warranty period.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- Include in the package evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send standard UPS or its equivalent to:

Thomson Consumer Electronics, Inc.
11721 B Alameda Ave.
Socorro, Texas 79927

- A new or refurbished unit will be shipped to you prepaid freight.

What your warranty *does not* cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments.
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of nature, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

- This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

If you purchased your product outside the USA:


- This warranty does not apply. Contact your dealer for warranty information.

Cut out this remote access card so that you can take it with you to help you use the remote features.

FOLD

Write your 3-digit security code here.

1. Dial phone number of the answerer.
2. Enter 3-digit security code during greeting or after the beep.
3. Enter touch-tone command.
4. Hang up.



Digital Answerer

2-9868

To:	Press:
Play messages	1
Play previous message	7
<i>(during message playback)</i>	
Skip to next message	9
<i>(during message playback)</i>	
Erase message	0
<i>(During message playback)</i>	
Turn on answerer	2
Turn off answerer	3
Leave a memo	4
<i>(press 6 again when finished)</i>	
Record greeting	5
<i>(press 6 again when finished)</i>	
Stop playback	6
<i>(during message playback)</i>	
To set security code	7
Play greeting	8
Erase message	0

Model 2-9868
15380380 (Rev. 1 E/S)
98-51
Printed in China

 **THOMSON CONSUMER ELECTRONICS**

P.O. Box 1976, Indianapolis, IN 46206
© 1998 Thomson Consumer Electronics, Inc.
Trademark(s) ® Registered
Marca(s) Registrada(s)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>