





INTRODUCTION

Your GE Digital Answer-Phone™ is designed to give you flexibility in use, and high quality performance. To get the most from your new telephone, we suggest that you take a few minutes right now to read through this instruction manual. If you have any questions or problems, consult the Table of Contents, the Troubleshooting Guide, or the Index for the solution.

TABLE OF CONTENTS


- INSTALLATION AND SETUP 2
 - BEFORE YOU BEGIN 2
 - BATTERY INSTALLATION 3
 - TABLETOP INSTALLATION 4
 - WALL MOUNT INSTALLATION 5
 - BATTERY LOW INDICATOR 7
 - ANSWERING MACHINE SETUP 7
 - CHOOSING/RECORDING AN OUTGOING ANNOUNCEMENT 8
- TELEPHONE OPERATION 9
 - FLASH BUTTON 9
 - REDIAL BUTTON 10
 - TEMPORARY TONE FEATURE 10
- MEMORY DIALING 11
 - STORING A NUMBER IN MEMORY 11
 - DIALING A NUMBER FROM MEMORY 12
- ANSWERING MACHINE OPERATION 13
 - MESSAGE PLAYBACK 13
 - ERASING MESSAGES DURING MESSAGE PLAYBACK 13
 - LEAVING A MEMO 14
 - CALL SCREENING/AUTO DISCONNECT 14
 - TOLL SAVER FEATURE 15
 - ACCESSING THE ANSWERER FROM ANOTHER LOCATION 15
- TROUBLESHOOTING TIPS 16
- CARE AND MAINTENANCE 18
- SERVICE 18
- INDEX 19
- LIMITED WARRANTY 20

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

 <small>THE LIGHTNING FLASH AND ARROW HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.</small>	<div style="border: 1px solid black; padding: 2px; font-weight: bold; font-size: small;">CAUTION</div> <small>RISK OF ELECTRIC SHOCK DO NOT OPEN</small> <small>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</small>	 <small>THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.</small>
SEE MARKING ON BOTTOM / BACK OF PRODUCT		

PARTS CHECKLIST

Your package should contain the following items:



Base unit




Handset



Long handset cord



Phone line cord



AC power adapter 5-2399


INSTALLATION AND SETUP

Your GE Digital Answer-Phone™ can be mounted on the wall or placed on a counter top or table top. After you decide which type of installation you want, refer to the appropriate installation diagram.

BEFORE YOU BEGIN

MODULAR JACK REQUIREMENTS


You need a USOC: RJ11C type modular jack, similar to the one pictured here. If you don't have a modular jack, call your phone company to find out how to get one installed.



BATTERY INSTALLATION

In the event of a power loss, the 9-volt alkaline battery backup enables the answerer to retain messages stored in memory, the outgoing announcement, and time/day information.

1. Unplug the telephone line from the modular jack on the wall.
2. Open the battery compartment door with a flat tool.
3. Insert a 9-volt alkaline battery (not included), as shown on the diagram inside the battery compartment.
4. Snap battery compartment door into place.




NOTE: When the battery needs to be replaced, the BATT. LOW indicator flashes.

BATTERY SAFETY PRECAUTIONS

For your safety, please follow these precautions:

- Do not recharge, disassemble, mutilate, wet, or dispose of batteries in fire.
- Keep batteries out of reach of children.
- Replace with 9V battery only (not included).
- When replacing batteries, be sure to unplug the phone line from the unit before opening the battery compartment door and inserting the batteries.

TABLETOP INSTALLATION



1. Plug the telephone line cord into PHONE LINE jack on the back of the unit and the other end into a modular jack RJ11C .
2. Plug the handset cord into the handset and into the telephone jack on the left side of the unit.
3. Set the PULSE/TONE switch on the left side of the phone to TONE if you use touch-tone service; set it to PULSE if you have rotary service.
4. Adjust the RINGER volume switch on the left side of the phone to the desired setting (the phone will only ring with the ringer set to LO or HI).
5. Adjust the ANSWERER volume switch on the right side of the phone to the desired setting.
6. Plug the AC power adapter into the phone and into an AC outlet.


NOTE: Only use the Thomson 5-2399 AC adapter that came with this unit. Using other adapters may damage the unit.

NOTE: Make sure that you have inserted the battery before installing the phone. If you have not, see p. 3 for battery installation information.


WALL MOUNT INSTALLATION

Your phone can be mounted on a wall phone plate (not included). Before you mount the phone on the wall, write down the 3-digit security code that is on the underside of the phone. You need to know this code in order to pick up your messages from another phone.

1. Rotate the handset hook one-half turn.




2. Plug one end of the telephone line cord into the jack marked PHONE LINE on the back of the unit. Wrap the excess cord around the plastic tabs. Plug the other end of the telephone line cord into a modular wall jack.




3. Attach the wall mount bracket by turning the T-shaped bracket upside down, as pictured. Then put the tabs at the bottom of the bracket into the matching slots near the bottom of the unit and snap the top tab into place.
4. Plug the AC adapter into the back of the phone and into an AC outlet.

- Slip the mounting holes over the wall plate posts and slide the unit down firmly into place.



- Plug one end of the handset cord into the handset and the other end into the unit. Hang up the phone.


- Set the PULSE/TONE switch on the left side of the phone to TONE if you use touch-tone service; set it to PULSE if you have rotary service.



- Adjust the RINGER volume switch on the left side of the phone to the desired setting (the phone will only ring with the ringer set to LO or HI).

- Adjust the ANSWERER volume switch on the right side of the phone to the desired setting.

NOTE: Make sure that you have inserted the battery before installing the phone. If you have not, see p. 3 for battery installation information.



6

BATTERY LOW INDICATOR

When a battery has not been installed or needs to be replaced, the BATT. LOW indicator flashes rapidly.

ANSWERING MACHINE SETUP

This section shows you how to set up your answering machine to receive incoming calls. Before you begin the setup, you must be sure the answerer is on.

TURNING ON THE ANSWERING MACHINE

Press and hold the ANS.ON button to turn the answering machine on and off (the unit beeps twice and a voice prompts "functions on" or "functions off").


NOTE: The unit takes approximately 10 seconds to emit the voice prompts "functions on" and/or "functions off."

When the answerer is on, the MESSAGES/ANSWER ON indicator lights. When the day and time need to be set or the outgoing announcement needs to be recorded, the MESSAGES/ANSWER ON indicator light flashes rapidly.

SETTING THE VOICE TIME/DAY


- Press and hold the DAY button to set the day of the week.
- Press the HOUR button to set the hour (a.m. or p.m.).
- Press the MINUTE button to set the minute. When you hold the MINUTE button, it advances the time in 5-minute increments.
- Press and quickly release the DAY button to review the day/time setting.

MESSAGES/ANSWER ON indicator light



ANS. ON button

BATT. LOW indicator light





CHOOSING AN OUTGOING ANNOUNCEMENT OPTION

The outgoing announcement is the announcement callers hear when they call you and your answering system picks up the call. You can record a personalized outgoing announcement or use the default announcement that is programmed into the answering system.

USING THE DEFAULT ANNOUNCEMENT

If you choose to use the default announcement, callers will hear, *"Please leave your message after the tone."*

This announcement also serves as the default announcement when the answering system loses power and is completely reset (unless you installed a 9-volt battery). If you installed the battery and recorded a personalized outgoing announcement, your answerer does not default to this announcement because your personalized outgoing announcement is retained in memory by the battery power.

If you recorded a personalized outgoing announcement and then decide that you want to use the default announcement instead, press the ANNOUNCE button and release it within 1 second after the unit beeps.

RECORDING A PERSONALIZED OUTGOING ANNOUNCEMENT

When recording your outgoing announcement, you should be about 9 inches from the MIC, located on the front of the unit, and eliminate as much background noise as possible.

1. Press and hold the ANNOUNCE button.
2. Begin talking after you hear the tone.
3. Release the ANNOUNCE button when you're finished talking.

SAMPLE OUTGOING ANNOUNCEMENT

Hi, this is (use your name here), I can't answer the phone right now, so please leave your name, number and a brief message after the tone, and I'll get back to you. Thanks.

REVIEWING THE OUTGOING ANNOUNCEMENT

You can review the outgoing announcement by pressing and quickly releasing the ANNOUNCE button.

NOTE: You can stop the outgoing announcement by pressing STOP while the announcement is playing.

TELEPHONE OPERATION

MAKING A CALL

1. Pick up the handset to get a dial tone.
2. Dial the number.


RECEIVING A CALL

Make sure that the RINGER (on the side of the unit) is set to LO or HI.

1. Pick up the handset when the phone rings.
2. Put handset in cradle when finished with conversation.

FLASH BUTTON

To activate custom calling services such as call waiting or call transfer, press the FLASH button instead of using the hook switch. (Custom calling services are provided by your local phone company.)



FLASH button


REDIAL BUTTON


Redial the last number you called by pressing the REDIAL button after you get a dial tone.

NOTE: Your phone's memory retains the last phone number you dialed (as many as 32 digits). If you pressed any numbers after dialing the phone number, (for example, when accessing a voice-menu system) those numbers are also redialed.

TEMPORARY TONE FEATURE

The temporary tone feature enables a pulse phone to temporarily change to a tone phone. People with pulse-tone (rotary) service would use this feature in order to access voice information that requires touch-tone service, such as getting information from a local bank or using a voicemail system. To use temporary tone:

1. Dial the number of the service.
2. Press the tone button () after you have connected to the service in order to enable touch-tone dialing.
3. When you hang up, the phone automatically returns to pulse dialing mode.



MEMORY DIALING

Store as many as 10 numbers in memory for easy dialing. Numbers can be stored in the numbered keys (0-9).

STORING A NUMBER IN MEMORY


1. Pick up the handset.
2. Press STORE.
3. Dial the number to be stored.
4. Press STORE followed by a Memory Location (0-9 on the keypad).
5. Write the phone number on the memory directory (located in the cradle area of the base, under the plastic cover).

ADDING A PAUSE TO THE DIALING SEQUENCE

Use the REDIAL button to insert a pause in the dialing sequence when storing a number (for example, when you must dial 9 to get an outside line or enter codes to access your bank's information line). Press REDIAL at the point in the dialing sequence in which a pause is required.

For example, if you want to add a pause to the dialing sequence when storing a number in memory because you must dial 9 to get an outside line:

1. Pick up the handset.
2. Press STORE.
3. Press 9.
4. Press REDIAL to add a pause and then dial the phone number to be stored in memory.
5. Press STORE followed by a Memory Location (0-9 on the keypad).



STORE button

MEMORY DIAL button



CHANGING A STORED NUMBER

Change a stored number by replacing it with a different number (see "Storing a Number in Memory"). Be sure to update your memory directory when you change numbers.

DIALING A NUMBER FROM MEMORY


You can dial numbers from memory when using the handset. When you get a dial tone, press the MEMORY DIAL button followed by the Memory Location (0-9) for the number you want to dial.

CAUTION: If you make test calls to emergency numbers, remain on the line and explain the reason for the call. Also, make these calls in off-peak hours, such as early morning or late evening.



ANSWERING MACHINE OPERATION

This section discusses the buttons and features on the answering machine.



MESSAGE PLAYBACK

The MESSAGES/ANSWER ON indicator light lets you know when somebody has left a message. When you have new messages the light blinks. If you have old messages that have not been erased, the light stays on. To hear messages, press and release the PLAY•STOP button. Incoming messages are limited to 3 minutes each. Press and hold PLAY•STOP for 2 seconds to hear only new messages. (If no new messages, old messages will play).

While a message is playing, you can do the following:

- Press PLAY•STOP to stop message playback.
- Press and release REVIEW to restart the current message; continue to press and release REVIEW to go to previous messages.
- Press and hold REVIEW to review current message.
- Press and release SKIP to go to the next message.
- Press and hold SKIP to fast forward through current message.

ERASING MESSAGES DURING MESSAGE PLAYBACK

Press and release the ERASE button to erase the message that is playing.

NOTE: Messages erased during playback cannot be restored.



TOTAL MESSAGE ERASE

You can erase all the messages from memory by pressing and holding the ERASE button when the unit is not playing messages (the unit beeps to confirm the messages are erased). Note that total message erase cannot be completed if there are any unplayed messages.

NOTE: If you hear several high-pitched beeps, your answerer has not erased the messages because some of them or all of them have not been played.

You can restore messages erased this way by pressing the PLAY•STOP button—but only if you haven't activated any other answerer functions or received new messages after erasing the messages.

LEAVING A MEMO

Leaving a memo is just like recording an outgoing announcement, except you use the MEMO button instead of the ANNOUNCE button.

1. Press and hold MEMO.
2. When you hear a beep, continue holding MEMO and leave your message.
3. Release MEMO when you finish your message.

The memo is included in the message count represented by the number of times the MESSAGES/ANSWER ON indicator light flashes.

CALL SCREENING/AUTO DISCONNECT

Because the answerer automatically stops recording when an extension phone is picked up (Auto Disconnect feature), you can screen incoming calls. Listen as the caller leaves a message and pick up the handset (or any extension phone) if you want to talk to that caller.

MEMORY FULL

When the memory is full, you must erase old messages so that there is room in the memory for new messages.

If the memory is full, the unit answers on the 10th ring and the MESSAGES/ANSWER ON light flashes rapidly. When using the remote access feature, you can enter your security code and then access your messages.

NOTE: The unit answers on the 10th ring when it is turned off or the memory is full. To access the answerer, enter the 3-digit security code after the beep. If memory is full, play messages and erase some of them to restore memory. If the answerer is off, press 6 to turn it on.



ACCESSING THE ANSWERER FROM ANOTHER LOCATION

You can access your answering machine from a touch-tone phone by entering the three-digit, security code after you hear the announcement. The security code is located on the underside of your telephone.

1. Dial the phone number for the answering machine.
2. Enter the 3-digit security code after you hear the tone.
3. Follow the voice menu instructions to perform the answerer functions.

The remote feature enables you to perform the following functions:

<i>To</i>	<i>Press this Button</i>
Play message	1
Repeat message	8 (while messages are playing)
Play previous message	7 (while messages are playing)
Stop message playback	3 (while messages are playing)
Erase message	0 (while messages are playing)
Skip message	9 (while messages are playing)
Turn answerer off	5
Turn answerer on	6
Record new announcement	8
Leave a message	7
Play outgoing announcement	2

TIP: You can bypass the outgoing announcement by pressing any numbered key on the keypad while the announcement is playing. Then, after the beep you can enter your security code to access the answering machine.

TOLL SAVER FEATURE

If you call to retrieve messages and there are no saved messages or new messages, the unit answers on the 5th ring. If there are new messages, the unit answers on the 2nd ring. If you're calling long distance or from a pay phone to pick up your messages, you can hang up after 3rd ring and save the cost of the call.



TROUBLESHOOTING TIPS

TELEPHONE PROBLEM	SOLUTION/EXPLANATION
No dial tone Can't dial out	<ul style="list-style-type: none">• Check hook switch to make sure it pops up.• Make sure TONE/PULSE is set to correct position.• Unplug the phone, wait 30 seconds, and plug the phone back in.
Phone doesn't ring	<ul style="list-style-type: none">• Check RINGER VOLUME.• Could have too many phones on one line. (See FCC information regarding REN)
Light and tone feedback flutter when dialing in pulse mode.	<ul style="list-style-type: none">• This is normal as power is fluctuating with phone outpulsing.
Can't be heard by other party	<ul style="list-style-type: none">• Make sure phone cord is securely plugged in.
Memory dialing problems	<ul style="list-style-type: none">• Make sure you entered numbers correctly. (See "Memory Dialing.")



ANSWERING MACHINE PROBLEM	SOLUTION/EXPLANATION
Can't hear messages	<ul style="list-style-type: none">• Adjust answerer volume (p.4)
Time/Day Stamp stuck at 1 a.m Monday	<ul style="list-style-type: none">• Set the time/day clock (p. 7).
Answers on 10th ring	<ul style="list-style-type: none">• Make sure answerer is turned on.• Memory is full. Play messages and erase them. (p. 14)
Incoming messages are incomplete	<ul style="list-style-type: none">• Was an extension phone picked up while the caller was leaving a message?• Memory is full.• You accidentally pressed the PLAY•STOP button during playback and stopped the message.
Won't respond to commands when you call machine from another location	<ul style="list-style-type: none">• Must use a tone-dial phone.• Must enter correct security code (p. 15)• Did the unit hang up? If you take no action for a period of time, it automatically hangs up.
Answer function operates erroneously or not at all.	<ul style="list-style-type: none">• Unplug the power cord from the back of the unit and plug it back in to reset the answerer.





CARE AND MAINTENANCE

To keep your GE telephone working and looking good, follow these few simple guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise. (i.e., motors, fluorescent lamps.)
- Phone should not be exposed to direct sunlight or moisture.
- Avoid dropping the handset and other rough treatment.
- Clean telephone with a soft cloth. (Remember to first unplug the phone from the wall outlet.)
- Never use a strong cleaning agent or abrasive powder, as this will damage the finish.
- Retain the original packaging for future use.

SERVICE

The FCC requires this product be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by Thomson Consumer Electronics could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this guide or call customer service's telephone number: 800-448-0329.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____

Store Name _____



INDEX

A
ANS. ON button 7
Answering machine setup 7
Accessing answering machine from
another location 15

B
Battery Installation 3
Battery safety precautions 3
BATT. LOW indicator 7

C
Care and maintenance 18

E
ERASE button 13
Erasing messages 13, 14

F
FLASH button 9

H
Handset 2

M
Memo 14
Memory dialing
storing a number 11
dialing a stored number 12
Message playback 13
Modular jack 2

O
Outgoing announcement 8
recording 8
reviewing 8

P
Parts checklist 2
Pulse (rotary) service 4, 6, 10
PULSE/TONE switch 4, 6

R
REDIAL button 10
Remote access
from another location 15
Review an outgoing announcement 8
REVIEW button 13
RINGER volume switch 4, 6

S
Security code 15
Service 18
Setup 2-7
SKIP button 13
STOP button 13

T
Tabletop installation 4
Temporary tone feature 10
Time/Day stamp, setting up 7
Troubleshooting tips 16

W
Wall mount installation 5



LIMITED WARRANTY

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- Two years.

(The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

What we will do:

- Provide you with a new, or at our option, a refurbished unit.
- The exchange unit is under warranty for the remainder of the original product's warranty period.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- Include in the package evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send standard UPS or its equivalent to:

Thomson Consumer Electronics, Inc.
Product Exchange Center
32 Spur Drive
El Paso, Texas 79906

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- A new or refurbished unit will be shipped to you prepaid freight.

What your warranty *does not* cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments.
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of God, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

- This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

If you purchased your product outside the USA:

- This warranty does not apply. Contact your dealer for warranty information.

Model 2-9827A
347A8329-0001 (Rev. 2 E/S)
97-15
Printed in China

 **THOMSON CONSUMER ELECTRONICS**

P.O. Box 1976, Indianapolis, IN 46206
© 1997 Thomson Consumer Electronics, Inc.
Trademark(s) ® Registered
Marca(s) Registrada(s)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>