




Coffee Urn Urne à café Cafetera



**READ BEFORE USE
LIRE AVANT L'UTILISATION
LEA ANTES DE USAR**

840146700

106840R

**For Customer Assistance, call Customer Service at
1-877-207-0923 (US) or 1-877-556-0973 (Canada)**

Pour l'assistance à la clientèle au Canada : 1-877-556-0973

**Para comunicarse con Asistencia al Cliente en México: 01-800-343-7378
Le invitamos a leer cuidadosamente este instructivo antes de usar su aparato.**

WARNING

Shock Hazard

- Do not immerse this appliance in water or other liquid.
- If the plug on this appliance does not fit in your outlet:
 - Do not modify the plug.
 - Do not use an adaptor.
 - Have an electrician replace the obsolete outlet.

IMPORTANT SAFEGUARDS

When using electric appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs. Care must be taken, as burns can occur from touching hot parts or from spilled, hot liquid.
3. To protect against fire, electric shock, and injury to persons do not immerse cord, plug or any part of the coffeemaker in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when the coffeemaker is not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the appliance.
6. Coffeemaker must be operated on a flat surface away from the edge of counter to prevent accidental tipping.
7. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. Call our toll-free customer assistance number for information on examination, repair or adjustment.
8. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electrical shock or injury to persons.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter or touch hot surfaces, including stove.
11. Lock cover securely in place during brew cycle and when serving coffee.
12. Scalding may occur if cover is removed during brew cycle.
13. Do not place coffeemaker on or near a hot gas or electric burner or in a heated oven.
14. Always attach plug to appliance first, then plug cord into wall outlet. To disconnect coffeemaker, remove plug from wall outlet, then unplug from coffeemaker.
15. Warning: To reduce the risk of fire or electric shock, do not remove the bottom cover. No user serviceable parts are inside. Repair should be done by authorized service personnel only.
16. Do not use appliance for other than intended use.

SAVE THESE INSTRUCTIONS!

Other Consumer Safety Information

This appliance intended for household use only.


The length of the cord used on this appliance was selected to reduce the hazards of becoming tangled in, or tripping over a longer cord.

If a longer cord is necessary an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the coffeemaker. Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

To avoid an electrical circuit overload, do not use another high wattage appliance on the same circuit with your coffeemaker.

PARTS AND FEATURES

1. Cover
2. Coffee Basket
3. Stem
4. Heating Unit Well
5. Serving Spout
6. Dispensing Bar
7. Ready Light




TO MAKE COFFEE

Before First Use: Clean the coffee urn by following the steps in "How To Clean."

1. To make coffee, remove cover, coffee basket and stem. Fill coffee urn with cold water to desired level as indicated by numbered servings on inside of urn.
2. Place stem into coffee basket. Then holding the center post of the coffee basket place large end of stem into heating unit well.
3. Measure ground coffee into coffee basket. Avoid getting ground coffee in the stem. Refer to the Coffee Making Chart that follows. Spread coffee evenly in basket.
4. Place cover onto coffee urn and turn to lock.
5. Plug cord into the coffee urn then plug the cord into electrical outlet. The unit automatically turns on.
6. The coffee urn will stop automatically when the coffee has finished brewing, and the Ready light will glow. Allow about 1 minute per cup for brewing time.
7. Using a hot mitt, remove cover then carefully remove coffee basket with HOT grounds and stem. Replace cover.

NOTE: The coffee urn will remain at serving temperature until it is unplugged.

8. **To serve coffee:** press a cup against the dispensing bar; remove cup when it is filled to desired level.



NOTE: Do not lift or pull dispensing bar away from unit. Coffee should only be dispensed by pressing cup against dispensing bar.

9. When finished serving coffee, unplug the coffee urn from the electrical outlet. Then remove cord from the coffee urn.

USING YOUR ELECTRIC KETTLE

Water Level	Amount of Ground Coffee
42 cups (10.5 L)	2½ cups (625 ml)
36 cups (9 L)	2¼ cups (562.5 ml)
30 cups (7.5 L)	1¾ cups (437.5 ml)
24 cups (6 L)	1½ cups (375 ml)
18 cups (4.5 L)	1 cup (250 ml)
12 cups (3 L)	¾ cup (175 ml)

NOTE: We recommend using coffee that has been ground specifically for use in a **percolator-type** coffee maker. Although, coffee marked "For All Coffee Makers" is acceptable. If using a coffee grinder and whole beans, percolator coffee should be a coarse grind. A finely ground coffee may cause the coffee basket to overflow.

TO HEAT WATER

Use heated water to make instant coffee, hot cocoa, or tea.

NOTE: Do not store the unit with water remaining inside.

1. To heat water, remove cover, coffee basket and stem. Fill coffee urn with cold water to desired level as indicated by numbered servings on inside of urn.
2. Place stem into coffee basket then place large end of stem into heating unit well. (Using the stem and basket will speed heating time.)
3. Place cover onto coffee urn and turn to lock. Plug in coffee urn and let go through complete perk cycle. Water is hot when Ready light glows.

HOW TO CLEAN

1. After each use, unplug cord from outlet then remove cord from the coffee urn. Let cool before cleaning.
2. Remove cover, coffee basket and stem. Wash these in hot soapy water. Rinse and dry. These parts can also be placed in dishwasher. Do not put urn in dishwasher.
3. Fill the coffee urn half full with hot water. Add a drop of liquid dishwashing detergent and wash the inside of the coffee urn. Use a scouring pad and clean the inside of the heating unit well. This part must be properly cleaned to maintain the proper operation of the coffeemaker.
4. Drain the soapy water then fill the coffee urn with hot water to rinse. Open serving spout and let hot water flow through to clean the spout. Repeat with another hot water rinse. Dry.
5. Clean outside of coffee urn with a damp cloth. Do not use abrasive scouring pads or cleansers.

TO REMOVE MINERAL DEPOSITS AND BUILDUP

If the coffee urn is used daily follow these instructions every other week. Fill the coffee urn with 1 quart (1 L) cold water and 1 quart (1 L) white vinegar. Assemble with stem, coffee basket and cover.

Plug in and let go through the perk cycle. When perking has stopped let sit another 15 minutes. Unplug and drain the coffee urn. Let cool then clean according to "How To Clean."

TO REMOVE DISCOLORATION

To lighten discolored metal inside the coffee urn, fill the urn to the 42 cup level (10.5 L). Assemble with stem and coffee basket. Place 2 tablespoons plus 1 teaspoon (35 ml) cream of tartar into basket (found in the spice section of supermarket). Place cover onto coffee urn.

Plug in and let go through the perk cycle. When perking has stopped let sit another 15 minutes. Unplug and drain the coffee urn. Let cool then clean according to "How To Clean."

CUSTOMER SERVICE

If you have a claim under this warranty, please call our Customer Assistance Number. For faster service please have model, series, and type numbers ready for operator to assist you. These numbers can be found on the bottom of your appliance.

MODEL: _____ **TYPE:** _____ **SERIES:** _____

Customer Assistance Number 1-877-207-0923 (US) or 1-877-556-0973 (Canada)

Keep these numbers for future reference!

For more information, please visit us at www.walmart.com

Two-Year Limited Warranty

What does your warranty cover?

- Any defect in material or workmanship.

For how long after the original purchase?

- Two years.

What will we do?

- Provide you with a new one.
- For those items still under warranty but no longer available, WAL-MART reserves the right to replace with a similar GE branded product of equal or greater value.

How do you make a warranty claim?

- Save your receipt.
- Properly pack your unit. We recommend using the original carton and packing materials.
- Return the product to your nearest WAL-MART store or call Customer Assistance at 1-877-207-0923 (US) or 1-877-556-0973 (Canada)

What does your warranty not cover?

- Parts subject to wear, including, without limitation, glass parts, glass containers, cutter/strainer, blades, seals, gaskets, clutches, motor brushes, and/or agitators, etc.
- Commercial use or any other use not found in printed directions.
- Damage from misuse, abuse, or neglect, including failure to clean product regularly in accordance with manufacturer's instructions.

How does state law relate to this warranty?

- This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.
- THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY OR CONDITION, WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, INCLUDING, WITHOUT LIMITATION, ANY STATUTORY WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.
- WAL-MART, GE, AND THE PRODUCT MANUFACTURER EXPRESSLY DISCLAIM ALL RESPONSIBILITY FOR SPECIAL, INCIDENTAL, AND CONSEQUENTIAL DAMAGES OR LOSSES CAUSED BY USE OF THIS APPLIANCE. ANY LIABILITY IS EXPRESSLY LIMITED TO AN AMOUNT EQUAL TO THE PURCHASE PRICE PAID WHETHER A CLAIM, HOWEVER INSTITUTED, IS BASED ON CONTRACT, INDEMNITY, WARRANTY, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY, OR OTHERWISE. SOME STATES OR PROVINCES DO NOT ALLOW THIS EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL LOSSES SO THE FOREGOING DISCLAIMER MAY NOT APPLY TO YOU.

What if you encounter a problem with this product while using it outside the country of purchase?

- The warranty is valid only in the country of purchase and you follow the warranty claim procedure as noted.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>