



CONVECTION TOASTER OVEN

Model Number: 169127/169140

UPC: 681131691277 (US)/681131691406 (Canada)

Customer Assistance

1-877-207-0923 (US)

1-877-556-0973 (Canada)



Thank you for purchasing a GE small appliance.

In keeping with the GE ecomagination initiative, please consider the option to recycle the packaging material and donate the appliance you are no longer using.

To read about GE's ecomagination commitment, visit
<http://ge.ecomagination.com>

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- **READ ALL INSTRUCTIONS BEFORE USING.**
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not place cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Call our toll-free customer service number for information on examination, repair or adjustment.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven or in a microwave oven.
- Do not use appliance for other than intended use.
- Do not clean with material scouring pads. Pieces may break off and touch electrical parts.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- When operating the oven keep at least four inches of space on all sides of the oven to allow for adequate air circulation.
- To disconnect, turn the control to OFF, then remove the plug. Always hold the plug, but never pull the cord.
- Extreme caution must be used when moving an appliance containing hot oil, or other hot liquids.
- Do not cover CRUMB TRAY or any part of the Oven with metal foil. This may cause overheating of the OVEN.
- Use extreme caution when removing tray or disposing of hot grease or other hot liquids.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or a risk of electric shock.
- A fire may occur if the oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation. Do not store any item on the Oven during operation.
- Extreme caution should be exercised when using containers constructed of anything other than metal or glass.
- Do not place any of the following materials in the Oven: cardboard, plastic, paper, or other flammable materials.
- Do not store any materials, other than manufacturer's recommended accessories, in this Oven when not in use.
- Always wear protective, insulated oven mitts when inserting or removing items from the hot Oven.
- Avoid scratching door surface or nicking edges. If the door has a scratch or nick, contact our toll-free consumer relations line before using the oven.
- To reduce risk of fire, do not place anything directly on top of appliance surface when in operation.

SAVE THESE INSTRUCTIONS!

CONSUMER SAFETY INFORMATION

This unit is for household use only.

Polarized Plug

This appliance has a polarized plug, (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.





Caution: A short power-supply is provided to reduce the risk of personal injury resulting from becoming entangled in or tripping over a longer cord. Extension cords are available and may be used if care is exercised in their use. If an extension cord is required, special care and caution is necessary. Also the cord must be: (1) the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance. And (2) the cord should be arranged so that it will not drape over the counter top or tabletop, where it can be pulled on by children or tripped over unintentionally.

Electrical Power

If the electric circuit is overloaded with other appliances, your appliance may not operate properly. It should be operated on a separate electric circuit from other appliances.

Caution: Unplug appliance from electrical outlet when assembling, removing parts or cleaning. Never place this appliance or cord in water or other liquids.

PARTS



- 1. Door Handle
- 2. Power Light
- 3. Control Panel
- 4. Curved Glass Door
- 5. Rack Support Guides
- 6. Heating Elements

- 7. Crumb Tray
- 8. Back Rack shown face up
- 9. Broil Rack
- 10. Bake Pan
- 11. Cookie Sheet

PARTS AND FEATURES

Control Panel


Temperature Control—Turn to select temperature 150 degrees to Broil

Time Control—To activate the timer or to toast, turn the dial to the right (clockwise). A bell will sound at the selected time (0-60 minutes).

Function Control—Turn to select the desired cook function:

- **Convection keep warm**—Keep food warm for up to 60 minutes.
- **Broil**—For broiling fish, steak, poultry and pork chops, etc.
- **Convection bake**—For baking cakes, pies, cookies, poultry, beef, pork, etc.
- **Toast**—For toasting bread, muffins, frozen waffles, etc.

Power On Light—The Power On light will illuminate whenever the Oven is turned on.



ACCESSORIES

Bake Rack—May be positioned in the upper or lower Rack Support Guides for toasting, baking, and general cooking.

Cookie sheets—Each cookie sheet holds approximately 9-12 medium-size cookies.

Bake Pan & Broil Rack—For use in broiling and baking meat, poultry, fish, and various other foods. The Broil rack allows fat drippings to drip into the Bake Pan and away from the food. This will help prevent spattering that could result in smoking and flare-ups.

Note: Sugar and salt-based foods have a tendency to stick to all surfaces and are very hard to clean. When cooking these types of foods with the Bake Pan and Broil Rack, soak and clean them immediately after each use.

INSTRUCTIONS FOR USE

Caution:

Appliance surfaces are hot during and after use. Always wear protective, insulated oven mitts when touching hot oven, dishes and food, or when inserting or removing Bake Rack, Broil Rack, or Cookie Sheet.

Never leave oven unattended while in use. Be sure the Crumb Tray is in position while using any of the Toaster Oven's functions.

To activate timer for periods less than 20 minutes, turn dial past 20 and back to desired time or for toast function to desired darkness.

Broiling/Top Browning

For best results, it is recommended that you preheat the oven for 10 minutes at your desired temperature.

Trim excess fat from meat and dry any moisture that may be on the food.

1. Set the Temperature Control to Broil/Toast.
2. Turn the Function Control to Broil.
3. Set the Time control to preheat the oven for 10 minutes.
4. Place the Bake Rack in the upper Rack Support Guide, facing up.
5. Place the Broil Rack onto the Bake Pan.
6. Place the food on the Broil rack. Brush food with sauces or oil, if desired. Then slide onto the Bake Rack.
7. Food should be placed as close as possible to the top heating element without touching it.
8. Turn on the Time control.
9. Turn food over midway through cooking time.
10. Timer will shut off automatically or manually turn timer to off.

Convection Bake

Positioning the Bake Racks

Cookies can be baked using either or both Rack Support Guides with Racks facing up. Layer cakes can be baked on the lower position with the Bake Rack facing down, and on the upper position with the Bake Rack facing up.

Pies can be baked in either or both positions with the Bake Rack facing down. Be sure to place Cookie Sheet under the pies to catch any spills or drips.

Baking Guide

Follow the package or recipe instructions for baking times and temperature.

INSTRUCTIONS FOR USE

Note: When using a single rack, position the Bake Rack in the bottom Support Guide, facing up.

Bakeware that will fit in the Oven are: a bundt pan, 6-cup muffin pan, 9-inch pie pan, 9-inch loaf pan, or an angel food cake pan.

Do not use roasting bags or plastic or glass containers in the oven.

1. Place the Bake Rack in the lower Rack Support Guide or according to recipe directions.
2. Preheat the oven as directed in the recipe.
3. Turn the function control to Convection Bake.
4. Place item to be baked on the Bake Rack.
5. Turn on the time control.
6. Timer will shut off automatically or manually turn timer to off.

Toasting

The large capacity oven allows for toasting up to 6 slices of bread. When toasting only 1 or 2 items, place the food in the center of the oven.

1. Be sure the Crumb Tray is in place.
2. Set the Temperature control to Broil/toast.
3. Turn the function control to toast.
4. Bake Rack should be positioned in lower rack support guide, facing up.
5. Place food to be toasted on the Bake Rack.
6. Turn the time control to the desired darkness. To activate timer, turn dial past 20 and back to desired darkness.
7. Bell will signal and oven will turn off at the end of the toast cycle.

Convection Warm

Keeps cooked food warm for up to 60 minutes. Longer periods of time are not recommended as food will become dry or spoil.

1. Set the temperature control to 250°F or less.
2. Turn the function control to warm.
3. Turn on the time control
4. Timer will shut off automatically or manually turn timer to off.

CARE AND CLEANING

Caution: Do not immerse cord, plug, or appliance into water or any other liquid. Do not use metal scouring pads to clean the oven. Pieces of the pad may break off and touch electrical parts.

1. Unplug the Oven and allow all parts to cool completely before cleaning or moving.
2. All accessories should be washed in hot, sudsy water or can be cleaned in the dishwasher. Rinse and dry all accessories thoroughly.
3. The Glass Door can be wiped clean with a damp sponge and wiped dry with a paper or cloth towel.
4. Clean the outside with a damp sponge. DO NOT USE AN ABRASIVE CLEANER, AS IT MAY DAMAGE THE EXTERIOR FINISH.

CUSTOMER ASSISTANCE

For faster service, please have the model number and product name ready for the operator to assist you. This number can be found on the bottom of your appliance and on the front page of this manual.

Model Number: _____ **Product Name:** _____

Customer Assistance Number 1-877-207-0923 (U.S.) or 1-877-556-0973 (Canada)

Keep these numbers for future reference!

For more information, please visit us at www.gehousewares.com

TWO-YEAR LIMITED WARRANTY

What does your warranty cover?

- Any defect in material or workmanship.

For how long after the original purchase?

- Two years.

What will we do?

- Provide you with a new one.
- For those items still under warranty but no longer available, WAL-MART reserves the right to replace with a similar GE branded product of equal or greater value.

How do you make a warranty claim?

- Save your receipt.
- Properly pack your unit. We recommend using the original carton and packing materials.
- Return the product to your nearest WAL-MART store or call Customer Assistance at 1-877-207-0923 (U.S.) or 1-877-556-0973 (Canada).

What does your warranty not cover?

- Parts subject to wear, including, without limitation, glass parts, glass containers, cutter/strainer, blades, seals, gaskets, clutches, motor brushes, and/or agitators, etc.
- Commercial use or any other use not found in printed directions.
- Damage from misuse, abuse, or neglect, including failure to clean product regularly in accordance with manufacturer's instructions.

How does state law relate to this warranty?

- This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.
- This warranty is in lieu of any other warranty or condition, whether express or implied, written or oral, including, without limitation, any statutory warranty or condition of merchantability or fitness for a particular purpose.
- WAL-MART, GE and the product manufacturer expressly disclaim all responsibility for special, incidental and consequential damages or losses caused by use of this appliance. Any liability is expressly limited to an amount equal to the purchase price paid whether a claim, however instituted, is based on contract, indemnity, warranty, tort (including negligence), strict liability, or otherwise. Some states or provinces do not allow this exclusion or limitation of incidental or consequential losses so the foregoing disclaimer may not apply to you.

What if you encounter a problem with this product while using it outside the country of purchase?

- The warranty is valid only in the country of purchase and you follow the warranty claim procedure as noted.



is a trademark of General Electric Company and is used under the license by Wal-Mart Stores Inc., Bentonville, AR 72716

Marketed in Canada by:

Wal-Mart Canada Corp.
1940 Argentia Road, Mississauga, Ontario L5N1P9

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>