



# Advantium™ 120 Oven

## Advantium

*Advantium Quick Start* . . .10, 11  
*Cooking controls* . . . . .14  
*Customer information* . . . . .8  
*Oven features* . . . . .13, 14  
*Safety* . . . . .2-7  
*What is Advantium?* . . . . .9

## Speedcooking

*Cooking tips* . . . . .16  
*Custom speedcook recipes* . . .19, 20  
*Custom speedcook recipe log* . . .21  
*Manual speedcook* . . . . .18  
*Power level* . . . . .17  
*Repeat last* . . . . .16  
*Resume feature* . . . . .16  
*Speedcook cookware* . . . . .18  
*Speedcook menu guide* . . . . .12  
*Speedcook-safe cookware* . . . . .5  
*Things that are normal* . . . . .22  
*Using a pre-set speedcook menu* . . .15

## Microwaving

*Baking* . . . . .23  
*Cooking tips* . . . . .27  
*Custom microwave recipes* . . .27, 28  
*Custom microwave recipe log* . . .28  
*Defrost-Auto* . . . . .29  
*Defrost-Time* . . . . .29  
*Defrosting tips* . . . . .30  
*Micro Express* . . . . .26  
*Microwave power levels* . . . . .27  
*Microwave-safe cookware* . . . . .6  
*Precautions to avoid possible exposure to excessive microwave energy* . . . . .2  
*Sensor cooking* . . . . .31, 32  
*Things that are normal* . . . . .33  
*Time cook* . . . . .26  
*Using pre-set microwave selections* . . . . .26  
*Warming and reheating* . . .24, 25

## Other Features

*Auto night light* . . . . .34  
*Automatic fan* . . . . .37  
*Beeper volume* . . . . .34  
*Child lockout* . . . . .36  
*Clock* . . . . .10, 34  
*Display ON/OFF* . . . . .34  
*Help* . . . . .35  
*Reminder* . . . . .37  
*Review* . . . . .34  
*Scroll speed* . . . . .34  
*Surface light* . . . . .36  
*Timer* . . . . .36  
*Vent fan* . . . . .36

## Care and Cleaning

*Cleaning the inside* . . . . .38, 39  
*Cleaning the outside* . . . . .40  
*Filters* . . . . .41, 42  
*Optional kits* . . . . .42  
*Replacing lights* . . . . .41

## Troubleshooting

*Problem Solver* . . . . .43, 44

## Consumer Support

*Consumer Support* . . . . .Back Cover  
*Customer Information* . . . . .8  
*Product Registration* . . . . .45, 46  
*Warranty* . . . . .47

## Owner's Manual

SCA1000  
SCA1001



# IMPORTANT SAFETY INSTRUCTIONS

[www.geadvantium.com](http://www.geadvantium.com)

## ***PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY***

- (a) Do Not Attempt** to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) Do Not Place** any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do Not Operate** the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
- (1) door (bent),
  - (2) hinges and latches (broken or loosened),
  - (3) door seals and sealing surfaces.
- (d) The Oven Should Not** be adjusted or repaired by anyone except properly qualified service personnel.

# IMPORTANT SAFETY INSTRUCTIONS

[www.geadvantium.com](http://www.geadvantium.com)

**▲ WARNING!** *To reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy:*

## SAFETY PRECAUTIONS

- **Read all instructions before using this appliance. When using electrical appliances, basic safety precautions should be followed, including the following:**
- Read and follow the specific precautions in the *PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY* section on page 2.
- Be sure your appliance is properly installed and grounded by a qualified technician in accordance with the provided installation instructions.
- Install or locate this appliance only in accordance with the provided installation instructions.
- Some products such as whole eggs and sealed containers—for example, closed jars—are able to explode and should not be heated in this oven. Such use of the oven could result in injury.
- Do not mount this appliance over a sink.
- This oven is not approved or tested for marine use.
- This oven is UL listed for installation over electric and gas ranges.
- This oven was designed for use over ranges no wider than 36 inches. It may be installed over both gas and electric cooking equipment.
- Do not operate this appliance if it has a damaged power cord or plug, if it is not working properly, or if it has been damaged or dropped. If the power cord is damaged, it must be replaced by General Electric Service or an authorized service agent using a power cord available from General Electric.
- As with any appliance, close supervision is necessary when used by children.
- Use this appliance only for its intended use as described in this manual.
- Do not use corrosive chemicals or vapors in this appliance.
- This oven is specifically designed to heat, dry or cook food, and is not intended for laboratory or industrial use.
- This appliance should be serviced only by qualified service personnel. Contact nearest authorized service facility for examination, repair or adjustment.
- Do not cover or block any openings on the appliance.
- Do not store this appliance outdoors. Do not use this product near water—for example, in a wet basement, near a swimming pool, near a sink or in similar locations.
- Keep power cord away from heated surfaces.
- Do not immerse power cord or plug in water.
- See door surface cleaning instructions in the Care and Cleaning of the Oven section of this manual.
- To reduce the risk of fire in the oven cavity:
  - Do not overcook food. Carefully attend appliance when paper, plastic or other combustible materials are placed inside the oven while cooking.
  - Remove wire twist-ties and metal handles from paper or plastic containers before placing them in the oven.
  - Do not use the oven for storage purposes. Do not leave paper products, cooking utensils or food in the oven when not in use.
  - If materials inside the oven ignite, keep the oven door closed, turn the oven off and disconnect the power cord, or shut off power at the fuse or circuit breaker panel. If the door is opened, the fire may spread.
  - Do not use the Sensor Features twice in succession on the same food portion. If food is undercooked after the first countdown, use TIME COOK for additional cooking time.

# IMPORTANT SAFETY INSTRUCTIONS

*www.geadvantium.com*

## **▲ WARNING!**

### **SAFETY PRECAUTIONS**

- Do not operate the oven without the oven rack (turntable) in place. The oven rack (turntable) must be unrestricted so it can turn.
- During and after use, do not touch, or let clothing or other flammable materials contact any interior area of the oven; allow sufficient time for cooling first.
- Do not store anything directly on top of the oven surface when the oven is in operation.
- Cook meat and poultry thoroughly—meat to at least an INTERNAL temperature of 160°F, and poultry to at least an INTERNAL temperature of 180°F. Cooking to these temperatures usually protects against foodborne illness.
- Keep the oven free from grease buildup.
- Potentially hot surfaces include the oven door, floor, walls and oven rack (turntable).

## **ARCING**

*Arcing can occur during both speedcooking and microwave cooking. If you see arcing, press the CLEAR/OFF pad and correct the problem.*

Arcing is the microwave term for sparks in the oven. Arcing is caused by:

- Metal or foil touching the side of the oven.
- Foil not molded to food (upturned edges act like antennas).
- Metal cookware used during either speedcook or microwave cooking (except for the pans provided with the oven).
- Metal, such as twist-ties, poultry pins, or gold-rimmed dishes, in the oven.
- Recycled paper towels containing small metal pieces being used in the oven.
- Use foil only as recommended in this guide.

## **THE VENT FAN**

- The fan will operate automatically under certain conditions (see the *Automatic Fan* section). Take care to prevent the starting and spreading of accidental cooking fires while the vent fan is in use.
- Clean the underside of the oven often. Do not allow grease to build up on the oven or the fan filters.
- In the event of a grease fire on the surface units below the oven, smother a flaming pan on the surface unit by covering the pan completely with a lid, a cookie sheet or a flat tray.
- Use care when cleaning the vent fan filters. Corrosive cleaning agents, such as lye-based oven cleaners, may damage the filters.
- When preparing flaming foods under the oven, turn the vent fan on.
- Never leave surface units beneath your oven unattended at high heat settings. Boilovers cause smoking and greasy spillovers that may ignite and spread if the oven vent fan is operating. To minimize automatic fan operation, use adequate sized cookware and use high heat on surface units only when necessary.

# IMPORTANT SAFETY INSTRUCTIONS

www.geadvantium.com

## ▲ WARNING!

### FOODS

- When microwaving, place all foods and containers on the glass microwave tray.
- Do not pop popcorn in your oven unless in a special microwave popcorn accessory or unless you use popcorn labeled for use in microwave ovens.
- Do not boil eggs in this oven. Pressure will build up inside egg yolk and will cause it to burst, possibly resulting in injury.
- Do not operate the oven without food inside. This may cause damage to the oven. It increases the heat around the magnetron and can shorten the life of the oven.
- Foods with unbroken outer “skin” such as potatoes, hot dogs, sausages, tomatoes, apples, chicken livers and other giblets, and egg yolks should be pierced to allow steam to escape during cooking.


### ■ SUPERHEATED WATER

*Liquids, such as water, coffee or tea are able to be overheated beyond the boiling point without appearing to be boiling. Visible bubbling or boiling when the container is removed from the microwave oven is not always present. THIS COULD RESULT IN VERY HOT LIQUIDS SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A SPOON OR OTHER UTENSIL IS INSERTED INTO THE LIQUID.*


To reduce the risk of injury to persons:

- Do not overheat the liquid.
- Stir the liquid both before and halfway through heating it.
- Do not use straight-sided containers with narrow necks.
- After heating, allow the container to stand in the microwave oven for a short time before removing the container.
- Use extreme care when inserting a spoon or other utensil into the container.

## Oven-safe cookware for Speedcook, Oven/Bake & Warming features



*The oven rack (turntable) must always be in place when using the oven.*



*Put food or non-metal, oven-safe cookware directly on the **black metal tray** for speedcooking, baking or warming.*


- **The oven and door will get very hot when speedcooking or using the oven/bake feature.**
- **Cookware will become hot .** Oven mitts will be needed to handle the cookware.
- Do not use coverings, containers or cooking/roasting bags made of foil, plastic, wax or paper when speedcooking.
- Do not cover the oven rack (turntable), trays or any part of the oven with metal foil. This will cause arcing in the oven.
- Use the black metal flat tray in the same way you would use a shallow baking pan or baking tray.
- Place food or oven-safe cookware directly on the trays when cooking.
- Any oven-safe dish can be used in your oven. Recipes in the Advantium Cookbook were tested in Pyrex® and Anchor Hocking® glass cookware and Corningware® ceramic casseroles. Cooktimes and results may vary when using other types of oven-safe dishes. Place them directly on the black metal tray.
- Do not use the oven to dry newspapers.
- Use of the glass microwave tray with the speedcook or oven/bake features will result in inferior cooking performance.

# IMPORTANT SAFETY INSTRUCTIONS


[www.geadvantium.com](http://www.geadvantium.com)

## ▲ WARNING!

### Microwave-safe cookware



The oven rack (turntable) must always be in place when using the oven.



The glass microwave tray should always be in place when microwaving.

Make sure to use suitable cookware during microwave cooking. Most glass casseroles, cooking dishes, measuring cups, custard cups, pottery or china dinnerware which does not have metallic trim or glaze with a metallic sheen can be used. Some cookware is labeled “suitable for microwaving.”

- Place food or microwavable container directly on the glass microwave tray to cook your food.
  - Use of the black metal tray during microwave cooking will result in inferior cooking performance.
  - If you are not sure if a dish is microwave-safe, use this test: Place in the oven both the dish you are testing and a glass measuring cup filled with 1 cup of water—set the measuring cup either in or next to the dish. Microwave 30-45 seconds at high. If the dish heats, it should not be used for microwaving.

If the dish remains cool and only the water in the cup heats, then the dish is microwave-safe.
  - Cookware may become hot because of heat transferred from the heated food. Oven mitts may be needed to handle the cookware.
  - Do not use recycled paper products. Recycled paper towels, napkins and waxed paper can contain metal flecks which may cause arcing or ignite. Paper products containing nylon or nylon filaments should be avoided, as they may also ignite.
  - Use foil only as directed in this guide. TV dinners may be microwaved in foil trays less than 3/4" high; remove the top foil cover and return the tray to the box. When using foil in the oven, keep the foil at least 1 inch away from the sides of the oven.
  - Do not use the oven to dry newspapers.
  - If you use a meat thermometer while cooking, make sure it is safe for use in microwave ovens.
  - Some styrofoam trays (like those that meat is packaged on) have a thin strip of metal embedded in the bottom.
- When microwaved, the metal can burn the floor of the oven or ignite a paper towel.
- Paper towels, waxed paper and plastic wrap can be used to cover dishes in order to retain moisture and prevent spattering. Be sure to vent plastic wrap so steam can escape.
  - Not all plastic wrap is suitable for use in microwave ovens. Check the package for proper use.
  - “Boilable” cooking pouches and tightly closed plastic bags should be slit, pierced or vented as directed by package. If they are not, plastic could burst during or immediately after cooking, possibly resulting in injury. Also, plastic storage containers should be at least partially uncovered because they form a tight seal. When cooking with containers tightly covered with plastic wrap, remove covering carefully and direct steam away from hands and face.
  - Plastic cookware—Plastic cookware designed for microwave cooking is very useful, but should be used carefully. Even microwave-safe plastic may not be as tolerant of overcooking conditions as are glass or ceramic materials and may soften or char if subjected to short periods of overcooking. In longer exposures to overcooking, the food and cookware could ignite.

Follow these guidelines:

1. Use microwave-safe plastics only and use them in strict compliance with the cookware manufacturer’s recommendations.
2. Do not microwave empty containers.
3. Do not permit children to use plastic cookware without complete supervision.

# IMPORTANT SAFETY INSTRUCTIONS

*www.geadvantium.com*

---

## **▲ WARNING!**

### *SAFETY PRECAUTIONS*

- Don't defrost frozen beverages in narrow-necked bottles (especially carbonated beverages). Even if the container is open, pressure can build up. This can cause the container to burst, possibly resulting in injury.
- Foods cooked in liquids (such as pasta) may tend to boil more rapidly than foods containing less moisture. Should this occur, refer to the *Care and Cleaning of the oven* section for instructions on how to clean the inside of the oven.
- Hot foods and steam can cause burns. Be careful when opening any containers of hot food, including popcorn bags, cooking pouches and boxes. To prevent possible injury, direct steam away from hands and face.
- Do not overcook potatoes. They could dehydrate and catch fire, causing damage to your oven.
- Avoid heating baby food in glass jars, even with the lid off. Make sure all infant food is thoroughly cooked. Stir food to distribute the heat evenly. Be careful to prevent scalding when warming formula. The container may feel cooler than the formula really is. Always test the formula before feeding the baby.
- Do not attempt to deep fry in the oven.

---

## **▲ WARNING!**

### *PACEMAKERS*

All microwave ovens must meet Federal DHHS and FCC requirements. However, the operation of some pacemakers may be affected by microwaves. Cognizant of this problem, most pacemaker manufacturers have taken steps to minimize the susceptibility of their products to external interference, including microwaves. Most new pacemakers (1982 and later) are now protected from microwave interference. However, prior to using your microwave oven it is recommended that persons with pacemakers consult the manufacturer of the device for additional information and/or their physician to ensure their pacemaker will not be affected by microwaves.

***SAVE THESE INSTRUCTIONS***

*Introduction****Congratulations! You are now part of the cooking revolution!***

As part of the vision to help consumers live better, easier lives, GE Appliances introduces the revolutionary GE Advantium oven with Speedcook technology. This new oven roasts, grills, bakes, browns and broils, just like your conventional oven—only faster—and with delicious results. You also save time because Advantium requires no preheating.

The information on the following pages will help you operate and maintain your new Advantium oven. We appreciate your purchase, and hope you will continue to rely on us whenever you need quality appliances for your home. We thank you for buying GE.

*Product registration*

Fill out the Consumer Product Registration Card.

***Two Easy Ways To Register Your Appliance!***

- Through the internet at [www.GEAppliances.com](http://www.GEAppliances.com).
- Complete and mail the enclosed Product Registration Card.

*Write down the model & serial numbers*

You can find them on a label, behind the open oven door, on the front face.

These numbers are also on the Consumer Product Ownership Registration Card packed separately with your oven.

Proof of the original purchase date is needed to obtain service under the warranty.

**For future reference, please write these numbers here:**

\_\_\_\_\_

Model Number

\_\_\_\_\_

Serial Number

*Read this manual*

Inside you will find many helpful hints on how to use and maintain your oven properly. Just a little preventive care on

your part can save you a great deal of time and money over the life of your oven.

*If you need service*

You'll find many answers to common problems in the *Before You Call For Service* section. If you review our chart of *Troubleshooting Tips* first, you may not need to call for service at all. Or, visit the GE Appliances website at [www.GEAppliances.com](http://www.GEAppliances.com).


If you do need service, you can relax knowing help is only a phone call away. A list of toll-free customer service numbers is included in the back section.



## Getting to know Advantium

The new Advantium oven uses breakthrough Speedcook technology to harness the power of light. The Advantium oven cooks the outside of foods much like conventional radiant heat, while also penetrating

the surface so the inside cooks simultaneously. While radiant heat is the primary source of power, a “microwave boost” is added with certain foods. Foods cook evenly and fast, retaining their natural moisture.



### Turntable

- The oven rack (turntable) rotates to ensure even cooking.

### Controls

- The oven control contains preset recipes.
- Turn and press dial makes menu selection easy.

### Speedcooking

- A 500 watt halogen bulb and a 600 watt ceramic heater cook food from above.
- One 375 watt ceramic heater cooks food from below.
- The convection fan ensures even heating.


### Oven/Bake and Warming

- One 1100 watt heater cooks food from above.
- One 375 watt ceramic heater cooks food from below.
- The convection fan ensures even heating.

### Microwave

- A microwave “boost” is automatically added with certain foods.
- The oven can also be used as a 900 watt microwave oven.

## Set the clock




When you first plug in the oven or after a power outage:

1. Turn the selector dial to set the hour. Press the dial to enter.
2. Turn the dial to set the minute. Press the dial to enter.
3. Turn the dial to select AM or PM. Press the dial to enter.

To change the time:


1. Press the OPTIONS button.
2. Turn the dial to CLOCK. Press the dial to enter and follow the display directions to set.

## Begin speedcooking




**Step 1:**  
Press the SPEEDCOOK button.

**Step 2:**  
Turn the dial until the display shows FOOD MENU. Press the dial to enter.



**Step 3:**  
Turn the dial to select the type of food you want. Press the dial to enter it.

**Step 4:**  
Turn the dial to select the specific food. Press the dial to enter it.




**Step 5:**  
Turn the dial to select the amount, size, and/or doneness (if required, the oven will prompt you). Press the dial after each selection.

**Step 6:**  
After the last selection is made, the time and power levels will be displayed. This is followed a short time later by a cookware message and *START?*.


**Step 7:**  
Once the display shows *START?*, place the food in the oven and press the dial or start button to start cooking. Speedcooking does not require

preheating.

■ Press CLEAR/OFF at any time to stop cooking.




The oven rack (turntable) must always be in place when using the oven.




Put food or non-metal, oven-safe cookware directly on the black metal tray to speedcook.

## Microwaving with Micro Express



Press MICRO EXPRESS for 30 second increments of microwave cooking time.

The oven starts immediately. You may add or subtract time by turning the dial. You may also add time in 30 second increments by pressing MICRO EXPRESS.




The oven rack (turntable) must always be in place when using the oven.



The glass microwave tray should always be in place when microwaving.

## Using the Oven/Bake feature



### With Preheating


**Step 1:**  
Press the OVEN/BAKE button.

**Step 2:**  
Turn the dial to set the oven temperature and press dial to start preheating. Do not place the food in the oven. (You will be prompted to enter the cook time after the oven is preheated.)


**Step 3:**  
Press the START/PAUSE button to start preheating.

**Step 4:**  
When the oven is finished preheating, it will signal. If you do not open the door within 1 hour, the oven will turn off automatically. Open the oven door and, using caution, place the food in the oven.

**Step 5:**  
Close the oven door. Turn the dial to set the cook time and press START/PAUSE to start cooking. When cooking is complete, the oven will signal and turn off.




*The oven rack (turntable) must always be in place when using the oven.*



*Put food or oven-safe cookware directly on the black metal tray to bake.*

*Cook times are shown in minutes and can be a maximum of 179 minutes. Time can be changed during cooking by turning the dial.*



### Without Preheating

**Step 1:**  
If your recipe does not require preheating, press the OVEN/BAKE button.

**Step 2:**  
Turn the dial to set the oven temperature and press to enter.


**Step 3:**  
To bypass preheating, press the dial again.

**Step 4:**  
Turn the dial to set the cook time and press to enter.

**Step 5:**  
Place the food in the oven, and press the START/PAUSE button to start the oven.

*Cook times are shown in minutes and can be a maximum of 179 minutes. Time can be changed during cooking by turning the dial.*

## Using the Warming feature



**Step 1:**  
Press the WARM/REHEAT button.


**Step 2:**  
Turn the dial to select WARMING. Press the dial to enter.

**Step 3:**  
Turn the dial to select the oven temperature.


LOW.....140-160°F  
MEDIUM ....160-195°F  
HIGH .....195-230°F

**Step 4:**  
Turn the dial to select the level of moisture you want. Press the dial to enter.

## Display prompts



After pressing the SPEEDCOOK button, the oven will prompt you to make several selections, such as in the example below.



**NOTE:** When speedcooking, always use the black tray.


1. Turn the dial until *FOOD MENU* appears. Press the dial to enter.
2. Turn the dial until *CHICKEN* appears. Press the dial to enter.
3. Turn the dial until *BONELESS BRST* (*boneless breast*) appears. Press the dial to enter.
4. Turn the dial to *Select SIZE:*  
*Sm (3-4 oz)*  
*Lg (5+ oz)*  
Press the dial to enter.
5. Turn the dial to *Select amount:*  
*1-2 pieces*  
*3-4 pieces*  
Press the dial to enter.
6. Use *METAL TRAY* is displayed.

## Pre-set speedcook menu selections

- After a cooking cycle has been completed, use the Resume feature to cook for additional time.
- To review settings during cooking, press the selector dial.
- See the Cooking Guide packed with the oven for a complete list of pre-set speedcook menu selections.

## Oven features

Throughout this manual, features and appearance may vary from your model.



- 1** *Oven Rack (Turntable)*  
The oven rack (turntable) must always be in place, on the oven floor, for all cooking. Be sure the oven rack (turntable) is seated securely over the hub in the center of the oven.
- 2** *Black Metal Tray/Baking Sheet*  
Put food or appropriate cookware directly on the black metal tray and place on the oven rack (turntable) when using the speedcook, oven/bake or warming features.
- 3** *Glass Microwave Tray*  
Center the tray on the oven rack (turntable) when using the microwave features. The tray will not lock onto the center hub. Place food or microwave-safe cookware directly on the tray.
- 4** *Upper Heaters*  
Operate when using the speedcook, oven/bake or warming features.
- 5** *Window*  
Allows food to be viewed while keeping microwaves confined in the oven.
- 6** *Door Handle*  
Pull to open the door. The door must be securely latched for the oven to operate.
- 7** *Door Latches*
- 8** *Vent Fan*  
Press the VENT FAN button to remove steam and other vapors from surface cooking.
- 9** *Lower Ceramic Heater*  
Operates when using the speedcook, oven/bake or warming features.
- 10** *Cooktop Light*  
Press the SURFACE LIGHT button to turn the cooktop light on and off.
- 11** *Control Panel*  
The buttons used to operate the oven are located on the control panel.
- 12** *Hub*  
The hub turns the oven rack. Make sure the hub is always firmly in place in the bottom of the oven.

## Cooking controls

With your Advantium oven, you can cook with high-intensity halogen lights, ceramic heaters and/or conventional microwave energy.

### **SPEEDCOOK**

Press this button to access the speedcook menu or to set your own speedcook program. Press and hold for 3 seconds to repeat the last cooking selection.

### **SELECTOR DIAL**—Turn to select, Push to enter

First turn then press the dial to make selections. Also use the dial to increase (turn clockwise) or decrease (turn counterclockwise) cooking times or temperatures.

### **START/PAUSE**

Press this button to start or pause any cooking function.

### **CLEAR/OFF**

Press this button to cancel **ALL** oven programs except the clock, auto night light, timer and reminder.

### **POWER LEVEL**

Press this button and turn/press the selector dial to change the speedcook or microwave power levels, or the oven/bake temperature before and during cooking.

### **TIMER**

Press this button to set the minute timer.

### **MICROWAVE**

Press this button to access the microwave menu or to set your own microwave program.

### **MICRO EXPRESS**

Press for 30 seconds of microwave cooking time. Each time the button is pressed adds an additional 30 seconds to the remaining cooking time. The oven starts immediately.

### **BACK**


On certain features, press this button to return to the previous step.

### **OVEN/BAKE**

Press this button to bake foods using conventional oven cooking.

### **WARM/REHEAT**

Press this button to operate the warming and reheating features. Keep hot, cooked foods at serving temperature, or reheat servings of previously cooked foods.



### **VENT FAN**

Press this button to remove steam and other vapors from surface cooking.

### **REMINDER**

Can be used like an alarm clock and can be used at any time, even when the oven is operating. It can be set to beep at a certain time, up to 24 hours later.

### **OPTIONS**

Press this button to set the *Clock* and access the *Beeper Volume*, *Clock Display ON/OFF*, *Display Scroll Speed*, *Delayed Start* and *Night Light* features.

### **HELP**

Press this button to find out more about your oven's features.

### **SURFACE LIGHT**


Press this button to turn the cooktop light on and off.

## Using speedcook features


**CAUTION: When using speedcook programs, remember that the oven, door and dishes will be very hot!**

Prior to the first use of your oven, the clock must be set. See the Advantium Quick Start section.

Before you begin, make sure the oven rack (turntable) is in place. Use the black metal tray (baking sheet), at all times when speedcooking.




The oven rack (turntable) must always be in place when using the oven.



Put food or non-metal, oven-safe cookware directly on the black metal tray to speedcook.

## To use a pre-set speedcook menu



Advantium is already pre-set to cook over 100 popular dishes.

1. Press the speedcook button.  
*If no selection is made within 15 seconds, the display will revert back to the time of day.*
2. Turn the selector dial to FOOD MENU. Press the dial to enter.
3. Turn the selector dial to select the type of food category you want. Press the dial to enter.
4. Turn the selector dial to select the specific food (menu selection). Press the dial to enter.
5. Turn the selector dial to select amount, size and/or doneness (if required, the oven will prompt you.) Press the dial after each selection.

6. Once the display shows: START? either press start or the selector dial to start cooking.

*For certain foods, turn the food over when the oven signals TURN FOOD OVER. Press START to resume cooking.*

*For certain foods, the oven will signal CHECK for DONENESS,. Check to see if the food is done to your liking. The oven will continue to cook for several minutes. Take the food out when it is done to your liking.*

*To review settings during cooking, press the selector dial.*

*If you enter an undesired selection at any time, simply press the BACK button to return to the previous step, or press the CLEAR/OFF button and re-enter the desired selections.*

■ Early in a speedcook program, you will see OPTIMIZING COOK TIME in the display. The oven automatically senses the electrical voltage level in your home and adjusts the cooking time up or down for proper cooking.

■ If the door is opened during cooking, the oven will stop and PAUSE will appear in the display. Close the door and press the START/PAUSE button to resume cooking.

■ At anytime during cooking you can turn the selector dial to change the

cooking time. You can change power levels by pressing POWER LEVEL.

■ To assure consistent cooking results, the oven may reduce power levels if the oven is hot at the beginning of a program.


■ At the end of cooking, the automatic fan may continue to run for a short time to cool internal components.

■ To cook for additional time after a cooking cycle has been completed, use the resume feature.


## Cooking tips for great tasting results

To ensure consistent and even browning when cooking foods directly on the black metal tray, arrange food as shown below.


**Foods can touch but should not overlap.**



*Circular pattern*  
(Example: biscuits, cookies, meats)




*Spoke pattern*  
(Example: crescent rolls, breadsticks)



*Single layer*  
(Example: appetizers)

Fresh meat, chicken, fish or seafood that has been frozen should be **thawed before cooking** (the microwave defrost feature can be used). For other frozen prepackaged foods, follow package directions.

## Repeat last




Use this time saving feature for cooking repetitive items like cookies or appetizers.

1. Press and hold the SPEEDCOOK button for about 3 seconds.
2. The last pre-set food will be displayed.

**NOTE:** The last program used is stored for two hours.

3. Press the START/PAUSE button or the selector dial to start cooking.

## Resume feature




1. If your food needs to cook a bit longer, you can restart the oven by pressing the START button or selector dial.
2. **RESUME COOKING** will be displayed and the oven will restart immediately at 10% of the original time.

The program stays in memory for 3 minutes. After that you will need to begin the program again. See *To use a pre-set speedcook menu.*



## Speedcook power level



Advantium uses power from a high intensity halogen light, ceramic heaters, and microwaves to cook food from the top, bottom, and interior simultaneously to seal in moisture and flavor.

When using the pre-set speedcook recipes on the food menu, the power levels are already selected for you. However, these power levels can be adjusted before or during cooking. Also, the manual cook feature allows you to speedcook items not on the pre-set food menu by selecting your own cook time and power level settings.

Each power level gives you heater power and microwave energy for a certain percentage of the time.

**UPPER POWER (U)** controls both the upper heater and microwave power. A higher **UPPER POWER** setting will utilize more upper heater power, browning food faster on top. A lower **UPPER POWER** setting utilizes more microwave power, causing food to cook more evenly throughout. Select a higher setting for foods such as pizza and baked goods. Select a lower setting for foods such as casseroles, meat and fish.

**LOWER POWER (L)** controls the lower heater. Select a higher setting to brown foods more on the bottom. Select a lower setting for less browning on the bottom.


1. Press the **SPEEDCOOK** button and turn the dial to select **FOOD MENU** or **MANUAL COOK**. Press the dial to enter.
2. Follow instructions from *To use a pre-set speedcook menu* or *Manual Cook*.
3. To change the power level when prompted by the display, turn the dial clockwise to increase or counterclockwise to decrease the upper power level. Press the dial to enter.
4. Turn the dial to change the lower power level. Press the dial to enter.
5. Press the **START/PAUSE** button or the selector dial to start cooking.

*If you do not want to change one of the settings, just press the dial to move to the next selection.*

**NOTE:** *Be careful when adjusting power levels so that you do not over- or undercook food.*


## Speedcook cookware

- Follow cookware suggestions on the oven display or in the Cookbook or Cooking Guide.
- Cookware will become hot. Oven mitts will be needed to handle the cookware.
- Place food or oven-safe cookware directly on the black tray when cooking.
- Use the black metal tray in the same way you would use a shallow baking pan or baking tray.
- In addition to the cookware provided, you can use non-metal casserole dishes, pie plates and other heat-safe cookware. Place them directly on the black metal tray.
- Be sure to select a size that will rotate easily.
- Place the black metal tray directly on the oven rack (turntable).



- Do not use cookware or coverings made of paper, plastic or foil when cooking during a speedcook cycle.
- The black metal tray must be in place during the speedcook operations.

## Manual speedcook



Advantium gives you the flexibility to cook your favorite dishes.

If you want to cook a food item that is not among the pre-set selections, use manual speedcook.

1. Press the SPEEDCOOK button.

*If no entries are made within 15 seconds, the display will revert back to the time of day.*


2. Turn the selector dial to **MANUAL COOK**.
3. Turn the selector dial to select the cooking time. Press the dial to enter.

*The display will prompt you to select **UPPER POWER** and **LOWER POWER**.*

4. Turn the dial clockwise to increase or counterclockwise to decrease the upper power level. Press the dial to enter.
5. Turn the dial to change the lower power level. Press the dial to enter.
6. Press the **START/PAUSE** button or press the selector dial to start cooking.

*For power level and cooking time suggestions, use your cooking guide or cook book.*

*Speedcook recipe—to enter and save*



**Create up to 30 of your own Speedcook recipes, or customize an existing custom recipe to suit your tastes. Once it's done, your food cooks just the way you want it every time!**

1. Press the SPEEDCOOK button.
2. Turn the dial until *MY RECIPES* appears. Press the dial to enter.
3. Turn the dial until *<empty>* appears. Press the dial to enter.
4. *SELECT COOK TIME* appears. Turn the dial to select the cooking time. Press the dial to enter.


*The display will prompt you to select UPPER POWER and LOWER POWER.*

5. Turn the dial clockwise to increase or counterclockwise to decrease the upper power level. Press the dial to enter.

6. Turn the dial to change the lower power level. Press the dial to enter.
7. Spell out the food name by turning the selector dial to advance through the available characters. Press the dial to enter a character. When you have entered the entire name, press START/PAUSE. You may change previously entered characters by pressing the BACK button.
8. *RECIPE ADDED* appears. To begin cooking, press the START/PAUSE button. To store the recipe without cooking, press the CLEAR/OFF button.

*For power level and cooking time suggestions, use your cooking guide or cook book.*

*Speedcook recipe—to find and use*




**To find and use stored custom speedcook recipes:**

1. Press the SPEEDCOOK button.
2. Turn dial to *MY RECIPES* and press to enter.
3. *FOOD NAME* and the recipe names you have previously entered will appear.

4. Turn dial until the recipe you want is displayed and press the dial to enter.
5. Press the START/PAUSE button or press the selector dial to start cooking.

## Speedcook recipe—to adjust or change



### To adjust or change stored custom speedcook recipes:


1. Press the SPEEDCOOK button.
2. Turn the dial until *MY RECIPES* appears. Press the dial to enter.
3. Turn the dial to the recipe you want to change. Press the dial to enter.
4. Press the OPTIONS button.
5. Turn the dial to select *CHANGE RECIPE*. Press the dial to enter.
6. The display will prompt you to *SELECT COOK TIME*, then select *UPPER POWER*, *LOWER POWER* and *FOOD NAME*. Turn the dial and press to enter the appropriate settings.

(For more detailed instructions, follow steps 4 through 7 in the section *Speedcook recipe—to enter and save*.)

7. *RECIPE ADDED* appears. To begin cooking press the START/PAUSE button. To store the recipe without cooking, press the CLEAR/OFF button.

*For power level and cooking time suggestions, use your cooking guide or cook book.*

## Speedcook recipe—to delete



### To delete stored custom speedcook recipes:

1. Press the SPEEDCOOK button.
2. Turn the dial until *MY RECIPES* appears and press the dial to enter.
3. Turn dial to the recipe you want to delete and press the dial to enter.

4. Press the OPTIONS button.
5. Turn the dial to select *DELETE RECIPE*, and press the dial to enter. This deletes the recipe. You may now enter and save a new recipe or press CLEAR/OFF to return to the clock display.



## *Things that are normal during speedcooking*

### **Cooking Times**

- When speedcooking preprogrammed foods, you may see *OPTIMIZING COOK TIME* in the display several seconds after you press **START**. The oven automatically senses the electrical voltage level in your home and adjusts the cooking time up or down for proper cooking.

### **Fan/Vent**

- The fan will come on during cooking. At the end of cooking, the automatic fan will continue to run for a short time, and the display will read *Oven is Cooling*. The fan will automatically shut off when the internal parts of the oven have cooled.
- The exhaust fan may come on automatically if the cooktop is in use.
- The oven vent will emit warm air while the oven is on.

### **Lights**

- When the oven is on, light may be visible around the door or outer case.
- The heaters will dim and cycle on and off during a speedcook cycle, sometimes even at full power levels. This is normal. The oven senses the heat level and adjusts automatically.


### **Heaters**

- No preheating is required. The oven begins cooking immediately.
- The door and inside of the oven will be very hot. Use caution when opening the door and removing food.
- Do not use cookware or coverings made of paper, plastic or foil when cooking during a speedcook cycle.
- When cooking for an extended period of time, the oven may automatically reduce the power levels to maintain the appropriate level of oven heat.


### **Sounds**

- Clicks and a fan blowing are normal sounds during cooking. The relay board is turning components on and off.

## Baking



The oven rack (turntable) must always be in place when using the oven.



Put food or oven-safe cookware directly on the black metal tray to bake.


Baking allows you to cook foods the same way as a conventional oven, using a heating element to raise the temperature of the air inside the oven. Any oven temperature from 250°F to 450°F may be set. A fan gently circulates this heated air throughout the oven, over and around the food, producing golden brown exteriors and rich, moist interiors.

Because the heated air is kept constantly moving, not permitting a layer of cooler air to develop around the food, some foods cook slightly faster than in regular oven cooking.

Before you begin, make sure the oven rack (turntable) is in place. Use the black metal tray at all times when baking.

**Caution: When baking, remember that the oven, door and dishes will be very hot!**

## Bake with preheat



1. Press the oven/bake button.
2. When using the OVEN/BAKE mode to cook baked goods such as cakes, brownies, cookies, pies, rolls, etc., reduce the oven temperature 25°F–40°F from the recipe to prevent overbrowning of baked goods.

Turn the dial to set the oven temperature and press dial to start preheating. Do not place the food in the oven. (You will be prompted to enter the cook time, after the oven is preheated.)

3. Press the start/pause button to start preheating.
4. When the oven is finished preheating, it will signal. If you do not open the door within

1 hour, the oven will turn off automatically. Open the oven door and, using caution, place the food in the oven.


5. Close the oven door. Turn the dial to set the cook time and press START/PAUSE to start cooking. When cooking is complete, the oven will signal and turn off.

You may change the oven temperature during preheating by pressing the power level button and turning the dial to select the new temperature.

If the oven door is opened during cooking, PAUSE will appear in the display. Close the door and press start/pause.

Cook times are shown in minutes and can be a maximum of 179 minutes. Time can be changed during cooking by turning the dial.

## Bake without preheat



1. If your recipe does not require preheating, press the oven/bake button.
2. When using the OVEN/BAKE mode to cook baked goods such as cakes, brownies, cookies, pies, rolls, etc., reduce the oven temperature 25°F–40°F from the recipe to prevent overbrowning of baked goods.

Turn the dial to set the oven temperature and press to enter.


3. To bypass preheating, press the dial again.

4. Turn the dial to set the cook time and press to enter.
5. Place the food in the oven, and press the Start/pause button to start the oven.

If the oven door is opened during cooking, PAUSE will appear in the display. Close the door and press START/PAUSE.

Cook times are shown in minutes and can be a maximum of 179 minutes. Time can be changed during cooking by turning the dial.

## Warming



The warming feature will keep hot, cooked foods at serving temperature. Always start with hot food. Use cookware and utensils that can withstand temperatures up to 230°F.

1. Press the WARM/REHEAT button.
2. Turn the dial to select WARMING. Press the dial to enter.
3. Turn the dial to select the oven temperature.

LOW .....140-160°F  
 MEDIUM .....160-195°F  
 HIGH .....195-230°F

4. Turn the dial to select the level of moisture you want. Press the dial to enter.

If the oven door is opened during warming, PAUSE will appear in the display. Close the door and press START/PAUSE.

### Temperature and Moisture Selection Chart

Food Type	Control Setting	Moisture Setting
Bread, hard rolls	MEDIUM	CRISP
Bread, soft rolls	MEDIUM	MOIST
Casseroles	MEDIUM	MOIST
Fried foods	HIGH	CRISP
Meats* and fish	MEDIUM	CRISP
Pancakes, waffles	HIGH	CRISP
Pizza	HIGH	CRISP
Potatoes, baked	HIGH	CRISP
Potatoes, mashed	MEDIUM	MOIST
Poultry	HIGH	MOIST
Tortilla Chips	LOW	CRISP
Vegetables	MEDIUM	MOIST

\* USDA/FSIS recommends an internal temperature of 145°F as the minimum doneness for beef. Use a portable meat thermometer to check internal temperatures.

#### Tips for Crisp Foods:

- Leave food uncovered.
- Do not use plastic containers or plastic wrap.
- Preheat prior to use according to recommended times.

#### Tips for Moist Foods:


- Cover food with lid or aluminum foil.
- Do not put water in the warming pan.
- Do not use plastic containers or plastic wrap.
- Preheat prior to use according to recommended times.

#### To Crisp Stale Items

- Place food or dishes directly on the black metal tray.
- Preheat on LOW setting and select CRISP.
- Check crispness after 45 minutes. Add time as needed.



## Timed Reheat



The *Timed Reheat* feature reheats servings of previously cooked foods or a plate of leftovers.

*Timed Reheat* uses a combination of heaters and microwave power. A microwave-only reheat feature is also available in the **MICROWAVE** selections.

1. Press the **WARM/REHEAT** button.
2. Turn the dial to select **REHEAT**. Press the dial to enter.
3. Turn the dial to set the reheat time and press to enter.
4. Press the **START/PAUSE** button to start the oven.

*If the oven door is opened during cooking, PAUSE will appear in the display. Close the door and press START/PAUSE.*

*After removing food from the oven, stir, if possible, to even out the temperature. If the food is not hot enough, reheat for more time. Reheated foods may have wide variations in temperature. Some areas of food may be extremely hot.*


*Place the food in a non-metallic container on the black metal tray. The cookware will get hot.*

*Use cookware and utensils that can withstand temperatures up to 275° F.*


## Using the microwave features

*Make sure the oven rack (turntable) and glass microwave tray are in place. Place food or microwavable container directly on the glass microwave tray to cook your food.*

*Center the tray on the oven rack (turntable). The tray will not lock onto the center hub.*



*The oven rack (turntable) must always be in place when using the oven.*



*The glass microwave tray should always be in place when microwaving.*


### Cookware

- Make sure that cookware is suitable for microwaving.
- Place food or microwavable container directly on the glass microwave tray to cook your food.

### **MICROWAVE PRE-SET FOOD SELECTIONS:**

- |                                  |                               |   |
|----------------------------------|-------------------------------|---|
| ■ <b>Bacon</b>                   | ■ <b>My Recipes</b>           | ■ <b>Soup</b>                               |
| ■ <b>Beverage</b>                | ■ <b>Popcorn</b>              | ■ <b>Time cook</b>                          |
| ■ <b>Defrost (Auto and Time)</b> | ■ <b>Reheat (one serving)</b> | ■ <b>Vegetables (fresh, frozen, canned)</b> |

## How to use pre-set microwave selections




1. Press the MICROWAVE button.  
*If no selection is made within 15 seconds, the display will revert back to the time of day.*
2. Turn the dial to find the food you want to cook. Press the dial to enter.
3. If required, the oven will prompt you to select amount, weight or size. Turn the dial and press after each selection.
4. Press the dial or the START/PAUSE button to start cooking.

*To review settings during cooking, press the selector dial.*

*If the door is opened during cooking, the oven will stop and PAUSE will appear in the display. Close the door and press START/ PAUSE to resume cooking.*

*If you enter an undesired selection at any time, simply press the BACK button to return to the previous step, or press the CLEAR/OFF button and re-enter the desired selections.*

## Time Cook



*Use Time Cook to microwave food that is not in the recipe section.*

■ The power level is automatically set at high, but you can change it for more flexibility.


1. Press the MICROWAVE button.
2. Turn the dial to TIME COOK and press the dial to enter.
3. Turn the dial to set the time and press the dial to enter.

4. To change the power level if you don't want full power, press the POWER LEVEL button. Turn the dial to select. Press the dial to enter.

5. Press the dial or the START/PAUSE button to start cooking.

*You may open the door during TIME COOK to check the food. Close the door and press START to resume cooking.*


## Micro Express



Press MICRO EXPRESS for 30 second increments of microwave cooking time. Oven starts immediately.

You may add or subtract time by turning the dial. You may also add time in 30 second increments by pressing MICRO EXPRESS again.

## Microwave power level



1. First, follow directions for **TIME COOK**, **TIME DEFROST** or **MICRO EXPRESS**.
2. Press the **POWER LEVEL** button.
3. Turn the dial clockwise to increase and counterclockwise to decrease the power level. Press the dial to enter.
4. Press the dial or the **START/PAUSE** button to start cooking.

■ You can change the power level before or during a cooking program.

Here are some examples of uses for various power levels:

**High 10:** Fish, bacon, vegetables, boiling liquids.

**Med-High 7:** Gentle cooking of meat and poultry; baking casseroles and reheating.

**Medium 5:** Slow cooking and tenderizing for stews and less tender cuts of meat.

**Low 2 or 3:** Defrosting; simmering; delicate sauces.

**Warm 1:** Keeping food warm; softening butter.

## Cooking tips


■ When cooking bacon, layer strips on a plate. Cover each layer with a paper towel.

■ When cooking vegetables, use a microwave-safe casserole or bowl. Cover with a lid or vented plastic wrap.

■ For frozen vegetables, follow the package instructions for adding water.

■ For fresh vegetables, add two tablespoons of water for each serving.

## Microwave recipe—to enter and save




### Create and store up to 10 of your own microwave recipes.

1. Press the **MICROWAVE** button.
2. Turn dial until **MY RECIPES** appears. Press the dial to enter.
3. Turn dial until **<empty>** appears. Press the dial to enter.
4. **SELECT COOK TIME** appears. Turn the dial to select the cooking time you want. Press the dial to enter.
5. Turn the dial to change the power level and press to enter.

6. Spell out the food name by turning the selector dial to advance through the available characters. Press the dial to enter a character. When you have entered the entire name, press **START/PAUSE**. You may change previously entered characters by pressing the **BACK** button.
7. **RECIPE ADDED** appears. To begin cooking, press the **START/PAUSE** button or press the **CLEAR/OFF** button to store the recipe without cooking.

## Microwave recipe—to find and use



### To find and use stored custom microwave recipes:


1. Press the **MICROWAVE** button.
2. Turn dial to **MY RECIPES** and press the dial to enter.
3. **FOOD NAME** and the recipe names you entered will appear.

4. Turn dial to your recipe and press the dial to enter.
5. Press the **START/PAUSE** button or the selector dial to start cooking.

## Custom microwave recipes

Custom Recipe Name	Cook Time	Microwave Power Level	Comments
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

## Microwave recipe—to adjust or change




### To adjust or change stored custom microwave recipes:

1. Press the MICROWAVE button.
2. Turn dial to MY RECIPES and press the dial to enter.
3. Turn the dial to the recipe you want to change. Press the dial to enter.
4. Press the OPTIONS button.
5. Turn the dial to select CHANGE RECIPE. Press the dial to enter.

6. Turn the dial to select the cook time and press the dial to enter.
7. Turn the dial to select the POWER LEVEL and press the dial to enter.
8. RECIPE ADDED appears. To begin cooking, press the START/PAUSE button or press the CLEAR/OFF button to store the recipe without cooking.

## Microwave recipe—to delete




### To delete stored custom microwave recipes:

1. Press the MICROWAVE button.
2. Turn dial to MY RECIPES and press the dial to enter.
3. Turn the dial to the recipe you want to delete. Press the dial to enter.
4. Press the OPTIONS button.

5. Turn the dial to select DELETE RECIPE, and press the dial to enter. This deletes the recipe. You may now enter and save a new recipe or press CLEAR/OFF to return to the clock display.

## Auto defrost



Auto Defrost automatically sets the defrosting times and power levels to give even defrosting results for meats, poultry and fish weighing up to six pounds.

1. Remove food from the package and place it on a microwave-safe dish.
2. Press the MICROWAVE button.
3. Turn the dial to *DEFROST-AUTO*. Press the dial to enter.
4. Turn the dial to the food weight, using the Conversion Guide at right. For example, dial 1.2 for 1.2 pounds (1 pound, 3 oz.) Press the dial to enter.
5. Press the dial or START/PAUSE button to start defrosting.
6. Turn the food over when the oven signals *TURN FOOD OVER*.


- Remove defrosted meat or shield warm areas with small pieces of foil for even defrosting.
- After defrosting, most meats need to stand 5 minutes to complete defrosting. Large roasts should stand for about 30 minutes.

### Conversion Guide

If the weight of food is stated in pounds and ounces, the ounces must be converted to tenths (.1) of a pound.

Weight of Food in Ounces	Enter Food Weight (tenths of a pound)
1-2	.1
3	.2
4-5	.3
6-7	.4
8	.5
9-10	.6
11	.7
12-13	.8
14-15	.9

## Time defrost



Use Time Defrost to defrost for a selected length of time.

1. Press the MICROWAVE button.
2. Turn the selector dial to *DEFROST-TIME*. Press the dial to enter.
3. Turn the dial to select the time you want. Press the dial to enter.
4. Press the dial or START/PAUSE button to start defrosting.
5. Turn the food over when the oven signals *TURN FOOD OVER*.

Power level is automatically set at 3, but can be changed. To change the power levels, see the Microwave Power Level section. You can defrost small items quickly by raising the power level after entering the time. Power level 7 cuts the total defrosting time in about half; power level 10 cuts the total time to about 1/3. When defrosting at high power levels, food will need more frequent attention than usual.

### *Defrosting tips*

*Use DEFROST-AUTO for meat, poultry and fish. Use DEFROST-TIME for most other frozen foods.*

- Foods frozen in paper or plastic can be time defrosted in the package, but foods should be taken out of the package when using *DEFROST-AUTO*. Closed packages should be slit, pierced or vented **after** food has partially defrosted. Plastic storage containers should be partially uncovered.
- Family-size, prepackaged frozen dinners can be defrosted and microwaved. If the food is in a foil container, transfer it to a microwave-safe dish.
- Foods that spoil easily should not be allowed to sit out for more than one hour after defrosting. Room temperature promotes the growth of harmful bacteria.
- For more even defrosting of larger foods, such as roasts, use *DEFROST-AUTO*. Be sure large meats are completely defrosted before cooking.
- When defrosted, food should be cool but softened in all areas. If still slightly icy, return to the microwave very briefly, or let it stand a few minutes.


## Microwave sensor cooking

The sensor feature detects the increasing humidity released during cooking. The oven automatically adjusts the cooking time to various types and amounts of food.


Do not use the Sensor Features twice in succession on the same food portion—it may result in severely overcooked or burnt food. If food is undercooked after the first countdown, use TIME COOK for additional cooking time.

**The proper containers and covers are essential for best sensor cooking.**


- Always use microwave-safe containers and cover them with lids or vented plastic wrap. Never use tight sealing plastic containers—they can prevent steam from escaping and cause food to overcook.
- Be sure the outside of the cooking containers and the inside of the oven are dry before placing food in the oven. Beads of moisture turning into steam can mislead the sensor.
- Beverages are best heated uncovered.



Covered



Vented




Dry off dishes so they don't mislead the sensor.

### **MICROWAVE SENSOR PROGRAMS:**

- **Beverage**
- **Popcorn – Prepackaged microwave popcorn, 1.5 oz. to 3.5 oz.**
- **Reheat – Single servings (4 to 6 oz.) of leftovers.**
- **Soup**

## To use all sensor programs



Advantium's microwave mode features sensor cooking. The oven automatically senses when food is done and shuts itself off—eliminating the need to program cooktimes and power levels.

1. Press the MICROWAVE button.
2. Turn the dial to select the food you want. Press the dial to enter.
3. Press the dial or press the START/PAUSE button to start cooking.

Do not open the oven door until time is counting down in the display. If the door is opened, close it and press START/PAUSE immediately. If the food is not done enough, use *TIME COOK* in the microwave selector to cook for more time.

**NOTE:** Do not use the Sensor Features twice in succession on the same food portion—it may result in severely overcooked or burnt food.

- If you have been speedcooking or baking and the oven is already hot, it may indicate that it is too hot for sensor cooking. Of course, you can always continue with the non-sensor functions.
- To shorten or lengthen the cook time, wait until the time countdown shows in the display. Then turn the dial to add or subtract time.

- Drinks heated with the *BEVERAGE* feature may be very hot. Remove the container with care.
- If you open the door while sensor cooking, *SENSOR ERROR* will appear. Close the door, press *START* to begin again.

### Notes about the Reheat program:

Reheated foods may have wide variations in temperature. Some areas may be extremely hot.

For improved reheating quality on crisper foods, use the *TIMED REHEAT* feature found by pressing *WARM/REHEAT*.

It is best to use *TIME COOK* and not *REHEAT* for these foods:

- Bread products
- Food that must be reheated uncovered.
- Foods that need to be stirred or turned.
- Foods calling for a dry look or crisp surface after reheating.



## *Things that are normal*

### ***Interference***

- TV/radio interference might be noticed while using the microwave. Similar to the interference caused by other small appliances, it does not indicate a problem with the microwave. Move the radio or TV as far away from the microwave as possible, or check the position of the TV/radio antenna.

### ***Oven Heat***

- Cookware may become hot because of heat transferred from the heated food. Oven mitts may be needed to handle the cookware.
- Steam or vapor may escape from around the door.

### ***Sounds***


- You may hear a dull thumping sound while the oven is operating.

**“FOOD IS READY”**

To remind you that you have food in the oven, the oven will display *FOOD IS READY* and beep once a minute until you either open the oven door or press the CLEAR/OFF button.



*Features under the OPTIONS button*



**Clock:**

The clock must be set before you use your oven for the first time (see *Quick Start* for instructions).

1. To change the clock time, press the OPTIONS pad and turn the dial to *CLOCK*. Press the dial to enter.
2. Turn the dial to set hours. Press the dial to enter.
3. Turn the dial to set minutes. Press the dial to enter.
4. Turn the dial to select AM or PM. Press the dial to enter.

**Clock Display ON/OFF:**

Use this feature to turn your clock display on or off. Press the OPTIONS button, turn the dial to select *CLOCK DISPLAY*. Turn the dial to select *ON* or *OFF*. Press the dial to enter.

**Auto Night Light:**

Use this feature to program the on-off time for an automatic night light. Press the OPTIONS button, turn the dial to select *NIGHT LIGHT*, press the dial to enter and follow the display directions.

**Beeper Volume:**

Use this feature to adjust the volume of the beeper. You can even turn it off. Press the OPTIONS button, turn the dial to select *BEEPER VOLUME*, press the dial to enter and follow the display directions.


**Scroll Speed:**

Is the message scroll too slow or too fast? Change it! Press the OPTIONS button, turn the dial to select *DISPLAY SPEED*, press the dial to enter, and follow the display directions.

**Delayed Start:**

Delayed Start allows you to set the oven to delay cooking up to 24 hours. Press the OPTIONS button, turn the dial to select *DELAYED START* and press the dial to enter. Follow the display directions to set the Delayed Start time and feature you wish to delay.


*Review*



Use this feature to review the current cooking selections you have set.

Press the selector dial at any time during cooking.

*Help*



Use this feature to find out more about your oven and its features.


1. Press the HELP button.
2. Turn the dial to select the feature name. Press the dial to enter.

The display will show a description for the program you have chosen.

*Features found in the HELP function.*

<i>Adjust</i>	<i>Night Light</i>
<i>Back</i>	<i>Options</i>
<i>Bacon</i>	<i>Oven/Bake</i>
<i>Beeper Volume</i>	<i>Popcorn</i>
<i>Beverage</i>	<i>Power Level</i>
<i>Child Lockout</i>	<i>Reheat-1 Serving</i>
<i>Clear/Off</i>	<i>Reminder</i>
<i>Clock</i>	<i>Repeat Last</i>
<i>Clock Display On/Off</i>	<i>Resume</i>
<i>Defrost (Auto)</i>	<i>Review</i>
<i>Defrost (Time)</i>	<i>Soup</i>
<i>Delayed Start</i>	<i>Speedcook</i>
<i>Display Speed</i>	<i>Start/Pause</i>
<i>Food Menu</i>	<i>Surface Light</i>
<i>Heat/Pwr/Temp</i>	<i>Time Cook</i>
<i>Help</i>	<i>Timer On/Off</i>
<i>Manual Cook</i>	<i>Vegetables (Canned)</i>
<i>Microwave</i>	<i>Vegetables (Fresh)</i>
<i>Micro Express</i>	<i>Vegetables (Frozen)</i>
<i>Micro Power</i>	<i>Vent Fan</i>
<i>My Recipes</i>	

*Child lockout*




*You may lock the control panel to prevent the oven from being accidentally started or used by children.*

Press and hold CLEAR/OFF for about 3 seconds to lock and unlock.

When the control panel is locked, *Control Panel LOCKED* will be displayed briefly anytime a button or dial is pressed.

*Surface light*




*Use to light your cooktop.*

Press the SURFACE LIGHT button to select the proper setting.

Continue pressing to change from bright to nightlight to off.

*Vent fan*




*The vent fan removes steam and other vapors from surface cooking.*

Press the VENT FAN button to select the fan speed.

Continue pressing to change from high to low to off.

*Timer*



*Use this feature anytime you need a general purpose timer. It can even be used while cooking in the oven.*


1. Press the TIMER button.
2. Turn the dial to select the minutes. Press the dial to enter.

3. Turn the dial to select the seconds. Press the dial to enter.

*To pause, press TIMER. To restart, press TIMER again.*

*To cancel, press and hold the TIMER button down for about 3 seconds.*

### *Reminder*



Use this feature like an alarm clock to help you keep up with things to do.

1. Press the REMINDER button and select reminder time. Follow the directions in the display:
  - A. Turn the dial to set hours.  
Press the dial to enter.
  - B. Turn the dial to set minutes.  
Press the dial to enter.
  - C. Turn the dial to select AM or PM. Press the dial to enter.

*To briefly display the reminder time, press the REMINDER button.*

*To cancel, press and hold the REMINDER button for about 3 seconds.*

### *Automatic fan*

An automatic fan feature protects the oven from too much heat rising from the cooktop below it and from too much heat inside the oven cavity.

It automatically turns on at low speed if it senses too much heat.

If you have turned the fan on you may find that you cannot turn it off. The fan will automatically turn off when the internal parts are cool. It may stay on for 30 minutes or more after the cooktop and oven controls are turned off.

### *Helpful hints*

An occasional thorough wiping with a solution of baking soda and water keeps the inside fresh.

**Be certain the oven control is turned off before cleaning any part of this oven.**



### *How to clean the inside*

Some spatters can be removed with a paper towel, others may require a damp soapy cloth. Remove greasy spatters with a damp sudsy cloth, then rinse with a damp cloth.


**Do not spray or splash liquids directly into the heater areas.**

Do not use abrasive cleaners or sharp utensils on oven walls.

**Never use a commercial oven cleaner on any part of your oven.**

Do not clean the inside of the oven with metal scouring pads. Pieces can break off the pad, causing electrical shock.

Some food or liquids may fall into the heater areas. The heaters will cook most of the food away. Any remaining residue will not affect cooking.




*Walls, Floor, Inside Window, Metal and Plastic Parts on the Door*

### *Removable oven rack (turntable)*

The area underneath the oven rack (turntable) should be cleaned frequently to avoid odors and smoking during a cooking cycle.

The oven rack (turntable) can be broken if dropped. Wash carefully in warm, sudsy water. Dry completely and replace.

To replace the oven rack (turntable), place its center over the hub in the center of the oven and turn it until it seats into place.



*Oven Rack (Turntable)*


*Do not use the oven without the oven rack (turntable) in place.*

### *Baking sheets (cooking trays)*


To prevent breakage, allow the trays to cool completely before cleaning. Wash carefully in warm, sudsy water or in the dishwasher.

A soap-filled scouring pad can also be used to clean the black metal tray.

Do not use abrasives, as they may damage the finish.



*Glass microwave tray*



*Black metal tray*

## How to clean the outside

*We recommend against using cleaners with ammonia or alcohol, as they can damage the appearance of the microwave oven. If you choose to use a common household cleaner, first apply the cleaner directly to a clean cloth, then wipe the soiled area.*

### Case

Clean the outside with a sudsy cloth. Rinse and then dry. Wipe the window clean with a damp cloth.

### Glass Door (on some models)

Wipe with a clean damp sponge. Dry thoroughly. Do not use cleaning sprays, large amounts of soap and water, abrasives or sharp objects on the panel—they can damage it.

### Stainless Steel Control Panel and Door (on some models)

*Do not use a steel wool pad; it will scratch the surface.*

To clean the stainless steel surface, use a hot, damp cloth with a mild detergent suitable for stainless steel surfaces. Use a clean, hot, damp cloth to remove soap. Dry with a dry, clean cloth.

If food soil remains, try a general kitchen cleaner, such as Fantastik®, Simple Green® or Formula 409®.

For hard-to-clean soil, use a standard stainless steel cleaner, such as Bon-Ami® or Cameo®.

Apply cleaner with a damp sponge. Use a clean, hot, damp cloth to remove cleaner. Dry with a dry, clean cloth. Always scrub lightly in the direction of the grain.

After cleaning, use a stainless steel polish, such as Stainless Steel Magic®, Revere Copper and Stainless Steel Cleaner® or Wenol All Purpose Metal Polish®. Follow the product instructions for cleaning the stainless steel surface.

### Bottom



Clean off the grease and dust on the bottom often. Use a solution of warm water and detergent.

### Vent Grill

Use warm soapy water and a dishcloth to wipe off the grill. If desired, use cotton swabs to get in between the grill louvers.

### Door Frame

It's important to keep the area clean where the door seals against the oven. Use only mild, non-abrasive detergents applied with a clean sponge or soft cloth. Rinse well.




## The vent fan

The vent fan has 2 metal reusable vent filters.

Ovens configured to recirculate air back into the room should also use a charcoal filter.

### Charcoal Filter (on some models)



### Reusable Vent Filters (on all models)




## Cooktop light/ night light


1. To replace the cooktop light/  
night light, first disconnect the  
power at the main fuse or circuit  
breaker panel.
2. Remove the screw from the  
side of the light compartment  
cover and lower the cover until  
it stops.
3. Be sure the bulb to be replaced is  
cool before removing. Gently pull  
the bulb from the receptacle.

*Replace with 20-watt (max.) 12 volt  
halogen bulb. Order WB36X10176 from  
your GE supplier. High-intensity 20-watt  
bulbs, available in supermarkets and  
hardware stores, may also be used for  
replacements.*

4. Raise the light cover and replace  
the screw. Connect electrical  
power to the oven.



Remove screw



## Reusable vent filters

The metal filters trap grease released  
by foods on the cooktop. They also  
prevent flames from foods on the  
cooktop from damaging the inside  
of the oven.

For this reason, the filters must  
**always** be in place when the hood  
is used. The vent filters should be  
cleaned once a month, or as needed.


## Removing and cleaning the filters

**To remove**, slide them to the rear  
using the tabs. Pull down and out.

To clean the vent filters, soak them  
and then swish around in hot water  
and detergent. Don't use ammonia  
or ammonia products because  
they will darken the metal. Light  
brushing can be used to remove  
embedded dirt.

Rinse, shake and let dry before  
replacing.

**To replace**, slide the filters into the  
frame slots on the back of each  
opening. Press up and to the front  
to lock into place.



### Charcoal filter (JX81A)

The charcoal filter cannot be cleaned. It must be replaced. Order Part No. **WB2X9883** from your GE supplier.

If the model is not vented to the outside, the air will be recirculated through a disposable charcoal filter that helps remove smoke and odors.

The charcoal filter should be replaced when it is noticeably dirty or discolored (usually after 6 to 12 months, depending on usage).


### To remove the charcoal filter

To remove the charcoal filter, **first disconnect power at the main fuse.**

Remove the top grille by removing the 2 screws that hold it in place.

You may need to open the cabinet doors to remove the screws.

Slide the filter towards the front of the oven and remove it.




Remove 2 grille screws to remove the grille.

### To install the charcoal filter

To install a new filter, remove plastic and other outer wrapping from the new filter.

Insert the filter into the top opening of the oven as shown maneuvering it behind the plastic grille until it fits squarely into place.

It will rest at an angle behind the plastic grille on two side support tabs and in front of the right rear tab. Replace the grille and 2 screws. Reconnect power at the main fuse.



### Optional kits

Available at extra cost from your GE supplier.

#### Filler Panel Kits

- JX40CT—Bisque
- JX40WH—White
- JX41—Black

When replacing a 36" range hood, filler panel kits fill in the additional width to provide a custom built-in appearance.

For installation between cabinets only; not for end-of-cabinet installation. Each kit contains two 3" wide filler panels.

#### Filter Kits

- JX81A—Recirculating Charcoal Filter Kit

Filter kits are used when the oven cannot be vented to the outside.

#### Decorative Panel Kit

- JX22SS—Stainless Steel

When replacing a Hi/Low range, the decorative panel kit fills in the area between the oven and the range left by the Hi/Low model.

*Questions? Use this problem solver or visit the GE website at [www.GEAppliances.com](http://www.GEAppliances.com)*

Problem	Possible Causes	What To Do/Explanation
<b>LIGHTS</b>		
<b>Light during a speedcook cycle dims and cycles on and off, even at full power levels</b>	This is normal. Power level has been automatically reduced because the oven is hot.	<ul style="list-style-type: none"> <li>This is normal. The oven senses the heat level and adjusts automatically.</li> </ul>
<b>Light visible around the door and outer case while speedcooking</b>	This is normal.	<ul style="list-style-type: none"> <li>When the oven is on, light may be visible around the door and outer case.</li> </ul>
<b>FAN</b>		
<b>Fan continues to run after cooking stops</b>	The oven is cooling.	<ul style="list-style-type: none"> <li>The fan will automatically shut off when the internal parts of the oven have cooled.</li> </ul>
<b>Oven vent emits warm air while oven is on</b>	This is normal.	
<b>Fan comes on automatically when oven not in use</b>	This is normal.	<ul style="list-style-type: none"> <li>If the cooktop gets too hot, the vent fan comes on.</li> </ul>
<b>Fan comes on automatically when using the microwave</b>	This is normal.	<ul style="list-style-type: none"> <li>If the microwave is used after speedcook and the oven senses that it is too hot, the vent fan comes on to cool the oven.</li> </ul>
<b>COOKING</b>		
<b>The oven makes unusual sounds while cooking</b>	Clicks and fans blowing are normal. The relay board is turning the components on and off.	<ul style="list-style-type: none"> <li>These sounds are normal.</li> </ul>
<b>Smoke comes out of the oven when I open the door</b>	Food is high in fat content. Aerosol spray used on the pans.	<ul style="list-style-type: none"> <li>Smoke is normal when cooking high-fat foods. Use vegetable oil or olive oil on the meat itself instead of coating the entire pan.</li> </ul>
<b>Food is not fully cooked or browned at the end of a cooking program</b>	Programmed times may not match the size or amount of food you are cooking.	<ul style="list-style-type: none"> <li>Increase or decrease time for doneness or adjust the upper or lower lamps for browning.</li> </ul>

Questions?  
Use this  
problem  
solver

Problem	Possible Causes	What To Do/Explanation
<b>DISPLAY</b>		
<b>The display is blank</b>	The clock display has been turned off.	<ul style="list-style-type: none"> <li>• Check the OPTIONS menu for clock display settings. Turn the display on.</li> </ul>
<b>“Control Panel LOCKED” appears in display</b>	The control has been locked.	<ul style="list-style-type: none"> <li>• Press and hold CLEAR/OFF for about 3 seconds to unlock the control.</li> </ul>
<b>Control display is lighted yet oven will not start</b>	Clock is not set.	<ul style="list-style-type: none"> <li>• Set the clock.</li> </ul>
	Door not securely closed.	<ul style="list-style-type: none"> <li>• Open the door and close securely.</li> </ul>
	START/PAUSE button not pressed after entering cooking selection.	<ul style="list-style-type: none"> <li>• Press START/PAUSE.</li> </ul>
	Another selection already entered in oven and CLEAR/OFF button not pressed to cancel it.	<ul style="list-style-type: none"> <li>• Press CLEAR/OFF.</li> </ul>
	Size, quantity, or cooking time not entered after selecting <i>VEGETABLES (FRESH, FROZEN, CANNED)</i> , <i>BACON</i> , <i>DEFROST-TIME</i> or <i>TIME COOK</i> .	<ul style="list-style-type: none"> <li>• Make sure you have entered cooking time after selecting.</li> </ul>
	CLEAR/OFF was pressed accidentally.	<ul style="list-style-type: none"> <li>• Reset cooking program and press START/PAUSE.</li> </ul>
	Food weight not entered after selecting DEFROST-AUTO.	<ul style="list-style-type: none"> <li>• Make sure you have entered food weight after selecting DEFROST-AUTO.</li> </ul>
<b>OTHER PROBLEMS</b>		
<b>The door and inside of the oven feels hot</b>	The heat lamps produce intense heat in a small space.	<ul style="list-style-type: none"> <li>• This is normal.</li> <li>• Use oven mitts to remove food when ready.</li> </ul>
<b>Floor of the oven is warm, even when the oven has not been used</b>	The cooktop light is located below the oven floor. When the light is on, the heat it produces may make the oven floor get warm.	<ul style="list-style-type: none"> <li>• This is normal.</li> </ul>
<b>Oven will not start</b>	A fuse in your home may be blown or the circuit breaker tripped.	<ul style="list-style-type: none"> <li>• Replace fuse or reset circuit breaker.</li> </ul>
	Power surge.	<ul style="list-style-type: none"> <li>• Unplug the oven, then plug it back in.</li> </ul>
	Plug not fully inserted into wall outlet.	<ul style="list-style-type: none"> <li>• Make sure the plug on the oven is fully inserted into wall outlet.</li> </ul>
<b>Glass microwave tray does not lock into center hub.</b>		<ul style="list-style-type: none"> <li>• This is normal. Center the tray on the oven rack (turntable).</li> </ul>

## GE Service Protection Plus™

GE, a name recognized worldwide for quality and dependability, offers you Service Protection Plus™—comprehensive protection on all your appliances—**No Matter What Brand!**

**Benefits Include:**

- Backed by GE
- All brands covered
- Unlimited service calls
- All parts and labor costs included
- No out-of-pocket expenses
- No hidden deductibles
- One 800 number to call

***We'll Cover Any Appliance.  
Anywhere. Anytime.\****

You will be completely satisfied with our service protection or you may request your money back on the remaining value of your contract. No questions asked. It's that simple.

Protect your refrigerator, dishwasher, washer and dryer, range, TV, VCR and much more—**any brand!** Plus there's no extra charge for emergency service and low monthly financing is available. Even icemaker coverage and food spoilage protection is offered. You can rest easy, knowing that all your valuable household products are protected against expensive repairs.

Place your confidence in GE and call us in the U.S. toll-free at **800-626-2224** for more information.

\*All brands covered, up to 20 years old, in the continental U.S.



Please place in envelope and mail to:

***General Electric Company***  
**Warranty Registration Department**  
**P.O. Box 32150**  
**Louisville, KY 40232-2150**

**Keep this portion for your records.**


Return your completed Product Warranty Registration Card below and store this section with your important documents. You will need to refer to this information if your appliance should need service.

Product: \_\_\_\_\_  
\_\_\_\_\_

Model No.: \_\_\_\_\_

Serial No.: \_\_\_\_\_

Your GE Service Number  
1-800-GE-CARES  
(1-800-432-2737)




**It's Important!**

Prompt product registration helps in more ways than one.

- Enhanced communication should you need service
- Ownership verification for insurance purposes
- Notification of product modification

**Important: If you did not get a registration card with your product, detach and return the form below to ensure that your product is registered, or register online at [www.GEAppliances.com](http://www.GEAppliances.com).**



# Consumer Product Ownership Registration



Model Number

Serial Number

\_\_\_\_\_

\_\_\_\_\_

Mr.  Ms.  Mrs.  Miss

First Name \_\_\_\_\_

Last Name \_\_\_\_\_

Street Address \_\_\_\_\_

Apt. # \_\_\_\_\_

E-mail Address\* \_\_\_\_\_

City \_\_\_\_\_

State \_\_\_\_\_

Zip Code \_\_\_\_\_

Date Placed In Use  
Month \_\_\_\_\_

Day \_\_\_\_\_

Year \_\_\_\_\_

Phone Number \_\_\_\_\_-\_\_\_\_\_-\_\_\_\_\_

\* Please provide your e-mail address to receive, via e-mail, discounts, special offers and other important communications from GE Appliances (GEA).

Check here if you do not want to receive communications from GEA's carefully selected partners.



**GE Appliances**

GE Consumer Products  
General Electric Company  
Louisville, Kentucky  
[www.GEAppliances.com](http://www.GEAppliances.com)

# Advantium Oven Warranty

[www.geadvantium.com](http://www.geadvantium.com)

All warranty service provided by an authorized Customer Care® technician. To schedule service, online, 24 hours a day, contact us at [www.GEAppliances.com](http://www.GEAppliances.com), or call 800-GE-CARES.

For The Period Of:	GE Will Replace:
<b>One Year</b> <i>From the date of the original purchase</i>	<i>Any part</i> of the oven which fails due to a defect in materials or workmanship. During this <b>full one-year warranty</b> , GE will also provide, <b>free of charge</b> , all labor and related service costs to replace the defective part.
<b>Second through Third Year</b> <i>From the date of the original purchase</i>	<i>The heating system</i> , if any heater or lamp fails due to a defect in materials or workmanship. During this <b>full three-year warranty</b> , GE will also provide, <b>free of charge</b> , all labor and related service costs to replace the defective part.
<b>Second through Tenth Year</b> <i>From the date of the original purchase</i>	<i>The magnetron tube</i> , if the magnetron tube fails due to a defect in materials or workmanship. During this additional <b>nine-year limited warranty</b> , you will be responsible for any labor or related service costs.

## What GE Will Not Cover:

- Service trips to your home to teach you how to use the product.
- Improper installation, delivery or maintenance.
- Failure of the product if it is abused, misused, or used for other than the intended purpose or used commercially.
- Replacement of house fuses or resetting of circuit breakers.
- Replacement of the cooktop light bulbs.
- Damage to the product caused by accident, fire, floods or acts of God.
- Incidental or consequential damage caused by possible defects with this appliance.
- Damage caused after delivery.

*This warranty is extended to the original purchaser and any succeeding owner for products purchased for home use within the USA. In Alaska, the warranty excludes the cost of shipping or service calls to your home. Proof of the original purchase date is needed to obtain service under the warranty.*

*Some states do not allow the exclusion or limitation of incidental or consequential damages. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. To know what your legal rights are, consult your local or state consumer affairs office or your state's Attorney General.*

**Warrantor: General Electric Company. Louisville, KY 40225**

---

## *GE Appliances Website*

*www.GEAppliances.com*

---

Have a question or need assistance with your appliance? Try the GE Appliances Website 24 hours a day, any day of the year! For greater convenience and faster service, you can now download Owner's Manuals, order parts, catalogs, or even schedule service on-line. You can also "Ask Our Team of Experts™" your questions, and so much more...

---

## *Schedule Service*

*www.GEAppliances.com*

---

Expert GE repair service is only one step away from your door. Get on-line and schedule your service at your convenience 24 hours any day of the year! Or call 800-GE-CARES (800-432-2737) during normal business hours.

---

## *Real Life Design Studio*

*www.GEAppliances.com*

---

GE supports the Universal Design concept—products, services and environments that can be used by people of all ages, sizes and capabilities. We recognize the need to design for a wide range of physical and mental abilities and impairments. For details of GE's Universal Design applications, including kitchen design ideas for people with disabilities, check out our Website today. For the hearing impaired, please call 800-TDD-GEAC (800-833-4322).

---

## *Extended Warranties*

*www.GEAppliances.com*

---

Purchase a GE extended warranty and learn about special discounts that are available while your warranty is still in effect. You can purchase it on-line anytime, or call 800-626-2224 during normal business hours. GE Consumer Home Services will still be there after your warranty expires.

---

## *Parts and Accessories*

*www.GEAppliances.com*

---

Individuals qualified to service their own appliances can have parts or accessories sent directly to their homes (VISA, MasterCard and Discover cards are accepted). Order on-line today, 24 hours every day or by phone at 800-626-2002 during normal business hours.

***Instructions contained in this manual cover procedures to be performed by any user. Other servicing generally should be referred to qualified service personnel. Caution must be exercised, since improper servicing may cause unsafe operation.***

---

## *Contact Us*

*www.GEAppliances.com*

---

If you are not satisfied with the service you receive from GE, contact us on our Website with all the details including your phone number, or write to:

General Manager, Customer Relations  
GE Appliances, Appliance Park  
Louisville, KY 40225



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>