

TVP5158 Evaluation Module

User's Guide



Literature Number: SLEU108
November 2009

1	Description	6
1.1	Functional Overview	6
1.2	Notational Conventions	6
2	Board Level Description	7
2.1	Analog Video/Audio Inputs	7
2.2	Analog Video/Audio Outputs	7
2.3	Digital Video/Audio Outputs to DaVinci HD EVM	8
2.4	Digital Video/Audio Cascade Output/Input	8
2.5	I2C Configuration Options	8
2.6	Test Points and Jumpers	8
3	System Level Description	9
4	Required Hardware and Equipment	10
5	Hardware Setup	10
5.1	Setup for TVP5158EVM Stand-Alone Configuration	10
5.2	Setup for TVP5158EVM with DaVinci HD EVM	11
6	Software Installation	14
7	TVP5158EVM Evaluation Procedures	17
7.1	Stand-Alone Operation - Non-Interleaved Digital Video Output Modes	17
7.2	Evaluation Using the DaVinci HD EVM	19
7.3	Evaluation of Pixel-Interleaved Digital Video Output Modes	24
8	VCC Software in Depth	25
8.1	VCC Main Window	25
8.2	Register Map Editor	25
8.3	Property Sheets	26
8.4	Video Decoder Select and Write Enables	27
8.5	Example TVP5158 Property Pages	28
9	Troubleshooting	34
9.1	Troubleshooting Guide	34
10	TVP5158 EVM Schematics	38

List of Figures

1	TVP5158 EVM Block Diagram	7
2	TVP5158EVM System Level Block Diagram	9
3	Location of TVP5158EVM Video/Audio Inputs	11
4	TVP5158EVM Software Setup Wizard	15
5	Select Installation Folder	15
6	Confirm Installation	16
7	Installation Complete.....	16
8	VCC Configuration	18
9	Specifying Cascaded Devices	18
10	USB Device Not Found Error Message	18
11	Real-Time Polling Enable	19
12	VCC Main Window - Set for Communication to All Decoders	19
13	System Initialization for Analog Component YPbPr Video Output.....	19
14	Browse to Command File	21
15	System Initialization for Line-Interleaved Modes	22
16	mcvip_test Demo Application Menu	23
17	System Initialization for Pixel Interleave Modes	24
18	TVP5158 Register Map Editor	25
19	VCC Main Window – Configured for Broadcast Write Access (default).....	28
20	VCC Main Window – Configured for Single Video Decoder Write Access	28
21	TVP5158 Output Formatter Property Page With Decoder 1 Selected	30
22	TVP5158 Output Formatter Property Page With Decoder 4 Selected	31
23	TVP5158 Noise Reduction and Auto Contrast Property Page	32
24	TVP5158 Audio Property Page (Seen Only When Decoder 1 is Selected)	32
25	TDM I2S Audio Data Configuration	33
26	TVP5158 Video Format Property Page.....	37
27	THS8200 Input Controls / Status Property Page.....	37
28	Schematics (1 of 8).....	39
29	Schematics (2 of 8).....	40
30	Schematics (3 of 8).....	41
31	Schematics (4 of 8).....	42
32	Schematics (5 of 8).....	43
33	Schematics (6 of 8).....	44
34	Schematics (7 of 8).....	45

List of Tables

1	TVP5158EVM Jumper Descriptions	8
2	Jumper Settings for Stand-Alone Configuration	11
3	Hardware Modification for I2S Audio to DM6467	12
4	Jumper Settings for DaVinci HD EVM as TVP5158 I2C Master	13
5	Jumper Settings for PC USB Interface as TVP5158 I2C Master	13
6	Jumper Settings for a Cascaded TVP5158EVM	14
7	Recommended DM6467 Clock Frequencies	19
8	VCC Main Menu Summary.....	25
9	VCC Register Map Editor Controls.....	26
10	Property Sheet Controls	26
11	Property Sheet Button Controls	27
12	Editing Tools vs Video Decoder Write Enables	28
13	Troubleshooting Setup and General Issues	34
14	Troubleshooting with THS8200 and CompositeVideo Output	34
15	Troubleshooting with DM6467 DaVinci HD EVM.....	35
16	Troubleshooting I2C Connections and Cascaded EVMs.....	35

TVP5158 Evaluation Module

1 Description

The TVP5158EVM evaluation module is a printed circuit board designed for evaluation of the TVP5158 Four-Channel PAL/NTSC Video Decoder. The TMS320DM6467 DVEVM (digital video evaluation module) can be used with the TVP5158EVM as a back-end video processor. This user guide outlines the necessary hardware and software setup required to provide full evaluation of the TVP5158.

1.1 Functional Overview

TVP5158EVM is powered by a single 5-V universal supply. The TVP5158EVM allows the user to have up to four composite video inputs and up to four audio inputs. Analog YPbPr component video output is supported for non-interleaved video modes. Digital video is output to the DaVinci HD EVM in a single or dual ITU-R BT.656 configuration or in ITU-R BT.601 (16-Bit) configuration for evaluation of line-interleaved modes.

The TVP5158EVM uses one PC USB port to provide I2C communication with the TVP5158, THS8200 Video/Graphics Triple DAC and the TLV320DAC32 Stereo Audio DAC devices on the TVP5158EVM. The Video Control Center (VCC) application software is provided for control and evaluation of the TVP5158EVM. A VT100 terminal program is required to connect to the DaVinci HD EVM via UART to send Linux shell commands to control the DSP.

1.2 Notational Conventions

This document uses the following conventions.

The TMS320DM6467 Digital Video Evaluation Module is usually referred to as the DaVinci HD EVM.

The TMS320DM6467 Digital Media System-on-Chip is usually referred to as the DM6467.

2 Board Level Description

Figure 1 shows the various features available on the TVP5158EVM.




Figure 1. TVP5158 EVM Block Diagram

2.1 Analog Video/Audio Inputs

The TVP5158EVM makes use of all the available inputs on the TVP5158 decoder, including four CVBS video inputs and four analog audio inputs. Connector J1 has four analog video (CVBS) inputs (yellow RCA jacks) and four analog audio inputs (white RCA jacks).

2.2 Analog Video/Audio Outputs

The TVP5158EVM has a THS8200 Video/PC Graphics Triple DAC and a TLV320DAC32 audio DAC on the board so that the user can evaluate video and audio performance using a single EVM setup. The THS8200 Video/Graphics Triple DAC takes the video output from DVO port A of TVP5158 and outputs analog YPbPr video signals to component output connector J4. The TLV320DAC32 Stereo Audio DAC takes digital audio output from TVP5158 and outputs analog audio to the head phone jack J5.

2.3 Digital Video/Audio Outputs to DaVinci HD EVM

The TVP5158EVM has two dedicated connectors which match the digital video/audio input connectors on the DaVinci HD EVM. Connector J9 includes a 16-bit video data bus (buffered data from DVO_A and DVO_B of TVP5158), OCLK_P, OCLK_N, I2C and interrupts. The connector J10 includes BCLK, LRCLK and SD_R/SD_M outputs from TVP5158. Samtec HQCD cables are required to connect TVP5158EVM digital video and audio signals to the DaVinci HD EVM.

2.4 Digital Video/Audio Cascade Output/Input

The TVP5158EVM has two connectors for video/audio cascade mode test. The connector J2 is for video/audio cascade output, which includes buffered data from the DVO_A and DVO_B video output ports and audio cascade output from TVP5158. The connector J3 is for video/audio cascade input, which includes video input data to the DVO_C and DVO_D video ports and audio cascade input from a lower cascaded stage TVP5158 device.

2.5 I2C Configuration Options

The TVP5158EVM uses one PC USB port for I2C communication. The I2C bus master can be changed based on jumper settings. Control is via the PCB USB interface (VCC application controls TVP5158), via the DaVinci EVM (DSP driver software controls TVP5158) or via the cascade input/output connectors J3 or J2.

2.6 Test Points and Jumpers

Various test points are available on the TVP5158EVM for the user. This includes the various power supplies as well as a few GND test points. The user can also use J2/J3 for primary test-point headers to access video/audio data, video/audio clocks, I2C and GND.

There are several jumpers available on the TVP5158EVM that configure I2C address select, I2C control configuration, clock source selection and I2S source select. Each jumper is set by default in its preferred state for the TVP5158EVM. Next to each jumper on the TVP5158EVM is the silkscreen that describes the various jumper configurations. If the I2C address is changed on the TVP5158EVM while the TVP5158EVM is powered up, then that device will not recognize the new I2C address. The reset button on the TVP5158EVM must be pressed and the VCC application must be exited, restarted, and re-configured for the new I2C address. [Table 1](#) shows the TVP5158EVM jumper settings.

Table 1. TVP5158EVM Jumper Descriptions

Jumper Designator	Description of Function	Default
W0	TVP5158 I2C address selection (I2C_A0) 1-2: Low 2-3: High	1-2
W1	TVP5158 I2C address selection (I2C_A1) 1-2: Low 2-3: High	1-2
W2	TVP5158 I2C address selection (I2C_A2) 1-2: Low 2-3: High	1-2
W3	I2C SDA source selection 1-2: USB controls I2C 2-3: DaVinciHD controls I2C OFF: Control by another EVM for cascade mode.	1-2
W4	I2C SCL source selection 1-2: USB controls I2C 2-3: DaVinciHD controls I2C OFF: Control by another EVM for cascade mode.	1-2

Table 1. TVP5158EVM Jumper Descriptions (continued)


Jumper Designator	Description of Function	Default
W5	Clock source selection 1-2: Crystal 2-3: Clock from another EVM for cascade mode	1-2
W6	I2C EEPROM ON: Use EEPROM (MUST ALWAYS BE ON)	ON
W7	I2C SCL connection for audio DAC	ON
W8	I2C SDA connection for audio DAC	ON
W9	I2S input selection for audio DAC 1-2: TVP5158 mixing output to audio DAC (SD_M) 2-3: TVP5158 record output to audio DAC (SD_R)	2-3

3 System Level Description

The system block diagram illustrated in [Figure 2](#) provides an example of how the TVP5158EVM may be used for evaluation. Typically, the analog video/audio input is provided by a video source such as a pattern generator or a DVD player running a test DVD. The TVP5158EVM is configured with the 5-V supply and the USB cable provided.

The TVP5158EVM analog video output is standard definition component video (YPbPr). These outputs are then fed into a high-end or studio-quality NTSC/PAL monitor.

The user can also connect the TVP5158EVM to a DaVinci HD EVM and then output combined video from the DaVinci HD EVM to a 1080i HD monitor.


Figure 2. TVP5158EVM System Level Block Diagram

4 Required Hardware and Equipment

The required hardware and equipment are as follows:

- Windows-based PC with Windows XP or later
- Video sources (security camera, pattern generator, DVD player, etc.)
- Display monitor that supports
 - 1080i component YPbPr video (50 and 60 Hz)
 - 480i and 576i component YPbPr video
- Audio amplifier/speakers or headphones
- TVP5158EVM (provided)
 - Cables to provide up to four composite video and up to four audio line inputs
 - Component Video (YPbPr) cable for output
 - USB cable (provided)
 - Universal 5-V power supply (100 to 240 VAC in, 5 VDC/3.0 A out) (provided)
- DaVinci HD EVM
 - Two Samtec HQCD cables
 - Component video (YPbPr) cable for output
 - RS-232 null MODEM cable
 - Universal 5-V power supply (100 to 250 VAC in, 5 VDC/5.0 A out)


5 Hardware Setup

The following sections describe the hardware setup for evaluation of the TVP5158.

5.1 Setup for TVP5158EVM Stand-Alone Configuration

For evaluation of video quality, comb filter, noise reduction, auto-contrast and other features, the TVP5158EVM can be setup in a stand-alone configuration. Analog video and audio sources are input to TVP5158. TVP5158 outputs digital video as ITU-R BT.656 or ITU-R BT.601 non-interleaved video to the THS8200 PC Graphics/Video Triple DAC. Component Video YPbPr from the THS8200 is output in 480i or 576i format to a video monitor. To setup the stand-alone configuration, make the following connections:

1. Analog video sources to TVP5158EVM composite video inputs (see [Figure 3](#))
2. Analog audio sources to TVP5158EVM audio line inputs (see [Figure 3](#))
3. Analog component YPbPr video out from TVP5158EVM to video monitor
4. Stereo audio headphone output from TVP5158EVM to audio amplifier/speakers or headphones
5. USB cable from PC to TVP5158EVM. A green LED should be lit indicating that the EVM is ready for communication on the USB.
6. 5-V power supply to the dc jack on the TVP5158EVM


Figure 3. Location of TVP5158EVM Video/Audio Inputs
Table 2. Jumper Settings for Stand-Alone Configuration

Jumper Designator	Function	Setting	Comment
W2, W1, W0	TVP5158 I2C address selection	1-2, 1-2, 1-2	Slave address 0xB0 (1011 LLL0)
W3, W4	I2C master selection	1-2, 1-2	PC USB port controls TVP5158 I2C
W7, W8	I2C connection to audio DAC	ON, ON	Connected
W9	I2S selection to audio DAC	2-3 or 1-2	Monitor record I2S output or mixer I2S output from TVP5158

5.2 Setup for TVP5158EVM with DaVinci HD EVM

The TMS320DM6467 DVEVM (digital video evaluation module) can be used as the audio/video back-end processor for evaluation of TVP5158. This EVM is available separately from Texas Instruments and is referred to as the DaVinci HD EVM in this document.

This configuration allows evaluation of all line-interleaved video output formats with up to four channels in D1, Half-D1 or CIF resolution. Eight-channel line-interleaved video is also possible if two TVP5158EVM boards are cascaded together.

Sample video and audio driver code and a demo application are provided to run on the TMS320DM6467 on the Linux O/S.

To setup the TVP5158EVM with DaVinci HD EVM configuration, make the following connections:

1. Analog video sources to TVP5158EVM composite video inputs (see [Figure 3](#))
2. Analog audio sources to TVP5158EVM audio line inputs (see [Figure 3](#))
3. Analog component YPbPr video out from DaVinci HD EVM to monitor
4. USB cable from PC to TVP5158EVM. A green LED should be lit indicating that the EVM is ready for communication on the USB.

NOTE: If the VCC GUI Software for TVP5158 is not used, it is not necessary to connect the TVP5158EVM to a PC USB port.

5. RS-232 null MODEM cable from PC to DaVinci HD EVM
6. 5-V power supply to the dc jack on the TVP5158EVM
7. 5-V power supply to the dc jack on the DaVinci HD EVM
8. Ethernet cable from LAN to DaVinci HD EVM

5.2.1 Additional Setup when DSP Processes Video Only

In this configuration, digital video goes to the DaVinci HD EVM. Digital I2S audio goes to the TLV320DAC32 Audio DAC on the TVP5158EVM. Stereo audio output can then be taken from the TVP5158EVM headphone jack. Make the following additional connections:

1. Samtec HQCD ribbon cable from TVP5158EVM DaVinci Video connector to the DaVinci HD EVM DC_P2 Video Expansion connector.
2. TVP5158EVM headphone jack to audio amplifier/speakers or headphones

5.2.2 Additional Setup When DSP Processes Video and Audio

CAUTION

A modification to both the TVP5158EVM and the DaVinci HD EVM must be made if I2S digital audio is to be processed by the DM6467 DSP (see [Section 5.2.2.1](#)).

In this configuration, digital video and digital audio go to the DaVinci HD EVM. For the digital audio connection, a hardware modification is required as described in Section 5.2.2.1. The stereo audio is then output from the DaVinci HD EVM headphone jack. After making the hardware modification, make the following additional connections:

1. Samtec HQCD ribbon cable from TVP5158EVM DaVinci Video connector to the DaVinci HD EVM DC_P2 Video Expansion connector
2. Samtec HQCD ribbon cable from TVP5158EVM DaVinci Audio connector to DaVinci HD EVM DC_P3 I/O Expansion connector
3. DaVinci HD EVM headphone jack to audio amplifier/speakers or headphones

5.2.2.1 Hardware Modification for I2S Audio to DM6467 DSP

Three 0-Ω resistors must be removed from the TVP5158EVM and three 0-Ω resistors must be removed from the DaVinci HD EVM according to [Table 3](#).

Table 3. Hardware Modification for I2S Audio to DM6467

Remove From TVP5158EVM	Remove From DaVinci HD EVM
R42 SD_M	R13 MCASP0_ACLKR
R98 MCASP0_EN	R17 MCASP0_AFSR
R99 AUDIO_CLK_EN	R31 MCASP0_AXR1

NOTE: After this modification has been made, the SD_M I2S digital audio output from TVP5158 will no longer be available. The SD_R output must be used and W9 must be jumpered 2-3. If headphone output from the TVP5158EVM is to be tested using the audio mixer (SD_M I2S output), 0-ohm resistor R42 must be reinstalled and W9 must be jumpered 1-2.

5.2.3 Jumper Settings with DaVinci HD EVM

When the DaVinci HD EVM is used, the video and/or audio driver software can be set to control the entire system, or can be set to skip I2C programming of the TVP5158. In the latter case, the PC USB interface and the Video Control Center application software are used to initialize and experiment with TVP5158 register settings through a graphical user interface.

5.2.3.1 DaVinci HD EVM as TVP5158 I2C Master

Table 4 describes the jumper settings to set the DaVinci HD EVM as I2C master for the TVP5158. In this case, the Linux application and driver software control the entire system. Audio can be output from the TVP5158EVM or from the DaVinci HD EVM. See Section 5.2.1 and Section 5.2.2 for audio configurations.

Table 4. Jumper Settings for DaVinci HD EVM as TVP5158 I2C Master

Jumper Designator	Function	Setting	Comment
W2, W1, W0	TVP5158 I2C Address selection	1-2, 1-2, 1-2	Slave address 0xB0 (1011 LLL0)
W3, W4	I2C master selection	2-3, 2-3	DaVinci HD EVM controls TVP5158 I2C
W7, W8	I2C connection to audio DAC	ON, ON	Connected
W9	I2S selection to audio DAC	2-3 or 1-2	Monitor record I2S output or mixer I2S output from TVP5158

5.2.3.2 PC USB as TVP5158 I2C Master with DaVinci HD EVM

Table 5 describes the jumper settings to set the PC USB interface as I2C master for the TVP5158. In this case, the Video Control Center application software can be used to experiment with TVP5158 register settings through a graphical user interface.

NOTE: This system configuration has known I2C issues that sometimes occur when PC USB and DaVinci HD EVM I2C buses are used independently.

Table 5. Jumper Settings for PC USB Interface as TVP5158 I2C Master

Jumper Designator	Function	Setting	Comment
W2, W1, W0	TVP5158 I2C address selection	1-2, 1-2, 1-2	Slave address 0xB0 (1011 LLL0)
W3, W4	I2C master selection	1-2, 1-2	PC USB port controls TVP5158 I2C
W7, W8	I2C connection to audio DAC	ON, ON	Connected
W9	I2S selection to audio DAC	2-3 or 1-2	Monitor record I2S output or mixer I2S output from TVP5158

5.2.3.3 Jumper Settings for Audio/Video Cascade Configuration

CAUTION

If two or more TVP5158EVM boards are cascaded together, care must be taken that the leads on the J2 and J3 connectors are in alignment, because the connectors are not keyed.

Table 6 describes the jumper settings for a second stage TVP5158EVM connected for video/audio cascade operation. In this case, the I2C slave address must be set differently than the first EVM. The I2C Master jumpers must be removed to allow the first stage EVM to control I2C (either from USB or from DaVinci HD EVM). USB should be connected to the first stage EVM if used. The Audio DAC I2C must be disconnected on the second stage, since they are both at the same I2C slave address.

Table 6. Jumper Settings for a Cascaded TVP5158EVM

Jumper Designator	Function	Setting	Comment
W2, W1, W0	TVP5158 I2C address selection	1-2, 1-2, 2-3	Slave address 0xB2 (1011 LLH0)
W3, W4	I2C master selection	OFF, OFF	Stage 1 TVP5158EVM controls TVP5158 I2C
W7, W8	I2C connection to audio DAC	OFF, OFF	Disconnected
W9	I2S selection to audio DAC	2-3	Not used

6 Software Installation

If the TVP5158EVM Software has previously been installed on the PC, it is necessary to uninstall the previous version. To uninstall:

1. Click Start > Control Panel > Add or Remove Programs.
2. Wait for the list to populate.
3. Scroll down and click on "TVP5158EVM Software" to highlight it.
4. Click the remove button.
5. When prompted with Are you sure you want to remove TVP5158EVM Software from your computer?, click Yes.


The TVP5158EVM software installation program is contained in a ZIP archive file containing the following two files:

Setup.exe
TVP5158EVM_Software.msi

Unzip these two files to a temporary directory and run setup.exe. The dialog box in [Figure 4](#) appears. Click Next on the dialog boxes shown in [Figure 4](#), [Figure 5](#), and [Figure 6](#). When the installation is finished, the dialog box shown in [Figure 7](#) appears. Click Close to complete the installation.

Documentation and a shortcut to the VCC application can now be found in the Windows start menu at:

Start > All Programs > TVP5158EVM > TVP5158EVM Software
Start > All Programs > TVP5158EVM > TVP5158EVM User Guide


Figure 4. TVP5158EVM Software Setup Wizard




Figure 5. Select Installation Folder




Figure 6. Confirm Installation




Figure 7. Installation Complete

7 TVP5158EVM Evaluation Procedures

7.1 Stand-Alone Operation - Non-Interleaved Digital Video Output Modes

The following is the procedure for evaluation of TVP5158 for non-interleaved modes. The digital video output from TVP5158 is converted to analog component YPbPr video using a THS8200 Video/PC Graphics Triple DAC:

1. Double-click the TVP5158EVM Software icon on the Windows desktop to start the VCC application.
2. The VCC Configuration dialog box appears (see [Figure 8](#)). Click OK to continue.
3. The Cascaded Devices dialog box appears (see [Figure 9](#)). Click OK to continue. If a message appears indicating that the USB device was not found (see [Figure 10](#)), disconnect the USB cable, wait three seconds and reconnect the USB cable.
4. After 3 to 5 seconds, the Real-Time Polling dialog box appears (see [Figure 11](#)). Click OK to continue.
5. The VCC main window appears (see [Figure 12](#)).
6. Set video source(s) to the NTSC video standard (for this example).
7. Click the Tools > System Initialization menu item. The System Initialization dialog box (see [Figure 13](#)) appears. Click once on the following table entry:
 TVP5158 + THS8200, NTSC, Non-Interleaved, 1-Ch D1, Quad BT.656 @ 27 MHz
 Click the PROGRAM button. The TVP5158 is now programmed for the NTSC standard using the above video output format. The output formatter is bypassed.
8. To select a video input:
 - (a) In the VCC main window, select the video decoder for the video input to be displayed. This will select which source is used to detect the video standard for updating THS8200 register settings.
 - (b) In System Initialization table, click once on one of the following table entries to select the video channel to be displayed and click the Program button.
 Select Ch-1 Video Input
 Select Ch-2 Video Input
 Select Ch-3 Video Input
 Select Ch-4 Video Input
9. Video from the selected video input should now be seen on the monitor and audio channels 1 and 2 should be heard from the left and right speakers respectively.




Figure 8. VCC Configuration




Figure 9. Specifying Cascaded Devices



Figure 10. USB Device Not Found Error Message




Figure 11. Real-Time Polling Enable




Figure 12. VCC Main Window - Set for Communication to All Decoders




Figure 13. System Initialization for Analog Component YPbPr Video Output

7.2 Evaluation Using the DaVinci HD EVM

7.2.1 Setting DM6467 ARM and DDR2 Memory Clock Rates

For maximum performance, in a system using DM6467 and TVP5158(s) in the line-interleaved video modes, the DM6467 clock frequencies should be set as specified in [Table 7](#).

Table 7. Recommended DM6467 Clock Frequencies

ARM Clock	675 MHz
DDR2 Memory Clock	324 MHz ⁽¹⁾

⁽¹⁾ DaVinci HD EVM assembly revision F or later is required.

Since the DaVinci HD EVM is not packaged with the TVP5158, it is usually necessary to program its NAND flash memory to the recommended clock frequencies, as described by the following procedure:

1. Unzip the UBL_DM646x_NAND_675_324.zip archive file onto the PC's local hard drive. Suggested location is C:\UBL
2. Connect a null MODEM 9-pin serial cable from the DaVinci HD EVM UART connector to the PC COM1 serial port.
3. Close any open program that is using the COM1 serial port.
4. Turn OFF the DaVinci HD EVM power switch.
5. Set SW3 Boot Mode Configuration positions 1-3 to OFF and position 4 to ON to select UART0 Flash Boot. SW3 is located beneath the Samtec HQCD digital video ribbon cable. In the OFF position, the switch is moved toward the PCI connector.
6. In the Windows Start menu, click Run, type cmd, and click OK to open a command window.
7. Execute these commands in the command window:

```
cd \ubl
sfh_DM646x.exe -nandflash UBL_DM646x_NAND_675_324.bin u-boot.bin
```
8. After the Waiting for the DM646x... message appears in the terminal window, turn ON the DaVinci HD EVM power switch.
9. After flash programming has completed, turn OFF the DaVinci HD EVM power switch. Set the SW3 Boot Mode Configuration positions 1-3 to ON and position 4 to OFF to select NAND Flash boot mode.

7.2.2 Evaluation Procedure for Line-Interleaved Video Output Modes

The following are the instructions for evaluation of TVP5158 for line-interleaved modes. The digital video output from TVP5158 is captured using a DM6467 DaVinci HD EVM and is demultiplexed and displayed on a 1080i HD monitor.

7.2.2.1 DaVinci HD EVM Boot

1. Start the VT100 terminal application of your choice. For example, HyperTerminal can be started in Windows XP using these steps:
 - (a) Click Start > All Programs > Accessories > Communications > HyperTerminal.
 - Set "Connect using" to:
 - COM1 (or other available serial port)
 - Set "Port Settings" to:
 - Bits per second: 115200
 - Data bits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: None
2. Turn ON the DaVinci HD EVM power switch. It may be necessary to halt the boot process (by striking a key at the terminal) to modify boot parameters (especially the first time). For details of the boot methods see separate documentation that is provided with the DaVinci HD EVM: *TMS320DM6467 DVEVM Getting Started Guide* ([SPRUF88](#)).

NOTE: See the `mcvip_tvp5158\README.TXT` file for instructions on running or building target image and application. This is found in the zip file containing the DaVinci HD video/audio driver source code.

7.2.2.2 Setup DaVinci HD Video / Audio Drivers

Once the DaVinci HD EVM boot has completed, the login: prompt appears at the terminal. Copy and paste the Linux commands below to set up the video capture and audio driver software. In place of <program_directory>, insert the directory path where the driver files are stored.

```
root
cd <program_directory>
insmod cmemk.ko phys_start=0x87800000 phys_end=0x8ba00000 pools=1x1000
./mapdmaq-hd
insmod drv.ko
mknod /dev/dev_i2c c 251 0
mknod /dev/dev_dma c 250 0
```

7.2.2.3 Start VCC Application (Optional – Provides GUI Interface for TVP5158)

1. Double-click the TVP5158EVM Software icon on the Windows desktop to start the VCC application.
2. The VCC Configuration dialog box appears (see [Figure 8](#)). Set THS8200 device family to NOT USED. Click OK to continue.
3. The Cascaded Devices dialog box appears (see [Figure 9](#)). Click OK to continue. If a message appears indicating that the USB device was not found (see [Figure 10](#)), disconnect the USB cable, wait three seconds, and reconnect the USB cable.

NOTE: If a second TVP5158EVM is used for cascade operation select "2 Devices Cascaded" and I2C slave addresses 0xB0 and 0xB2.

4. The VCC main window appears (see [Figure 12](#)).
5. Click the Tools > System Initialization menu item. The System Initialization dialog box appears (see [Figure 13](#)).
6. Click the Browse... button. The Open dialog box appears (see [Figure 14](#)). Double-click the file TVP5158EVM_DaVinci_HD_Setup.CMD




Figure 14. Browse to Command File

The dataset descriptions table should now appear (see [Figure 15](#)).





Figure 15. System Initialization for Line-Interleaved Modes

7.2.2.4 *mcvip_test Demo Application*

The syntax and main menu of the `mcvip_test` (multi-channel video interface port) demo application is shown in Figure 16.



```

Tera Term Web 3.1 - COM3 VT
File Edit Setup Web Control Window Help

Multi Channel Video Input Port (MCVIP) Capture Demo. (c) Texas Instruments 2009
USAGE: ./mcvip_test.out <videoSystem> <i2c Mode> <Cascade Mode> <Audio Mode>

videoSystem = NTSC (default) or PAL
i2c Mode    = WinVCC or DM6467 (default)
Cascade Mode = C1 (default), C2, C3 or C4
Audio Mode  = audio

=====
MCVIP Main Menu (NTSC mode)
=====
00: Start - 2Ch D1 - Port A (BT656 )
01: Start - 2Ch D1 - Port B (BT656 )
02: Start - 4Ch D1 (BT656 )
03: Start - 4Ch Half-D1 (BT656 )
04: Start - 4Ch CIF (BT656 )
05: Start - 4Ch D1 (BT601 )
06: Start - 4Ch Half-D1 (BT601 )
07: Start - 8Ch Half-D1 (BT656 )
08: Start - 8Ch CIF (BT656 )
09: Start - 4Ch Half-D1 + D1 (BT656 )
0a: Start - 4Ch CIF + D1 (BT656 )
0b: Start - 8Ch CIF + D1 (BT656 )
10: Start - 2Ch D1 - Port A (BT656 ) CROP
11: Start - 2Ch D1 - Port B (BT656 ) CROP
12: Start - 4Ch D1 (BT656 ) CROP
13: Start - 4Ch Half-D1 (BT656 ) CROP
14: Start - 4Ch CIF (BT656 ) CROP
15: Start - 4Ch D1 (BT601 ) CROP
16: Start - 4Ch Half-D1 (BT601 ) CROP
17: Start - 8Ch Half-D1 (BT656 ) CROP
18: Start - 8Ch CIF (BT656 ) CROP
19: Start - 4Ch Half-D1 + D1 (BT656 ) CROP
1a: Start - 4Ch CIF + D1 (BT656 ) CROP
1b: Start - 8Ch CIF + D1 (BT656 ) CROP

x: Exit
Enter Choice :

```

Figure 16. `mcvip_test` Demo Application Menu

7.2.2.5 *Procedure for Initializing Individual Video Formats*

The procedure for initializing the system for each individual video output format is as follows:

1. Start the `mcvip_test` application (do not enter the menu option yet).
Example: `./mcvip_test.out NTSC VCC <Cascade Mode Option> <Audio Mode Option>`
 2. Program TVP5158 for the video output format (only if using VCC GUI Software).
In the VCC System Initialization window, click on the video output format (same format as chosen in step 3) and click the PROGRAM button.
 3. Select the video capture format for the DaVinci HD EVM:
In terminal window, type video format menu option (00-1b) and then <Enter>.
The video output should now be displayed on the HD video monitor using 1080i format.
 4. At Linux terminal, type 0 <return> to stop the video capture.
 5. Audio should be heard from the left and right speakers respectively if audio mode option selected.
- Repeat steps 1 through 4 for each line-interleaved video output format.

7.3 Evaluation of Pixel-Interleaved Digital Video Output Modes

The TVP5158EVM can be programmed for pixel-interleaved modes as described below. The DM6467 DaVinci HD EVM does not support pixel interleave modes, so a different back-end processor is required for this evaluation.

1. In the VCC System Initialization dialog box, click the Browse button. The Open dialog box shown in [Figure 14](#) appears. Double-click the following file:
TVP5158EVM_Pixel_Interleave_Setup.CMD
2. The dataset descriptions table should now appear as shown in [Figure 17](#). Click once on the following table entry:

Multi-Standard, Pixel-Interleave, 2-Ch D1, 8-bit @ 54MHz (OCLK_P, OCLK_N @ 27MHz, Opposite Phase)

Click the PROGRAM button. The TVP5158 is now programmed to automatically detect the video standard received at the input and output video in the above pixel-interleaved format.




Figure 17. System Initialization for Pixel Interleave Modes

8 VCC Software in Depth

8.1 VCC Main Window

The VCC main window contains the menu bar whose contents are summarized in [Table 8](#).

Table 8. VCC Main Menu Summary


Menu	Contents
File	Exit
Edit	Register Map – Edit I2C registers directly TVP5158 THS8200 Generic I2C – Edit I2C registers for any slave address Property Sheets – GUI controls for the I2C register map TVP5158 THS8200
Tools	System Initialization – Initializes system using .CMD files Real-time Polling – Enables update of THS8200 when a video standard change occurs USB/LPT/I2C Options – Set 100 or 400 kHz I2C
Window	Allows selection of the active window
Help	Displays program version

8.2 Register Map Editor

The register map editor (see [Figure 18](#)) allows the display and editing of the entire used register space of the TVP5158 within a simple scrolling text box. To open this, click on the following menu item:

Edit > Register Map > TVP5158

[Table 9](#) describes how to use each of the controls in the register map editor.



NOTE: To save registers to a file, check the Histogram Enable checkbox and click Read All. Click Show to view the saved file.

Figure 18. TVP5158 Register Map Editor

Table 9. VCC Register Map Editor Controls

Control	Definition
Register Window	Scrolling text box that displays the address and data for the I2C registers that are defined for the device.
Address Edit Box	This contains the I2C subaddress that will be accessed using the Write and Read buttons. Clicking on a row selects an address, which then appears in the address edit box. NOTE: After clicking on a row, the Data Edit box contains the data that was in the register window. The device has not yet been read. The address up/down arrows are used to jump to the next/previous subaddress that is defined for the device. If an address is not defined for the device, then it can still be accessed by typing the subaddress in the Address Edit box.
Data Edit Box	This contains the data which will be written to or was read from the I2C subaddress. The data up/down arrows increment/decrement the data value by 1.
Write Button	Writes the byte in the Data Edit box to the address in the Address Edit box. The I2C register is written to whether or not the data is different from the last time the register was read.
Read Button	Reads the data from the address in the Address Edit box into the Data Edit box and the register window.
Read All Button	Reads all defined readable registers from the device and updates the register window.
Hex Button	Converts all values in the register window and address and data edit boxes to hexadecimal.
Dec Button	Converts all values in the register window and address and data edit boxes to decimal.
Close Button	Closes the dialog. NOTE: Multiple edit register map windows can be open at the same time (one for each device). Use the Window menu to navigate.
Loop Count	Causes subsequent write, read or read all operations to be performed N times. N is entered as a decimal number from 1 to 999.

8.3 Property Sheets

The property sheets represent the register data in a user-friendly format. The data is organized by function, with each function having its own page and being selectable via tabs at the top.

To open this for the TVP5158, click on the following menu item:

Edit > Property Sheets > TVP5158

When the property sheet function is started or whenever you tab to a different page, all readable registers in the device are read from hardware to initialize the dialog pages. Values on the page are changed by manipulating the various dialog controls as described in [Table 11](#).

Table 10. Property Sheet Controls

Type of Control	Function/How to Set a Value	When is Hardware Updated?
Read-Only Edit Box	Read status information	N/A
Check Box	Toggle a single bit	After Apply
Drop-Down List	Select from a text list	After Apply
Edit Box	Type a number	After Apply
Edit Box with Up/Down Arrows	Use up/down arrows or type a number	Up/Down Arrows: Immediately Type a number: After Apply
Slider	Slide a lever	Immediately
Pushbutton	Initiate an action	Immediately

Table 11. Property Sheet Button Controls

Button	Definition
OK	Writes to all writeable registers whose data has changed. A register is flagged as changed if the value to be written is different from the value last read from that address. Closes the dialog.
Cancel	Causes all changes made to the property page since the last Apply to be discarded. Changes made to dialog controls with 'immediate hardware update' are not discarded, because they have already been changed in hardware. Does not write to hardware. Closes the dialog.
Apply	Writes to all writeable registers whose data has changed. A register is flagged as changed if the value to be written is different from the value last read from that address. Does not close the dialog.

8.3.1 Property Sheet Refresh

The property sheets were designed so that the data displayed is always current. Certain actions cause the entire register map to be read from the device and to update the property sheets. This happens when:

- Property sheets are initially opened.
- When tabbing from one page to another.
- When Read All is clicked.
- When making the Property Sheets window the active window (by clicking on it).
- When making a Register Map Editor window the active window (by clicking on it).

8.4 Video Decoder Select and Write Enables

The VCC main window contains controls for accessing the four video decoders within the TVP5158. The buttons under “Selected Video Decoder Core” are mutually exclusive. Four sets of the various editing tools (Register Map Edit and Property Sheets) exist in memory, but only the data for the selected video decoder can be seen. Any or all of the write enable buttons can be enabled. These control which of the video decoders will accept I2C writes.

8.4.1 Broadcast Write Access

This is the default configuration as shown in [Figure 19](#). All four decoders are enabled for I2C writes. All I2C writes done using the Edit Register Map, Property Sheets, or System Initialization tools will affect all video decoders.

8.4.2 Single Video Decoder Write Access

This configuration is used to program unique settings for one video decoder without effecting the others. The “Set write enable for selected decoder only” check box should be checked as shown in [Figure 20](#). This provides a shortcut, so that as each decoder is selected using the decoder buttons, the same decoder is also enabled for writes (and the other three are disabled for writes).

8.4.3 Arbitrary Video Decoder Write Access

This configuration is used to program the write enabled video decoder(s) in any combination. The “Set write enable for selected decoder only” check box should be unchecked.

NOTE: The command files used by the System Initialization tool can override the write enable button settings. They are generally setup for writing to all decoders independent of the current write enable buttons setting.

8.4.4 Editing Tools vs Video Decoder Write Enables

The behavior of the System Initialization, Edit Register Map and Property Sheets tools regarding the decoder write enables is described in [Table 12](#).




Figure 19. VCC Main Window – Configured for Broadcast Write Access (default)




Figure 20. VCC Main Window – Configured for Single Video Decoder Write Access

Table 12. Editing Tools vs Video Decoder Write Enables

Editing Tool	Reads From	Writes To	Writes What
Command File	N/A	Write Enabled decoders (can be overridden in cmd file)	I2C register values
Edit Register Map	Selected Decoder	Write Enabled decoders	1 byte – same data to all
Edit Property Sheets	Selected Decoder	Write Enabled decoders	Bit fields that changed on the selected decoder

8.5 Example TVP5158 Property Pages

Example property pages are shown in [Figure 21](#) through [Figure 24](#).

Some of the controls for the Output Formatter (OFM) page only exist for video decoder 1. [Figure 21](#) shows the OFM page when Decoder 1 is the selected decoder. [Figure 22](#) shows the OFM page when Decoder 4 is the selected decoder (some of the OFM controls are not visible). They would also not be visible for Decoder 2 and Decoder 3. To change the Port A selection, for example, Decoder 1 must be the selected decoder.

The Audio property page only exists for video decoder 1. To access the Audio controls Decoder 1 must be the selected decoder.




Figure 21. TVP5158 Output Formatter Property Page With Decoder 1 Selected

TVP5158 Decoder #4 (0x80) Property Sheets

Video Format	Analog Video (Not Used)	Automatic Gain Control	Composite Chroma	Composite Luma	Synchronization	Output Control
Macrovision Detection	Video Decoder Status	AFE Gain	Noise Reduction and Auto-Contrast	Output Formatter		

Interleave Mode:

Non-Interleaved
 Pixel Interleaved
 Line Interleaved
 Line Interleaved Hybrid

Common Controls:

No. Multiplexed Channels: 4 Channels

Scaled Image Resolution: D1 (720 x 480)

Crop Image

Interface Type: ITU-R BT.656 (8-bit)

10 to 8-bit Conversion:

Truncate
 Dither
 Round

Pixel Interleaved Options:

Chan ID in SAV/EAV
 Chan ID in Blank Level
 Video Detection Bit

Line Interleaved Options:

Line ID:

Count through VBI
 Hold at Start of VBI

Non-Interleaved Options:

Line-Locked Output Clock

Cascade Stage: First

Figure 22. TVP5158 Output Formatter Property Page With Decoder 4 Selected




Figure 23. TVP5158 Noise Reduction and Auto Contrast Property Page




Figure 24. TVP5158 Audio Property Page (Seen Only When Decoder 1 is Selected)

Figure 25 shows how TDM I2S audio data can be configured. Jumper W9 can be used to select the SD_R (default) or SD_M I2S output to the audio DAC.

I ^S																			
tdm_ch	tdm_out_pin	LRCLK_RLeft									LRCLK_RRight								
		Slot1	Slot2	Slot3	Slot4	Slot5	Slot6	Slot7	Slot8	Slot9	Slot10	Slot11	Slot12	Slot13	Slot14	Slot15	Slot16		
0 (2 channel)	0	SD_R	AIN_1									AIN_2							
	SD_M																		
1	SD_R	AIN_1																	
	SD_M	AIN_2																	
1 (4 channel)	0	SD_R	AIN_1	AIN_3								AIN_2	AIN_4						
	SD_M																		
1	SD_R	AIN_1										AIN_2							
	SD_M	AIN_3										AIN_4							
2 (8 channel)	0	SD_R	AIN_1	AIN_3	AIN_5	AIN_7						AIN_2	AIN_4	AIN_6	AIN_8				
	SD_M																		
1	SD_R	AIN_1	AIN_5									AIN_2	AIN_6						
	SD_M	AIN_3	AIN_7									AIN_4	AIN_8						
3 (12 channel)	0	SD_R	AIN_1	AIN_3	AIN_5	AIN_7	AIN_9	AIN_11				AIN_2	AIN_4	AIN_6	AIN_8	AIN_10	AIN_12		
	SD_M																		
1	SD_R	AIN_1	AIN_5	AIN_9								AIN_2	AIN_6	AIN_10					
	SD_M	AIN_3	AIN_7	AIN_11								AIN_4	AIN_8	AIN_12					
4 (16channel)	0	SD_R	AIN_1	AIN_3	AIN_5	AIN_7	AIN_9	AIN_11	AIN_13	AIN_15		AIN_2	AIN_4	AIN_6	AIN_8	AIN_10	AIN_12	AIN_14	AIN_16
	SD_M																		
1	SD_R	AIN_1	AIN_5	AIN_9	AIN_13							AIN_2	AIN_6	AIN_10	AIN_14				
	SD_M	AIN_3	AIN_7	AIN_11	AIN_15							AIN_4	AIN_8	AIN_12	AIN_16				

DSP Format																		
tdm_ch	tdm_out_pin	LRCLK_RLeft									LRCLK_RRight							
		Slot1	Slot2	Slot3	Slot4	Slot5	Slot6	Slot7	Slot8	Slot9	Slot10	Slot11	Slot12	Slot13	Slot14	Slot15	Slot16	
0 (2 channel)	0	SD_R	AIN_1	AIN_2														
	SD_M																	
1	SD_R	AIN_1																
	SD_M	AIN_2																
1 (4 channel)	0	SD_R	AIN_1	AIN_3	AIN_2	AIN_4												
	SD_M																	
1	SD_R	AIN_1	AIN_2															
	SD_M	AIN_3	AIN_4															
2 (8 channel)	0	SD_R	AIN_1	AIN_3	AIN_5	AIN_7	AIN_2	AIN_4	AIN_6	AIN_8								
	SD_M																	
1	SD_R	AIN_1	AIN_5	AIN_2	AIN_6													
	SD_M	AIN_3	AIN_7	AIN_4	AIN_8													
3 (12 channel)	0	SD_R	AIN_1	AIN_3	AIN_5	AIN_7	AIN_9	AIN_11	AIN_2	AIN_4	AIN_6	AIN_8	AIN_10	AIN_12				
	SD_M																	
1	SD_R	AIN_1	AIN_5	AIN_9	AIN_2	AIN_6	AIN_10											
	SD_M	AIN_3	AIN_7	AIN_11	AIN_4	AIN_8	AIN_12											
4 (16channel)	0	SD_R	AIN_1	AIN_3	AIN_5	AIN_7	AIN_9	AIN_11	AIN_13	AIN_15	AIN_2	AIN_4	AIN_6	AIN_8	AIN_10	AIN_12	AIN_14	AIN_16
	SD_M																	
1	SD_R	AIN_1	AIN_5	AIN_9	AIN_13	AIN_2	AIN_6	AIN_10	AIN_14									
	SD_M	AIN_3	AIN_7	AIN_11	AIN_15	AIN_4	AIN_8	AIN_12	AIN_16									

Figure 25. TDM I2S Audio Data Configuration

9 Troubleshooting

This section discusses ways to troubleshoot the TVP5158EVM.

9.1 Troubleshooting Guide

If you are experiencing problems with the TVP5158EVM hardware or the VCC software, see [Table 13](#) through [Table 16](#) for available solutions.

Table 13. Troubleshooting Setup and General Issues

Symptom	Cause	Solution
TVP5158EVM Software Installer reports that previous version must be uninstalled	Previous version was installed	Use "Add or Remove Programs" in Windows Control Panel to remove previous version of TVP5158EVM Software. Run SETUP.EXE again.
On connecting USB cable, green "connected LED" does not light.	EVM was not recognized on the USB.	Disconnect USB cable between PC and EVM. Wait 3 seconds. Reconnect the USB cable. Green "connected LED" near USB connector should light.
On connecting USB cable, New Hardware Wizard appears	Jumper W6 has been removed.	Install jumper W6 near USB connector. Disconnect USB cable between PC and EVM. Wait 3 seconds. Reconnect the USB cable. Green "connected LED" should light.
VCC application has slow response time.	USB polling rate is too slow.	Connect EVM directly to a laptop/desktop USB port instead going through a docking station. Property Pages can not be refreshed using Read All buttons at more than about a 1-Hz rate.
Nothing seems to happen when I click Read All repeatedly.	Clicking Read All button too frequently.	Property Pages can not be refreshed using Read All buttons at more than about a 1-Hz rate.

Table 14. Troubleshooting with THS8200 and CompositeVideo Output

Symptom	Cause	Solution
USB: Device Not Found error message	EVM was not recognized on the USB.	Disconnect USB cable. Wait 3 seconds. Reconnect USB cable. Green "connected LED" should light. Click continue
USB: I2C Error Code 1 error message. An I2C acknowledge error has occurred. See reported I2C slave address and sub-address.	5V power not present	Connect 5V power supply to EVM. Click Continue.
	EVM hardware reset button has been pressed.	Normal occurrence. An I2C error will occur if the hardware reset button is pressed while real-time polling or property page auto-update is active. Click Continue.
	I2C slave address jumper setting and program setting do not match.	Check that jumpers W2, W1 and W0 are connected across pins 1-2 (L, L, L) to specify slave address 0xB0 (Set jumper W0 across pins 2-3 (L, L, H) to specify slave address 0xB2 for a cascaded 2nd TVP5158EVM.) Exit VCC application. Restart VCC and select the correct I2C slave address.
No video output	I2C bus master jumpered incorrectly.	Check that jumpers W3 and W4 are connected across pins 1-2 to select USB as I2C master.
	Wrong video input is selected.	Click on System Initialization in the Tools menu. Browse to TVP5158EVM_YPbPr_Output_Setup.CMD. Click on the dataset named "Select Ch-X Video Input". (X is the channel to be displayed.) Click the program button.
	TVP5158 is not locked to video signal.	Click on Property Sheets -> TVP5158 in the Edit menu (see Figure 26). Lock status LEDs should both be green. In main window, click buttons Decoder1,...,Decoder4 to see the lock status of each decoder (see Figure 3). for numbering of video inputs.
	THS8200 is not receiving BT.656 data correctly.	Click on Property Sheets -> THS8200 in the Edit menu. Pixel count/line count status should be 858/525 for NTSC or 864/625 for PAL (see Figure 27).
Horizontal instability in displayed image	THS8200 programmed for wrong standard.	Click on Property Sheets -> THS8200 in the Edit menu. Click DTG tab. Frame Size should be set to 525 if source is NTSC or 625 if source is PAL. If not, click Real-time polling button in the Tools menu.
	THS8200 Video Triple DAC requires a line-locked clock.	On TVP5158 Output Formatter property page, check the Line-Locked Output Clock check box. Set the Port A Channel Selection drop-down box to select the video input for display. Line-Locked Output Clock is required when using non-interleaved mode and THS8200.
No audio	Wrong digital audio output selected.	Set jumper W9 across pins 2-3 to hear the record output (SD_R) or across 1-2 to hear the mixer output (SD_M).

Table 15. Troubleshooting with DM6467 DaVinci HD EVM

Symptom	Cause	Solution
No serial communication	Wrong serial port settings	Set terminal program to 115200 baud, 8 bit data, no parity, 1 stop bit. Check that COM port is available in the Windows Device Manager and is not being used by another program.
	Wrong cable type	Use a null MODEM 9-pin serial cable. Pins 2 and 3 at one end should be wired to pins 3 and 2 at the other end.
Boot up process fails	No wired network connection	Connect Ethernet LAN cable to DaVinci HD EVM
	No FTP server available	Boot up arguments must specify the IP address of the computer that contains the image file to be loaded. An FTP server program must be running on that computer.
	No Linux host available	A PC running the Linux O/S or a PC running the Windows O/S with a virtual Linux O/S must be accessible on the LAN and provide a shared file system for the boot process.

Table 16. Troubleshooting I2C Connections and Cascaded EVMs

Symptom	Cause	Solution
When PC USB (VCC application) is I2C master for TVP5158		
USB: I2C Error Code 1 error message.	I2C bus master jumpered incorrectly.	Check that jumpers W3 and W4 are connected across pins 1-2 to select USB as I2C master.
When DSP video/audio driver is I2C master for TVP5158		
I2C error messages from demo application.	I2C bus master jumpered incorrectly.	Check that jumpers W3 and W4 are connected across pins 2-3 to select DaVinci HD EVM as I2C master.
When cascading two TVP5158EVMs together		
I2C error messages from demo application.	I2C bus master jumpered incorrectly.	<p>The Stage 2 TVP5158EVM feeds cascaded video and audio data through connector J2 to connector J3 of the Stage 1 TVP5158EVM.</p> <p>On the Stage 2 board, check that jumpers W2, W1, and W0 are connected across pins 1-2, 1-2 and 2-3 (L, L, H) respectively, to specify slave address 0xB2.</p> <p>On the Stage 2 board, check that jumpers W3 and W4 are both removed to allow I2C to be mastered by the stage 1 board.</p> <p>Also on the Stage 2 board, remove W7 and W8 to remove the second Audio DAC from the I2C bus.</p> <p>The Stage 1 TVP5158EVM can have I2C controlled by USB or the DaVinci HD EVM.</p> <p>Any changes to the above setup require that VCC be exited and restarted so that the correct I2C slave address(es) can be selected.</p>




Figure 26. TVP5158 Video Format Property Page






Figure 27. THS8200 Input Controls / Status Property Page




TEXAS INSTRUMENTS	
TVP5158 EVM	
Doc Number	AUDIO
Rev	3
Part	TVP5158_0209
Sheet	2 of 3

Figure 29. Schematics (2 of 8)



TEXAS INSTRUMENTS	
TVP5158 EVM	
Document Number	TVP5158 MISC
Rev	3
Part Number	TVP5158
Subject	08_2009

Figure 30. Schematics (3 of 8)



File	TEXAS INSTRUMENTS
Part	TVP5158 EVM
Document Number	TVP5158_POWER
Rev	3
Page	8
Subject	TVP5158 EVM

Figure 31. Schematics (4 of 8)






Figure 33. Schematics (6 of 8)



TEXAS INSTRUMENTS	
TVP5158 EVM	
Document Number	USB I2C
Rev	3
Part Number	TPV5158_020008.08_2009

Figure 34. Schematics (7 of 8)



IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products

Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
RF/IF and ZigBee® Solutions	www.ti.com/lprf

Applications

Audio	www.ti.com/audio
Automotive	www.ti.com/automotive
Broadband	www.ti.com/broadband
Digital Control	www.ti.com/digitalcontrol
Medical	www.ti.com/medical
Military	www.ti.com/military
Optical Networking	www.ti.com/opticalnetwork
Security	www.ti.com/security
Telephony	www.ti.com/telephony
Video & Imaging	www.ti.com/video
Wireless	www.ti.com/wireless

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2009, Texas Instruments Incorporated

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>