



DK	Elektronisk vinkøleskab	2
UK	Electronic wine cooler	4

INTRODUKTION

For at De kan få mest glæde af Deres nye vinkøleskab, beder vi Dem venligst gennemlæse denne brugsanvisning, før De tager apparatet i brug. Vi anbefaler Dem yderligere at gemme brugsanvisningen, hvis De på et senere tidspunkt skulle få brug for at opfriske apparatets funktioner.

ALMINDELIGE SIKKERHEDSFORANSTALTNINGER

- Nedsænk aldrig ledningen, stikket eller selve apparatet i nogen former for væske.
- Hvis ledningen, stikket eller selve apparatet skulle blive beskadiget, forsøg da ikke selv at reparere skaden, men henvend Dem til en fagmand for reparation, da der skal anvendes specialværktøj.
- Brug kun apparatet indendørs.
- Sørg for at ledningen ikke kommer i berøring med varmekilder såsom kogeplader, kogeapparater m.v., da dette kan beskadige ledningen.
- Apparatet må ikke placeres nær varmekilder, ovne, varmeblæsere m.v.
- Apparatet må kun anvendes til det, den er fremstillet til.
- Der må kun bruges originale reservedele til denne maskine.

BEMÆRK

Leverandøren påtager sig intet ansvar for evt. skader påført indholdet, såfremt der skulle opstå fejl eller anden funktionssvigt ved skabet.

FØR IBRUGTAGNING

Fjern transport sikringerne før ibrugtagning.

Inden vinkøleskabet tilsluttes efter transport skal det stå i 2 timer for at undgå fejl på kølesystemet.

INSTALLATION OG PLACERING AF VINKØLESKABET

- Vinkøleskabet skal placeres på en plan og hård overflade (visse modeller har justerbare fødder) i et tørt og regelmæssigt ventileret rum.
- Placer ikke vinkøleskabet nær varmekilder som eksempelvis kogeplader, radiatorer, vandvarmere o.l. eller i direkte sollys.
- Sørg for at der er luft rundt om vinkøleskabet

Vinkøleskabet har to fastindstillede temperaturer, en for rødvin, og en for hvidvin.

Tryk på RED tasten, temperaturen i vinkøleskabet vil blive 13°C, eller tryk på WHITE tasten, temperaturen vil nu blive 8°C. Disse fastindstillede temperaturer kan ikke ændres.

Når der trykkes på enten RED eller WHITE tasterne vil opbevarings temperaturen for den pågældende vin type vises i displayet i nogle få sekunder, derefter vil displayet igen vende tilbage til den aktuelle temperatur i vinkøleskabet.

MANUEL TEMPERATUR INDSTILLING

- Hvis en anden temperatur ønskes gøres dette ved hjælp af pil op og pil ned tasterne på følgende måde. (Temperaturen kan indstilles fra 4° C til 18° C.)

- Tryk på og hold SET tasten inde til der høres en beep lyd (ca. 15 sekunder)
- Tryk på pil op eller pil ned for at indstille den ønskede temperatur, hvert tryk ændrer temperaturen med én grad.
- Når den ønskede temperatur vises i displayet trykkes der på SET for at bekræfte den valgte temperatur. Efter manuel indstilling af temperaturen vil begge indikatorer for henholdsvis RED og WHITE være slukket.
- Bemærk: Den valgte temperatur skal bekræftes inden 10 sekunder, ellers skal der startes forfra.

BEMÆRK

Kontrollampen på vinkøleskabet har 3 funktioner

1. Begynder at blinke lige før kompressoren starter.
2. Lyser konstant når vinkøleskabet køler.
3. Er slukket når kompressoren ikke kører.

SPARE TIPS

- Undgå at åbne lågen unødvendigt, især når det er varmt og fugtigt.
- Når lågen åbnes bør den lukkes så hurtigt som muligt.
- Sørg for at der er tilstrækkeligt med luftcirkulation bag vinkøleskabet
- Dannes der is inde i skabet øges energiforbruget, dette bør fjernes når det er 3-5 mm tykt.
- Skades pakningen i lågen skal denne skiftes.

AUTOMATISK AFRIMNING

- Det er ikke nødvendig at afrime vinkøleskabet, da dette foregår automatisk.
- Når kompressoren kører kan der dannes is på bagvæggen, dette is vil blive afrimet og vandet blive afledt til en skål beliggende ovenover kompressoren hvorfra det vil fordampe.

FEJLFINDING PÅ VINKØLESKABET

Vinkøleskabet køler ikke:

- Se efter om stikket er i stikkontakten og at der er tændt for denne.
- Om sikringen / HFI relæ er OK.
- At der er tændt for vinkøleskabet.

Vinkøleskabets kompressor kører uafbrudt:

- Lågen er ofte åben eller er åben for længe ad gangen.
- Lågen er ikke lukket helt til, eller pakningen er beskadiget.
- Vinkøleskabet er overfyldt, eller utilstrækkelig ventilation af kompressoren.

Is indvendig på bagvæggen:

- Normalt skal vinkøleskabet ikke afrimes, men hvis f. eks pakningen er defekt, lågen har stået åben for længe, eller indholdet har været for varmt kan der dannes is på bagvæggen hvis den får en tykkelse på 3-5 mm er det nødvendigt med en manuel afrimning.
- Set termostaten på stop, lad lågen stå åben således isen smelter.
- Afrim ikke vinkøleskabet med andre elektriske apparater f. eks en hårtørrer e.l.
- Forsøg heller ikke at skrabe is af med skarpe genstande.
- Efter endt afrimning sættes termostaten igen på den ønskede temperatur.

FABRIKSINDSTILLING

Programmering til fabriksindstilling.

- Tryk og hold WHITE tasten inde, derefter straks (indenfor ét sekund) på RED tasten, disse holdes inde i ca. 10 sekunder til der høres et beep, herefter er indstillingerne tilbage til fabriksindstilling.
- Dette kan være nyttigt i forbindelse med fejlfinding på vinkøleskabet.

UDSKIFTNING AF PÆRE I VINKØLESKABET

- Tag stikket ud af stikkontakten.
- Løsn skruen der holder beskyttelsesglasset under pæren og fjern dette.
- Skift pæren, og sæt beskyttelsesglasset på igen.

RENGØRING AF VINKØLESKABET

- Sluk for vinkøleskabet, og tag stikket ud af stikkontakten inden rengøring.
- Du må ikke bruge skurepulver, stålsvampe eller andre stærke rengøringsmidler til rengøring af vinkøleskabets indvendige og udvendige overflader, da disse rengøringsmidler kan ridse fladerne.
- Brug i stedet en klud fugtet med varmt vand, og tilsæt eventuelt lidt opvaskemiddel, hvis vinkøleskabet er meget beskidt.
- Til indvendig rengøring kan der tilsættes en smule eddike.
- Plasticdele må ikke vaskes i opvaskemaskine

REPARATION

Reparation skal foretages af et autoriseret værksted.

MILJØTIPS

Et el/elektronik produkt bør, når det ikke længere er funktionsdygtigt, bortskaffes med mindst mulig miljøbelastning. Apparatet skal bortskaffes efter de lokale regler i din kommune, men i de fleste tilfælde kan du komme af med produktet på din lokale genbrugsstation

GARANTIE GÆLDER IKKE

1. Hvis ovennævnte ikke iagttages.
2. Hvis apparatet har været misligholdt, været udsat for vold, eller lidt anden form for overlast.
3. Hvis der har været foretaget uautoriserede indgreb i apparatet.
4. Fejl som måtte opstå grundet fejl på ledningsnettet.

Vi tager forbehold for trykfejl.

IMPORTØR:

Adexi group

INTRODUCTION

Please read this instruction manual carefully and familiarise yourself with your new wine cooler, before using the first time. Please retain this manual for future reference.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock and/or personal injury, including the following:

- Check that the voltage of your appliance corresponds with the mains voltage of your home. The appliance is fitted with an earth for extra safety.
- Read all instructions before using.
- To protect against fire, electric shock and personal injury, do not immerse cord, plug in water or other liquid.
- Do not operate with a damaged cord or plug. There are no user serviceable parts.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner or in a heated oven.
- Do not use this appliance for other than intended household use.
- Remove plug by grasping plug body and pulling it from the outlet. Never yank or twist the cord.

NOTE

Supplier will accept no responsibility for any damage to the content, arising as a result of fault or other malfunction of this unit.

BEFORE USE

Remove the transport securings before using the device.

Before connecting your wine refrigerator following transportation, leave it to stand for 2 hours in order to avoid problems in the refrigeration system.

INSTALLATION AND POSITIONING OF THE WINE REFRIGERATOR

- The wine refrigerator must be placed on a firm, level surface (some models have adjustable legs) in a dry and well-ventilated room.
- Do not place the wine refrigerator near to heat sources such as hotplates, radiators or water heaters, or in direct sunlight.
- Ensure there is air around the wine refrigerator

The wine refrigerator has two fixed temperatures, one for red wine and one for white wine.

Press the RED button for a temperature of 13°C in the wine refrigerator, or press the WHITE button for a temperature of 8°C. These fixed temperatures cannot be altered.

When you press either the RED or the WHITE button, the storage temperature for the relevant wine type will appear on the display for a few seconds, following which the display will return to showing the current temperature inside the wine refrigerator.

MANUAL TEMPERATURE SETTING

- If you require a different temperature, use the up and down arrow buttons as follows. (Possible temperature settings range from 4° C to 18° C.)
- Press and hold the SET button until you hear a beep (around 15 seconds).
- Press the up or down arrow to set the temperature you want; each time you press, the temperature changes one degree.
- Once the temperature you want appears in the display, press SET to confirm the selected temperature. After you have set the temperature manually, the indicators for both RED and WHITE will disappear.
- Please note: The selected temperature must be confirmed within 10 seconds, otherwise you must start again from the beginning.

NOTE

The indicator light on the wine refrigerator has 3 functions

1. It begins to flash just before the compressor starts up.
2. It stays on when the wine refrigerator is in cooling mode.
3. It goes off when the compressor is not running.

ENERGY-SAVING TIPS

- Avoid opening the door unnecessarily, particularly when it is warm and humid.
- When you do open the door, close it again as soon as possible.
- Ensure there is plenty of air circulation behind the wine refrigerator.
- If ice forms inside the cabinet, energy consumption will increase, so you should remove it once it is 3-5 mm thick.
- If the door seal is damaged, it must be replaced.

AUTOMATIC DEFROSTING

- It is not necessary to defrost the wine refrigerator, as this happens automatically.
- When the compressor is running, ice may form on the rear wall. This ice will be defrosted and the water will be conducted away to a container above the compressor, from where it will simply evaporate.

TROUBLESHOOTING THE WINE REFRIGERATOR

The wine refrigerator will not cool:

- Check the plug is in the wall and that it is switched on at the wall.
- Check that the fuse / HFI relay is OK.
- Check that the wine refrigerator is switched on.

The compressor of the wine refrigerator is running all the time:

- The door is often open or is open for long periods.
- The door is not fully shut, or the seal is damaged.
- The wine refrigerator is overfull, or the compressor is inadequately ventilated.

Ice on the inside of the rear wall:

- The wine refrigerator does not normally need defrosting, but if, for example, the seal is defective, the door has stood open for a long period, or the contents were too warm, ice may form on the rear wall. If it reaches a thickness of 3-5 mm, manual defrosting is necessary.
- Set the thermostat to stop, and leave the door open so the ice melts.
- Do not use other electrical devices (hair dryer, etc.) to defrost the wine refrigerator.
- Do not attempt to scrape ice off using sharp objects.
- Once defrosting is complete, set the thermostat back to the temperature you want.

FACTORY SETTING

Programming to factory setting.

- Press and hold the WHITE button, then immediately (within one second) the RED button, and hold these down for approximately 10 seconds until you hear a beep. The settings have now been returned to the factory setting.
- This may be useful when troubleshooting the wine refrigerator.

CHANGING THE LIGHT BULB IN THE WINE REFRIGERATOR

- Remove the plug from the socket.
- Loosen the screw holding the protective glass over the light bulb and remove this.
- Change the bulb and then replace the protective glass.

CLEANING THE WINE REFRIGERATOR

- Switch the wine refrigerator off and remove the plug from the wall socket before cleaning.
- Never use scouring powder, steel scourers or other strong cleaning agents to clean the interior or exterior surfaces of the wine refrigerator, as they may scratch the surfaces.
- Instead use a cloth dampened with hot water, and add detergent if the wine refrigerator is very dirty.
- A little vinegar may be added for cleaning the interior.
- The plastic parts are not dishwasher-safe

REPAIRS

- Any repairs must be carried out by an authorised workshop.
4 sets 35 pieces ENVIRONMENTAL TIP
- An electronic appliance should, when it is no longer capable of functioning be disposed with least possible environmental damage. The appliance should be disposed according to the local regulations in your municipality, in most cases you can discharge the appliance at your local recycling center.

THE WARRENTY DO NOT COVER

- If the above points have not been observed.
- If the appliance has not been properly maintained, if force has been used against it or if it has been damaged in any other way.
- If the appliance has been repaired or modified or changed in any way or by any person not properly authorized.
- Errors or faults owing to defects in the distribution system.

We take reservation for printing errors.

Owing to our constant development of our products on both functionality and design we reserve the right to change the product without preceding notice.

Importer

Adexi group

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>