FRONT

SS4 47280 MUG

SUPER STREET FIGHTER™ IV FIGHTPAD™

Thank you for purchasing the Super Street Fighter™ IV FightPad™ for use with the Xbox 360® video game system. Be sure to register your product online at www.madcatz.com/support/register and keep a copy of this other quality video game accessories.

IMPORTANT! Before using the Xbox 360®: with this product, read the Xbox 360 instruction manual for safety, health, and other information regarding the use of the Xbox 360.

DISCLAIMER
This game controller was specifically designed for use with Super Street Fighter IV. For use with other games, please refer to the game's manual or in-game control options.

Usage and Turbo Instructions

3-Way Switch

The "FightPad" is equipped with a 3-way switch labeled "LS", "DP" and "RS," which allows the D-Pad to emulate either the left or right analog stick of a standard controller. Set the switch to the desired location to make use of this feature.

Turbo Button Usage:

NOTE: The action buttons to which the turbo feature can be assigned are: A, B, X, Y, LT, RT, LB and RB.

Press and hold the "TURBO" button. Once the "TURBO" button has been pressed for approximately 1 sec, wait a few (~5) second seconds to begin the programming process below:
1. While continuing to hold down the "TURBO" button, press the action button you want to assign turbo to:
a. One (1) time for fast turbo speed – the turbo LED will flash rapidly.
b. Two (2) times for slow turbo speed – the turbo LED will flash slowly.
c. Three (3) times to cancel turbo – the turbo LED will go out.
2. Release the "TURBO" button and the action button you pressed above.
3. Once turbo has been assigned to an action button, simply press and release the "TURBO" button to complete the process.

NOTE: The controller's turbo LED will remain illuminated during gameplay if an action button(s) has been properly programmed. If the setup procedure has not been properly completed, the turbo LED will not illuminate and the procedure must be retried.

Turbo Cancellation

NOTE: If the controller (wired) is unplugged from the console, or loses its wireless connection or is powered off, all programmed turbo functions will be cancelled.

There are two (2) different cancellation methods, individual action buttons and all action buttons:

Individual action buttons:
1. Press and hold the "TURBO" button.
2. While continuing to hold down the "TURBO" button, press any action button(s) which turbo has been assigned to (which turbo to cancel).
3. Repeat step two (2) above to cancel other action buttons.

All action buttons:
1. Press and hold the "TURBO" button for five (5) seconds without depressing any programmable action buttons.
2. After five (5) seconds, the turbo LED will illuminate for one (1) second and then go out, indicating all turbo functionality has been cancelled.

FAQ
Q: When starting my Xbox 360, why can't I navigate through the main dashboard?
A: Ensure the Control Function Switch is set to the D-Pad "DP" setting. This will enable you to navigate through the Xbox 360 dashboard.

Q: How do I deactivate the turbo settings?
A: The "FightPad" has a "TURBO" button and turbo feature. By holding down the "TURBO" button for approximately 5 sec and without depressing any programmable action buttons, all turbo settings will be cleared. You can also unplug the "FightPad" from the console. All turbo settings will be cleared after plugging it back into the console.

Q: My "FightPad" is not being recognized by the Xbox 360 console. What should I do?
A: Ensure the breakaway cable is fully plugged in and the USB cable is placed firmly into the controller port on the Xbox 360 console. When the breakaway cable is loose, the console will sometimes fail to recognize the controller.

Q: The D-Pad doesn't function at all when I try inputting directions. Why is that?
A: Ensure the Control Function Switch is set to either the left analog stick ("LS" or D-Pad "DP" setting).

90-day LIMITED WARRANTY USA:
Mad Catz warrants to the original purchaser that this product is free from defects in materials and workmanship for the warranty period. This warranty does not cover consumable parts, batteries, or damage that occurs in shipment or due to misuse, abuse, or neglect. This warranty is void if the user has modified your product (shell, PCB, or any other component) or if your Mad Catz product is in a device used for illegal or commercial purposes. If a defect covered by this warranty occurs during the warranty period, Mad Catz will repair or replace the product at its option, with repaired or replaced product of equal value.

2 year LIMITED WARRANTY Europe:
Mad Catz warrants to the original purchaser that this product is free from defects in materials and workmanship for the warranty period. This warranty does not cover consumable parts, batteries, or damage that occurs in shipment or due to misuse, abuse, or neglect. This warranty is void if the user has modified your product (shell, PCB, or any other component) or if your Mad Catz product is in a device used for illegal or commercial purposes. If a defect covered by this warranty occurs during the warranty period, Mad Catz will repair or replace the product at its option, with repaired or replaced product of equal value.

Mad Catz Europe GmbH
Technical Support Department
Tel: +49 (0) 180 5 22 72 37 (DE, AT, CH, LU)
Tel: +44 (0) 870 873 1179 (UK, IE)
Fax: +49 (0) 180 5 22 72 38
Technical Support Hours: Mon-Fri 10:00 - 19:00 CET

Mad Catz Inc.
Technical Support Department
Tel: +1 (858) 268-2500
Fax: +1 (858) 268-2501
Technical Support Hours: Mon-Fri 8:00 - 17:00 PST

Mad Catz Asia Pacific Limited
Technical Support Department
Tel: +852 2511 6533
Fax: +852 2511 6534
Technical Support Hours: Mon-Fri 10:00 - 18:00 HKT

Product No. 47280-1200

BACK

SS4 47280 MUG

1. Sul un segundo y luego se apagará. Lo que indica que se cancelaron todas las funciones.

PROCEDIMIENTO MAS PRECISO(PC-DVD)
Si el D-Pad no funciona como debería, comprueba que el interruptor del control de juego del Xbox 360® "DP" está en la posición de desplazarse por el tablero de la Xbox 360.

¿Cómo desactivo la configuración del turbo?
R: Rey 2 (sólo manera de desactivar la función turbo. Al presionar el botón de activación Turbo durante 5 segundos con sólo los botones de acción programables, se borrará toda la configuración turbo. También puede desconectar el "FightPad" de la consola. Todas las configuraciones turbo se borrarán después de volver a conectarlo.

P: La consola Xbox 360 no reconoce mi "FightPad". ¿Qué puedo hacer?
R: Asegurarse de que el cable de separación esté completamente enchufado y que el cable USB está firmemente colocado en el puerto del controlador de la consola Xbox 360. Si el cable no está bien conectado, la consola podría no reconocer el controlador.

P: El D-Pad no funciona cuando intento ingresar direcciones. ¿Por qué ocurre esto?
R: Asegúrese de que el interruptor de función de control está configurado como izquierda analógica ("LS" o D-Pad "DP" ajuste).

GARANTIA LIMITADA DE 90 DIAS ESTADOS UNIDOS:
Mad Catz garantiza al comprador original que este producto está libre de materiales y mano de obra durante la vigencia de la garantía. Esta garantía no cubre piezas consumibles, baterías o daños que ocurren en el envío o debido a mal uso, abuso o negligencia. Esta garantía es nula si el usuario ha modificado su producto (shell, PCB, o cualquier otro componente) o si su producto Mad Catz está en un dispositivo usado para fines ilegales o comerciales. Si un defecto cubierto por esta garantía ocurre durante el período de garantía, Mad Catz reparará o reemplazará el producto a su opción, con producto reparado o reemplazado de igual valor.
Corporation. Microsoft, Xbox, Xbox 360 and Xbox logos These and/or other marks are the marks of the Microsoft

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com