



K00121 KIT

Installation Instructions

Note: This kit will convert a C-900/C-970 bin to a C-950 bin or a C-910/C-980 bin to a C-960 bin.

1. Remove the gasket along the front of the bin. Note: C-970/980 only - remove the gasket from both sides of the bin.
2. Remove the #8 screws holding the current ice deflector. Save these screws, a total of 6 from a C-900/910 or a total of 12 from a C-970/980.
3. Remove the ice deflector.
4. Place the new ice deflector on the bin.
5. Fasten the ice deflector using the screws removed in step 2. If needed, use the two additional screws shipped with the kit. Note: C-970/980 only - seal the open screw holes in the bin sides with RTV sealant or with the screws removed in step 2.
6. Install the new gasket material along the front of the bin and also along both sides, if required.

Manitowoc Ice, Inc.

2110 South 26 Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA
Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879
Web Site - www.manitowocice.com

8009183
Rev. 05/30/01

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>