


furniture company

Item #: W52C2DW Assembly Instructions




For our most current instructions, to request missing, lost or broken parts, or for any other Customer Service issues, please visit our website at **www.walkeredison.com** or call us at 877-207-5906.

Revised 11/2010

General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The four main types of hardware used to assemble this product are: wood dowels, cam bolts and locks, bolts and screws.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




VI. A Phillips head screwdriver is required for the assembly of this product.



VII. Power tools should not be used to assemble this product.







Hardware List

| Α | | Ø8x30 | Large wood dowel | 12 | pcs |
|---|----------|---------------|-------------------|----|-----|
| В | | Ø6x30 | Small wood dowel | 18 | pcs |
| С | | Ø6x32 | Cam bolt | 22 | pcs |
| D | | Ø15x9.5 | Cam lock | 22 | pcs |
| E | -mm-B | Ø8x4x25 | Extra-large screw | 16 | pcs |
| F | | Ø7x2.5x12 | Flange screw | 28 | pcs |
| G | | Ø8x5x16 | Shelf support pin | 8 | pcs |
| Н | 6 | Ø24x21 | Handle | 4 | pcs |
| J | amman(3) | Ø9x5/32"x3/4" | Bolt | 4 | pcs |
| K | | Ø12x0.5 | Metal washer | 16 | pcs |
| L | | | Door stopper | 2 | pcs |
| M | | | Drawer stopper | 2 | pcs |
| N | < | Ø6x3x15 | Large screw | 4 | pcs |
| Р | (J) | Ø6x3x12 | Medium screw | 10 | pcs |
| Q | | Ø4x2x8 | Small screw | 16 | pcs |
| R | | | Glue tube | 1 | рс |
| S | | | Touch-up marker | 1 | рс |


The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.

Step 1







Insert large dowels (A) into side panels (1,2). Screw cam bolts (C) into side panels (1,2).



Insert small dowels (B) into panels (7,8) and slats (3,9). Insert large dowels (A) into slat (3). Attach door stoppers (L) to slat (3) using large screws (N). Attach drawer stopper (M) to slat (9) using medium screw (P).




Insert large dowels (A) into slat (6). Insert small dowels (B) into bottom panel (4). Screw cam bolt (C) into bottom panel (4).




tighten with a screwdriver. Screw leg (5) into bottom panel (4).

Step 5




Screw cam bolts (C) into bottom panel (4). Attach drawer stopper (M) to bottom panel (4) using medium screw (P).


Step 6




Join panels (7,8) together with slat (9). Use dowels as guides.




Attach the panel assembly from the previous step to bottom panel (4) using cam bolts and dowels as guides. Insert cam locks (D) into panels (7,8) and tighten with a screwdriver. *Note that two cam locks (D) will be inserted into each panel (7,8).*











Attach side panel (1) to the assembly from the previous step using cam bolts and dowels as guides. Insert cam locks (D) into panel (4) and slats (3,6). Tighten cam locks (D) with a screwdriver.




Attach side panel (2) to the opposite side of the assembly from Step 8 using cam bolts and dowels as guides. Insert cam locks (D) into panel (4) and slats (3,6). Tighten cam locks (D) with a screwdriver.


Step 11




Screw cam bolts (C) into top panel (10).









Insert cam locks (D) into the assembly from Step 10. Attach top panel (10) to the assembly using cam bolts and dowels as guides. Tighten cam locks (D) with a screwdriver.




Attach back panels (11,12) to the assembly from the previous step using flange screws (F). *Note that back panels (12) will overlap back panel (11).*






Secure glass panes (16) by attaching metal washers (K) to door frames (14,15) with small screws (Q). Note that the curve of metal washers (K) will arc into glass panes (16).




Attach drawer sides (18,19) to drawer back (20) using extra-large screws (E). Note that the thin grooves at the base of each drawer piece will align along the inside of the drawer assembly. Repeat this step for the second drawer.






Slide drawer bottom (21) into place along the thin grooves of the drawer assembly. Fit drawer front (17) into place. Repeat this step for the second drawer.


Step 18




Secure drawer front (17) to the drawer assembly using extra-large screws (E). Attach handle (H) to drawer front (17) using bolt (J). Repeat this step for the second drawer.




Attach doors (14,15) to the stand assembly using medium screws (P) at the hinges. Attach handles (H) to doors (14,15) using bolts (J).





Insert shelf support pins (G) into the stand assembly at the desired shelf heights. Place shelves (13) on shelf support pins (G).



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com