

## XM<sup>®</sup> SATELLITE DIGITAL AUDIO RECEIVER SYSTEM MODEL SRXM-001

# **INSTALLATION MANUAL**

# FOR USE WITH THE RADIO RECEIVER UNIT (RRU) MODEL XM-RCV



# INTRODUCTION

The Audiovox Electronics XM<sup>®</sup> Satellite Digital Audio Control And Receiver System (Model SRXM-001) was developed to allow the user to listen to a huge selection of programming supplied by a subscription to XM<sup>®</sup> Radio. (XM<sup>®</sup>-compatible antenna also required).

The Audiovox Electronics XM<sup>®</sup> Satellite Digital Audio Control And Receiver System is easily installed using the installation instructions herein, and is designed to work with the user's existing car stereo system through an unused FM frequency or the auxiliary audio inputs. The programming and use of this system is described in detail in the supplied Owner's Manual.

The Audiovox Electronics XM<sup>®</sup> Satellite Digital Audio Control and Receiver System comes with a satellite RADIO RECEIVER UNIT (RRU), a SATELLITE SYSTEM CONTROL UNIT (SCU), and a FM MODULATOR/CONTROL INTERFACE unit that allows the user to select an exact XM<sup>®</sup> Radio channel on the easy to read display. The controller is compact, pleasantly designed and can be mounted in the cab of the vehicle in numerous ways. This Installation Guide depicts typical installation scenarios.

It is important that the installer reads and understands all of the installation procedures for each of the components to be installed, either supplied with the Audiovox Electronics XM Satellite Digital Audio Control and Receiver System (Model SRXM-001) or equipment that is to be installed in conjunction with the system such as the XM<sup>®</sup> Antenna.

The Audiovox Electronics XM<sup>®</sup> Satellite Digital Audio Control and Receiver System (Model SRXM-001) comes with a 36 month limited warranty (see the back cover of the owner's manual for details)

## TRADEMARKS

XM® is a registered trademark of XM Satellite Radio. All Rights Reserved. www.xmradio.com

PRO.Fit<sup>®</sup> and VSM<sup>®</sup> are registered trademarks of Pro.Fit International. All rights reserved. www.pro-fit-intl.com

Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

# **INSTALLATION and WIRING PRECAUTIONS**

**1.** To prevent a short-circuit, Be sure to turn off the ignition and remove the negative (-) battery cable, prior to installation. Connect power wires last.

**NOTE:** If the SRXM-001 System is to be installed in a car that is equipped with an on-board drive or navigation computer, do not disconnect the battery cable. If the cable is disconnected, the computer memory may be lost. Under these conditions, use extra caution during installation not to cause a short circuit.


2. Do not install the unit in the following locations: Locations exposed to direct sunlight. Where hot air is discharged from the car heater. In areas subject to extreme temperatures.




- **3.** Incorrect installation may cause damage to the system. Mount the unit firmly in place, using the supplied brackets and screws.
- **4.** Be careful not to damage the car wiring.
- **5.** Be sure to use the supplied screws and washers.
- **6.** Be careful not to snag any wires when tightening screws.

### PACKING LIST SRXM-001 MAIN SYSTEM COMPONENTS


(NOTE: Components are not drawn to scale.)




## TYPICAL FM MODULATED SYSTEM INSTALLATION



### TYPICAL AUXILLARY AUDIO SYSTEM INSTALLATION



### TYPICAL FM MODULATED INSTALLATION for SRXM-001 SYSTEM COMPONENT LAYOUT




### SYSTEM INSTALLATION


### RADIO RECEIVER UNIT (RRU)

### **PROCEDURE for HORIZONTAL INSTALLATION of the RRU**

1. Attach the mounting brackets to each side of the RRU, using the 4 Phillips Round Head Screws (4mm x 8mm).




**2.** Determine the mounting location and drill 4x 1/8" (4mm) mounting holes.




**NOTE**: If mounting surface is carpeted, use caution when drilling holes to prevent drill bit from catching on carpet. Cut holes in carpet before drilling into subsurface.

 Mount the unit in place, using 4 Self-tapping Screws (5mm x 15mm), w/Flat Washers and Lock Washers. Use RTV (silicone sealer) on screw threads or around the holes to prevent moisture intrusion.




### **PROCEDURE for VERTICAL INSTALLATION of the RRU**

1. Attach a mounting bracket to each side of the RRU, using the 4 Phillips Round Head Screws (4mm x 8mm).




**2.** Determine the mounting location and drill  $4 \times 1/8^{\circ}$  (4mm) mounting holes.




**NOTE:** If mounting surface is carpeted, use caution when drilling holes to prevent drill bit from catching on carpet. Cut holes in carpet before drilling into subsurface.

 Mount the unit in place, using 4 Self-tapping Screws (5mm x 15mm), w/Flat Washers and Lock Washers. Use RTV (silicone sealer) on screw threads or around the holes to prevent moisture intrusion.




#### **PROCEDURE** for the MOUNTING of the RRU UNDER THE REAR DECK


1. Attach the mounting brackets to each side of the RRU, using the 4 Phillips Round Head Screws (4mm x 8mm).



**2.** Determine the mounting location and drill four 4mm mounting holes.



**3.** Mount the unit in place, using 4 Self-tapping Screws (5mm x 15mm), w/Flat Washers and Lock Washers.



### INSTALLING THE SATELLITE SYSTEM CONTROL UNIT (SCU)

# PROCEDURE for a TYPICAL INSTALLATION of the SCU USING HOOK & LOOP ADHESIVE TAPE (SUPPLIED)

- 1. Determine where the SCU is to be located (flat surface) NOTE: The chosen position must allow a clear view of the display and easy access to the controls for both the Driver and Passenger of the vehicle.
- 2. Using an Alcohol Swab, clean and dry the entire surface area where the SCU is to be mounted and the back surface of the SCU.
- 3. Remove the protective paper from the back of the first piece of the supplied Hook & Loop Adhesive Tape (Loop side) and apply it to the mounting surface (see Figure 1.)
- 4. Remove the protective paper from the back of the second piece of the supplied Hook & Loop Adhesive Tape (Hook side) and apply it to the back side of the SCU (see Figure 2.). Position the SCU cable in the appropriate directional channel on the back of the SCU so that the back surface is flat (see Figure 3.).
- 5. Carefully press the SCU into place.




Figure 1.



Figure 2.




Figure 3.

**NOTE:** Do not install the unit in the following locations: In Locations exposed to direct sunlight. Where hot air is discharged from the car heater. In areas subject to extreme temperatures.

#### PROCEDURE FOR A TYPICAL BRACKET INSTALLATION OF THE SCU

#### (Bracket not supplied)

Audiovox suggests this type of installation over the Hook & Loop type of installation though the Hook & Loop installation (if done correctly) is a secure and sufficient mounting option. Installation of the SCU using a bracket results in a professional, factory-installed look, without visibly damaging the interior of the vehicle. When combined with the optional Trim Ring (model #SAT-PF) the results are further cosmetically enhanced. There are several types of brackets available to accomplish this type of installation.


The installation procedure that follows, illustrates the use of a Pro.Fit<sup>®</sup> mounting bracket. Audiovox has found that the Pro.Fit<sup>®</sup> VSM<sup>®</sup> line of mounting brackets are easy to install and compliments the installation of the SCU as well as being a perfect match to the optional Trim Ring (model #SAT-PF). Pro.Fit<sup>®</sup> VSM<sup>®</sup> mounting bracket reduce the installation liability while maintaining the resale value of a car because of the professional fit, professional look and safe design.

Currently Pro.Fit<sup>®</sup> VSM<sup>®</sup> offers hundreds of brackets, covering most popular cars, vans, and trucks. Stepby-step instructions and technical support are available for every mount and application.

After the proper mounting bracket has been selected and installed using the Original Manufacturers installation instructions, proceed with the following steps:

- 1. Feed the SCU Cable through the hole in the Trim Ring (optional) and connect it to the RF Modulator.
- 2. Using the Phillips Head Screws and the External Tooth Lock Washers (supplied),
- Mount the SCU to the bracket as shown in the Figure below.
- **NOTE:** Use caution not to over tighten the screws into the back of the SCU as this may cause damage to the unit.
- NOTE: Do not install the unit in the following locations:

In Locations exposed to direct sunlight. Where hot air is discharged from the car heater. In areas subject to extreme temperatures.



Upon completion of the SCU installation and before the XM radio is activated a test of the system should be performed. To verify that the SRXM-001 system and the antenna have been installed correctly and are functioning, select and listen to CH 1. (XM preview channel). If there is no power to the SCU check that all connections have been made and that fuses are good. If there is no signal present, make sure that the antenna is unobstructed (move vehicle) and check the antenna cable connection to the RF Modulator. For a detailed trouble-shooting guide, refer to the Owner's Manual.

© Copyright 2001 Audiovox Electronics Corp. 150 Marcus Blvd. Hauppauge, NY 11788

128-6213A

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com