



HARDENED PUSHRODS

CATALOG #9629, #9630, #9631, #9632, #9633, #9637, & 9638

(See Description Below)

INSTRUCTIONS

- **PLEASE** study these instructions carefully before installing your new pushrods. If you have any questions or problems, do not hesitate to contact our **Technical Hotline at: 1-800-416-8628**, 7 am - 5 pm, Monday-Friday, Pacific Standard Time or e-mail us at edelbrock.edelbrock.com.
- **DESCRIPTIONS**
 - #9629 - For Small-Block Chevrolet V8s, 5/16" diameter (+.100" Longer Than Stock)
 - #9630 - For Small-Block Chevrolet V8s, 5/16" diameter (standard length)
 - #9631 - For Big-Block Chevrolet V8s, 5/16" diameter (standard length)
 - #9632 - For Small-Block Ford V8s, 5/16" diameter (standard length)
 - #9633 - For 351 M/400 Ford V8s, 5/16" diameter (standard length)
 - #9637 - For 343-401 AMC V8s, 5/16" diameter (standard length)
 - #9638 - For Chrysler Magnum 5.2L & 5.9L V8s, 5/16" diameter (standard length)
- **PUSHRODS:** These pushrods are manufactured from case hardened tubing. They are designed to be used in engines with or without hardened steel guideplates. Guideplate slots must be correct width for 5/16" pushrods. Lube all parts thoroughly upon installation. Use moly lube (preferred) or motor oil.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>