

INSTALL INSTRUCTIONS C-VS-1200-DUR 2004-2008 DODGE DURANGO

TOOLS REQUIRED:

Cordless Screwdriver
Power drill with 1/8" drill bit

HARDWARE:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
8	#10 x 3/4" Sheet metal screws	GSM33195

SUB ASSEMBLY:

1. Run wiring for control heads to OEM console area.

INSTALLATION:

1. Mount Vehicle Specific Console :

- Place console between dashboard and OEM armrest. *Works best if console is carefully slid in from side.*
- Vehicle Specific console will rest on top of OEM console.
- Mark and pre-drill console.
- Screw Vehicle specific console directly to OEM console.

Note: Console can be centered off the Dash, or centered off the OEM Armrest. The OEM Traction control switch and 12 volt socket can be relocated to the mounting plate provided (Installer must lengthen wires)



Shown with console model options: C-SP-3B, C-CH-2, C-ML-LP2 and Equipment Bracket.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>