

## INSTALL INSTRUCTIONS C-STB-CHGR 2006-2008 DODGE CHARGER SPARE TIRE BRACKET

### TOOLS REQUIRED:

Ratcheting Wrench

Metric/Standard Socket Sets

**HARDWARE:** *(Uses OEM hardware for mounting bracket)*

### Always!

- ❖ Read all instructions before installing any Havis-Shields Equipment Corp products.
- ❖ Check for obstructions (Wire, brake lines, fuel tank, etc.) before drilling any holes!
- ❖ Use hardware provided with install kit.



Attach C-STB-CHGR mount, as shown above, using OEM hardware



Slide OEM bolt through jack stand, then through C-STB-CHGR.



Re-attach "wing" nut onto bolt and tighten.



Completed installation shown with optional C-TTB-CHGR slide out radio tray

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>